

Where Used: Part Number 0317230

Model Name	Diagram
115JEEOB 1995	JET PUMP
115JEERA 1994	JET PUMP
115TJEDB 1996	JET PUMP
115TJEOA 1995	JET PUMP
115TJEUC 1997	JET PUMP
50202C 1972	GEARCASE 50 HP MANUAL START
50202C 1972	GEARCASE ELECTRIC START
50203C 1972	GEARCASE 50 HP MANUAL START
50203C 1972	GEARCASE ELECTRIC START
50272C 1972	GEARCASE 50 HP MANUAL START
50272C 1972	GEARCASE ELECTRIC START
50273C 1972	GEARCASE 50 HP MANUAL START
50273C 1972	GEARCASE ELECTRIC START
50302R 1973	GEARCASE MANUAL START
50302R 1973	GEARCASE ELECTRIC START
50303R 1973	GEARCASE MANUAL START
50303R 1973	GEARCASE ELECTRIC START
50372R 1973	GEARCASE MANUAL START
50372R 1973	GEARCASE ELECTRIC START
50373R 1973	GEARCASE MANUAL START
50373R 1973	GEARCASE ELECTRIC START
50442M 1974	GEARCASE
50443M 1974	GEARCASE
50472M 1974	GEARCASE
50473M 1974	GEARCASE
50902C 1979	GEARCASE ROPE START
50903C 1979	GEARCASE ROPE START
50ES72C 1972	GEARCASE 50 HP MANUAL START
50ES72C 1972	GEARCASE ELECTRIC START
50ES73R 1973	GEARCASE MANUAL START
50ES73R 1973	GEARCASE ELECTRIC START
50ES74M 1974	GEARCASE
50ESL72C 1972	GEARCASE 50 HP MANUAL START

50ESL72C 1972	GEARCASE ELECTRIC START
50ESL73R 1973	GEARCASE MANUAL START
50ESL73R 1973	GEARCASE ELECTRIC START
50ESL74M 1974	GEARCASE
50R72C 1972	GEARCASE 50 HP MANUAL START
50R72C 1972	GEARCASE ELECTRIC START
50R73R 1973	GEARCASE MANUAL START
50R73R 1973	GEARCASE ELECTRIC START
50R79C 1979	GEARCASE, ROPE START
50RL72C 1972	GEARCASE 50 HP MANUAL START
50RL72C 1972	GEARCASE ELECTRIC START
50RL73R 1973	GEARCASE MANUAL START
50RL73R 1973	GEARCASE ELECTRIC START
50RL79C 1979	GEARCASE, ROPE START
55974C 1979	GEARCASE ROPE START
55975C 1979	GEARCASE ROPE START
55E79C 1979	GEARCASE, ROPE START
55EL79C 1979	GEARCASE, ROPE START
65372R 1973	GEARCASE
65373R 1973	GEARCASE
65ES72S 1972	GEARCASE
65ES73R 1973	GEARCASE
65ESL72S 1972	GEARCASE
65ESL73R 1973	GEARCASE
70442M 1974	GEARCASE
70443M 1974	GEARCASE
70472M 1974	GEARCASE
70473M 1974	GEARCASE
70572B 1975	GEARCASE FOR MODELS 70572B,70573B
70572B 1975	GEARCASE FOR MODELS 70572E,70573E
70572E 1975	GEARCASE FOR MODELS 70572B,70573B
70572E 1975	GEARCASE FOR MODELS 70572E,70573E
70573B 1975	GEARCASE FOR MODELS 70572B,70573B
70573B 1975	GEARCASE FOR MODELS 70572E,70573E
70573E 1975	GEARCASE FOR MODELS 70572B,70573B

70573E 1975	GEARCASE FOR MODELS 70572E,70573E
70673D 1976	GEARCASE
70873C 1978	GEARCASE - 20" TRANSOM
70973R 1979	GEARCASE-20" TRANSOM
70EL76D 1976	GEARCASE
70EL77S 1977	GEARCASE-20"TRANSOM
70EL78C 1978	GEARCASE-20 INCH TRANSOM
70EL79R 1979	GEARCASE-20" TRANSOM
70ES74M 1974	GEARCASE
70ES75B 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ES75B 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ES75E 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ES75E 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESL74M 1974	GEARCASE
70ESL75B 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ESL75B 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESL75E 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ESL75E 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESLR74M 1974	GEARCASE
75542B 1975	GEARCASE - 20" TRANSOM
75543B 1975	GEARCASE - 20" TRANSOM
75642D 1976	GEARCASE-20" TRANSOM
75643D 1976	GEARCASE-20" TRANSOM
75842C 1978	GEARCASE - 20" TRANSOM
75843C 1978	GEARCASE - 20" TRANSOM
75942R 1979	GEARCASE-20" TRANSOM
75943R 1979	GEARCASE-20" TRANSOM
75ELR76D 1976	GEARCASE-20" TRANSOM
75ELR77S 1977	GEARCASE-20"TRANSOM
75ELR78C 1978	GEARCASE-20 INCH TRANSOM
75ELR79R 1979	GEARCASE-20" TRANSOM
75ER76D 1976	GEARCASE-20" TRANSOM
75ER77S 1977	GEARCASE-20"TRANSOM
75ER78C 1978	GEARCASE-20 INCH TRANSOM
75ER79R 1979	GEARCASE-20" TRANSOM

75ESLR75B 1975	GEARCASE-20" TRANSOM
75ESR75B 1975	GEARCASE-20" TRANSOM
90JEEOB 1995	JET PUMP
90JEERA 1994	JET PUMP
AM55RSLD 1999	GEARCASE
BE50DTLEDC 1996	GEARCASE
BE50DTLEUR 1997	GEARCASE
BE60ELEDR 1996	GEARCASE
BE60ELEUA 1997	GEARCASE
BE60TLECM 1998	GEARCASE
BE60TLEDR 1996	GEARCASE
BE60TLEUA 1997	GEARCASE
BE70ELECB 1998	GEARCASE
BE70ELEDA 1996	GEARCASE
BE70ELEUM 1997	GEARCASE
BE70TLECB 1998	GEARCASE
BE70TLEDA 1996	GEARCASE
BE70TLEUM 1997	GEARCASE
BJ50DTLEDC 1996	GEARCASE
BJ50DTLEUR 1997	GEARCASE
BJ60ELEDR 1996	GEARCASE
BJ60ELEUA 1997	GEARCASE
BJ60TLECM 1998	GEARCASE
BJ60TLEDR 1996	GEARCASE
BJ60TLEUA 1997	GEARCASE
BJ70ELECB 1998	GEARCASE
BJ70ELEDA 1996	GEARCASE
BJ70ELEUM 1997	GEARCASE
BJ70PLEEE 1999	GEARCASE
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
BJ70TLECB 1998	GEARCASE
BJ70TLEDA 1996	GEARCASE
BJ70TLEUM 1997	GEARCASE
E40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY

E40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40DELSDA	GEARCASE
E40DELSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DELSOR	GEARCASE
E40DELSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DELSRC	GEARCASE
E40DELSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DGTLAGA	07-1_GEARCASE, F-Type
E40DGTLAGB	07-1_GEARCASE, F-Type
E40DGTLAGC	07-1_GEARCASE, F-Type
E40DGTLAGD	07-1_GEARCASE, F-Type
E40DGTLAGF	07-1_GEARCASE, F-Type
E40DGTLAGG	07-1_GEARCASE, F-Type
E40DHGLAGA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGC - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGD - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGF - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGG - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAAA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLABA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAFA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAFB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAGA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAGB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAGC - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DHLINS - ITALY ONLY	GEARCASE, F-Type
E40DHSLAAA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLABA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAFA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAFB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGB - ITALY ONLY	07-1_GEARCASE, F-Type

E40DHSLAGC - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGD - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGF - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGG - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DHSLINS - ITALY ONLY	GEARCASE, F-Type
E40DPGLAGA	07-1_GEARCASE, F-Type
E40DPGLAGB	07-1_GEARCASE, F-Type
E40DPGLAGC	07-1_GEARCASE, F-Type
E40DPGLAGD	07-1_GEARCASE, F-Type
E40DPGLAGF	07-1_GEARCASE, F-Type
E40DPGLAGG	07-1_GEARCASE, F-Type
E40DPLAAA	07-1_GEARCASE, F-Type
E40DPLABA	07-1_GEARCASE, F-Type
E40DPLAFA	07-1_GEARCASE, F-Type
E40DPLAFB	07-1_GEARCASE, F-Type
E40DPLAGA	07-1_GEARCASE, F-Type
E40DPLIIS	GEARCASE, F-Type
E40DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLINC	GEARCASE, F-Type
E40DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLISD	GEARCASE
E40DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLISF	GEARCASE
E40DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSCB	GEARCASE
E40DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSDA	GEARCASE
E40DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSEE	GEARCASE
E40DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSOR	GEARCASE
E40DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DPLSRC	GEARCASE
E40DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES

E40DPLSUM	GEARCASE
E40DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRGLAGA	07-1_GEARCASE, F-Type
E40DRGLAGB	07-1_GEARCASE, F-Type
E40DRGLAGC	07-1_GEARCASE, F-Type
E40DRGLAGD	07-1_GEARCASE, F-Type
E40DRGLAGF	07-1_GEARCASE, F-Type
E40DRGLAGG	07-1_GEARCASE, F-Type
E40DRLAAA	07-1_GEARCASE, F-Type
E40DRLABA	07-1_GEARCASE, F-Type
E40DRLAFA	07-1_GEARCASE, F-Type
E40DRLAFB	07-1_GEARCASE, F-Type
E40DRLAGA	07-1_GEARCASE, F-Type
E40DRLIIS	GEARCASE, F-Type
E40DRLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLINC	GEARCASE, F-Type
E40DRLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLISD	GEARCASE
E40DRLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLISF	GEARCASE
E40DRLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSCB	GEARCASE
E40DRLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSDA	GEARCASE
E40DRLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSEE	GEARCASE
E40DRLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSOR	GEARCASE
E40DRLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DRLSRC	GEARCASE
E40DRLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DRLSUM	GEARCASE
E40DRLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRMLABA	07-1_GEARCASE, F-Type
E40DRMLAGA	07-1_GEARCASE, F-Type

E40DRMLAGB	07-1_GEARCASE, F-Type
E40DRMLAGC	07-1_GEARCASE, F-Type
E40DRMLAGD	07-1_GEARCASE, F-Type
E40DRMLAGF	07-1_GEARCASE, F-Type
E40DRMLAGG	07-1_GEARCASE, F-Type
E40DSLAAA	07-1_GEARCASE, F-Type
E40DSLABA	07-1_GEARCASE, F-Type
E40DSLafa	07-1_GEARCASE, F-Type
E40DSLAFB	07-1_GEARCASE, F-Type
E40DSLAGA	07-1_GEARCASE, F-Type
E40DSLAGB	07-1_GEARCASE, F-Type
E40DSLAGC	07-1_GEARCASE, F-Type
E40DSLAGD	07-1_GEARCASE, F-Type
E40DSLAGF	07-1_GEARCASE, F-Type
E40DSLAGG	07-1_GEARCASE, F-Type
E40DSLIIA	GEARCASE, F-Type
E40DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLINM	GEARCASE, F-Type
E40DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLISF	GEARCASE
E40DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLISR	GEARCASE
E40DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLSCS	GEARCASE
E40DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLSEC	GEARCASE
E40DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLAAA	07-1_GEARCASE, F-Type
E40DTLABA	07-1_GEARCASE, F-Type
E40DTLafa	07-1_GEARCASE, F-Type
E40DTLAFB	07-1_GEARCASE, F-Type
E40DTLAGA	07-1_GEARCASE, F-Type
E40DTLIIA	GEARCASE, F-Type
E40DTLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLINM	GEARCASE, F-Type

E40DTLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLISF	GEARCASE
E40DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLISR	GEARCASE
E40DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLSCS	GEARCASE
E40DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLSEC	GEARCASE
E40DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40WREES 1999	GEARCASE
E40WRLEES 1999	GEARCASE
E40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRYEES 1999	GEARCASE
E40WRY SIR commercial, rope start, 25 in shaft 2001	GEARCASE
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
E45RCCDS 1986	GEARCASE
E45RCCUC 1987	GEARCASE
E45RCE 1989	GEARCASE
E45RCEIA 1991	GEARCASE
E45RCENM 1992	GEARCASE
E45RCEOD 1995	GEARCASE
E45RCERE 1994	GEARCASE
E45RCESR 1990	GEARCASE

E45RCETB 1993	GEARCASE
E45RCLCDS 1986	GEARCASE
E45RCLCUC 1987	GEARCASE
E45RCLE 1989	GEARCASE
E45RCLEDS 1996	GEARCASE
E45RCLEIA 1991	GEARCASE
E45RCLENM 1992	GEARCASE
E45RCLEOD 1995	GEARCASE
E45RCLERE 1994	GEARCASE
E45RCLESR 1990	GEARCASE
E45RCLETB 1993	GEARCASE
E45RCLEUC 1997	GEARCASE
E45WMLE 1989	GEARCASE
E45WMLEIA 1991	GEARCASE
E45WMLENM 1992	GEARCASE
E45WMLESR 1990	GEARCASE
E50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50BECIC 1981	GEARCASE, ROPE START
E50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50BELCIC 1981	GEARCASE, ROPE START
E50DGTLAGA	07-1_GEARCASE, F-Type
E50DGTLAGB	07-1_GEARCASE, F-Type
E50DGTLAGC	07-1_GEARCASE, F-Type
E50DGTLAGD	07-1_GEARCASE, F-Type
E50DGTLAGF	07-1_GEARCASE, F-Type
E50DGTLAGG	07-1_GEARCASE, F-Type
E50DPGLAGA	07-1_GEARCASE, F-Type
E50DPGLAGB	07-1_GEARCASE, F-Type
E50DPGLAGC	07-1_GEARCASE, F-Type
E50DPGLAGD	07-1_GEARCASE, F-Type
E50DPGLAGF	07-1_GEARCASE, F-Type
E50DPGLAGG	07-1_GEARCASE, F-Type
E50DPLAAA	07-1_GEARCASE, F-Type
E50DPLABA	07-1_GEARCASE, F-Type
E50DPLAFA	07-1_GEARCASE, F-Type

E50DPLAFB	07-1_GEARCASE, F-Type
E50DPLAGA	07-1_GEARCASE, F-Type
E50DPLIIS	GEARCASE, F-Type
E50DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLINC	GEARCASE, F-Type
E50DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLISD	GEARCASE
E50DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLISF	GEARCASE
E50DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSCB	GEARCASE
E50DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSDA	GEARCASE
E50DPLSEE	GEARCASE
E50DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSOR	GEARCASE
E50DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E50DPLSRC	GEARCASE
E50DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E50DPLSUM	GEARCASE
E50DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DRMLAFA	07-1_GEARCASE, F-Type
E50DRMLAFB	07-1_GEARCASE, F-Type
E50DSLAAA	07-1_GEARCASE, F-Type
E50DSLABA	07-1_GEARCASE, F-Type
E50DSLafa	07-1_GEARCASE, F-Type
E50DSLAFB	07-1_GEARCASE, F-Type
E50DSLAGA	07-1_GEARCASE, F-Type
E50DSLAGB	07-1_GEARCASE, F-Type
E50DSLAGC	07-1_GEARCASE, F-Type
E50DSLAGD	07-1_GEARCASE, F-Type
E50DSLAGF	07-1_GEARCASE, F-Type
E50DSLAGG	07-1_GEARCASE, F-Type
E50DSLIIA	GEARCASE, F-Type
E50DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F

E50DSLINM	GEARCASE, F-Type
E50DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLISF	GEARCASE
E50DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLISR	GEARCASE
E50DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLSCS	GEARCASE
E50DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLSEC	GEARCASE
E50DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLAAA	07-1_GEARCASE, F-Type
E50DTLABA	07-1_GEARCASE, F-Type
E50DTLAFA	07-1_GEARCASE, F-Type
E50DTLAFB	07-1_GEARCASE, F-Type
E50DTLAGA	07-1_GEARCASE, F-Type
E50DTLECA 1998	GEARCASE
E50DTLEDC 1996	GEARCASE
E50DTLEOS 1995	GEARCASE
E50DTLEUR 1997	GEARCASE
E50DTLIIA	GEARCASE, F-Type
E50DTLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLINM	GEARCASE, F-Type
E50DTLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLISF	GEARCASE
E50DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLISR	GEARCASE
E50DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLSCS	GEARCASE
E50DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLSEC	GEARCASE
E50DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50ELED 1996	GEARCASE
E50ELEOS 1995	GEARCASE
E50ELEUR 1997	GEARCASE
E50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY

E50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50TTLECA 1998	GEARCASE
E50TTLEDC 1996	GEARCASE
E50TTLEOS 1995	GEARCASE
E50TTLEUR 1997	GEARCASE
E55MJRLAAA	07-1_GEARCASE, F-Type (MJRL)
E55MJRLABA	07-1_GEARCASE, F-Type (MJRL)
E55MJRLABB	07-1_GEARCASE, F-Type (MJRL)
E55MJRLABF	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFA	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFB	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFC	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFD	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFF	07-1_GEARCASE, F-Type (MJRL)
E55MJRLIIM	GEARCASE, F-Type (MJRL)
E55MJRLIIM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLINB	GEARCASE, F-Type (MJRL)
E55MJRLINB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLISA	GEARCASE
E55MJRLISA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLSCC	GEARCASE
E55MJRLSCC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLSEF	GEARCASE
E55MJRLSEF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLSER	GEARCASE
E55MJRLSER - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MRLAAA	07-1_GEARCASE, F-Type (MRL)
E55MRLABA	07-1_GEARCASE, F-Type (MRL)
E55MRLABB	07-1_GEARCASE, F-Type (MRL)
E55MRLABF	07-1_GEARCASE, F-Type (MRL)
E55MRLAFA	07-1_GEARCASE, F-Type (MRL)
E55MRLAFB	07-1_GEARCASE, F-Type (MRL)
E55MRLAFC	07-1_GEARCASE, F-Type (MRL)
E55MRLAFD	07-1_GEARCASE, F-Type (MRL)
E55MRLAFF	07-1_GEARCASE, F-Type (MRL)

E55MRLIIM	GEARCASE, F-Type (MRL)
E55MRLINB	GEARCASE, F-Type (MRL)
E55MRLINB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLISA	GEARCASE
E55MRLISA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSCC	GEARCASE
E55MRLSCC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSEF	GEARCASE
E55MRLSEF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSER	GEARCASE
E55MRLSER - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55RCIM 1981	GEARCASE, ROPE START
E55RLCSA 1980	GEARCASE, ROPE START
E55RSLC 1997	GEARCASE
E55RSLG 1995	GEARCASE
E55RSLN 1983	GEARCASE
E55RSLN-2 1983	GEARCASE
E55RSLW 1996	GEARCASE
E55RSN 1983	GEARCASE
E55RSN-2 1983	GEARCASE
E55RSYN 1983	GEARCASE
E55RSYN-2 1983	GEARCASE
E55RWLDCD 1986	GEARCASE
E55RWLCOS 1985	GEARCASE
E55RWLCRD 1984	GEARCASE
E55RWLCUC 1987	GEARCASE
E55RWLE 1989	GEARCASE
E55RWLEIA 1991	GEARCASE
E55RWLENM 1992	GEARCASE
E55RWLERE 1994	GEARCASE
E55RWLESR 1990	GEARCASE
E55RWLETB 1993	GEARCASE
E55TLCIM 1981	GEARCASE, ROPE START
E55WREES 1999	GEARCASE
E55WRLEES 1999	GEARCASE

E55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E55WRYEES 1999	GEARCASE
E55WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
E60DGTLAGA	07-1_GEARCASE, F-Type
E60DGTLAGB	07-1_GEARCASE, F-Type
E60DGTLAGC	07-1_GEARCASE, F-Type
E60DGTLAGD	07-1_GEARCASE, F-Type
E60DGTLAGF	07-1_GEARCASE, F-Type
E60DGTLAGG	07-1_GEARCASE, F-Type
E60DPGLAGA	07-1_GEARCASE, F-Type
E60DPGLAGB	07-1_GEARCASE, F-Type
E60DPGLAGC	07-1_GEARCASE, F-Type
E60DPGLAGD	07-1_GEARCASE, F-Type
E60DPGLAGF	07-1_GEARCASE, F-Type
E60DPGLAGG	07-1_GEARCASE, F-Type
E60DPLAAA	07-1_GEARCASE, F-Type
E60DPLABA	07-1_GEARCASE, F-Type
E60DPLAFA	07-1_GEARCASE, F-Type
E60DPLAFB	07-1_GEARCASE, F-Type
E60DPLAGA	07-1_GEARCASE, F-Type
E60DPLIIS	GEARCASE, F-Type
E60DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLINC	GEARCASE, F-Type
E60DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLISD	GEARCASE
E60DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLISF	GEARCASE
E60DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSCB	GEARCASE
E60DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F

E60DPLSDA	GEARCASE
E60DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSEE	GEARCASE
E60DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSUM	GEARCASE
E60DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLAAA	07-1_GEARCASE, F-Type
E60DSLABA	07-1_GEARCASE, F-Type
E60DSLafa	07-1_GEARCASE, F-Type
E60DSLafb	07-1_GEARCASE, F-Type
E60DSLaga	07-1_GEARCASE, F-Type
E60DSLagb	07-1_GEARCASE, F-Type
E60DSLagc	07-1_GEARCASE, F-Type
E60DSLagd	07-1_GEARCASE, F-Type
E60DSLagf	07-1_GEARCASE, F-Type
E60DSLagg	07-1_GEARCASE, F-Type
E60DSLIIA	GEARCASE, F-Type
E60DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLINM	GEARCASE, F-Type
E60DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLISF	GEARCASE
E60DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLISR	GEARCASE
E60DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLSCS	GEARCASE
E60DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLSEC	GEARCASE
E60DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLAAA	07-1_GEARCASE, F-Type
E60DTLABA	07-1_GEARCASE, F-Type
E60DTLafa	07-1_GEARCASE, F-Type
E60DTlafb	07-1_GEARCASE, F-Type
E60DTLAGA	07-1_GEARCASE, F-Type
E60DTLIIA	GEARCASE, F-Type
E60DTLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F

E60DTLINM	GEARCASE, F-Type
E60DTLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLISF	GEARCASE
E60DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLISR	GEARCASE
E60DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLSCS	GEARCASE
E60DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLSEC	GEARCASE
E60DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60ECIA 1981	GEARCASE, ROPE START
E60ECIH 1981	GEARCASE, ROPE START
E60ECSR 1980	GEARCASE, ROPE START
E60ELCDS 1986	GEARCASE - 20" MODELS
E60ELCEA 1989	GEARCASE
E60ELCIA 1981	GEARCASE, ROPE START
E60ELCIH 1981	GEARCASE, ROPE START
E60ELCSR 1980	GEARCASE, ROPE START
E60ELCUC 1987	GEARCASE - 20" MODELS
E60ELEDR 1996	GEARCASE
E60ELEIB 1991	GEARCASE
E60ELENE 1992	GEARCASE
E60ELEOC 1995	GEARCASE
E60ELERS 1994	GEARCASE
E60ELERV 1994	GEARCASE
E60ELES M 1990	GEARCASE
E60ELET D 1993	GEARCASE
E60ELEUA 1997	GEARCASE
E60TLCDS 1986	GEARCASE - 20" MODELS
E60TLCEA 1989	GEARCASE
E60TLCIA 1981	GEARCASE, ROPE START
E60TLCIH 1981	GEARCASE, ROPE START
E60TLCUC 1987	GEARCASE - 20" MODELS
E60TLECM 1998	GEARCASE
E60TLEDR 1996	GEARCASE

E60TLEIB 1991	GEARCASE
E60TLENE 1992	GEARCASE
E60TLEOC 1995	GEARCASE
E60TLERS 1994	GEARCASE
E60TLERV 1994	GEARCASE
E60TLESM 1990	GEARCASE
E60TLETD 1993	GEARCASE
E60TLEUA 1997	GEARCASE
E60TTLCEA 1989	GEARCASE
E60TTLECM 1998	GEARCASE
E60TTLEDR 1996	GEARCASE
E60TTLEIB 1991	GEARCASE
E60TTLENE 1992	GEARCASE
E60TTLEOC 1995	GEARCASE
E60TTLERS 1994	GEARCASE
E60TTLERV 1994	GEARCASE
E60TTLESM 1990	GEARCASE
E60TTLETD 1993	GEARCASE
E60TTLEUA 1997	GEARCASE
E60WDRLSOS	GEARCASE
E60WDRLSOS - FR	07-1_BOÎTIER D'ENGRENAGES
E60WDRYSOS	GEARCASE
E60WDRYSOS - FR	07-1_BOÎTIER D'ENGRENAGES
E65RSLC 1995	GEARCASE
E65RSLM 1996	GEARCASE
E65RSLZ2 1997	GEARCASE
E65RWLCDR 1986	GEARCASE
E65RWLCOC 1985	GEARCASE
E65RWLCRS 1984	GEARCASE
E65TELCDR 1986	GEARCASE
E65TELCOC 1985	GEARCASE
E65TELCRS 1984	GEARCASE
E65WDRLIIA	GEARCASE, F-Type
E65WDRLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLINM	GEARCASE, F-Type

E65WDRLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLISF	GEARCASE
E65WDRLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLISR	GEARCASE
E65WDRLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLSCS	GEARCASE
E65WDRLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLSEC	GEARCASE
E65WDRLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYIIA	GEARCASE, F-Type
E65WDRYIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYINM	GEARCASE, F-Type
E65WDRYINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYISF	GEARCASE
E65WDRYISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYISR	GEARCASE
E65WDRYISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYSCS	GEARCASE
E65WDRYSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYSEC	GEARCASE
E65WDRYSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WELEES 1999	GEARCASE
E65WELSIR Commercial, elec start, 20 in shaft 2001	GEARCASE
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
E65WMLCDR 1986	GEARCASE
E65WMLCOC 1985	GEARCASE
E65WMLCUA 1987	GEARCASE
E65WMLEIB 1991	GEARCASE
E65WMLENE 1992	GEARCASE
E65WMLEOC 1995	GEARCASE
E65WMLERS 1994	GEARCASE
E65WMLISM 1990	GEARCASE
E65WMLSTD 1993	GEARCASE
E65WMLZ 1989	GEARCASE
E65WRLEEO 1999	GEARCASE

E65WRLEES 1999	GEARCASE
E65WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
E65WRYEEO 1999	GEARCASE
E65WRYEES 1999	GEARCASE
E65WRY SIR commercial, rope start, 22.5 in shaft 2001	GEARCASE
E65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
E65WTLCOC 1985	GEARCASE
E65WTLCRS 1984	GEARCASE
E70ELCCA 1988	GEARCASE
E70ELCDC 1986	GEARCASE
E70ELCEM 1989	GEARCASE
E70ELCIH 1981	GEARCASE - 20" TRANSOM
E70ELCIM 1981	GEARCASE - 20" TRANSOM
E70ELCNB 1982	GEARCASE - 20" TRANSOM
E70ELCOS 1985	GEARCASE - 20" MODELS
E70ELCRD 1984	GEARCASE - 20" MODELS
E70ELCSA 1980	GEARCASE-20" TRANSOM
E70ELCTE 1983	GEARCASE - 20" TRANSOM
E70ELCUR 1987	GEARCASE
E70ELEIE 1991	GEARCASE
E70ELEND 1992	GEARCASE
E70ELEOR 1995	GEARCASE
E70ELERC 1994	GEARCASE
E70ELERV 1994	GEARCASE
E70ELESB 1990	GEARCASE
E70ELETS 1993	GEARCASE
E70TLCCA 1988	GEARCASE
E70TLCDC 1986	GEARCASE
E70TLCEM 1989	GEARCASE
E70TLCIM 1981	GEARCASE - 20" TRANSOM
E70TLCNB 1982	GEARCASE - 20" TRANSOM
E70TLCOS 1985	GEARCASE - 20" MODELS
E70TLCRD 1984	GEARCASE - 20" MODELS
E70TLCTE 1983	GEARCASE - 20" TRANSOM

E70TLCUR 1987	GEARCASE
E70TLECB 1998	GEARCASE
E70TLEDA 1996	GEARCASE
E70TLEIE 1991	GEARCASE
E70TLEND 1992	GEARCASE
E70TLEOR 1995	GEARCASE
E70TLERC 1994	GEARCASE
E70TLERV 1994	GEARCASE
E70TLESB 1990	GEARCASE
E70TLETS 1993	GEARCASE
E70TLEUM 1997	GEARCASE
E70TTLEIE 1991	GEARCASE
E70TTLEND 1992	GEARCASE
E70TTLEOR 1995	GEARCASE
E70TTLERC 1994	GEARCASE
E70TTLERV 1994	GEARCASE
E70TTLETS 1993	GEARCASE
E75ECDC 1986	GEARCASE - 20" MODELS
E75ECOS 1985	GEARCASE - 20" MODELS
E75ECDR 1984	GEARCASE - 20" MODELS
E75ECUR 1987	GEARCASE - 20" MODELS
E75ELCRD 1984	GEARCASE - 20" MODELS
E75ERCIH 1981	GEARCASE - 20" TRANSOM
E75ERCIM 1981	GEARCASE - 20" TRANSOM
E75ERCNB 1982	GEARCASE - 20" TRANSOM
E75ERCSA 1980	GEARCASE-20" TRANSOM
E75ERCTE 1983	GEARCASE - 20" TRANSOM
E75ERLCIH 1981	GEARCASE - 20" TRANSOM
E75ERLCIM 1981	GEARCASE - 20" TRANSOM
E75ERLCNB 1982	GEARCASE - 20" TRANSOM
E75ERLCSA 1980	GEARCASE-20" TRANSOM
E75ERLCTE 1983	GEARCASE - 20" TRANSOM
E75TLCRD 1984	GEARCASE - 20" MODELS
E75TRLCIH 1981	GEARCASE - 20" TRANSOM
E75TRLCIM 1981	GEARCASE - 20" TRANSOM

E75TRLCNB 1982	GEARCASE - 20" TRANSOM
E75TRLCSA 1980	GEARCASE-20" TRANSOM
E75TRLCTE 1983	GEARCASE - 20" TRANSOM
HE45RCLEDS 1996	GEARCASE
HE45RCLEUC 1997	GEARCASE
HE55RSLC 1997	GEARCASE
HE55RSLW 1996	GEARCASE
HE55WMLM 1996	GEARCASE
HE55WMLZ 1997	GEARCASE
HE70TXEDA 1996	GEARCASE
HE70TXEUM 1997	GEARCASE
HJ45RCLEDS 1996	GEARCASE
HJ45RCLEUC 1997	GEARCASE
HJ55RSLC 1997	GEARCASE
HJ55RSLW 1996	GEARCASE
HJ55WMLM 1996	GEARCASE
HJ55WMLZ 1997	GEARCASE
HJ70TXEDA 1996	GEARCASE
HJ70TXEUM 1997	GEARCASE
J40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40JPLEEC 1999	GEARCASE
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	GEARCASE
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J40JVLSIA jet drive,elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40WREES 1999	GEARCASE

J40WRLEES 1999	GEARCASE
J40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40WRYEES 1999	GEARCASE
J40WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J45RCCDS 1986	GEARCASE
J45RCCUC 1987	GEARCASE
J45RCE 1989	GEARCASE
J45RCEIA 1991	GEARCASE
J45RCENM 1992	GEARCASE
J45RCEOD 1995	GEARCASE
J45RCERE 1994	GEARCASE
J45RCESR 1990	GEARCASE
J45RCETB 1993	GEARCASE
J45RCLCDS 1986	GEARCASE
J45RCLCUC 1987	GEARCASE
J45RCLE 1989	GEARCASE
J45RCLEDS 1996	GEARCASE
J45RCLEIA 1991	GEARCASE
J45RCLENM 1992	GEARCASE
J45RCLEOD 1995	GEARCASE
J45RCLERE 1994	GEARCASE
J45RCLESR 1990	GEARCASE
J45RCLETB 1993	GEARCASE
J45RCLEUC 1997	GEARCASE
J45WMLE 1989	GEARCASE
J45WMLEIA 1991	GEARCASE
J45WMLENM 1992	GEARCASE
J45WMLER 1990	GEARCASE
J50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50BECIC 1981	GEARCASE, ROPE START

J50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50BELCIC 1981	GEARCASE, ROPE START
J50DTLECA 1998	GEARCASE
J50DTLEDC 1996	GEARCASE
J50DTLEOS 1995	GEARCASE
J50DTLEUR 1997	GEARCASE
J50ELED 1996	GEARCASE
J50ELEOS 1995	GEARCASE
J50ELEUR 1997	GEARCASE
J50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50TTLECA 1998	GEARCASE
J50TTLEDC 1996	GEARCASE
J50TTLEOS 1995	GEARCASE
J50TTLEUR 1997	GEARCASE
J55APRL	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRL - FR	27-6_BOÎTIER D'ENGRENAGES & BOÎTIER DE ROTOR - Modèles APRL
J55APRLSOM	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSOM - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRA	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRA - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRG	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRG - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55MLSOR	GEARCASE (ML MODEL)
J55MLSOR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MLSRC	GEARCASE (ML MODEL)
J55MLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MLSRG	GEARCASE (ML MODEL)
J55MLSRG - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MRL	GEARCASE (ML MODEL)
J55MRL - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55RCIM 1981	GEARCASE, ROPE START
J55RLCIM 1981	GEARCASE, ROPE START

J55RLCSA 1980	GEARCASE,ROPE START
J55RSLC 1997	GEARCASE
J55RSLG 1995	GEARCASE
J55RSLN 1983	GEARCASE
J55RSLN-2 1983	GEARCASE
J55RSLW 1996	GEARCASE
J55RSN 1983	GEARCASE
J55RSN-2 1983	GEARCASE
J55RSYN 1983	GEARCASE
J55RSYN-2 1983	GEARCASE
J55RWLDCD 1986	GEARCASE
J55RWLCOS 1985	GEARCASE
J55RWLCRD 1984	GEARCASE
J55RWLCUC 1987	GEARCASE
J55RWLE 1989	GEARCASE
J55RWLEIA 1991	GEARCASE
J55RWLENM 1992	GEARCASE
J55RWLERE 1994	GEARCASE
J55RWLESR 1990	GEARCASE
J55RWLETB 1993	GEARCASE
J55WREES 1999	GEARCASE
J55WRLEES 1999	GEARCASE
J55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J55WRLSOE	GEARCASE
J55WRLSOE - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSRB	GEARCASE
J55WRLSRB - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSRG	GEARCASE
J55WRLSRG - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J55WRLSTM	GEARCASE
J55WRLSTM - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE

J55WRYEES 1999	GEARCASE
J55WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J55WRYSOB	GEARCASE
J55WRYSOB - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRYSRM	GEARCASE
J55WRYSRM - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J60ECIA 1981	GEARCASE, ROPE START
J60ECIH 1981	GEARCASE, ROPE START
J60ECSR 1980	GEARCASE,ROPE START
J60ELCDS 1986	GEARCASE - 20" MODELS
J60ELCEA 1989	GEARCASE
J60ELCIA 1981	GEARCASE, ROPE START
J60ELCIH 1981	GEARCASE, ROPE START
J60ELCSR 1980	GEARCASE,ROPE START
J60ELCUC 1987	GEARCASE - 20" MODELS
J60ELEDR 1996	GEARCASE
J60ELEIB 1991	GEARCASE
J60ELENE 1992	GEARCASE
J60ELEOC 1995	GEARCASE
J60ELERS 1994	GEARCASE
J60ELERV 1994	GEARCASE
J60ELES 1990	GEARCASE
J60ELET 1993	GEARCASE
J60ELEUA 1997	GEARCASE
J60PLEEB 1999	GEARCASE
J60PLSID elec start, TNT, 20 in shaft 2001	GEARCASE
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J60TLCDS 1986	GEARCASE - 20" MODELS
J60TLCEA 1989	GEARCASE
J60TLCIA 1981	GEARCASE, ROPE START
J60TLCIH 1981	GEARCASE, ROPE START
J60TLCUC 1987	GEARCASE - 20" MODELS
J60TLECM 1998	GEARCASE

J60TLEDR 1996	GEARCASE
J60TLEIB 1991	GEARCASE
J60TLENE 1992	GEARCASE
J60TLEOC 1995	GEARCASE
J60TLERS 1994	GEARCASE
J60TLERV 1994	GEARCASE
J60TLESM 1990	GEARCASE
J60TLETD 1993	GEARCASE
J60TLEUA 1997	GEARCASE
J60TTLCEA 1989	GEARCASE
J60TTLECM 1998	GEARCASE
J60TTLEDR 1996	GEARCASE
J60TTLEIB 1991	GEARCASE
J60TTLENE 1992	GEARCASE
J60TTLEOC 1995	GEARCASE
J60TTLERS 1994	GEARCASE
J60TTLERV 1994	GEARCASE
J60TTLESM 1990	GEARCASE
J60TTLETD 1993	GEARCASE
J60TTLEUA 1997	GEARCASE
J60VLSID elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J65RSLC 1995	GEARCASE
J65RSLM 1996	GEARCASE
J65RSLZ2 1997	GEARCASE
J65RWLCDR 1986	GEARCASE
J65RWLCOC 1985	GEARCASE
J65RWLCRS 1984	GEARCASE
J65TELCDR 1986	GEARCASE
J65TELCOC 1985	GEARCASE
J65TELCRS 1984	GEARCASE
J65WELEES 1999	GEARCASE
J65WELSIR Commercial, elec start, 20 in shaft 2001	GEARCASE
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
J65WMLCDR 1986	GEARCASE
J65WMLCOC 1985	GEARCASE

J65WMLCUA 1987	GEARCASE
J65WMLEIB 1991	GEARCASE
J65WMLENE 1992	GEARCASE
J65WMLEOC 1995	GEARCASE
J65WMLERS 1994	GEARCASE
J65WMLESM 1990	GEARCASE
J65WMLETD 1993	GEARCASE
J65WMLZ 1989	GEARCASE
J65WRLEEO 1999	GEARCASE
J65WRLEES 1999	GEARCASE
J65WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
J65WRYEEO 1999	GEARCASE
J65WRYEES 1999	GEARCASE
J65WRYSIR commercial, rope start, 22.5 in shaft 2001	GEARCASE
J65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
J65WTLCOG 1985	GEARCASE
J65WTLCRS 1984	GEARCASE
J70ELCCA 1988	GEARCASE
J70ELCDC 1986	GEARCASE
J70ELCEM 1989	GEARCASE
J70ELCIH 1981	GEARCASE - 20" TRANSOM
J70ELCIM 1981	GEARCASE - 20" TRANSOM
J70ELCNB 1982	GEARCASE - 20" TRANSOM
J70ELCOS 1985	GEARCASE - 20" MODELS
J70ELCRD 1984	GEARCASE - 20" MODELS
J70ELCSA 1980	GEARCASE-20"TRANSOM
J70ELCTE 1983	GEARCASE - 20" TRANSOM
J70ELCUR 1987	GEARCASE
J70ELEIE 1991	GEARCASE
J70ELEND 1992	GEARCASE
J70ELEOR 1995	GEARCASE
J70ELERC 1994	GEARCASE
J70ELERV 1994	GEARCASE
J70ELESB 1990	GEARCASE

J70ELET5 1993	GEARCASE
J70JLEOS 1995	GEARCASE
J70PLEEE 1999	GEARCASE
J70PLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J70TLCCA 1988	GEARCASE
J70TLCDC 1986	GEARCASE
J70TLCEM 1989	GEARCASE
J70TLCIM 1981	GEARCASE - 20" TRANSOM
J70TLCNB 1982	GEARCASE - 20" TRANSOM
J70TLCOS 1985	GEARCASE - 20" MODELS
J70TLCRD 1984	GEARCASE - 20" MODELS
J70TLCTE 1983	GEARCASE - 20" TRANSOM
J70TLCUR 1987	GEARCASE
J70TLECB 1998	GEARCASE
J70TLEDA 1996	GEARCASE
J70TLEIE 1991	GEARCASE
J70TLEND 1992	GEARCASE
J70TLEOR 1995	GEARCASE
J70TLERC 1994	GEARCASE
J70TLERV 1994	GEARCASE
J70TLESB 1990	GEARCASE
J70TLETS 1993	GEARCASE
J70TLEUM 1997	GEARCASE
J70TTLEIE 1991	GEARCASE
J70TTLEND 1992	GEARCASE
J70TTLEOR 1995	GEARCASE
J70TTLERC 1994	GEARCASE
J70TTLERV 1994	GEARCASE
J70TTLETS 1993	GEARCASE
J70VLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
J75ECDC 1986	GEARCASE - 20" MODELS
J75ECNB 1982	GEARCASE - 20" TRANSOM
J75ECOS 1985	GEARCASE - 20" MODELS
J75ECDR 1984	GEARCASE - 20" MODELS

J75ECTE 1983	GEARCASE - 20" TRANSOM
J75ECUR 1987	GEARCASE - 20" MODELS
J75ELCNB 1982	GEARCASE - 20" TRANSOM
J75ELCRD 1984	GEARCASE - 20" MODELS
J75ELCTE 1983	GEARCASE - 20" TRANSOM
J75ERCIH 1981	GEARCASE - 20" TRANSOM
J75ERCIM 1981	GEARCASE - 20" TRANSOM
J75ERCSA 1980	GEARCASE-20"TRANSOM
J75ERLCIH 1981	GEARCASE - 20" TRANSOM
J75ERLCIM 1981	GEARCASE - 20" TRANSOM
J75ERLCSA 1980	GEARCASE-20"TRANSOM
J75TELCIM 1981	GEARCASE - 20" TRANSOM
J75TLCNB 1982	GEARCASE - 20" TRANSOM
J75TLCRD 1984	GEARCASE - 20" MODELS
J75TLCTE 1983	GEARCASE - 20" TRANSOM
J75TRLCIH 1981	GEARCASE - 20" TRANSOM
J75TRLCSA 1980	GEARCASE-20"TRANSOM
M55RWLR 1988	GEARCASE
N65WMLM 1988	GEARCASE
R45RCLR 1988	GEARCASE
R45RCR 1988	GEARCASE
R55RWLR 1988	GEARCASE
RJ70PLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
S45RCLR 1988	GEARCASE
S45RCR 1988	GEARCASE
SE40RPB 1997	GEARCASE
SE40RPH 1996	GEARCASE
SE40RPLB 1997	GEARCASE
SE40RPLH 1996	GEARCASE
SE40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPYB 1997	GEARCASE

SE40RPYH 1996	GEARCASE
SE40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE45RSLB 1997	GEARCASE
SE45RSLH 1996	GEARCASE
SE55RSC 1997	GEARCASE
SE55RSLC 1997	GEARCASE
SE55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSLW 1996	GEARCASE
SE55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSW 1996	GEARCASE
SE55RSYC 1997	GEARCASE
SE55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSYW 1996	GEARCASE
SE65RSLD 1998	GEARCASE
SE65RSLM 1996	GEARCASE
SE65RSLZ2 1997	GEARCASE
SE65RSYD 1998	GEARCASE
SE65RSYM 1996	GEARCASE
SE65RSYZ2 1997	GEARCASE
SE65WMLD 1998	GEARCASE
SE65WMLM 1996	GEARCASE
SE65WMLZ2 1997	GEARCASE
SE65WMYD 1998	GEARCASE
SE65WMYM 1996	GEARCASE
SE65WMYZ2 1997	GEARCASE
SJ40RPB 1997	GEARCASE
SJ40RPH 1996	GEARCASE
SJ40RPLB 1997	GEARCASE
SJ40RPLH 1996	GEARCASE
SJ40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY

SJ40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RPYB 1997	GEARCASE
SJ40RPYH 1996	GEARCASE
SJ40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ45RSLB 1997	GEARCASE
SJ45RSLH 1996	GEARCASE
SJ55RSC 1997	GEARCASE
SJ55RSLC 1997	GEARCASE
SJ55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSLW 1996	GEARCASE
SJ55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSW 1996	GEARCASE
SJ55RSYC 1997	GEARCASE
SJ55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSYW 1996	GEARCASE
SJ60TLEDR 1996	GEARCASE
SJ65RSLD 1998	GEARCASE
SJ65RSLM 1996	GEARCASE
SJ65RSLZ2 1997	GEARCASE
SJ65RSYD 1998	GEARCASE
SJ65RSYM 1996	GEARCASE
SJ65RSYZ2 1997	GEARCASE
SJ65WMLD 1998	GEARCASE
SJ65WMLM 1996	GEARCASE
SJ65WMLZ2 1997	GEARCASE
SJ65WMYD 1998	GEARCASE
SJ65WMYM 1996	GEARCASE
SJ65WMYZ2 1997	GEARCASE
SJ70TLEDA 1996	GEARCASE
T65WMLM 1988	GEARCASE

TE60TLCEA 1989	GEARCASE
TE60TLEIB 1991	GEARCASE
TE60TLENE 1992	GEARCASE
TE60TLESF 1989	GEARCASE
TE60TLESF 1990	GEARCASE
TE60TLESM 1990	GEARCASE
TE60TLETD 1993	GEARCASE
TE70TLCEM 1989	GEARCASE
TE70TLESB 1990	GEARCASE
TE70TLESF 1989	GEARCASE
TE70TLESF 1990	GEARCASE
TJ60TLCEA 1989	GEARCASE
TJ60TLEIB 1991	GEARCASE
TJ60TLENE 1992	GEARCASE
TJ60TLESF 1989	GEARCASE
TJ60TLESF 1990	GEARCASE
TJ60TLESM 1990	GEARCASE
TJ60TLETD 1993	GEARCASE
TJ70TLCEM 1989	GEARCASE
TJ70TLESB 1990	GEARCASE
TJ70TLESF 1989	GEARCASE
TJ70TLESF 1990	GEARCASE
VE60ELEIB 1991	GEARCASE
VE60ELENE 1992	GEARCASE
VE60ELESM 1990	GEARCASE
VE60ELETD 1993	GEARCASE
VE60TLEIB 1991	GEARCASE
VE60TLENE 1992	GEARCASE
VE60TLESM 1990	GEARCASE
VE70ELEIE 1991	GEARCASE
VE70ELEND 1992	GEARCASE
VE70ELESB 1990	GEARCASE
VE70ELETS 1993	GEARCASE
VE70TLEIE 1991	GEARCASE
VE70TLEND 1992	GEARCASE

VE70TLESB 1990	GEARCASE
VE70TLETS 1993	GEARCASE
VJ60ELEIB 1991	GEARCASE
VJ60ELENE 1992	GEARCASE
VJ60ELESB 1990	GEARCASE
VJ60ELETD 1993	GEARCASE
VJ60TLEIB 1991	GEARCASE
VJ60TLENE 1992	GEARCASE
VJ60TLESM 1990	GEARCASE
VJ70ELEIE 1991	GEARCASE
VJ70ELEND 1992	GEARCASE
VJ70ELESB 1990	GEARCASE
VJ70ELETS 1993	GEARCASE
VJ70TLEIE 1991	GEARCASE
VJ70TLEND 1992	GEARCASE
VJ70TLESB 1990	GEARCASE
VJ70TLETS 1993	GEARCASE