

Where Used: Part Number 0115206

Model Name	Diagram
BE2REDE 1996	ARMATURE PLATE & COIL ASSEMBLY
BE2REUD 1997	ARMATURE PLATE & COIL ASSEMBLY
BE3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
BE3ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
BJ2REDE 1996	ARMATURE PLATE & COIL ASSEMBLY
BJ2REUD 1997	ARMATURE PLATE & COIL ASSEMBLY
BJ3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
BJ3ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
E2RECS 1998	ARMATURE PLATE & COIL ASSEMBLY
E2ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
E2ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RE, 2RO, 3RO
E2ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RS-3RS
E2ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
E2RSS 1998	ARMATURE PLATE & COIL ASSEMBLY
E2WREES 1999	ARMATURE PLATE & COIL ASSEMBLY
E2WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	ARMATURE PLATE & COIL ASSEMBLY
E2WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	ARMATURE PLATE & COIL ASSEMBLY
E3ROECS 1998	ARMATURE PLATE & COIL ASSEMBLY
E3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
E3ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RE, 2RO, 3RO
E3ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RS-3RS
E3ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
E3ROLECS 1998	ARMATURE PLATE & COIL ASSEMBLY
E3ROSIA Commercial, Rope Start, Tiller, 15 IN. shaft, N/A USA 2001	ARMATURE PLATE & COIL ASSEMBLY
E3ROSSR Rope Start, Tiller, 15 in. shaft, N/A USA 2000	ARMATURE PLATE & COIL ASSEMBLY
E3RSS 1998	ARMATURE PLATE & COIL ASSEMBLY
E3WREES 1999	ARMATURE PLATE & COIL ASSEMBLY
E3WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	ARMATURE PLATE & COIL ASSEMBLY
E3WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	ARMATURE PLATE & COIL ASSEMBLY
HE2DRERM 1994	ARMATURE PLATE & COIL ASSEMBLY
HE2DRETC 1993	ARMATURE PLATE & COIL ASSEMBLY
HE2REDE 1996	ARMATURE PLATE & COIL ASSEMBLY

HE2REUD 1997	ARMATURE PLATE & COIL ASSEMBLY
HE2RSA 1996	ARMATURE PLATE & COIL ASSEMBLY
HE2RSK 1997	ARMATURE PLATE & COIL ASSEMBLY
HE3RERM 1994	ARMATURE PLATE & COIL ASSEMBLY
HE3RETC 1993	ARMATURE PLATE & COIL ASSEMBLY
HE3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
HE3ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
HE3RSA 1996	ARMATURE PLATE & COIL ASSEMBLY
HE3RSK 1997	ARMATURE PLATE & COIL ASSEMBLY
HJ2DRERM 1994	ARMATURE PLATE & COIL ASSEMBLY
HJ2DRETC 1993	ARMATURE PLATE & COIL ASSEMBLY
HJ2REDE 1996	ARMATURE PLATE & COIL ASSEMBLY
HJ2REUD 1997	ARMATURE PLATE & COIL ASSEMBLY
HJ2RSA 1996	ARMATURE PLATE & COIL ASSEMBLY
HJ2RSK 1997	ARMATURE PLATE & COIL ASSEMBLY
HJ3RERM 1994	ARMATURE PLATE & COIL ASSEMBLY
HJ3RETC 1993	ARMATURE PLATE & COIL ASSEMBLY
HJ3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
HJ3ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
HJ3RSA 1996	ARMATURE PLATE & COIL ASSEMBLY
HJ3RSK 1997	ARMATURE PLATE & COIL ASSEMBLY
J2RECS 1998	ARMATURE PLATE & COIL ASSEMBLY
J2REEC 1999	ARMATURE PLATE & COIL ASSEMBLY
J2ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
J2ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RE, 2RO, 3RO
J2ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RS-3RS
J2ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
J2RSS 1998	ARMATURE PLATE & COIL ASSEMBLY
J2RTSIA Commercial, Rope Start, Tiller, 15 IN. shaft 2001	ARMATURE PLATE & COIL ASSEMBLY
J2RTSSR Rope Start, Tiller, 15 in. shaft 2000	ARMATURE PLATE & COIL ASSEMBLY
J2RTVSIA Commercial, Rope Start, Tiller, 15 IN. shaft, wht 2001	ARMATURE PLATE & COIL ASSEMBLY
J2WREES 1999	ARMATURE PLATE & COIL ASSEMBLY
J2WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	ARMATURE PLATE & COIL ASSEMBLY
J2WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	ARMATURE PLATE & COIL ASSEMBLY

J3REEC 1999	ARMATURE PLATE & COIL ASSEMBLY
J3RLEEC 1999	ARMATURE PLATE & COIL ASSEMBLY
J3ROECS 1998	ARMATURE PLATE & COIL ASSEMBLY
J3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
J3ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RE, 2RO, 3RO
J3ROEOB 1995	ARMATURE PLATE & COIL ASSEMBLY - 2RS-3RS
J3ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
J3ROLECS 1998	ARMATURE PLATE & COIL ASSEMBLY
J3RSDE	IGNITION / ELECTRICAL
J3RSDE - FR	22-4_SYSTÈME ÉLECTRIQUE
J3RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J3RSNF Carbureted, Rope start, Neutral & Forward, White 2002	IGNITION / ELECTRICAL
J3RSOD	IGNITION / ELECTRICAL
J3RSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J3RSRE	IGNITION / ELECTRICAL
J3RSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J3RSS 1998	ARMATURE PLATE & COIL ASSEMBLY
J3RSTB	IGNITION / ELECTRICAL
J3RSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J3RSTF	IGNITION / ELECTRICAL
J3RSTF - FR	22-5_SYSTÈME D'ALLUMAGE
J3RTLSIA Commercial, Rope Start, Tiller, 20 IN. shaft 2001	ARMATURE PLATE & COIL ASSEMBLY
J3RTLSSR Rope Start, Tiller, 20 in. shaft 2000	ARMATURE PLATE & COIL ASSEMBLY
J3RTSIA Commercial, Rope Start, Tiller, 15 IN. shaft 2001	ARMATURE PLATE & COIL ASSEMBLY
J3RTSSR Rope Start, Tiller, 15 in. shaft 2000	ARMATURE PLATE & COIL ASSEMBLY
J3RTVSIA Commercial, Rope Start, Tiller, 15 IN. shaft, wht 2001	ARMATURE PLATE & COIL ASSEMBLY
J3WREES 1999	ARMATURE PLATE & COIL ASSEMBLY
J3WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	ARMATURE PLATE & COIL ASSEMBLY
J3WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	ARMATURE PLATE & COIL ASSEMBLY
SE2REDE 1996	ARMATURE PLATE & COIL ASSEMBLY
SE3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY
SE3ROEUD 1997	ARMATURE PLATE & COIL ASSEMBLY
SJ2REDE 1996	ARMATURE PLATE & COIL ASSEMBLY
SJ3ROEDE 1996	ARMATURE PLATE & COIL ASSEMBLY

