

Where Used: Part Number 0130743

Model Name	Diagram
3802A 1968	MAGNETO GROUP
3802M 1968	MAGNETO GROUP
3803A 1968	MAGNETO GROUP
3803M 1968	MAGNETO GROUP
3806A 1968	MAGNETO GROUP
3806M 1968	MAGNETO GROUP
3807A 1968	MAGNETO GROUP
3807M 1968	MAGNETO GROUP
3832A 1968	MAGNETO GROUP
3832M 1968	MAGNETO GROUP
3833A 1968	MAGNETO GROUP
3833M 1968	MAGNETO GROUP
3836A 1968	MAGNETO GROUP
3836M 1968	MAGNETO GROUP
3837A 1968	MAGNETO GROUP
3837M 1968	MAGNETO GROUP
4006E 1970	MAGNETO GROUP
4007E 1970	MAGNETO GROUP
4036E 1970	MAGNETO GROUP
4037E 1970	MAGNETO GROUP
4106D 1971	MAGNETO
4107D 1971	MAGNETO
4136D 1971	MAGNETO
4137D 1971	MAGNETO
4206S 1972	MAGNETO
4236S 1972	MAGNETO
4706B 1977	MAGNETO
4736B 1977	MAGNETO
4806E 1978	MAGNETO
4836E 1978	MAGNETO
4837E 1978	MAGNETO
4902B 1969	MAGNETO GROUP
4904D 1979	MAGNETO

4906B 1969	MAGNETO GROUP
4932D 1979	MAGNETO
4933D 1979	MAGNETO
4936B 1969	MAGNETO GROUP
4R69B 1969	MAGNETO GROUP
4R70E 1970	MAGNETO GROUP
4R71D 1971	MAGNETO
4R72S 1972	MAGNETO
4R77B 1977	MAGNETO
4R78E 1978	MAGNETO
4R79D 1979	MAGNETO
4RL70E 1970	MAGNETO GROUP
4RL71D 1971	MAGNETO
4RL78E 1978	MAGNETO
4RL79D 1979	MAGNETO
4W69B 1969	MAGNETO GROUP
4W70E 1970	MAGNETO GROUP
4W71D 1971	MAGNETO
4W72S 1972	MAGNETO
4W77B 1977	MAGNETO
4W78E 1978	MAGNETO
4W79D 1979	MAGNETO
4WF69B 1969	MAGNETO GROUP
4WL70E 1970	MAGNETO GROUP
4WL71D 1971	MAGNETO
744AMRGDP 1988	STARTER MOTOR
744APRGDP 1988	STARTER MOTOR
990334A 1981	STARTER MOTOR GROUP
990334C 1980	STARTER MOTOR GROUP
990334F 1981	STARTER MOTOR GROUP
990334R 1981	STARTER MOTOR GROUP
990335A 1981	STARTER MOTOR GROUP
990335C 1980	STARTER MOTOR GROUP
990335F 1981	STARTER MOTOR GROUP
990335R 1981	STARTER MOTOR GROUP

990336A 1981	STARTER MOTOR GROUP
990336C 1980	STARTER MOTOR GROUP
990336F 1981	STARTER MOTOR GROUP
990336R 1981	STARTER MOTOR GROUP
990337A 1981	STARTER MOTOR GROUP
990337C 1980	STARTER MOTOR GROUP
990337F 1981	STARTER MOTOR GROUP
990337R 1981	STARTER MOTOR GROUP
990338A 1981	STARTER MOTOR GROUP
990338C 1980	STARTER MOTOR GROUP
990338F 1981	STARTER MOTOR GROUP
990338R 1981	STARTER MOTOR GROUP
990339A 1981	STARTER MOTOR GROUP
990339C 1980	STARTER MOTOR GROUP
990339F 1981	STARTER MOTOR GROUP
990339R 1981	STARTER MOTOR GROUP
990344A 1981	STARTER MOTOR GROUP
990344C 1980	STARTER MOTOR GROUP
990344F 1981	STARTER MOTOR GROUP
990344R 1981	STARTER MOTOR GROUP
990345A 1981	STARTER MOTOR GROUP
990345C 1980	STARTER MOTOR GROUP
990345F 1981	STARTER MOTOR GROUP
990345R 1981	STARTER MOTOR GROUP
990346A 1981	STARTER MOTOR GROUP
990346C 1980	STARTER MOTOR GROUP
990346F 1981	STARTER MOTOR GROUP
990346R 1981	STARTER MOTOR GROUP
990347A 1981	STARTER MOTOR GROUP
990347C 1980	STARTER MOTOR GROUP
990347F 1981	STARTER MOTOR GROUP
990347R 1981	STARTER MOTOR GROUP
990347U 1980	STARTER MOTOR GROUP
990348A 1981	STARTER MOTOR GROUP
990348C 1980	STARTER MOTOR GROUP

990348F 1981	STARTER MOTOR GROUP
990348R 1981	STARTER MOTOR GROUP
990349A 1981	STARTER MOTOR GROUP
990349C 1980	STARTER MOTOR GROUP
990349F 1981	STARTER MOTOR GROUP
990349R 1981	STARTER MOTOR GROUP
BE3REDS 1996	IGNITION
BE4BREDS 1996	IGNITION
BE4BREUC 1997	IGNITION
BE4BRLEDS 1996	IGNITION
BE4BRLEUC 1997	IGNITION
BE4RDHEDS 1996	MAGNETO
BE4RDHLEDS 1996	MAGNETO
BE4REDS 1996	IGNITION
BE4RLEDS 1996	IGNITION
BJ200CXEEB 1999	CYLINDER & CRANKCASE
BJ200CXEEN 1999	CYLINDER & CRANKCASE
BJ200CXSS Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	CYLINDER & CRANKCASE
BJ200PLEEB 1999	CYLINDER & CRANKCASE
BJ200PLEEN 1999	CYLINDER & CRANKCASE
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	CYLINDER & CRANKCASE
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ200PXEEB 1999	CYLINDER & CRANKCASE
BJ200PXEEN 1999	CYLINDER & CRANKCASE
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	CYLINDER & CRANKCASE
BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	CYLINDER & CRANKCASE
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	CYLINDER & CRANKCASE
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	CYLINDER & CRANKCASE
BJ225CXEEC 1999	CYLINDER & CRANKCASE
BJ225CXEEN 1999	CYLINDER & CRANKCASE
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	CYLINDER & CRANKCASE
BJ225PLEEC 1999	CYLINDER & CRANKCASE
BJ225PLEEN 1999	CYLINDER & CRANKCASE
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	CYLINDER & CRANKCASE

BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ225PXEEC 1999	CYLINDER & CRANKCASE
BJ225PXEEEN 1999	CYLINDER & CRANKCASE
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	CYLINDER & CRANKCASE
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	CYLINDER & CRANKCASE
BJ3REDS 1996	IGNITION
BJ4BREDS 1996	IGNITION
BJ4BREUC 1997	IGNITION
BJ4BRLEDS 1996	IGNITION
BJ4BRLEUC 1997	IGNITION
BJ4RDHEDS 1996	MAGNETO
BJ4RDHLEDS 1996	MAGNETO
BJ4REDS 1996	IGNITION
BJ4RLEDS 1996	IGNITION
E200FCXEEN 1999	CYLINDER & CRANKCASE
E200FCXEES 1999	CYLINDER & CRANKCASE
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E200FPLEEN 1999	CYLINDER & CRANKCASE
E200FPLEES 1999	CYLINDER & CRANKCASE
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
E200FPXEEN 1999	CYLINDER & CRANKCASE
E200FPXEES 1999	CYLINDER & CRANKCASE
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
E200FSLEEN 1999	CYLINDER & CRANKCASE
E200FSLEES 1999	CYLINDER & CRANKCASE
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
E200WPXEEN 1999	CYLINDER & CRANKCASE
E200WPXEES 1999	CYLINDER & CRANKCASE
E200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	CYLINDER & CRANKCASE
E225FCXEEN 1999	CYLINDER & CRANKCASE
E225FCXEEO 1999	CYLINDER & CRANKCASE

E225FCXEES 1999	CYLINDER & CRANKCASE
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E225FCZEEN 1999	CYLINDER & CRANKCASE
E225FCZEEO 1999	CYLINDER & CRANKCASE
E225FCZEES 1999	CYLINDER & CRANKCASE
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
E225FPLEEN 1999	CYLINDER & CRANKCASE
E225FPLEEO 1999	CYLINDER & CRANKCASE
E225FPLEES 1999	CYLINDER & CRANKCASE
E225FPLSIF FFI	CYLINDER & CRANKCASE
E225FPXEEN 1999	CYLINDER & CRANKCASE
E225FPXEEO 1999	CYLINDER & CRANKCASE
E225FPXEES 1999	CYLINDER & CRANKCASE
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
E225FPZEEN 1999	CYLINDER & CRANKCASE
E225FPZEEO 1999	CYLINDER & CRANKCASE
E225FPZEES 1999	CYLINDER & CRANKCASE
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	CYLINDER & CRANKCASE
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	CYLINDER & CRANKCASE
E3BRCEC 1989	IGNITION
E3BRESR 1990	IGNITION
E3RCCM 1988	IGNITION
E3RCUA 1987	IGNITION
E3REIA 1991	IGNITION
E3RENM 1992	IGNITION
E3REOD 1995	IGNITION
E3RERE 1994	IGNITION
E3RETB 1993	IGNITION
E3REUC 1997	IGNITION
E4BRCICI 1981	EXHAUST HOUSING
E4BRCICI 1981	MAGNETO

E4BRECRJ 1998	IGNITION
E4BRHCCS 1988	IGNITION
E4BRHCCS 1988	MIDSECTION
E4BRHCDE 1986	IGNITION
E4BRHCDE 1986	MIDSECTION
E4BRHCNR 1982	EXHAUST HOUSING
E4BRHCNR 1982	MAGNETO
E4BRHCOB 1985	IGNITION
E4BRHCOB 1985	MIDSECTION
E4BRHCRM 1984	IGNITION
E4BRHCRM 1984	MIDSECTION
E4BRHCTA 1983	MAGNETO
E4BRHCTA 1983	MID-SECTION
E4BRHCUD 1987	IGNITION
E4BRHCUD 1987	MIDSECTION
E4BRHLCCS 1988	IGNITION
E4BRHLCCS 1988	MIDSECTION
E4BRHLCDE 1986	IGNITION
E4BRHLCDE 1986	MIDSECTION
E4BRHLCNR 1982	EXHAUST HOUSING
E4BRHLCNR 1982	MAGNETO
E4BRHLCOB 1985	IGNITION
E4BRHLCOB 1985	MIDSECTION
E4BRHLCRM 1984	IGNITION
E4BRHLCRM 1984	MIDSECTION
E4BRHLCTA 1983	MAGNETO
E4BRHLCTA 1983	MID-SECTION
E4BRHLCUD 1987	IGNITION
E4BRHLCUD 1987	MIDSECTION
E4BRLCIC 1981	EXHAUST HOUSING
E4BRLCIC 1981	MAGNETO
E4BRLECRJ 1998	IGNITION
E4RCCS 1988	IGNITION
E4RCEC 1989	IGNITION
E4RCUD 1987	IGNITION

E4RDHCCS 1988	MAGNETO
E4RDHCDE 1986	MAGNETO
E4RDHCEC 1989	IGNITION
E4RDHCUD 1987	MAGNETO
E4RDHEIA 1991	IGNITION
E4RDHENM 1992	IGNITION
E4RDHEOD 1995	MAGNETO
E4RDHERE 1994	MAGNETO
E4RDHESR 1990	IGNITION
E4RDHETB 1993	IGNITION
E4RDHLCCS 1988	MAGNETO
E4RDHLCEC 1989	IGNITION
E4RDHLCUD 1987	MAGNETO
E4RDHLEIA 1991	IGNITION
E4RDHLENM 1992	IGNITION
E4RDHLEOD 1995	MAGNETO
E4RDHLERE 1994	MAGNETO
E4RDHLESR 1990	IGNITION
E4RDHLETB 1993	IGNITION
E4REDS 1996	IGNITION
E4REIA 1991	IGNITION
E4RENM 1992	IGNITION
E4REOD 1995	IGNITION
E4RERE 1994	IGNITION
E4RESR 1990	IGNITION
E4RETB 1993	IGNITION
E4REUC 1997	IGNITION
E4RLCCS 1988	IGNITION
E4RLCEC 1989	IGNITION
E4RLCSS 1980	MAGNETO
E4RLCUD 1987	IGNITION
E4RLEDS 1996	IGNITION
E4RLEIA 1991	IGNITION
E4RLENM 1992	IGNITION
E4RLEOD 1995	IGNITION



E4RLERE 1994	IGNITION
E4RLESR 1990	IGNITION
E4RLETB 1993	IGNITION
E4RLEUC 1997	IGNITION
E4WCIC 1981	MAGNETO
E4WCNR 1982	MAGNETO
E4WCSS 1980	MAGNETO
E5RCIC 1981	MAGNETO-4.5
E5RCSS 1980	MAGNETO-4.5
E5RHCIC 1981	MAGNETO-4.5
E5RHCNR 1982	MAGNETO - 4.5
E5RHCSS 1980	MAGNETO-4.5
E5RHCTA 1983	MAGNETO-4.5
E5RHLCIC 1981	MAGNETO-4.5
E5RHLCNR 1982	MAGNETO - 4.5
E5RHLCSS 1980	MAGNETO-4.5
E5RHLCTA 1983	MAGNETO-4.5
E5RLCIC 1981	MAGNETO-4.5
E5RLCSS 1980	MAGNETO-4.5
E8RCIC 1981	MAGNETO-4.5
E8RCNR 1982	MAGNETO - 4.5
E8RCSS 1980	MAGNETO-4.5
E8RCTA 1983	MAGNETO-4.5
E8RLCIC 1981	MAGNETO-4.5
E8RLCNR 1982	MAGNETO - 4.5
E8RLCSS 1980	MAGNETO-4.5
E8RLCTA 1983	MAGNETO-4.5
E8SRLCNR 1982	MAGNETO - 4.5
E8SRLCTA 1983	MAGNETO-4.5
J200CXEEB 1999	CYLINDER & CRANKCASE
J200CXEEN 1999	CYLINDER & CRANKCASE
J200CXSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	CYLINDER & CRANKCASE
J200PLEEB 1999	CYLINDER & CRANKCASE
J200PLEEN 1999	CYLINDER & CRANKCASE
J200PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE

J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
J200PXEEB 1999	CYLINDER & CRANKCASE
J200PXEEB 1999	CYLINDER & CRANKCASE
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
J200WPXEEN 1999	CYLINDER & CRANKCASE
J200WPXEES 1999	CYLINDER & CRANKCASE
J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	CYLINDER & CRANKCASE
J225CXEEC 1999	CYLINDER & CRANKCASE
J225CXEEN 1999	CYLINDER & CRANKCASE
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	CYLINDER & CRANKCASE
J225HGLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	CYLINDER & CRANKCASE
J225HPLEEN 1999	CYLINDER & CRANKCASE
J225HPLEES 1999	CYLINDER & CRANKCASE
J225HPLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	CYLINDER & CRANKCASE
J225PLEEC 1999	CYLINDER & CRANKCASE
J225PLEEN 1999	CYLINDER & CRANKCASE
J225PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
J225PXEEC 1999	CYLINDER & CRANKCASE
J225PXEEB 1999	CYLINDER & CRANKCASE
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
J250CXEEN 1999	CYLINDER & CRANKCASE

J250CXEES 1999	CYLINDER & CRANKCASE
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250CZEEN 1999	CYLINDER & CRANKCASE
J250CZEES 1999	CYLINDER & CRANKCASE
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250PXEEN 1999	CYLINDER & CRANKCASE
J250PXEES 1999	CYLINDER & CRANKCASE
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
J250PZEEN 1999	CYLINDER & CRANKCASE
J250PZEES 1999	CYLINDER & CRANKCASE
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	CYLINDER & CRANKCASE
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	CYLINDER & CRANKCASE
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	CYLINDER & CRANKCASE
J3BRCEC 1989	IGNITION
J3BRESR 1990	IGNITION
J3RCCM 1988	IGNITION
J3RCUA 1987	IGNITION
J3REIA 1991	IGNITION
J3RENM 1992	IGNITION
J3REOD 1995	IGNITION
J3RERE 1994	IGNITION
J3RETB 1993	IGNITION
J3REUC 1997	IGNITION
J4BRCIC 1981	EXHAUST HOUSING
J4BRCIC 1981	MAGNETO
J4BRECRJ 1998	IGNITION
J4BRHCCS 1988	IGNITION
J4BRHCCS 1988	MIDSECTION
J4BRHCDE 1986	IGNITION
J4BRHCDE 1986	MIDSECTION



J4RDHENM 1992	IGNITION
J4RDHEOD 1995	MAGNETO
J4RDHERE 1994	MAGNETO
J4RDHESR 1990	IGNITION
J4RDHETB 1993	IGNITION
J4RDHLCCS 1988	MAGNETO
J4RDHLCEC 1989	IGNITION
J4RDHLCUD 1987	MAGNETO
J4RDHLEIA 1991	IGNITION
J4RDHLENM 1992	IGNITION
J4RDHLEOD 1995	MAGNETO
J4RDHLERE 1994	MAGNETO
J4RDHLESR 1990	IGNITION
J4RDHLETB 1993	IGNITION
J4REDS 1996	IGNITION
J4REEA 1999	IGNITION
J4REIA 1991	IGNITION
J4RENM 1992	IGNITION
J4REOD 1995	IGNITION
J4RERE 1994	IGNITION
J4RESR 1990	IGNITION
J4RETB 1993	IGNITION
J4REUC 1997	IGNITION
J4RLCCS 1988	IGNITION
J4RLCEC 1989	IGNITION
J4RLCSS 1980	MAGNETO
J4RLCUD 1987	IGNITION
J4RLEDs 1996	IGNITION
J4RLEEA 1999	IGNITION
J4RLEIA 1991	IGNITION
J4RLENM 1992	IGNITION
J4RLEOD 1995	IGNITION
J4RLERE 1994	IGNITION
J4RLESR 1990	IGNITION
J4RLETB 1993	IGNITION

J4RLEUC 1997	IGNITION
J4RLSIB Rope Start, Tiller, 20 IN. shaft 2001	IGNITION
J4RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J4RSIB Rope Start, Tiller, 15 IN. shaft 2001	IGNITION
J4RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J4WCIC 1981	MAGNETO
J4WCNR 1982	MAGNETO
J4WCSS 1980	MAGNETO
J5RCIC 1981	MAGNETO-4.5
J5RCSS 1980	MAGNETO-4.5
J5RHCIC 1981	MAGNETO-4.5
J5RHCNR 1982	MAGNETO - 4.5
J5RHCSS 1980	MAGNETO-4.5
J5RHCTA 1983	MAGNETO-4.5
J5RHLCIC 1981	MAGNETO-4.5
J5RHLCNR 1982	MAGNETO - 4.5
J5RHLCSS 1980	MAGNETO-4.5
J5RHLCTA 1983	MAGNETO-4.5
J5RLCIC 1981	MAGNETO-4.5
J5RLCSS 1980	MAGNETO-4.5
J8RCIC 1981	MAGNETO-4.5
J8RCNR 1982	MAGNETO - 4.5
J8RCSS 1980	MAGNETO-4.5
J8RCTA 1983	MAGNETO-4.5
J8RLCIC 1981	MAGNETO-4.5
J8RLCNR 1982	MAGNETO - 4.5
J8RLCSS 1980	MAGNETO-4.5
J8RLCTA 1983	MAGNETO-4.5
J8SRLCNR 1982	MAGNETO - 4.5
J8SRLCTA 1983	MAGNETO-4.5
JH-23A 1968	MAGNETO GROUP
JH-23M 1968	MAGNETO GROUP
JHF-23A 1968	MAGNETO GROUP
JHF-23M 1968	MAGNETO GROUP
JHFL-23A 1968	MAGNETO GROUP

JHFL-23M 1968	MAGNETO GROUP
JHL-23A 1968	MAGNETO GROUP
JHL-23M 1968	MAGNETO GROUP
JW-23A 1968	MAGNETO GROUP
JW-23M 1968	MAGNETO GROUP
JWF-23A 1968	MAGNETO GROUP
JWF-23M 1968	MAGNETO GROUP
JWFL-23A 1968	MAGNETO GROUP
JWFL-23M 1968	MAGNETO GROUP
JWL-23A 1968	MAGNETO GROUP
JWL-23M 1968	MAGNETO GROUP
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	CYLINDER & CRANKCASE
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ200PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
RJ225CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	CYLINDER & CRANKCASE
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	CYLINDER & CRANKCASE
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	CYLINDER & CRANKCASE
RJ225HLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	CYLINDER & CRANKCASE
RJ225PLSIF elec start, TNT, 20 in shaft 2001	CYLINDER & CRANKCASE
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	CYLINDER & CRANKCASE
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	CYLINDER & CRANKCASE
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	CYLINDER & CRANKCASE

RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	CYLINDER & CRANKCASE
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	CYLINDER & CRANKCASE
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	CYLINDER & CRANKCASE
SJ3REDS 1996	IGNITION
SJ4REDS 1996	IGNITION
SJ4RLEDS 1996	IGNITION