

Where Used: Part Number 0172522

Model Name	Diagram
4506A 1975	MAGNETO
4536A 1975	MAGNETO
4606M 1976	MAGNETO
4636M 1976	MAGNETO
4R75A 1975	MAGNETO
4R76M 1976	MAGNETO
4W75A 1975	MAGNETO
4W76M 1976	MAGNETO
6504R 1975	MAGNETO
6505R 1975	MAGNETO
6604A 1976	MAGNETO
6605A 1976	MAGNETO
6R75R 1975	MAGNETO
6R76A 1976	MAGNETO
6RL75R 1975	MAGNETO
6RL76A 1976	MAGNETO
E3BRCEC 1989	IGNITION
E3BRESR 1990	IGNITION
E4BRCICI 1981	MAGNETO
E4BRHCCS 1988	IGNITION
E4BRHCDE 1986	IGNITION
E4BRHCNR 1982	MAGNETO
E4BRHCOB 1985	IGNITION
E4BRHCRM 1984	IGNITION
E4BRHCTA 1983	MAGNETO
E4BRHCUD 1987	IGNITION
E4BRHLCCS 1988	IGNITION
E4BRHLCDE 1986	IGNITION
E4BRHLCNR 1982	MAGNETO
E4BRHLCOB 1985	IGNITION
E4BRHLCRM 1984	IGNITION
E4BRHLCTA 1983	MAGNETO
E4BRHLAUD 1987	IGNITION

E4BRLCIC 1981	MAGNETO
E4WCIC 1981	MAGNETO
E4WCNR 1982	MAGNETO
J3BRCEC 1989	IGNITION
J3BRESR 1990	IGNITION
J4BRCIC 1981	MAGNETO
J4BRHCCS 1988	IGNITION
J4BRHCDE 1986	IGNITION
J4BRHCNR 1982	MAGNETO
J4BRHCOB 1985	IGNITION
J4BRHCRM 1984	IGNITION
J4BRHCTA 1983	MAGNETO
J4BRHCUD 1987	IGNITION
J4BRHLCCS 1988	IGNITION
J4BRHLCDE 1986	IGNITION
J4BRHLCNR 1982	MAGNETO
J4BRHLCOB 1985	IGNITION
J4BRHLCRM 1984	IGNITION
J4BRHLCTA 1983	MAGNETO
J4BRHLCUD 1987	IGNITION
J4BRLCIC 1981	MAGNETO
J4WCIC 1981	MAGNETO
J4WCNR 1982	MAGNETO