

Where Used: Part Number 0302538

Model Name	Diagram
18002C 1970	POWERHEAD GROUP
18002E 1970	POWERHEAD GROUP
18003C 1970	POWERHEAD GROUP
18003E 1970	POWERHEAD GROUP
18102S 1971	CRANKSHAFT & PISTON
18103S 1971	CRANKSHAFT & PISTON
18202R 1972	CRANKSHAFT & PISTON
18203R 1972	CRANKSHAFT & PISTON
18304A 1973	CRANKSHAFT & PISTON
18305A 1973	CRANKSHAFT & PISTON
18802A 1968	POWERHEAD GROUP
18802E 1968	POWERHEAD GROUP
18802M 1968	POWERHEAD GROUP
18803A 1968	POWERHEAD GROUP
18803E 1968	POWERHEAD GROUP
18803M 1968	POWERHEAD GROUP
18902B 1969	POWERHEAD GROUP
18902D 1969	POWERHEAD GROUP
18903B 1969	POWERHEAD GROUP
18903D 1969	POWERHEAD GROUP
20R69B 1969	POWERHEAD GROUP
20R69D 1969	POWERHEAD GROUP
20R70C 1970	POWERHEAD GROUP
20R70E 1970	POWERHEAD GROUP
20R71S 1971	CRANKSHAFT & PISTON
20R72R 1972	CRANKSHAFT & PISTON
20R73A 1973	CRANKSHAFT & PISTON
20RL69B 1969	POWERHEAD GROUP
20RL69D 1969	POWERHEAD GROUP
20RL70C 1970	POWERHEAD GROUP
20RL70E 1970	POWERHEAD GROUP
20RL71S 1971	CRANKSHAFT & PISTON
20RL72R 1972	CRANKSHAFT & PISTON

20RL73A 1973	CRANKSHAFT & PISTON
25002C 1970	POWERHEAD GROUP
25002E 1970	POWERHEAD GROUP
25003C 1970	POWERHEAD GROUP
25003E 1970	POWERHEAD GROUP
25102S 1971	CRANKSHAFT & PISTON
25103S 1971	CRANKSHAFT & PISTON
25202R 1972	CRANKSHAFT & PISTON
25203R 1972	CRANKSHAFT & PISTON
25252R 1972	CRANKSHAFT & PISTON
25253R 1972	CRANKSHAFT & PISTON
25302A 1973	CRANKSHAFT & PISTON
25303A 1973	CRANKSHAFT & PISTON
25352A 1973	CRANKSHAFT & PISTON
25353A 1973	CRANKSHAFT & PISTON
25402M 1974	CRANKSHAFT AND PISTON
25403M 1974	CRANKSHAFT AND PISTON
25452M 1974	CRANKSHAFT AND PISTON
25453M 1974	CRANKSHAFT AND PISTON
25502B 1975	CRANKSHAFT & PISTON
25503B 1975	CRANKSHAFT & PISTON
25552B 1975	CRANKSHAFT & PISTON
25553B 1975	CRANKSHAFT & PISTON
25602E 1976	CRANKSHAFT & PISTON
25603E 1976	CRANKSHAFT & PISTON
25652E 1976	CRANKSHAFT & PISTON
25653E 1976	CRANKSHAFT & PISTON
25902B 1969	POWERHEAD GROUP
25902D 1969	POWERHEAD GROUP
25903B 1969	POWERHEAD GROUP
25903D 1969	POWERHEAD GROUP
25E72R 1972	CRANKSHAFT & PISTON
25E73A 1973	CRANKSHAFT & PISTON
25E74M 1974	CRANKSHAFT & PISTON
25E75B 1975	CRANKSHAFT & PISTON

25E76E 1976	CRANKSHAFT & PISTON
25EL72R 1972	CRANKSHAFT & PISTON
25EL73A 1973	CRANKSHAFT & PISTON
25EL74M 1974	CRANKSHAFT & PISTON
25EL75B 1975	CRANKSHAFT & PISTON
25EL76E 1976	CRANKSHAFT & PISTON
25R69B 1969	POWERHEAD GROUP
25R69D 1969	POWERHEAD GROUP
25R70C 1970	POWERHEAD GROUP
25R70E 1970	POWERHEAD GROUP
25R71S 1971	CRANKSHAFT & PISTON
25R72R 1972	CRANKSHAFT & PISTON
25R73A 1973	CRANKSHAFT & PISTON
25R74M 1974	CRANKSHAFT & PISTON
25R75B 1975	CRANKSHAFT & PISTON
25R76E 1976	CRANKSHAFT & PISTON
25RL69B 1969	POWERHEAD GROUP
25RL69D 1969	POWERHEAD GROUP
25RL70C 1970	POWERHEAD GROUP
25RL70E 1970	POWERHEAD GROUP
25RL71S 1971	CRANKSHAFT & PISTON
25RL72R 1972	CRANKSHAFT & PISTON
25RL73A 1973	CRANKSHAFT & PISTON
25RL74M 1974	CRANKSHAFT & PISTON
25RL75B 1975	CRANKSHAFT & PISTON
25RL76E 1976	CRANKSHAFT & PISTON
33002M 1970	CRANKSHAFT GROUP
33003M 1970	CRANKSHAFT GROUP
33052M 1970	CRANKSHAFT GROUP
33053M 1970	CRANKSHAFT GROUP
33802M 1968	CRANKSHAFT GROUP
33802R 1968	CRANKSHAFT GROUP
33803M 1968	CRANKSHAFT GROUP
33803R 1968	CRANKSHAFT GROUP
33852M 1968	CRANKSHAFT GROUP

33852R 1968	CRANKSHAFT GROUP
33853M 1968	CRANKSHAFT GROUP
33853R 1968	CRANKSHAFT GROUP
33902A 1969	CRANKSHAFT GROUP
33903A 1969	CRANKSHAFT GROUP
33952A 1969	CRANKSHAFT GROUP
33953A 1969	CRANKSHAFT GROUP
33E69A 1969	CRANKSHAFT GROUP
33E70M 1970	CRANKSHAFT GROUP
33EL69A 1969	CRANKSHAFT GROUP
33EL70M 1970	CRANKSHAFT GROUP
33R69A 1969	CRANKSHAFT GROUP
33R70M 1970	CRANKSHAFT GROUP
33RL69A 1969	CRANKSHAFT GROUP
33RL70M 1970	CRANKSHAFT GROUP
40002A 1970	CRANKSHAFT GROUP
40003A 1970	CRANKSHAFT GROUP
40052A 1970	CRANKSHAFT GROUP
40053A 1970	CRANKSHAFT GROUP
40072A 1970	CRANKSHAFT GROUP ELECTRIC SHIFT
40073A 1970	CRANKSHAFT GROUP ELECTRIC SHIFT
40102B 1971	CRANKSHAFT & PISTON
40102G 1971	CRANKSHAFT & PISTON
40103B 1971	CRANKSHAFT & PISTON
40103G 1971	CRANKSHAFT & PISTON
40152B 1971	CRANKSHAFT & PISTON
40152G 1971	CRANKSHAFT & PISTON
40153B 1971	CRANKSHAFT & PISTON
40153G 1971	CRANKSHAFT & PISTON
40202E 1972	CRANKSHAFT AND PISTON
40203E 1972	CRANKSHAFT AND PISTON
40252E 1972	CRANKSHAFT AND PISTON
40253E 1972	CRANKSHAFT AND PISTON
40304D 1973	CRANKSHAFT & PISTON
40305D 1973	CRANKSHAFT & PISTON

40354D 1973	CRANKSHAFT & PISTON
40355D 1973	CRANKSHAFT & PISTON
40802A 1968	CRANKSHAFT GROUP
40802D 1968	CRANKSHAFT GROUP
40802S 1968	CRANKSHAFT GROUP
40803A 1968	CRANKSHAFT GROUP
40803D 1968	CRANKSHAFT GROUP
40803S 1968	CRANKSHAFT GROUP
40852A 1968	CRANKSHAFT GROUP ELECTRIC START
40852C 1968	CRANKSHAFT GROUP ELECTRIC START
40852D 1968	CRANKSHAFT GROUP ELECTRIC START
40852S 1968	CRANKSHAFT GROUP ELECTRIC START
40853A 1968	CRANKSHAFT GROUP ELECTRIC START
40853C 1968	CRANKSHAFT GROUP ELECTRIC START
40853D 1968	CRANKSHAFT GROUP ELECTRIC START
40853S 1968	CRANKSHAFT GROUP ELECTRIC START
40872A 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
40872C 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
40872D 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
40873A 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
40873C 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
40873D 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
40902R 1969	CRANKSHAFT GROUP
40903R 1969	CRANKSHAFT GROUP
40952R 1969	CRANKSHAFT GROUP
40953R 1969	CRANKSHAFT GROUP
40972R 1969	CRANKSHAFT GROUP ELECTRIC SHIFT
40973R 1969	CRANKSHAFT GROUP ELECTRIC SHIFT
40E69R 1969	CRANKSHAFT GROUP ELECTRIC START
40E70A 1970	CRANKSHAFT GROUP
40E71B 1971	CRANKSHAFT & PISTON
40E71G 1971	CRANKSHAFT & PISTON
40E72E 1972	CRANKSHAFT AND PISTON
40E73D 1973	CRANKSHAFT & PISTON
40EL69R 1969	CRANKSHAFT GROUP ELECTRIC START

40EL70A 1970	CRANKSHAFT GROUP
40EL71B 1971	CRANKSHAFT & PISTON
40EL71G 1971	CRANKSHAFT & PISTON
40EL72E 1972	CRANKSHAFT AND PISTON
40EL73D 1973	CRANKSHAFT & PISTON
40ES69R 1969	CRANKSHAFT GROUP ELECTRIC SHIFT
40ES70A 1970	CRANKSHAFT GROUP ELECTRIC SHIFT
40ESL69R 1969	CRANKSHAFT GROUP ELECTRIC SHIFT
40ESL70A 1970	CRANKSHAFT GROUP ELECTRIC SHIFT
40R69R 1969	CRANKSHAFT GROUP
40R70A 1970	CRANKSHAFT GROUP
40R71B 1971	CRANKSHAFT & PISTON
40R71G 1971	CRANKSHAFT & PISTON
40R72E 1972	CRANKSHAFT AND PISTON
40R73D 1973	CRANKSHAFT & PISTON
40RL69R 1969	CRANKSHAFT GROUP
40RL70A 1970	CRANKSHAFT GROUP
40RL71B 1971	CRANKSHAFT & PISTON
40RL71G 1971	CRANKSHAFT & PISTON
40RL72E 1972	CRANKSHAFT AND PISTON
40RL73D 1973	CRANKSHAFT & PISTON
FD-22A 1968	POWERHEAD GROUP
FD-22E 1968	POWERHEAD GROUP
FD-22M 1968	POWERHEAD GROUP
FDL-22A 1968	POWERHEAD GROUP
FDL-22E 1968	POWERHEAD GROUP
FDL-22M 1968	POWERHEAD GROUP
RD-30A 1968	CRANKSHAFT GROUP MANUAL START
RD-30D 1968	CRANKSHAFT GROUP MANUAL START
RD-30S 1968	CRANKSHAFT GROUP MANUAL START
RDL-30A 1968	CRANKSHAFT GROUP MANUAL START
RDL-30D 1968	CRANKSHAFT GROUP MANUAL START
RDL-30S 1968	CRANKSHAFT GROUP MANUAL START
RDS-30A 1968	CRANKSHAFT GROUP
RDS-30C 1968	CRANKSHAFT GROUP

RDS-30D 1968	CRANKSHAFT GROUP
RDS-30S 1968	CRANKSHAFT GROUP
RDSL-30A 1968	CRANKSHAFT GROUP
RDSL-30C 1968	CRANKSHAFT GROUP
RDSL-30D 1968	CRANKSHAFT GROUP
RDSL-30S 1968	CRANKSHAFT GROUP
RK-30A 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
RK-30C 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
RK-30D 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
RKL-30A 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
RKL-30C 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
RKL-30D 1968	CRANKSHAFT GROUP ELECTRIC SHIFT
RX-16M 1968	CRANKSHAFT GROUP
RX-16R 1968	CRANKSHAFT GROUP
RXE-16M 1968	CRANKSHAFT GROUP
RXE-16R 1968	CRANKSHAFT GROUP
RXEL-16M 1968	CRANKSHAFT GROUP
RXEL-16R 1968	CRANKSHAFT GROUP
RXL-16M 1968	CRANKSHAFT GROUP
RXL-16R 1968	CRANKSHAFT GROUP