

## Where Used: Part Number 0302944

Model Name	Diagram
10424G 1974	MAGNETO
10424S 1974	MAGNETO
10425G 1974	MAGNETO
10425S 1974	MAGNETO
10454G 1974	MAGNETO
10454S 1974	MAGNETO
10455G 1974	MAGNETO
10455S 1974	MAGNETO
10524C 1975	MAGNETO
10525C 1975	MAGNETO
10554C 1975	MAGNETO
10555C 1975	MAGNETO
10624G 1976	MAGNETO
10624H 1976	MAGNETO
10624R 1976	MAGNETO
10625G 1976	MAGNETO
10625H 1976	MAGNETO
10625R 1976	MAGNETO
10654G 1976	MAGNETO
10654H 1976	MAGNETO
10654R 1976	MAGNETO
10655G 1976	MAGNETO
10655H 1976	MAGNETO
10655R 1976	MAGNETO
10724A 1977	MAGNETO
10725A 1977	MAGNETO
10754A 1977	MAGNETO
10755A 1977	MAGNETO
10824M 1978	MAGNETO
10825M 1978	MAGNETO
10835M 1978	MAGNETO
10854M 1978	MAGNETO
10855M 1978	MAGNETO

10924B 1979	MAGNETO
10925B 1979	MAGNETO
10935B 1979	MAGNETO
10955B 1979	MAGNETO
10E74G 1974	MAGNETO
10E74S 1974	MAGNETO
10E75C 1975	MAGNETO
10E76G 1976	MAGNETO
10E76H 1976	MAGNETO
10E76R 1976	MAGNETO
10E77A 1977	MAGNETO
10E78M 1978	MAGNETO
10EL74G 1974	MAGNETO
10EL75C 1975	MAGNETO
10EL76G 1976	MAGNETO
10EL76H 1976	MAGNETO
10EL76R 1976	MAGNETO
10EL77A 1977	MAGNETO
10EL78M 1978	MAGNETO
10EL79B 1979	MAGNETO
10ELT4S 1974	MAGNETO
10R74G 1974	MAGNETO
10R74S 1974	MAGNETO
10R75C 1975	MAGNETO
10R76G 1976	MAGNETO
10R76H 1976	MAGNETO
10R76R 1976	MAGNETO
10R77A 1977	MAGNETO
10R78M 1978	MAGNETO
10R79B 1979	MAGNETO
10RL74G 1974	MAGNETO
10RL74S 1974	MAGNETO
10RL75C 1975	MAGNETO
10RL76G 1976	MAGNETO
10RL76H 1976	MAGNETO

10RL76R 1976	MAGNETO
10RL77A 1977	MAGNETO
10RL78M 1978	MAGNETO
10RL79B 1979	MAGNETO
10SEL78M 1978	MAGNETO
10SEL79B 1979	MAGNETO
15404G 1974	MAGNETO
15404S 1974	MAGNETO
15405G 1974	MAGNETO
15405S 1974	MAGNETO
15454G 1974	MAGNETO
15454S 1974	MAGNETO
15455G 1974	MAGNETO
15455S 1974	MAGNETO
15504C 1975	MAGNETO
15505C 1975	MAGNETO
15554C 1975	MAGNETO
15555C 1975	MAGNETO
15604A 1976	MAGNETO
15604R 1976	MAGNETO
15605A 1976	MAGNETO
15605R 1976	MAGNETO
15654A 1976	MAGNETO
15654R 1976	MAGNETO
15655A 1976	MAGNETO
15655R 1976	MAGNETO
15704M 1977	MAGNETO
15705M 1977	MAGNETO
15754M 1977	MAGNETO
15804B 1978	MAGNETO
15805B 1978	MAGNETO
15854B 1978	MAGNETO
15855B 1978	MAGNETO
15904E 1979	MAGNETO
15905E 1979	MAGNETO

15954E 1979	MAGNETO
15955E 1979	MAGNETO
15E74G 1974	MAGNETO
15E74S 1974	MAGNETO
15E75C 1975	MAGNETO
15E76A 1976	MAGNETO
15E76R 1976	MAGNETO
15E77M 1977	MAGNETO
15E78B 1978	MAGNETO
15E79E 1979	MAGNETO
15EL74G 1974	MAGNETO
15EL74S 1974	MAGNETO
15EL75C 1975	MAGNETO
15EL76A 1976	MAGNETO
15EL76R 1976	MAGNETO
15EL77M 1977	MAGNETO
15EL78B 1978	MAGNETO
15EL79E 1979	MAGNETO
15R74G 1974	MAGNETO
15R74S 1974	MAGNETO
15R75C 1975	MAGNETO
15R76A 1976	MAGNETO
15R76R 1976	MAGNETO
15R77M 1977	MAGNETO
15R78B 1978	MAGNETO
15R79E 1979	MAGNETO
15RL74G 1974	MAGNETO
15RL74S 1974	MAGNETO
15RL75C 1975	MAGNETO
15RL76A 1976	MAGNETO
15RL76R 1976	MAGNETO
15RL77M 1977	MAGNETO
15RL78B 1978	MAGNETO
15RL79E 1979	MAGNETO
BE10EEDD 1996	IGNITION - ELECTRIC

BE10EEDD 1996	IGNITION - ROPE
BE10ELEDD 1996	IGNITION - ELECTRIC
BE10ELEDD 1996	IGNITION - ROPE
BE10FDLECM 1998	IGNITION -- ELECTRIC
BE10FDLECM 1998	IGNITION -- ROPE
BE10FDLEDR 1996	IGNITION - ELECTRIC START
BE10FDLEDR 1996	IGNITION - ROPE START
BE10FDLEUA 1997	IGNITION - ELECTRIC
BE10FDLEUA 1997	IGNITION - ROPE
BE10FPXEDC 1996	IGNITION - ELECTRIC START
BE10FPXEDC 1996	IGNITION - ROPE START
BE10FPXEUR 1997	IGNITION - ELECTRIC
BE10FPXEUR 1997	IGNITION - ROPE
BE10FRELDR 1996	IGNITION - ELECTRIC START
BE10FRELDR 1996	IGNITION - ROPE START
BE10FRELUA 1997	IGNITION - ELECTRIC
BE10FRELUA 1997	IGNITION - ROPE
BE10REDD 1996	IGNITION - ELECTRIC
BE10REDD 1996	IGNITION - ROPE
BE10RELEDD 1996	IGNITION - ELECTRIC
BE10RELEDD 1996	IGNITION - ROPE
BE10RELEUS 1997	IGNITION - ELECTRIC
BE10RELEUS 1997	IGNITION - ROPE
BE10RLEDD 1996	IGNITION - ELECTRIC
BE10RLEDD 1996	IGNITION - ROPE
BE10SELEDD 1996	IGNITION - ELECTRIC
BE10SELEDD 1996	IGNITION - ROPE
BE15EEDS 1996	IGNITION - ELECTRIC
BE15EEDS 1996	IGNITION - ROPE
BE15ELEDs 1996	IGNITION - ELECTRIC
BE15ELEDs 1996	IGNITION - ROPE
BE15FAEDR 1996	IGNITION - ELECTRIC START
BE15FAEDR 1996	IGNITION - ROPE START
BE15FAEUA 1997	IGNITION - ELECTRIC
BE15FAEUA 1997	IGNITION - ROPE

BE15FDLECM 1998	IGNITION -- ELECTRIC
BE15FDLECM 1998	IGNITION -- ROPE
BE15FDLEDR 1996	IGNITION - ELECTRIC START
BE15FDLEDR 1996	IGNITION - ROPE START
BE15FDLEUA 1997	IGNITION - ELECTRIC
BE15FDLEUA 1997	IGNITION - ROPE
BE15FKEDR 1996	IGNITION - ELECTRIC START
BE15FKEDR 1996	IGNITION - ROPE START
BE15FKEUA 1997	IGNITION - ELECTRIC
BE15FKEUA 1997	IGNITION - ROPE
BE15FREDR 1996	IGNITION - ELECTRIC START
BE15FREDR 1996	IGNITION - ROPE START
BE15FRELEDR 1996	IGNITION - ELECTRIC START
BE15FRELEDR 1996	IGNITION - ROPE START
BE15FRELUUA 1997	IGNITION - ELECTRIC
BE15FRELUUA 1997	IGNITION - ROPE
BE15FREUA 1997	IGNITION - ELECTRIC
BE15FREUA 1997	IGNITION - ROPE
BE15FWECA 1998	IGNITION -- ELECTRIC
BE15FWECA 1998	IGNITION -- ROPE
BE15FWEDC 1996	IGNITION - ELECTRIC START
BE15FWEDC 1996	IGNITION - ROPE START
BE15FWEUR 1997	IGNITION - ELECTRIC
BE15FWEUR 1997	IGNITION - ROPE
BE15FWLECA 1998	IGNITION -- ELECTRIC
BE15FWLECA 1998	IGNITION -- ROPE
BE15FWLEDC 1996	IGNITION - ELECTRIC START
BE15FWLEDC 1996	IGNITION - ROPE START
BE15FWLEUR 1997	IGNITION - ELECTRIC
BE15FWLEUR 1997	IGNITION - ROPE
BE15REDS 1996	IGNITION - ELECTRIC
BE15REDS 1996	IGNITION - ROPE
BE15RELEUC 1997	IGNITION - ELECTRIC
BE15RELEUC 1997	IGNITION - ROPE
BE15RLEDS 1996	IGNITION - ELECTRIC

BE15RLEDS 1996	IGNITION - ROPE
BJ10EEDD 1996	IGNITION - ELECTRIC
BJ10EEDD 1996	IGNITION - ROPE
BJ10ELEDD 1996	IGNITION - ELECTRIC
BJ10ELEDD 1996	IGNITION - ROPE
BJ10FDLECM 1998	IGNITION -- ELECTRIC
BJ10FDLECM 1998	IGNITION -- ROPE
BJ10FDLEDR 1996	IGNITION - ELECTRIC START
BJ10FDLEDR 1996	IGNITION - ROPE START
BJ10FDLEUA 1997	IGNITION - ELECTRIC
BJ10FDLEUA 1997	IGNITION - ROPE
BJ10FPXEDC 1996	IGNITION - ELECTRIC START
BJ10FPXEDC 1996	IGNITION - ROPE START
BJ10FPXEUR 1997	IGNITION - ELECTRIC
BJ10FPXEUR 1997	IGNITION - ROPE
BJ10FREldr 1996	IGNITION - ELECTRIC START
BJ10FREldr 1996	IGNITION - ROPE START
BJ10FRELUA 1997	IGNITION - ELECTRIC
BJ10FRELUA 1997	IGNITION - ROPE
BJ10REDD 1996	IGNITION - ELECTRIC
BJ10REDD 1996	IGNITION - ROPE
BJ10RELEDD 1996	IGNITION - ELECTRIC
BJ10RELEDD 1996	IGNITION - ROPE
BJ10RELEUS 1997	IGNITION - ELECTRIC
BJ10RELEUS 1997	IGNITION - ROPE
BJ10RHLSDA	IGNITION
BJ10RHLSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSOR	IGNITION
BJ10RHLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSRC	IGNITION
BJ10RHLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSTS	IGNITION
BJ10RHLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSDA	IGNITION
BJ10RHSDA - FR	22-5_SYSTÈME D'ALLUMAGE

BJ10RHSOR	IGNITION
BJ10RHSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSRC	IGNITION
BJ10RHSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSTS	IGNITION
BJ10RHSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RLEDD 1996	IGNITION - ELECTRIC
BJ10RLEDD 1996	IGNITION - ROPE
BJ10SELEDD 1996	IGNITION - ELECTRIC
BJ10SELEDD 1996	IGNITION - ROPE
BJ15EEDS 1996	IGNITION - ELECTRIC
BJ15EEDS 1996	IGNITION - ROPE
BJ15ELEDS 1996	IGNITION - ELECTRIC
BJ15ELEDS 1996	IGNITION - ROPE
BJ15FAEDR 1996	IGNITION - ELECTRIC START
BJ15FAEDR 1996	IGNITION - ROPE START
BJ15FAEUA 1997	IGNITION - ELECTRIC
BJ15FAEUA 1997	IGNITION - ROPE
BJ15FDLECM 1998	IGNITION -- ELECTRIC
BJ15FDLECM 1998	IGNITION -- ROPE
BJ15FDLEDR 1996	IGNITION - ELECTRIC START
BJ15FDLEDR 1996	IGNITION - ROPE START
BJ15FDLEUA 1997	IGNITION - ELECTRIC
BJ15FDLEUA 1997	IGNITION - ROPE
BJ15FKEDR 1996	IGNITION - ELECTRIC START
BJ15FKEDR 1996	IGNITION - ROPE START
BJ15FKEUA 1997	IGNITION - ELECTRIC
BJ15FKEUA 1997	IGNITION - ROPE
BJ15FREDR 1996	IGNITION - ELECTRIC START
BJ15FREDR 1996	IGNITION - ROPE START
BJ15FRELEDR 1996	IGNITION - ELECTRIC START
BJ15FRELEDR 1996	IGNITION - ROPE START
BJ15FRELUUA 1997	IGNITION - ELECTRIC
BJ15FRELUUA 1997	IGNITION - ROPE
BJ15FREUUA 1997	IGNITION - ELECTRIC



BJ15FREUA 1997	IGNITION - ROPE
BJ15FWECA 1998	IGNITION -- ELECTRIC
BJ15FWECA 1998	IGNITION -- ROPE
BJ15FWEDC 1996	IGNITION - ELECTRIC START
BJ15FWEDC 1996	IGNITION - ROPE START
BJ15FWEUR 1997	IGNITION - ELECTRIC
BJ15FWEUR 1997	IGNITION - ROPE
BJ15FWLECA 1998	IGNITION -- ELECTRIC
BJ15FWLECA 1998	IGNITION -- ROPE
BJ15FWLEDC 1996	IGNITION - ELECTRIC START
BJ15FWLEDC 1996	IGNITION - ROPE START
BJ15FWLEUR 1997	IGNITION - ELECTRIC
BJ15FWLEUR 1997	IGNITION - ROPE
BJ15REDS 1996	IGNITION - ELECTRIC
BJ15REDS 1996	IGNITION - ROPE
BJ15RELEUC 1997	IGNITION - ELECTRIC
BJ15RELEUC 1997	IGNITION - ROPE
BJ15RLEDS 1996	IGNITION - ELECTRIC
BJ15RLEDS 1996	IGNITION - ROPE
E10EBL4EEB 1999	IGNITION -- ROPE
E10EBL4EEB 1999	IGNITION -- ELECTRIC
E10ECCD 1988	IGNITION
E10ECDB 1986	IGNITION
E10ECES 1989	IGNITION
E10ECOM 1985	IGNITION
E10ECSE 1980	MAGNETO
E10ECUE 1987	IGNITION
E10EECC 1998	IGNITION -- ELECTRIC
E10EECC 1998	IGNITION -- ROPE
E10EEDD 1996	IGNITION - ELECTRIC
E10EEDD 1996	IGNITION - ROPE
E10EEIR 1991	IGNITION
E10EENA 1992	IGNITION
E10EEOE 1995	IGNITION - ELECTRIC
E10EEOE 1995	IGNITION - ROPE

E10EERB 1994	IGNITION - ELECTRIC
E10EERB 1994	IGNITION - ROPE
E10EESC 1990	IGNITION
E10EETM 1993	IGNITION - ELECTRIC
E10EETM 1993	IGNITION - ROPE
E10EEUS 1997	IGNITION - ELECTRIC
E10EEUS 1997	IGNITION - ROPE
E10EL4EEB 1999	IGNITION -- ROPE
E10EL4EEB 1999	IGNITION -- ELECTRIC
E10EL4SID 4-stroke, elec start, remote, 20 in shaft 2001	IGNITION - ROPE
E10EL4SID 4-stroke, elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
E10EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ROPE
E10EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ELECTRIC
E10ELCCD 1988	IGNITION
E10ELCDB 1986	IGNITION
E10ELCES 1989	IGNITION
E10ELCID 1981	MAGNETO
E10ELCNS 1982	MAGNETO
E10ELCOM 1985	IGNITION
E10ELCRA 1984	MAGNETO
E10ELCSE 1980	MAGNETO
E10ELCTC 1983	MAGNETO
E10ELCUE 1987	IGNITION
E10ELECC 1998	IGNITION -- ELECTRIC
E10ELECC 1998	IGNITION -- ROPE
E10ELEDD 1996	IGNITION - ELECTRIC
E10ELEDD 1996	IGNITION - ROPE
E10ELEIR 1991	IGNITION
E10ELENA 1992	IGNITION
E10ELEOE 1995	IGNITION - ELECTRIC
E10ELEOE 1995	IGNITION - ROPE
E10ELERB 1994	IGNITION - ELECTRIC
E10ELERB 1994	IGNITION - ROPE
E10ELESC 1990	IGNITION
E10ELETM 1993	IGNITION - ELECTRIC

E10ELETM 1993	IGNITION - ROPE
E10ELEUS 1997	IGNITION - ELECTRIC
E10ELEUS 1997	IGNITION - ROPE
E10EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ROPE
E10EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
E10EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ROPE
E10EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E10FEXECM 1998	IGNITION -- ELECTRIC
E10FEXECM 1998	IGNITION -- ROPE
E10FEXEDR 1996	IGNITION - ELECTRIC START
E10FEXEDR 1996	IGNITION - ROPE START
E10FEXEO 1995	IGNITION - ELECTRIC START
E10FEXEO 1995	IGNITION - ROPE START
E10FEXEUA 1997	IGNITION - ELECTRIC
E10FEXEUA 1997	IGNITION - ROPE
E10FRECM 1998	IGNITION -- ELECTRIC
E10FRECM 1998	IGNITION -- ROPE
E10FREDR 1996	IGNITION - ELECTRIC START
E10FREDR 1996	IGNITION - ROPE START
E10FRELECM 1998	IGNITION -- ELECTRIC
E10FRELECM 1998	IGNITION -- ROPE
E10FRELEDR 1996	IGNITION - ELECTRIC START
E10FRELEDR 1996	IGNITION - ROPE START
E10FRELEOC 1995	IGNITION - ELECTRIC START
E10FRELEOC 1995	IGNITION - ROPE START
E10FRELEUA 1997	IGNITION - ELECTRIC
E10FRELEUA 1997	IGNITION - ROPE
E10FREOC 1995	IGNITION - ELECTRIC START
E10FREOC 1995	IGNITION - ROPE START
E10FREUA 1997	IGNITION - ELECTRIC
E10FREUA 1997	IGNITION - ROPE
E10FRLECM 1998	IGNITION -- ELECTRIC
E10FRLECM 1998	IGNITION -- ROPE
E10FRLEDR 1996	IGNITION - ELECTRIC START
E10FRLEDR 1996	IGNITION - ROPE START

E10FRLEO 1995	IGNITION - ELECTRIC START
E10FRLEO 1995	IGNITION - ROPE START
E10FRLEUA 1997	IGNITION - ELECTRIC
E10FRLEUA 1997	IGNITION - ROPE
E10R4EEB 1999	IGNITION -- ROPE
E10R4EEB 1999	IGNITION -- ELECTRIC
E10R4SID 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
E10R4SID 4-stroke, rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
E10R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ROPE
E10R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ELECTRIC
E10RCCD 1988	IGNITION
E10RCDB 1986	IGNITION
E10RCES 1989	IGNITION
E10RCID 1981	MAGNETO
E10RCNS 1982	MAGNETO
E10RCOM 1985	IGNITION
E10RCRA 1984	MAGNETO
E10RCSE 1980	MAGNETO
E10RCTC 1983	MAGNETO
E10RCTR 1983	MAGNETO
E10RCUE 1987	IGNITION
E10RECC 1998	IGNITION -- ELECTRIC
E10RECC 1998	IGNITION -- ROPE
E10REDD 1996	IGNITION - ELECTRIC
E10REDD 1996	IGNITION - ROPE
E10REIR 1991	IGNITION
E10RELECC 1998	IGNITION -- ELECTRIC
E10RELECC 1998	IGNITION -- ROPE
E10RELEDD 1996	IGNITION - ELECTRIC
E10RELEDD 1996	IGNITION - ROPE
E10RELEIR 1991	IGNITION
E10RELENA 1992	IGNITION
E10RELEOE 1995	IGNITION - ELECTRIC
E10RELEOE 1995	IGNITION - ROPE
E10RELERB 1994	IGNITION - ELECTRIC

E10RELERB 1994	IGNITION - ROPE
E10RELESC 1990	IGNITION
E10RELETM 1993	IGNITION - ELECTRIC
E10RELETM 1993	IGNITION - ROPE
E10RELEUS 1997	IGNITION - ELECTRIC
E10RELEUS 1997	IGNITION - ROPE
E10RENA 1992	IGNITION
E10REOE 1995	IGNITION - ELECTRIC
E10REOE 1995	IGNITION - ROPE
E10RERB 1994	IGNITION - ELECTRIC
E10RERB 1994	IGNITION - ROPE
E10RESC 1990	IGNITION
E10RETM 1993	IGNITION - ELECTRIC
E10RETM 1993	IGNITION - ROPE
E10REUS 1997	IGNITION - ELECTRIC
E10REUS 1997	IGNITION - ROPE
E10RL4EEB 1999	IGNITION -- ROPE
E10RL4EEB 1999	IGNITION -- ELECTRIC
E10RL4SID 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
E10RL4SID 4-stroke, rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
E10RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ROPE
E10RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ELECTRIC
E10RLCCD 1988	IGNITION
E10RLCDB 1986	IGNITION
E10RLCES 1989	IGNITION
E10RLCID 1981	MAGNETO
E10RLCNS 1982	MAGNETO
E10RLCOM 1985	IGNITION
E10RLCRA 1984	MAGNETO
E10RLCSE 1980	MAGNETO
E10RLCTC 1983	MAGNETO
E10RLCUE 1987	IGNITION
E10RLECC 1998	IGNITION -- ELECTRIC
E10RLECC 1998	IGNITION -- ROPE
E10RLEDD 1996	IGNITION - ELECTRIC

E10RLEDD 1996	IGNITION - ROPE
E10RLEIR 1991	IGNITION
E10RLENA 1992	IGNITION
E10RLEOE 1995	IGNITION - ELECTRIC
E10RLEOE 1995	IGNITION - ROPE
E10RLERB 1994	IGNITION - ELECTRIC
E10RLERB 1994	IGNITION - ROPE
E10RLESC 1990	IGNITION
E10RLETM 1993	IGNITION - ELECTRIC
E10RLETM 1993	IGNITION - ROPE
E10RLEUS 1997	IGNITION - ELECTRIC
E10RLEUS 1997	IGNITION - ROPE
E10RV4SIC 4-stroke, rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
E10RV4SIC 4-stroke, rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
E10RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ROPE
E10RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ELECTRIC
E10RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
E10RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
E10RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ROPE
E10RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E10SELCCD 1988	IGNITION
E10SELCDB 1986	IGNITION
E10SELCES 1989	IGNITION
E10SELCID 1981	MAGNETO
E10SELCNS 1982	MAGNETO
E10SELCOM 1985	IGNITION
E10SELCRA 1984	MAGNETO
E10SELCSE 1980	MAGNETO
E10SELCTC 1983	MAGNETO
E10SELCUE 1987	IGNITION
E10SELECC 1998	IGNITION -- ELECTRIC
E10SELECC 1998	IGNITION -- ROPE
E10SELEDD 1996	IGNITION - ELECTRIC
E10SELEDD 1996	IGNITION - ROPE
E10SELEIR 1991	IGNITION

E10SELENA 1992	IGNITION
E10SELEOE 1995	IGNITION - ELECTRIC
E10SELEOE 1995	IGNITION - ROPE
E10SELERB 1994	IGNITION - ELECTRIC
E10SELERB 1994	IGNITION - ROPE
E10SELESC 1990	IGNITION
E10SELETM 1993	IGNITION - ELECTRIC
E10SELETM 1993	IGNITION - ROPE
E10SELEUS 1997	IGNITION - ELECTRIC
E10SELEUS 1997	IGNITION - ROPE
E10TEX4EEB 1999	IGNITION -- ROPE
E10TEX4EEB 1999	IGNITION -- ELECTRIC
E10TEX4SID 4-stroke, elec start, tiller, 25 in shaft 2001	IGNITION - ROPE
E10TEX4SID 4-stroke, elec start, tiller, 25 in shaft 2001	IGNITION - ELECTRIC
E10TEX4SSE 4-Stroke, Elec. Start, Tiller, 25 IN shaft 2000	IGNITION - ROPE
E10TEX4SSE 4-Stroke, Elec. Start, Tiller, 25 IN shaft 2000	IGNITION - ELECTRIC
E10TVX4SIC 4-stroke, elec start, tiller, 25 in shaft, wht 2001	IGNITION - ROPE
E10TVX4SIC 4-stroke, elec start, tiller, 25 in shaft, wht 2001	IGNITION - ELECTRIC
E10TVX4SSS 4-Stroke, Elec. Start, Tiller, 25 IN shaft, wht 2000	IGNITION - ROPE
E10TVX4SSS 4-Stroke, Elec. Start, Tiller, 25 IN shaft, wht 2000	IGNITION - ELECTRIC
E15DLEOC 1995	IGNITION - ELECTRIC START
E15DLEOC 1995	IGNITION - ROPE START
E15EBL4EEB 1999	IGNITION -- ROPE
E15EBL4EEB 1999	IGNITION -- ELECTRIC
E15ECCS 1988	IGNITION
E15ECDE 1986	IGNITION
E15ECEC 1989	IGNITION
E15ECIS 1981	MAGNETO
E15ECNC 1982	MAGNETO
E15ECOB 1985	IGNITION
E15ECRM 1984	MAGNETO
E15ECSD 1980	MAGNETO
E15ECTR 1983	MAGNETO
E15ECUD 1987	IGNITION
E15EECR 1998	IGNITION -- ELECTRIC

E15EECR 1998	IGNITION -- ROPE
E15EEDS 1996	IGNITION - ELECTRIC
E15EEDS 1996	IGNITION - ROPE
E15EEIA 1991	IGNITION
E15EENM 1992	IGNITION
E15EEOD 1995	IGNITION - ELECTRIC
E15EEOD 1995	IGNITION - ROPE
E15EERE 1994	IGNITION - ELECTRIC
E15EERE 1994	IGNITION - ROPE
E15EESR 1990	IGNITION
E15EETB 1993	IGNITION - ELECTRIC
E15EETB 1993	IGNITION - ROPE
E15EEUC 1997	IGNITION - ELECTRIC
E15EEUC 1997	IGNITION - ROPE
E15EL4EEB 1999	IGNITION -- ROPE
E15EL4EEB 1999	IGNITION -- ELECTRIC
E15EL4SID 4-stroke, elec start, 20 in shaft 2001	IGNITION - ROPE
E15EL4SID 4-stroke, elec start, 20 in shaft 2001	IGNITION - ELECTRIC
E15EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ROPE
E15EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	IGNITION - ELECTRIC
E15ELCCS 1988	IGNITION
E15ELCDE 1986	IGNITION
E15ELCEC 1989	IGNITION
E15ELCOB 1985	IGNITION
E15ELCRM 1984	MAGNETO
E15ELCSD 1980	MAGNETO
E15ELCTR 1983	MAGNETO
E15ELCUD 1987	IGNITION
E15ELECR 1998	IGNITION -- ELECTRIC
E15ELECR 1998	IGNITION -- ROPE
E15ELEDS 1996	IGNITION - ELECTRIC
E15ELEDS 1996	IGNITION - ROPE
E15ELEIA 1991	IGNITION
E15ELENM 1992	IGNITION
E15ELEOD 1995	IGNITION - ELECTRIC



E15ELEOD 1995	IGNITION - ROPE
E15ELERE 1994	IGNITION - ELECTRIC
E15ELERE 1994	IGNITION - ROPE
E15ELESR 1990	IGNITION
E15ELETB 1993	IGNITION - ELECTRIC
E15ELETB 1993	IGNITION - ROPE
E15ELEUC 1997	IGNITION - ELECTRIC
E15ELEUC 1997	IGNITION - ROPE
E15EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ROPE
E15EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
E15EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ROPE
E15EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E15FKEDR 1996	IGNITION - ELECTRIC START
E15FKEDR 1996	IGNITION - ROPE START
E15FKEUA 1997	IGNITION - ELECTRIC
E15FKEUA 1997	IGNITION - ROPE
E15FRECM 1998	IGNITION -- ELECTRIC
E15FRECM 1998	IGNITION -- ROPE
E15FREDR 1996	IGNITION - ELECTRIC START
E15FREDR 1996	IGNITION - ROPE START
E15FRELECM 1998	IGNITION -- ELECTRIC
E15FRELECM 1998	IGNITION -- ROPE
E15FRELEDR 1996	IGNITION - ELECTRIC START
E15FRELEDR 1996	IGNITION - ROPE START
E15FRELEUA 1997	IGNITION - ELECTRIC
E15FRELEUA 1997	IGNITION - ROPE
E15FREOC 1995	IGNITION - ELECTRIC START
E15FREOC 1995	IGNITION - ROPE START
E15FREUA 1997	IGNITION - ELECTRIC
E15FREUA 1997	IGNITION - ROPE
E15FRLECM 1998	IGNITION -- ELECTRIC
E15FRLECM 1998	IGNITION -- ROPE
E15FRLEDR 1996	IGNITION - ELECTRIC START
E15FRLEDR 1996	IGNITION - ROPE START
E15FRLEOC 1995	IGNITION - ELECTRIC START

E15FRLEOC 1995	IGNITION - ROPE START
E15FRLEUA 1997	IGNITION - ELECTRIC
E15FRLEUA 1997	IGNITION - ROPE
E15KEOC 1995	IGNITION - ELECTRIC START
E15KEOC 1995	IGNITION - ROPE START
E15R4EEB 1999	IGNITION -- ROPE
E15R4EEB 1999	IGNITION -- ELECTRIC
E15R4SID 4-stroke, rope start, 15 in shaft 2001	IGNITION - ROPE
E15R4SID 4-stroke, rope start, 15 in shaft 2001	IGNITION - ELECTRIC
E15R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ROPE
E15R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	IGNITION - ELECTRIC
E15RB4EEB 1999	IGNITION -- ROPE
E15RB4EEB 1999	IGNITION -- ELECTRIC
E15RBL4EEB 1999	IGNITION -- ROPE
E15RBL4EEB 1999	IGNITION -- ELECTRIC
E15RCCS 1988	IGNITION
E15RCDE 1986	IGNITION
E15RCEC 1989	IGNITION
E15RCIS 1981	MAGNETO
E15RCNC 1982	MAGNETO
E15RCOB 1985	IGNITION
E15RCRM 1984	MAGNETO
E15RCSD 1980	MAGNETO
E15RCTA 1983	MAGNETO
E15RCTR 1983	MAGNETO
E15RCUD 1987	IGNITION
E15RECR 1998	IGNITION -- ELECTRIC
E15RECR 1998	IGNITION -- ROPE
E15REDS 1996	IGNITION - ELECTRIC
E15REDS 1996	IGNITION - ROPE
E15REIA 1991	IGNITION
E15RELECR 1998	IGNITION -- ELECTRIC
E15RELECR 1998	IGNITION -- ROPE
E15RELEDS 1996	IGNITION - ELECTRIC
E15RELEDS 1996	IGNITION - ROPE

E15RELEIA 1991	IGNITION
E15RELENM 1992	IGNITION
E15RELEOD 1995	IGNITION - ELECTRIC
E15RELEOD 1995	IGNITION - ROPE
E15RELERE 1994	IGNITION - ELECTRIC
E15RELERE 1994	IGNITION - ROPE
E15RELESR 1990	IGNITION
E15RELETB 1993	IGNITION - ELECTRIC
E15RELETB 1993	IGNITION - ROPE
E15RELEUC 1997	IGNITION - ELECTRIC
E15RELEUC 1997	IGNITION - ROPE
E15RENM 1992	IGNITION
E15REOD 1995	IGNITION - ELECTRIC
E15REOD 1995	IGNITION - ROPE
E15RERE 1994	IGNITION - ELECTRIC
E15RERE 1994	IGNITION - ROPE
E15RESR 1990	IGNITION
E15RETB 1993	IGNITION - ELECTRIC
E15RETB 1993	IGNITION - ROPE
E15REUC 1997	IGNITION - ELECTRIC
E15REUC 1997	IGNITION - ROPE
E15RL4EEB 1999	IGNITION -- ROPE
E15RL4EEB 1999	IGNITION -- ELECTRIC
E15RL4SID 4-stroke, rope start, 20 in shaft 2001	IGNITION - ROPE
E15RL4SID 4-stroke, rope start, 20 in shaft 2001	IGNITION - ELECTRIC
E15RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ROPE
E15RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	IGNITION - ELECTRIC
E15RLCCS 1988	IGNITION
E15RLCDE 1986	IGNITION
E15RLCEC 1989	IGNITION
E15RLCIS 1981	MAGNETO
E15RLCNC 1982	MAGNETO
E15RLCOB 1985	IGNITION
E15RLCRM 1984	MAGNETO
E15RLCSD 1980	MAGNETO

E15RLCTA 1983	MAGNETO
E15RLCTR 1983	MAGNETO
E15RLCUD 1987	IGNITION
E15RLECR 1998	IGNITION -- ELECTRIC
E15RLECR 1998	IGNITION -- ROPE
E15RLEDS 1996	IGNITION - ELECTRIC
E15RLEDS 1996	IGNITION - ROPE
E15RLEIA 1991	IGNITION
E15RLENM 1992	IGNITION
E15RLEOD 1995	IGNITION - ELECTRIC
E15RLEOD 1995	IGNITION - ROPE
E15RLERE 1994	IGNITION - ELECTRIC
E15RLERE 1994	IGNITION - ROPE
E15RLESR 1990	IGNITION
E15RLETB 1993	IGNITION - ELECTRIC
E15RLETB 1993	IGNITION - ROPE
E15RLEUC 1997	IGNITION - ELECTRIC
E15RLEUC 1997	IGNITION - ROPE
E15RV4SIC 4-stroke,rope start, 15 in shaft, wht 2001	IGNITION - ROPE
E15RV4SIC 4-stroke,rope start, 15 in shaft, wht 2001	IGNITION - ELECTRIC
E15RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ROPE
E15RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	IGNITION - ELECTRIC
E15RVL4SIC 4-stroke, elec start, 15 in shaft, wht 2001	IGNITION - ROPE
E15RVL4SIC 4-stroke, elec start, 15 in shaft, wht 2001	IGNITION - ELECTRIC
E15RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ROPE
E15RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	IGNITION - ELECTRIC
E15WREES 1999	IGNITION
E15WRLEES 1999	IGNITION
E15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
E15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
HE15KCF 1997	IGNITION
HE15KCLF 1997	IGNITION
HE15KCLN 1996	IGNITION

HE15KCLO 1998	IGNITION
HE15KCN 1996	IGNITION
HE15KCO 1998	IGNITION
HE15RPLW 1997	IGNITION
HE15RPW 1997	IGNITION
HJ15KCF 1997	IGNITION
HJ15KCLF 1997	IGNITION
HJ15KCLN 1996	IGNITION
HJ15KCLO 1998	IGNITION
HJ15KCN 1996	IGNITION
HJ15KCO 1998	IGNITION
HJ15RPLW 1997	IGNITION
HJ15RPW 1997	IGNITION
J10ECCD 1988	IGNITION
J10ECDB 1986	IGNITION
J10ECES 1989	IGNITION
J10ECOM 1985	IGNITION
J10ECSE 1980	MAGNETO
J10ECUE 1987	IGNITION
J10EECC 1998	IGNITION -- ELECTRIC
J10EECC 1998	IGNITION -- ROPE
J10EEDD 1996	IGNITION - ELECTRIC
J10EEDD 1996	IGNITION - ROPE
J10EEIR 1991	IGNITION
J10EENA 1992	IGNITION
J10EEOE 1995	IGNITION - ELECTRIC
J10EEOE 1995	IGNITION - ROPE
J10EERB 1994	IGNITION - ELECTRIC
J10EERB 1994	IGNITION - ROPE
J10EESC 1990	IGNITION
J10EETM 1993	IGNITION - ELECTRIC
J10EETM 1993	IGNITION - ROPE
J10EEUS 1997	IGNITION - ELECTRIC
J10EEUS 1997	IGNITION - ROPE
J10ELCCD 1988	IGNITION

J10ELCDB 1986	IGNITION
J10ELCES 1989	IGNITION
J10ELCID 1981	MAGNETO
J10ELCNS 1982	MAGNETO
J10ELCOM 1985	IGNITION
J10ELCRA 1984	MAGNETO
J10ELCSE 1980	MAGNETO
J10ELCTC 1983	MAGNETO
J10ELCUE 1987	IGNITION
J10ELECC 1998	IGNITION -- ELECTRIC
J10ELECC 1998	IGNITION -- ROPE
J10ELEDD 1996	IGNITION - ELECTRIC
J10ELEDD 1996	IGNITION - ROPE
J10ELEER 1999	IGNITION -- ROPE
J10ELEER 1999	IGNITION -- ELECTRIC
J10ELEIR 1991	IGNITION
J10ELENA 1992	IGNITION
J10ELEOE 1995	IGNITION - ELECTRIC
J10ELEOE 1995	IGNITION - ROPE
J10ELERB 1994	IGNITION - ELECTRIC
J10ELERB 1994	IGNITION - ROPE
J10ELESC 1990	IGNITION
J10ELETM 1993	IGNITION - ELECTRIC
J10ELETM 1993	IGNITION - ROPE
J10ELEUS 1997	IGNITION - ELECTRIC
J10ELEUS 1997	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION - ROPE
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10EVLISIC elec start, 20 in shaft, wht 2001	IGNITION - ROPE
J10EVLISIC elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10FEXECM 1998	IGNITION -- ELECTRIC

J10FEXECM 1998	IGNITION -- ROPE
J10FEXEDR 1996	IGNITION - ELECTRIC START
J10FEXEDR 1996	IGNITION - ROPE START
J10FEXEO 1995	IGNITION - ELECTRIC START
J10FEXEO 1995	IGNITION - ROPE START
J10FEXEUA 1997	IGNITION - ELECTRIC
J10FEXEUA 1997	IGNITION - ROPE
J10FRECM 1998	IGNITION -- ELECTRIC
J10FRECM 1998	IGNITION -- ROPE
J10FREDR 1996	IGNITION - ELECTRIC START
J10FREDR 1996	IGNITION - ROPE START
J10FRELECM 1998	IGNITION -- ELECTRIC
J10FRELECM 1998	IGNITION -- ROPE
J10FRELEDR 1996	IGNITION - ELECTRIC START
J10FRELEDR 1996	IGNITION - ROPE START
J10FRELEOC 1995	IGNITION - ELECTRIC START
J10FRELEOC 1995	IGNITION - ROPE START
J10FRELEUA 1997	IGNITION - ELECTRIC
J10FRELEUA 1997	IGNITION - ROPE
J10FREOC 1995	IGNITION - ELECTRIC START
J10FREOC 1995	IGNITION - ROPE START
J10FREUA 1997	IGNITION - ELECTRIC
J10FREUA 1997	IGNITION - ROPE
J10FRLECM 1998	IGNITION -- ELECTRIC
J10FRLECM 1998	IGNITION -- ROPE
J10FRLEDR 1996	IGNITION - ELECTRIC START
J10FRLEDR 1996	IGNITION - ROPE START
J10FRLEO 1995	IGNITION - ELECTRIC START
J10FRLEO 1995	IGNITION - ROPE START
J10FRLEUA 1997	IGNITION - ELECTRIC
J10FRLEUA 1997	IGNITION - ROPE
J10RCCD 1988	IGNITION
J10RCDB 1986	IGNITION
J10RCES 1989	IGNITION
J10RCID 1981	MAGNETO

J10RCNS 1982	MAGNETO
J10RCOM 1985	IGNITION
J10RCRA 1984	MAGNETO
J10RCSE 1980	MAGNETO
J10RCTC 1983	MAGNETO
J10RCTR 1983	MAGNETO
J10RCUE 1987	IGNITION
J10RECC 1998	IGNITION -- ELECTRIC
J10RECC 1998	IGNITION -- ROPE
J10REDD 1996	IGNITION - ELECTRIC
J10REDD 1996	IGNITION - ROPE
J10REER 1999	IGNITION -- ROPE
J10REER 1999	IGNITION -- ELECTRIC
J10REIR 1991	IGNITION
J10RELECC 1998	IGNITION -- ELECTRIC
J10RELECC 1998	IGNITION -- ROPE
J10RELEDD 1996	IGNITION - ELECTRIC
J10RELEDD 1996	IGNITION - ROPE
J10RELEIR 1991	IGNITION
J10RELENA 1992	IGNITION
J10RELEOE 1995	IGNITION - ELECTRIC
J10RELEOE 1995	IGNITION - ROPE
J10RELERB 1994	IGNITION - ELECTRIC
J10RELERB 1994	IGNITION - ROPE
J10RELESC 1990	IGNITION
J10RELETM 1993	IGNITION - ELECTRIC
J10RELETM 1993	IGNITION - ROPE
J10RELEUS 1997	IGNITION - ELECTRIC
J10RELEUS 1997	IGNITION - ROPE
J10RENA 1992	IGNITION
J10REOE 1995	IGNITION - ELECTRIC
J10REOE 1995	IGNITION - ROPE
J10RERB 1994	IGNITION - ELECTRIC
J10RERB 1994	IGNITION - ROPE
J10RESC 1990	IGNITION



J10RETM 1993	IGNITION - ELECTRIC
J10RETM 1993	IGNITION - ROPE
J10REUS 1997	IGNITION - ELECTRIC
J10REUS 1997	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10RLCCD 1988	IGNITION
J10RLCDB 1986	IGNITION
J10RLCES 1989	IGNITION
J10RLCID 1981	MAGNETO
J10RLCNS 1982	MAGNETO
J10RLCOM 1985	IGNITION
J10RLCRA 1984	MAGNETO
J10RLCSE 1980	MAGNETO
J10RLCTC 1983	MAGNETO
J10RLCTR 1983	MAGNETO
J10RLCUE 1987	IGNITION
J10RLECC 1998	IGNITION -- ELECTRIC
J10RLECC 1998	IGNITION -- ROPE
J10RLEDD 1996	IGNITION - ELECTRIC
J10RLEDD 1996	IGNITION - ROPE
J10RLEER 1999	IGNITION -- ROPE
J10RLEER 1999	IGNITION -- ELECTRIC
J10RLEIR 1991	IGNITION
J10RLENA 1992	IGNITION
J10RLEOE 1995	IGNITION - ELECTRIC
J10RLEOE 1995	IGNITION - ROPE
J10RLERB 1994	IGNITION - ELECTRIC
J10RLERB 1994	IGNITION - ROPE
J10RLESC 1990	IGNITION
J10RLETM 1993	IGNITION - ELECTRIC
J10RLETM 1993	IGNITION - ROPE
J10RLEUS 1997	IGNITION - ELECTRIC

J10RLEUS 1997	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ELECTRIC
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10RLSDC	IGNITION
J10RLSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10RLSOS	IGNITION
J10RLSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSRD	IGNITION
J10RLSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10RLSTE	IGNITION
J10RLSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSUR	IGNITION
J10RLSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RSDC	IGNITION
J10RSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10RSOS	IGNITION
J10RSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSRD	IGNITION
J10RSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10RSTE	IGNITION
J10RSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSUR	IGNITION
J10RSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC

J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10SELCCD 1988	IGNITION
J10SELCDB 1986	IGNITION
J10SELCES 1989	IGNITION
J10SELCID 1981	MAGNETO
J10SELCNS 1982	MAGNETO
J10SELCOM 1985	IGNITION
J10SELCRA 1984	MAGNETO
J10SELCSE 1980	MAGNETO
J10SELCTC 1983	MAGNETO
J10SELCUE 1987	IGNITION
J10SELECC 1998	IGNITION -- ELECTRIC
J10SELECC 1998	IGNITION -- ROPE
J10SELEDD 1996	IGNITION - ELECTRIC
J10SELEDD 1996	IGNITION - ROPE
J10SELEIR 1991	IGNITION
J10SELENA 1992	IGNITION
J10SELEOE 1995	IGNITION - ELECTRIC
J10SELEOE 1995	IGNITION - ROPE
J10SELERB 1994	IGNITION - ELECTRIC
J10SELERB 1994	IGNITION - ROPE
J10SELESC 1990	IGNITION
J10SELETM 1993	IGNITION - ELECTRIC
J10SELETM 1993	IGNITION - ROPE
J10SELEUS 1997	IGNITION - ELECTRIC
J10SELEUS 1997	IGNITION - ROPE
J10TEEER 1999	IGNITION -- ROPE
J10TEEER 1999	IGNITION -- ELECTRIC
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC

J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10TELEER 1999	IGNITION -- ROPE
J10TELEER 1999	IGNITION -- ELECTRIC
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15DLEOC 1995	IGNITION - ELECTRIC START
J15DLEOC 1995	IGNITION - ROPE START
J15ECCS 1988	IGNITION
J15ECDE 1986	IGNITION
J15ECEC 1989	IGNITION
J15ECIS 1981	MAGNETO
J15ECNC 1982	MAGNETO
J15ECOB 1985	IGNITION
J15ECRM 1984	MAGNETO
J15ECSO 1980	MAGNETO
J15ECTR 1983	MAGNETO
J15ECUD 1987	IGNITION
J15EECR 1998	IGNITION -- ELECTRIC
J15EECR 1998	IGNITION -- ROPE
J15EEDS 1996	IGNITION - ELECTRIC
J15EEDS 1996	IGNITION - ROPE
J15EEIA 1991	IGNITION
J15EENM 1992	IGNITION
J15EEOD 1995	IGNITION - ELECTRIC
J15EEOD 1995	IGNITION - ROPE
J15EERE 1994	IGNITION - ELECTRIC

J15EERE 1994	IGNITION - ROPE
J15EESR 1990	IGNITION
J15EETB 1993	IGNITION - ELECTRIC
J15EETB 1993	IGNITION - ROPE
J15EEUC 1997	IGNITION - ELECTRIC
J15EEUC 1997	IGNITION - ROPE
J15ELCCS 1988	IGNITION
J15ELCDE 1986	IGNITION
J15ELCEC 1989	IGNITION
J15ELCOB 1985	IGNITION
J15ELCRM 1984	MAGNETO
J15ELCSD 1980	MAGNETO
J15ELCTR 1983	MAGNETO
J15ELCUD 1987	IGNITION
J15ELECR 1998	IGNITION -- ELECTRIC
J15ELECR 1998	IGNITION -- ROPE
J15ELEDS 1996	IGNITION - ELECTRIC
J15ELEDS 1996	IGNITION - ROPE
J15ELEEA 1999	IGNITION -- ROPE
J15ELEEA 1999	IGNITION -- ELECTRIC
J15ELEIA 1991	IGNITION
J15ELENM 1992	IGNITION
J15ELEOD 1995	IGNITION - ELECTRIC
J15ELEOD 1995	IGNITION - ROPE
J15ELERE 1994	IGNITION - ELECTRIC
J15ELERE 1994	IGNITION - ROPE
J15ELESR 1990	IGNITION
J15ELETB 1993	IGNITION - ELECTRIC
J15ELETB 1993	IGNITION - ROPE
J15ELEUC 1997	IGNITION - ELECTRIC
J15ELEUC 1997	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION - ROPE
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION-ELECTRIC

J15EVLSIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ROPE
J15EVLSIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15FKEDR 1996	IGNITION - ELECTRIC START
J15FKEDR 1996	IGNITION - ROPE START
J15FKEUA 1997	IGNITION - ELECTRIC
J15FKEUA 1997	IGNITION - ROPE
J15FRECM 1998	IGNITION -- ELECTRIC
J15FRECM 1998	IGNITION -- ROPE
J15FREDR 1996	IGNITION - ELECTRIC START
J15FREDR 1996	IGNITION - ROPE START
J15FRELECM 1998	IGNITION -- ELECTRIC
J15FRELECM 1998	IGNITION -- ROPE
J15FRELEDR 1996	IGNITION - ELECTRIC START
J15FRELEDR 1996	IGNITION - ROPE START
J15FRELEUA 1997	IGNITION - ELECTRIC
J15FRELEUA 1997	IGNITION - ROPE
J15FREOC 1995	IGNITION - ELECTRIC START
J15FREOC 1995	IGNITION - ROPE START
J15FREUA 1997	IGNITION - ELECTRIC
J15FREUA 1997	IGNITION - ROPE
J15FRLECM 1998	IGNITION -- ELECTRIC
J15FRLECM 1998	IGNITION -- ROPE
J15FRLEDR 1996	IGNITION - ELECTRIC START
J15FRLEDR 1996	IGNITION - ROPE START
J15FRLEOC 1995	IGNITION - ELECTRIC START
J15FRLEOC 1995	IGNITION - ROPE START
J15FRLEUA 1997	IGNITION - ELECTRIC
J15FRLEUA 1997	IGNITION - ROPE
J15KEOC 1995	IGNITION - ELECTRIC START
J15KEOC 1995	IGNITION - ROPE START
J15RCCS 1988	IGNITION
J15RCDE 1986	IGNITION
J15RCEC 1989	IGNITION

J15RCIS 1981	MAGNETO
J15RCNC 1982	MAGNETO
J15RCOB 1985	IGNITION
J15RCRM 1984	MAGNETO
J15RCSD 1980	MAGNETO
J15RCTA 1983	MAGNETO
J15RCTR 1983	MAGNETO
J15RCUD 1987	IGNITION
J15RECR 1998	IGNITION -- ELECTRIC
J15RECR 1998	IGNITION -- ROPE
J15REDS 1996	IGNITION - ELECTRIC
J15REDS 1996	IGNITION - ROPE
J15REEA 1999	IGNITION -- ROPE
J15REEA 1999	IGNITION -- ELECTRIC
J15REIA 1991	IGNITION
J15RELECR 1998	IGNITION -- ELECTRIC
J15RELECR 1998	IGNITION -- ROPE
J15RELEDS 1996	IGNITION - ELECTRIC
J15RELEDS 1996	IGNITION - ROPE
J15RELEIA 1991	IGNITION
J15RELENM 1992	IGNITION
J15RELEOD 1995	IGNITION - ELECTRIC
J15RELEOD 1995	IGNITION - ROPE
J15RELERE 1994	IGNITION - ELECTRIC
J15RELERE 1994	IGNITION - ROPE
J15RELESR 1990	IGNITION
J15RELETB 1993	IGNITION - ELECTRIC
J15RELETB 1993	IGNITION - ROPE
J15RELEUC 1997	IGNITION - ELECTRIC
J15RELEUC 1997	IGNITION - ROPE
J15RENM 1992	IGNITION
J15REOD 1995	IGNITION - ELECTRIC
J15REOD 1995	IGNITION - ROPE
J15RERE 1994	IGNITION - ELECTRIC
J15RERE 1994	IGNITION - ROPE

J15RESR 1990	IGNITION
J15RETB 1993	IGNITION - ELECTRIC
J15RETB 1993	IGNITION - ROPE
J15REUC 1997	IGNITION - ELECTRIC
J15REUC 1997	IGNITION - ROPE
J15RLCCS 1988	IGNITION
J15RLCDE 1986	IGNITION
J15RLCEC 1989	IGNITION
J15RLCIS 1981	MAGNETO
J15RLCNC 1982	MAGNETO
J15RLCOB 1985	IGNITION
J15RLCRM 1984	MAGNETO
J15RLCSD 1980	MAGNETO
J15RLCTA 1983	MAGNETO
J15RLCTR 1983	MAGNETO
J15RLCUD 1987	IGNITION
J15RLECR 1998	IGNITION -- ELECTRIC
J15RLECR 1998	IGNITION -- ROPE
J15RLEDS 1996	IGNITION - ELECTRIC
J15RLEDS 1996	IGNITION - ROPE
J15RLEEA 1999	IGNITION -- ROPE
J15RLEEA 1999	IGNITION -- ELECTRIC
J15RLEIA 1991	IGNITION
J15RLENM 1992	IGNITION
J15RLEOD 1995	IGNITION - ELECTRIC
J15RLEOD 1995	IGNITION - ROPE
J15RLERE 1994	IGNITION - ELECTRIC
J15RLERE 1994	IGNITION - ROPE
J15RLESR 1990	IGNITION
J15RLETB 1993	IGNITION - ELECTRIC
J15RLETB 1993	IGNITION - ROPE
J15RLEUC 1997	IGNITION - ELECTRIC
J15RLEUC 1997	IGNITION - ROPE
J15RLSDR	IGNITION
J15RLSDR - FR	22-5_SYSTÈME D'ALLUMAGE



J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15RLSOC	IGNITION
J15RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSRS	IGNITION
J15RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15RLSTD	IGNITION
J15RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSUA	IGNITION
J15RLSUA - FR	02-5_SYSTÈME D'ALLUMAGE
J15RSDR	IGNITION
J15RSDR - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15RSOC	IGNITION
J15RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSRS	IGNITION
J15RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15RSTD	IGNITION
J15RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSUA	IGNITION
J15RSUA - FR	02-5_SYSTÈME D'ALLUMAGE
J15RTSDC	IGNITION
J15RTSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RTSOS	IGNITION
J15RTSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RTSUR	IGNITION
J15RTSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE

J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15TEEEA 1999	IGNITION -- ROPE
J15TEEEA 1999	IGNITION -- ELECTRIC
J15TELEEA 1999	IGNITION -- ROPE
J15TELEEA 1999	IGNITION -- ELECTRIC
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15WREES 1999	IGNITION
J15WRLEES 1999	IGNITION
J15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J15WRLSOB	IGNITION
J15WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSRM	IGNITION
J15WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
J15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J15WRSOB	IGNITION
J15WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSRM	IGNITION
J15WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
L10FRELECM 1998	IGNITION -- ELECTRIC
L10FRELECM 1998	IGNITION -- ROPE

L10FRELEDR 1996	IGNITION - ELECTRIC START
L10FRELEDR 1996	IGNITION - ROPE START
L10FRELEUA 1997	IGNITION - ELECTRIC
L10FRELEUA 1997	IGNITION - ROPE
SE10RPB 1996	IGNITION
SE10RPLB 1996	IGNITION
SE10RPLT 1997	IGNITION
SE10RPLY 1998	IGNITION
SE10RPT 1997	IGNITION
SE10RPY 1998	IGNITION
SE15BAECA 1998	IGNITION -- ELECTRIC
SE15BAECA 1998	IGNITION -- ROPE
SE15BAEDC 1996	IGNITION - ELECTRIC
SE15BAEDC 1996	IGNITION - ROPE
SE15BAEEM 1999	IGNITION -- ROPE
SE15BAEEM 1999	IGNITION -- ELECTRIC
SE15BAEUR 1997	IGNITION - ELECTRIC
SE15BAEUR 1997	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
SE15RPC 1998	IGNITION
SE15RPG 1996	IGNITION
SE15RPLC 1998	IGNITION
SE15RPLG 1996	IGNITION
SE15RPLW 1997	IGNITION
SE15RPW 1997	IGNITION
SJ10REDD 1996	IGNITION - ELECTRIC
SJ10REDD 1996	IGNITION - ROPE
SJ10REDD 1996	IGNITION - ELECTRIC
SJ10REDD 1996	IGNITION - ROPE
SJ10RPB 1996	IGNITION
SJ10RPLB 1996	IGNITION
SJ10RPLT 1997	IGNITION

SJ10RPLY 1998	IGNITION
SJ10RPT 1997	IGNITION
SJ10RPY 1998	IGNITION
SJ10SELEDD 1996	IGNITION - ELECTRIC
SJ10SELEDD 1996	IGNITION - ROPE
SJ15BAECA 1998	IGNITION -- ELECTRIC
SJ15BAECA 1998	IGNITION -- ROPE
SJ15BAEDC 1996	IGNITION - ELECTRIC
SJ15BAEDC 1996	IGNITION - ROPE
SJ15BAEEM 1999	IGNITION -- ROPE
SJ15BAEEM 1999	IGNITION -- ELECTRIC
SJ15BAEUR 1997	IGNITION - ELECTRIC
SJ15BAEUR 1997	IGNITION - ROPE
SJ15REDS 1996	IGNITION - ELECTRIC
SJ15REDS 1996	IGNITION - ROPE
SJ15RLEDS 1996	IGNITION - ELECTRIC
SJ15RLEDS 1996	IGNITION - ROPE
SJ15RPC 1998	IGNITION
SJ15RPG 1996	IGNITION
SJ15RPLC 1998	IGNITION
SJ15RPLG 1996	IGNITION
SJ15RPLW 1997	IGNITION
SJ15RPW 1997	IGNITION
SJ15RTEEM 1999	IGNITION -- ROPE
SJ15RTEEM 1999	IGNITION -- ELECTRIC
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
TE10ELCES 1989	IGNITION
TE10ELESC 1990	IGNITION
TE10RELEIR 1991	IGNITION
TE10RELENA 1992	IGNITION
TE10RELESC 1990	IGNITION
TE10RELETM 1993	IGNITION - ELECTRIC

TE10RELETM 1993	IGNITION - ROPE
TE10RLCES 1989	IGNITION
TE10RLESC 1990	IGNITION
TE15RLCEC 1989	IGNITION
TJ10ELCES 1989	IGNITION
TJ10ELESC 1990	IGNITION
TJ10RELEIR 1991	IGNITION
TJ10RELENA 1992	IGNITION
TJ10RELESC 1990	IGNITION
TJ10RELETM 1993	IGNITION - ELECTRIC
TJ10RELETM 1993	IGNITION - ROPE
TJ10RLCES 1989	IGNITION
TJ10RLESC 1990	IGNITION
TJ15RLCEC 1989	IGNITION
VE14RCCS 1988	MAGNETO
VE14RCEC 1989	IGNITION
VJ14RCCS 1988	MAGNETO
VJ14RCEC 1989	IGNITION