

Where Used: Part Number 0303395

Model Name	Diagram
6002B 1970	GEARCASE GROUP
6003B 1970	GEARCASE GROUP
6102E 1971	GEARCASE
6102G 1971	GEARCASE
6103E 1971	GEARCASE
6103G 1971	GEARCASE
6202D 1972	GEARCASE
6203D 1972	GEARCASE
6302S 1973	GEARCASE
6303S 1973	GEARCASE
6402C 1974	GEARCASE
6403C 1974	GEARCASE
6504R 1975	GEARCASE
6505R 1975	GEARCASE
6604A 1976	GEARCASE
6605A 1976	GEARCASE
6704M 1977	GEARCASE
6705M 1977	GEARCASE
6802A 1968	GEARCASE GROUP
6802C 1968	GEARCASE GROUP
6802R 1968	GEARCASE GROUP
6803A 1968	GEARCASE GROUP
6803C 1968	GEARCASE GROUP
6803R 1968	GEARCASE GROUP
6804B 1978	GEARCASE
6805B 1978	GEARCASE
6902M 1969	GEARCASE GROUP
6903M 1969	GEARCASE GROUP
6R69M 1969	GEARCASE GROUP
6R70B 1970	GEARCASE GROUP
6R71E 1971	GEARCASE
6R71G 1971	GEARCASE
6R72D 1972	GEARCASE

6R73S 1973	GEARCASE
6R74C 1974	GEARCASE
6R75R 1975	GEARCASE
6R76A 1976	GEARCASE
6R77M 1977	GEARCASE
6R78B 1978	GEARCASE
6RL69M 1969	GEARCASE GROUP
6RL70B 1970	GEARCASE GROUP
6RL71E 1971	GEARCASE
6RL71G 1971	GEARCASE
6RL72 1972	GEARCASE
6RL73S 1973	GEARCASE
6RL74C 1974	GEARCASE
6RL75R 1975	GEARCASE
6RL76A 1976	GEARCASE
6RL77M 1977	GEARCASE
6RL78B 1978	GEARCASE
9022A 1970	GEARCASE GROUP
9022C 1970	GEARCASE GROUP
9023A 1970	GEARCASE GROUP
9023C 1970	GEARCASE GROUP
9122R 1971	GEARCASE
9123R 1971	GEARCASE
9222M 1972	GEARCASE
9223M 1972	GEARCASE
9322B 1973	GEARCASE
9323B 1973	GEARCASE
9822D 1968	GEARCASE GROUP
9822E 1968	GEARCASE GROUP
9823D 1968	GEARCASE GROUP
9823E 1968	GEARCASE GROUP
9922S 1969	GEARCASE GROUP
9923S 1969	GEARCASE GROUP
9R69S 1969	GEARCASE GROUP
9R70A 1970	GEARCASE GROUP

9R70C 1970	GEARCASE GROUP
9R71R 1971	GEARCASE
9R72M 1972	GEARCASE
9R73B 1973	GEARCASE
9RL69S 1969	GEARCASE GROUP
9RL70A 1970	GEARCASE GROUP
9RL70C 1970	GEARCASE GROUP
9RL71R 1971	GEARCASE
9RL72M 1972	GEARCASE
9RL73B 1973	GEARCASE
CD-25A 1968	GEARCASE GROUP
CD-25C 1968	GEARCASE GROUP
CD-25R 1968	GEARCASE GROUP
CDL-25A 1968	GEARCASE GROUP
CDL-25C 1968	GEARCASE GROUP
CDL-25R 1968	GEARCASE GROUP
D100WTLM 1988	CYLINDER & CRANKCASE
D100WTXM 1988	CYLINDER & CRANKCASE
E100STLCCA 1988	CYLINDER & CRANKCASE
E100WMLCDR 1986	CYLINDER & CRANKCASE
E100WTLCDR 1986	CYLINDER & CRANKCASE
E100WTLCUA 1987	CYLINDER & CRANKCASE
E100WTXCDR 1986	CYLINDER & CRANKCASE
E100WTXCUA 1987	CYLINDER & CRANKCASE
E110MLCCA 1988	CYLINDER & CRANKCASE
E110MLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
E110MLCUR 1987	CYLINDER & CRANKCASE
E110TLCCA 1988	CYLINDER & CRANKCASE
E110TLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
E110TLCDF 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
E110TLCUR 1987	CYLINDER & CRANKCASE
E110TXCCA 1988	CYLINDER & CRANKCASE
E110TXCUR 1987	CYLINDER & CRANKCASE
E50TTLECA 1998	SHIFT & THROTTLE LINKAGE
E50TTLEDC 1996	SHIFT & THROTTLE LINKAGE

E50TTLEOS 1995	SHIFT & THROTTLE LINKAGE
E50TTLEUR 1997	SHIFT & THROTTLE LINKAGE
E60ELCCR 1988	SHIFT & THROTTLE LINKAGE - 60 TTLC MODELS ONLY
E60ELCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
E60ELES M 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
E60TLCCR 1988	SHIFT & THROTTLE LINKAGE - 60 TTLC MODELS ONLY
E60TLCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
E60TLES M 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
E60TTLCCR 1988	SHIFT & THROTTLE LINKAGE - 60 TTLC MODELS ONLY
E60TTLCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
E60TTLECM 1998	SHIFT & THROTTLE LINKAGE
E60TTLEDR 1996	SHIFT & THROTTLE LINKAGE
E60TTLEIB 1991	SHIFT & THROTTLE LINKAGE
E60TTLENE 1992	SHIFT & THROTTLE LINKAGE
E60TTLEOC 1995	SHIFT & THROTTLE LINKAGE
E60TTLERS 1994	SHIFT & THROTTLE LINKAGE
E60TTLERV 1994	SHIFT & THROTTLE LINKAGE
E60TTLES M 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
E60TTLETD 1993	SHIFT & THROTTLE LINKAGE
E60TTLEUA 1997	SHIFT & THROTTLE LINKAGE
E65RSLC 1995	SHIFT & THROTTLE LINKAGE
E65RSLM 1996	SHIFT & THROTTLE LINKAGE
E65RSLZ2 1997	SHIFT & THROTTLE LINKAGE
E65RWLC DR 1986	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
E65RWLCOC 1985	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
E65TELC DR 1986	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
E65TELCOC 1985	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
E65WRLEEO 1999	SHIFT & THROTTLE LINKAGE
E65WRLEES 1999	SHIFT & THROTTLE LINKAGE
E65WRLSIR commercial, rope start, 20 in shaft 2001	SHIFT & THROTTLE LINKAGE
E65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	SHIFT AND THROTTLE LINKAGE
E65WRYEEO 1999	SHIFT & THROTTLE LINKAGE
E65WRYEES 1999	SHIFT & THROTTLE LINKAGE

E65WRYSIR commercial, rope start, 22.5 in shaft 2001	SHIFT & THROTTLE LINKAGE
E65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	SHIFT AND THROTTLE LINKAGE
E70TTLEIE 1991	SHIFT & THROTTLE LINKAGE
E70TTLEND 1992	SHIFT & THROTTLE LINKAGE
E70TTLEOR 1995	SHIFT & THROTTLE LINKAGE
E70TTLERC 1994	SHIFT & THROTTLE LINKAGE
E70TTLERV 1994	SHIFT & THROTTLE LINKAGE
E70TTLETS 1993	SHIFT & THROTTLE LINKAGE
E88MSLCCC 1988	CYLINDER & CRANKCASE
E88MSLCUS 1987	CYLINDER & CRANKCASE
E90MLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
E90MLCUR 1987	CYLINDER & CRANKCASE
E90TLCCA 1988	CYLINDER & CRANKCASE
E90TLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
E90TLCUR 1987	CYLINDER & CRANKCASE
E90TXCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
J100STLCCA 1988	CYLINDER & CRANKCASE
J100WMLCDR 1986	CYLINDER & CRANKCASE
J100WTLCDR 1986	CYLINDER & CRANKCASE
J100WTLCUA 1987	CYLINDER & CRANKCASE
J100WTXCDR 1986	CYLINDER & CRANKCASE
J100WTXCUA 1987	CYLINDER & CRANKCASE
J110MLCCA 1988	CYLINDER & CRANKCASE
J110MLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
J110MLCUR 1987	CYLINDER & CRANKCASE
J110TLCCA 1988	CYLINDER & CRANKCASE
J110TLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
J110TLCDF 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
J110TLCUR 1987	CYLINDER & CRANKCASE
J110TXCCA 1988	CYLINDER & CRANKCASE
J110TXCUR 1987	CYLINDER & CRANKCASE
J50TTLECA 1998	SHIFT & THROTTLE LINKAGE
J50TTLEDC 1996	SHIFT & THROTTLE LINKAGE
J50TTLEOS 1995	SHIFT & THROTTLE LINKAGE
J50TTLEUR 1997	SHIFT & THROTTLE LINKAGE

J60ELCCR 1988	SHIFT & THROTTLE LINKAGE - 60 TTLC MODELS ONLY
J60ELCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
J60ELES 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
J60TLCCR 1988	SHIFT & THROTTLE LINKAGE - 60 TTLC MODELS ONLY
J60TLCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
J60TLES 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
J60TTLCCR 1988	SHIFT & THROTTLE LINKAGE - 60 TTLC MODELS ONLY
J60TTLCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
J60TTLECM 1998	SHIFT & THROTTLE LINKAGE
J60TTLEDR 1996	SHIFT & THROTTLE LINKAGE
J60TTLEIB 1991	SHIFT & THROTTLE LINKAGE
J60TTLENE 1992	SHIFT & THROTTLE LINKAGE
J60TTLEOC 1995	SHIFT & THROTTLE LINKAGE
J60TTLERS 1994	SHIFT & THROTTLE LINKAGE
J60TTLERV 1994	SHIFT & THROTTLE LINKAGE
J60TTLES 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
J60TTLETD 1993	SHIFT & THROTTLE LINKAGE
J60TTLEUA 1997	SHIFT & THROTTLE LINKAGE
J65RSLC 1995	SHIFT & THROTTLE LINKAGE
J65RSLM 1996	SHIFT & THROTTLE LINKAGE
J65RSLZ 1997	SHIFT & THROTTLE LINKAGE
J65RWLCR 1986	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
J65RWLCOC 1985	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
J65TELCR 1986	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
J65TELCOC 1985	SHIFT & THROTTLE LINKAGE TILLER ELECTRIC, ROPE MODELS
J65WRLEEO 1999	SHIFT & THROTTLE LINKAGE
J65WRLEES 1999	SHIFT & THROTTLE LINKAGE
J65WRLSIR commercial, rope start, 20 in shaft 2001	SHIFT & THROTTLE LINKAGE
J65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	SHIFT AND THROTTLE LINKAGE
J65WRYEEO 1999	SHIFT & THROTTLE LINKAGE
J65WRYEES 1999	SHIFT & THROTTLE LINKAGE
J65WRYSIR commercial, rope start, 22.5 in shaft 2001	SHIFT & THROTTLE LINKAGE
J65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	SHIFT AND THROTTLE LINKAGE

J70TTLEIE 1991	SHIFT & THROTTLE LINKAGE
J70TTLEND 1992	SHIFT & THROTTLE LINKAGE
J70TTLEOR 1995	SHIFT & THROTTLE LINKAGE
J70TTLERC 1994	SHIFT & THROTTLE LINKAGE
J70TTLERV 1994	SHIFT & THROTTLE LINKAGE
J70TTLETS 1993	SHIFT & THROTTLE LINKAGE
J88MSLCCC 1988	CYLINDER & CRANKCASE
J88MSLCUS 1987	CYLINDER & CRANKCASE
J90MLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
J90MLCUR 1987	CYLINDER & CRANKCASE
J90TLCCA 1988	CYLINDER & CRANKCASE
J90TLCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
J90TLCUR 1987	CYLINDER & CRANKCASE
J90TXCDC 1986	CYLINDER & CRANKCASE - ALL MODELS EXCEPT 110TLCDF
MQ-14D 1968	GEARCASE GROUP
MQ-14E 1968	GEARCASE GROUP
MQL-14D 1968	GEARCASE GROUP
MQL-14E 1968	GEARCASE GROUP
SE65RSLD 1998	SHIFT & THROTTLE LINKAGE
SE65RSLM 1996	SHIFT & THROTTLE LINKAGE
SE65RSLZ2 1997	SHIFT & THROTTLE LINKAGE
SE65RSYD 1998	SHIFT & THROTTLE LINKAGE
SE65RSYM 1996	SHIFT & THROTTLE LINKAGE
SE65RSYZ2 1997	SHIFT & THROTTLE LINKAGE
SJ65RSLD 1998	SHIFT & THROTTLE LINKAGE
SJ65RSLM 1996	SHIFT & THROTTLE LINKAGE
SJ65RSLZ2 1997	SHIFT & THROTTLE LINKAGE
SJ65RSYD 1998	SHIFT & THROTTLE LINKAGE
SJ65RSYM 1996	SHIFT & THROTTLE LINKAGE
SJ65RSYZ2 1997	SHIFT & THROTTLE LINKAGE
TE60TLCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
TE60TLESF 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
TE60TLESF 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
TE60TLESM 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
TJ60TLCEA 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY

TJ60TLESF 1989	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
TJ60TLESF 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
TJ60TLESM 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
VE60ELESM 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
VE60TLESM 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
VE88MSLCCC 1988	CYLINDER & CRANKCASE
VJ60ELESM 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
VJ60TLESM 1990	SHIFT & THROTTLE LINKAGE - 60TTL MODELS ONLY
VJ88MSLCCC 1988	CYLINDER & CRANKCASE
W100WTLM 1988	CYLINDER & CRANKCASE
W100WTXM 1988	CYLINDER & CRANKCASE