

Where Used: Part Number 0303442

Model Name	Diagram
6002B 1970	GEARCASE GROUP
6003B 1970	GEARCASE GROUP
6102E 1971	GEARCASE
6102G 1971	GEARCASE
6103E 1971	GEARCASE
6103G 1971	GEARCASE
6202D 1972	GEARCASE
6203D 1972	GEARCASE
6302S 1973	GEARCASE
6303S 1973	GEARCASE
6402C 1974	GEARCASE
6403C 1974	GEARCASE
6504R 1975	GEARCASE
6505R 1975	GEARCASE
6604A 1976	GEARCASE
6605A 1976	GEARCASE
6704M 1977	GEARCASE
6705M 1977	GEARCASE
6802A 1968	GEARCASE GROUP
6802C 1968	GEARCASE GROUP
6802R 1968	GEARCASE GROUP
6803A 1968	GEARCASE GROUP
6803C 1968	GEARCASE GROUP
6803R 1968	GEARCASE GROUP
6804B 1978	GEARCASE
6805B 1978	GEARCASE
6902M 1969	GEARCASE GROUP
6903M 1969	GEARCASE GROUP
6R69M 1969	GEARCASE GROUP
6R70B 1970	GEARCASE GROUP
6R71E 1971	GEARCASE
6R71G 1971	GEARCASE
6R72D 1972	GEARCASE

6R73S 1973	GEARCASE
6R74C 1974	GEARCASE
6R75R 1975	GEARCASE
6R76A 1976	GEARCASE
6R77M 1977	GEARCASE
6R78B 1978	GEARCASE
6RL69M 1969	GEARCASE GROUP
6RL70B 1970	GEARCASE GROUP
6RL71E 1971	GEARCASE
6RL71G 1971	GEARCASE
6RL72 1972	GEARCASE
6RL73S 1973	GEARCASE
6RL74C 1974	GEARCASE
6RL75R 1975	GEARCASE
6RL76A 1976	GEARCASE
6RL77M 1977	GEARCASE
6RL78B 1978	GEARCASE
CD-25A 1968	GEARCASE GROUP
CD-25C 1968	GEARCASE GROUP
CD-25R 1968	GEARCASE GROUP
CDL-25A 1968	GEARCASE GROUP
CDL-25C 1968	GEARCASE GROUP
CDL-25R 1968	GEARCASE GROUP