

Where Used: Part Number 0304575

Model Name	Diagram
33002M 1970	GEARCASE GROUP
33003M 1970	GEARCASE GROUP
33052M 1970	GEARCASE GROUP
33053M 1970	GEARCASE GROUP
33802M 1968	GEARCASE GROUP
33802R 1968	GEARCASE GROUP
33803M 1968	GEARCASE GROUP
33803R 1968	GEARCASE GROUP
33852M 1968	GEARCASE GROUP
33852R 1968	GEARCASE GROUP
33853M 1968	GEARCASE GROUP
33853R 1968	GEARCASE GROUP
33902A 1969	GEARCASE GROUP
33903A 1969	GEARCASE GROUP
33952A 1969	GEARCASE GROUP
33953A 1969	GEARCASE GROUP
33E69A 1969	GEARCASE GROUP
33E70M 1970	GEARCASE GROUP
33EL69A 1969	GEARCASE GROUP
33EL70M 1970	GEARCASE GROUP
33R69A 1969	GEARCASE GROUP
33R70M 1970	GEARCASE GROUP
33RL69A 1969	GEARCASE GROUP
33RL70M 1970	GEARCASE GROUP
40002A 1970	GEARCASE GROUP
40003A 1970	GEARCASE GROUP
40052A 1970	GEARCASE GROUP
40053A 1970	GEARCASE GROUP
40072A 1970	GEARCASE GROUP ELECTRIC SHIFT
40073A 1970	GEARCASE GROUP ELECTRIC SHIFT
40102B 1971	GEARCASE
40102G 1971	GEARCASE
40103B 1971	GEARCASE

40103G 1971	GEARCASE
40152B 1971	GEARCASE
40152G 1971	GEARCASE
40153B 1971	GEARCASE
40153G 1971	GEARCASE
40202E 1972	GEARCASE
40203E 1972	GEARCASE
40252E 1972	GEARCASE
40253E 1972	GEARCASE
40304D 1973	GEARCASE
40305D 1973	GEARCASE
40354D 1973	GEARCASE
40355D 1973	GEARCASE
40404S 1974	GEARCASE
40405S 1974	GEARCASE
40454S 1974	GEARCASE
40455S 1974	GEARCASE
40504C 1975	GEARCASE
40505C 1975	GEARCASE
40554C 1975	GEARCASE
40555C 1975	GEARCASE
40604A 1976	GEARCASE
40604R 1976	GEARCASE
40605A 1976	GEARCASE
40605R 1976	GEARCASE
40654A 1976	GEARCASE
40654R 1976	GEARCASE
40655A 1976	GEARCASE
40655R 1976	GEARCASE
40802A 1968	GEARCASE GROUP
40802D 1968	GEARCASE GROUP
40802S 1968	GEARCASE GROUP
40803A 1968	GEARCASE GROUP
40803D 1968	GEARCASE GROUP
40803S 1968	GEARCASE GROUP

40852A 1968	GEARCASE GROUP ELECTRIC START
40852C 1968	GEARCASE GROUP ELECTRIC START
40852D 1968	GEARCASE GROUP ELECTRIC START
40852S 1968	GEARCASE GROUP ELECTRIC START
40853A 1968	GEARCASE GROUP ELECTRIC START
40853C 1968	GEARCASE GROUP ELECTRIC START
40853D 1968	GEARCASE GROUP ELECTRIC START
40853S 1968	GEARCASE GROUP ELECTRIC START
40872A 1968	GEARCASE GROUP ELECTRIC SHIFT
40872C 1968	GEARCASE GROUP ELECTRIC SHIFT
40872D 1968	GEARCASE GROUP ELECTRIC SHIFT
40873A 1968	GEARCASE GROUP ELECTRIC SHIFT
40873C 1968	GEARCASE GROUP ELECTRIC SHIFT
40873D 1968	GEARCASE GROUP ELECTRIC SHIFT
40902R 1969	GEARCASE GROUP
40903R 1969	GEARCASE GROUP
40952R 1969	GEARCASE GROUP
40953R 1969	GEARCASE GROUP
40972R 1969	GEARCASE GROUP ELECTRIC SHIFT
40973R 1969	GEARCASE GROUP ELECTRIC SHIFT
40E69R 1969	GEARCASE GROUP ELECTRIC START
40E70A 1970	GEARCASE GROUP
40E71B 1971	GEARCASE
40E71G 1971	GEARCASE
40E72E 1972	GEARCASE
40E73D 1973	GEARCASE
40E74S 1974	GEARCASE
40E75C 1975	GEARCASE
40E76A 1976	GEARCASE
40E76R 1976	GEARCASE
40EL69R 1969	GEARCASE GROUP ELECTRIC START
40EL70A 1970	GEARCASE GROUP
40EL71B 1971	GEARCASE
40EL71G 1971	GEARCASE
40EL72E 1972	GEARCASE

40EL73D 1973	GEARCASE
40EL74S 1974	GEARCASE
40EL75C 1975	GEARCASE
40EL76A 1976	GEARCASE
40EL76R 1976	GEARCASE
40ES69R 1969	GEARCASE GROUP ELECTRIC SHIFT
40ES70A 1970	GEARCASE GROUP ELECTRIC SHIFT
40ESL69R 1969	GEARCASE GROUP ELECTRIC SHIFT
40ESL70A 1970	GEARCASE GROUP ELECTRIC SHIFT
40R69R 1969	GEARCASE GROUP
40R70A 1970	GEARCASE GROUP
40R71B 1971	GEARCASE
40R71G 1971	GEARCASE
40R72E 1972	GEARCASE
40R73D 1973	GEARCASE
40R74S 1974	GEARCASE
40R75C 1975	GEARCASE
40R76A 1976	GEARCASE
40R76R 1976	GEARCASE
40RL69R 1969	GEARCASE GROUP
40RL70A 1970	GEARCASE GROUP
40RL71B 1971	GEARCASE
40RL71G 1971	GEARCASE
40RL72E 1972	GEARCASE
40RL73D 1973	GEARCASE
40RL74S 1974	GEARCASE
40RL75C 1975	GEARCASE
40RL76A 1976	GEARCASE
40RL76R 1976	GEARCASE
E40RSLR 1983	GEARCASE
E40RSR 1983	GEARCASE
E40RWADB 1986	GEARCASE
E40RWCOM 1985	GEARCASE
E40RWCRA 1984	GEARCASE
E40RWLCDB 1986	GEARCASE

E40RWLCOM 1985	GEARCASE
E40RWLCRA 1984	GEARCASE
E40RWLCTR 1983	GEARCASE
E40RWLTR 1983	GEARCASE
J40RSLR 1983	GEARCASE
J40RSR 1983	GEARCASE
J40RWADB 1986	GEARCASE
J40RWCOM 1985	GEARCASE
J40RWCRA 1984	GEARCASE
J40RWCTR 1983	GEARCASE
J40RWADB 1986	GEARCASE
J40RWLCOM 1985	GEARCASE
J40RWLCRA 1984	GEARCASE
J40RWLCTR 1983	GEARCASE
RD-30A 1968	GEARCASE GROUP
RD-30D 1968	GEARCASE GROUP
RD-30S 1968	GEARCASE GROUP
RDL-30A 1968	GEARCASE GROUP
RDL-30D 1968	GEARCASE GROUP
RDL-30S 1968	GEARCASE GROUP
RDS-30A 1968	GEARCASE GROUP
RDS-30C 1968	GEARCASE GROUP
RDS-30D 1968	GEARCASE GROUP
RDS-30S 1968	GEARCASE GROUP
RDSL-30A 1968	GEARCASE GROUP
RDSL-30C 1968	GEARCASE GROUP
RDSL-30D 1968	GEARCASE GROUP
RDSL-30S 1968	GEARCASE GROUP
RK-30A 1968	GEARCASE GROUP ELECTRIC SHIFT
RK-30C 1968	GEARCASE GROUP ELECTRIC SHIFT
RK-30D 1968	GEARCASE GROUP ELECTRIC SHIFT
RKL-30A 1968	GEARCASE GROUP ELECTRIC SHIFT
RKL-30C 1968	GEARCASE GROUP ELECTRIC SHIFT
RKL-30D 1968	GEARCASE GROUP ELECTRIC SHIFT
RX-16M 1968	GEARCASE GROUP

RX-16R 1968	GEARCASE GROUP
RXE-16M 1968	GEARCASE GROUP
RXE-16R 1968	GEARCASE GROUP
RXEL-16M 1968	GEARCASE GROUP
RXEL-16R 1968	GEARCASE GROUP
RXL-16M 1968	GEARCASE GROUP
RXL-16R 1968	GEARCASE GROUP