

Where Used: Part Number 0305282

Model Name	Diagram
115ESL74B 1974	POWER TILT AND TRIM
115ESL75E 1975	POWER TILT AND TRIM
115ETL74B 1974	POWER TILT AND TRIM
115ETL75E 1975	POWER TILT AND TRIM
120FTHRCIF 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
120FTHRCIS 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
135443B 1974	POWER TILT AND TRIM
135483B 1974	POWER TILT AND TRIM
135489B 1974	POWER TILT AND TRIM
135543E 1975	POWER TILT AND TRIM
135583E 1975	POWER TILT AND TRIM
135589E 1975	POWER TILT AND TRIM
135ESL74B 1974	POWER TILT AND TRIM
135ESL75E 1975	POWER TILT AND TRIM
135ETL74B 1974	POWER TILT AND TRIM
135ETL75E 1975	POWER TILT AND TRIM
140FTHRCIF 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
140FTHRCIS 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
140SPHRCIF 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
140SPHRCIS 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
140STHRCIF 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
140STHRCIS 1981	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
170SPMCCIF 1981	UPPER GEARCASE GROUP
170SPMCCIS 1981	UPPER GEARCASE GROUP
170SPMRCIF 1981	UPPER GEARCASE GROUP
170SPMRCIS 1981	UPPER GEARCASE GROUP
170STMCCIF 1981	UPPER GEARCASE GROUP
170STMCCIS 1981	UPPER GEARCASE GROUP
170STMRCIF 1981	UPPER GEARCASE GROUP
170STMRCIS 1981	UPPER GEARCASE GROUP
252FTHRCNC 1982	UPPER GEARCASE GROUP
252FTHRCNG 1982	UPPER GEARCASE GROUP
252FTHRCOM 1985	UPPER GEARCASE GROUP

252FTHRCRA 1984	UPPER GEARCASE GROUP
252FTHRCTR 1983	UPPER GEARCASE GROUP
252STHRCNC 1982	UPPER GEARCASE GROUP
252STHRCOM 1985	UPPER GEARCASE GROUP
252STHRCRA 1984	UPPER GEARCASE GROUP
252STHRCTR 1983	UPPER GEARCASE GROUP
302FPHRCNC 1982	UPPER GEARCASE GROUP
302FPHRCNG 1982	UPPER GEARCASE GROUP
302FPHRCTR 1983	UPPER GEARCASE GROUP
302FTHRCNC 1982	UPPER GEARCASE GROUP
302FTHRCNG 1982	UPPER GEARCASE GROUP
302FTHRCOM 1985	UPPER GEARCASE GROUP
302FTHRCRA 1984	UPPER GEARCASE GROUP
302FTHRCTR 1983	UPPER GEARCASE GROUP
302SPHRCNC 1982	UPPER GEARCASE GROUP
302SPHRCNG 1982	UPPER GEARCASE GROUP
302SPHRCOM 1985	UPPER GEARCASE GROUP
302SPHRCRA 1984	UPPER GEARCASE GROUP
302SPHRCTR 1983	UPPER GEARCASE GROUP
302STHRCNC 1982	UPPER GEARCASE GROUP
302STHRCNG 1982	UPPER GEARCASE GROUP
302STHRCOM 1985	UPPER GEARCASE GROUP
302STHRCRA 1984	UPPER GEARCASE GROUP
302STHRCTR 1983	UPPER GEARCASE GROUP
382FTMRCOM 1985	UPPER GEARCASE GROUP
382FTMRCRA 1984	UPPER GEARCASE GROUP
382FTMRCRJ 1984	UPPER GEARCASE GROUP
382FTMRCTR 1983	UPPER GEARCASE GROUP
382SPMCCNC 1982	UPPER GEARCASE GROUP
382SPMCCTR 1983	UPPER GEARCASE GROUP
382SPMRCNC 1982	UPPER GEARCASE GROUP
382SPMRCOM 1985	UPPER GEARCASE GROUP
382SPMRCRA 1984	UPPER GEARCASE GROUP
382SPMRCRJ 1984	UPPER GEARCASE GROUP
382SPMRCTR 1983	UPPER GEARCASE GROUP

382STMCCNC 1982	UPPER GEARCASE GROUP
382STMCCTR 1983	UPPER GEARCASE GROUP
382STMRCNC 1982	UPPER GEARCASE GROUP
382STMRCOM 1985	UPPER GEARCASE GROUP
382STMRCR 1983	UPPER GEARCASE GROUP
384FTMRCOM 1985	UPPER GEARCASE GROUP
384FTMRCRA 1984	UPPER GEARCASE GROUP
384FTMRCR 1984	UPPER GEARCASE GROUP
384FTMRCR 1983	UPPER GEARCASE GROUP
384SPMCCNC 1982	UPPER GEARCASE GROUP
384SPMCCTR 1983	UPPER GEARCASE GROUP
384SPMRCNC 1982	UPPER GEARCASE GROUP
384SPMRCOM 1985	UPPER GEARCASE GROUP
384SPMRCRA 1984	UPPER GEARCASE GROUP
384SPMRCR 1984	UPPER GEARCASE GROUP
384SPMRCR 1983	UPPER GEARCASE GROUP
384STMCCNC 1982	UPPER GEARCASE GROUP
384STMCCTR 1983	UPPER GEARCASE GROUP
384STMRCNC 1982	UPPER GEARCASE GROUP
384STMRCOM 1985	UPPER GEARCASE GROUP
384STMRCRA 1984	UPPER GEARCASE GROUP
384STMRCR 1984	UPPER GEARCASE GROUP
384STMRCR 1983	UPPER GEARCASE GROUP
384STNRCNC 1982	UPPER GEARCASE GROUP
40002A 1970	LOWER UNIT GROUP
40003A 1970	LOWER UNIT GROUP
40052A 1970	LOWER UNIT GROUP
40053A 1970	LOWER UNIT GROUP
40072A 1970	LOWER UNIT GROUP ELECTRIC SHIFT
40073A 1970	LOWER UNIT GROUP ELECTRIC SHIFT
40802A 1968	LOWER UNIT GROP
40802D 1968	LOWER UNIT GROP
40802S 1968	LOWER UNIT GROP
40803A 1968	LOWER UNIT GROP
40803D 1968	LOWER UNIT GROP

40803S 1968	LOWER UNIT GROU
40852A 1968	LOWER UNIT GROUP ELECTRIC START
40852C 1968	LOWER UNIT GROUP ELECTRIC START
40852D 1968	LOWER UNIT GROUP ELECTRIC START
40852S 1968	LOWER UNIT GROUP ELECTRIC START
40853A 1968	LOWER UNIT GROUP ELECTRIC START
40853C 1968	LOWER UNIT GROUP ELECTRIC START
40853D 1968	LOWER UNIT GROUP ELECTRIC START
40853S 1968	LOWER UNIT GROUP ELECTRIC START
40872A 1968	LOWER UNIT GROUP ELECTRIC SHIFT
40872C 1968	LOWER UNIT GROUP ELECTRIC SHIFT
40872D 1968	LOWER UNIT GROUP ELECTRIC SHIFT
40873A 1968	LOWER UNIT GROUP ELECTRIC SHIFT
40873C 1968	LOWER UNIT GROUP ELECTRIC SHIFT
40873D 1968	LOWER UNIT GROUP ELECTRIC SHIFT
40902R 1969	LOWER UNIT GROUP
40903R 1969	LOWER UNIT GROUP
40952R 1969	LOWER UNIT GROUP
40953R 1969	LOWER UNIT GROUP
40972R 1969	LOWER UNIT GROUP ELECTRIC SHIFT
40973R 1969	LOWER UNIT GROUP ELECTRIC SHIFT
40E69R 1969	LOWER UNIT GROUP ELECTRIC START
40E70A 1970	LOWER UNIT GROUP
40EL69R 1969	LOWER UNIT GROUP ELECTRIC START
40EL70A 1970	LOWER UNIT GROUP
40ES69R 1969	LOWER UNIT GROUP ELECTRIC SHIFT
40ES70A 1970	LOWER UNIT GROUP ELECTRIC SHIFT
40ESL69R 1969	LOWER UNIT GROUP ELECTRIC SHIFT
40ESL70A 1970	LOWER UNIT GROUP ELECTRIC SHIFT
40R69R 1969	LOWER UNIT GROUP
40R70A 1970	LOWER UNIT GROUP
40RL69R 1969	LOWER UNIT GROUP
40RL70A 1970	LOWER UNIT GROUP
432FTMRCOM 1985	UPPER GEARCASE GROUP
432SPMRCOM 1985	UPPER GEARCASE GROUP

432STMRCOM 1985	UPPER GEARCASE GROUP
434FTMRCOM 1985	UPPER GEARCASE GROUP
434SPMRCOM 1985	UPPER GEARCASE GROUP
434STMRCOM 1985	UPPER GEARCASE GROUP
50172S 1971	GEARCASE
50173S 1971	GEARCASE
50202C 1972	GEARCASE 50 HP MANUAL START
50202C 1972	GEARCASE ELECTRIC START
50203C 1972	GEARCASE 50 HP MANUAL START
50203C 1972	GEARCASE ELECTRIC START
50272C 1972	GEARCASE 50 HP MANUAL START
50272C 1972	GEARCASE ELECTRIC START
50273C 1972	GEARCASE 50 HP MANUAL START
50273C 1972	GEARCASE ELECTRIC START
502FTHRCOK 1985	UPPER GEARCASE GROUP
502FTHRCOM 1985	UPPER GEARCASE GROUP
502FTHRCRA 1984	UPPER GEARCASE GROUP
502FTHRCTR 1983	UPPER GEARCASE GROUP
502SPHCCNC 1982	UPPER GEARCASE GROUP
502SPHCCNG 1982	UPPER GEARCASE GROUP
502SPHCCTR 1983	UPPER GEARCASE GROUP
502SPHRCNC 1982	UPPER GEARCASE GROUP
502SPHRCNG 1982	UPPER GEARCASE GROUP
502SPHRCOK 1985	UPPER GEARCASE GROUP
502SPHRCOM 1985	UPPER GEARCASE GROUP
502SPHRCRA 1984	UPPER GEARCASE GROUP
502SPHRCTR 1983	UPPER GEARCASE GROUP
502SPMCCNC 1982	UPPER GEARCASE GROUP
502SPMCCNG 1982	UPPER GEARCASE GROUP
502SPMCCTR 1983	UPPER GEARCASE GROUP
502SPMRCNC 1982	UPPER GEARCASE GROUP
502SPMRCNG 1982	UPPER GEARCASE GROUP
502SPMRCTR 1983	UPPER GEARCASE GROUP
502SPNCCNC 1982	UPPER GEARCASE GROUP
502SPNRCNC 1982	UPPER GEARCASE GROUP

502SPNRCNG 1982	UPPER GEARCASE GROUP
502STHCCNC 1982	UPPER GEARCASE GROUP
502STHCCNG 1982	UPPER GEARCASE GROUP
502STHCCTR 1983	UPPER GEARCASE GROUP
502STHRCNC 1982	UPPER GEARCASE GROUP
502STHRCNG 1982	UPPER GEARCASE GROUP
502STHRCOK 1985	UPPER GEARCASE GROUP
502STHRCOM 1985	UPPER GEARCASE GROUP
502STHRCRA 1984	UPPER GEARCASE GROUP
502STHRCTR 1983	UPPER GEARCASE GROUP
502STMCCNC 1982	UPPER GEARCASE GROUP
502STMCCNG 1982	UPPER GEARCASE GROUP
502STMCCTR 1983	UPPER GEARCASE GROUP
502STMRCNC 1982	UPPER GEARCASE GROUP
502STMRCNG 1982	UPPER GEARCASE GROUP
502STMRCTR 1983	UPPER GEARCASE GROUP
50302R 1973	GEARCASE MANUAL START
50302R 1973	GEARCASE ELECTRIC START
50303R 1973	GEARCASE MANUAL START
50303R 1973	GEARCASE ELECTRIC START
50372R 1973	GEARCASE MANUAL START
50372R 1973	GEARCASE ELECTRIC START
50373R 1973	GEARCASE MANUAL START
50373R 1973	GEARCASE ELECTRIC START
50442M 1974	GEARCASE
50443M 1974	GEARCASE
50472M 1974	GEARCASE
50473M 1974	GEARCASE
504FTHRCOK 1985	UPPER GEARCASE GROUP
504FTHRCOM 1985	UPPER GEARCASE GROUP
504FTHRCRA 1984	UPPER GEARCASE GROUP
504FTHRCTR 1983	UPPER GEARCASE GROUP
504SPHCCNC 1982	UPPER GEARCASE GROUP
504SPHCCNG 1982	UPPER GEARCASE GROUP
504SPHCCTR 1983	UPPER GEARCASE GROUP

504SPHRCNC 1982	UPPER GEARCASE GROUP
504SPHRCNG 1982	UPPER GEARCASE GROUP
504SPHRCOK 1985	UPPER GEARCASE GROUP
504SPHRCOM 1985	UPPER GEARCASE GROUP
504SPHRCRA 1984	UPPER GEARCASE GROUP
504SPHRCTR 1983	UPPER GEARCASE GROUP
504SPMCCNC 1982	UPPER GEARCASE GROUP
504SPMCCNG 1982	UPPER GEARCASE GROUP
504SPMCCTR 1983	UPPER GEARCASE GROUP
504SPMRCNC 1982	UPPER GEARCASE GROUP
504SPMRCNG 1982	UPPER GEARCASE GROUP
504SPMRCTR 1983	UPPER GEARCASE GROUP
504STHCNC 1982	UPPER GEARCASE GROUP
504STHCNG 1982	UPPER GEARCASE GROUP
504STHCCTR 1983	UPPER GEARCASE GROUP
504STHRCNC 1982	UPPER GEARCASE GROUP
504STHRCNG 1982	UPPER GEARCASE GROUP
504STHRCOK 1985	UPPER GEARCASE GROUP
504STHRCOM 1985	UPPER GEARCASE GROUP
504STHRCRA 1984	UPPER GEARCASE GROUP
504STHRCTR 1983	UPPER GEARCASE GROUP
504STMCCNG 1982	UPPER GEARCASE GROUP
504STMCCCTR 1983	UPPER GEARCASE GROUP
504STMRCNC 1982	UPPER GEARCASE GROUP
504STMRCNG 1982	UPPER GEARCASE GROUP
504STMRCTR 1983	UPPER GEARCASE GROUP
504STNCCNC 1982	UPPER GEARCASE GROUP
50542B 1975	GEARCASE
50543B 1975	GEARCASE
50572B 1975	GEARCASE
50573B 1975	GEARCASE
50902C 1979	GEARCASE ROPE START
50902C 1979	GEARCASE, ELECTRIC START
50903C 1979	GEARCASE ROPE START
50903C 1979	GEARCASE, ELECTRIC START

50ES71S 1971	GEARCASE
50ES72C 1972	GEARCASE 50 HP MANUAL START
50ES72C 1972	GEARCASE ELECTRIC START
50ES73R 1973	GEARCASE MANUAL START
50ES73R 1973	GEARCASE ELECTRIC START
50ES74M 1974	GEARCASE
50ES75B 1975	GEARCASE
50ESL71S 1971	GEARCASE
50ESL72C 1972	GEARCASE 50 HP MANUAL START
50ESL72C 1972	GEARCASE ELECTRIC START
50ESL73R 1973	GEARCASE MANUAL START
50ESL73R 1973	GEARCASE ELECTRIC START
50ESL74M 1974	GEARCASE
50ESL75B 1975	GEARCASE
50R72C 1972	GEARCASE 50 HP MANUAL START
50R72C 1972	GEARCASE ELECTRIC START
50R73R 1973	GEARCASE MANUAL START
50R73R 1973	GEARCASE ELECTRIC START
50R79C 1979	GEARCASE, ELECTRIC START
50R79C 1979	GEARCASE, ROPE START
50RL72C 1972	GEARCASE 50 HP MANUAL START
50RL72C 1972	GEARCASE ELECTRIC START
50RL73R 1973	GEARCASE MANUAL START
50RL73R 1973	GEARCASE ELECTRIC START
50RL79C 1979	GEARCASE, ELECTRIC START
50RL79C 1979	GEARCASE, ROPE START
55642E 1976	GEARCASE
55643E 1976	GEARCASE
55672E 1976	GEARCASE
55673E 1976	GEARCASE
55772D 1977	GEARCASE
55773D 1977	GEARCASE
55874S 1978	GEARCASE
55875S 1978	GEARCASE
55974C 1979	GEARCASE ROPE START

55974C 1979	GEARCASE, ELECTRIC START
55975C 1979	GEARCASE ROPE START
55975C 1979	GEARCASE, ELECTRIC START
55E76E 1976	GEARCASE
55E77D 1977	GEARCASE
55E78S 1978	GEARCASE
55E79C 1979	GEARCASE, ELECTRIC START
55E79C 1979	GEARCASE, ROPE START
55EL76E 1976	GEARCASE
55EL77D 1977	GEARCASE
55EL78S 1978	GEARCASE
55EL79C 1979	GEARCASE, ELECTRIC START
55EL79C 1979	GEARCASE, ROPE START
574FTHRCOK 1985	UPPER GEARCASE GROUP
574FTHRCOM 1985	UPPER GEARCASE GROUP
574FTHRCRA 1984	UPPER GEARCASE GROUP
574SPHCCNC 1982	UPPER GEARCASE GROUP
574SPHCCNG 1982	UPPER GEARCASE GROUP
574SPHCCTR 1983	UPPER GEARCASE GROUP
574SPHRCNC 1982	UPPER GEARCASE GROUP
574SPHRCNG 1982	UPPER GEARCASE GROUP
574SPHRCOK 1985	UPPER GEARCASE GROUP
574SPHRCOM 1985	UPPER GEARCASE GROUP
574SPHRCRA 1984	UPPER GEARCASE GROUP
574SPHRCTR 1983	UPPER GEARCASE GROUP
574SPMCCNC 1982	UPPER GEARCASE GROUP
574SPMCCNG 1982	UPPER GEARCASE GROUP
574SPMCCTR 1983	UPPER GEARCASE GROUP
574SPMRCNC 1982	UPPER GEARCASE GROUP
574SPMRCNG 1982	UPPER GEARCASE GROUP
574SPMRCTR 1983	UPPER GEARCASE GROUP
574STHCCNC 1982	UPPER GEARCASE GROUP
574STHCCNG 1982	UPPER GEARCASE GROUP
574STHCCTR 1983	UPPER GEARCASE GROUP
574STHRCNC 1982	UPPER GEARCASE GROUP

574STHRCNG 1982	UPPER GEARCASE GROUP
574STHRCOK 1985	UPPER GEARCASE GROUP
574STHRCOM 1985	UPPER GEARCASE GROUP
574STHRCRA 1984	UPPER GEARCASE GROUP
574STHRCTR 1983	UPPER GEARCASE GROUP
574STMCCNC 1982	UPPER GEARCASE GROUP
574STMCCNG 1982	UPPER GEARCASE GROUP
574STMCCTR 1983	UPPER GEARCASE GROUP
574STMRCMC 1982	UPPER GEARCASE GROUP
574STMRCMG 1982	UPPER GEARCASE GROUP
574STMRCNC 1982	UPPER GEARCASE GROUP
574STMRCNG 1982	UPPER GEARCASE GROUP
574STMRCTR 1983	UPPER GEARCASE GROUP
990210R2 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990210R2 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990211A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990211A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990211A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990211A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990211A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990211A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990211M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990211M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990211R11 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990211R11 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990212A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990212A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990218R2 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990218R2 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990220R2 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990220R2 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990223A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990223A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE

990223A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990223A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990223A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990223A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990224A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990224A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990224A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990224A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990224A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990224A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990225A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990225A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990225A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990225A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990225A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990225A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990226A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990226A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990226A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990226A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990226A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990226A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990227A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990227A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990227A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990227A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990227A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990227A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990228A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990228A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE

990228A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990228A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990228A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990228A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990229A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990229A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990229A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990229A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990229A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990229A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990229E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990229E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990229G 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990229G 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990229M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990229M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990230A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990230A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990230A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990230A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990230E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990230E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990230G 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990230G 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990230M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990230M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP

990231A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990231A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990231A1 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990231A1 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990231A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990231A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990231E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990231E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990231G 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990231G 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990231M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990231M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990232A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990232A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990232A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990232A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990232E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990232E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990232G 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990232G 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990232M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990232M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990234E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990234E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990234E1 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP

990234E1 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990234M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990234M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990235E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990235E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990235E1 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990235E1 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990235M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990235M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990236E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990236E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990236E1 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990236E1 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990236M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990236M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990237E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990237E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990237E1 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990237E1 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990237M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990237M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990239M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990239M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP

990240A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990240A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990240A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990240A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990240E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990240E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990240G 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990240G 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990240M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990240M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990241A 1975	UPPER GEARCASE GROUP 120,140,165,175,190 & 235 HP
990241A 1975	UPPER GEARCASE GROUP 225 & 245 HP STERN DRIVE
990241A11 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990241A11 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990241E 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990241E 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990241G 1977	UPPER GEARCASE GROUP-HIGH PROFILE 120,140,175,190,& 235 HP
990241G 1977	UPPER GEARCASE GROUP-LOW PROFILE 120,140,175,190 & 235 HP
990241M 1976	UPPER GEARCASE GROUP-HIGH PROFILE 120 - 235 HP STERN DRIVE
990241M 1976	UPPER GEARCASE GROUP-LOW PROFILE 120,140,165,175,190&235 HP
990242C 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990242C1 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990242D 1978	UPPER GEARCASE GROUP
990242H 1978	UPPER GEARCASE GROUP
990242H1 1978	UPPER GEARCASE GROUP
990242S 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
990242S1 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE

990243C 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990243C1 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990243D 1978	UPPER GEARCASE GROUP
990243H 1978	UPPER GEARCASE GROUP
990243H1 1978	UPPER GEARCASE GROUP
990243S 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
990243S1 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
990244C 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990244C1 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990244D 1978	UPPER GEARCASE GROUP
990244H 1978	UPPER GEARCASE GROUP
990244H1 1978	UPPER GEARCASE GROUP
990244P 1978	UPPER GEARCASE GROUP
990244S 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
990244S1 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
990245C 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990245C1 1980	UPPER GEARCASE GROUP 120,140 MODELS STERN DRIVE
990245D 1978	UPPER GEARCASE GROUP
990245H 1978	UPPER GEARCASE GROUP
990245H1 1978	UPPER GEARCASE GROUP
990245S 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
990245S1 1979	UPPER GEARCASE GROUP 120, 140 MODELS STERN DRIVE
990250D 1978	UPPER GEARCASE GROUP
990250H 1978	UPPER GEARCASE GROUP
990250J 1978	UPPER GEARCASE GROUP
990250N 1978	UPPER GEARCASE GROUP
990250P 1978	UPPER GEARCASE GROUP
990250U 1978	UPPER GEARCASE GROUP
990251D 1978	UPPER GEARCASE GROUP
990251H 1978	UPPER GEARCASE GROUP
990251J 1978	UPPER GEARCASE GROUP
990251N 1978	UPPER GEARCASE GROUP
990251S 1979	UPPER GEARCASE GROUP
990251U 1978	UPPER GEARCASE GROUP
990252C 1980	UPPER GEARCASE GROUP

990252D 1978	UPPER GEARCASE GROUP
990252H 1978	UPPER GEARCASE GROUP
990252J 1978	UPPER GEARCASE GROUP
990252K 1980	UPPER GEARCASE GROUP
990252S 1979	UPPER GEARCASE GROUP
990252S1 1979	UPPER GEARCASE GROUP
990253C 1980	UPPER GEARCASE GROUP
990253D 1978	UPPER GEARCASE GROUP
990253H 1978	UPPER GEARCASE GROUP
990253J 1978	UPPER GEARCASE GROUP
990253K 1980	UPPER GEARCASE GROUP
990253S 1979	UPPER GEARCASE GROUP
990253S1 1979	UPPER GEARCASE GROUP
990254C 1980	UPPER GEARCASE GROUP
990254D 1978	UPPER GEARCASE GROUP
990254H 1978	UPPER GEARCASE GROUP
990254J 1978	UPPER GEARCASE GROUP
990254K 1980	UPPER GEARCASE GROUP
990254S 1979	UPPER GEARCASE GROUP
990254S1 1979	UPPER GEARCASE GROUP
990254V 1979	UPPER GEARCASE GROUP
990255C 1980	UPPER GEARCASE GROUP
990255D 1978	UPPER GEARCASE GROUP
990255H 1978	UPPER GEARCASE GROUP
990255J 1978	UPPER GEARCASE GROUP
990255K 1980	UPPER GEARCASE GROUP
990255S 1979	UPPER GEARCASE GROUP
990255S1 1979	UPPER GEARCASE GROUP
990255V 1979	UPPER GEARCASE GROUP
990256C 1980	UPPER GEARCASE GROUP
990256K 1980	UPPER GEARCASE GROUP
990256S 1979	UPPER GEARCASE GROUP
990256S1 1979	UPPER GEARCASE GROUP
990257C 1980	UPPER GEARCASE GROUP
990257K 1980	UPPER GEARCASE GROUP

990257S 1979	UPPER GEARCASE GROUP
990257S1 1979	UPPER GEARCASE GROUP
990260C 1980	UPPER GEARCASE GROUP
990260K 1980	UPPER GEARCASE GROUP
990260S 1979	UPPER GEARCASE GROUP
990260S1 1979	UPPER GEARCASE GROUP
990260U 1980	UPPER GEARCASE GROUP
990261C 1980	UPPER GEARCASE GROUP
990261K 1980	UPPER GEARCASE GROUP
990261S 1979	UPPER GEARCASE GROUP
990261S1 1979	UPPER GEARCASE GROUP
990261U 1980	UPPER GEARCASE GROUP
990262C 1980	UPPER GEARCASE GROUP
990262K 1980	UPPER GEARCASE GROUP
990262S 1979	UPPER GEARCASE GROUP
990262S1 1979	UPPER GEARCASE GROUP
990262U 1980	UPPER GEARCASE GROUP
990266C 1980	UPPER GEARCASE GROUP
990266K 1980	UPPER GEARCASE GROUP
990266S 1979	UPPER GEARCASE GROUP
990266S1 1979	UPPER GEARCASE GROUP
990267C 1980	UPPER GEARCASE GROUP
990267K 1980	UPPER GEARCASE GROUP
990267S 1979	UPPER GEARCASE GROUP
990267S1 1979	UPPER GEARCASE GROUP
AM55RSLD 1999	GEARCASE
BE40EECR 1998	GEARCASE
BE40EEDS 1996	GEARCASE
BE40EEUC 1997	GEARCASE
BE40ELECR 1998	GEARCASE
BE40ELEDs 1996	GEARCASE
BE40ELEUC 1997	GEARCASE
BE40TLECR 1998	GEARCASE
BE40TLEDs 1996	GEARCASE
BE40TLEUC 1997	GEARCASE

BE50BEEDS 1996	GEARCASE
BE50BELEDS 1996	GEARCASE
BE50ESECC 1998	GEARCASE
BE50RLECR 1998	GEARCASE
BE50RLEUC 1997	GEARCASE
BE50TLECR 1998	GEARCASE
BE50TLEDS 1996	GEARCASE
BE50TLEUC 1997	GEARCASE
BE50TSLECC 1998	GEARCASE
BE50TSLEUS 1997	GEARCASE
BJ40EECR 1998	GEARCASE
BJ40EEDS 1996	GEARCASE
BJ40EEEE 1999	GEARCASE
BJ40EEUC 1997	GEARCASE
BJ40ELECR 1998	GEARCASE
BJ40ELEDS 1996	GEARCASE
BJ40ELEEA 1999	GEARCASE
BJ40ELEUC 1997	GEARCASE
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40PLEEA 1999	GEARCASE
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40TLECR 1998	GEARCASE
BJ40TLEDS 1996	GEARCASE
BJ40TLEUC 1997	GEARCASE
BJ50BEEDS 1996	GEARCASE
BJ50BELEDS 1996	GEARCASE
BJ50EEER 1999	GEARCASE
BJ50ELEER 1999	GEARCASE
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50ESECC 1998	GEARCASE

BJ50ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ50PLEEA 1999	GEARCASE
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50RLECR 1998	GEARCASE
BJ50RLEEA 1999	GEARCASE
BJ50RLEUC 1997	GEARCASE
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50TLECR 1998	GEARCASE
BJ50TLEDS 1996	GEARCASE
BJ50TLEUC 1997	GEARCASE
BJ50TSLECC 1998	GEARCASE
BJ50TSLEUS 1997	GEARCASE
E35AELCDE 1986	GEARCASE
E35AELCUD 1987	GEARCASE
E35ARLCDE 1986	GEARCASE
E35ARLCUD 1987	GEARCASE
E40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40AELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ARLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ATLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ECDE 1986	GEARCASE
E40ECEC 1989	GEARCASE
E40ECOB 1985	GEARCASE
E40ECRM 1984	GEARCASE
E40ECUD 1987	GEARCASE
E40EEIA 1991	GEARCASE
E40EENJ 1992	GEARCASE

E40EENM 1992	GEARCASE
E40EEOD 1995	GEARCASE
E40EERE 1994	GEARCASE
E40EESR 1990	GEARCASE
E40EETB 1993	GEARCASE
E40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ELCDE 1986	GEARCASE
E40ELCEC 1989	GEARCASE
E40ELCOB 1985	GEARCASE
E40ELCRM 1984	GEARCASE
E40ELCUD 1987	GEARCASE
E40ELECR 1998	GEARCASE
E40ELEDs 1996	GEARCASE
E40ELEIA 1991	GEARCASE
E40ELENJ 1992	GEARCASE
E40ELENM 1992	GEARCASE
E40ELEOD 1995	GEARCASE
E40ELERE 1994	GEARCASE
E40ELESR 1990	GEARCASE
E40ELETB 1993	GEARCASE
E40ELEUC 1997	GEARCASE
E40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40RCDE 1986	GEARCASE
E40RCEC 1989	GEARCASE
E40RCOB 1985	GEARCASE
E40RCRM 1984	GEARCASE
E40RCUD 1987	GEARCASE
E40RECR 1998	GEARCASE
E40REDS 1996	GEARCASE
E40REIA 1991	GEARCASE
E40RENM 1992	GEARCASE
E40REOD 1995	GEARCASE
E40RERE 1994	GEARCASE

E40RESR 1990	GEARCASE
E40RETB 1993	GEARCASE
E40REUC 1997	GEARCASE
E40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40RLCDE 1986	GEARCASE
E40RLCEC 1989	GEARCASE
E40RLCOB 1985	GEARCASE
E40RLCRM 1984	GEARCASE
E40RLCUD 1987	GEARCASE
E40RLECR 1998	GEARCASE
E40RLEDS 1996	GEARCASE
E40RLEIA 1991	GEARCASE
E40RLENM 1992	GEARCASE
E40RLEOD 1995	GEARCASE
E40RLERE 1994	GEARCASE
E40RLESR 1990	GEARCASE
E40RLETB 1993	GEARCASE
E40RLEUC 1997	GEARCASE
E40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TECDE 1986	GEARCASE
E40TECEC 1989	GEARCASE
E40TECOB 1985	GEARCASE
E40TECRM 1984	GEARCASE
E40TECUD 1987	GEARCASE
E40TEECR 1998	GEARCASE
E40TEEDS 1996	GEARCASE
E40TEEIA 1991	GEARCASE
E40TEENJ 1992	GEARCASE
E40TEENM 1992	GEARCASE
E40TEEOD 1995	GEARCASE
E40TEERE 1994	GEARCASE
E40TEESR 1990	GEARCASE
E40TEETB 1993	GEARCASE

E40TEEUC 1997	GEARCASE
E40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TELCDE 1986	GEARCASE
E40TELCEC 1989	GEARCASE
E40TELCOB 1985	GEARCASE
E40TELCRM 1984	GEARCASE
E40TELECR 1998	GEARCASE
E40TELEDS 1996	GEARCASE
E40TELEIA 1991	GEARCASE
E40TELENJ 1992	GEARCASE
E40TELENM 1992	GEARCASE
E40TELEOD 1995	GEARCASE
E40TELERE 1994	GEARCASE
E40TELESR 1990	GEARCASE
E40TELETB 1993	GEARCASE
E40TELEUC 1997	GEARCASE
E40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TLCDE 1986	GEARCASE
E40TLCEC 1989	GEARCASE
E40TLCUD 1987	GEARCASE
E40TLECR 1998	GEARCASE
E40TLEDS 1996	GEARCASE
E40TLEIA 1991	GEARCASE
E40TLENJ 1992	GEARCASE
E40TLENM 1992	GEARCASE
E40TLEOD 1995	GEARCASE
E40TLERE 1994	GEARCASE
E40TLESR 1990	GEARCASE
E40TLETB 1993	GEARCASE
E40TLETF 1993	GEARCASE
E40TLEUC 1997	GEARCASE
E40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TTLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT

E40TTLCEC 1989	GEARCASE
E40TTLECR 1998	GEARCASE
E40TTLEDS 1996	GEARCASE
E40TTLEIA 1991	GEARCASE
E40TTLENM 1992	GEARCASE
E40TTLEOD 1995	GEARCASE
E40TTLERE 1994	GEARCASE
E40TTLESR 1990	GEARCASE
E40TTLETB 1993	GEARCASE
E40TTLETF 1993	GEARCASE
E40TTLEUC 1997	GEARCASE
E40WREES 1999	GEARCASE
E40WRLEES 1999	GEARCASE
E40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRYEES 1999	GEARCASE
E40WRY SIR commercial, rope start, 25 in shaft 2001	GEARCASE
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
E45RCCDS 1986	GEARCASE
E45RCCUC 1987	GEARCASE
E45RCE 1989	GEARCASE
E45RCEIA 1991	GEARCASE
E45RCENM 1992	GEARCASE
E45RCEOD 1995	GEARCASE
E45RCERE 1994	GEARCASE
E45RCESR 1990	GEARCASE
E45RCETB 1993	GEARCASE
E45RCLCDS 1986	GEARCASE
E45RCLCUC 1987	GEARCASE
E45RCLE 1989	GEARCASE
E45RCLEDS 1996	GEARCASE
E45RCLEIA 1991	GEARCASE

E45RCLENM 1992	GEARCASE
E45RCLEOD 1995	GEARCASE
E45RCLERE 1994	GEARCASE
E45RCLESR 1990	GEARCASE
E45RCLETB 1993	GEARCASE
E45RCLEUC 1997	GEARCASE
E45WMLE 1989	GEARCASE
E45WMLEIA 1991	GEARCASE
E45WMLNEM 1992	GEARCASE
E45WMLESR 1990	GEARCASE
E48ESLCCC 1988	GEARCASE
E48ESLCER 1989	GEARCASE
E48ESLCUS 1987	GEARCASE
E48ESLEDC 1996	GEARCASE
E48ESLEIM 1991	GEARCASE
E48ESLENB 1992	GEARCASE
E48ESLEOS 1995	GEARCASE
E48ESLERD 1994	GEARCASE
E48ESLESA 1990	GEARCASE
E48ESLETE 1993	GEARCASE
E50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50BECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50BECDE 1986	GEARCASE
E50BECEC 1989	GEARCASE
E50BECIC 1981	GEARCASE, ELECTRIC START
E50BECIC 1981	GEARCASE, ROPE START
E50BECNR 1982	GEARCASE
E50BECOB 1985	GEARCASE
E50BECRM 1984	GEARCASE
E50BECTA 1983	GEARCASE
E50BECUD 1987	GEARCASE
E50BEEIA 1991	GEARCASE
E50BEENJ 1992	GEARCASE
E50BEENM 1992	GEARCASE
E50BEEOD 1995	GEARCASE

E50BEERE 1994	GEARCASE
E50BEESR 1990	GEARCASE
E50BEETB 1993	GEARCASE
E50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50BELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50BELCDE 1986	GEARCASE
E50BELCEC 1989	GEARCASE
E50BELCIC 1981	GEARCASE, ELECTRIC START
E50BELCIC 1981	GEARCASE, ROPE START
E50BELCNR 1982	GEARCASE
E50BELCOB 1985	GEARCASE
E50BELCRM 1984	GEARCASE
E50BELCTA 1983	GEARCASE
E50BELCUD 1987	GEARCASE
E50BELEIA 1991	GEARCASE
E50BELENJ 1992	GEARCASE
E50BELENM 1992	GEARCASE
E50BELEOD 1995	GEARCASE
E50BELERE 1994	GEARCASE
E50BELESR 1990	GEARCASE
E50BELETB 1993	GEARCASE
E50ECSR 1980	GEARCASE
E50ELCSR 1980	GEARCASE
E50ESLECC 1998	GEARCASE
E50ESLEUR 1997	GEARCASE
E50JEDS 1996	GEARCASE
E50JEIA 1991	GEARCASE
E50JENJ 1992	GEARCASE
E50JENM 1992	GEARCASE
E50JEOD 1995	GEARCASE
E50JERE 1994	GEARCASE
E50JETB 1993	GEARCASE
E50JEUC 1997	GEARCASE
E50RNLIA 1990	GEARCASE
E50RNLIB 1992	GEARCASE

E50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50TELCDE 1986	GEARCASE
E50TELCEC 1989	GEARCASE
E50TELCOB 1985	GEARCASE
E50TELCRM 1984	GEARCASE
E50TELCCTA 1983	GEARCASE
E50TELCUD 1987	GEARCASE
E50TELEIA 1991	GEARCASE
E50TELENM 1992	GEARCASE
E50TELEOD 1995	GEARCASE
E50TELERE 1994	GEARCASE
E50TELESR 1990	GEARCASE
E50TELETB 1993	GEARCASE
E50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50TLCDE 1986	GEARCASE
E50TLCEC 1989	GEARCASE
E50TLCOB 1985	GEARCASE
E50TLCRM 1984	GEARCASE
E50TLCUD 1987	GEARCASE
E50TLECR 1998	GEARCASE
E50TLEDS 1996	GEARCASE
E50TLEIA 1991	GEARCASE
E50TLENJ 1992	GEARCASE
E50TLENM 1992	GEARCASE
E50TLEOD 1995	GEARCASE
E50TLERE 1994	GEARCASE
E50TLESR 1990	GEARCASE
E50TLETB 1993	GEARCASE
E50TLETF 1993	GEARCASE
E50TLEUC 1997	GEARCASE
E50TSLECC 1998	GEARCASE
E50TSLEUS 1997	GEARCASE
E55RCIM 1981	GEARCASE, ELECTRIC START

E55RCIM 1981	GEARCASE, ROPE START
E55RLCSA 1980	GEARCASE, ELECTRIC START
E55RLCSA 1980	GEARCASE, ROPE START
E55RSLC 1997	GEARCASE
E55RSLG 1995	GEARCASE
E55RSLN 1983	GEARCASE
E55RSLN-2 1983	GEARCASE
E55RSLW 1996	GEARCASE
E55RSN 1983	GEARCASE
E55RSN-2 1983	GEARCASE
E55RSYN 1983	GEARCASE
E55RSYN-2 1983	GEARCASE
E55RWLDCD 1986	GEARCASE
E55RWLCOS 1985	GEARCASE
E55RWLCRD 1984	GEARCASE
E55RWLCUC 1987	GEARCASE
E55RWLE 1989	GEARCASE
E55RWLEIA 1991	GEARCASE
E55RWLENM 1992	GEARCASE
E55RWLERE 1994	GEARCASE
E55RWLESR 1990	GEARCASE
E55RWLETB 1993	GEARCASE
E55TLCIM 1981	GEARCASE, ELECTRIC START
E55TLCIM 1981	GEARCASE, ROPE START
E55WREES 1999	GEARCASE
E55WRLEES 1999	GEARCASE
E55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E55WRYEES 1999	GEARCASE
E55WRYISIR commercial, rope start, 25 in shaft 2001	GEARCASE
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE

E60ECIA 1981	GEARCASE, ELECTRIC START
E60ECIA 1981	GEARCASE, ROPE START
E60ECIH 1981	GEARCASE, ELECTRIC START
E60ECIH 1981	GEARCASE, ROPE START
E60ECNM 1982	GEARCASE
E60ECSR 1980	GEARCASE, ELECTRIC START
E60ECSR 1980	GEARCASE, ROPE START
E60ECTB 1983	GEARCASE
E60ELCIA 1981	GEARCASE, ELECTRIC START
E60ELCIA 1981	GEARCASE, ROPE START
E60ELCIH 1981	GEARCASE, ELECTRIC START
E60ELCIH 1981	GEARCASE, ROPE START
E60ELCNM 1982	GEARCASE
E60ELCOD 1985	GEARCASE
E60ELCRE 1984	GEARCASE
E60ELCSR 1980	GEARCASE, ELECTRIC START
E60ELCSR 1980	GEARCASE, ROPE START
E60ELCTB 1983	GEARCASE
E60TLCIA 1981	GEARCASE, ELECTRIC START
E60TLCIA 1981	GEARCASE, ROPE START
E60TLCIH 1981	GEARCASE, ELECTRIC START
E60TLCIH 1981	GEARCASE, ROPE START
E60TLCNM 1982	GEARCASE
E60TLCOD 1985	GEARCASE
E60TLCRE 1984	GEARCASE
E60TLCTB 1983	GEARCASE
ELECTRICAL 1972	BOLT KIT
ELECTRICAL 1973	POWER TILT AND TRIM 65 LONG SHAFT,85,115 AND 135 HP
ELECTRICAL 1974	POWER TILT AND TRIM 70 LONG SHAFT, 85,115 & 135 HP
GUFM-10C 1972	PUMP UNIT 245 JET DRIVE
GUFM-10S 1972	PUMP UNIT 245 JET DRIVE
GUFP-10C 1972	PUMP UNIT 245 JET DRIVE
HE40REDS 1996	GEARCASE
HE40REUC 1997	GEARCASE
HE40RLEDs 1996	GEARCASE

HE40RLEUC 1997	GEARCASE
HE45RCLEDS 1996	GEARCASE
HE45RCLEUC 1997	GEARCASE
HE55RSLC 1997	GEARCASE
HE55RSLW 1996	GEARCASE
HE55WMLM 1996	GEARCASE
HE55WMLZ 1997	GEARCASE
HJ40REDS 1996	GEARCASE
HJ40REUC 1997	GEARCASE
HJ40RLEDS 1996	GEARCASE
HJ40RLEUC 1997	GEARCASE
HJ45RCLEDS 1996	GEARCASE
HJ45RCLEUC 1997	GEARCASE
HJ55RSLC 1997	GEARCASE
HJ55RSLW 1996	GEARCASE
HJ55WMLM 1996	GEARCASE
HJ55WMLZ 1997	GEARCASE
HUFM-21C 1972	PUMP UNIT 245 JET DRIVE
HUFM-21S 1972	PUMP UNIT 245 JET DRIVE
HUFP-21C 1972	PUMP UNIT 245 JET DRIVE
HUTM-21C 1972	PUMP UNIT 245 JET DRIVE
HUTM-21S 1972	PUMP UNIT 245 JET DRIVE
HUTP-21C 1972	PUMP UNIT 245 JET DRIVE
J35AELCDE 1986	GEARCASE
J35AELCUD 1987	GEARCASE
J35ARLCDE 1986	GEARCASE
J35ARLCUD 1987	GEARCASE
J40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40AELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ARLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ATLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT

J40ECDE 1986	GEARCASE
J40ECEC 1989	GEARCASE
J40ECOB 1985	GEARCASE
J40ECRM 1984	GEARCASE
J40ECUD 1987	GEARCASE
J40EEIA 1991	GEARCASE
J40EENJ 1992	GEARCASE
J40EENM 1992	GEARCASE
J40EEOD 1995	GEARCASE
J40EERE 1994	GEARCASE
J40EESR 1990	GEARCASE
J40EETB 1993	GEARCASE
J40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ELCDE 1986	GEARCASE
J40ELCEC 1989	GEARCASE
J40ELCOB 1985	GEARCASE
J40ELCRM 1984	GEARCASE
J40ELCUD 1987	GEARCASE
J40ELECR 1998	GEARCASE
J40ELEDS 1996	GEARCASE
J40ELEIA 1991	GEARCASE
J40ELENJ 1992	GEARCASE
J40ELENM 1992	GEARCASE
J40ELEOD 1995	GEARCASE
J40ELERE 1994	GEARCASE
J40ELESR 1990	GEARCASE
J40ELETB 1993	GEARCASE
J40ELEUC 1997	GEARCASE
J40PLEEA 1999	GEARCASE
J40PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J40PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J40PLSOC	GEARCASE

J40PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSRS	GEARCASE
J40PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J40PLSTD	GEARCASE
J40PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40RCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40RCDE 1986	GEARCASE
J40RCEC 1989	GEARCASE
J40RCOB 1985	GEARCASE
J40RCRM 1984	GEARCASE
J40RCUD 1987	GEARCASE
J40RECR 1998	GEARCASE
J40REDS 1996	GEARCASE
J40REEA 1999	GEARCASE
J40REIA 1991	GEARCASE
J40RENM 1992	GEARCASE
J40REOD 1995	GEARCASE
J40RERE 1994	GEARCASE
J40RESR 1990	GEARCASE
J40RETB 1993	GEARCASE
J40REUC 1997	GEARCASE
J40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40RLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40RLCDE 1986	GEARCASE
J40RLCEC 1989	GEARCASE
J40RLCOB 1985	GEARCASE
J40RLCRM 1984	GEARCASE
J40RLCUD 1987	GEARCASE
J40RLECR 1998	GEARCASE
J40RLEDS 1996	GEARCASE
J40RLEEA 1999	GEARCASE
J40RLEIA 1991	GEARCASE
J40RLENM 1992	GEARCASE

J40RLEOD 1995	GEARCASE
J40RLERE 1994	GEARCASE
J40RLESR 1990	GEARCASE
J40RLETB 1993	GEARCASE
J40RLEUC 1997	GEARCASE
J40RLSIF rope start, 20 in shaft 2001	GEARCASE
J40RLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RLSOC	GEARCASE
J40RLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSRS	GEARCASE
J40RLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40RLSTD	GEARCASE
J40RLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSIF rope start, 15 in shaft 2001	GEARCASE
J40RSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RSOC	GEARCASE
J40RSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSRS	GEARCASE
J40RSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40RSTD	GEARCASE
J40RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TECDE 1986	GEARCASE
J40TECEC 1989	GEARCASE
J40TECOB 1985	GEARCASE
J40TECRM 1984	GEARCASE
J40TECUD 1987	GEARCASE
J40TEECR 1998	GEARCASE
J40TEEDS 1996	GEARCASE

J40TEEIA 1991	GEARCASE
J40TEENJ 1992	GEARCASE
J40TEENM 1992	GEARCASE
J40TEEOD 1995	GEARCASE
J40TEERE 1994	GEARCASE
J40TEESR 1990	GEARCASE
J40TEETB 1993	GEARCASE
J40TEEUC 1997	GEARCASE
J40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TELCDE 1986	GEARCASE
J40TELCEC 1989	GEARCASE
J40TELCOB 1985	GEARCASE
J40TELCRM 1984	GEARCASE
J40TELECR 1998	GEARCASE
J40TELEDS 1996	GEARCASE
J40TELEIA 1991	GEARCASE
J40TELENJ 1992	GEARCASE
J40TELENM 1992	GEARCASE
J40TELEOD 1995	GEARCASE
J40TELERE 1994	GEARCASE
J40TELESR 1990	GEARCASE
J40TELETB 1993	GEARCASE
J40TELEUC 1997	GEARCASE
J40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TLCDE 1986	GEARCASE
J40TLCEC 1989	GEARCASE
J40TLCUD 1987	GEARCASE
J40TLECR 1998	GEARCASE
J40TLEDS 1996	GEARCASE
J40TLEIA 1991	GEARCASE
J40TLENJ 1992	GEARCASE
J40TLENM 1992	GEARCASE
J40TLEOD 1995	GEARCASE

J40TLERE 1994	GEARCASE
J40TLESR 1990	GEARCASE
J40TLETB 1993	GEARCASE
J40TLETF 1993	GEARCASE
J40TLEUC 1997	GEARCASE
J40TPLEEA 1999	GEARCASE
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	GEARCASE
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TTLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TTLCEC 1989	GEARCASE
J40TTLECR 1998	GEARCASE
J40TTLEDS 1996	GEARCASE
J40TTLEIA 1991	GEARCASE
J40TTLENM 1992	GEARCASE
J40TTLEOD 1995	GEARCASE
J40TTLERE 1994	GEARCASE
J40TTLESR 1990	GEARCASE
J40TTLETB 1993	GEARCASE
J40TTLETF 1993	GEARCASE
J40TTLEUC 1997	GEARCASE
J40WREES 1999	GEARCASE
J40WRLEES 1999	GEARCASE
J40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40WRYEES 1999	GEARCASE
J40WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J45RCCDS 1986	GEARCASE
J45RCCUC 1987	GEARCASE
J45RCE 1989	GEARCASE
J45RCEIA 1991	GEARCASE

J45RCENM 1992	GEARCASE
J45RCEOD 1995	GEARCASE
J45RCERE 1994	GEARCASE
J45RCESR 1990	GEARCASE
J45RCETB 1993	GEARCASE
J45RCLCDS 1986	GEARCASE
J45RCLCUC 1987	GEARCASE
J45RCLE 1989	GEARCASE
J45RCLEDS 1996	GEARCASE
J45RCLEIA 1991	GEARCASE
J45RCLENM 1992	GEARCASE
J45RCLEOD 1995	GEARCASE
J45RCLERE 1994	GEARCASE
J45RCLESR 1990	GEARCASE
J45RCLETB 1993	GEARCASE
J45RCLEUC 1997	GEARCASE
J45WMLE 1989	GEARCASE
J45WMLEIA 1991	GEARCASE
J45WMLNEM 1992	GEARCASE
J45WMLESR 1990	GEARCASE
J48ESLCCC 1988	GEARCASE
J48ESLCER 1989	GEARCASE
J48ESLCUS 1987	GEARCASE
J48ESLEDC 1996	GEARCASE
J48ESLEIM 1991	GEARCASE
J48ESLENB 1992	GEARCASE
J48ESLEOS 1995	GEARCASE
J48ESLERD 1994	GEARCASE
J48ESLESA 1990	GEARCASE
J48ESLETE 1993	GEARCASE
J50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50BECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50BECDE 1986	GEARCASE
J50BECEC 1989	GEARCASE
J50BECIC 1981	GEARCASE, ELECTRIC START

J50BECIC 1981	GEARCASE, ROPE START
J50BECNR 1982	GEARCASE
J50BECOB 1985	GEARCASE
J50BECRM 1984	GEARCASE
J50BECTA 1983	GEARCASE
J50BECUD 1987	GEARCASE
J50BEEIA 1991	GEARCASE
J50BEENJ 1992	GEARCASE
J50BEENM 1992	GEARCASE
J50BEEOD 1995	GEARCASE
J50BEERE 1994	GEARCASE
J50BEESR 1990	GEARCASE
J50BEETB 1993	GEARCASE
J50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50BELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50BELCDE 1986	GEARCASE
J50BELCEC 1989	GEARCASE
J50BELCIC 1981	GEARCASE, ELECTRIC START
J50BELCIC 1981	GEARCASE, ROPE START
J50BELCNR 1982	GEARCASE
J50BELCOB 1985	GEARCASE
J50BELCRM 1984	GEARCASE
J50BELCTA 1983	GEARCASE
J50BELCUD 1987	GEARCASE
J50BELEIA 1991	GEARCASE
J50BELENJ 1992	GEARCASE
J50BELENM 1992	GEARCASE
J50BELEOD 1995	GEARCASE
J50BELERE 1994	GEARCASE
J50BELESR 1990	GEARCASE
J50BELETB 1993	GEARCASE
J50ECSR 1980	GEARCASE
J50ELCSR 1980	GEARCASE
J50ELEER 1999	GEARCASE
J50ELSIF elec start, 20 in shaft 2001	GEARCASE

J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	GEARCASE
J50ESLECC 1998	GEARCASE
J50ESLEUR 1997	GEARCASE
J50JEDS 1996	GEARCASE
J50JEIA 1991	GEARCASE
J50JENJ 1992	GEARCASE
J50JENM 1992	GEARCASE
J50JEOD 1995	GEARCASE
J50JERE 1994	GEARCASE
J50JETB 1993	GEARCASE
J50JEUC 1997	GEARCASE
J50PLEEA 1999	GEARCASE
J50PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J50PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J50PLSOC	GEARCASE
J50PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSRS	GEARCASE
J50PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J50PLSTD	GEARCASE
J50PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50TELCDE 1986	GEARCASE
J50TELCEC 1989	GEARCASE
J50TELCOB 1985	GEARCASE
J50TELCRM 1984	GEARCASE
J50TELCCTA 1983	GEARCASE
J50TELCUD 1987	GEARCASE
J50TELEIA 1991	GEARCASE
J50TELENM 1992	GEARCASE
J50TELEOD 1995	GEARCASE
J50TELERE 1994	GEARCASE

J50TELESR 1990	GEARCASE
J50TELETB 1993	GEARCASE
J50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50TLCDE 1986	GEARCASE
J50TLCEC 1989	GEARCASE
J50TLCOB 1985	GEARCASE
J50TLCRM 1984	GEARCASE
J50TLCUD 1987	GEARCASE
J50TLECR 1998	GEARCASE
J50TLEDS 1996	GEARCASE
J50TLEIA 1991	GEARCASE
J50TLENJ 1992	GEARCASE
J50TLENM 1992	GEARCASE
J50TLEOD 1995	GEARCASE
J50TLERE 1994	GEARCASE
J50TLESR 1990	GEARCASE
J50TLETB 1993	GEARCASE
J50TLETF 1993	GEARCASE
J50TLEUC 1997	GEARCASE
J50TSLECC 1998	GEARCASE
J50TSLEUS 1997	GEARCASE
J55APRL	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRL - FR	27-6_BOÎTIER D'ENGRENAGES & BOÎTIER DE ROTOR - Modèles APRL
J55APRLSOM	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSOM - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRA	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRA - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRG	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRG - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55MLSOR	GEARCASE (ML MODEL)
J55MLSOR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MLSRC	GEARCASE (ML MODEL)

J55MLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MLSRG	GEARCASE (ML MODEL)
J55MLSRG - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MRL	GEARCASE (ML MODEL)
J55MRL - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55RCIM 1981	GEARCASE, ELECTRIC START
J55RCIM 1981	GEARCASE, ROPE START
J55RLCIM 1981	GEARCASE, ELECTRIC START
J55RLCIM 1981	GEARCASE, ROPE START
J55RLCSA 1980	GEARCASE,ELECTRIC START
J55RLCSA 1980	GEARCASE,ROPE START
J55RSLC 1997	GEARCASE
J55RSLG 1995	GEARCASE
J55RSLN 1983	GEARCASE
J55RSLN-2 1983	GEARCASE
J55RSLW 1996	GEARCASE
J55RSN 1983	GEARCASE
J55RSN-2 1983	GEARCASE
J55RSYN 1983	GEARCASE
J55RSYN-2 1983	GEARCASE
J55RWLCDC 1986	GEARCASE
J55RWLCOS 1985	GEARCASE
J55RWLCRD 1984	GEARCASE
J55RWLCUC 1987	GEARCASE
J55RWLE 1989	GEARCASE
J55RWLEIA 1991	GEARCASE
J55RWLENM 1992	GEARCASE
J55RWLERE 1994	GEARCASE
J55RWLESR 1990	GEARCASE
J55RWLETB 1993	GEARCASE
J55WREES 1999	GEARCASE
J55WRLEES 1999	GEARCASE
J55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE

J55WRLSTM	GEARCASE
J55WRLSTM - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J55WRYEES 1999	GEARCASE
J55WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J60ECIA 1981	GEARCASE, ELECTRIC START
J60ECIA 1981	GEARCASE, ROPE START
J60ECIH 1981	GEARCASE, ELECTRIC START
J60ECIH 1981	GEARCASE, ROPE START
J60ECNM 1982	GEARCASE
J60ECSR 1980	GEARCASE,ELECTRIC START
J60ECSR 1980	GEARCASE,ROPE START
J60ECTB 1983	GEARCASE
J60ELCIA 1981	GEARCASE, ELECTRIC START
J60ELCIA 1981	GEARCASE, ROPE START
J60ELCIH 1981	GEARCASE, ELECTRIC START
J60ELCIH 1981	GEARCASE, ROPE START
J60ELCNM 1982	GEARCASE
J60ELCOD 1985	GEARCASE
J60ELCRE 1984	GEARCASE
J60ELCSR 1980	GEARCASE,ELECTRIC START
J60ELCSR 1980	GEARCASE,ROPE START
J60ELCTB 1983	GEARCASE
J60TLCIA 1981	GEARCASE, ELECTRIC START
J60TLCIA 1981	GEARCASE, ROPE START
J60TLCIH 1981	GEARCASE, ELECTRIC START
J60TLCIH 1981	GEARCASE, ROPE START
J60TLCNM 1982	GEARCASE
J60TLCOD 1985	GEARCASE
J60TLCRE 1984	GEARCASE
J60TLCTB 1983	GEARCASE
JUFM-10C 1972	PUMP UNIT 245 JET DRIVE

JUFM-10S 1972	PUMP UNIT 245 JET DRIVE
JX-245 1972	PUMP UNIT 245 JET DRIVE
LUFM-10C 1972	PUMP UNIT 245 JET DRIVE
LUFM-10S 1972	PUMP UNIT 245 JET DRIVE
LUFP-10C 1972	PUMP UNIT 245 JET DRIVE
M55RWLR 1988	GEARCASE
MISCELLANEOUS 1973	CARRYING HANDLE KIT 40 HP MODELS
MISCELLANEOUS 1974	CARRYING HANDLE KIT 40 HP MODELS
MISCELLANEOUS 1975	CARRYING HANDLE KIT 40 HP MODELS
MISCELLANEOUS 1976	CARRYING HANDLE KIT 40 H.P.
R45RCLR 1988	GEARCASE
R45RCR 1988	GEARCASE
R55RWLR 1988	GEARCASE
RD-30A 1968	LOWER UNIT GROUP MANUAL START
RD-30D 1968	LOWER UNIT GROUP MANUAL START
RD-30S 1968	LOWER UNIT GROUP MANUAL START
RDL-30A 1968	LOWER UNIT GROUP MANUAL START
RDL-30D 1968	LOWER UNIT GROUP MANUAL START
RDL-30S 1968	LOWER UNIT GROUP MANUAL START
RDS-30A 1968	LOWER UNIT GROUP
RDS-30C 1968	LOWER UNIT GROUP
RDS-30D 1968	LOWER UNIT GROUP
RDS-30S 1968	LOWER UNIT GROUP
RDSL-30A 1968	LOWER UNIT GROUP
RDSL-30C 1968	LOWER UNIT GROUP
RDSL-30D 1968	LOWER UNIT GROUP
RDSL-30S 1968	LOWER UNIT GROUP
RJ50ELSIF elec start, TNT, 20 in shaft 2001	GEARCASE
RK-30A 1968	LOWER UNIT GROUP ELECTRIC SHIFT
RK-30C 1968	LOWER UNIT GROUP ELECTRIC SHIFT
RK-30D 1968	LOWER UNIT GROUP ELECTRIC SHIFT
RKL-30A 1968	LOWER UNIT GROUP ELECTRIC SHIFT
RKL-30C 1968	LOWER UNIT GROUP ELECTRIC SHIFT
RKL-30D 1968	LOWER UNIT GROUP ELECTRIC SHIFT
S45RCLR 1988	GEARCASE

S45RCR 1988	GEARCASE
SE40RPB 1997	GEARCASE
SE40RPH 1996	GEARCASE
SE40RPLB 1997	GEARCASE
SE40RPLH 1996	GEARCASE
SE40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPYB 1997	GEARCASE
SE40RPYH 1996	GEARCASE
SE40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RSLD 1997	GEARCASE
SE40RSLR 1998	GEARCASE
SE40RSLZ 1996	GEARCASE
SE45RSLB 1997	GEARCASE
SE45RSLH 1996	GEARCASE
SE50TLEDS 1996	GEARCASE
SE55RSC 1997	GEARCASE
SE55RSLC 1997	GEARCASE
SE55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSLW 1996	GEARCASE
SE55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSW 1996	GEARCASE
SE55RSYC 1997	GEARCASE
SE55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSYW 1996	GEARCASE
SJ40EEDS 1996	GEARCASE
SJ40REDS 1996	GEARCASE
SJ40RLEDS 1996	GEARCASE
SJ40RPB 1997	GEARCASE

SJ40RPH 1996	GEARCASE
SJ40RPLB 1997	GEARCASE
SJ40RPLH 1996	GEARCASE
SJ40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RPYB 1997	GEARCASE
SJ40RPYH 1996	GEARCASE
SJ40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RSLD 1997	GEARCASE
SJ40RSLR 1998	GEARCASE
SJ40RSLZ 1996	GEARCASE
SJ45RSLB 1997	GEARCASE
SJ45RSLH 1996	GEARCASE
SJ55RSC 1997	GEARCASE
SJ55RSLC 1997	GEARCASE
SJ55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSLW 1996	GEARCASE
SJ55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSW 1996	GEARCASE
SJ55RSYC 1997	GEARCASE
SJ55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSYW 1996	GEARCASE
TE40ELCEC 1989	GEARCASE
TE40ELEIA 1991	GEARCASE
TE40ELENJ 1992	GEARCASE
TE40ELENM 1992	GEARCASE
TE40ELESR 1990	GEARCASE
TE40ELETB 1993	GEARCASE
TE40TELESF 1990	GEARCASE

TE40TELESR 1990	GEARCASE
TE48ESLETE 1993	GEARCASE
TE50TLCEC 1989	GEARCASE
TE50TLESF 1989	GEARCASE
TE50TLESF 1990	GEARCASE
TE50TLESR 1990	GEARCASE
TJ40ELCEC 1989	GEARCASE
TJ40ELEIA 1991	GEARCASE
TJ40ELENJ 1992	GEARCASE
TJ40ELENM 1992	GEARCASE
TJ40ELESF 1990	GEARCASE
TJ40ELESR 1990	GEARCASE
TJ40ELETB 1993	GEARCASE
TJ40TELESF 1990	GEARCASE
TJ40TELESR 1990	GEARCASE
TJ48ESLETE 1993	GEARCASE
TJ50TLCEC 1989	GEARCASE
TJ50TLESF 1989	GEARCASE
TJ50TLESF 1990	GEARCASE
TJ50TLESR 1990	GEARCASE
TUFM-21C 1972	PUMP UNIT 245 JET DRIVE
TUFM-21S 1972	PUMP UNIT 245 JET DRIVE
TUFP-21C 1972	PUMP UNIT 245 JET DRIVE
VE40EEIA 1991	GEARCASE
VE40EENJ 1992	GEARCASE
VE40EENM 1992	GEARCASE
VE40EESR 1990	GEARCASE
VE40EETB 1993	GEARCASE
VE40ELEIA 1991	GEARCASE
VE40ELENJ 1992	GEARCASE
VE40ELENM 1992	GEARCASE
VE40ELESR 1990	GEARCASE
VE40ELETB 1993	GEARCASE
VE40TELEIA 1991	GEARCASE
VE40TELENJ 1992	GEARCASE

VE40TELENM 1992	GEARCASE
VE40TELESR 1990	GEARCASE
VE40TELETB 1993	GEARCASE
VE40TLEIA 1991	GEARCASE
VE40TLENJ 1992	GEARCASE
VE40TLENM 1992	GEARCASE
VE40TLESR 1990	GEARCASE
VE40TLETB 1993	GEARCASE
VE40TLETF 1993	GEARCASE
VE48ESLCCC 1988	GEARCASE
VE48ESLCER 1989	GEARCASE
VE48ESLENB 1992	GEARCASE
VE48ESLESA 1990	GEARCASE
VE48ESLETE 1993	GEARCASE
VE50BEEIA 1991	GEARCASE
VE50BEENJ 1992	GEARCASE
VE50BEENM 1992	GEARCASE
VE50BEESR 1990	GEARCASE
VE50BEETB 1993	GEARCASE
VE50BELEIA 1991	GEARCASE
VE50BELENJ 1992	GEARCASE
VE50BELENM 1992	GEARCASE
VE50BELESR 1990	GEARCASE
VE50BELETB 1993	GEARCASE
VE50TELENM 1992	GEARCASE
VE50TLEIA 1991	GEARCASE
VE50TLENJ 1992	GEARCASE
VE50TLENM 1992	GEARCASE
VE50TLESR 1990	GEARCASE
VE50TLETB 1993	GEARCASE
VE50TLETF 1993	GEARCASE
VJ40EEIA 1991	GEARCASE
VJ40EENJ 1992	GEARCASE
VJ40EENM 1992	GEARCASE
VJ40EESR 1990	GEARCASE

VJ40EETB 1993	GEARCASE
VJ40ELEIA 1991	GEARCASE
VJ40ELENJ 1992	GEARCASE
VJ40ELENM 1992	GEARCASE
VJ40ELESR 1990	GEARCASE
VJ40ELETB 1993	GEARCASE
VJ40TELEIA 1991	GEARCASE
VJ40TELENJ 1992	GEARCASE
VJ40TELENM 1992	GEARCASE
VJ40TELESR 1990	GEARCASE
VJ40TELETB 1993	GEARCASE
VJ40TLEIA 1991	GEARCASE
VJ40TLENJ 1992	GEARCASE
VJ40TLENM 1992	GEARCASE
VJ40TLESR 1990	GEARCASE
VJ40TLETB 1993	GEARCASE
VJ40TLETF 1993	GEARCASE
VJ48ESLCCC 1988	GEARCASE
VJ48ESLCER 1989	GEARCASE
VJ48ESLENB 1992	GEARCASE
VJ48ESLESA 1990	GEARCASE
VJ48ESLETE 1993	GEARCASE
VJ50BEEIA 1991	GEARCASE
VJ50BEENJ 1992	GEARCASE
VJ50BEENM 1992	GEARCASE
VJ50BEESR 1990	GEARCASE
VJ50BEETB 1993	GEARCASE
VJ50BELEIA 1991	GEARCASE
VJ50BELENJ 1992	GEARCASE
VJ50BELENM 1992	GEARCASE
VJ50BELESR 1990	GEARCASE
VJ50BELETB 1993	GEARCASE
VJ50TELENM 1992	GEARCASE
VJ50TLEIA 1991	GEARCASE
VJ50TLENJ 1992	GEARCASE

VJ50TLENM 1992	GEARCASE
VJ50TLESR 1990	GEARCASE
VJ50TLETB 1993	GEARCASE
VJ50TLETF 1993	GEARCASE
VUFM-10C 1972	PUMP UNIT 245 JET DRIVE
VUFM-10S 1972	PUMP UNIT 245 JET DRIVE
VUFP-10C 1972	PUMP UNIT 245 JET DRIVE
WUFM-10C 1972	PUMP UNIT 245 JET DRIVE
WUPM-10C 1972	PUMP UNIT 245 JET DRIVE
X50ESLECC 1998	GEARCASE
XUFM-21A 1972	PUMP UNIT 245 JET DRIVE
XUFM-21R 1972	PUMP UNIT 245 JET DRIVE
XUFP-21A 1972	PUMP UNIT 245 JET DRIVE