

Where Used: Part Number 0310331

Model Name	Diagram
3802A 1968	GEARCASE GROUP-STANDARD DRIVE
3802M 1968	GEARCASE GROUP-STANDARD DRIVE
3803A 1968	GEARCASE GROUP-STANDARD DRIVE
3803M 1968	GEARCASE GROUP-STANDARD DRIVE
3806A 1968	GEARCASE GROUP-STANDARD DRIVE
3806M 1968	GEARCASE GROUP-STANDARD DRIVE
3807A 1968	GEARCASE GROUP-STANDARD DRIVE
3807M 1968	GEARCASE GROUP-STANDARD DRIVE
3832A 1968	GEARCASE GROUP-STANDARD DRIVE
3832M 1968	GEARCASE GROUP-STANDARD DRIVE
3833A 1968	GEARCASE GROUP-STANDARD DRIVE
3833M 1968	GEARCASE GROUP-STANDARD DRIVE
3836A 1968	GEARCASE GROUP-STANDARD DRIVE
3836M 1968	GEARCASE GROUP-STANDARD DRIVE
3837A 1968	GEARCASE GROUP-STANDARD DRIVE
3837M 1968	GEARCASE GROUP-STANDARD DRIVE
4006E 1970	GEARCASE GROUP-STANDARD DRIVE
4007E 1970	GEARCASE GROUP-STANDARD DRIVE
4036E 1970	GEARCASE GROUP-STANDARD DRIVE
4037E 1970	GEARCASE GROUP-STANDARD DRIVE
4106D 1971	GEARCASE-STANDARD DRIVE
4107D 1971	GEARCASE-STANDARD DRIVE
4136D 1971	GEARCASE-STANDARD DRIVE
4137D 1971	GEARCASE-STANDARD DRIVE
4206S 1972	GEARCASE-STANDARD DRIVE
4236S 1972	GEARCASE-STANDARD DRIVE
4306C 1973	GEARCASE - STANDARD DRIVE
4336C 1973	GEARCASE - STANDARD DRIVE
4406R 1974	GEARCASE - STANDARD DRIVE
4436R 1974	GEARCASE - STANDARD DRIVE
4506A 1975	GEARCASE-STANDARD DRIVE
4536A 1975	GEARCASE-STANDARD DRIVE
4606M 1976	GEARCASE-STANDARD DRIVE

4636M 1976	GEARCASE-STANDARD DRIVE
4706B 1977	GEARCASE-STANDARD DRIVE
4736B 1977	GEARCASE-STANDARD DRIVE
4806E 1978	GEARCASE STANDARD DRIVE
4836E 1978	GEARCASE STANDARD DRIVE
4837E 1978	GEARCASE STANDARD DRIVE
4902B 1969	GEARCASE GROUP-STANDARD DRIVE
4904D 1979	GEARCASE-STANDARD DRIVE
4906B 1969	GEARCASE GROUP-STANDARD DRIVE
4932D 1979	GEARCASE-STANDARD DRIVE
4933D 1979	GEARCASE-STANDARD DRIVE
4936B 1969	GEARCASE GROUP-STANDARD DRIVE
4R69B 1969	GEARCASE GROUP - STANDARD DRIVE
4R70E 1970	GEARCASE GROUP STANDARD DRIVE
4R71D 1971	GEARCASE-STANDARD DRIVE
4R72S 1972	GEARCASE-STANDARD DRIVE
4R73C 1973	GEARCASE-STANDARD DRIVE
4R74R 1974	GEARCASE - STANDARD DRIVE
4R75A 1975	GEARCASE-STANDARD DRIVE
4R76M 1976	GEARCASE-STANDARD DRIVE
4R77B 1977	GEARCASE-STANDARD DRIVE
4R78E 1978	GEARCASE - STANDARD DRIVE
4R79D 1979	GEARCASE - STANDARD DRIVE
4RL70E 1970	GEARCASE GROUP STANDARD DRIVE
4RL71D 1971	GEARCASE-STANDARD DRIVE
4RL78E 1978	GEARCASE - STANDARD DRIVE
4RL79D 1979	GEARCASE - STANDARD DRIVE
4W69B 1969	GEARCASE GROUP - STANDARD DRIVE
4W70E 1970	GEARCASE GROUP STANDARD DRIVE
4W71D 1971	GEARCASE-STANDARD DRIVE
4W72S 1972	GEARCASE-STANDARD DRIVE
4W73C 1973	GEARCASE-STANDARD DRIVE
4W74R 1974	GEARCASE - STANDARD DRIVE
4W75A 1975	GEARCASE-STANDARD DRIVE
4W76M 1976	GEARCASE-STANDARD DRIVE

4W77B 1977	GEARCASE-STANDARD DRIVE
4W78E 1978	GEARCASE - STANDARD DRIVE
4W79D 1979	GEARCASE - STANDARD DRIVE
4WF69B 1969	GEARCASE GROUP - STANDARD DRIVE
4WL70E 1970	GEARCASE GROUP STANDARD DRIVE
4WL71D 1971	GEARCASE-STANDARD DRIVE
BE3REDS 1996	GEARCASE
BE4BREDS 1996	GEARCASE
BE4BREUC 1997	GEARCASE
BE4BRLEDS 1996	GEARCASE
BE4BRLEUC 1997	GEARCASE
BE4REDS 1996	GEARCASE
BE4RLEDS 1996	GEARCASE
BJ3REDS 1996	GEARCASE
BJ4BREDS 1996	GEARCASE
BJ4BREUC 1997	GEARCASE
BJ4BRLEDS 1996	GEARCASE
BJ4BRLEUC 1997	GEARCASE
BJ4REDS 1996	GEARCASE
BJ4RLEDS 1996	GEARCASE
E2WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE - 3WR
E3BRCEC 1989	GEARCASE
E3BRESR 1990	GEARCASE
E3RCCM 1988	GEARCASE - 3RC MODELS
E3RCCM 1988	GEARCASE - 4RC & 4RLC MODELS
E3RCUA 1987	GEARCASE - 3RC MODELS
E3RCUA 1987	GEARCASE - 4RC & 4RLC MODELS
E3REIA 1991	GEARCASE
E3RENM 1992	GEARCASE
E3REOD 1995	GEARCASE
E3RERE 1994	GEARCASE
E3RETB 1993	GEARCASE
E3REUC 1997	GEARCASE
E3ROSIA Commercial, Rope Start, Tiller, 15 IN. shaft, N/A USA 2001	GEARCASE - 3RT - RTV - RO
E3WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE - 3WR

E4BRCICI 1981	GEARCASE
E4BRECRJ 1998	GEARCASE
E4BRHCCS 1988	GEARCASE
E4BRHCDE 1986	GEARCASE
E4BRHCNR 1982	GEARCASE
E4BRHCOB 1985	GEARCASE
E4BRHCRM 1984	GEARCASE
E4BRHCTA 1983	GEARCASE
E4BRHCUD 1987	GEARCASE
E4BRHLCCS 1988	GEARCASE
E4BRHLCDE 1986	GEARCASE
E4BRHLCNR 1982	GEARCASE
E4BRHLCOB 1985	GEARCASE
E4BRHLCRM 1984	GEARCASE
E4BRHLCTA 1983	GEARCASE
E4BRHLCUD 1987	GEARCASE
E4BRLCIC 1981	GEARCASE
E4BRLECRJ 1998	GEARCASE
E4RCCS 1988	GEARCASE - 3RC MODELS
E4RCCS 1988	GEARCASE - 4RC & 4RLC MODELS
E4RCEC 1989	GEARCASE
E4RCUD 1987	GEARCASE - 3RC MODELS
E4RCUD 1987	GEARCASE - 4RC & 4RLC MODELS
E4REDS 1996	GEARCASE
E4REIA 1991	GEARCASE
E4RENM 1992	GEARCASE
E4REOD 1995	GEARCASE
E4RERE 1994	GEARCASE
E4RESR 1990	GEARCASE
E4RETB 1993	GEARCASE
E4REUC 1997	GEARCASE
E4RLCCS 1988	GEARCASE - 3RC MODELS
E4RLCCS 1988	GEARCASE - 4RC & 4RLC MODELS
E4RLCEC 1989	GEARCASE
E4RLCSS 1980	GEARCASE-STANDARD DRIVE

E4RLCUD 1987	GEARCASE - 3RC MODELS
E4RLCUD 1987	GEARCASE - 4RC & 4RLC MODELS
E4RLEDS 1996	GEARCASE
E4RLEIA 1991	GEARCASE
E4RLENM 1992	GEARCASE
E4RLEOD 1995	GEARCASE
E4RLERE 1994	GEARCASE
E4RLESR 1990	GEARCASE
E4RLETB 1993	GEARCASE
E4RLEUC 1997	GEARCASE
E4WCSS 1980	GEARCASE-STANDARD DRIVE
J2RTSIA Commercial, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE - 3RT - RTV - RO
J2RTVSIA Commercial, Rope Start, Tiller, 15 IN. shaft, wht 2001	GEARCASE - 3RT - RTV - RO
J2WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE - 3WR
J3BRCEC 1989	GEARCASE
J3BRESR 1990	GEARCASE
J3RCCM 1988	GEARCASE - 3RC MODELS
J3RCCM 1988	GEARCASE - 4RC & 4RLC MODELS
J3RCUA 1987	GEARCASE - 3RC MODELS
J3RCUA 1987	GEARCASE - 4RC & 4RLC MODELS
J3REIA 1991	GEARCASE
J3RENM 1992	GEARCASE
J3REOD 1995	GEARCASE
J3RERE 1994	GEARCASE
J3RETB 1993	GEARCASE
J3REUC 1997	GEARCASE
J3RSDE	GEARCASE
J3RSDE - FR	27-1_BOÎTIER D'ENGRENAGES
J3RSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J3RSNF Carbureted, Rope start, Neutral & Forward, White 2002	GEARCASE
J3RSOD	GEARCASE
J3RSOD - FR	27-1_BOÎTIER D'ENGRENAGES
J3RSRE	GEARCASE
J3RSRE - FR	27-1_BOÎTIER D'ENGRENAGES
J3RSTB	GEARCASE

J3RSTB - FR	27-1_BOÎTIER D'ENGRENAGES
J3RSTF	GEARCASE
J3RSTF - FR	27-1_BOÎTIER D'ENGRENAGES
J3RTLZIA Commercial, Rope Start, Tiller, 20 IN. shaft 2001	GEARCASE - 3RT - RTV - RO
J3RTSIA Commercial, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE - 3RT - RTV - RO
J3RTVSIA Commercial, Rope Start, Tiller, 15 IN. shaft, wht 2001	GEARCASE - 3RT - RTV - RO
J3WRSIR Commercial, Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE - 3WR
J4BRCIC 1981	GEARCASE
J4BRECRJ 1998	GEARCASE
J4BRHCCS 1988	GEARCASE
J4BRHCDE 1986	GEARCASE
J4BRHCNR 1982	GEARCASE
J4BRHCOB 1985	GEARCASE
J4BRHCRM 1984	GEARCASE
J4BRHCTA 1983	GEARCASE
J4BRHCUD 1987	GEARCASE
J4BRHLCCS 1988	GEARCASE
J4BRHLCDE 1986	GEARCASE
J4BRHLCNR 1982	GEARCASE
J4BRHLCOB 1985	GEARCASE
J4BRHLCRM 1984	GEARCASE
J4BRHLCTA 1983	GEARCASE
J4BRHLCUD 1987	GEARCASE
J4BRLCIC 1981	GEARCASE
J4BRLECRJ 1998	GEARCASE
J4RCCS 1988	GEARCASE - 3RC MODELS
J4RCCS 1988	GEARCASE - 4RC & 4RLC MODELS
J4RCEC 1989	GEARCASE
J4RCUD 1987	GEARCASE - 3RC MODELS
J4RCUD 1987	GEARCASE - 4RC & 4RLC MODELS
J4REDS 1996	GEARCASE
J4REEA 1999	GEARCASE
J4REIA 1991	GEARCASE
J4RENM 1992	GEARCASE
J4REOD 1995	GEARCASE

J4RERE 1994	GEARCASE
J4RESR 1990	GEARCASE
J4RETB 1993	GEARCASE
J4REUC 1997	GEARCASE
J4RLCCS 1988	GEARCASE - 3RC MODELS
J4RLCCS 1988	GEARCASE - 4RC & 4RLC MODELS
J4RLCEC 1989	GEARCASE
J4RLCSS 1980	GEARCASE-STANDARD DRIVE
J4RLCUD 1987	GEARCASE - 3RC MODELS
J4RLCUD 1987	GEARCASE - 4RC & 4RLC MODELS
J4RLEDS 1996	GEARCASE
J4RLEEA 1999	GEARCASE
J4RLEIA 1991	GEARCASE
J4RLENM 1992	GEARCASE
J4RLEOD 1995	GEARCASE
J4RLERE 1994	GEARCASE
J4RLESR 1990	GEARCASE
J4RLETB 1993	GEARCASE
J4RLEUC 1997	GEARCASE
J4RLSIB Rope Start, Tiller, 20 IN. shaft 2001	GEARCASE
J4RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J4RSIB Rope Start, Tiller, 15 IN. shaft 2001	GEARCASE
J4RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J4WCSS 1980	GEARCASE-STANDARD DRIVE
JH-23A 1968	GEARCASE GROUP-STANDARD DRIVE
JH-23M 1968	GEARCASE GROUP-STANDARD DRIVE
JHF-23A 1968	GEARCASE GROUP-STANDARD DRIVE
JHF-23M 1968	GEARCASE GROUP-STANDARD DRIVE
JHFL-23A 1968	GEARCASE GROUP-STANDARD DRIVE
JHFL-23M 1968	GEARCASE GROUP-STANDARD DRIVE
JHL-23A 1968	GEARCASE GROUP-STANDARD DRIVE
JHL-23M 1968	GEARCASE GROUP-STANDARD DRIVE
JW-23A 1968	GEARCASE GROUP-STANDARD DRIVE
JW-23M 1968	GEARCASE GROUP-STANDARD DRIVE
JWF-23A 1968	GEARCASE GROUP-STANDARD DRIVE

JWF-23M 1968	GEARCASE GROUP-STANDARD DRIVE
JWFL-23A 1968	GEARCASE GROUP-STANDARD DRIVE
JWFL-23M 1968	GEARCASE GROUP-STANDARD DRIVE
JWL-23A 1968	GEARCASE GROUP-STANDARD DRIVE
JWL-23M 1968	GEARCASE GROUP-STANDARD DRIVE
SJ3REDS 1996	GEARCASE
SJ4REDS 1996	GEARCASE
SJ4RLEDS 1996	GEARCASE