

Where Used: Part Number 0310584

Model Name	Diagram
262AMLMED 1989	OIL SYSTEM (OMC KING COBRA)
262APRMED 1989	OIL SYSTEM (OMC KING COBRA)
350AMLMED 1989	OIL SYSTEM (OMC KING COBRA)
350APRMED 1989	OIL SYSTEM (OMC KING COBRA)
432AMLMED 1989	OIL SYSTEM (OMC KING COBRA)
432AMLPWS 1990	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
432APLAMH 1992	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
432APLRGD 1991	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
432APRAMH 1992	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
432APRMED 1989	OIL SYSTEM (OMC KING COBRA)
432APRPWS 1990	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
432APRRGD 1991	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
434AMLPWS 1990	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
434APLAMH 1992	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
434APLRGD 1991	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
434APRAMH 1992	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
434APRPWS 1990	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
434APRRGD 1991	OIL SYSTEM (4.3 LITRE H.O. 4V MODELS ONLY)
460AMLMED 1989	OIL SYSTEM
460APRMED 1989	OIL SYSTEM
502AMLGDP 1988	OIL SYSTEM (OMC KING COBRA)
502APRGDP 1988	OIL SYSTEM (OMC KING COBRA)
504AMLGDP 1988	OIL SYSTEM (OMC KING COBRA)
504APRGDP 1988	OIL SYSTEM (OMC KING COBRA)
574AMLGDP 1988	OIL SYSTEM (OMC KING COBRA)
574AMLMED 1989	OIL SYSTEM (OMC KING COBRA)
574APEPWS 1990	OIL SYSTEM - 350 MODELS
574APERGD 1991	OIL SYSTEM - 350 MODELS
574APRGDP 1988	OIL SYSTEM (OMC KING COBRA)
574APRMED 1989	OIL SYSTEM (OMC KING COBRA)
574BMLGDP 1988	OIL SYSTEM (OMC KING COBRA)
574BPEPWS 1990	OIL SYSTEM - 350 MODELS
574BPERGD 1991	OIL SYSTEM - 350 MODELS

574BPRGDP 1988	OIL SYSTEM (OMC KING COBRA)
584DPEAMH 1992	OIL SYSTEM
584DPEAMK 1992	OIL SYSTEM
584DPEJVB 1993	OIL SYSTEM
584DPPJVB 1993	OIL SYSTEM
58FAPEJVB 1993	OIL SYSTEM
58FAPPJVB 1993	OIL SYSTEM
58FBPEJVB 1993	OIL SYSTEM
744APEPWS 1990	OIL SYSTEM
744APERGD 1991	OIL SYSTEM
744APERGF 1991	OIL SYSTEM
744BPERGD 1991	OIL SYSTEM
744CPEAMH 1992	OIL SYSTEM
744CPEJVB 1993	OIL SYSTEM
744DPEAMH 1992	OIL SYSTEM
744DPEJVB 1993	OIL SYSTEM
744DPPAMH 1992	OIL SYSTEM
744DPPJVB 1993	OIL SYSTEM
754APEPWS 1990	OIL SYSTEM
754APFTC 1987	OIL SYSTEM
754APSRC 1987	OIL SYSTEM
754BMLGDP 1988	OIL SYSTEM
754BPFTC 1987	OIL SYSTEM
754BPRGDP 1988	OIL SYSTEM
754BPSRC 1987	OIL SYSTEM
824BPEAMH 1992	OIL SYSTEM
824BPEJVB 1993	OIL SYSTEM
BE40EECR 1998	GEARCASE
BE40EEDS 1996	GEARCASE
BE40EEUC 1997	GEARCASE
BE40ELECR 1998	GEARCASE
BE40ELEDS 1996	GEARCASE
BE40ELEUC 1997	GEARCASE
BE40TLECR 1998	GEARCASE
BE40TLEDS 1996	GEARCASE

BE40TLEUC 1997	GEARCASE
BE50BEEDS 1996	GEARCASE
BE50BELEDS 1996	GEARCASE
BE50DTLEDC 1996	GEARCASE
BE50DTLEDC 1996	JET DRIVE UNIT - J70JL ONLY
BE50DTLEUR 1997	GEARCASE
BE50ESECC 1998	GEARCASE
BE50RLECR 1998	GEARCASE
BE50RLEUC 1997	GEARCASE
BE50TLECR 1998	GEARCASE
BE50TLEDS 1996	GEARCASE
BE50TLEUC 1997	GEARCASE
BE50TSLECC 1998	GEARCASE
BE50TSLEUS 1997	GEARCASE
BE60ELEDR 1996	GEARCASE
BE60ELEDR 1996	JET DRIVE UNIT - J70JL ONLY
BE60ELEUA 1997	GEARCASE
BE60TLEDR 1996	GEARCASE
BE60TLEDR 1996	JET DRIVE UNIT - J70JL ONLY
BE60TLEUA 1997	GEARCASE
BE70ELEDA 1996	GEARCASE
BE70ELEDA 1996	JET DRIVE UNIT - J70JL ONLY
BE70ELEUM 1997	GEARCASE
BE70TLEDA 1996	GEARCASE
BE70TLEDA 1996	JET DRIVE UNIT - J70JL ONLY
BE70TLEUM 1997	GEARCASE
BJ40EECR 1998	GEARCASE
BJ40EEEDS 1996	GEARCASE
BJ40EEEAA 1999	GEARCASE
BJ40EEUC 1997	GEARCASE
BJ40ELECR 1998	GEARCASE
BJ40ELEDS 1996	GEARCASE
BJ40ELEEA 1999	GEARCASE
BJ40ELEUC 1997	GEARCASE
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE

BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40PLEEA 1999	GEARCASE
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40TLECR 1998	GEARCASE
BJ40TLEDS 1996	GEARCASE
BJ40TLEUC 1997	GEARCASE
BJ50BEEDS 1996	GEARCASE
BJ50BELEDS 1996	GEARCASE
BJ50DTLEDC 1996	GEARCASE
BJ50DTLEDC 1996	JET DRIVE UNIT - J70JL ONLY
BJ50DTLEUR 1997	GEARCASE
BJ50EEER 1999	GEARCASE
BJ50ELEER 1999	GEARCASE
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50ESECC 1998	GEARCASE
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ50PLEEA 1999	GEARCASE
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50RLECR 1998	GEARCASE
BJ50RLEEA 1999	GEARCASE
BJ50RLEUC 1997	GEARCASE
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50TLECR 1998	GEARCASE
BJ50TLEDS 1996	GEARCASE
BJ50TLEUC 1997	GEARCASE
BJ50TSLECC 1998	GEARCASE
BJ50TSLEUS 1997	GEARCASE

BJ60ELEDR 1996	GEARCASE
BJ60ELEDR 1996	JET DRIVE UNIT - J70JL ONLY
BJ60ELEUA 1997	GEARCASE
BJ60TLEDR 1996	GEARCASE
BJ60TLEDR 1996	JET DRIVE UNIT - J70JL ONLY
BJ60TLEUA 1997	GEARCASE
BJ70ELEDA 1996	GEARCASE
BJ70ELEDA 1996	JET DRIVE UNIT - J70JL ONLY
BJ70ELEUM 1997	GEARCASE
BJ70TLEDA 1996	GEARCASE
BJ70TLEDA 1996	JET DRIVE UNIT - J70JL ONLY
BJ70TLEUM 1997	GEARCASE
CU-16C 1968	LOWER GEARCASE GROUP
CUE-16C 1968	LOWER GEARCASE GROUP
CUFM-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUFM-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
CUFM-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
CUFM-69B 1969	LOWER GEARCASE GROUP 120,155,210 HP
CUFM-69B 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUFM-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
CUFR-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUFR-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
CUFR-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
CUFR-69B 1969	LOWER GEARCASE GROUP 120,155,210 HP
CUFR-69B 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUFR-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
CUTM-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUTM-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
CUTM-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
CUTM-69B 1969	LOWER GEARCASE GROUP 120,155,210 HP
CUTM-69B 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUTM-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
CUTR-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUTR-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
CUTR-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP

CUTR-69B 1969	LOWER GEARCASE GROUP 120,155,210 HP
CUTR-69B 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
CUTR-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
E40EEOD 1995	GEARCASE
E40EEOD 1995	JET DRIVE UNIT
E40ELECR 1998	GEARCASE
E40ELEDS 1996	GEARCASE
E40ELEOD 1995	GEARCASE
E40ELEOD 1995	JET DRIVE UNIT
E40ELEUC 1997	GEARCASE
E40JRECA 1998	JET DRIVE UNIT
E40JREDC 1996	JET DRIVE UNIT
E40JREOS 1995	JET DRIVE UNIT
E40JREUR 1997	JET DRIVE UNIT
E40RECR 1998	GEARCASE
E40REDS 1996	GEARCASE
E40REOD 1995	GEARCASE
E40REOD 1995	JET DRIVE UNIT
E40REUC 1997	GEARCASE
E40RLECR 1998	GEARCASE
E40RLEDS 1996	GEARCASE
E40RLEOD 1995	GEARCASE
E40RLEOD 1995	JET DRIVE UNIT
E40RLEUC 1997	GEARCASE
E40TEECR 1998	GEARCASE
E40TEEDS 1996	GEARCASE
E40TEEOD 1995	GEARCASE
E40TEEOD 1995	JET DRIVE UNIT
E40TEEUC 1997	GEARCASE
E40TELECR 1998	GEARCASE
E40TELEDS 1996	GEARCASE
E40TELEOD 1995	GEARCASE
E40TELEOD 1995	JET DRIVE UNIT
E40TELEUC 1997	GEARCASE
E40TLECR 1998	GEARCASE

E40TLEDS 1996	GEARCASE
E40TLEOD 1995	GEARCASE
E40TLEOD 1995	JET DRIVE UNIT
E40TLEUC 1997	GEARCASE
E40TLECR 1998	GEARCASE
E40TTLEDS 1996	GEARCASE
E40TTLEOD 1995	GEARCASE
E40TTLEOD 1995	JET DRIVE UNIT
E40TTLEUC 1997	GEARCASE
E45RCEOD 1995	GEARCASE
E45RCLEDS 1996	GEARCASE
E45RCLEOD 1995	GEARCASE
E45RCLEUC 1997	GEARCASE
E48ESLEDC 1996	GEARCASE
E48ESLEOS 1995	GEARCASE
E50BEEOD 1995	GEARCASE
E50BEEOD 1995	JET DRIVE UNIT
E50BELEOD 1995	GEARCASE
E50BELEOD 1995	JET DRIVE UNIT
E50DTLEDC 1996	GEARCASE
E50DTLEDC 1996	JET DRIVE UNIT - J70JL ONLY
E50DTLEOS 1995	GEARCASE
E50DTLEOS 1995	JET DRIVE UNIT - J70JL ONLY
E50DTLEUR 1997	GEARCASE
E50ELED 1996	GEARCASE
E50ELED 1996	JET DRIVE UNIT - J70JL ONLY
E50ELEOS 1995	GEARCASE
E50ELEOS 1995	JET DRIVE UNIT - J70JL ONLY
E50ELEUR 1997	GEARCASE
E50ESLECC 1998	GEARCASE
E50ESLEUR 1997	GEARCASE
E50JEDS 1996	GEARCASE
E50JEOD 1995	GEARCASE
E50JEOD 1995	JET DRIVE UNIT
E50JEUC 1997	GEARCASE

E50TELEOD 1995	GEARCASE
E50TELEOD 1995	JET DRIVE UNIT
E50TLECR 1998	GEARCASE
E50TLEDS 1996	GEARCASE
E50TLEOD 1995	GEARCASE
E50TLEOD 1995	JET DRIVE UNIT
E50TLEUC 1997	GEARCASE
E50TSLECC 1998	GEARCASE
E50TSLEUS 1997	GEARCASE
E50TTLEDC 1996	GEARCASE
E50TTLEOS 1995	GEARCASE
E50TTLEUR 1997	GEARCASE
E55RSLC 1997	GEARCASE
E55RSLG 1995	GEARCASE
E55RSLW 1996	GEARCASE
E60ELEDR 1996	GEARCASE
E60ELEDR 1996	JET DRIVE UNIT - J70JL ONLY
E60ELEOC 1995	GEARCASE
E60ELEOC 1995	JET DRIVE UNIT - J70JL ONLY
E60ELEUA 1997	GEARCASE
E60TLEDR 1996	GEARCASE
E60TLEDR 1996	JET DRIVE UNIT - J70JL ONLY
E60TLEOC 1995	GEARCASE
E60TLEOC 1995	JET DRIVE UNIT - J70JL ONLY
E60TLEUA 1997	GEARCASE
E60TTLEDR 1996	GEARCASE
E60TTLEOC 1995	GEARCASE
E60TTLEUA 1997	GEARCASE
E65RSLC 1995	GEARCASE
E65RSLM 1996	GEARCASE
E65RSLZ2 1997	GEARCASE
E65WMLEOC 1995	GEARCASE
E70ELEOR 1995	GEARCASE
E70ELEOR 1995	JET DRIVE UNIT - J70JL ONLY
E70TLEDA 1996	GEARCASE

E70TLEDA 1996	JET DRIVE UNIT - J70JL ONLY
E70TLEOR 1995	GEARCASE
E70TLEOR 1995	JET DRIVE UNIT - J70JL ONLY
E70TLEUM 1997	GEARCASE
E70TTLEOR 1995	GEARCASE
GUFM-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
GUFM-10S 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
GUFP-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
HE40REDS 1996	GEARCASE
HE40REUC 1997	GEARCASE
HE40RLEDS 1996	GEARCASE
HE40RLEUC 1997	GEARCASE
HE45RCLEDS 1996	GEARCASE
HE45RCLEUC 1997	GEARCASE
HE55RSLC 1997	GEARCASE
HE55RSLW 1996	GEARCASE
HE55WMLM 1996	GEARCASE
HE55WMLZ 1997	GEARCASE
HE70TXEDA 1996	GEARCASE
HE70TXEDA 1996	JET DRIVE UNIT - J70JL ONLY
HE70TXEUM 1997	GEARCASE
HJ40REDS 1996	GEARCASE
HJ40REUC 1997	GEARCASE
HJ40RLEDS 1996	GEARCASE
HJ40RLEUC 1997	GEARCASE
HJ45RCLEDS 1996	GEARCASE
HJ45RCLEUC 1997	GEARCASE
HJ55RSLC 1997	GEARCASE
HJ55RSLW 1996	GEARCASE
HJ55WMLM 1996	GEARCASE
HJ55WMLZ 1997	GEARCASE
HJ70TXEDA 1996	GEARCASE
HJ70TXEDA 1996	JET DRIVE UNIT - J70JL ONLY
HJ70TXEUM 1997	GEARCASE

HU-16C 1968	LOWER GEARCASE GROUP
HUE-16C 1968	LOWER GEARCASE GROUP
HUFM-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
HUFM-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUFM-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUFM-21C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
HUFM-21S 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
HUFM-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
HUFM-69M 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
HUFP-21C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
HUFR-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
HUFR-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUFR-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUFR-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
HUFR-69M 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
HUTM-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
HUTM-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUTM-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUTM-21C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
HUTM-21S 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
HUTM-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
HUTM-69M 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
HUTP-21C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
HUTR-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
HUTR-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUTR-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
HUTR-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
HUTR-69M 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	JET DRIVE UNIT
J30JREEM 1999	JET DRIVE UNIT
J30JRSIE jet drive, rope start, 15 in shaft 2001	STEERING HANDLE
J30JRSIE jet drive, rope start, 15 in shaft 2001	JET DRIVE UNIT

J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	JET DRIVE UNIT
J40EEOD 1995	GEARCASE
J40EEOD 1995	JET DRIVE UNIT
J40ELECR 1998	GEARCASE
J40ELEDS 1996	GEARCASE
J40ELEOD 1995	GEARCASE
J40ELEOD 1995	JET DRIVE UNIT
J40ELEUC 1997	GEARCASE
J40JRECA 1998	JET DRIVE UNIT
J40JREDC 1996	JET DRIVE UNIT
J40JREOS 1995	JET DRIVE UNIT
J40JREUR 1997	JET DRIVE UNIT
J40PLEEA 1999	GEARCASE
J40PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J40PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J40PLSOC	GEARCASE
J40PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSRS	GEARCASE
J40PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J40PLSTD	GEARCASE
J40PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RECR 1998	GEARCASE
J40REDS 1996	GEARCASE
J40REEA 1999	GEARCASE
J40REOD 1995	GEARCASE
J40REOD 1995	JET DRIVE UNIT
J40REUC 1997	GEARCASE
J40RLECR 1998	GEARCASE
J40RLEDS 1996	GEARCASE
J40RLEEA 1999	GEARCASE
J40RLEOD 1995	GEARCASE
J40RLEOD 1995	JET DRIVE UNIT

J40RLEUC 1997	GEARCASE
J40RLSIF rope start, 20 in shaft 2001	GEARCASE
J40RLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RLSOC	GEARCASE
J40RLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSRS	GEARCASE
J40RLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40RLSTD	GEARCASE
J40RLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSIF rope start, 15 in shaft 2001	GEARCASE
J40RSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RSOC	GEARCASE
J40RSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSRS	GEARCASE
J40RSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40RSTD	GEARCASE
J40RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40TEECR 1998	GEARCASE
J40TEEDS 1996	GEARCASE
J40TEEOD 1995	GEARCASE
J40TEEOD 1995	JET DRIVE UNIT
J40TEEUC 1997	GEARCASE
J40TELECR 1998	GEARCASE
J40TELEDS 1996	GEARCASE
J40TELEOD 1995	GEARCASE
J40TELEOD 1995	JET DRIVE UNIT
J40TELEUC 1997	GEARCASE
J40TLECR 1998	GEARCASE
J40TLEDS 1996	GEARCASE
J40TLEOD 1995	GEARCASE

J40TLEOD 1995	JET DRIVE UNIT
J40TLEUC 1997	GEARCASE
J40TPLEEA 1999	GEARCASE
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	GEARCASE
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J40TTLECR 1998	GEARCASE
J40TTLEDS 1996	GEARCASE
J40TTLEOD 1995	GEARCASE
J40TTLEOD 1995	JET DRIVE UNIT
J40TTLEUC 1997	GEARCASE
J45RCEOD 1995	GEARCASE
J45RCLEDS 1996	GEARCASE
J45RCLEOD 1995	GEARCASE
J45RCLEUC 1997	GEARCASE
J48ESLEDC 1996	GEARCASE
J48ESLEOS 1995	GEARCASE
J50BEEOD 1995	GEARCASE
J50BEEOD 1995	JET DRIVE UNIT
J50BELEOD 1995	GEARCASE
J50BELEOD 1995	JET DRIVE UNIT
J50DTLEDC 1996	GEARCASE
J50DTLEDC 1996	JET DRIVE UNIT - J70JL ONLY
J50DTLEOS 1995	GEARCASE
J50DTLEOS 1995	JET DRIVE UNIT - J70JL ONLY
J50DTLEUR 1997	GEARCASE
J50ELED 1996	GEARCASE
J50ELED 1996	JET DRIVE UNIT - J70JL ONLY
J50ELEER 1999	GEARCASE
J50ELEOS 1995	GEARCASE
J50ELEOS 1995	JET DRIVE UNIT - J70JL ONLY
J50ELEUR 1997	GEARCASE
J50ELSIF elec start, 20 in shaft 2001	GEARCASE
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	GEARCASE
J50ESLECC 1998	GEARCASE
J50ESLEUR 1997	GEARCASE

J50JEDS 1996	GEARCASE
J50JEOD 1995	GEARCASE
J50JEOD 1995	JET DRIVE UNIT
J50JEUC 1997	GEARCASE
J50PLEEA 1999	GEARCASE
J50PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J50PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J50PLSOC	GEARCASE
J50PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLRS	GEARCASE
J50PLRS - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J50PLSTD	GEARCASE
J50PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J50TELEOD 1995	GEARCASE
J50TELEOD 1995	JET DRIVE UNIT
J50TLECR 1998	GEARCASE
J50TLEDS 1996	GEARCASE
J50TLEOD 1995	GEARCASE
J50TLEOD 1995	JET DRIVE UNIT
J50TLEUC 1997	GEARCASE
J50TSLECC 1998	GEARCASE
J50TSLEUS 1997	GEARCASE
J50TTLEDC 1996	GEARCASE
J50TTLEOS 1995	GEARCASE
J50TTLEUR 1997	GEARCASE
J55RSLC 1997	GEARCASE
J55RSLG 1995	GEARCASE
J55RSLW 1996	GEARCASE
J60ELEDR 1996	GEARCASE
J60ELEDR 1996	JET DRIVE UNIT - J70JL ONLY
J60ELEOC 1995	GEARCASE
J60ELEOC 1995	JET DRIVE UNIT - J70JL ONLY

J60ELEUA 1997	GEARCASE
J60TLEDR 1996	GEARCASE
J60TLEDR 1996	JET DRIVE UNIT - J70JL ONLY
J60TLEOC 1995	GEARCASE
J60TLEOC 1995	JET DRIVE UNIT - J70JL ONLY
J60TLEUA 1997	GEARCASE
J60TTLEDR 1996	GEARCASE
J60TTLEOC 1995	GEARCASE
J60TTLEUA 1997	GEARCASE
J65RSLC 1995	GEARCASE
J65RSLM 1996	GEARCASE
J65RSLZ2 1997	GEARCASE
J65WMLEOC 1995	GEARCASE
J70ELEOR 1995	GEARCASE
J70ELEOR 1995	JET DRIVE UNIT - J70JL ONLY
J70JLEOS 1995	GEARCASE
J70JLEOS 1995	JET DRIVE UNIT - J70JL ONLY
J70TLEDA 1996	GEARCASE
J70TLEDA 1996	JET DRIVE UNIT - J70JL ONLY
J70TLEOR 1995	GEARCASE
J70TLEOR 1995	JET DRIVE UNIT - J70JL ONLY
J70TLEUM 1997	GEARCASE
J70TTLEOR 1995	GEARCASE
JUFM-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
JUFM-10S 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
JX-245 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
KU-16C 1968	LOWER GEARCASE GROUP
KUE-16C 1968	LOWER GEARCASE GROUP
LUFM-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
LUFM-10S 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
LUFP-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
NU-10S 1969	LOWER GEARCASE GROUP 120,155,210 HP

NUE-10S 1969	LOWER GEARCASE GROUP 120,155,210 HP
NUFM-12A 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
NUFM-12AX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
NUFM-13M 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
NUFM-69R 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
NUFR-12A 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
NUFR-12AX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
NUFR-13M 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
NUFR-69R 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
RJ50ELSIF elec start, TNT, 20 in shaft 2001	GEARCASE
SD ACCESSORIES 1990	REMOTE OIL FILTER KIT - 5.7 MODELS
SD ACCESSORIES 1991	REMOTE OIL FILTER KIT 4.3 & 5.7 MODELS
SD ACCESSORIES 1991	TRIM LIMIT KIT
SD ACCESSORIES 1992	REMOTE OIL FILTER KIT 4.3 & 5.7 MODELS
SD ACCESSORIES 1992	TRIM LIMIT KIT
SD ACCESSORIES 1993	REMOTE OIL FILTER KIT 4.3 MODELS
SD ACCESSORIES 1993	REMOTE OIL FILTER KIT 5.0 & 5.8 MODELS
SD ACCESSORIES 1993	TRIM LIMIT KIT
SD ACCESSORIES 1994	TRIM LIMIT KIT
SD ACCESSORIES 1995	TRIM LIMIT KIT
SD ACCESSORIES 1996	TRIM LIMIT KIT
SD ACCESSORIES 1997	TRIM LIMIT KIT
SD ACCESSORIES 1998	TRIM LIMIT KIT
SE40RPB 1997	GEARCASE
SE40RPH 1996	GEARCASE
SE40RPLB 1997	GEARCASE
SE40RPLH 1996	GEARCASE
SE40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPYB 1997	GEARCASE
SE40RPYH 1996	GEARCASE
SE40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RSLD 1997	GEARCASE
SE40RSLR 1998	GEARCASE
SE40RSLZ 1996	GEARCASE

SE45RSLB 1997	GEARCASE
SE45RSLH 1996	GEARCASE
SE50TLEDS 1996	GEARCASE
SE55RSC 1997	GEARCASE
SE55RSLC 1997	GEARCASE
SE55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSLW 1996	GEARCASE
SE55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSW 1996	GEARCASE
SE55RSYC 1997	GEARCASE
SE55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSYW 1996	GEARCASE
SE65RSLM 1996	GEARCASE
SE65RSLZ2 1997	GEARCASE
SE65RSYM 1996	GEARCASE
SE65RSYZZ 1997	GEARCASE
SE65WMLM 1996	GEARCASE
SE65WMLZ2 1997	GEARCASE
SE65WMYM 1996	GEARCASE
SE65WMYZ2 1997	GEARCASE
SJ40EEDS 1996	GEARCASE
SJ40REDS 1996	GEARCASE
SJ40RLEDS 1996	GEARCASE
SJ40RPB 1997	GEARCASE
SJ40RPH 1996	GEARCASE
SJ40RPLB 1997	GEARCASE
SJ40RPLH 1996	GEARCASE
SJ40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPYB 1997	GEARCASE
SJ40RPYH 1996	GEARCASE
SJ40RPTY2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RSLD 1997	GEARCASE
SJ40RSLR 1998	GEARCASE
SJ40RSLZ 1996	GEARCASE

SJ45RSLB 1997	GEARCASE
SJ45RSLH 1996	GEARCASE
SJ55RSC 1997	GEARCASE
SJ55RSLC 1997	GEARCASE
SJ55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSLW 1996	GEARCASE
SJ55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSW 1996	GEARCASE
SJ55RSYC 1997	GEARCASE
SJ55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSYW 1996	GEARCASE
SJ60TLEDR 1996	GEARCASE
SJ60TLEDR 1996	JET DRIVE UNIT - J70JL ONLY
SJ65RSLM 1996	GEARCASE
SJ65RSLZ2 1997	GEARCASE
SJ65RSYM 1996	GEARCASE
SJ65RSYZZ 1997	GEARCASE
SJ65WMLM 1996	GEARCASE
SJ65WMLZ2 1997	GEARCASE
SJ65WMYM 1996	GEARCASE
SJ65WMYZ2 1997	GEARCASE
SJ70TLEDA 1996	GEARCASE
SJ70TLEDA 1996	JET DRIVE UNIT - J70JL ONLY
TU-16C 1968	LOWER GEARCASE GROUP
TU-17R 1968	LOWER GEARCASE GROUP
TUE-16C 1968	LOWER GEARCASE GROUP
TUE-17R 1968	LOWER GEARCASE GROUP
TUFM-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
TUFM-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
TUFM-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
TUFM-21C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
TUFM-21S 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
TUFM-69B 1969	LOWER GEARCASE GROUP 120,155,210 HP
TUFM-69B 1970	LOWER GEARCASE GROUP 120, 155, 210 HP

TUFM-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
TUFP-21C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
TUFR-19E 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
TUFR-19EX 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
TUFR-20D 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
TUFR-69B 1969	LOWER GEARCASE GROUP 120,155,210 HP
TUFR-69B 1970	LOWER GEARCASE GROUP 120, 155, 210 HP
TUFR-69M 1969	LOWER GEARCASE GROUP 120,155,210 HP
VUFM-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
VUFM-10S 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
VUFP-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
WUFM-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
WUPM-10C 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
X50ESLECC 1998	GEARCASE
XUFM-20C 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
XUFM-20S 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
XUFM-21A 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
XUFM-21R 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
XUFP-21A 1972	LOWER GEARCASE GROUP 100,120,155,165,225&245 HP STERN DRIVE
XUFR-20C 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP
XUFR-20S 1971	LOWER GEARCASE GROUP 120,155,215 & 235 HP