

Where Used: Part Number 0310729

Model Name	Diagram
100193A 1971	REMOTE CONTROL
100193C 1971	REMOTE CONTROL
100293R 1972	REMOTE CONTROL
100882B 1968	PUSH-BUTTON REMOTE CONTROL GROUP
100883B 1968	PUSH-BUTTON REMOTE CONTROL GROUP
100ESL71A 1971	REMOTE CONTROL
100ESL71C 1971	REMOTE CONTROL
100ESL72R 1972	REMOTE CONTROL
115083D 1970	PUSH-BUTTON REMOTE CONTROL GROUP
115393M 1973	REMOTE CONTROL
115493B 1974	REMOTE CONTROL
115593 1975	REMOTE CONTROL
115693D 1976	REMOTE CONTROL
115693G 1976	REMOTE CONTROL
115699D 1976	REMOTE CONTROL
115699G 1976	REMOTE CONTROL
115790S 1977	REMOTE CONTROL
115793S 1977	REMOTE CONTROL
115799S 1977	REMOTE CONTROL
115890C 1978	REMOTE CONTROL
115893C 1978	REMOTE CONTROL
115899C 1978	REMOTE CONTROL
115983E 1969	PUSH-BUTTON REMOTE CONTROL GROUP
115983S 1969	PUSH-BUTTON REMOTE CONTROL GROUP
115EL77S 1977	REMOTE CONTROL
115ESL69E 1969	REMOTE CONTROL GROUP ELECTRIC SHIFT
115ESL69S 1969	REMOTE CONTROL GROUP ELECTRIC SHIFT
115ESL70D 1970	REMOTE CONTROL GROUP ELECTRIC SHIFT
115ESL73M 1973	REMOTE CONTROL
115ESL74B 1974	REMOTE CONTROL
115ESL75E 1975	REMOTE CONTROL
115ETL74B 1974	REMOTE CONTROL
115ETL75E 1975	REMOTE CONTROL

115ETL77 1977	REMOTE CONTROL
115ETZ78C 1978	REMOTE CONTROL
115ML78C 1978	REMOTE CONTROL
115TXL77S 1977	REMOTE CONTROL
115TXL78C 1978	REMOTE CONTROL
125183C 1971	REMOTE CONTROL
125283R 1972	REMOTE CONTROL
125ESL71C 1971	REMOTE CONTROL
125ESL72R 1972	REMOTE CONTROL
135383M 1973	REMOTE CONTROL
135443B 1974	REMOTE CONTROL
135483B 1974	REMOTE CONTROL
135489B 1974	REMOTE CONTROL
135543E 1975	REMOTE CONTROL
135583E 1975	REMOTE CONTROL
135589E 1975	REMOTE CONTROL
135643D 1976	REMOTE CONTROL
135643G 1976	REMOTE CONTROL
135683D 1976	REMOTE CONTROL
135683G 1976	REMOTE CONTROL
135ESL73M 1973	REMOTE CONTROL
135ESL74B 1974	REMOTE CONTROL
135ESL75E 1975	REMOTE CONTROL
135ETL74B 1974	REMOTE CONTROL
135ETL75E 1975	REMOTE CONTROL
140740S 1977	REMOTE CONTROL
140743S 1977	REMOTE CONTROL
140783S 1977	REMOTE CONTROL
140840C 1978	REMOTE CONTROL
140843C 1978	REMOTE CONTROL
140883C 1978	REMOTE CONTROL
140ML77S 1977	REMOTE CONTROL
140ML78C 1978	REMOTE CONTROL
140TL77S 1977	REMOTE CONTROL
140TL78C 1978	REMOTE CONTROL

140TX78C 1978	REMOTE CONTROL
140TXL77S 1977	REMOTE CONTROL
40072A 1970	PUSH-BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40073A 1970	PUSH-BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40872A 1968	PUSH-BOTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40872C 1968	PUSH-BOTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40872D 1968	PUSH-BOTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40873A 1968	PUSH-BOTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40873C 1968	PUSH-BOTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40873D 1968	PUSH-BOTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40972R 1969	PUSH-BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
40973R 1969	PUSH-BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
50172S 1971	REMOTE CONTROL
50173S 1971	REMOTE CONTROL
50202C 1972	REMOTE CONTROL
50203C 1972	REMOTE CONTROL
50272C 1972	REMOTE CONTROL
50273C 1972	REMOTE CONTROL
50302R 1973	REMOTE CONTROL
50303R 1973	REMOTE CONTROL
50372R 1973	REMOTE CONTROL
50373R 1973	REMOTE CONTROL
50442M 1974	REMOTE CONTROL
50443M 1974	REMOTE CONTROL
50472M 1974	REMOTE CONTROL
50473M 1974	REMOTE CONTROL
50542B 1975	REMOTE CONTROL
50543B 1975	REMOTE CONTROL
50572B 1975	REMOTE CONTROL
50573B 1975	REMOTE CONTROL
50ES71S 1971	REMOTE CONTROL
50ES72C 1972	REMOTE CONTROL
50ES73R 1973	REMOTE CONTROL
50ES74M 1974	REMOTE CONTROL
50ES75B 1975	REMOTE CONTROL

50ESL71S 1971	REMOTE CONTROL
50ESL72C 1972	REMOTE CONTROL
50ESL73R 1973	REMOTE CONTROL
50ESL74M 1974	REMOTE CONTROL
50ESL75B 1975	REMOTE CONTROL
50R72C 1972	REMOTE CONTROL
50R73R 1973	REMOTE CONTROL
50RL72C 1972	REMOTE CONTROL
50RL73R 1973	REMOTE CONTROL
55642E 1976	REMOTE CONTROL
55643E 1976	REMOTE CONTROL
55672E 1976	REMOTE CONTROL
55673E 1976	REMOTE CONTROL
55772D 1977	REMOTE CONTROL
55773D 1977	REMOTE CONTROL
55872A 1968	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55872R 1968	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55872S 1968	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55873A 1968	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55873R 1968	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55873S 1968	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55874S 1978	REMOTE CONTROL
55875S 1978	REMOTE CONTROL
55972A 1969	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55972C 1969	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55973A 1969	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55973C 1969	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
55E76E 1976	REMOTE CONTROL
55E77D 1977	REMOTE CONTROL
55E78S 1978	REMOTE CONTROL
55EL76E 1976	REMOTE CONTROL
55EL77D 1977	REMOTE CONTROL
55EL78S 1978	REMOTE CONTROL
55ES69A 1969	REMOTE CONTROL GROUP
55ES69C 1969	REMOTE CONTROL GROUP

55ESL69A 1969	REMOTE CONTROL GROUP
55ESL69C 1969	REMOTE CONTROL GROUP
60072B 1970	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
60072D 1970	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
60073B 1970	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
60073D 1970	PUSH BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
60172C 1971	REMOTE CONTROL
60172E 1971	REMOTE CONTROL
60173C 1971	REMOTE CONTROL
60173E 1971	REMOTE CONTROL
60ES70B 1970	REMOTE CONTROL GROUP
60ES70D 1970	REMOTE CONTROL GROUP
60ES71C 1971	REMOTE CONTROL
60ES71E 1971	REMOTE CONTROL
60ESL70B 1970	REMOTE CONTROL GROUP
60ESL70D 1970	REMOTE CONTROL GROUP
60ESL71C 1971	REMOTE CONTROL
60ESL71E 1971	REMOTE CONTROL
65272S 1972	REMOTE CONTROL
65273S 1972	REMOTE CONTROL
65372R 1973	REMOTE CONTROL
65373R 1973	REMOTE CONTROL
65ES72S 1972	REMOTE CONTROL
65ES73R 1973	REMOTE CONTROL
65ESL72S 1972	REMOTE CONTROL
65ESL73R 1973	REMOTE CONTROL
70442M 1974	REMOTE CONTROL
70443M 1974	REMOTE CONTROL
70472M 1974	REMOTE CONTROL
70473M 1974	REMOTE CONTROL
70572B 1975	REMOTE CONTROL
70572E 1975	REMOTE CONTROL
70573B 1975	REMOTE CONTROL
70573E 1975	REMOTE CONTROL
70673D 1976	REMOTE CONTROL

70773S 1977	REMOTE CONTROL
70873C 1978	REMOTE CONTROL
70EL76D 1976	REMOTE CONTROL
70EL77S 1977	REMOTE CONTROL
70EL78C 1978	REMOTE CONTROL
70ES74M 1974	REMOTE CONTROL
70ES75B 1975	REMOTE CONTROL
70ES75E 1975	REMOTE CONTROL
70ESL74M 1974	REMOTE CONTROL
70ESL75B 1975	REMOTE CONTROL
70ESL75E 1975	REMOTE CONTROL
70ESLR74M 1974	REMOTE CONTROL
75542B 1975	REMOTE CONTROL
75543B 1975	REMOTE CONTROL
75642D 1976	REMOTE CONTROL
75643D 1976	REMOTE CONTROL
75742S 1977	REMOTE CONTROL
75743S 1977	REMOTE CONTROL
75842C 1978	REMOTE CONTROL
75843C 1978	REMOTE CONTROL
75ELR76D 1976	REMOTE CONTROL
75ELR77S 1977	REMOTE CONTROL
75ELR78C 1978	REMOTE CONTROL
75ER76D 1976	REMOTE CONTROL
75ER77S 1977	REMOTE CONTROL
75ER78C 1978	REMOTE CONTROL
75ESLR75B 1975	REMOTE CONTROL
75ESR75B 1975	REMOTE CONTROL
85093B 1970	PUSH-BUTTON REMOTE CONTROL GROUP
85093D 1970	PUSH-BUTTON REMOTE CONTROL GROUP
85193A 1971	REMOTE CONTROL
85193H 1971	REMOTE CONTROL
85293R 1972	REMOTE CONTROL
85393M 1973	REMOTE CONTROL
85493B 1974	REMOTE CONTROL

85593E 1975	REMOTE CONTROL
85693D 1976	REMOTE CONTROL
85693G 1976	REMOTE CONTROL
85699G 1976	REMOTE CONTROL
85790S 1977	REMOTE CONTROL
85793S 1977	REMOTE CONTROL
85799S 1977	REMOTE CONTROL
85890C 1978	REMOTE CONTROL
85892A 1968	PUSH-BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
85893A 1968	PUSH-BUTTON REMOTE CONTROL GROUP ELECTRIC SHIFT
85895C 1978	REMOTE CONTROL
85899C 1978	REMOTE CONTROL
85993E 1969	PUSH-BUTTON REMOTE CONTROL GROUP
85993M 1969	PUSH-BUTTON REMOTE CONTROL GROUP
85993S 1969	PUSH-BUTTON REMOTE CONTROL GROUP
85EL77S 1977	REMOTE CONTROL
85ESL69E 1969	REMOTE CONTROL GROUP ELECTRIC SHIFT
85ESL69M 1969	REMOTE CONTROL GROUP ELECTRIC SHIFT
85ESL69S 1969	REMOTE CONTROL GROUP ELECTRIC SHIFT
85ESL70B 1970	REMOTE CONTROL GROUP ELECTRIC SHIFT
85ESL70D 1970	REMOTE CONTROL GROUP ELECTRIC SHIFT
85ESL71A 1971	REMOTE CONTROL
85ESL71H 1971	REMOTE CONTROL
85ESL72R 1972	REMOTE CONTROL
85ESL73M 1973	REMOTE CONTROL
85ESL74B 1974	REMOTE CONTROL
85ESL75E 1975	REMOTE CONTROL
85ETLR77S 1977	REMOTE CONTROL
85ETLR78C 1978	REMOTE CONTROL
85ML78C 1978	REMOTE CONTROL
85TXLR77S 1977	REMOTE CONTROL
85TXLR78C 1978	REMOTE CONTROL
REMOTE CONTROL 1972	BINNACLE MOUNT CONTROL
REMOTE CONTROL 1974	BINNACLE MOUNT CONTROL & WIRING KIT 50 THRU 135 HP
REMOTE CONTROL 1975	BINNACLE MOUNT CTRL & WIRING KIT 50 HP THRU 135 HP

REMOTE CONTROL 1975	REMOTE CONTROL SINGLE MOTOR
REMOTE CONTROL 1975	SINGLE LEVER REMOTE CONTROL
REMOTE CONTROL 1976	BINNACLE MOUNT CONTROL AND WIRING KIT 55 THRU 200 HP
REMOTE CONTROL 1976	REMOTE CONTROL SINGLE MOTOR
REMOTE CONTROL 1976	REMOTE CONTROL TWIN MOTOR
REMOTE CONTROL 1976	SINGLE LEVER REMOTE CONTROL
REMOTE CONTROL 1977	BINNACLE MOUNT CONTROL AND WIRING KIT 55 - 200
REMOTE CONTROL 1977	REMOTE CONTROL SINGLE MOTOR
REMOTE CONTROL 1977	REMOTE CONTROL TWIN MOTOR
REMOTE CONTROL 1977	SINGLE LEVER REMOTE CONTROL
REMOTE CONTROL 1978	BINNACLE MOUNT CONTROL AND WIRING KIT55 - 235 HP
REMOTE CONTROL 1978	CABLE MOUNT HARDWARE KIT
REMOTE CONTROL 1978	REMOTE CONTROL SINGLE MOTOR
REMOTE CONTROL 1978	REMOTE CONTROL TWIN MOTOR
REMOTE CONTROL 1978	REMOTE CTRL ASSY BINNACLE MOUNT DUAL LEVER 6-235 HP
REMOTE CONTROL 1978	REMOTE CTRL ASSY SINGLE LEVER 6 - 235 HP
REMOTE CONTROL 1978	REMOTE CTRL ASSY-BINNACLE MOUNT 6 - 235 HP
REMOTE CONTROL 1978	REMOTE CTRL ASSY-CONCEALED SIDE MOUNT 6 - 235 HP
REMOTE CONTROL 1978	SINGLE LEVER REMOTE CONTROL
REMOTE CONTROL 1979	CABLE MOUNT HARDWARE KIT SINGLE LEVER REMOTE CONTROL
REMOTE CONTROL 1979	RETRO-FIT KIT - 2 & 4 LEVER
REMOTE CONTROL 1980	CBL MNT HARDWARE KIT SNGL LEVER REMOTE CNTRL LG LIFE CABLES
REMOTE CONTROL 1980	RETRO-FIT KIT-2 & 4 LEVER FOR LONG LIFE CABLES
REMOTE CONTROL 1981	RETRO-FIT KIT-2 & 4 LEVER
REMOTE CONTROL 1982	CABLEMOUNT HRDWR KIT SINGLE LVR RMT CTRL.-LONG LIFE CABLES
REMOTE CONTROL 1982	RETRO-FIT KIT-2 & 4 LEVER FOR LONG LIFE CABLES
REMOTE CONTROL 1983	CABLE MOUNT HARDWARE KIT SINGLE LEVER REMOTE -
REMOTE CONTROL 1983	RETRO-FIT KIT - 2 & 4 LEVER FOR LONG LIFE CABLES
REMOTE CONTROL 1995	CABLE ADAPTER KIT-SINGLE LEVER REMOTE CNTRL-LONG LIFE CABLES
REMOTE CONTROL 1995	CABLE ADAPTER KIT - 2 & 4 LEVER - LONG LIFE CABLES
REMOTE CONTROL 1996	CABLE ADAPTER KIT 2 & 4 LEVER FOR LONG LIFE CABLES
REMOTE CONTROL 1996	CABLE ADAPTER KIT SINGLE LEVER REMOTE CTRL-LONG LIFE CABLES
REMOTE CONTROLS 1984	CABLE MOUNT SINGLE LEVER REM. CONT. FOR LONG LIFE CABLES
REMOTE CONTROLS 1984	RETRO-FIT KIT - 2 & 4 LEVER FOR LONG LIFE CABLES
REMOTE CONTROLS 1985	CABLE MOUNT SINGLE LEVER REM. CONT. FOR LONG LIFE CABLES

REMOTE CONTROLS 1985	RETRO-FIT KIT - 2 & 4 LEVER FOR LONG LIFE CABLES
REMOTE CONTROLS 1986	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1986	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1987	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1987	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1988	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1988	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1989	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1989	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1990	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1990	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1991	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1991	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1992	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1992	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1993	CABLE ADAPT. KIT - SINGLE LEVER RMT CONT.- LONG LIFE CABLES
REMOTE CONTROLS 1993	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1994	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
REMOTE CONTROLS 1994	CABLE ADAPTER KIT - SINGLE LEVER REMOTE CONTROL - FOR LONG L
REMOTE CONTROLS 1997	CABLE ADAPTER KIT-2 & 4 LEVER-FOR LONG LIFE CABLES
REMOTE CONTROLS 1997	CABLE ADAPTER KIT-SINGLE LEVER REMOTE CNTRL-LONG LIFE CABLES
REMOTE CONTROLS 1998	CABLE ADAPTER KIT-2 & 4 LEVER-FOR LONG LIFE CABLES
REMOTE CONTROLS 1999	CABLE ADAPTER KIT -- 2 & 4 LEVER -- FOR LONG LIFE CABLES
REMOTE CONTROLS 2000	CABLE ADAPTER KIT - 2 & 4 LEVER - FOR LONG LIFE CABLES
V4T-14B 1968	REMOTE CONTROL GROUP ELECTRIC SHIFT
V4TL-14B 1968	REMOTE CONTROL GROUP ELECTRIC SHIFT