

Where Used: Part Number 0313697

Model Name	Diagram
100193A 1971	GEARCASE
100193C 1971	GEARCASE
100293R 1972	GEARCASE
100990S 1979	GEARCASE
100993S 1979	GEARCASE
100999S 1979	GEARCASE
100ESL71A 1971	GEARCASE
100ESL71C 1971	GEARCASE
100ESL72R 1972	GEARCASE
100ML79S 1979	GEARCASE
100TLR79S 1979	GEARCASE
100TXLR79S 1979	GEARCASE
115083D 1970	GEARCASE GROUP
115393M 1973	GEARCASE
115493B 1974	GEARCASE GROUP
115593 1975	GEARCASE
115693D 1976	GEARCASE
115693G 1976	GEARCASE
115699D 1976	GEARCASE
115699G 1976	GEARCASE
115790S 1977	GEARCASE
115793S 1977	GEARCASE
115799S 1977	GEARCASE
115890C 1978	GEARCASE
115893C 1978	GEARCASE
115899C 1978	GEARCASE
115983E 1969	GEARCASE GROUP
115983S 1969	GEARCASE GROUP
115990R 1979	GEARCASE
115993R 1979	GEARCASE
115999R 1979	GEARCASE
115EL77S 1977	GEARCASE
115ESL69E 1969	GEARCASE GROUP

115ESL69S 1969	GEARCASE GROUP
115ESL70D 1970	GEARCASE GROUP
115ESL73M 1973	GEARCASE
115ESL74B 1974	GEARCASE
115ESL75E 1975	GEARCASE
115ETL74B 1974	GEARCASE
115ETL75E 1975	GEARCASE
115ETL77 1977	GEARCASE
115ETZ78C 1978	GEARCASE
115ML78C 1978	GEARCASE
115ML79R 1979	GEARCASE
115TL79R 1979	GEARCASE
115TXL77S 1977	GEARCASE
115TXL78C 1978	GEARCASE
115TXL79R 1979	GEARCASE
120FTHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
120FTHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
125183C 1971	GEARCASE
125283R 1972	GEARCASE
125ESL71C 1971	GEARCASE
125ESL72R 1972	GEARCASE
135383M 1973	GEARCASE
135443B 1974	GEARCASE
135483B 1974	GEARCASE
135489B 1974	GEARCASE
135543E 1975	GEARCASE
135583E 1975	GEARCASE
135589E 1975	GEARCASE
135643D 1976	GEARCASE
135643G 1976	GEARCASE
135683D 1976	GEARCASE
135683G 1976	GEARCASE
135ESL73M 1973	GEARCASE
135ESL74B 1974	GEARCASE
135ESL75E 1975	GEARCASE

135ETL74B 1974	GEARCASE
135ETL75E 1975	GEARCASE
140740S 1977	GEARCASE
140743S 1977	GEARCASE
140783S 1977	GEARCASE
140840C 1978	GEARCASE
140843C 1978	GEARCASE
140883C 1978	GEARCASE
140940R 1979	GEARCASE
140943R 1979	GEARCASE
140983R 1979	GEARCASE
140FTHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140FTHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140ML77S 1977	GEARCASE
140ML78C 1978	GEARCASE
140ML79R 1979	GEARCASE
140SPHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140SPHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140STHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140STHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140TL77S 1977	GEARCASE
140TL78C 1978	GEARCASE
140TL79R 1979	GEARCASE
140TX78C 1978	GEARCASE
140TXL77S 1977	GEARCASE
140TXL79R 1979	GEARCASE
150840S 1978	GEARCASE
150849S 1978	GEARCASE
150940C 1979	GEARCASE
150949C 1979	GEARCASE
150TL78S 1978	GEARCASE
150TL79C 1979	GEARCASE
150TXL78S 1978	GEARCASE
150TXL79C 1979	GEARCASE
170SPMCCIF 1981	LOWER GEARCASE GROUP

170SPMCCIS 1981	LOWER GEARCASE GROUP
170SPMRCIF 1981	LOWER GEARCASE GROUP
170SPMRCIS 1981	LOWER GEARCASE GROUP
170STMCCIF 1981	LOWER GEARCASE GROUP
170STMCCIS 1981	LOWER GEARCASE GROUP
170STMRCIF 1981	LOWER GEARCASE GROUP
170STMRCIS 1981	LOWER GEARCASE GROUP
175740S 1977	GEARCASE
175749S 1977	GEARCASE
175840C 1978	GEARCASE
175840S 1978	GEARCASE
175940R 1979	GEARCASE
175949R 1979	GEARCASE
175TL77S 1977	GEARCASE
175TL78C 1978	GEARCASE
175TL79R 1979	GEARCASE
175TX78C 1978	GEARCASE
175TXL77S 1977	GEARCASE
175TXL79R 1979	GEARCASE
200490A 1979	GEARCASE
200640S 1976	GEARCASE
200649S 1976	GEARCASE
200740C 1977	GEARCASE
200749C 1977	GEARCASE
200840R 1978	GEARCASE
200849R 1978	GEARCASE
200940A 1979	GEARCASE
200949A 1979	GEARCASE
200FTHRCIF 1981	LOWER GEARCASE GROUP
200FTHRCIS 1981	LOWER GEARCASE GROUP
200SPHRCIF 1981	LOWER GEARCASE GROUP
200SPHRCIS 1981	LOWER GEARCASE GROUP
200STHRCIF 1981	LOWER GEARCASE GROUP
200STHRCIS 1981	LOWER GEARCASE GROUP
200TL76S 1976	GEARCASE

200TL77C 1977	GEARCASE
200TL78R 1978	GEARCASE
200TL79A 1979	GEARCASE
200TX78R 1978	GEARCASE
200TXL76S 1976	GEARCASE
200TXL77C 1977	GEARCASE
200TXL79A 1979	GEARCASE
230FTHRCIF 1981	LOWER GEARCASE GROUP
230FTHRCIS 1981	LOWER GEARCASE GROUP
230SPHRCIF 1981	LOWER GEARCASE GROUP
230SPHRCIS 1981	LOWER GEARCASE GROUP
230STHRCIF 1981	LOWER GEARCASE GROUP
230STHRCIS 1981	LOWER GEARCASE GROUP
235840R 1978	GEARCASE
235849R 1978	GEARCASE
235940A 1979	GEARCASE
235949A 1979	GEARCASE
235TL70A 1979	GEARCASE
235TL78R 1978	GEARCASE
235TX78R 1978	GEARCASE
235TXL79A 1979	GEARCASE
252FTHRCNC 1982	LOWER GEARCASE GROUP
252FTHRCNG 1982	LOWER GEARCASE GROUP
252FTHRCTR 1983	LOWER GEARCASE GROUP
252STHRCNC 1982	LOWER GEARCASE GROUP
252STHRCTR 1983	LOWER GEARCASE GROUP
260FTHRCIF 1981	LOWER GEARCASE GROUP
260FTHRCIS 1981	LOWER GEARCASE GROUP
260SPHRCIF 1981	LOWER GEARCASE GROUP
260SPHRCIS 1981	LOWER GEARCASE GROUP
260STHRCIF 1981	LOWER GEARCASE GROUP
260STHRCIS 1981	LOWER GEARCASE GROUP
302FPHRCNC 1982	LOWER GEARCASE GROUP
302FPHRCNG 1982	LOWER GEARCASE GROUP
302FPHRCTR 1983	LOWER GEARCASE GROUP

302FTHRCNC 1982	LOWER GEARCASE GROUP
302FTHRCNG 1982	LOWER GEARCASE GROUP
302FTHRCTR 1983	LOWER GEARCASE GROUP
302SPHRCNC 1982	LOWER GEARCASE GROUP
302SPHRCNG 1982	LOWER GEARCASE GROUP
302SPHRCTR 1983	LOWER GEARCASE GROUP
302STHRCNC 1982	LOWER GEARCASE GROUP
302STHRCNG 1982	LOWER GEARCASE GROUP
302STHRCTR 1983	LOWER GEARCASE GROUP
382FTMRCTR 1983	LOWER GEARCASE GROUP
382SPMCCNC 1982	LOWER GEARCASE GROUP
382SPMCCTR 1983	LOWER GEARCASE GROUP
382SPMRCNC 1982	LOWER GEARCASE GROUP
382SPMRCTR 1983	LOWER GEARCASE GROUP
382STMCCNC 1982	LOWER GEARCASE GROUP
382STMCCCTR 1983	LOWER GEARCASE GROUP
382STMRCNC 1982	LOWER GEARCASE GROUP
382STMRCCTR 1983	LOWER GEARCASE GROUP
384FTMRCTR 1983	LOWER GEARCASE GROUP
384SPMCCNC 1982	LOWER GEARCASE GROUP
384SPMCCTR 1983	LOWER GEARCASE GROUP
384SPMRCNC 1982	LOWER GEARCASE GROUP
384SPMRCTR 1983	LOWER GEARCASE GROUP
384STMCCNC 1982	LOWER GEARCASE GROUP
384STMCCCTR 1983	LOWER GEARCASE GROUP
384STMRCNC 1982	LOWER GEARCASE GROUP
384STMRCCTR 1983	LOWER GEARCASE GROUP
384STNRCNC 1982	LOWER GEARCASE GROUP
50172S 1971	GEARCASE
50173S 1971	GEARCASE
50202C 1972	GEARCASE 50 HP MANUAL START
50202C 1972	GEARCASE ELECTRIC START
50203C 1972	GEARCASE 50 HP MANUAL START
50203C 1972	GEARCASE ELECTRIC START
50272C 1972	GEARCASE 50 HP MANUAL START

50272C 1972	GEARCASE ELECTRIC START
50273C 1972	GEARCASE 50 HP MANUAL START
50273C 1972	GEARCASE ELECTRIC START
502FTHRCTR 1983	LOWER GEARCASE GROUP
502SPHCCNC 1982	LOWER GEARCASE GROUP
502SPHCCNG 1982	LOWER GEARCASE GROUP
502SPHCCTR 1983	LOWER GEARCASE GROUP
502SPHRCNC 1982	LOWER GEARCASE GROUP
502SPHRCNG 1982	LOWER GEARCASE GROUP
502SPHRCTR 1983	LOWER GEARCASE GROUP
502SPMCCNC 1982	LOWER GEARCASE GROUP
502SPMCCNG 1982	LOWER GEARCASE GROUP
502SPMCCTR 1983	LOWER GEARCASE GROUP
502SPMRCNC 1982	LOWER GEARCASE GROUP
502SPMRCNG 1982	LOWER GEARCASE GROUP
502SPMRCTR 1983	LOWER GEARCASE GROUP
502SPNCCNC 1982	LOWER GEARCASE GROUP
502SPNRCNC 1982	LOWER GEARCASE GROUP
502SPNRCNG 1982	LOWER GEARCASE GROUP
502STHCCNC 1982	LOWER GEARCASE GROUP
502STHCCNG 1982	LOWER GEARCASE GROUP
502STHCCTR 1983	LOWER GEARCASE GROUP
502STHRCNC 1982	LOWER GEARCASE GROUP
502STHRCNG 1982	LOWER GEARCASE GROUP
502STHRCTR 1983	LOWER GEARCASE GROUP
502STMCCNC 1982	LOWER GEARCASE GROUP
502STMCCNG 1982	LOWER GEARCASE GROUP
502STMCCR 1983	LOWER GEARCASE GROUP
502STMRCNC 1982	LOWER GEARCASE GROUP
502STMRCNG 1982	LOWER GEARCASE GROUP
502STMRCTR 1983	LOWER GEARCASE GROUP
50302R 1973	GEARCASE MANUAL START
50302R 1973	GEARCASE ELECTRIC START
50303R 1973	GEARCASE MANUAL START
50303R 1973	GEARCASE ELECTRIC START

50372R 1973	GEARCASE MANUAL START
50372R 1973	GEARCASE ELECTRIC START
50373R 1973	GEARCASE MANUAL START
50373R 1973	GEARCASE ELECTRIC START
50442M 1974	GEARCASE
50443M 1974	GEARCASE
50472M 1974	GEARCASE
50473M 1974	GEARCASE
504FTHRCTR 1983	LOWER GEARCASE GROUP
504SPHCCNC 1982	LOWER GEARCASE GROUP
504SPHCCNG 1982	LOWER GEARCASE GROUP
504SPHCCTR 1983	LOWER GEARCASE GROUP
504SPHRCNC 1982	LOWER GEARCASE GROUP
504SPHRCNG 1982	LOWER GEARCASE GROUP
504SPHRCTR 1983	LOWER GEARCASE GROUP
504SPMCCNC 1982	LOWER GEARCASE GROUP
504SPMCCNG 1982	LOWER GEARCASE GROUP
504SPMCCTR 1983	LOWER GEARCASE GROUP
504SPMRCNC 1982	LOWER GEARCASE GROUP
504SPMRCNG 1982	LOWER GEARCASE GROUP
504SPMRCTR 1983	LOWER GEARCASE GROUP
504STHCCNC 1982	LOWER GEARCASE GROUP
504STHCCNG 1982	LOWER GEARCASE GROUP
504STHCCTR 1983	LOWER GEARCASE GROUP
504STHRCNC 1982	LOWER GEARCASE GROUP
504STHRCNG 1982	LOWER GEARCASE GROUP
504STHRCTR 1983	LOWER GEARCASE GROUP
504STMCCNG 1982	LOWER GEARCASE GROUP
504STMCCCTR 1983	LOWER GEARCASE GROUP
504STMRCNC 1982	LOWER GEARCASE GROUP
504STMRCNG 1982	LOWER GEARCASE GROUP
504STMRCTR 1983	LOWER GEARCASE GROUP
504STNCCNC 1982	LOWER GEARCASE GROUP
50542B 1975	GEARCASE
50543B 1975	GEARCASE

50572B 1975	GEARCASE
50573B 1975	GEARCASE
50902C 1979	GEARCASE ROPE START
50902C 1979	GEARCASE, ELECTRIC START
50903C 1979	GEARCASE ROPE START
50903C 1979	GEARCASE, ELECTRIC START
50ES71S 1971	GEARCASE
50ES72C 1972	GEARCASE 50 HP MANUAL START
50ES72C 1972	GEARCASE ELECTRIC START
50ES73R 1973	GEARCASE MANUAL START
50ES73R 1973	GEARCASE ELECTRIC START
50ES74M 1974	GEARCASE
50ES75B 1975	GEARCASE
50ESL71S 1971	GEARCASE
50ESL72C 1972	GEARCASE 50 HP MANUAL START
50ESL72C 1972	GEARCASE ELECTRIC START
50ESL73R 1973	GEARCASE MANUAL START
50ESL73R 1973	GEARCASE ELECTRIC START
50ESL74M 1974	GEARCASE
50ESL75B 1975	GEARCASE
50R72C 1972	GEARCASE 50 HP MANUAL START
50R72C 1972	GEARCASE ELECTRIC START
50R73R 1973	GEARCASE MANUAL START
50R73R 1973	GEARCASE ELECTRIC START
50R79C 1979	GEARCASE, ELECTRIC START
50R79C 1979	GEARCASE, ROPE START
50RL72C 1972	GEARCASE 50 HP MANUAL START
50RL72C 1972	GEARCASE ELECTRIC START
50RL73R 1973	GEARCASE MANUAL START
50RL73R 1973	GEARCASE ELECTRIC START
50RL79C 1979	GEARCASE, ELECTRIC START
50RL79C 1979	GEARCASE, ROPE START
55642E 1976	GEARCASE
55643E 1976	GEARCASE
55672E 1976	GEARCASE

55673E 1976	GEARCASE
55772D 1977	GEARCASE
55773D 1977	GEARCASE
55872A 1968	GEARCASE GROUP
55872R 1968	GEARCASE GROUP
55872S 1968	GEARCASE GROUP
55873A 1968	GEARCASE GROUP
55873R 1968	GEARCASE GROUP
55873S 1968	GEARCASE GROUP
55874S 1978	GEARCASE
55875S 1978	GEARCASE
55972A 1969	GEARCASE GROUP
55972C 1969	GEARCASE GROUP
55973A 1969	GEARCASE GROUP
55973C 1969	GEARCASE GROUP
55974C 1979	GEARCASE ROPE START
55974C 1979	GEARCASE, ELECTRIC START
55975C 1979	GEARCASE ROPE START
55975C 1979	GEARCASE, ELECTRIC START
55E76E 1976	GEARCASE
55E77D 1977	GEARCASE
55E78S 1978	GEARCASE
55E79C 1979	GEARCASE, ELECTRIC START
55E79C 1979	GEARCASE, ROPE START
55EL76E 1976	GEARCASE
55EL77D 1977	GEARCASE
55EL78S 1978	GEARCASE
55EL79C 1979	GEARCASE, ELECTRIC START
55EL79C 1979	GEARCASE, ROPE START
55ES69A 1969	GEARCASE GROUP
55ES69C 1969	GEARCASE GROUP
55ESL69A 1969	GEARCASE GROUP
55ESL69C 1969	GEARCASE GROUP
574SPHCCNC 1982	LOWER GEARCASE GROUP
574SPHCCNG 1982	LOWER GEARCASE GROUP

574SPHCCTR 1983	LOWER GEARCASE GROUP
574SPHRCNC 1982	LOWER GEARCASE GROUP
574SPHRCNG 1982	LOWER GEARCASE GROUP
574SPHRCTR 1983	LOWER GEARCASE GROUP
574SPMCCNC 1982	LOWER GEARCASE GROUP
574SPMCCNG 1982	LOWER GEARCASE GROUP
574SPMCCTR 1983	LOWER GEARCASE GROUP
574SPMRCNC 1982	LOWER GEARCASE GROUP
574SPMRCNG 1982	LOWER GEARCASE GROUP
574SPMRCTR 1983	LOWER GEARCASE GROUP
574STHCNC 1982	LOWER GEARCASE GROUP
574STHCNG 1982	LOWER GEARCASE GROUP
574STHCCTR 1983	LOWER GEARCASE GROUP
574STHRCNC 1982	LOWER GEARCASE GROUP
574STHRCNG 1982	LOWER GEARCASE GROUP
574STHRCTR 1983	LOWER GEARCASE GROUP
574STMCCNC 1982	LOWER GEARCASE GROUP
574STMCCNG 1982	LOWER GEARCASE GROUP
574STMCCR 1983	LOWER GEARCASE GROUP
574STMRCMC 1982	LOWER GEARCASE GROUP
574STMRCMG 1982	LOWER GEARCASE GROUP
574STMRCNC 1982	LOWER GEARCASE GROUP
574STMRCNG 1982	LOWER GEARCASE GROUP
574STMRCTR 1983	LOWER GEARCASE GROUP
60072B 1970	GEARCASE GROUP
60072D 1970	GEARCASE GROUP
60073B 1970	GEARCASE GROUP
60073D 1970	GEARCASE GROUP
60172C 1971	GEARCASE
60172E 1971	GEARCASE
60173C 1971	GEARCASE
60173E 1971	GEARCASE
60ES70B 1970	GEARCASE GROUP
60ES70D 1970	GEARCASE GROUP
60ES71C 1971	GEARCASE

60ES71E 1971	GEARCASE
60ESL70B 1970	GEARCASE GROUP
60ESL70D 1970	GEARCASE GROUP
60ESL71C 1971	GEARCASE
60ESL71E 1971	GEARCASE
65272S 1972	GEARCASE
65273S 1972	GEARCASE
65372R 1973	GEARCASE
65373R 1973	GEARCASE
65ES72S 1972	GEARCASE
65ES73R 1973	GEARCASE
65ESL72S 1972	GEARCASE
65ESL73R 1973	GEARCASE
70442M 1974	GEARCASE
70443M 1974	GEARCASE
70472M 1974	GEARCASE
70473M 1974	GEARCASE
70572B 1975	GEARCASE FOR MODELS 70572B,70573B
70572B 1975	GEARCASE FOR MODELS 70572E,70573E
70572E 1975	GEARCASE FOR MODELS 70572B,70573B
70572E 1975	GEARCASE FOR MODELS 70572E,70573E
70573B 1975	GEARCASE FOR MODELS 70572B,70573B
70573B 1975	GEARCASE FOR MODELS 70572E,70573E
70573E 1975	GEARCASE FOR MODELS 70572B,70573B
70573E 1975	GEARCASE FOR MODELS 70572E,70573E
70673D 1976	GEARCASE
70773S 1977	GEARCASE-15" TRANSOM
70873C 1978	GEARCASE-15" TRANSOM
70973R 1979	GEARCASE-15" TRANSOM
70973R 1979	GEARCASE-20" TRANSOM
70EL76D 1976	GEARCASE
70EL77S 1977	GEARCASE-15"TRANSOM
70EL78C 1978	GEARCASE-15 INCH TRANSOM
70EL79R 1979	GEARCASE-15"TRANSOM
70EL79R 1979	GEARCASE-20" TRANSOM

70ES74M 1974	GEARCASE
70ES75B 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ES75B 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ES75E 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ES75E 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESL74M 1974	GEARCASE
70ESL75B 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ESL75B 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESL75E 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ESL75E 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESLR74M 1974	GEARCASE
75542B 1975	GEARCASE - 15" TRANSOM
75542B 1975	GEARCASE - 20" TRANSOM
75543B 1975	GEARCASE - 15" TRANSOM
75543B 1975	GEARCASE - 20" TRANSOM
75642D 1976	GEARCASE-15" TRANSOM
75642D 1976	GEARCASE-20" TRANSOM
75643D 1976	GEARCASE-15" TRANSOM
75643D 1976	GEARCASE-20" TRANSOM
75742S 1977	GEARCASE-15" TRANSOM
75743S 1977	GEARCASE-15" TRANSOM
75842C 1978	GEARCASE-15" TRANSOM
75843C 1978	GEARCASE-15" TRANSOM
75942R 1979	GEARCASE-15" TRANSOM
75942R 1979	GEARCASE-20" TRANSOM
75943R 1979	GEARCASE-15" TRANSOM
75943R 1979	GEARCASE-20" TRANSOM
75ELR76D 1976	GEARCASE-15" TRANSOM
75ELR76D 1976	GEARCASE-20" TRANSOM
75ELR77S 1977	GEARCASE-15"TRANSOM
75ELR78C 1978	GEARCASE-15 INCH TRANSOM
75ELR79R 1979	GEARCASE-15"TRANSOM
75ELR79R 1979	GEARCASE-20" TRANSOM
75ER76D 1976	GEARCASE-15" TRANSOM
75ER76D 1976	GEARCASE-20" TRANSOM

75ER77S 1977	GEARCASE-15"TRANSOM
75ER78C 1978	GEARCASE-15 INCH TRANSOM
75ER79R 1979	GEARCASE-15"TRANSOM
75ER79R 1979	GEARCASE-20" TRANSOM
75ESLR75B 1975	GEARCASE-15"TRANSOM
75ESLR75B 1975	GEARCASE-20" TRANSOM
75ESR75B 1975	GEARCASE-15"TRANSOM
75ESR75B 1975	GEARCASE-20" TRANSOM
85093B 1970	GEARCASE GROUP
85093D 1970	GEARCASE GROUP
85193A 1971	GEARCASE
85193H 1971	GEARCASE
85293R 1972	GEARCASE
85393M 1973	GEARCASE
85493B 1974	GEARCASE
85593E 1975	GEARCASE
85693D 1976	GEARCASE
85693G 1976	GEARCASE
85699G 1976	GEARCASE
85790S 1977	GEARCASE
85793S 1977	GEARCASE
85799S 1977	GEARCASE
85890C 1978	GEARCASE
85895C 1978	GEARCASE
85899C 1978	GEARCASE
85990R 1979	GEARCASE
85993E 1969	GEARCASE GROUP
85993M 1969	GEARCASE GROUP
85993S 1969	GEARCASE GROUP
85995R 1979	GEARCASE
85999R 1979	GEARCASE
85EL76D 1976	GEARCASE
85EL76G 1976	GEARCASE
85EL77S 1977	GEARCASE
85ESL69E 1969	GEARCASE GROUP

85ESL69M 1969	GEARCASE GROUP
85ESL69S 1969	GEARCASE GROUP
85ESL70B 1970	GEARCASE GROUP
85ESL70D 1970	GEARCASE GROUP
85ESL71A 1971	GEARCASE
85ESL71H 1971	GEARCASE
85ESL72R 1972	GEARCASE
85ESL73M 1973	GEARCASE
85ESL74B 1974	GEARCASE
85ESL75E 1975	GEARCASE
85ETLR76D 1976	GEARCASE
85ETLR76G 1976	GEARCASE
85ETLR77S 1977	GEARCASE
85ETLR78C 1978	GEARCASE
85ML78C 1978	GEARCASE
85ML79R 1979	GEARCASE
85TL79R 1979	GEARCASE
85TXL79R 1979	GEARCASE
85TXLR77S 1977	GEARCASE
85TXLR78C 1978	GEARCASE
990242C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990242C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990242D 1978	LOWER GEARCASE
990242H 1978	LOWER GEARCASE
990242H1 1978	LOWER GEARCASE
990242S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990242S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990243C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990243C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990243D 1978	LOWER GEARCASE
990243H 1978	LOWER GEARCASE
990243H1 1978	LOWER GEARCASE
990243S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990243S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990244C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE

990244C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990244D 1978	LOWER GEARCASE
990244H 1978	LOWER GEARCASE
990244H1 1978	LOWER GEARCASE
990244P 1978	LOWER GEARCASE
990244S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990244S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990245C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990245C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990245D 1978	LOWER GEARCASE
990245H 1978	LOWER GEARCASE
990245H1 1978	LOWER GEARCASE
990245S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990245S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990250D 1978	LOWER GEARCASE GROUP
990250H 1978	LOWER GEARCASE GROUP
990250J 1978	LOWER GEARCASE GROUP
990250N 1978	LOWER GEARCASE GROUP
990250P 1978	LOWER GEARCASE GROUP
990250U 1978	LOWER GEARCASE GROUP
990251D 1978	LOWER GEARCASE GROUP
990251H 1978	LOWER GEARCASE GROUP
990251J 1978	LOWER GEARCASE GROUP
990251N 1978	LOWER GEARCASE GROUP
990251S 1979	LOWER GEARCASE GROUP
990251U 1978	LOWER GEARCASE GROUP
990252C 1980	LOWER GEARCASE GROUP
990252D 1978	LOWER GEARCASE GROUP
990252H 1978	LOWER GEARCASE GROUP
990252J 1978	LOWER GEARCASE GROUP
990252K 1980	LOWER GEARCASE GROUP
990252S 1979	LOWER GEARCASE GROUP
990252S1 1979	LOWER GEARCASE GROUP
990253C 1980	LOWER GEARCASE GROUP
990253D 1978	LOWER GEARCASE GROUP

990253H 1978	LOWER GEARCASE GROUP
990253J 1978	LOWER GEARCASE GROUP
990253K 1980	LOWER GEARCASE GROUP
990253S 1979	LOWER GEARCASE GROUP
990253S1 1979	LOWER GEARCASE GROUP
990254C 1980	LOWER GEARCASE GROUP
990254D 1978	LOWER GEARCASE GROUP
990254H 1978	LOWER GEARCASE GROUP
990254J 1978	LOWER GEARCASE GROUP
990254K 1980	LOWER GEARCASE GROUP
990254S 1979	LOWER GEARCASE GROUP
990254S1 1979	LOWER GEARCASE GROUP
990254V 1979	LOWER GEARCASE GROUP
990255C 1980	LOWER GEARCASE GROUP
990255D 1978	LOWER GEARCASE GROUP
990255H 1978	LOWER GEARCASE GROUP
990255J 1978	LOWER GEARCASE GROUP
990255K 1980	LOWER GEARCASE GROUP
990255S 1979	LOWER GEARCASE GROUP
990255S1 1979	LOWER GEARCASE GROUP
990255V 1979	LOWER GEARCASE GROUP
990256C 1980	LOWER GEARCASE GROUP
990256K 1980	LOWER GEARCASE GROUP
990256S 1979	LOWER GEARCASE GROUP
990256S1 1979	LOWER GEARCASE GROUP
990257C 1980	LOWER GEARCASE GROUP
990257K 1980	LOWER GEARCASE GROUP
990257S 1979	LOWER GEARCASE GROUP
990257S1 1979	LOWER GEARCASE GROUP
990260C 1980	LOWER GEARCASE GROUP
990260K 1980	LOWER GEARCASE GROUP
990260S 1979	LOWER GEARCASE GROUP
990260S1 1979	LOWER GEARCASE GROUP
990260U 1980	LOWER GEARCASE GROUP
990261C 1980	LOWER GEARCASE GROUP

990261K 1980	LOWER GEARCASE GROUP
990261S 1979	LOWER GEARCASE GROUP
990261S1 1979	LOWER GEARCASE GROUP
990261U 1980	LOWER GEARCASE GROUP
990262C 1980	LOWER GEARCASE GROUP
990262K 1980	LOWER GEARCASE GROUP
990262S 1979	LOWER GEARCASE GROUP
990262S1 1979	LOWER GEARCASE GROUP
990262U 1980	LOWER GEARCASE GROUP
990266C 1980	LOWER GEARCASE GROUP
990266K 1980	LOWER GEARCASE GROUP
990266S 1979	LOWER GEARCASE GROUP
990266S1 1979	LOWER GEARCASE GROUP
990267C 1980	LOWER GEARCASE GROUP
990267K 1980	LOWER GEARCASE GROUP
990267S 1979	LOWER GEARCASE GROUP
990267S1 1979	LOWER GEARCASE GROUP
AM55RSLD 1999	GEARCASE
BE40EECR 1998	GEARCASE
BE40EEDS 1996	GEARCASE
BE40EEUC 1997	GEARCASE
BE40ELECR 1998	GEARCASE
BE40ELEDs 1996	GEARCASE
BE40ELEUC 1997	GEARCASE
BE40TLECR 1998	GEARCASE
BE40TLEDs 1996	GEARCASE
BE40TLEUC 1997	GEARCASE
BE50BEEDs 1996	GEARCASE
BE50BELEDs 1996	GEARCASE
BE50DTLEDc 1996	GEARCASE
BE50DTLEUR 1997	GEARCASE
BE50ESECC 1998	GEARCASE
BE50RLECR 1998	GEARCASE
BE50RLEUC 1997	GEARCASE
BE50TLECR 1998	GEARCASE

BE50TLEDS 1996	GEARCASE
BE50TLEUC 1997	GEARCASE
BE50TSLECC 1998	GEARCASE
BE50TSLEUS 1997	GEARCASE
BE60ELEDR 1996	GEARCASE
BE60ELEUA 1997	GEARCASE
BE60TLECM 1998	GEARCASE
BE60TLEDR 1996	GEARCASE
BE60TLEUA 1997	GEARCASE
BE70ELECB 1998	GEARCASE
BE70ELEDA 1996	GEARCASE
BE70ELEUM 1997	GEARCASE
BE70TLECB 1998	GEARCASE
BE70TLEDA 1996	GEARCASE
BE70TLEUM 1997	GEARCASE
BJ40EECR 1998	GEARCASE
BJ40EEDS 1996	GEARCASE
BJ40EEEE 1999	GEARCASE
BJ40EEUC 1997	GEARCASE
BJ40ELECR 1998	GEARCASE
BJ40ELEDs 1996	GEARCASE
BJ40ELEEA 1999	GEARCASE
BJ40ELEUC 1997	GEARCASE
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40PLEEA 1999	GEARCASE
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40TLECR 1998	GEARCASE
BJ40TLEDS 1996	GEARCASE
BJ40TLEUC 1997	GEARCASE
BJ50BEEDS 1996	GEARCASE
BJ50BELEDs 1996	GEARCASE

BJ50DTLEDC 1996	GEARCASE
BJ50DTLEUR 1997	GEARCASE
BJ50EEER 1999	GEARCASE
BJ50ELEER 1999	GEARCASE
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50ESECC 1998	GEARCASE
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ50PLEEA 1999	GEARCASE
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50RLECR 1998	GEARCASE
BJ50RLEEA 1999	GEARCASE
BJ50RLEUC 1997	GEARCASE
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50TLECR 1998	GEARCASE
BJ50TLEDS 1996	GEARCASE
BJ50TLEUC 1997	GEARCASE
BJ50TSLECC 1998	GEARCASE
BJ50TSLEUS 1997	GEARCASE
BJ60ELEDR 1996	GEARCASE
BJ60ELEUA 1997	GEARCASE
BJ60TLECM 1998	GEARCASE
BJ60TLEDR 1996	GEARCASE
BJ60TLEUA 1997	GEARCASE
BJ70ELECB 1998	GEARCASE
BJ70ELED A 1996	GEARCASE
BJ70ELEUM 1997	GEARCASE
BJ70PLEEE 1999	GEARCASE
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
BJ70TLECB 1998	GEARCASE

BJ70TLEDA 1996	GEARCASE
BJ70TLEUM 1997	GEARCASE
E100MLCSC 1980	GEARCASE
E100TLCSC 1980	GEARCASE
E100TXCSC 1980	GEARCASE
E115JKLEOC 1995	GEARCASE
E115JKLERS 1994	GEARCASE
E115MLCIH 1981	GEARCASE
E115MLCIM 1981	GEARCASE
E115MLCNB 1982	GEARCASE
E115MLCOS 1985	GEARCASE
E115MLCRD 1984	GEARCASE
E115MLCSA 1980	GEARCASE
E115MLCTE 1983	GEARCASE
E115TLCIH 1981	GEARCASE
E115TLCIM 1981	GEARCASE
E115TLCNB 1982	GEARCASE
E115TLCOS 1985	GEARCASE
E115TLCRD 1984	GEARCASE
E115TLCSA 1980	GEARCASE
E115TLCTE 1983	GEARCASE
E115TXCIH 1981	GEARCASE
E115TXCIM 1981	GEARCASE
E115TXCNB 1982	GEARCASE
E115TXCRD 1984	GEARCASE
E115TXCSA 1980	GEARCASE
E115TXCTE 1983	GEARCASE
E120TLCCA 1988	GEARCASE - 120TL & TX/140 TL
E120TLCEM 1989	GEARCASE - 120TL & TX/140 TL
E120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
E120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E120TLESB 1990	GEARCASE - 120TL & TX/140 TL
E120TXCCA 1988	GEARCASE - 120TL & TX/140 TL
E120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
E120TXEIE 1991	GEARCASE - 120TL & TX/140 TL

E120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E120TXESB 1990	GEARCASE - 120TL & TX/140 TL
E125ESXENR 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E125ESXESS 1990	GEARCASE - ESX MODELS ONLY
E125ESXW 1989	GEARCASE - ESX MODELS ONLY
E140CXCCS 1988	GEARCASE - 120TL & TX/140 TL
E140CXCEC 1989	GEARCASE - 120TL & TX/140 TL
E140CXEIA 1991	GEARCASE - 120TL & TX/140 TL
E140CXENM 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140CXESR 1990	GEARCASE - 120TL & TX/140 TL
E140MLCIH 1981	GEARCASE
E140MLCIM 1981	GEARCASE
E140MLCNB 1982	GEARCASE
E140MLCSA 1980	GEARCASE
E140MLCTE 1983	GEARCASE
E140TLCCM 1988	GEARCASE - 120TL & TX/140 TL
E140TLCEB 1989	GEARCASE - 120TL & TX/140 TL
E140TLCRD 1984	GEARCASE
E140TLEID 1991	GEARCASE - 120TL & TX/140 TL
E140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140TLESE 1990	GEARCASE - 120TL & TX/140 TL
E140TRLCIH 1981	GEARCASE
E140TRLCIM 1981	GEARCASE
E140TRLCNB 1982	GEARCASE
E140TRLCSA 1980	GEARCASE
E140TRLCTE 1983	GEARCASE
E140TRXCIH 1981	GEARCASE
E140TRXCIM 1981	GEARCASE
E140TRXCNB 1982	GEARCASE
E140TRXCSA 1980	GEARCASE
E140TRXCTE 1983	GEARCASE
E140TXCCM 1988	GEARCASE - 120TL & TX/140 TL
E140TXCEB 1989	GEARCASE - 120TL & TX/140 TL
E140TXCRD 1984	GEARCASE
E140TXEID 1991	GEARCASE - 120TL & TX/140 TL

E140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140TXESE 1990	GEARCASE - 120TL & TX/140 TL
E150STLCTE 1983	GEARCASE
E150TRLCIA 1981	GEARCASE
E150TRLCIH 1981	GEARCASE
E150TRLCNM 1982	GEARCASE
E150TRLCSF 1980	GEARCASE
E150TRLCSS 1980	GEARCASE
E150TRLCIB 1983	GEARCASE
E150TRLCIE 1983	GEARCASE
E150TRXCIA 1981	GEARCASE
E150TRXCIB 1981	GEARCASE
E150TRXCNM 1982	GEARCASE
E150TRXCSS 1980	GEARCASE
E150TRXCIB 1980	GEARCASE
E150TRXCIB 1983	GEARCASE
E150TRXCIE 1983	GEARCASE
E175TRLCIM 1981	GEARCASE
E175TRLCNB 1982	GEARCASE
E175TRLCSA 1980	GEARCASE
E175TRLCSS 1980	GEARCASE
E175TRLCID 1983	GEARCASE
E175TRLCIE 1983	GEARCASE
E175TRXCIB 1981	GEARCASE
E175TRXCIM 1981	GEARCASE
E175TRXCNB 1982	GEARCASE
E175TRXCSA 1980	GEARCASE
E175TRXCSS 1980	GEARCASE
E175TRXCID 1983	GEARCASE
E175TRXCIE 1983	GEARCASE
E200TRLCIB 1981	GEARCASE
E200TRLCIH 1981	GEARCASE
E200TRLCNE 1982	GEARCASE
E200TRLCSS 1980	GEARCASE
E200TRLCSS 1980	GEARCASE

E200TRLCTD 1983	GEARCASE
E200TRLCTS 1983	GEARCASE
E200TRXCIB 1981	GEARCASE
E200TRXCIH 1981	GEARCASE
E200TRXCNE 1982	GEARCASE
E200TRXCSF 1980	GEARCASE
E200TRXCSM 1980	GEARCASE
E200TRXCTD 1983	GEARCASE
E200TRXCTS 1983	GEARCASE
E235STLCTS 1983	GEARCASE
E235TRLCIB 1981	GEARCASE
E235TRLCIH 1981	GEARCASE
E235TRLCNE 1982	GEARCASE
E235TRLCSM 1980	GEARCASE
E235TRLCTD 1983	GEARCASE
E235TRLCTS 1983	GEARCASE
E235TRXCIB 1981	GEARCASE
E235TRXCIH 1981	GEARCASE
E235TRXCNE 1982	GEARCASE
E235TRXCSM 1980	GEARCASE
E235TRXCTD 1983	GEARCASE
E235TRXCTS 1983	GEARCASE
E35AELCDE 1986	GEARCASE
E35AELCUD 1987	GEARCASE
E35ARLCDE 1986	GEARCASE
E35ARLCUD 1987	GEARCASE
E40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40AELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ARLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ATLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40DELSDA	GEARCASE
E40DELSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DELSOR	GEARCASE

E40DELSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DELSRC	GEARCASE
E40DELSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DPLISD	GEARCASE
E40DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLISF	GEARCASE
E40DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSCB	GEARCASE
E40DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSDA	GEARCASE
E40DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSEE	GEARCASE
E40DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSOR	GEARCASE
E40DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DPLSRC	GEARCASE
E40DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DPLSUM	GEARCASE
E40DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLISD	GEARCASE
E40DRLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLISF	GEARCASE
E40DRLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSCB	GEARCASE
E40DRLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSDA	GEARCASE
E40DRLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSEE	GEARCASE
E40DRLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSOR	GEARCASE
E40DRLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DRLSRC	GEARCASE
E40DRLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DRLSUM	GEARCASE
E40DRLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F

E40DSLISF	GEARCASE
E40DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLISR	GEARCASE
E40DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLSCS	GEARCASE
E40DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLSEC	GEARCASE
E40DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLISF	GEARCASE
E40DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLISR	GEARCASE
E40DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLSCS	GEARCASE
E40DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLSEC	GEARCASE
E40DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ECDE 1986	GEARCASE
E40ECEC 1989	GEARCASE
E40ECOB 1985	GEARCASE
E40ECRM 1984	GEARCASE
E40ECUD 1987	GEARCASE
E40EEIA 1991	GEARCASE
E40EENJ 1992	GEARCASE
E40EENM 1992	GEARCASE
E40EEOD 1995	GEARCASE
E40EERE 1994	GEARCASE
E40EESR 1990	GEARCASE
E40EETB 1993	GEARCASE
E40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ELCDE 1986	GEARCASE
E40ELCEC 1989	GEARCASE
E40ELCOB 1985	GEARCASE

E40ELCRM 1984	GEARCASE
E40ELCUD 1987	GEARCASE
E40ELECR 1998	GEARCASE
E40ELED 1996	GEARCASE
E40ELEIA 1991	GEARCASE
E40ELENJ 1992	GEARCASE
E40ELENM 1992	GEARCASE
E40ELEOD 1995	GEARCASE
E40ELERE 1994	GEARCASE
E40ELESR 1990	GEARCASE
E40ELETB 1993	GEARCASE
E40ELEUC 1997	GEARCASE
E40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40RCDE 1986	GEARCASE
E40RCEC 1989	GEARCASE
E40RCOB 1985	GEARCASE
E40RCRM 1984	GEARCASE
E40RCUD 1987	GEARCASE
E40RECR 1998	GEARCASE
E40REDS 1996	GEARCASE
E40REIA 1991	GEARCASE
E40RENM 1992	GEARCASE
E40REOD 1995	GEARCASE
E40RERE 1994	GEARCASE
E40RESR 1990	GEARCASE
E40RETB 1993	GEARCASE
E40REUC 1997	GEARCASE
E40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40RLCDE 1986	GEARCASE
E40RLCEC 1989	GEARCASE
E40RLCOB 1985	GEARCASE
E40RLCRM 1984	GEARCASE
E40RLCUD 1987	GEARCASE

E40RLECR 1998	GEARCASE
E40RLEDS 1996	GEARCASE
E40RLEIA 1991	GEARCASE
E40RLENM 1992	GEARCASE
E40RLEOD 1995	GEARCASE
E40RLERE 1994	GEARCASE
E40RLESR 1990	GEARCASE
E40RLETB 1993	GEARCASE
E40RLEUC 1997	GEARCASE
E40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TECDE 1986	GEARCASE
E40TECEC 1989	GEARCASE
E40TECOB 1985	GEARCASE
E40TECRM 1984	GEARCASE
E40TECUD 1987	GEARCASE
E40TEECR 1998	GEARCASE
E40TEEDS 1996	GEARCASE
E40TEEIA 1991	GEARCASE
E40TEENJ 1992	GEARCASE
E40TEENM 1992	GEARCASE
E40TEEOD 1995	GEARCASE
E40TEERE 1994	GEARCASE
E40TEESR 1990	GEARCASE
E40TEETB 1993	GEARCASE
E40TEEUC 1997	GEARCASE
E40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TELCDE 1986	GEARCASE
E40TELCEC 1989	GEARCASE
E40TELCOB 1985	GEARCASE
E40TELCRM 1984	GEARCASE
E40TELECR 1998	GEARCASE
E40TELEDS 1996	GEARCASE
E40TELEIA 1991	GEARCASE

E40TELENJ 1992	GEARCASE
E40TELENM 1992	GEARCASE
E40TELEOD 1995	GEARCASE
E40TELERE 1994	GEARCASE
E40TELESR 1990	GEARCASE
E40TELETB 1993	GEARCASE
E40TELEUC 1997	GEARCASE
E40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TLCDE 1986	GEARCASE
E40TLCEC 1989	GEARCASE
E40TLCUD 1987	GEARCASE
E40TLECR 1998	GEARCASE
E40TLEDS 1996	GEARCASE
E40TLEIA 1991	GEARCASE
E40TLENJ 1992	GEARCASE
E40TLENM 1992	GEARCASE
E40TLEOD 1995	GEARCASE
E40TLERE 1994	GEARCASE
E40TLESR 1990	GEARCASE
E40TLETB 1993	GEARCASE
E40TLETF 1993	GEARCASE
E40TLEUC 1997	GEARCASE
E40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TTLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TTLCEC 1989	GEARCASE
E40TTLECR 1998	GEARCASE
E40TTLEDS 1996	GEARCASE
E40TTLEIA 1991	GEARCASE
E40TTLENM 1992	GEARCASE
E40TTLEOD 1995	GEARCASE
E40TTLERE 1994	GEARCASE
E40TTLESR 1990	GEARCASE
E40TTLETB 1993	GEARCASE
E40TTLETF 1993	GEARCASE

E40TTLEUC 1997	GEARCASE
E40WREES 1999	GEARCASE
E40WRLEES 1999	GEARCASE
E40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRYEES 1999	GEARCASE
E40WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
E45RCCDS 1986	GEARCASE
E45RCCUC 1987	GEARCASE
E45RCE 1989	GEARCASE
E45RCEIA 1991	GEARCASE
E45RCENM 1992	GEARCASE
E45RCEOD 1995	GEARCASE
E45RCERE 1994	GEARCASE
E45RCESR 1990	GEARCASE
E45RCETB 1993	GEARCASE
E45RCLCDS 1986	GEARCASE
E45RCLCUC 1987	GEARCASE
E45RCLE 1989	GEARCASE
E45RCLEDS 1996	GEARCASE
E45RCLEIA 1991	GEARCASE
E45RCLENM 1992	GEARCASE
E45RCLEOD 1995	GEARCASE
E45RCLERE 1994	GEARCASE
E45RCLESR 1990	GEARCASE
E45RCLETB 1993	GEARCASE
E45RCLEUC 1997	GEARCASE
E45WMLE 1989	GEARCASE
E45WMLEIA 1991	GEARCASE
E45WMLENM 1992	GEARCASE
E45WMLESR 1990	GEARCASE

E48ESLCCC 1988	GEARCASE
E48ESLCER 1989	GEARCASE
E48ESLCUS 1987	GEARCASE
E48ESLEDC 1996	GEARCASE
E48ESLEIM 1991	GEARCASE
E48ESLENB 1992	GEARCASE
E48ESLEOS 1995	GEARCASE
E48ESLERD 1994	GEARCASE
E48ESLESA 1990	GEARCASE
E48ESLETE 1993	GEARCASE
E50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50BECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50BECDE 1986	GEARCASE
E50BECEC 1989	GEARCASE
E50BECIC 1981	GEARCASE, ELECTRIC START
E50BECIC 1981	GEARCASE, ROPE START
E50BECNR 1982	GEARCASE
E50BECOB 1985	GEARCASE
E50BECRM 1984	GEARCASE
E50BECTA 1983	GEARCASE
E50BECUD 1987	GEARCASE
E50BEEIA 1991	GEARCASE
E50BEENJ 1992	GEARCASE
E50BEENM 1992	GEARCASE
E50BEEOD 1995	GEARCASE
E50BEERE 1994	GEARCASE
E50BEESR 1990	GEARCASE
E50BEETB 1993	GEARCASE
E50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50BELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50BELCDE 1986	GEARCASE
E50BELCEC 1989	GEARCASE
E50BELCIC 1981	GEARCASE, ELECTRIC START
E50BELCIC 1981	GEARCASE, ROPE START
E50BELCNR 1982	GEARCASE

E50BELCOB 1985	GEARCASE
E50BELCRM 1984	GEARCASE
E50BELCTA 1983	GEARCASE
E50BELCUD 1987	GEARCASE
E50BELEIA 1991	GEARCASE
E50BELENJ 1992	GEARCASE
E50BELENM 1992	GEARCASE
E50BELEOD 1995	GEARCASE
E50BELERE 1994	GEARCASE
E50BELESR 1990	GEARCASE
E50BELETB 1993	GEARCASE
E50DPLISD	GEARCASE
E50DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLISF	GEARCASE
E50DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSCB	GEARCASE
E50DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSDA	GEARCASE
E50DPLSEE	GEARCASE
E50DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSOR	GEARCASE
E50DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E50DPLSRC	GEARCASE
E50DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E50DPLSUM	GEARCASE
E50DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLISF	GEARCASE
E50DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLISR	GEARCASE
E50DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLSCS	GEARCASE
E50DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLSEC	GEARCASE
E50DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLECA 1998	GEARCASE

E50DTLEDC 1996	GEARCASE
E50DTLEOS 1995	GEARCASE
E50DTLEUR 1997	GEARCASE
E50DTLISF	GEARCASE
E50DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLISR	GEARCASE
E50DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLSCS	GEARCASE
E50DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLSEC	GEARCASE
E50DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50ECSR 1980	GEARCASE
E50ELCSR 1980	GEARCASE
E50ELED 1996	GEARCASE
E50ELEOS 1995	GEARCASE
E50ELEUR 1997	GEARCASE
E50ESLECC 1998	GEARCASE
E50ESLEUR 1997	GEARCASE
E50JEDS 1996	GEARCASE
E50JEIA 1991	GEARCASE
E50JENJ 1992	GEARCASE
E50JENM 1992	GEARCASE
E50JEOD 1995	GEARCASE
E50JERE 1994	GEARCASE
E50JETB 1993	GEARCASE
E50JEUC 1997	GEARCASE
E50RNLIA 1990	GEARCASE
E50RNLIB 1992	GEARCASE
E50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50TELCDE 1986	GEARCASE
E50TELCEC 1989	GEARCASE
E50TELCOB 1985	GEARCASE
E50TELCRM 1984	GEARCASE
E50TELCTA 1983	GEARCASE

E50TELCUD 1987	GEARCASE
E50TELEIA 1991	GEARCASE
E50TELENM 1992	GEARCASE
E50TELEOD 1995	GEARCASE
E50TELERE 1994	GEARCASE
E50TELESR 1990	GEARCASE
E50TELETB 1993	GEARCASE
E50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50TLCDE 1986	GEARCASE
E50TLCEC 1989	GEARCASE
E50TLCOB 1985	GEARCASE
E50TLCRM 1984	GEARCASE
E50TLCUD 1987	GEARCASE
E50TLECR 1998	GEARCASE
E50TLEDS 1996	GEARCASE
E50TLEIA 1991	GEARCASE
E50TLENJ 1992	GEARCASE
E50TLENM 1992	GEARCASE
E50TLEOD 1995	GEARCASE
E50TLERE 1994	GEARCASE
E50TLESR 1990	GEARCASE
E50TLETB 1993	GEARCASE
E50TLETF 1993	GEARCASE
E50TLEUC 1997	GEARCASE
E50TSLECC 1998	GEARCASE
E50TSLEUS 1997	GEARCASE
E50TTLECA 1998	GEARCASE
E50TTLEDC 1996	GEARCASE
E50TTLEOS 1995	GEARCASE
E50TTLEUR 1997	GEARCASE
E55MRLISA	GEARCASE
E55MRLISA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSCC	GEARCASE
E55MRLSCC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL

E55MRLSEF	GEARCASE
E55MRLSEF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSER	GEARCASE
E55MRLSER - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55RCIM 1981	GEARCASE, ELECTRIC START
E55RCIM 1981	GEARCASE, ROPE START
E55RLCSA 1980	GEARCASE, ELECTRIC START
E55RLCSA 1980	GEARCASE, ROPE START
E55RSLC 1997	GEARCASE
E55RSLG 1995	GEARCASE
E55RSLN 1983	GEARCASE
E55RSLN-2 1983	GEARCASE
E55RSLW 1996	GEARCASE
E55RSN 1983	GEARCASE
E55RSN-2 1983	GEARCASE
E55RSYN 1983	GEARCASE
E55RSYN-2 1983	GEARCASE
E55RWLDCD 1986	GEARCASE
E55RWLCOS 1985	GEARCASE
E55RWLCRD 1984	GEARCASE
E55RWLCUC 1987	GEARCASE
E55RWLE 1989	GEARCASE
E55RWLEIA 1991	GEARCASE
E55RWLENM 1992	GEARCASE
E55RWLERE 1994	GEARCASE
E55RWLESR 1990	GEARCASE
E55RWLETB 1993	GEARCASE
E55TLCIM 1981	GEARCASE, ELECTRIC START
E55TLCIM 1981	GEARCASE, ROPE START
E55WREES 1999	GEARCASE
E55WRLEES 1999	GEARCASE
E55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE

E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E55WRYEES 1999	GEARCASE
E55WRYISIR commercial, rope start, 25 in shaft 2001	GEARCASE
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
E60DPLISD	GEARCASE
E60DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLISF	GEARCASE
E60DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSCB	GEARCASE
E60DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSDA	GEARCASE
E60DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSEE	GEARCASE
E60DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSUM	GEARCASE
E60DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLISF	GEARCASE
E60DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLISR	GEARCASE
E60DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLSCS	GEARCASE
E60DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLSEC	GEARCASE
E60DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLISF	GEARCASE
E60DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLISR	GEARCASE
E60DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLSCS	GEARCASE
E60DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLSEC	GEARCASE
E60DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60ECIA 1981	GEARCASE, ELECTRIC START
E60ECIA 1981	GEARCASE, ROPE START

E60ECIH 1981	GEARCASE, ELECTRIC START
E60ECIH 1981	GEARCASE, ROPE START
E60ECNM 1982	GEARCASE
E60ECSR 1980	GEARCASE, ELECTRIC START
E60ECSR 1980	GEARCASE, ROPE START
E60ECTB 1983	GEARCASE
E60ELCCR 1988	GEARCASE
E60ELCDS 1986	GEARCASE - 20" MODELS
E60ELCEA 1989	GEARCASE
E60ELCIA 1981	GEARCASE, ELECTRIC START
E60ELCIA 1981	GEARCASE, ROPE START
E60ELCIH 1981	GEARCASE, ELECTRIC START
E60ELCIH 1981	GEARCASE, ROPE START
E60ELCNM 1982	GEARCASE
E60ELCOD 1985	GEARCASE
E60ELCRE 1984	GEARCASE
E60ELCSR 1980	GEARCASE, ELECTRIC START
E60ELCSR 1980	GEARCASE, ROPE START
E60ELCTB 1983	GEARCASE
E60ELCUC 1987	GEARCASE - 15" TRANSOM
E60ELCUC 1987	GEARCASE - 20" MODELS
E60ELEDR 1996	GEARCASE
E60ELEIB 1991	GEARCASE
E60ELENE 1992	GEARCASE
E60ELEOC 1995	GEARCASE
E60ELERS 1994	GEARCASE
E60ELERV 1994	GEARCASE
E60ELES 1990	GEARCASE
E60ELET 1993	GEARCASE
E60ELEUA 1997	GEARCASE
E60TLCCR 1988	GEARCASE
E60TLCDS 1986	GEARCASE - 20" MODELS
E60TLCEA 1989	GEARCASE
E60TLCIA 1981	GEARCASE, ELECTRIC START
E60TLCIA 1981	GEARCASE, ROPE START

E60TLCIH 1981	GEARCASE, ELECTRIC START
E60TLCIH 1981	GEARCASE, ROPE START
E60TLCNM 1982	GEARCASE
E60TLCOD 1985	GEARCASE
E60TLCRE 1984	GEARCASE
E60TLCTB 1983	GEARCASE
E60TLCUC 1987	GEARCASE - 15" TRANSOM
E60TLCUC 1987	GEARCASE - 20" MODELS
E60TLECM 1998	GEARCASE
E60TLEDR 1996	GEARCASE
E60TLEIB 1991	GEARCASE
E60TLENE 1992	GEARCASE
E60TLEOC 1995	GEARCASE
E60TLERS 1994	GEARCASE
E60TLERV 1994	GEARCASE
E60TLESM 1990	GEARCASE
E60TLETD 1993	GEARCASE
E60TLEUA 1997	GEARCASE
E60TTLCCR 1988	GEARCASE
E60TTLCEA 1989	GEARCASE
E60TTLECM 1998	GEARCASE
E60TTLEDR 1996	GEARCASE
E60TTLEIB 1991	GEARCASE
E60TTLENE 1992	GEARCASE
E60TTLEOC 1995	GEARCASE
E60TTLERS 1994	GEARCASE
E60TTLERV 1994	GEARCASE
E60TTLESM 1990	GEARCASE
E60TTLETD 1993	GEARCASE
E60TTLEUA 1997	GEARCASE
E60WDRLSOS	GEARCASE
E60WDRLSOS - FR	07-1_BOÎTIER D'ENGRENAGES
E60WDREYSOS	GEARCASE
E60WDREYSOS - FR	07-1_BOÎTIER D'ENGRENAGES
E65RSLC 1995	GEARCASE

E65RSLM 1996	GEARCASE
E65RSLZ2 1997	GEARCASE
E65RWLCDR 1986	GEARCASE
E65RWLCOC 1985	GEARCASE
E65RWLCRS 1984	GEARCASE
E65TELCDR 1986	GEARCASE
E65TELCOC 1985	GEARCASE
E65TELCRS 1984	GEARCASE
E65WDRLISF	GEARCASE
E65WDRLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLISR	GEARCASE
E65WDRLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLSCS	GEARCASE
E65WDRLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLSEC	GEARCASE
E65WDRLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYISF	GEARCASE
E65WDRYISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYISR	GEARCASE
E65WDRYISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYSCS	GEARCASE
E65WDRYSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYSEC	GEARCASE
E65WDRYSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WELEES 1999	GEARCASE
E65WELSIR Commercial, elec start, 20 in shaft 2001	GEARCASE
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
E65WMLCDR 1986	GEARCASE
E65WMLCOC 1985	GEARCASE
E65WMLCUA 1987	GEARCASE
E65WMLEIB 1991	GEARCASE
E65WMLENE 1992	GEARCASE
E65WMLEOC 1995	GEARCASE
E65WMLERS 1994	GEARCASE
E65WMLESM 1990	GEARCASE

E65WMLETD 1993	GEARCASE
E65WMLZ 1989	GEARCASE
E65WRLEEO 1999	GEARCASE
E65WRLEES 1999	GEARCASE
E65WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
E65WRYEEO 1999	GEARCASE
E65WRYEES 1999	GEARCASE
E65WRYSIR commercial, rope start, 22.5 in shaft 2001	GEARCASE
E65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
E65WTLCOC 1985	GEARCASE
E65WTLCRS 1984	GEARCASE
E70ELCCA 1988	GEARCASE
E70ELCDC 1986	GEARCASE
E70ELCEM 1989	GEARCASE
E70ELCIH 1981	GEARCASE-15" TRANSOM
E70ELCIH 1981	GEARCASE - 20" TRANSOM
E70ELCIM 1981	GEARCASE-15" TRANSOM
E70ELCIM 1981	GEARCASE - 20" TRANSOM
E70ELCNB 1982	GEARCASE - 15" TRANSOM
E70ELCNB 1982	GEARCASE - 20" TRANSOM
E70ELCOS 1985	GEARCASE - 15" TRANSOM
E70ELCOS 1985	GEARCASE - 20" MODELS
E70ELCRD 1984	GEARCASE - 15" TRANSOM
E70ELCRD 1984	GEARCASE - 20" MODELS
E70ELCSA 1980	GEARCASE-15" TRANSOM
E70ELCSA 1980	GEARCASE-20" TRANSOM
E70ELCTE 1983	GEARCASE-15" TRANSOM
E70ELCTE 1983	GEARCASE - 20" TRANSOM
E70ELCUR 1987	GEARCASE
E70ELEIE 1991	GEARCASE
E70ELEND 1992	GEARCASE
E70ELEOR 1995	GEARCASE
E70ELERC 1994	GEARCASE
E70ELERV 1994	GEARCASE

E70ELESB 1990	GEARCASE
E70ELETS 1993	GEARCASE
E70TLCCA 1988	GEARCASE
E70TLCDC 1986	GEARCASE
E70TLCEM 1989	GEARCASE
E70TLCIM 1981	GEARCASE-15" TRANSOM
E70TLCIM 1981	GEARCASE - 20" TRANSOM
E70TLCNB 1982	GEARCASE - 15" TRANSOM
E70TLCNB 1982	GEARCASE - 20" TRANSOM
E70TLCOS 1985	GEARCASE - 15" TRANSOM
E70TLCOS 1985	GEARCASE - 20" MODELS
E70TLCRD 1984	GEARCASE - 15" TRANSOM
E70TLCRD 1984	GEARCASE - 20" MODELS
E70TLCTE 1983	GEARCASE-15" TRANSOM
E70TLCTE 1983	GEARCASE - 20" TRANSOM
E70TLCUR 1987	GEARCASE
E70TLECB 1998	GEARCASE
E70TLEDA 1996	GEARCASE
E70TLEIE 1991	GEARCASE
E70TLEND 1992	GEARCASE
E70TLEOR 1995	GEARCASE
E70TLERC 1994	GEARCASE
E70TLERV 1994	GEARCASE
E70TLESB 1990	GEARCASE
E70TLETS 1993	GEARCASE
E70TLEUM 1997	GEARCASE
E70TTLEIE 1991	GEARCASE
E70TTLEND 1992	GEARCASE
E70TTLEOR 1995	GEARCASE
E70TTLERC 1994	GEARCASE
E70TTLERV 1994	GEARCASE
E70TTLETS 1993	GEARCASE
E75ECDC 1986	GEARCASE - 20" MODELS
E75ECOS 1985	GEARCASE - 15" TRANSOM
E75ECOS 1985	GEARCASE - 20" MODELS

E75ECDR 1984	GEARCASE - 15" TRANSOM
E75ECDR 1984	GEARCASE - 20" MODELS
E75ECCR 1987	GEARCASE - 15" TRANSOM
E75ECCR 1987	GEARCASE - 20" MODELS
E75ELCRD 1984	GEARCASE - 15" TRANSOM
E75ELCRD 1984	GEARCASE - 20" MODELS
E75ERICI 1981	GEARCASE-15" TRANSOM
E75ERICI 1981	GEARCASE - 20" TRANSOM
E75ERICM 1981	GEARCASE-15" TRANSOM
E75ERICM 1981	GEARCASE - 20" TRANSOM
E75ERCNB 1982	GEARCASE - 15" TRANSOM
E75ERCNB 1982	GEARCASE - 20" TRANSOM
E75ERCSA 1980	GEARCASE-15" TRANSOM
E75ERCSA 1980	GEARCASE-20" TRANSOM
E75ERCTE 1983	GEARCASE-15" TRANSOM
E75ERCTE 1983	GEARCASE - 20" TRANSOM
E75ERLCI 1981	GEARCASE-15" TRANSOM
E75ERLCI 1981	GEARCASE - 20" TRANSOM
E75ERLCM 1981	GEARCASE-15" TRANSOM
E75ERLCM 1981	GEARCASE - 20" TRANSOM
E75ERLCNB 1982	GEARCASE - 15" TRANSOM
E75ERLCNB 1982	GEARCASE - 20" TRANSOM
E75ERLCSA 1980	GEARCASE-15" TRANSOM
E75ERLCSA 1980	GEARCASE-20" TRANSOM
E75ERLCTE 1983	GEARCASE-15" TRANSOM
E75ERLCTE 1983	GEARCASE - 20" TRANSOM
E75TLCRD 1984	GEARCASE - 15" TRANSOM
E75TLCRD 1984	GEARCASE - 20" MODELS
E75TRLCI 1981	GEARCASE-15" TRANSOM
E75TRLCI 1981	GEARCASE - 20" TRANSOM
E75TRLCM 1981	GEARCASE-15" TRANSOM
E75TRLCM 1981	GEARCASE - 20" TRANSOM
E75TRLCNB 1982	GEARCASE - 15" TRANSOM
E75TRLCNB 1982	GEARCASE - 20" TRANSOM
E75TRLCSA 1980	GEARCASE-15" TRANSOM

E75TRLCSA 1980	GEARCASE-20" TRANSOM
E75TRLCTE 1983	GEARCASE-15" TRANSOM
E75TRLCTE 1983	GEARCASE - 20" TRANSOM
E85MLCSA 1980	GEARCASE
E85STLCSA 1980	GEARCASE
E85STXCOSA 1980	GEARCASE
E85TTLEOR 1995	GEARCASE
E85TTLERC 1994	GEARCASE
E88MSLCUS 1987	GEARCASE
E90MLCIH 1981	GEARCASE
E90MLCIM 1981	GEARCASE
E90MLCNB 1982	GEARCASE
E90MLCOS 1985	GEARCASE
E90MLCRD 1984	GEARCASE
E90MLCTE 1983	GEARCASE
E90TLCIH 1981	GEARCASE
E90TLCIM 1981	GEARCASE
E90TLCNB 1982	GEARCASE
E90TLCOS 1985	GEARCASE
E90TLCRD 1984	GEARCASE
E90TLCTE 1983	GEARCASE
E90TXCIH 1981	GEARCASE
E90TXCIM 1981	GEARCASE
E90TXCNB 1982	GEARCASE
E90TXCOS 1985	GEARCASE
E90TXCRD 1984	GEARCASE
E90TXCTE 1983	GEARCASE
ELECTRICAL 1972	BOLT KIT
HE40REDS 1996	GEARCASE
HE40REUC 1997	GEARCASE
HE40RLEDS 1996	GEARCASE
HE40RLEUC 1997	GEARCASE
HE45RCLEDS 1996	GEARCASE
HE45RCLEUC 1997	GEARCASE
HE55RSLC 1997	GEARCASE

HE55RSLW 1996	GEARCASE
HE55WMLM 1996	GEARCASE
HE55WMLZ 1997	GEARCASE
HE70TXEDA 1996	GEARCASE
HE70TXEUM 1997	GEARCASE
HJ40REDS 1996	GEARCASE
HJ40REUC 1997	GEARCASE
HJ40RLEDS 1996	GEARCASE
HJ40RLEUC 1997	GEARCASE
HJ45RCLEDS 1996	GEARCASE
HJ45RCLEUC 1997	GEARCASE
HJ55RSLC 1997	GEARCASE
HJ55RSLW 1996	GEARCASE
HJ55WMLM 1996	GEARCASE
HJ55WMLZ 1997	GEARCASE
HJ70TXEDA 1996	GEARCASE
HJ70TXEUM 1997	GEARCASE
J100MLCSC 1980	GEARCASE
J100TRLCSC 1980	GEARCASE
J100TRXCSC 1980	GEARCASE
J115JKLEOC 1995	GEARCASE
J115JKLERS 1994	GEARCASE
J115MLCIH 1981	GEARCASE
J115MLCIM 1981	GEARCASE
J115MLCNB 1982	GEARCASE
J115MLCOS 1985	GEARCASE
J115MLCRD 1984	GEARCASE
J115MLCSA 1980	GEARCASE
J115MLCTE 1983	GEARCASE
J115TLCIH 1981	GEARCASE
J115TLCIM 1981	GEARCASE
J115TLCNB 1982	GEARCASE
J115TLCOS 1985	GEARCASE
J115TLCRD 1984	GEARCASE
J115TLCSA 1980	GEARCASE

J115TLCTE 1983	GEARCASE
J115TXCIH 1981	GEARCASE
J115TXCIM 1981	GEARCASE
J115TXCNB 1982	GEARCASE
J115TXCRD 1984	GEARCASE
J115TXCSA 1980	GEARCASE
J115TXCTE 1983	GEARCASE
J120TLAEM 1989	GEARCASE - 120TL & TX/140 TL
J120TLAIE 1991	GEARCASE - 120TL & TX/140 TL
J120TLAND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TLASB 1990	GEARCASE - 120TL & TX/140 TL
J120TLCCA 1988	GEARCASE - 120TL & TX/140 TL
J120TLCEM 1989	GEARCASE - 120TL & TX/140 TL
J120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
J120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TLESB 1990	GEARCASE - 120TL & TX/140 TL
J120TXCCA 1988	GEARCASE - 120TL & TX/140 TL
J120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
J120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
J120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TXESB 1990	GEARCASE - 120TL & TX/140 TL
J125ESXENR 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J125ESXESS 1990	GEARCASE - ESX MODELS ONLY
J125ESXW 1989	GEARCASE - ESX MODELS ONLY
J140CXCCS 1988	GEARCASE - 120TL & TX/140 TL
J140CXCEC 1989	GEARCASE - 120TL & TX/140 TL
J140CXEIA 1991	GEARCASE - 120TL & TX/140 TL
J140CXENM 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140CXESR 1990	GEARCASE - 120TL & TX/140 TL
J140MLCIH 1981	GEARCASE
J140MLCIM 1981	GEARCASE
J140MLCNB 1982	GEARCASE
J140MLCSA 1980	GEARCASE
J140MLCTE 1983	GEARCASE
J140TLAEB 1989	GEARCASE - 120TL & TX/140 TL

J140TLANS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TLASE 1990	GEARCASE - 120TL & TX/140 TL
J140TLCCM 1988	GEARCASE - 120TL & TX/140 TL
J140TLCEB 1989	GEARCASE - 120TL & TX/140 TL
J140TLCIH 1981	GEARCASE
J140TLCIM 1981	GEARCASE
J140TLCNB 1982	GEARCASE
J140TLCRD 1984	GEARCASE
J140TLCSA 1980	GEARCASE
J140TLCTE 1983	GEARCASE
J140TLEID 1991	GEARCASE - 120TL & TX/140 TL
J140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TLESE 1990	GEARCASE - 120TL & TX/140 TL
J140TXCCM 1988	GEARCASE - 120TL & TX/140 TL
J140TXCEB 1989	GEARCASE - 120TL & TX/140 TL
J140TXCIH 1981	GEARCASE
J140TXCIM 1981	GEARCASE
J140TXCNB 1982	GEARCASE
J140TXCRD 1984	GEARCASE
J140TXCSA 1980	GEARCASE
J140TXCTE 1983	GEARCASE
J140TXEID 1991	GEARCASE - 120TL & TX/140 TL
J140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TXESE 1990	GEARCASE - 120TL & TX/140 TL
J150STLCTE 1983	GEARCASE
J150TLCIA 1981	GEARCASE
J150TLCIH 1981	GEARCASE
J150TLCNM 1982	GEARCASE
J150TLCSF 1980	GEARCASE
J150TLCSR 1980	GEARCASE
J150TLCTB 1983	GEARCASE
J150TLCTE 1983	GEARCASE
J150TXCIA 1981	GEARCASE
J150TXCIH 1981	GEARCASE
J150TXCNM 1982	GEARCASE

J150TXCSF 1980	GEARCASE
J150TXCSR 1980	GEARCASE
J150TXCTB 1983	GEARCASE
J150TXCTE 1983	GEARCASE
J175TLCIH 1981	GEARCASE
J175TLCIM 1981	GEARCASE
J175TLCNB 1982	GEARCASE
J175TLCSA 1980	GEARCASE
J175TLCSF 1980	GEARCASE
J175TLCTD 1983	GEARCASE
J175TLCTE 1983	GEARCASE
J175TXCIH 1981	GEARCASE
J175TXCIM 1981	GEARCASE
J175TXCNB 1982	GEARCASE
J175TXCSA 1980	GEARCASE
J175TXCSF 1980	GEARCASE
J175TXCTD 1983	GEARCASE
J175TXCTE 1983	GEARCASE
J200TLCIH 1981	GEARCASE
J200TLCNE 1982	GEARCASE
J200TLCSF 1980	GEARCASE
J200TLCSM 1980	GEARCASE
J200TLCTD 1983	GEARCASE
J200TLCTS 1983	GEARCASE
J200TXCIB 1981	GEARCASE
J200TXCIH 1981	GEARCASE
J200TXCNE 1982	GEARCASE
J200TXCSF 1980	GEARCASE
J200TXCSM 1980	GEARCASE
J200TXCTD 1983	GEARCASE
J200TXCTS 1983	GEARCASE
J235STLCTS 1983	GEARCASE
J235TLCIB 1981	GEARCASE
J235TLCIH 1981	GEARCASE
J235TLCNE 1982	GEARCASE

J235TLCSM 1980	GEARCASE
J235TLCTD 1983	GEARCASE
J235TLCTS 1983	GEARCASE
J235TXCIB 1981	GEARCASE
J235TXCIH 1981	GEARCASE
J235TXCNE 1982	GEARCASE
J235TXCSM 1980	GEARCASE
J235TXCTD 1983	GEARCASE
J235TXCTS 1983	GEARCASE
J35AELCDE 1986	GEARCASE
J35AELCUD 1987	GEARCASE
J35ARLCDE 1986	GEARCASE
J35ARLCUD 1987	GEARCASE
J40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40AELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ARLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ATLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ECDE 1986	GEARCASE
J40ECEC 1989	GEARCASE
J40ECOB 1985	GEARCASE
J40ECRM 1984	GEARCASE
J40ECUD 1987	GEARCASE
J40EEIA 1991	GEARCASE
J40EENJ 1992	GEARCASE
J40EENM 1992	GEARCASE
J40EEOB 1995	GEARCASE
J40EERE 1994	GEARCASE
J40EESR 1990	GEARCASE
J40EETB 1993	GEARCASE
J40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT

J40ELCDE 1986	GEARCASE
J40ELCEC 1989	GEARCASE
J40ELCOB 1985	GEARCASE
J40ELCRM 1984	GEARCASE
J40ELCUD 1987	GEARCASE
J40ELECR 1998	GEARCASE
J40ELEDs 1996	GEARCASE
J40ELEIA 1991	GEARCASE
J40ELENJ 1992	GEARCASE
J40ELENM 1992	GEARCASE
J40ELEOD 1995	GEARCASE
J40ELERE 1994	GEARCASE
J40ELESR 1990	GEARCASE
J40ELETB 1993	GEARCASE
J40ELEUC 1997	GEARCASE
J40JPLEEC 1999	GEARCASE
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	GEARCASE
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J40JVLsIA jet drive,elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J40PLEEA 1999	GEARCASE
J40PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J40PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J40PLSOC	GEARCASE
J40PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSRS	GEARCASE
J40PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J40PLSTD	GEARCASE
J40PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40RCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40RCDE 1986	GEARCASE
J40RCEC 1989	GEARCASE

J40RCOB 1985	GEARCASE
J40RCRM 1984	GEARCASE
J40RCUD 1987	GEARCASE
J40RECR 1998	GEARCASE
J40REDS 1996	GEARCASE
J40REEA 1999	GEARCASE
J40REIA 1991	GEARCASE
J40RENM 1992	GEARCASE
J40REOD 1995	GEARCASE
J40RERE 1994	GEARCASE
J40RESR 1990	GEARCASE
J40RETB 1993	GEARCASE
J40REUC 1997	GEARCASE
J40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40RLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40RLCDE 1986	GEARCASE
J40RLCEC 1989	GEARCASE
J40RLCOB 1985	GEARCASE
J40RLCRM 1984	GEARCASE
J40RLCUD 1987	GEARCASE
J40RLECR 1998	GEARCASE
J40RLEDS 1996	GEARCASE
J40RLEEA 1999	GEARCASE
J40RLEIA 1991	GEARCASE
J40RLENM 1992	GEARCASE
J40RLEOD 1995	GEARCASE
J40RLERE 1994	GEARCASE
J40RLESR 1990	GEARCASE
J40RLETB 1993	GEARCASE
J40RLEUC 1997	GEARCASE
J40RLSIF rope start, 20 in shaft 2001	GEARCASE
J40RLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RLSOC	GEARCASE

J40RLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSRS	GEARCASE
J40RLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40RLSTD	GEARCASE
J40RLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSIF rope start, 15 in shaft 2001	GEARCASE
J40RSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RSOC	GEARCASE
J40RSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSRS	GEARCASE
J40RSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40RSTD	GEARCASE
J40RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TECDE 1986	GEARCASE
J40TECEC 1989	GEARCASE
J40TECOB 1985	GEARCASE
J40TECRM 1984	GEARCASE
J40TECUD 1987	GEARCASE
J40TEECR 1998	GEARCASE
J40TEEDS 1996	GEARCASE
J40TEEIA 1991	GEARCASE
J40TEENJ 1992	GEARCASE
J40TEENM 1992	GEARCASE
J40TEEOD 1995	GEARCASE
J40TEERE 1994	GEARCASE
J40TEESR 1990	GEARCASE
J40TEETB 1993	GEARCASE
J40TEEUC 1997	GEARCASE
J40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT

J40TELCDE 1986	GEARCASE
J40TELCEC 1989	GEARCASE
J40TELCOB 1985	GEARCASE
J40TELCRM 1984	GEARCASE
J40TELECR 1998	GEARCASE
J40TELEDS 1996	GEARCASE
J40TELEIA 1991	GEARCASE
J40TELENJ 1992	GEARCASE
J40TELENM 1992	GEARCASE
J40TELEOD 1995	GEARCASE
J40TELERE 1994	GEARCASE
J40TELESR 1990	GEARCASE
J40TELETB 1993	GEARCASE
J40TELEUC 1997	GEARCASE
J40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TLCDE 1986	GEARCASE
J40TLCEC 1989	GEARCASE
J40TLCUD 1987	GEARCASE
J40TLECR 1998	GEARCASE
J40TLEDS 1996	GEARCASE
J40TLEIA 1991	GEARCASE
J40TLENJ 1992	GEARCASE
J40TLENM 1992	GEARCASE
J40TLEOD 1995	GEARCASE
J40TLERE 1994	GEARCASE
J40TLESR 1990	GEARCASE
J40TLETB 1993	GEARCASE
J40TLETF 1993	GEARCASE
J40TLEUC 1997	GEARCASE
J40TPLEEA 1999	GEARCASE
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	GEARCASE
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TTLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT

J40TTLCEC 1989	GEARCASE
J40TTLECR 1998	GEARCASE
J40TTLEDS 1996	GEARCASE
J40TTLEIA 1991	GEARCASE
J40TTLENM 1992	GEARCASE
J40TTLEOD 1995	GEARCASE
J40TTLERE 1994	GEARCASE
J40TTLESR 1990	GEARCASE
J40TTLETB 1993	GEARCASE
J40TTLETF 1993	GEARCASE
J40TTLEUC 1997	GEARCASE
J40WREES 1999	GEARCASE
J40WRLEES 1999	GEARCASE
J40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40WRYEES 1999	GEARCASE
J40WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J45RCCDS 1986	GEARCASE
J45RCCUC 1987	GEARCASE
J45RCE 1989	GEARCASE
J45RCEIA 1991	GEARCASE
J45RCENM 1992	GEARCASE
J45RCEOD 1995	GEARCASE
J45RCERE 1994	GEARCASE
J45RCESR 1990	GEARCASE
J45RCETB 1993	GEARCASE
J45RCLCDS 1986	GEARCASE
J45RCLCUC 1987	GEARCASE
J45RCLE 1989	GEARCASE
J45RCLEDS 1996	GEARCASE
J45RCLEIA 1991	GEARCASE

J45RCLENM 1992	GEARCASE
J45RCLEOD 1995	GEARCASE
J45RCLERE 1994	GEARCASE
J45RCLESR 1990	GEARCASE
J45RCLETB 1993	GEARCASE
J45RCLEUC 1997	GEARCASE
J45WMLE 1989	GEARCASE
J45WMLEIA 1991	GEARCASE
J45WMLENM 1992	GEARCASE
J45WMLESR 1990	GEARCASE
J48ESLCCC 1988	GEARCASE
J48ESLCER 1989	GEARCASE
J48ESLCUS 1987	GEARCASE
J48ESLEDC 1996	GEARCASE
J48ESLEIM 1991	GEARCASE
J48ESLENB 1992	GEARCASE
J48ESLEOS 1995	GEARCASE
J48ESLERD 1994	GEARCASE
J48ESLESA 1990	GEARCASE
J48ESLETE 1993	GEARCASE
J50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50BECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50BECDE 1986	GEARCASE
J50BECEC 1989	GEARCASE
J50BECIC 1981	GEARCASE, ELECTRIC START
J50BECIC 1981	GEARCASE, ROPE START
J50BECNR 1982	GEARCASE
J50BECOB 1985	GEARCASE
J50BECRM 1984	GEARCASE
J50BECTA 1983	GEARCASE
J50BECUD 1987	GEARCASE
J50BEEIA 1991	GEARCASE
J50BEENJ 1992	GEARCASE
J50BEENM 1992	GEARCASE
J50BEEOD 1995	GEARCASE

J50BEERE 1994	GEARCASE
J50BEE SR 1990	GEARCASE
J50BEETB 1993	GEARCASE
J50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50BELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50BELCDE 1986	GEARCASE
J50BELCEC 1989	GEARCASE
J50BELCIC 1981	GEARCASE, ELECTRIC START
J50BELCIC 1981	GEARCASE, ROPE START
J50BELCNR 1982	GEARCASE
J50BELCOB 1985	GEARCASE
J50BELCRM 1984	GEARCASE
J50BELCTA 1983	GEARCASE
J50BELCUD 1987	GEARCASE
J50BELEIA 1991	GEARCASE
J50BELENJ 1992	GEARCASE
J50BELENM 1992	GEARCASE
J50BELEOD 1995	GEARCASE
J50BELE RE 1994	GEARCASE
J50BELESR 1990	GEARCASE
J50BELETB 1993	GEARCASE
J50DTLECA 1998	GEARCASE
J50DTLEDC 1996	GEARCASE
J50DTLEOS 1995	GEARCASE
J50DTLEUR 1997	GEARCASE
J50ECSR 1980	GEARCASE
J50ELCSR 1980	GEARCASE
J50ELED 1996	GEARCASE
J50ELEER 1999	GEARCASE
J50ELEOS 1995	GEARCASE
J50ELEUR 1997	GEARCASE
J50ELSIF elec start, 20 in shaft 2001	GEARCASE
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	GEARCASE
J50ESLECC 1998	GEARCASE
J50ESLEUR 1997	GEARCASE

J50JEDS 1996	GEARCASE
J50JEIA 1991	GEARCASE
J50JENJ 1992	GEARCASE
J50JENM 1992	GEARCASE
J50JEOD 1995	GEARCASE
J50JERE 1994	GEARCASE
J50JETB 1993	GEARCASE
J50JEUC 1997	GEARCASE
J50PLEEA 1999	GEARCASE
J50PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J50PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J50PLSOC	GEARCASE
J50PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSRS	GEARCASE
J50PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J50PLSTD	GEARCASE
J50PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50TELCDE 1986	GEARCASE
J50TELCEC 1989	GEARCASE
J50TELCOB 1985	GEARCASE
J50TELCRM 1984	GEARCASE
J50TELCCTA 1983	GEARCASE
J50TELCUD 1987	GEARCASE
J50TELEIA 1991	GEARCASE
J50TELENM 1992	GEARCASE
J50TELEOD 1995	GEARCASE
J50TELERE 1994	GEARCASE
J50TELESR 1990	GEARCASE
J50TELETB 1993	GEARCASE
J50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY

J50TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50TLCDE 1986	GEARCASE
J50TLCEC 1989	GEARCASE
J50TLCOB 1985	GEARCASE
J50TLCRM 1984	GEARCASE
J50TLCUD 1987	GEARCASE
J50TLECR 1998	GEARCASE
J50TLEDS 1996	GEARCASE
J50TLEIA 1991	GEARCASE
J50TLENJ 1992	GEARCASE
J50TLENM 1992	GEARCASE
J50TLEOD 1995	GEARCASE
J50TLERE 1994	GEARCASE
J50TLESR 1990	GEARCASE
J50TLETB 1993	GEARCASE
J50TLETF 1993	GEARCASE
J50TLEUC 1997	GEARCASE
J50TSLECC 1998	GEARCASE
J50TSLEUS 1997	GEARCASE
J50TTLECA 1998	GEARCASE
J50TTLEDC 1996	GEARCASE
J50TTLEOS 1995	GEARCASE
J50TTLEUR 1997	GEARCASE
J55APRL	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRL - FR	27-6_BOÎTIER D'ENGRENAGES & BOÎTIER DE ROTOR - Modèles APRL
J55APRLSOM	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSOM - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRA	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRA - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRG	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRG - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55MLSOR	GEARCASE (ML MODEL)
J55MLSOR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML

J55MLSRC	GEARCASE (ML MODEL)
J55MLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MLSRG	GEARCASE (ML MODEL)
J55MLSRG - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MRL	GEARCASE (ML MODEL)
J55MRL - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55RCIM 1981	GEARCASE, ELECTRIC START
J55RCIM 1981	GEARCASE, ROPE START
J55RLCIM 1981	GEARCASE, ELECTRIC START
J55RLCIM 1981	GEARCASE, ROPE START
J55RLCSA 1980	GEARCASE,ELECTRIC START
J55RLCSA 1980	GEARCASE,ROPE START
J55RSLC 1997	GEARCASE
J55RSLG 1995	GEARCASE
J55RSLN 1983	GEARCASE
J55RSLN-2 1983	GEARCASE
J55RSLW 1996	GEARCASE
J55RSN 1983	GEARCASE
J55RSN-2 1983	GEARCASE
J55RSYN 1983	GEARCASE
J55RSYN-2 1983	GEARCASE
J55RWLCDC 1986	GEARCASE
J55RWLCOS 1985	GEARCASE
J55RWLCRD 1984	GEARCASE
J55RWLCUC 1987	GEARCASE
J55RWLE 1989	GEARCASE
J55RWLEIA 1991	GEARCASE
J55RWLENM 1992	GEARCASE
J55RWLERE 1994	GEARCASE
J55RWLESR 1990	GEARCASE
J55RWLETB 1993	GEARCASE
J55WREES 1999	GEARCASE
J55WRLEES 1999	GEARCASE
J55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J55WRLSOE	GEARCASE

J55WRLSOE - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSRB	GEARCASE
J55WRLSRB - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSRG	GEARCASE
J55WRLSRG - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J55WRLSTM	GEARCASE
J55WRLSTM - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J55WRYEES 1999	GEARCASE
J55WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J55WRYSOB	GEARCASE
J55WRYSOB - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRYSRM	GEARCASE
J55WRYSRM - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J60ECIA 1981	GEARCASE, ELECTRIC START
J60ECIA 1981	GEARCASE, ROPE START
J60ECIH 1981	GEARCASE, ELECTRIC START
J60ECIH 1981	GEARCASE, ROPE START
J60ECNM 1982	GEARCASE
J60ECSR 1980	GEARCASE,ELECTRIC START
J60ECSR 1980	GEARCASE,ROPE START
J60ECTB 1983	GEARCASE
J60ELCCR 1988	GEARCASE
J60ELCDS 1986	GEARCASE - 20" MODELS
J60ELCEA 1989	GEARCASE
J60ELCIA 1981	GEARCASE, ELECTRIC START
J60ELCIA 1981	GEARCASE, ROPE START
J60ELCIH 1981	GEARCASE, ELECTRIC START
J60ELCIH 1981	GEARCASE, ROPE START
J60ELCNM 1982	GEARCASE
J60ELCOD 1985	GEARCASE

J60ELCRE 1984	GEARCASE
J60ELCSR 1980	GEARCASE,ELECTRIC START
J60ELCSR 1980	GEARCASE,ROPE START
J60ELCTB 1983	GEARCASE
J60ELCUC 1987	GEARCASE - 15" TRANSOM
J60ELCUC 1987	GEARCASE - 20" MODELS
J60ELEDR 1996	GEARCASE
J60ELEIB 1991	GEARCASE
J60ELENE 1992	GEARCASE
J60ELEOC 1995	GEARCASE
J60ELERS 1994	GEARCASE
J60ELERV 1994	GEARCASE
J60ELES 1990	GEARCASE
J60ELET 1993	GEARCASE
J60ELEUA 1997	GEARCASE
J60PLEEB 1999	GEARCASE
J60PLSID elec start, TNT, 20 in shaft 2001	GEARCASE
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J60TLCCR 1988	GEARCASE
J60TLCDS 1986	GEARCASE - 20" MODELS
J60TLCEA 1989	GEARCASE
J60TLCIA 1981	GEARCASE, ELECTRIC START
J60TLCIA 1981	GEARCASE, ROPE START
J60TLCIH 1981	GEARCASE, ELECTRIC START
J60TLCIH 1981	GEARCASE, ROPE START
J60TLCNM 1982	GEARCASE
J60TLCOD 1985	GEARCASE
J60TLCRE 1984	GEARCASE
J60TLCTB 1983	GEARCASE
J60TLCUC 1987	GEARCASE - 15" TRANSOM
J60TLCUC 1987	GEARCASE - 20" MODELS
J60TLECM 1998	GEARCASE
J60TLEDR 1996	GEARCASE
J60TLEIB 1991	GEARCASE
J60TLENE 1992	GEARCASE

J60TLEOC 1995	GEARCASE
J60TLERS 1994	GEARCASE
J60TLERV 1994	GEARCASE
J60TLESM 1990	GEARCASE
J60TLETD 1993	GEARCASE
J60TLEUA 1997	GEARCASE
J60TTLCCR 1988	GEARCASE
J60TTLCEA 1989	GEARCASE
J60TTLECM 1998	GEARCASE
J60TTLEDR 1996	GEARCASE
J60TTLEIB 1991	GEARCASE
J60TTLENE 1992	GEARCASE
J60TTLEOC 1995	GEARCASE
J60TTLERS 1994	GEARCASE
J60TTLERV 1994	GEARCASE
J60TTLESM 1990	GEARCASE
J60TTLETD 1993	GEARCASE
J60TTLEUA 1997	GEARCASE
J60VLSID elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J65RSLC 1995	GEARCASE
J65RSLM 1996	GEARCASE
J65RSLZ2 1997	GEARCASE
J65RWLCDR 1986	GEARCASE
J65RWLCOC 1985	GEARCASE
J65RWLCRS 1984	GEARCASE
J65TELCDR 1986	GEARCASE
J65TELCOC 1985	GEARCASE
J65TELCRS 1984	GEARCASE
J65WELEES 1999	GEARCASE
J65WELSIR Commercial, elec start, 20 in shaft 2001	GEARCASE
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
J65WMLCDR 1986	GEARCASE
J65WMLCOC 1985	GEARCASE
J65WMLCUA 1987	GEARCASE
J65WMLEIB 1991	GEARCASE

J65WMLENE 1992	GEARCASE
J65WMLEOC 1995	GEARCASE
J65WMLERS 1994	GEARCASE
J65WMLESM 1990	GEARCASE
J65WMLETD 1993	GEARCASE
J65WMLZ 1989	GEARCASE
J65WRLEEO 1999	GEARCASE
J65WRLEES 1999	GEARCASE
J65WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
J65WRYEEO 1999	GEARCASE
J65WRYEES 1999	GEARCASE
J65WRYSIR commercial, rope start, 22.5 in shaft 2001	GEARCASE
J65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
J65WTLCOC 1985	GEARCASE
J65WTLCRS 1984	GEARCASE
J70ELCCA 1988	GEARCASE
J70ELCDC 1986	GEARCASE
J70ELCEM 1989	GEARCASE
J70ELCIH 1981	GEARCASE-15" TRANSOM
J70ELCIH 1981	GEARCASE - 20" TRANSOM
J70ELCIM 1981	GEARCASE-15" TRANSOM
J70ELCIM 1981	GEARCASE - 20" TRANSOM
J70ELCNB 1982	GEARCASE - 15" TRANSOM
J70ELCNB 1982	GEARCASE - 20" TRANSOM
J70ELCOS 1985	GEARCASE - 15" TRANSOM
J70ELCOS 1985	GEARCASE - 20" MODELS
J70ELCRD 1984	GEARCASE - 15" TRANSOM
J70ELCRD 1984	GEARCASE - 20" MODELS
J70ELCSA 1980	GEARCASE-15" TRANSOM
J70ELCSA 1980	GEARCASE-20"TRANSOM
J70ELCTE 1983	GEARCASE-15" TRANSOM
J70ELCTE 1983	GEARCASE - 20" TRANSOM
J70ELCUR 1987	GEARCASE
J70ELEIE 1991	GEARCASE

J70ELEND 1992	GEARCASE
J70ELEOR 1995	GEARCASE
J70ELERC 1994	GEARCASE
J70ELERV 1994	GEARCASE
J70ELESB 1990	GEARCASE
J70ELET5 1993	GEARCASE
J70JLEOS 1995	GEARCASE
J70PLEEE 1999	GEARCASE
J70PLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J70TLCCA 1988	GEARCASE
J70TLCDC 1986	GEARCASE
J70TLCEM 1989	GEARCASE
J70TLCIM 1981	GEARCASE-15" TRANSOM
J70TLCIM 1981	GEARCASE - 20" TRANSOM
J70TLCNB 1982	GEARCASE - 15" TRANSOM
J70TLCNB 1982	GEARCASE - 20" TRANSOM
J70TLCOS 1985	GEARCASE - 15" TRANSOM
J70TLCOS 1985	GEARCASE - 20" MODELS
J70TLCRD 1984	GEARCASE - 15" TRANSOM
J70TLCRD 1984	GEARCASE - 20" MODELS
J70TLCTE 1983	GEARCASE-15" TRANSOM
J70TLCTE 1983	GEARCASE - 20" TRANSOM
J70TLCUR 1987	GEARCASE
J70TLECB 1998	GEARCASE
J70TLEDA 1996	GEARCASE
J70TLEIE 1991	GEARCASE
J70TLEND 1992	GEARCASE
J70TLEOR 1995	GEARCASE
J70TLERC 1994	GEARCASE
J70TLERV 1994	GEARCASE
J70TLESB 1990	GEARCASE
J70TLETS 1993	GEARCASE
J70TLEUM 1997	GEARCASE
J70TTLEIE 1991	GEARCASE

J70TTLEND 1992	GEARCASE
J70TTLEOR 1995	GEARCASE
J70TTLERC 1994	GEARCASE
J70TTLERV 1994	GEARCASE
J70TTLETS 1993	GEARCASE
J70VLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
J75ECDC 1986	GEARCASE - 20" MODELS
J75ECNB 1982	GEARCASE - 15" TRANSOM
J75ECNB 1982	GEARCASE - 20" TRANSOM
J75ECOS 1985	GEARCASE - 15" TRANSOM
J75ECOS 1985	GEARCASE - 20" MODELS
J75ECDR 1984	GEARCASE - 15" TRANSOM
J75ECDR 1984	GEARCASE - 20" MODELS
J75ECTE 1983	GEARCASE-15" TRANSOM
J75ECTE 1983	GEARCASE - 20" TRANSOM
J75ECUR 1987	GEARCASE - 15" TRANSOM
J75ECUR 1987	GEARCASE - 20" MODELS
J75ELCNB 1982	GEARCASE - 15" TRANSOM
J75ELCNB 1982	GEARCASE - 20" TRANSOM
J75ELCRD 1984	GEARCASE - 15" TRANSOM
J75ELCRD 1984	GEARCASE - 20" MODELS
J75ELCTE 1983	GEARCASE-15" TRANSOM
J75ELCTE 1983	GEARCASE - 20" TRANSOM
J75ERCIH 1981	GEARCASE-15" TRANSOM
J75ERCIH 1981	GEARCASE - 20" TRANSOM
J75ERCIM 1981	GEARCASE-15" TRANSOM
J75ERCIM 1981	GEARCASE - 20" TRANSOM
J75ERCSA 1980	GEARCASE-15" TRANSOM
J75ERCSA 1980	GEARCASE-20"TRANSOM
J75ERLCIH 1981	GEARCASE-15" TRANSOM
J75ERLCIH 1981	GEARCASE - 20" TRANSOM
J75ERLCIM 1981	GEARCASE-15" TRANSOM
J75ERLCIM 1981	GEARCASE - 20" TRANSOM
J75ERLCSA 1980	GEARCASE-15" TRANSOM
J75ERLCSA 1980	GEARCASE-20"TRANSOM

J75TELCIM 1981	GEARCASE-15" TRANSOM
J75TELCIM 1981	GEARCASE - 20" TRANSOM
J75TLCNB 1982	GEARCASE - 15" TRANSOM
J75TLCNB 1982	GEARCASE - 20" TRANSOM
J75TLCRD 1984	GEARCASE - 15" TRANSOM
J75TLCRD 1984	GEARCASE - 20" MODELS
J75TLCTE 1983	GEARCASE-15" TRANSOM
J75TLCTE 1983	GEARCASE - 20" TRANSOM
J75TRLCIH 1981	GEARCASE-15" TRANSOM
J75TRLCIH 1981	GEARCASE - 20" TRANSOM
J75TRLCSA 1980	GEARCASE-15" TRANSOM
J75TRLCSA 1980	GEARCASE-20"TRANSOM
J85MLCSA 1980	GEARCASE
J85TLCSA 1980	GEARCASE
J85TTLEOR 1995	GEARCASE
J85TTLERC 1994	GEARCASE
J85TXCSA 1980	GEARCASE
J88MSLCUS 1987	GEARCASE
J90MLCIH 1981	GEARCASE
J90MLCIM 1981	GEARCASE
J90MLCNB 1982	GEARCASE
J90MLCOS 1985	GEARCASE
J90MLCRD 1984	GEARCASE
J90MLCTE 1983	GEARCASE
J90TLCIH 1981	GEARCASE
J90TLCIM 1981	GEARCASE
J90TLCNB 1982	GEARCASE
J90TLCOS 1985	GEARCASE
J90TLCRD 1984	GEARCASE
J90TLCTE 1983	GEARCASE
J90TXCIH 1981	GEARCASE
J90TXCIM 1981	GEARCASE
J90TXCNB 1982	GEARCASE
J90TXCOS 1985	GEARCASE
J90TXCRD 1984	GEARCASE

J90TXCTE 1983	GEARCASE
M55RWLR 1988	GEARCASE
N65WMLM 1988	GEARCASE
R45RCLR 1988	GEARCASE
R45RCR 1988	GEARCASE
R55RWLR 1988	GEARCASE
RJ50ELSIF elec start, TNT, 20 in shaft 2001	GEARCASE
RJ70PLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
S45RCLR 1988	GEARCASE
S45RCR 1988	GEARCASE
SE40RPB 1997	GEARCASE
SE40RPH 1996	GEARCASE
SE40RPLB 1997	GEARCASE
SE40RPLH 1996	GEARCASE
SE40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPYB 1997	GEARCASE
SE40RPYH 1996	GEARCASE
SE40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RSLD 1997	GEARCASE
SE40RSLR 1998	GEARCASE
SE40RSLZ 1996	GEARCASE
SE45RSLB 1997	GEARCASE
SE45RSLH 1996	GEARCASE
SE50TLEDS 1996	GEARCASE
SE55RSC 1997	GEARCASE
SE55RSLC 1997	GEARCASE
SE55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSLW 1996	GEARCASE
SE55RSM2 1998	GEARCASE -- T & M MODELS ONLY

SE55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSW 1996	GEARCASE
SE55RSYC 1997	GEARCASE
SE55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSYW 1996	GEARCASE
SE65RSLD 1998	GEARCASE
SE65RSLM 1996	GEARCASE
SE65RSLZ2 1997	GEARCASE
SE65RSYD 1998	GEARCASE
SE65RSYM 1996	GEARCASE
SE65RSYZ2 1997	GEARCASE
SE65WMLD 1998	GEARCASE
SE65WMLM 1996	GEARCASE
SE65WMLZ2 1997	GEARCASE
SE65WMYD 1998	GEARCASE
SE65WMYM 1996	GEARCASE
SE65WMYZ2 1997	GEARCASE
SJ40EEDS 1996	GEARCASE
SJ40REDS 1996	GEARCASE
SJ40RLEDs 1996	GEARCASE
SJ40RPB 1997	GEARCASE
SJ40RPH 1996	GEARCASE
SJ40RPLB 1997	GEARCASE
SJ40RPLH 1996	GEARCASE
SJ40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RPYB 1997	GEARCASE
SJ40RPYH 1996	GEARCASE
SJ40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RSLD 1997	GEARCASE
SJ40RSLR 1998	GEARCASE

SJ40RSLZ 1996	GEARCASE
SJ45RSLB 1997	GEARCASE
SJ45RSLH 1996	GEARCASE
SJ55RSC 1997	GEARCASE
SJ55RSLC 1997	GEARCASE
SJ55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSLW 1996	GEARCASE
SJ55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSW 1996	GEARCASE
SJ55RSYC 1997	GEARCASE
SJ55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSYW 1996	GEARCASE
SJ60TLEDR 1996	GEARCASE
SJ65RSLD 1998	GEARCASE
SJ65RSLM 1996	GEARCASE
SJ65RSLZ2 1997	GEARCASE
SJ65RSYD 1998	GEARCASE
SJ65RSYM 1996	GEARCASE
SJ65RSYZ2 1997	GEARCASE
SJ65WMLD 1998	GEARCASE
SJ65WMLM 1996	GEARCASE
SJ65WMLZ2 1997	GEARCASE
SJ65WMYD 1998	GEARCASE
SJ65WMYM 1996	GEARCASE
SJ65WMYZ2 1997	GEARCASE
SJ70TLEDA 1996	GEARCASE
T65WMLM 1988	GEARCASE
TE120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
TE40ELCEC 1989	GEARCASE
TE40ELEIA 1991	GEARCASE
TE40ELENJ 1992	GEARCASE
TE40ELENM 1992	GEARCASE

TE40ELESR 1990	GEARCASE
TE40ELETB 1993	GEARCASE
TE40TELESF 1990	GEARCASE
TE40TELESR 1990	GEARCASE
TE48ESLETE 1993	GEARCASE
TE50TLCEC 1989	GEARCASE
TE50TLESF 1989	GEARCASE
TE50TLESF 1990	GEARCASE
TE50TLESR 1990	GEARCASE
TE60TLCEA 1989	GEARCASE
TE60TLEIB 1991	GEARCASE
TE60TLENE 1992	GEARCASE
TE60TLESF 1989	GEARCASE
TE60TLESF 1990	GEARCASE
TE60TLESM 1990	GEARCASE
TE60TLETD 1993	GEARCASE
TE70TLCEM 1989	GEARCASE
TE70TLESB 1990	GEARCASE
TE70TLESF 1989	GEARCASE
TE70TLESF 1990	GEARCASE
TJ120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
TJ40ELCEC 1989	GEARCASE
TJ40ELEIA 1991	GEARCASE
TJ40ELENJ 1992	GEARCASE
TJ40ELENM 1992	GEARCASE
TJ40ELESF 1990	GEARCASE
TJ40ELESR 1990	GEARCASE
TJ40ELETB 1993	GEARCASE
TJ40TELESF 1990	GEARCASE
TJ40TELESR 1990	GEARCASE
TJ48ESLETE 1993	GEARCASE
TJ50TLCEC 1989	GEARCASE
TJ50TLESF 1989	GEARCASE
TJ50TLESF 1990	GEARCASE
TJ50TLESR 1990	GEARCASE

TJ60TLCEA 1989	GEARCASE
TJ60TLEIB 1991	GEARCASE
TJ60TLENE 1992	GEARCASE
TJ60TLESF 1989	GEARCASE
TJ60TLESF 1990	GEARCASE
TJ60TLESM 1990	GEARCASE
TJ60TLETD 1993	GEARCASE
TJ70TLCEM 1989	GEARCASE
TJ70TLESB 1990	GEARCASE
TJ70TLESF 1989	GEARCASE
TJ70TLESF 1990	GEARCASE
TR-10R 1968	GEARCASE GROUP
TR-10S 1968	GEARCASE GROUP
TRL-10R 1968	GEARCASE GROUP
TRL-10S 1968	GEARCASE GROUP
VE120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
VE120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE120TLESB 1990	GEARCASE - 120TL & TX/140 TL
VE120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
VE120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE120TXESB 1990	GEARCASE - 120TL & TX/140 TL
VE140TLEID 1991	GEARCASE - 120TL & TX/140 TL
VE140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE140TLESE 1990	GEARCASE - 120TL & TX/140 TL
VE140TXEID 1991	GEARCASE - 120TL & TX/140 TL
VE140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE140TXESE 1990	GEARCASE - 120TL & TX/140 TL
VE40EEIA 1991	GEARCASE
VE40EENJ 1992	GEARCASE
VE40EENM 1992	GEARCASE
VE40EESR 1990	GEARCASE
VE40EETB 1993	GEARCASE
VE40ELEIA 1991	GEARCASE
VE40ELENJ 1992	GEARCASE
VE40ELENM 1992	GEARCASE

VE40ELESR 1990	GEARCASE
VE40ELETB 1993	GEARCASE
VE40TELEIA 1991	GEARCASE
VE40TELENJ 1992	GEARCASE
VE40TELENM 1992	GEARCASE
VE40TELESR 1990	GEARCASE
VE40TELETB 1993	GEARCASE
VE40TLEIA 1991	GEARCASE
VE40TLENJ 1992	GEARCASE
VE40TLENM 1992	GEARCASE
VE40TLESR 1990	GEARCASE
VE40TLETB 1993	GEARCASE
VE40TLETF 1993	GEARCASE
VE48ESLCCC 1988	GEARCASE
VE48ESLCER 1989	GEARCASE
VE48ESLENB 1992	GEARCASE
VE48ESLESA 1990	GEARCASE
VE48ESLETE 1993	GEARCASE
VE50BEEIA 1991	GEARCASE
VE50BEENJ 1992	GEARCASE
VE50BEENM 1992	GEARCASE
VE50BEESR 1990	GEARCASE
VE50BEETB 1993	GEARCASE
VE50BELEIA 1991	GEARCASE
VE50BELENJ 1992	GEARCASE
VE50BELENM 1992	GEARCASE
VE50BELESR 1990	GEARCASE
VE50BELETB 1993	GEARCASE
VE50TELENM 1992	GEARCASE
VE50TLEIA 1991	GEARCASE
VE50TLENJ 1992	GEARCASE
VE50TLENM 1992	GEARCASE
VE50TLESR 1990	GEARCASE
VE50TLETB 1993	GEARCASE
VE50TLETF 1993	GEARCASE

VE60ELEIB 1991	GEARCASE
VE60ELENE 1992	GEARCASE
VE60ELESM 1990	GEARCASE
VE60ELETD 1993	GEARCASE
VE60TLEIB 1991	GEARCASE
VE60TLENE 1992	GEARCASE
VE60TLESM 1990	GEARCASE
VE70ELEIE 1991	GEARCASE
VE70ELEND 1992	GEARCASE
VE70ELESB 1990	GEARCASE
VE70ELET S 1993	GEARCASE
VE70TLEIE 1991	GEARCASE
VE70TLEND 1992	GEARCASE
VE70TLESB 1990	GEARCASE
VE70TLET S 1993	GEARCASE
VJ120TLAIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TLAND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TLASB 1990	GEARCASE - 120TL & TX/140 TL
VJ120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TLESB 1990	GEARCASE - 120TL & TX/140 TL
VJ120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TXESB 1990	GEARCASE - 120TL & TX/140 TL
VJ140TLAID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TLANS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TLASE 1990	GEARCASE - 120TL & TX/140 TL
VJ140TLEID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TLESE 1990	GEARCASE - 120TL & TX/140 TL
VJ140TXEID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TXESE 1990	GEARCASE - 120TL & TX/140 TL
VJ40EEIA 1991	GEARCASE
VJ40EENJ 1992	GEARCASE

VJ40EENM 1992	GEARCASE
VJ40EESR 1990	GEARCASE
VJ40EETB 1993	GEARCASE
VJ40ELEIA 1991	GEARCASE
VJ40ELENJ 1992	GEARCASE
VJ40ELENM 1992	GEARCASE
VJ40ELESR 1990	GEARCASE
VJ40ELETB 1993	GEARCASE
VJ40TELEIA 1991	GEARCASE
VJ40TELENJ 1992	GEARCASE
VJ40TELENM 1992	GEARCASE
VJ40TELESR 1990	GEARCASE
VJ40TELETB 1993	GEARCASE
VJ40TLEIA 1991	GEARCASE
VJ40TLENJ 1992	GEARCASE
VJ40TLENM 1992	GEARCASE
VJ40TLESR 1990	GEARCASE
VJ40TLETB 1993	GEARCASE
VJ40TLETF 1993	GEARCASE
VJ48ESLCCC 1988	GEARCASE
VJ48ESLCER 1989	GEARCASE
VJ48ESLENB 1992	GEARCASE
VJ48ESLESA 1990	GEARCASE
VJ48ESLETE 1993	GEARCASE
VJ50BEEIA 1991	GEARCASE
VJ50BEENJ 1992	GEARCASE
VJ50BEENM 1992	GEARCASE
VJ50BEESR 1990	GEARCASE
VJ50BEETB 1993	GEARCASE
VJ50BELEIA 1991	GEARCASE
VJ50BELENJ 1992	GEARCASE
VJ50BELENM 1992	GEARCASE
VJ50BELESR 1990	GEARCASE
VJ50BELETB 1993	GEARCASE
VJ50TELENM 1992	GEARCASE

VJ50TLEIA 1991	GEARCASE
VJ50TLENJ 1992	GEARCASE
VJ50TLENM 1992	GEARCASE
VJ50TLESR 1990	GEARCASE
VJ50TLETB 1993	GEARCASE
VJ50TLETF 1993	GEARCASE
VJ60ELEIB 1991	GEARCASE
VJ60ELENE 1992	GEARCASE
VJ60ELES M 1990	GEARCASE
VJ60ELET D 1993	GEARCASE
VJ60TLEIB 1991	GEARCASE
VJ60TLENE 1992	GEARCASE
VJ60TLES M 1990	GEARCASE
VJ70ELEIE 1991	GEARCASE
VJ70ELEND 1992	GEARCASE
VJ70ELES B 1990	GEARCASE
VJ70ELET S 1993	GEARCASE
VJ70TLEIE 1991	GEARCASE
VJ70TLEND 1992	GEARCASE
VJ70TLES B 1990	GEARCASE
VJ70TLET S 1993	GEARCASE
X50ESLECC 1998	GEARCASE