

Where Used: Part Number 0314731

Model Name	Diagram
100193A 1971	GEARCASE
100193C 1971	GEARCASE
100293R 1972	GEARCASE
100990S 1979	GEARCASE
100993S 1979	GEARCASE
100999S 1979	GEARCASE
100ESL71A 1971	GEARCASE
100ESL71C 1971	GEARCASE
100ESL72R 1972	GEARCASE
100ML79S 1979	GEARCASE
100TLR79S 1979	GEARCASE
100TXLR79S 1979	GEARCASE
115083D 1970	GEARCASE GROUP
115393M 1973	GEARCASE
115493B 1974	GEARCASE GROUP
115593 1975	GEARCASE
115693D 1976	GEARCASE
115693G 1976	GEARCASE
115699D 1976	GEARCASE
115699G 1976	GEARCASE
115790S 1977	GEARCASE
115793S 1977	GEARCASE
115799S 1977	GEARCASE
115890C 1978	GEARCASE
115893C 1978	GEARCASE
115899C 1978	GEARCASE
115983E 1969	GEARCASE GROUP
115983S 1969	GEARCASE GROUP
115990R 1979	GEARCASE
115993R 1979	GEARCASE
115999R 1979	GEARCASE
115EL77S 1977	GEARCASE
115ESL69E 1969	GEARCASE GROUP

115ESL69S 1969	GEARCASE GROUP
115ESL70D 1970	GEARCASE GROUP
115ESL73M 1973	GEARCASE
115ESL74B 1974	GEARCASE
115ESL75E 1975	GEARCASE
115ETL74B 1974	GEARCASE
115ETL75E 1975	GEARCASE
115ETL77 1977	GEARCASE
115ETZ78C 1978	GEARCASE
115ML78C 1978	GEARCASE
115ML79R 1979	GEARCASE
115TL79R 1979	GEARCASE
115TXL77S 1977	GEARCASE
115TXL78C 1978	GEARCASE
115TXL79R 1979	GEARCASE
120FTHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
120FTHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
125183C 1971	GEARCASE
125283R 1972	GEARCASE
125ESL71C 1971	GEARCASE
125ESL72R 1972	GEARCASE
135383M 1973	GEARCASE
135443B 1974	GEARCASE
135483B 1974	GEARCASE
135489B 1974	GEARCASE
135543E 1975	GEARCASE
135583E 1975	GEARCASE
135589E 1975	GEARCASE
135643D 1976	GEARCASE
135643G 1976	GEARCASE
135683D 1976	GEARCASE
135683G 1976	GEARCASE
135ESL73M 1973	GEARCASE
135ESL74B 1974	GEARCASE
135ESL75E 1975	GEARCASE

135ETL74B 1974	GEARCASE
135ETL75E 1975	GEARCASE
140740S 1977	GEARCASE
140743S 1977	GEARCASE
140783S 1977	GEARCASE
140840C 1978	GEARCASE
140843C 1978	GEARCASE
140883C 1978	GEARCASE
140940R 1979	GEARCASE
140943R 1979	GEARCASE
140983R 1979	GEARCASE
140FTHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140FTHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140ML77S 1977	GEARCASE
140ML78C 1978	GEARCASE
140ML79R 1979	GEARCASE
140SPHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140SPHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140STHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140STHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140TL77S 1977	GEARCASE
140TL78C 1978	GEARCASE
140TL79R 1979	GEARCASE
140TX78C 1978	GEARCASE
140TXL77S 1977	GEARCASE
140TXL79R 1979	GEARCASE
150840S 1978	GEARCASE
150849S 1978	GEARCASE
150940C 1979	GEARCASE
150949C 1979	GEARCASE
150SHLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
150SHLERC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
150SLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
150SLERC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

150TL78S 1978	GEARCASE
150TL79C 1979	GEARCASE
150TXL78S 1978	GEARCASE
150TXL79C 1979	GEARCASE
170SPMCCIF 1981	LOWER GEARCASE GROUP
170SPMCCIS 1981	LOWER GEARCASE GROUP
170SPMRCIF 1981	LOWER GEARCASE GROUP
170SPMRCIS 1981	LOWER GEARCASE GROUP
170STMCCIF 1981	LOWER GEARCASE GROUP
170STMCCIS 1981	LOWER GEARCASE GROUP
170STMRCIF 1981	LOWER GEARCASE GROUP
170STMRCIS 1981	LOWER GEARCASE GROUP
175740S 1977	GEARCASE
175749S 1977	GEARCASE
175840C 1978	GEARCASE
175840S 1978	GEARCASE
175940R 1979	GEARCASE
175949R 1979	GEARCASE
175TL77S 1977	GEARCASE
175TL78C 1978	GEARCASE
175TL79R 1979	GEARCASE
175TX78C 1978	GEARCASE
175TXL77S 1977	GEARCASE
175TXL79R 1979	GEARCASE
200490A 1979	GEARCASE
200640S 1976	GEARCASE
200649S 1976	GEARCASE
200740C 1977	GEARCASE
200749C 1977	GEARCASE
200840R 1978	GEARCASE
200849R 1978	GEARCASE
200940A 1979	GEARCASE
200949A 1979	GEARCASE
200FTHRCIF 1981	LOWER GEARCASE GROUP
200FTHRCIS 1981	LOWER GEARCASE GROUP

200SPHCIF 1981	LOWER GEARCASE GROUP
200SPHCIS 1981	LOWER GEARCASE GROUP
200STHCIF 1981	LOWER GEARCASE GROUP
200STHCIS 1981	LOWER GEARCASE GROUP
200TL76S 1976	GEARCASE
200TL77C 1977	GEARCASE
200TL78R 1978	GEARCASE
200TL79A 1979	GEARCASE
200TX78R 1978	GEARCASE
200TXL76S 1976	GEARCASE
200TXL77C 1977	GEARCASE
200TXL79A 1979	GEARCASE
230FTHRCIF 1981	LOWER GEARCASE GROUP
230FTHRCIS 1981	LOWER GEARCASE GROUP
230SPHCIF 1981	LOWER GEARCASE GROUP
230SPHCIS 1981	LOWER GEARCASE GROUP
230STHCIF 1981	LOWER GEARCASE GROUP
230STHCIS 1981	LOWER GEARCASE GROUP
232AMFTC 1987	LOWER GEARCASE
232AMRGDE 1988	LOWER GEARCASE
232AMRGDP 1988	LOWER GEARCASE
232APFTC 1987	LOWER GEARCASE
232APRGDE 1988	LOWER GEARCASE
232APRGDP 1988	LOWER GEARCASE
232APSRC 1987	LOWER GEARCASE
232BMRMED 1989	LOWER GEARCASE
232BMRMEF 1989	LOWER GEARCASE
232BMRPWS 1990	LOWER GEARCASE
232BPRMED 1989	LOWER GEARCASE
232BPRMEF 1989	LOWER GEARCASE
232BPRPWS 1990	LOWER GEARCASE
235840R 1978	GEARCASE
235849R 1978	GEARCASE
235940A 1979	GEARCASE
235949A 1979	GEARCASE

235TL70A 1979	GEARCASE
235TL78R 1978	GEARCASE
235TX78R 1978	GEARCASE
235TXL79A 1979	GEARCASE
252AMKWB 1986	LOWER GEARCASE
252APKWB 1986	LOWER GEARCASE
252FTHRCNC 1982	LOWER GEARCASE GROUP
252FTHRCNG 1982	LOWER GEARCASE GROUP
252FTHRCOM 1985	LOWER GEARCASE GROUP
252FTHRCRA 1984	LOWER GEARCASE GROUP
252FTHRCTR 1983	LOWER GEARCASE GROUP
252STHRCNC 1982	LOWER GEARCASE GROUP
252STHRCOM 1985	LOWER GEARCASE GROUP
252STHRCRA 1984	LOWER GEARCASE GROUP
252STHRCTR 1983	LOWER GEARCASE GROUP
260FTHRCIF 1981	LOWER GEARCASE GROUP
260FTHRCIS 1981	LOWER GEARCASE GROUP
260SPHRCIF 1981	LOWER GEARCASE GROUP
260SPHRCIS 1981	LOWER GEARCASE GROUP
260STHRCIF 1981	LOWER GEARCASE GROUP
260STHRCIS 1981	LOWER GEARCASE GROUP
262AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
262APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302AMARJ 1987	LOWER GEARCASE
302AMARY 1987	LOWER GEARCASE
302AMFTC 1987	LOWER GEARCASE
302AMKWB 1986	LOWER GEARCASE
302AMRGDP 1988	LOWER GEARCASE
302AMRMED 1989	LOWER GEARCASE
302AMRPWC 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302APARY 1987	LOWER GEARCASE
302APFTC 1987	LOWER GEARCASE
302APKWB 1986	LOWER GEARCASE
302APRGDP 1988	LOWER GEARCASE
302APRMED 1989	LOWER GEARCASE

302APRPWC 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302APSRC 1987	LOWER GEARCASE
302ARSRY 1987	LOWER GEARCASE
302BMRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
302BPRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BPRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMLPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
302CPRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
302FPHRCNC 1982	LOWER GEARCASE GROUP
302FPHRCNG 1982	LOWER GEARCASE GROUP
302FPHRCTR 1983	LOWER GEARCASE GROUP
302FTHRCNC 1982	LOWER GEARCASE GROUP
302FTHRCNG 1982	LOWER GEARCASE GROUP
302FTHRCOM 1985	LOWER GEARCASE GROUP
302FTHRCRA 1984	LOWER GEARCASE GROUP
302FTHRCTR 1983	LOWER GEARCASE GROUP
302SPHCNC 1982	LOWER GEARCASE GROUP
302SPHCNG 1982	LOWER GEARCASE GROUP

302SPHRCOM 1985	LOWER GEARCASE GROUP
302SPHRCRA 1984	LOWER GEARCASE GROUP
302SPHRCTR 1983	LOWER GEARCASE GROUP
302STHRCNC 1982	LOWER GEARCASE GROUP
302STHRCNG 1982	LOWER GEARCASE GROUP
302STHRCOM 1985	LOWER GEARCASE GROUP
302STHRCRA 1984	LOWER GEARCASE GROUP
302STHRCTR 1983	LOWER GEARCASE GROUP
350AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
350APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
382FTMRCOM 1985	LOWER GEARCASE GROUP
382FTMRCRA 1984	LOWER GEARCASE GROUP
382FTMRCRJ 1984	LOWER GEARCASE GROUP
382FTMRCTR 1983	LOWER GEARCASE GROUP
382SPMCCNC 1982	LOWER GEARCASE GROUP
382SPMCCTR 1983	LOWER GEARCASE GROUP
382SPMRCNC 1982	LOWER GEARCASE GROUP
382SPMRCOM 1985	LOWER GEARCASE GROUP
382SPMRCRA 1984	LOWER GEARCASE GROUP
382SPMRCRJ 1984	LOWER GEARCASE GROUP
382SPMRCTR 1983	LOWER GEARCASE GROUP
382STMCCNC 1982	LOWER GEARCASE GROUP
382STMCCCTR 1983	LOWER GEARCASE GROUP
382STMRCNC 1982	LOWER GEARCASE GROUP
382STMRCOM 1985	LOWER GEARCASE GROUP
382STMRCTR 1983	LOWER GEARCASE GROUP
384FTMRCOM 1985	LOWER GEARCASE GROUP
384FTMRCRA 1984	LOWER GEARCASE GROUP
384FTMRCRJ 1984	LOWER GEARCASE GROUP
384FTMRCTR 1983	LOWER GEARCASE GROUP
384SPMCCNC 1982	LOWER GEARCASE GROUP
384SPMCCTR 1983	LOWER GEARCASE GROUP
384SPMRCNC 1982	LOWER GEARCASE GROUP
384SPMRCOM 1985	LOWER GEARCASE GROUP
384SPMRCRA 1984	LOWER GEARCASE GROUP

384SPMRCRJ 1984	LOWER GEARCASE GROUP
384SPMRCTR 1983	LOWER GEARCASE GROUP
384STMCCNC 1982	LOWER GEARCASE GROUP
384STMCCTR 1983	LOWER GEARCASE GROUP
384STMRCNC 1982	LOWER GEARCASE GROUP
384STMRCOM 1985	LOWER GEARCASE GROUP
384STMRCRA 1984	LOWER GEARCASE GROUP
384STMRCRJ 1984	LOWER GEARCASE GROUP
384STMRCTR 1983	LOWER GEARCASE GROUP
384STNRCNC 1982	LOWER GEARCASE GROUP
432AMARY 1987	LOWER GEARCASE
432AMFTC 1987	LOWER GEARCASE
432AMKWB 1986	LOWER GEARCASE
432AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432AMLMD 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432AMWXS 1986	LOWER GEARCASE
432APARY 1987	LOWER GEARCASE
432APFTC 1987	LOWER GEARCASE
432APKWB 1986	LOWER GEARCASE
432APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APLJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APLRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
432APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRGDE 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
432APSRC 1987	LOWER GEARCASE
432APSRY 1987	LOWER GEARCASE
432APWXS 1986	LOWER GEARCASE

432FTMRCOM 1985	LOWER GEARCASE GROUP
432SPMRCOM 1985	LOWER GEARCASE GROUP
432STMRCOM 1985	LOWER GEARCASE GROUP
434AMARY 1987	LOWER GEARCASE
434AMFTC 1987	LOWER GEARCASE
434AMKWB 1986	LOWER GEARCASE
434AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434AMWXS 1986	LOWER GEARCASE
434APARY 1987	LOWER GEARCASE
434APFTC 1987	LOWER GEARCASE
434APKWB 1986	LOWER GEARCASE
434APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APLJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APLRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
434APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
434APSRC 1987	LOWER GEARCASE
434APSRV 1987	LOWER GEARCASE
434APWXS 1986	LOWER GEARCASE
434FTMRCOM 1985	LOWER GEARCASE GROUP
434SPMRCOM 1985	LOWER GEARCASE GROUP
434STMRCOM 1985	LOWER GEARCASE GROUP
460AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
460APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APLAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION

502APLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APLRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502FTHRCOK 1985	LOWER GEARCASE GROUP
502FTHRCOM 1985	LOWER GEARCASE GROUP
502FTHRCRA 1984	LOWER GEARCASE GROUP
502FTHRCTR 1983	LOWER GEARCASE GROUP
502SPHCCNC 1982	LOWER GEARCASE GROUP
502SPHCCNG 1982	LOWER GEARCASE GROUP
502SPHCCTR 1983	LOWER GEARCASE GROUP
502SPHCNC 1982	LOWER GEARCASE GROUP
502SPHCNG 1982	LOWER GEARCASE GROUP
502SPHCOK 1985	LOWER GEARCASE GROUP
502SPHRCOM 1985	LOWER GEARCASE GROUP
502SPHCRA 1984	LOWER GEARCASE GROUP
502SPHRCTR 1983	LOWER GEARCASE GROUP
502SPMCCNC 1982	LOWER GEARCASE GROUP
502SPMCCNG 1982	LOWER GEARCASE GROUP
502SPMCCTR 1983	LOWER GEARCASE GROUP
502SPMRCNC 1982	LOWER GEARCASE GROUP
502SPMRCNG 1982	LOWER GEARCASE GROUP
502SPMRCTR 1983	LOWER GEARCASE GROUP
502SPNCCNC 1982	LOWER GEARCASE GROUP

502SPNRCNC 1982	LOWER GEARCASE GROUP
502SPNRCNG 1982	LOWER GEARCASE GROUP
502STHCCNC 1982	LOWER GEARCASE GROUP
502STHCCNG 1982	LOWER GEARCASE GROUP
502STHCCTR 1983	LOWER GEARCASE GROUP
502STHCNC 1982	LOWER GEARCASE GROUP
502STHCNG 1982	LOWER GEARCASE GROUP
502STHCOK 1985	LOWER GEARCASE GROUP
502STHRCOM 1985	LOWER GEARCASE GROUP
502STHCRA 1984	LOWER GEARCASE GROUP
502STHRCTR 1983	LOWER GEARCASE GROUP
502STMCCNC 1982	LOWER GEARCASE GROUP
502STMCCNG 1982	LOWER GEARCASE GROUP
502STMCCTR 1983	LOWER GEARCASE GROUP
502STMRCNC 1982	LOWER GEARCASE GROUP
502STMRCNG 1982	LOWER GEARCASE GROUP
502STMRCTR 1983	LOWER GEARCASE GROUP
504AMARY 1987	LOWER GEARCASE
504AMFTC 1987	LOWER GEARCASE
504AMKWB 1986	LOWER GEARCASE
504AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
504AMWXS 1986	LOWER GEARCASE
504APARY 1987	LOWER GEARCASE
504APFTC 1987	LOWER GEARCASE
504APKWB 1986	LOWER GEARCASE
504APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
504APWXS 1986	LOWER GEARCASE
504FTHRCOK 1985	LOWER GEARCASE GROUP
504FTHRCOM 1985	LOWER GEARCASE GROUP
504FTHRCRA 1984	LOWER GEARCASE GROUP
504FTHRCTR 1983	LOWER GEARCASE GROUP
504SPHCCNC 1982	LOWER GEARCASE GROUP
504SPHCCNG 1982	LOWER GEARCASE GROUP
504SPHCCTR 1983	LOWER GEARCASE GROUP
504SPHCNC 1982	LOWER GEARCASE GROUP

504SPHRCNG 1982	LOWER GEARCASE GROUP
504SPHRCOK 1985	LOWER GEARCASE GROUP
504SPHRCOM 1985	LOWER GEARCASE GROUP
504SPHRCRA 1984	LOWER GEARCASE GROUP
504SPHRCTR 1983	LOWER GEARCASE GROUP
504SPMCCNC 1982	LOWER GEARCASE GROUP
504SPMCCNG 1982	LOWER GEARCASE GROUP
504SPMCCTR 1983	LOWER GEARCASE GROUP
504SPMRCNC 1982	LOWER GEARCASE GROUP
504SPMRCNG 1982	LOWER GEARCASE GROUP
504SPMRCTR 1983	LOWER GEARCASE GROUP
504STHCCNC 1982	LOWER GEARCASE GROUP
504STHCCNG 1982	LOWER GEARCASE GROUP
504STHCCTR 1983	LOWER GEARCASE GROUP
504STHRCNC 1982	LOWER GEARCASE GROUP
504STHRCNG 1982	LOWER GEARCASE GROUP
504STHRCOK 1985	LOWER GEARCASE GROUP
504STHRCOM 1985	LOWER GEARCASE GROUP
504STHRCRA 1984	LOWER GEARCASE GROUP
504STHRCTR 1983	LOWER GEARCASE GROUP
504STMCCNG 1982	LOWER GEARCASE GROUP
504STMCCCTR 1983	LOWER GEARCASE GROUP
504STMRCNC 1982	LOWER GEARCASE GROUP
504STMRCNG 1982	LOWER GEARCASE GROUP
504STMRCTR 1983	LOWER GEARCASE GROUP
504STNCCNC 1982	LOWER GEARCASE GROUP
50FAPLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
50FAPLJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
50FAPRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
50FAPRJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574AMFTC 1987	LOWER GEARCASE
574AMKWB 1986	LOWER GEARCASE
574AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION

574AMWXS 1986	LOWER GEARCASE
574APARY 1987	LOWER GEARCASE
574APFTC 1987	LOWER GEARCASE
574APKWB 1986	LOWER GEARCASE
574APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APLRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APSRC 1987	LOWER GEARCASE
574APWXS 1986	LOWER GEARCASE
574BMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574BPRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574FTHRCOK 1985	LOWER GEARCASE GROUP
574FTHRCOM 1985	LOWER GEARCASE GROUP
574FTHRCRA 1984	LOWER GEARCASE GROUP
574SPHCCNC 1982	LOWER GEARCASE GROUP
574SPHCCNG 1982	LOWER GEARCASE GROUP
574SPHCCTR 1983	LOWER GEARCASE GROUP
574SPHRCNC 1982	LOWER GEARCASE GROUP
574SPHRCNG 1982	LOWER GEARCASE GROUP
574SPHRCOK 1985	LOWER GEARCASE GROUP
574SPHRCOM 1985	LOWER GEARCASE GROUP
574SPHRCRA 1984	LOWER GEARCASE GROUP
574SPHRCTR 1983	LOWER GEARCASE GROUP
574SPMCCNC 1982	LOWER GEARCASE GROUP
574SPMCCNG 1982	LOWER GEARCASE GROUP
574SPMCCTR 1983	LOWER GEARCASE GROUP
574SPMRCNC 1982	LOWER GEARCASE GROUP
574SPMRCNG 1982	LOWER GEARCASE GROUP
574SPMRCTR 1983	LOWER GEARCASE GROUP
574STHCCNC 1982	LOWER GEARCASE GROUP
574STHCCNG 1982	LOWER GEARCASE GROUP

574STHCCTR 1983	LOWER GEARCASE GROUP
574STHRCNC 1982	LOWER GEARCASE GROUP
574STHRCNG 1982	LOWER GEARCASE GROUP
574STHRCOK 1985	LOWER GEARCASE GROUP
574STHRCOM 1985	LOWER GEARCASE GROUP
574STHRCRA 1984	LOWER GEARCASE GROUP
574STHRCTR 1983	LOWER GEARCASE GROUP
574STMCCNC 1982	LOWER GEARCASE GROUP
574STMCCNG 1982	LOWER GEARCASE GROUP
574STMCCCTR 1983	LOWER GEARCASE GROUP
574STMRCMC 1982	LOWER GEARCASE GROUP
574STMRCMG 1982	LOWER GEARCASE GROUP
574STMRCNC 1982	LOWER GEARCASE GROUP
574STMRCNG 1982	LOWER GEARCASE GROUP
574STMRCTR 1983	LOWER GEARCASE GROUP
584AMLMD 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584AML PWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APL AMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APL AMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APL JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APL RGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR AMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR AMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR MD 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR PWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR RGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPL JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPL JVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPR JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPR JVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
754APFTC 1987	LOWER GEARCASE
754APSRC 1987	LOWER GEARCASE
754BMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
754BPFTC 1987	LOWER GEARCASE

754BPRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
754BPSRC 1987	LOWER GEARCASE
85093B 1970	GEARCASE GROUP
85093D 1970	GEARCASE GROUP
85193A 1971	GEARCASE
85193H 1971	GEARCASE
85293R 1972	GEARCASE
85393M 1973	GEARCASE
85493B 1974	GEARCASE
85593E 1975	GEARCASE
85693D 1976	GEARCASE
85693G 1976	GEARCASE
85699G 1976	GEARCASE
85790S 1977	GEARCASE
85793S 1977	GEARCASE
85799S 1977	GEARCASE
85890C 1978	GEARCASE
85895C 1978	GEARCASE
85899C 1978	GEARCASE
85990R 1979	GEARCASE
85993E 1969	GEARCASE GROUP
85993M 1969	GEARCASE GROUP
85993S 1969	GEARCASE GROUP
85995R 1979	GEARCASE
85999R 1979	GEARCASE
85EL76D 1976	GEARCASE
85EL76G 1976	GEARCASE
85EL77S 1977	GEARCASE
85ESL69E 1969	GEARCASE GROUP
85ESL69M 1969	GEARCASE GROUP
85ESL69S 1969	GEARCASE GROUP
85ESL70B 1970	GEARCASE GROUP
85ESL70D 1970	GEARCASE GROUP
85ESL71A 1971	GEARCASE
85ESL71H 1971	GEARCASE

85ESL72R 1972	GEARCASE
85ESL73M 1973	GEARCASE
85ESL74B 1974	GEARCASE
85ESL75E 1975	GEARCASE
85ETLR76D 1976	GEARCASE
85ETLR76G 1976	GEARCASE
85ETLR77S 1977	GEARCASE
85ETLR78C 1978	GEARCASE
85ML78C 1978	GEARCASE
85ML79R 1979	GEARCASE
85TL79R 1979	GEARCASE
85TXL79R 1979	GEARCASE
85TXLR77S 1977	GEARCASE
85TXLR78C 1978	GEARCASE
990242C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990242C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990242D 1978	LOWER GEARCASE
990242H 1978	LOWER GEARCASE
990242H1 1978	LOWER GEARCASE
990242S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990242S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990243C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990243C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990243D 1978	LOWER GEARCASE
990243H 1978	LOWER GEARCASE
990243H1 1978	LOWER GEARCASE
990243S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990243S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990244C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990244C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990244D 1978	LOWER GEARCASE
990244H 1978	LOWER GEARCASE
990244H1 1978	LOWER GEARCASE
990244P 1978	LOWER GEARCASE
990244S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE

990244S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990245C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990245C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990245D 1978	LOWER GEARCASE
990245H 1978	LOWER GEARCASE
990245H1 1978	LOWER GEARCASE
990245S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990245S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990250D 1978	LOWER GEARCASE GROUP
990250H 1978	LOWER GEARCASE GROUP
990250J 1978	LOWER GEARCASE GROUP
990250N 1978	LOWER GEARCASE GROUP
990250P 1978	LOWER GEARCASE GROUP
990250U 1978	LOWER GEARCASE GROUP
990251D 1978	LOWER GEARCASE GROUP
990251H 1978	LOWER GEARCASE GROUP
990251J 1978	LOWER GEARCASE GROUP
990251N 1978	LOWER GEARCASE GROUP
990251S 1979	LOWER GEARCASE GROUP
990251U 1978	LOWER GEARCASE GROUP
990252C 1980	LOWER GEARCASE GROUP
990252D 1978	LOWER GEARCASE GROUP
990252H 1978	LOWER GEARCASE GROUP
990252J 1978	LOWER GEARCASE GROUP
990252K 1980	LOWER GEARCASE GROUP
990252S 1979	LOWER GEARCASE GROUP
990252S1 1979	LOWER GEARCASE GROUP
990253C 1980	LOWER GEARCASE GROUP
990253D 1978	LOWER GEARCASE GROUP
990253H 1978	LOWER GEARCASE GROUP
990253J 1978	LOWER GEARCASE GROUP
990253K 1980	LOWER GEARCASE GROUP
990253S 1979	LOWER GEARCASE GROUP
990253S1 1979	LOWER GEARCASE GROUP
990254C 1980	LOWER GEARCASE GROUP

990254D 1978	LOWER GEARCASE GROUP
990254H 1978	LOWER GEARCASE GROUP
990254J 1978	LOWER GEARCASE GROUP
990254K 1980	LOWER GEARCASE GROUP
990254S 1979	LOWER GEARCASE GROUP
990254S1 1979	LOWER GEARCASE GROUP
990254V 1979	LOWER GEARCASE GROUP
990255C 1980	LOWER GEARCASE GROUP
990255D 1978	LOWER GEARCASE GROUP
990255H 1978	LOWER GEARCASE GROUP
990255J 1978	LOWER GEARCASE GROUP
990255K 1980	LOWER GEARCASE GROUP
990255S 1979	LOWER GEARCASE GROUP
990255S1 1979	LOWER GEARCASE GROUP
990255V 1979	LOWER GEARCASE GROUP
990256C 1980	LOWER GEARCASE GROUP
990256K 1980	LOWER GEARCASE GROUP
990256S 1979	LOWER GEARCASE GROUP
990256S1 1979	LOWER GEARCASE GROUP
990257C 1980	LOWER GEARCASE GROUP
990257K 1980	LOWER GEARCASE GROUP
990257S 1979	LOWER GEARCASE GROUP
990257S1 1979	LOWER GEARCASE GROUP
990260C 1980	LOWER GEARCASE GROUP
990260K 1980	LOWER GEARCASE GROUP
990260S 1979	LOWER GEARCASE GROUP
990260S1 1979	LOWER GEARCASE GROUP
990260U 1980	LOWER GEARCASE GROUP
990261C 1980	LOWER GEARCASE GROUP
990261K 1980	LOWER GEARCASE GROUP
990261S 1979	LOWER GEARCASE GROUP
990261S1 1979	LOWER GEARCASE GROUP
990261U 1980	LOWER GEARCASE GROUP
990262C 1980	LOWER GEARCASE GROUP
990262K 1980	LOWER GEARCASE GROUP

990262S 1979	LOWER GEARCASE GROUP
990262S1 1979	LOWER GEARCASE GROUP
990262U 1980	LOWER GEARCASE GROUP
990266C 1980	LOWER GEARCASE GROUP
990266K 1980	LOWER GEARCASE GROUP
990266S 1979	LOWER GEARCASE GROUP
990266S1 1979	LOWER GEARCASE GROUP
990267C 1980	LOWER GEARCASE GROUP
990267K 1980	LOWER GEARCASE GROUP
990267S 1979	LOWER GEARCASE GROUP
990267S1 1979	LOWER GEARCASE GROUP
A115DGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115DGXAFG	07-1_GEARCASE, O-Type
A115DPXAFG	07-1_GEARCASE, O-Type
A115DSLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafH	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafI	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafK	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafL	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GHXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GHXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GHXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GNLAFG	07-1_GEARCASE, O-Type
A115SHlafH	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHlafI	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHlafK	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHlafL	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SHXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SHXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SHXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SNLAFG	07-1_GEARCASE, O-Type
BE115ELEDR 1996	GEARCASE - 20 IN. MODELS
BE115ELEDR 1996	GEARCASE - 25 IN. MODELS

BE115ELEUA 1997	GEARCASE - 20 IN. MODELS
BE115ELEUA 1997	GEARCASE - 25 IN. MODELS
BE115ELEUC 1997	GEARCASE - 20 IN. MODELS
BE115ELEUC 1997	GEARCASE - 25 IN. MODELS
BE115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE115GLEDR 1996	GEARCASE - 20 IN. MODELS
BE115GLEDR 1996	GEARCASE - 25 IN. MODELS
BE115GLEUA 1997	GEARCASE - 20 IN. MODELS
BE115GLEUA 1997	GEARCASE - 25 IN. MODELS
BE115GLEUC 1997	GEARCASE - 20 IN. MODELS
BE115GLEUC 1997	GEARCASE - 25 IN. MODELS
BE115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE115SXEDR 1996	GEARCASE - 20 IN. MODELS
BE115SXEDR 1996	GEARCASE - 25 IN. MODELS
BE115SXEUA 1997	GEARCASE - 20 IN. MODELS
BE115SXEUA 1997	GEARCASE - 25 IN. MODELS
BE115SXEUC 1997	GEARCASE - 20 IN. MODELS
BE115SXEUC 1997	GEARCASE - 25 IN. MODELS
BE115TLEDA 1996	GEARCASE
BE130TLECE 1998	GEARCASE
BE130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
BE130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
BE150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS

BE150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150XEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150XEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150XEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150XEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175XEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

BE175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE200CXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200CXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE200TXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS

BE200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225CXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE225CXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225CXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225SLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225SLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE225SLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225SLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225SLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225SLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225TXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE225TXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225TXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE250CXECB 1998	GEARCASE -- STANDARD ROTATION
BE250CXEDA 1996	GEARCASE - STANDARD ROTATION
BE250CXEUM 1997	GEARCASE - STANDARD ROTATION
BE250TXECB 1998	GEARCASE -- STANDARD ROTATION

BE250TXEDA 1996	GEARCASE - STANDARD ROTATION
BE250TXEUM 1997	GEARCASE - STANDARD ROTATION
BE90ELEDR 1996	GEARCASE - 20 IN. MODELS
BE90ELEDR 1996	GEARCASE - 25 IN. MODELS
BE90ELEUA 1997	GEARCASE - 20 IN. MODELS
BE90ELEUA 1997	GEARCASE - 25 IN. MODELS
BE90ELEUC 1997	GEARCASE - 20 IN. MODELS
BE90ELEUC 1997	GEARCASE - 25 IN. MODELS
BE90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE90SLEDR 1996	GEARCASE - 20 IN. MODELS
BE90SLEDR 1996	GEARCASE - 25 IN. MODELS
BE90SLEUA 1997	GEARCASE - 20 IN. MODELS
BE90SLEUA 1997	GEARCASE - 25 IN. MODELS
BE90SLEUC 1997	GEARCASE - 20 IN. MODELS
BE90SLEUC 1997	GEARCASE - 25 IN. MODELS
BE90SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE90SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE90SXEUUA 1997	GEARCASE - 20 IN. MODELS
BE90SXEUUA 1997	GEARCASE - 25 IN. MODELS
BE90SXEUUC 1997	GEARCASE - 20 IN. MODELS
BE90SXEUUC 1997	GEARCASE - 25 IN. MODELS
BE90TLEDA 1996	GEARCASE
BJ115ELEDR 1996	GEARCASE - 20 IN. MODELS
BJ115ELEDR 1996	GEARCASE - 25 IN. MODELS
BJ115ELEUA 1997	GEARCASE - 20 IN. MODELS
BJ115ELEUA 1997	GEARCASE - 25 IN. MODELS
BJ115ELEUC 1997	GEARCASE - 20 IN. MODELS
BJ115ELEUC 1997	GEARCASE - 25 IN. MODELS
BJ115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ115GLEDR 1996	GEARCASE - 20 IN. MODELS
BJ115GLEDR 1996	GEARCASE - 25 IN. MODELS
BJ115GLEUA 1997	GEARCASE - 20 IN. MODELS
BJ115GLEUA 1997	GEARCASE - 25 IN. MODELS

BJ115GLEUC 1997	GEARCASE - 20 IN. MODELS
BJ115GLEUC 1997	GEARCASE - 25 IN. MODELS
BJ115PLEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ115PLEEM 1999	GEARCASE -- 90 & 115 PX MODELS
BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ115PXEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ115PXEEM 1999	GEARCASE -- 90 & 115 PX MODELS
BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ115SXEDR 1996	GEARCASE - 20 IN. MODELS
BJ115SXEDR 1996	GEARCASE - 25 IN. MODELS
BJ115SXEUA 1997	GEARCASE - 20 IN. MODELS
BJ115SXEUA 1997	GEARCASE - 25 IN. MODELS
BJ115SXEUC 1997	GEARCASE - 20 IN. MODELS
BJ115SXEUC 1997	GEARCASE - 25 IN. MODELS
BJ115TLEDA 1996	GEARCASE
BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ130PLEED 1999	GEARCASE
BJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
BJ130PXEED 1999	GEARCASE
BJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
BJ130TLECE 1998	GEARCASE
BJ130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
BJ130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
BJ135PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ135VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE
BJ150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS

BJ150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150ELEDDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150ELEDDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

BJ150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
BJ175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS

BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
BJ175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BJ200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BJ200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS

BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BJ200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225CXEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225CXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS

BJ225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ250CXECB 1998	GEARCASE -- STANDARD ROTATION
BJ250CXEDA 1996	GEARCASE - STANDARD ROTATION
BJ250CXEUM 1997	GEARCASE - STANDARD ROTATION
BJ250TXECB 1998	GEARCASE -- STANDARD ROTATION
BJ250TXEDA 1996	GEARCASE - STANDARD ROTATION
BJ250TXEUM 1997	GEARCASE - STANDARD ROTATION

BJ90ELED R 1996	GEARCASE - 20 IN. MODELS
BJ90ELED R 1996	GEARCASE - 25 IN. MODELS
BJ90ELEUA 1997	GEARCASE - 20 IN. MODELS
BJ90ELEUA 1997	GEARCASE - 25 IN. MODELS
BJ90ELEUC 1997	GEARCASE - 20 IN. MODELS
BJ90ELEUC 1997	GEARCASE - 25 IN. MODELS
BJ90PLEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ90PLEEB 1999	GEARCASE -- 90 & 115 PX MODELS
BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ90PXEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ90PXEEB 1999	GEARCASE -- 90 & 115 PX MODELS
BJ90PXSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ90PXSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ90SLED R 1996	GEARCASE - 20 IN. MODELS
BJ90SLED R 1996	GEARCASE - 25 IN. MODELS
BJ90SLEUA 1997	GEARCASE - 20 IN. MODELS
BJ90SLEUA 1997	GEARCASE - 25 IN. MODELS
BJ90SLEUC 1997	GEARCASE - 20 IN. MODELS
BJ90SLEUC 1997	GEARCASE - 25 IN. MODELS
BJ90SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ90SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ90SXEU A 1997	GEARCASE - 20 IN. MODELS
BJ90SXEU A 1997	GEARCASE - 25 IN. MODELS
BJ90SXEU C 1997	GEARCASE - 20 IN. MODELS
BJ90SXEU C 1997	GEARCASE - 25 IN. MODELS
BJ90TLEDA 1996	GEARCASE
BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS

BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
C155WTLM 1988	GEARCASE
C155WTXM 1988	GEARCASE
CE275TLCDC 1986	GEARCASE
CE275TLCOS 1985	GEARCASE
CE275TXCDC 1986	GEARCASE
CE275TXCOS 1985	GEARCASE
CE300TLCDC 1986	GEARCASE
CE300TLCOS 1985	GEARCASE
CE300TXCDC 1986	GEARCASE
CE300TXCOS 1985	GEARCASE
CJ275TLCDC 1986	GEARCASE
CJ275TLCOS 1985	GEARCASE
CJ275TXCDC 1986	GEARCASE
CJ275TXCOS 1985	GEARCASE
CJ300TLCDC 1986	GEARCASE
CJ300TLCOS 1985	GEARCASE
CJ300TXCDC 1986	GEARCASE
CJ300TXCOS 1985	GEARCASE
D100WTLM 1988	GEARCASE
D100WTXM 1988	GEARCASE
E100FPLSOC	GEARCASE - FPL, FSL MODELS
E100FPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E100FPLSRS	GEARCASE - FPL, FSL MODELS
E100FPLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E100FSLSOC	GEARCASE - FPL, FSL MODELS
E100FSLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E100FSLSRS	GEARCASE - FPL, FSL MODELS
E100FSLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E100MLCSC 1980	GEARCASE
E100STLCCA 1988	GEARCASE
E100STLCEM 1989	GEARCASE
E100STLEIE 1991	GEARCASE
E100STLEND 1992	GEARCASE

E100STLERC 1994	GEARCASE
E100STLESB 1990	GEARCASE
E100STLETS 1993	GEARCASE
E100TLCSC 1980	GEARCASE
E100TXCSC 1980	GEARCASE
E100WMLCDR 1986	GEARCASE
E100WMLCOC 1985	GEARCASE
E100WMLCRS 1984	GEARCASE
E100WPLEEC 1999	GEARCASE
E100WPLSIF commercial, elec start, 20 in shaft 2001	GEARCASE
E100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
E100WPXEEC 1999	GEARCASE
E100WPXSIF commercial, elec start, 25 in shaft 2001	GEARCASE
E100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
E100WQLECS 1998	GEARCASE -- 100WQL MODELS
E100WQLECS 1998	GEARCASE -- 100WQX MODELS
E100WQXECS 1998	GEARCASE -- 100WQL MODELS
E100WQXECS 1998	GEARCASE -- 100WQX MODELS
E100WTLCDR 1986	GEARCASE
E100WTLCOG 1985	GEARCASE
E100WTLCRS 1984	GEARCASE
E100WTLCUA 1987	GEARCASE
E100WTLEDR 1996	GEARCASE
E100WTLEIB 1991	GEARCASE
E100WTLENE 1992	GEARCASE
E100WTLEOC 1995	GEARCASE
E100WTLERS 1994	GEARCASE
E100WTLESM 1990	GEARCASE EARLY PRODUCTION
E100WTLESM 1990	GEARCASE LATE PRODUCTION
E100WTLETD 1993	GEARCASE
E100WTLEUA 1997	GEARCASE
E100WTLZ 1989	GEARCASE
E100WTXCDR 1986	GEARCASE
E100WTXCUA 1987	GEARCASE
E100WTXEDR 1996	GEARCASE

E100WTXEIB 1991	GEARCASE
E100WTXENE 1992	GEARCASE
E100WTXEOC 1995	GEARCASE
E100WTXERS 1994	GEARCASE
E100WTXESM 1990	GEARCASE EARLY PRODUCTION
E100WTXESM 1990	GEARCASE LATE PRODUCTION
E100WTXETD 1993	GEARCASE
E100WTXEUA 1997	GEARCASE
E100WTXZ 1989	GEARCASE
E105WELEEN 1999	GEARCASE
E105WELEES 1999	GEARCASE
E105WELSIF commercial, elec start, 20 in shaft 2001	GEARCASE
E105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
E105WPLEES 1999	GEARCASE
E105WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
E105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
E105WPXEES 1999	GEARCASE
E105WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
E105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
E105WRLEES 1999	GEARCASE
E105WRLSIF commercial, rope start, 20 in shaft 2001	GEARCASE
E105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
E105WRYEES 1999	GEARCASE
E105WRYISIF commercial, rope start, 22.5 in shaft 2001	GEARCASE
E105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
E110MLCCA 1988	GEARCASE
E110MLCDC 1986	GEARCASE
E110MLCEM 1989	GEARCASE
E110MLCUR 1987	GEARCASE
E110TLCCA 1988	GEARCASE
E110TLCDC 1986	GEARCASE
E110TLCDF 1986	GEARCASE
E110TLCEM 1989	GEARCASE
E110TLCUR 1987	GEARCASE
E110TXCCA 1988	GEARCASE

E110TXCEM 1989	GEARCASE
E110TXCUR 1987	GEARCASE
E112TSLEDR 1996	GEARCASE
E112TSLEOC 1995	GEARCASE
E112TSLERS 1994	GEARCASE
E112TSXEDR 1996	GEARCASE
E112TSXEOC 1995	GEARCASE
E112TSXERS 1994	GEARCASE
E115DBXAAA	07-1_GEARCASE, O-Type
E115DBXAAB	07-1_GEARCASE, O-Type
E115DBXABA	07-1_GEARCASE, O-Type
E115DBXAFA	07-1_GEARCASE, O-Type
E115DBXAFB	07-1_GEARCASE, O-Type
E115DBXIIB	GEARCASE, O-Type
E115DBXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXINE	GEARCASE, O-Type
E115DBXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXISF	GEARCASE
E115DBXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXISM	GEARCASE
E115DBXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSCR	GEARCASE
E115DBXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSEF	GEARCASE
E115DBXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSUC	GEARCASE
E115DBXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFH	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFI	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFK	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGXAFB	07-1_GEARCASE, O-Type

E115DGXAFF	07-1_GEARCASE, O-Type
E115DGXAFG	07-1_GEARCASE, O-Type
E115DGXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DHLAAA	07-1_GEARCASE, S2-Type
E115DHLAAB	07-1_GEARCASE, S2-Type
E115DHLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DHLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DHLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DHLIIR	GEARCASE, S2-Type
E115DHLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLINA	GEARCASE, S2-Type
E115DHLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLISC	GEARCASE
E115DHLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLISF	GEARCASE
E115DHLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLSES	GEARCASE
E115DHLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHXAAA	07-1_GEARCASE, O-Type
E115DHXAAB	07-1_GEARCASE, O-Type
E115DHXABA	07-1_GEARCASE, O-Type
E115DHXAFA	07-1_GEARCASE, O-Type
E115DHXAFB	07-1_GEARCASE, O-Type
E115DHXAFF	07-1_GEARCASE, O-Type
E115DHXIIR	GEARCASE, O-Type
E115DHXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXINA	GEARCASE, O-Type
E115DHXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXISC	GEARCASE
E115DHXISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXISF	GEARCASE
E115DHXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E115DHXSES	GEARCASE
E115DHXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPLAAA	07-1_GEARCASE, S2-Type
E115DPLAAB	07-1_GEARCASE, S2-Type
E115DPLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DPLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DPLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DPLIIB	GEARCASE, S2-Type
E115DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLINE	GEARCASE, S2-Type
E115DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLISF	GEARCASE
E115DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLISM	GEARCASE
E115DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSCR	GEARCASE
E115DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSEF	GEARCASE
E115DPLSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSUC	GEARCASE
E115DPLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E115DPXAAA	07-1_GEARCASE, O-Type
E115DPXAAB	07-1_GEARCASE, O-Type
E115DPXABA	07-1_GEARCASE, O-Type
E115DPXAFA	07-1_GEARCASE, O-Type
E115DPXAFB	07-1_GEARCASE, O-Type
E115DPXAFF	07-1_GEARCASE, O-Type
E115DPXAFG	07-1_GEARCASE, O-Type
E115DPXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXIIB	GEARCASE, O-Type
E115DPXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXINE	GEARCASE, O-Type

E115DPXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXISF	GEARCASE
E115DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXISM	GEARCASE
E115DPXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSCR	GEARCASE
E115DPXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSEF	GEARCASE
E115DPXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSUC	GEARCASE
E115DPXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DSLAAA	07-1_GEARCASE, S2-Type
E115DSLAAAB	07-1_GEARCASE, S2-Type
E115DSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DSLAF A	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF F	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF G	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF H	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF I	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF K	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF L	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSL IIB	GEARCASE, S2-Type
E115DSL IIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL IINE	GEARCASE, S2-Type
E115DSL IINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL IISF	GEARCASE
E115DSL IISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL IISM	GEARCASE
E115DSL IISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL ISCR	GEARCASE
E115DSL ISCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL ISEF	GEARCASE
E115DSL ISEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL ISUC	GEARCASE

E115DSLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E115ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115ELEDR 1996	GEARCASE - 20 IN. MODELS
E115ELEDR 1996	GEARCASE - 25 IN. MODELS
E115ELEOC 1995	GEARCASE - 20 IN. MODELS
E115ELEOC 1995	GEARCASE - 25 IN. MODELS
E115ELEUA 1997	GEARCASE - 20 IN. MODELS
E115ELEUA 1997	GEARCASE - 25 IN. MODELS
E115ELEUC 1997	GEARCASE - 20 IN. MODELS
E115ELEUC 1997	GEARCASE - 25 IN. MODELS
E115FPLEEC 1999	GEARCASE -- FPL, FSL MODELS
E115FPLEEC 1999	GEARCASE -- FPX MODELS
E115FPLEEN 1999	GEARCASE -- FPL, FSL MODELS
E115FPLEEN 1999	GEARCASE -- FPX MODELS
E115FPLSDS	GEARCASE - PL, SL MODELS
E115FPLSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E115FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E115FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E115FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL
E115FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E115FPLSOD	GEARCASE - FPL, FSL MODELS
E115FPLSOD - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E115FPLSRE	GEARCASE - FPL, FSL MODELS
E115FPLSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E115FPLSTB	GEARCASE - FPL, FSL MODELS
E115FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E115FPXEEC 1999	GEARCASE -- FPL, FSL MODELS
E115FPXEEC 1999	GEARCASE -- FPX MODELS
E115FPXEEN 1999	GEARCASE -- FPL, FSL MODELS

E115FPXEEN 1999	GEARCASE -- FPX MODELS
E115FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E115FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E115FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL
E115FPXSNF Ficht Fuel Injection, 25 in., White, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E115FPXSSH FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPXSSH FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FPXSSR FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPXSSR FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FPXSTB	GEARCASE - FPL, FSL MODELS
E115FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E115FSLECS 1998	GEARCASE -- FSL, FTL MODELS
E115FSLECS 1998	GEARCASE -- FSX MODELS
E115FSLEEC 1999	GEARCASE -- FPL, FSL MODELS
E115FSLEEC 1999	GEARCASE -- FPX MODELS
E115FSLEEN 1999	GEARCASE -- FPL, FSL MODELS
E115FSLEEN 1999	GEARCASE -- FPX MODELS
E115FSLSDS	GEARCASE - PL, SL MODELS
E115FSLSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E115FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E115FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E115FSLSOD	GEARCASE - FPL, FSL MODELS
E115FSLSOD - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E115FSLSRE	GEARCASE - FPL, FSL MODELS
E115FSLSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E115FSLSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FSLSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FSLSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FSLSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FSLSTB	GEARCASE - FPL, FSL MODELS
E115FSLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E115FSXECS 1998	GEARCASE -- FSL, FTL MODELS
E115FSXECS 1998	GEARCASE -- FSX MODELS
E115FTLECS 1998	GEARCASE -- FSL, FTL MODELS

E115FTLECS 1998	GEARCASE -- FSX MODELS
E115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115GLEDR 1996	GEARCASE - 20 IN. MODELS
E115GLEDR 1996	GEARCASE - 25 IN. MODELS
E115GLEOC 1995	GEARCASE - 20 IN. MODELS
E115GLEOC 1995	GEARCASE - 25 IN. MODELS
E115GLEUA 1997	GEARCASE - 20 IN. MODELS
E115GLEUA 1997	GEARCASE - 25 IN. MODELS
E115GLEUC 1997	GEARCASE - 20 IN. MODELS
E115GLEUC 1997	GEARCASE - 25 IN. MODELS
E115GNLAFB	07-1_GEARCASE, O-Type
E115GNLAFF	07-1_GEARCASE, O-Type
E115GNLAFG	07-1_GEARCASE, O-Type
E115GNLAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115GNLAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E115GNLAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115GNLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAAA	07-1_GEARCASE, S2-Type
E115HSLAAB	07-1_GEARCASE, S2-Type
E115HSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HSLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLIIR	GEARCASE, S2-Type
E115HSLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLINA	GEARCASE, S2-Type
E115HSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLISC	GEARCASE
E115HSLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLISF	GEARCASE
E115HSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLSES	GEARCASE

E115HLSSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115JKLEOC 1995	GEARCASE
E115JKLERS 1994	GEARCASE
E115JLEDA 1996	GEARCASE
E115JLEIE 1991	GEARCASE
E115JLEND 1992	GEARCASE
E115JLEOR 1995	GEARCASE
E115JLERC 1994	GEARCASE
E115JLETS 1993	GEARCASE
E115JTLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115JTLECS 1998	GEARCASE -- 90 & 115 SX MODELS
E115MLCIH 1981	GEARCASE
E115MLCIM 1981	GEARCASE
E115MLCNB 1982	GEARCASE
E115MLCOS 1985	GEARCASE
E115MLCRD 1984	GEARCASE
E115MLCSA 1980	GEARCASE
E115MLCTE 1983	GEARCASE
E115MLEIE 1991	GEARCASE
E115MLEND 1992	GEARCASE
E115MLEOR 1995	GEARCASE
E115MLERS 1994	GEARCASE
E115MLESB 1990	GEARCASE
E115MLETS 1993	GEARCASE
E115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115SLEDR 1996	GEARCASE - 20 IN. MODELS
E115SLEDR 1996	GEARCASE - 25 IN. MODELS
E115SLEOC 1995	GEARCASE - 20 IN. MODELS
E115SLEOC 1995	GEARCASE - 25 IN. MODELS
E115SLEUA 1997	GEARCASE - 20 IN. MODELS
E115SLEUA 1997	GEARCASE - 25 IN. MODELS
E115SLEUC 1997	GEARCASE - 20 IN. MODELS
E115SLEUC 1997	GEARCASE - 25 IN. MODELS
E115SNLAFA	07-1_GEARCASE, O-Type

E115SNLAFB	07-1_GEARCASE, O-Type
E115SNLAFF	07-1_GEARCASE, O-Type
E115SNLAFG	07-1_GEARCASE, O-Type
E115SNLAFH	07-1_GEARCASE, O-Type
E115SNLAFI	07-1_GEARCASE, O-Type
E115SNLAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115SNLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115SXEDR 1996	GEARCASE - 20 IN. MODELS
E115SXEDR 1996	GEARCASE - 25 IN. MODELS
E115SXEOC 1995	GEARCASE - 20 IN. MODELS
E115SXEOC 1995	GEARCASE - 25 IN. MODELS
E115SXEU A 1997	GEARCASE - 20 IN. MODELS
E115SXEU A 1997	GEARCASE - 25 IN. MODELS
E115SXEU C 1997	GEARCASE - 20 IN. MODELS
E115SXEU C 1997	GEARCASE - 25 IN. MODELS
E115TLCIH 1981	GEARCASE
E115TLCIM 1981	GEARCASE
E115TLCNB 1982	GEARCASE
E115TLCOS 1985	GEARCASE
E115TLCRD 1984	GEARCASE
E115TLCSA 1980	GEARCASE
E115TLCTE 1983	GEARCASE
E115TLEDA 1996	GEARCASE
E115TLEIE 1991	GEARCASE
E115TLEND 1992	GEARCASE
E115TLEOR 1995	GEARCASE
E115TLERC 1994	GEARCASE
E115TLESB 1990	GEARCASE
E115TLETS 1993	GEARCASE
E115TSLECM 1998	GEARCASE
E115TSLEUA 1997	GEARCASE
E115TSXECM 1998	GEARCASE
E115TSXEUA 1997	GEARCASE

E115TXADA 1996	GEARCASE
E115TXAOR 1995	GEARCASE
E115TXARS 1994	GEARCASE
E115TXATS 1993	GEARCASE
E115TXCIH 1981	GEARCASE
E115XCIM 1981	GEARCASE
E115XCNB 1982	GEARCASE
E115XCRD 1984	GEARCASE
E115XCSA 1980	GEARCASE
E115XCTE 1983	GEARCASE
E115XEIE 1991	GEARCASE
E115XEND 1992	GEARCASE
E115XESB 1990	GEARCASE
E120TLCCA 1988	GEARCASE - 120TL & TX/140 TL
E120TLCCA 1988	GEARCASE - 140TX STANDARD ROTATION
E120TLCDC 1986	GEARCASE
E120TLCEM 1989	GEARCASE - 120TL & TX/140 TL
E120TLCEM 1989	GEARCASE - 140TX STANDARD ROTATION
E120TLCOS 1985	GEARCASE
E120TLCUR 1987	GEARCASE
E120LEIE 1991	GEARCASE - 120TL & TX/140 TL
E120LEIE 1991	GEARCASE - 140TX STANDARD ROTATION
E120LEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E120LEND 1992	GEARCASE - 140TX STANDARD ROTATION
E120TLERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TLERC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TLESB 1990	GEARCASE - 120TL & TX/140 TL
E120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
E120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

E120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXCCA 1988	GEARCASE - 120TL & TX/140 TL
E120TXCCA 1988	GEARCASE - 140TX STANDARD ROTATION
E120TXCDC 1986	GEARCASE
E120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
E120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
E120XCOS 1985	GEARCASE
E120XCUR 1987	GEARCASE
E120XEIE 1991	GEARCASE - 120TL & TX/140 TL
E120XEIE 1991	GEARCASE - 140TX STANDARD ROTATION
E120XEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E120XEND 1992	GEARCASE - 140TX STANDARD ROTATION
E120XERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120XERC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120XERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120XERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120XESB 1990	GEARCASE - 120TL & TX/140 TL
E120XESB 1990	GEARCASE - 140TX STANDARD ROTATION
E120XETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120XETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120XETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120XETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX

E125ESXENR 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E125ESXENR 1992	GEARCASE - 140TX STANDARD ROTATION
E125ESXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E125ESXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E125ESXESS 1990	GEARCASE - ESX MODELS ONLY
E125ESXETA 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E125ESXETA 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125ESXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E125ESXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125ESXW 1989	GEARCASE - ESX MODELS ONLY
E125WTPLE 1995	GEARCASE
E130CXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130DGLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAAA	07-1_GEARCASE, S2-Type
E130DPLAAB	07-1_GEARCASE, S2-Type
E130DPLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLIIR	GEARCASE, S2-Type
E130DPLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLINA	GEARCASE, S2-Type
E130DPLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLISC	GEARCASE
E130DPLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLISF	GEARCASE
E130DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLSES	GEARCASE

E130DPLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPXAAA	07-1_GEARCASE, O-Type
E130DPXAAB	07-1_GEARCASE, O-Type
E130DPXABA	07-1_GEARCASE, O-Type
E130DPXAFA	07-1_GEARCASE, O-Type
E130DPXAFB	07-1_GEARCASE, O-Type
E130DPXAFF	07-1_GEARCASE, O-Type
E130DPXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXIIR	GEARCASE, O-Type
E130DPXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXINA	GEARCASE, O-Type
E130DPXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXISC	GEARCASE
E130DPXISF	GEARCASE
E130DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXSES	GEARCASE
E130DPXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DSLAAA	07-1_GEARCASE, S2-Type
E130DSLAAAB	07-1_GEARCASE, S2-Type
E130DSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLIIIR	GEARCASE, S2-Type
E130DSLIIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLINA	GEARCASE, S2-Type
E130DSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLISC	GEARCASE

E130DSLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLISF	GEARCASE
E130DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLSES	GEARCASE
E130DSLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130TLECE 1998	GEARCASE
E130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TLEOA 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXACB 1998	GEARCASE
E130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
E135DHLAAB	07-1_GEARCASE, L2-Type
E135DHLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135DHLABA	07-1_GEARCASE, L2-Type
E135DHLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135DHLABB	07-1_GEARCASE, L2-Type
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FPLSDE	GEARCASE - PL - SL MODELS
E135FPLSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FPLSOB	GEARCASE - PL - SL MODELS
E135FPLSOB - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E135FPLSRM	GEARCASE - PL - SL MODELS
E135FPLSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS

E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FPLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E135FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FSLSD	GEARCASE - PL - SL MODELS
E135FSLSD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSLSOB	GEARCASE - PL - SL MODELS
E135FSLSOB - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E135FSLSRM	GEARCASE - PL - SL MODELS
E135FSLSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E135FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135HGLABB	07-1_GEARCASE, L2-Type
E135HGLABF	07-1_GEARCASE, L2-Type
E135HGLABG	07-1_GEARCASE, L2-Type
E135HGLABH	07-1_GEARCASE, L2-Type
E135HGLABJ	07-1_GEARCASE, L2-Type
E135HSLAAB	07-1_GEARCASE, L2-Type
E135HSLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135HSLABA	07-1_GEARCASE, L2-Type
E135HSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135HSLABB	07-1_GEARCASE, L2-Type

E135HSLABF	07-1_GEARCASE, L2-Type
E135HSLABG	07-1_GEARCASE, L2-Type
E135HSLABH	07-1_GEARCASE, L2-Type
E135HSLABJ	07-1_GEARCASE, L2-Type
E140CXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXCCS 1988	GEARCASE - 120TL & TX/140 TL
E140CXCCS 1988	GEARCASE - 140TX STANDARD ROTATION
E140CXCEC 1989	GEARCASE - 120TL & TX/140 TL
E140CXCEC 1989	GEARCASE - 140TX STANDARD ROTATION
E140CXEIA 1991	GEARCASE - 120TL & TX/140 TL
E140CXEIA 1991	GEARCASE - 140TX STANDARD ROTATION
E140CXENM 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140CXENM 1992	GEARCASE - 140TX STANDARD ROTATION
E140CXERE 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXERE 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXESR 1990	GEARCASE - 120TL & TX/140 TL
E140CXESR 1990	GEARCASE - 140TX STANDARD ROTATION
E140CXETB 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXETB 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140MLCIH 1981	GEARCASE

E140MLCIM 1981	GEARCASE
E140MLCNB 1982	GEARCASE
E140MLCSA 1980	GEARCASE
E140MLCTE 1983	GEARCASE
E140TLATC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TLATC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLCCM 1988	GEARCASE - 120TL & TX/140 TL
E140TLCCM 1988	GEARCASE - 140TX STANDARD ROTATION
E140TLCDC 1986	GEARCASE
E140TLCEB 1989	GEARCASE - 120TL & TX/140 TL
E140TLCEB 1989	GEARCASE - 140TX STANDARD ROTATION
E140TLCOS 1985	GEARCASE
E140TLCRD 1984	GEARCASE
E140TLCUA 1987	GEARCASE
E140TLEID 1991	GEARCASE - 120TL & TX/140 TL
E140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
E140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
E140TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TLERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TLERR 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TLESE 1990	GEARCASE - 120TL & TX/140 TL
E140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
E140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TRLCIH 1981	GEARCASE

E140TRLCIM 1981	GEARCASE
E140TRLCNB 1982	GEARCASE
E140TRLCSA 1980	GEARCASE
E140TRLCTE 1983	GEARCASE
E140TRXCIH 1981	GEARCASE
E140TRXCIM 1981	GEARCASE
E140TRXCNB 1982	GEARCASE
E140TRXCSA 1980	GEARCASE
E140TRXCTE 1983	GEARCASE
E140TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXCCM 1988	GEARCASE - 120TL & TX/140 TL
E140TXCCM 1988	GEARCASE - 140TX STANDARD ROTATION
E140TXCDC 1986	GEARCASE
E140TXCEB 1989	GEARCASE - 120TL & TX/140 TL
E140TXCEB 1989	GEARCASE - 140TX STANDARD ROTATION
E140XCOS 1985	GEARCASE
E140XCRD 1984	GEARCASE
E140XCUA 1987	GEARCASE
E140XEID 1991	GEARCASE - 120TL & TX/140 TL
E140XEID 1991	GEARCASE - 140TX STANDARD ROTATION
E140XENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140XENS 1992	GEARCASE - 140TX STANDARD ROTATION
E140XERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140XERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140XERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140XERR 1994	GEARCASE - 120TL, 125ESX, & 140TL

E140TXESE 1990	GEARCASE - 120TL & TX/140 TL
E140TXESE 1990	GEARCASE - 140TX STANDARD ROTATION
E140TXETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E150ANCRS 1984	GEARCASE
E150CXCCA 1988	GEARCASE - STANDARD ROTATION
E150CXCEM 1989	GEARCASE - STANDARD ROTATION
E150CXEIE 1991	GEARCASE - STANDARD ROTATION
E150CXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E150CXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E150DGLABB	07-1_GEARCASE, O-Type
E150DGLABF	07-1_GEARCASE, O-Type
E150DGLABG	07-1_GEARCASE, O-Type
E150DGLABH	07-1_GEARCASE, O-Type
E150DGLABJ	07-1_GEARCASE, O-Type
E150DHAAAA	07-1_GEARCASE, L2-Type
E150DHAAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHAAAB	07-1_GEARCASE, L2-Type
E150DHAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHABAA	07-1_GEARCASE, L2-Type
E150DHABAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHABBB	07-1_GEARCASE, L2-Type
E150DHAIIB	GEARCASE, L2-Type
E150DHAIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLINE	GEARCASE, L2-Type
E150DHLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLISF	GEARCASE
E150DHLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLISM	GEARCASE
E150DHLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLSCF	GEARCASE

E150DHLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLSCR	GEARCASE - HL MODEL
E150DHLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150DHLSEA	GEARCASE
E150DHLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLSUC	GEARCASE - HL MODEL
E150DHLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150DHLSUF	GEARCASE - HL MODEL
E150DHLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150DPLAAA	07-1_GEARCASE, O-Type
E150DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLAAB	07-1_GEARCASE, O-Type
E150DPLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLABA	07-1_GEARCASE, O-Type
E150DPLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLABB	07-1_GEARCASE, O-Type
E150DPLIIB	GEARCASE, O-Type
E150DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLINE	GEARCASE, O-Type
E150DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLISF	GEARCASE - PL, SL MODELS
E150DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLISM	GEARCASE - PL, SL MODELS
E150DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSCR	GEARCASE - PL, SL MODELS
E150DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSEA	GEARCASE - PL, SL MODELS
E150DPLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSUC	GEARCASE - PL, SL MODELS
E150DPLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSUF	GEARCASE - PL, SL MODELS
E150DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLAAA	07-1_GEARCASE, O-Type
E150DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLAAAB	07-1_GEARCASE, O-Type

E150DSLAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLABA	07-1_GEARCASE, O-Type
E150DSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLABB	07-1_GEARCASE, O-Type
E150DSLABF	07-1_GEARCASE, O-Type
E150DSLABG	07-1_GEARCASE, O-Type
E150DSLABH	07-1_GEARCASE, O-Type
E150DSLABJ	07-1_GEARCASE, O-Type
E150DSLIIB	GEARCASE, O-Type
E150DSLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLINA	GEARCASE, O-Type
E150DSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLISF	GEARCASE - PL, SL MODELS
E150DSLISM	GEARCASE - PL, SL MODELS
E150DSLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLSCR	GEARCASE - PL, SL MODELS
E150DSLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLSEA	GEARCASE - PL, SL MODELS
E150DSLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DLSUC	GEARCASE - PL, SL MODELS
E150DLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DLSUF	GEARCASE - PL, SL MODELS
E150DLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEIS 1991	GEARCASE - STANDARD ROTATION
E150ELENC 1992	GEARCASE - STANDARD ROTATION
E150ELEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150ELERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

E150ELERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEIS 1991	GEARCASE - STANDARD ROTATION
E150EXENC 1992	GEARCASE - STANDARD ROTATION
E150XEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150XEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

E150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150FCXEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FCXEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSMM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FCXSMM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FHLSDR	GEARCASE - FHL MODEL
E150FHLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E150FHLSOC	GEARCASE - FHL MODEL
E150FHLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - FHL MODELES
E150FHLSRS	GEARCASE - FHL MODEL
E150FHLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E150FPLEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS

E150FPLEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPLSDR	GEARCASE - PL - SL MODELS
E150FPLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSOC	GEARCASE - PL - SL MODELS
E150FPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E150FPLSRS	GEARCASE - PL - SL MODELS
E150FPLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FPLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E150FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FPXEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPXEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPXSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPXSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation

E150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150FSLEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FSLEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FSLSDR	GEARCASE - PL - SL MODELS
E150FSLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSOC	GEARCASE - PL - SL MODELS
E150FSLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E150FSLSRS	GEARCASE - PL - SL MODELS
E150FSLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FSLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E150FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEIS 1991	GEARCASE - STANDARD ROTATION
E150GLENC 1992	GEARCASE - STANDARD ROTATION
E150GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS

E150GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150GLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150GNLABB	07-1_GEARCASE, O-Type
E150GNLABF	07-1_GEARCASE, O-Type
E150GNLABG	07-1_GEARCASE, O-Type
E150GNLABH	07-1_GEARCASE, O-Type
E150GNLABJ	07-1_GEARCASE, O-Type
E150HGLABA	07-1_GEARCASE, L2-Type
E150HGLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HGLABB	07-1_GEARCASE, L2-Type
E150HGLABF	07-1_GEARCASE, L2-Type
E150HGLABG	07-1_GEARCASE, L2-Type
E150HGLABH	07-1_GEARCASE, L2-Type
E150HGLABJ	07-1_GEARCASE, L2-Type
E150HGLSES	GEARCASE
E150HGLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLAAA	07-1_GEARCASE, L2-Type
E150HSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLAAB	07-1_GEARCASE, L2-Type
E150HSLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLABA	07-1_GEARCASE, L2-Type
E150HSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLABB	07-1_GEARCASE, L2-Type

E150HSLABF	07-1_GEARCASE, L2-Type
E150HSLABG	07-1_GEARCASE, L2-Type
E150HSLABH	07-1_GEARCASE, L2-Type
E150HSLABJ	07-1_GEARCASE, L2-Type
E150HSLIIA	GEARCASE, L2-Type
E150HSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLINM	GEARCASE, L2-Type
E150HSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLISF	GEARCASE
E150HSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLISR	GEARCASE
E150HSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLSCF	GEARCASE
E150HSLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLSCS	GEARCASE - HL MODEL
E150HSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150HSLSEC	GEARCASE
E150HSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150ILECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150ILECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150JLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150JLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150JLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150JLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEIE 1991	GEARCASE - STANDARD ROTATION
E150JLENC 1992	GEARCASE - STANDARD ROTATION
E150JLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS

E150JLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150JLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150JLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150JLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150JLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150JLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEIS 1991	GEARCASE - STANDARD ROTATION
E150NXENC 1992	GEARCASE - STANDARD ROTATION
E150NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

E150NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150SNLABA	07-1_GEARCASE, O-Type
E150SNLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150SNLABB	07-1_GEARCASE, O-Type
E150SNLABF	07-1_GEARCASE, O-Type
E150SNLABG	07-1_GEARCASE, O-Type
E150SNLABH	07-1_GEARCASE, O-Type
E150SNLABJ	07-1_GEARCASE, O-Type
E150STLCCA 1988	GEARCASE
E150STLCDC 1986	GEARCASE

E150STLCEM 1989	GEARCASE
E150STLCOH 1985	GEARCASE
E150STLCOS 1985	GEARCASE
E150STLCRD 1984	GEARCASE
E150STLCTE 1983	GEARCASE
E150STLCUR 1987	GEARCASE
E150STLEIE 1991	GEARCASE
E150STLESB 1990	GEARCASE EARLY PRODUCTION
E150STLESB 1990	GEARCASE LATE PRODUCTION
E150TLCCA 1988	GEARCASE - STANDARD ROTATION
E150TLCDC 1986	GEARCASE
E150TLCEM 1989	GEARCASE - STANDARD ROTATION
E150TLCOS 1985	GEARCASE
E150TLCRD 1984	GEARCASE
E150TLCUR 1987	GEARCASE
E150TLEIE 1991	GEARCASE - STANDARD ROTATION
E150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E150TRLCIA 1981	GEARCASE
E150TRLCIH 1981	GEARCASE
E150TRLCNM 1982	GEARCASE
E150TRLCSF 1980	GEARCASE
E150TRLCSR 1980	GEARCASE
E150TRLCTB 1983	GEARCASE
E150TRLCTE 1983	GEARCASE
E150TRXCIA 1981	GEARCASE
E150TRXCIH 1981	GEARCASE
E150TRXCNM 1982	GEARCASE
E150TRXCSF 1980	GEARCASE
E150TRXCSR 1980	GEARCASE
E150TRXCTB 1983	GEARCASE
E150TRXCTE 1983	GEARCASE
E150TXCCA 1988	GEARCASE - STANDARD ROTATION
E150TXCDC 1986	GEARCASE
E150TXCEM 1989	GEARCASE - STANDARD ROTATION

E150TXCOS 1985	GEARCASE
E150TXCRD 1984	GEARCASE
E150TXCUR 1987	GEARCASE
E150TXEIE 1991	GEARCASE - STANDARD ROTATION
E150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
E150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
E150WTLEOR 1995	GEARCASE
E150WTLERC 1994	GEARCASE
E150WTLERV 1994	GEARCASE
E150WTLETG 1993	GEARCASE - 20" MODELS
E150WTLETG 1993	GEARCASE - 25" MODELS
E150WTLETS 1993	GEARCASE - 20" MODELS
E150WTLETS 1993	GEARCASE - 25" MODELS
E150WTXEOR 1995	GEARCASE
E150WTXERC 1994	GEARCASE
E150WTXERV 1994	GEARCASE
E150WTXETG 1993	GEARCASE - 20" MODELS
E150WTXETG 1993	GEARCASE - 25" MODELS
E150WTXETS 1993	GEARCASE - 20" MODELS
E150WTXETS 1993	GEARCASE - 25" MODELS
E155WTLCDR 1986	GEARCASE
E155WTLCOB 1985	GEARCASE
E155WTLCRS 1984	GEARCASE
E155WTLCUA 1987	GEARCASE
E155WTLIIB 1991	GEARCASE
E155WTLENE 1992	GEARCASE
E155WTLISM 1990	GEARCASE
E155WTLZ 1989	GEARCASE
E155WTXCDR 1986	GEARCASE
E155WTXCOC 1985	GEARCASE
E155WTXCRS 1984	GEARCASE
E155WTXCUA 1987	GEARCASE
E155WTXEIB 1991	GEARCASE

E155WTXENE 1992	GEARCASE
E155WTXESM 1990	GEARCASE
E155WTXZ 1989	GEARCASE
E175DGLABB	07-1_GEARCASE, O-Type
E175DGLABF	07-1_GEARCASE, O-Type
E175DGLABG	07-1_GEARCASE, O-Type
E175DGLABH	07-1_GEARCASE, O-Type
E175DPLAAA	07-1_GEARCASE, O-Type
E175DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLAAB	07-1_GEARCASE, O-Type
E175DPLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLABA	07-1_GEARCASE, O-Type
E175DPLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLABB	07-1_GEARCASE, O-Type
E175DPLIIB	GEARCASE, O-Type
E175DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLINE	GEARCASE, O-Type
E175DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLISF	GEARCASE - PL, SL MODELS
E175DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLISM	GEARCASE - PL, SL MODELS
E175DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSCR	GEARCASE - PL, SL MODELS
E175DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSEA	GEARCASE - PL, SL MODELS
E175DPLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSUF	GEARCASE - PL, SL MODELS
E175DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLAAA	07-1_GEARCASE, O-Type
E175DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLAAAB	07-1_GEARCASE, O-Type
E175DSLAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLABA	07-1_GEARCASE, O-Type
E175DSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLABB	07-1_GEARCASE, O-Type

E175DSLAFB	07-1_GEARCASE, O-Type
E175DSLABG	07-1_GEARCASE, O-Type
E175DSLABH	07-1_GEARCASE, O-Type
E175DSLABJ	07-1_GEARCASE, O-Type
E175DSLIIIB	GEARCASE, O-Type
E175DSLIIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIIE	GEARCASE, O-Type
E175DSLIIIE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIIF	GEARCASE - PL, SL MODELS
E175DSLIIIF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIIM	GEARCASE - PL, SL MODELS
E175DSLIIIM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIIS	GEARCASE - PL, SL MODELS
E175DSLIIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIISL	GEARCASE - PL, SL MODELS
E175DSLIIISL - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIISLSEA	GEARCASE - PL, SL MODELS
E175DSLIIISLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIISLSEAUF	GEARCASE - PL, SL MODELS
E175DSLIIISLSEAUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEIS 1991	GEARCASE - STANDARD ROTATION
E175EXENC 1992	GEARCASE - STANDARD ROTATION
E175EXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E175EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175FCXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FCXECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175FCXEEC 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FCXEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSTB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation

E175FPLEEC 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPLEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPLSDS	GEARCASE - PL - SL MODELS
E175FPLSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSOD	GEARCASE - PL - SL MODELS
E175FPLSOD - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E175FPLSRE	GEARCASE - PL - SL MODELS
E175FPLSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FPLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E175FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FPXEEC 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPXEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS

E175FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FSLSD	GEARCASE - PL - SL MODELS
E175FSLSD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSOE	GEARCASE - PL - SL MODELS
E175FSLSOE - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E175FSLSRB	GEARCASE - PL - SL MODELS
E175FSLSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E175FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"

E175GLEIS 1991	GEARCASE - STANDARD ROTATION
E175GLENC 1992	GEARCASE - STANDARD ROTATION
E175GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175NXENC 1992	GEARCASE - STANDARD ROTATION
E175NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

E175NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175SLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175SLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175STLCCM 1988	GEARCASE - STANDARD ROTATION
E175STLCEB 1989	GEARCASE - STANDARD ROTATION
E175STLEID 1991	GEARCASE - STANDARD ROTATION
E175STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E175STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E175TLCCM 1988	GEARCASE - STANDARD ROTATION
E175TLCDR 1986	GEARCASE
E175TLCOC 1985	GEARCASE
E175TLCUA 1987	GEARCASE

E175TRLCIM 1981	GEARCASE
E175TRLCNB 1982	GEARCASE
E175TRLCSA 1980	GEARCASE
E175TRLCSF 1980	GEARCASE
E175TRLCTD 1983	GEARCASE
E175TRLCTE 1983	GEARCASE
E175TRXCIH 1981	GEARCASE
E175TRXCIM 1981	GEARCASE
E175TRXCNB 1982	GEARCASE
E175TRXCSA 1980	GEARCASE
E175TRXCSF 1980	GEARCASE
E175TRXCTD 1983	GEARCASE
E175TRXCTE 1983	GEARCASE
E175TXCCM 1988	GEARCASE - STANDARD ROTATION
E175TXCDR 1986	GEARCASE
E175TXCEB 1989	GEARCASE - STANDARD ROTATION
E175TXCOC 1985	GEARCASE
E175TXCUA 1987	GEARCASE
E175TXEID 1991	GEARCASE - STANDARD ROTATION
E175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E185ESERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E185ESERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXENR 1992	GEARCASE - STANDARD ROTATION
E185ESXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E185ESXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E185ESXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E185ESXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E185ESXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXW 1989	GEARCASE - STANDARD ROTATION
E185TLCOC 1985	GEARCASE
E185TL CRS 1984	GEARCASE
E185TXCOC 1985	GEARCASE

E185TXCRS 1984	GEARCASE
E200CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXCCR 1988	GEARCASE - STANDARD ROTATION
E200CXCEA 1989	GEARCASE - STANDARD ROTATION
E200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200CXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXEIB 1991	GEARCASE - STANDARD ROTATION
E200CXENE 1992	GEARCASE - STANDARD ROTATION
E200CXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E200CXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E200CXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E200CXEUJ 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXEUJ 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200DGLABB	07-1_GEARCASE, O-Type
E200DGLABF	07-1_GEARCASE, O-Type
E200DGLABG	07-1_GEARCASE, O-Type
E200DHLIID - (90 degree V6 3,3 L)	GEARCASE, L2-Type
E200DHLIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLINF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLINS - (90 degree V6, 3.3 L)	GEARCASE, L2-Type
E200DHLINS - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLISE - (90 degree V6 3,3 L)	GEARCASE
E200DHLISE - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLISF - (90 degree V6 3,3 L)	GEARCASE
E200DHLISF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSCF - (90 degree V6 3,3 L)	GEARCASE

E200DHLSCF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHLSCG - (90 degree V6 3,3 L)	GEARCASE
E200DHLSCG - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSCH - (90 degree V6 3,3 L)	GEARCASE
E200DHLSCH - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSCM - (90 degree V6 3,3 L)	GEARCASE
E200DHLSCM - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHLSDF - (90 degree V6 3,3 L)	GEARCASE
E200DHLSDF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHLSEB - (90 degree V6 3,3 L)	GEARCASE
E200DHLSEB - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSOC - (90 degree V6 3,3 L)	GEARCASE - HL, HX MODELS (L Type)
E200DHLSOC - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHL SOG - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHL SUA - (90 degree V6, 3.3 L)	GEARCASE
E200DHL SUA - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHL SUG - (90 degree V6 3,3 L)	GEARCASE
E200DHL SUG - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DPLAAA - (60 degree V6)	07-1_GEARCASE, O-Type
E200DPLAAA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLAAB - (60 degree V6)	07-1_GEARCASE, O-Type
E200DPLAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLABA	07-1_GEARCASE, O-Type
E200DPLABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLABB	07-1_GEARCASE, O-Type
E200DPLIIE - (60 degree V6)	GEARCASE, O-Type
E200DPLIIE - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLIND - (60 degree V6)	GEARCASE, O-Type
E200DPLIND - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLISB	GEARCASE - PL, SL MODELS
E200DPLISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLISF	GEARCASE - PL, SL MODELS
E200DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSCA	GEARCASE - PL, SL MODELS
E200DPLSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E200DPLSEM	GEARCASE - PL, SL MODELS
E200DPLSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSUF	GEARCASE - PL, SL MODELS
E200DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSUR	GEARCASE - PL, SL MODELS
E200DPLSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLAAA - (60 degree V6)	07-1_GEARCASE, O-Type
E200DSLAAA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLAAAB - (60 degree V6)	07-1_GEARCASE, O-Type
E200DSLAAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLABA	07-1_GEARCASE, O-Type
E200DSLABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLABB	07-1_GEARCASE, O-Type
E200DSLABF	07-1_GEARCASE, O-Type
E200DSLABG	07-1_GEARCASE, O-Type
E200DSLABJ	07-1_GEARCASE, O-Type
E200DSLIIIE - (60 degree V6)	GEARCASE, O-Type
E200DSLIIIE - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLIND - (60 degree V6)	GEARCASE, O-Type
E200DSLIND - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLISB	GEARCASE - PL, SL MODELS
E200DSLISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLISF	GEARCASE - PL, SL MODELS
E200DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLSCA	GEARCASE - PL, SL MODELS
E200DSLSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLSEM	GEARCASE - PL, SL MODELS
E200DSLSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DLSUF	GEARCASE - PL, SL MODELS
E200DLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DLSUR	GEARCASE - PL, SL MODELS
E200DLSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS

E200FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FCXSTM	GEARCASE - FHL MODEL
E200FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FHLSOR	GEARCASE - FHL, FHX MODELS
E200FHLSRC	GEARCASE - FHL, FHX MODELS
E200FHLSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX
E200FHLSTS	GEARCASE - FHL MODEL
E200FHLSTS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FHL MODEL
E200FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPLSTM	GEARCASE - FHL MODEL
E200FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS

E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FHL MODEL
E200FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPXSTM	GEARCASE - FHL MODEL
E200FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FSLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FSLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FSLSSC FFI, Elec Start, TNT, 20 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FSLSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FSLSTM	GEARCASE - FHL MODEL
E200FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200HSLIIB - (90 degree V6 3,3 L)	GEARCASE, L2-Type
E200HSLINE - (90 degree V6, 3.3 L)	GEARCASE, L2-Type
E200HSLINE - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLINF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLISF - (90 degree V6 3,3 L)	GEARCASE
E200HSLISF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLISM - (90 degree V6 3,3 L)	GEARCASE
E200HSLISM - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLSCF - (90 degree V6 3,3 L)	GEARCASE
E200HSLSCF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200HSLSCG - (90 degree V6 3,3 L)	GEARCASE
E200HSLSCG - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLSCH - (90 degree V6 3,3 L)	GEARCASE
E200HSLSCH - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2

E200HSLSCR - (90 degree V6 3,3 L)	GEARCASE
E200HSLSCR - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200HSLSDS - (90 degree V6 3,3 L)	GEARCASE
E200HSLSDS - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200HSLSEA - (90 degree V6 3,3 L)	GEARCASE
E200HSLSEA - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLSUC - (90 degree V6 3,3 L)	GEARCASE
E200HSLSUC - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200STLCCM 1988	GEARCASE - STANDARD ROTATION
E200STLCDR 1986	GEARCASE
E200STLCEB 1989	GEARCASE - STANDARD ROTATION
E200STLCUA 1987	GEARCASE
E200STLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200STLECE 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E200STLEDM 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLEID 1991	GEARCASE - STANDARD ROTATION
E200STLENS 1992	GEARCASE - STANDARD ROTATION
E200STLEOA 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLEOA 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLERR 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLERR 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E200STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E200STLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLEUB 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXEIB 1991	GEARCASE - STANDARD ROTATION
E200TXENE 1992	GEARCASE - STANDARD ROTATION
E200TXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E200TZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200WPXEEN 1999	GEARCASE
E200WPXEES 1999	GEARCASE
E200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	GEARCASE
E225CLCUB 1987	GEARCASE
E225CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225XCCE 1988	GEARCASE - STANDARD ROTATION
E225XCED 1989	GEARCASE - STANDARD ROTATION
E225XCUB 1987	GEARCASE
E225XECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225XECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225XEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225XEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225XEIC 1991	GEARCASE - STANDARD ROTATION
E225XENR 1992	GEARCASE - STANDARD ROTATION
E225XEOb 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225XEOb 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225CXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225CXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225CXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225XEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225XEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225CZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225CZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225CZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225DHLISE	GEARCASE
E225DHLISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLISF	GEARCASE
E225DHLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSCF	GEARCASE
E225DHLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSCG	GEARCASE
E225DHLSCG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSCH	GEARCASE
E225DHLSCH - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSCM	GEARCASE
E225DHLSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSDF	GEARCASE
E225DHLSDF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSEB	GEARCASE
E225DHLSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSOC	GEARCASE - HL, HX MODELS (L Type)
E225DHLSOC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSONF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSONG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHL SUA	GEARCASE
E225DHL SUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHL SUG	GEARCASE
E225DHL SUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLXISB	GEARCASE
E225DHLXISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLXISF	GEARCASE
E225DHLXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2

E225DHXSCA	GEARCASE
E225DHXSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSCF	GEARCASE
E225DHXSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSCG	GEARCASE
E225DHXSCG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXSCH	GEARCASE
E225DHXSCH - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXSDF	GEARCASE
E225DHXSDF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSEM	GEARCASE
E225DHXSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXSOC	GEARCASE - HL, HX MODELS (L Type)
E225DHXSOC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSOG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSUG	GEARCASE
E225DHXSUR	GEARCASE
E225FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E225FCXSTM	GEARCASE - FHL MODEL
E225FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FCZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS

E225FCZEE0 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCZEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E225FCZSTM	GEARCASE - FHL MODEL
E225FCZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FGLSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FGLSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FHLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002	GEARCASE - FHL MODEL
E225FHLSOB	GEARCASE - FHL, FHX MODELS
E225FHLSRM	GEARCASE - FHL, FHX MODELS
E225FHLSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX
E225FHLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FHLSTA	GEARCASE - FHL MODEL
E225FHLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FHXSOC	GEARCASE - FHL, FHX MODELS
E225FHXSRS	GEARCASE - FHL, FHX MODELS
E225FHXSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX
E225FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS

E225FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLSIF FFI	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FHL MODEL
E225FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPLSTM	GEARCASE - FHL MODEL
E225FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FHL MODEL
E225FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSTM	GEARCASE - FHL MODEL
E225FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPZEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS

E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FHL MODEL
E225FPZSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZSTM	GEARCASE - FHL MODEL
E225FPZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225HSLISF	GEARCASE
E225HSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLISR	GEARCASE
E225HSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSCF	GEARCASE
E225HSLSCG	GEARCASE
E225HSLSCG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSCH	GEARCASE
E225HSLSCH - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSCS	GEARCASE
E225HSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSEC	GEARCASE
E225HSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225PLCCE 1988	GEARCASE - STANDARD ROTATION
E225PLCED 1989	GEARCASE - STANDARD ROTATION
E225PLCUB 1987	GEARCASE
E225PLEIC 1991	GEARCASE - STANDARD ROTATION
E225PLENR 1992	GEARCASE - STANDARD ROTATION
E225PLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PTLCDA 1986	GEARCASE
E225PTXCDA 1986	GEARCASE
E225PXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXCCE 1988	GEARCASE - STANDARD ROTATION
E225PXCED 1989	GEARCASE - STANDARD ROTATION
E225PXCUB 1987	GEARCASE
E225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXEIC 1991	GEARCASE - STANDARD ROTATION
E225PXENR 1992	GEARCASE - STANDARD ROTATION
E225PXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225STLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225STLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLERC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLCCE 1988	GEARCASE - STANDARD ROTATION
E225TLCDA 1986	GEARCASE
E225TLCED 1989	GEARCASE - STANDARD ROTATION
E225TLCUB 1987	GEARCASE
E225TLEIC 1991	GEARCASE - STANDARD ROTATION
E225TLENR 1992	GEARCASE - STANDARD ROTATION
E225TLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXCCE 1988	GEARCASE - STANDARD ROTATION
E225TXCDA 1986	GEARCASE

E225TXCED 1989	GEARCASE - STANDARD ROTATION
E225TXCUB 1987	GEARCASE
E225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225TXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225TXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXEIC 1991	GEARCASE - STANDARD ROTATION
E225TXENR 1992	GEARCASE - STANDARD ROTATION
E225TXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

E225TZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225TZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZEOb 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZEOb 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E235STLCOR 1985	GEARCASE
E235STLCRC 1984	GEARCASE
E235STLCTS 1983	GEARCASE
E235TLCOR 1985	GEARCASE
E235TLCRC 1984	GEARCASE
E235TRLCIB 1981	GEARCASE
E235TRLCIH 1981	GEARCASE
E235TRLCNE 1982	GEARCASE
E235TRLCSM 1980	GEARCASE
E235TRLCTD 1983	GEARCASE
E235TRLCTS 1983	GEARCASE
E235TRXCIB 1981	GEARCASE
E235TRXCIH 1981	GEARCASE
E235TRXCNE 1982	GEARCASE
E235TRXCSM 1980	GEARCASE
E235TRXCTD 1983	GEARCASE

E235TRXCTS 1983	GEARCASE
E235TXCOR 1985	GEARCASE
E235TXCRC 1984	GEARCASE
E250CXARC 1994	GEARCASE - STANDARD ROTATION
E250CXATF 1993	GEARCASE - STANDARD ROTATION
E250CXATS 1993	GEARCASE - STANDARD ROTATION
E250CXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250CXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E250CXEIE 1991	GEARCASE - STANDARD ROTATION
E250CXEND 1992	GEARCASE - STANDARD ROTATION
E250CXEOR 1995	GEARCASE - STANDARD ROTATION
E250CXERC 1994	GEARCASE - STANDARD ROTATION
E250CXETF 1993	GEARCASE - STANDARD ROTATION
E250CXETS 1993	GEARCASE - STANDARD ROTATION
E250CZATF 1993	GEARCASE - STANDARD ROTATION
E250CZATS 1993	GEARCASE - STANDARD ROTATION
E250CZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250CZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E250CZEND 1992	GEARCASE - STANDARD ROTATION
E250CZEOR 1995	GEARCASE - STANDARD ROTATION
E250CZERC 1994	GEARCASE - STANDARD ROTATION
E250CZETF 1993	GEARCASE - STANDARD ROTATION
E250CZETS 1993	GEARCASE - STANDARD ROTATION
E250DHLISF - (90 degree V6 3,4 L)	GEARCASE
E250DHLISF - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHLISG - (90 degree V6 3,4 L)	GEARCASE
E250DHLISG - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHLISR - (90 degree V6 3,4 L)	GEARCASE
E250DHLISR - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHLSCS - (90 degree V6 3,4 L)	GEARCASE
E250DHLSCS - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHLSEC - (90 degree V6 3,4 L)	GEARCASE
E250DHLSEC - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2

E250DHXISF - (90 degree V6 3,4 L)	GEARCASE
E250DHXISF - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXISG - (90 degree V6 3,4 L)	GEARCASE
E250DHXISG - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXISR - (90 degree V6 3,4 L)	GEARCASE
E250DHXISR - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXSCS - (90 degree V6 3,4 L)	GEARCASE
E250DHXSCS - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXSEC - (90 degree V6 3,4 L)	GEARCASE
E250DHXSEC - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E250FCXSTA	GEARCASE - FHL MODEL
E250FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E250FCZSTA	GEARCASE - FHL MODEL
E250FCZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FGLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FPLSSS FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FPLSTR	GEARCASE - FHL MODEL
E250FPLSTR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS

E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPXSSS FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPXSTA	GEARCASE - FHL MODEL
E250FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FHL MODEL
E250FPZSSS FFI, Elec Start, TNT, 30 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPZSTA	GEARCASE - FHL MODEL
E250FPZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250HGLSES - (90 degree V6 3,4 L)	GEARCASE
E250HGLSES - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HGXSES - (90 degree V6 3,4 L)	GEARCASE
E250HGXSES - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HSLISC - (90 degree V6 3,4 L)	GEARCASE
E250HSLISC - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HSLISF - (90 degree V6 3,4 L)	GEARCASE
E250HSLISF - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HSLISG - (90 degree V6 3,4 L)	GEARCASE
E250HSLISG - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HSLSES - (90 degree V6 3,4 L)	GEARCASE
E250HSLSES - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250PXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250PXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E250PZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250PZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS

E250TXARC 1994	GEARCASE - STANDARD ROTATION
E250TXATF 1993	GEARCASE - STANDARD ROTATION
E250TXATS 1993	GEARCASE - STANDARD ROTATION
E250TXEIE 1991	GEARCASE - STANDARD ROTATION
E250TXEND 1992	GEARCASE - STANDARD ROTATION
E250TXEOR 1995	GEARCASE - STANDARD ROTATION
E250TXERC 1994	GEARCASE - STANDARD ROTATION
E250XETF 1993	GEARCASE - STANDARD ROTATION
E250XETS 1993	GEARCASE - STANDARD ROTATION
E250TZATF 1993	GEARCASE - STANDARD ROTATION
E250TZATS 1993	GEARCASE - STANDARD ROTATION
E250TZEND 1992	GEARCASE - STANDARD ROTATION
E250TZEOR 1995	GEARCASE - STANDARD ROTATION
E250TZERC 1994	GEARCASE - STANDARD ROTATION
E250TZETF 1993	GEARCASE - STANDARD ROTATION
E250TZETS 1993	GEARCASE - STANDARD ROTATION
E275CLCUR 1987	GEARCASE
E275CXCCA 1988	GEARCASE - STANDARD ROTATION
E275CXCUR 1987	GEARCASE
E275PLCCA 1988	GEARCASE - STANDARD ROTATION
E275PLCUR 1987	GEARCASE
E275PTLCDC 1986	GEARCASE
E275PTXCDC 1986	GEARCASE
E275PXCCA 1988	GEARCASE - STANDARD ROTATION
E275PXCUR 1987	GEARCASE
E275TLCOS 1985	GEARCASE
E275TXCOS 1985	GEARCASE
E300CLCUR 1987	GEARCASE
E300CXCCA 1988	GEARCASE - STANDARD ROTATION
E300CXCEM 1989	GEARCASE - STANDARD ROTATION
E300CXCUR 1987	GEARCASE
E300XEIE 1991	GEARCASE - STANDARD ROTATION
E300XEND 1992	GEARCASE - STANDARD ROTATION
E300XEOR 1995	GEARCASE - STANDARD ROTATION
E300XERC 1994	GEARCASE - STANDARD ROTATION

E300CXESB 1990	GEARCASE - STANDARD ROTATION
E300CXETF 1993	GEARCASE - STANDARD ROTATION
E300CXETS 1993	GEARCASE - STANDARD ROTATION
E300PLCCA 1988	GEARCASE - STANDARD ROTATION
E300PLCEM 1989	GEARCASE - STANDARD ROTATION
E300PLCUR 1987	GEARCASE
E300PLEIE 1991	GEARCASE - STANDARD ROTATION
E300PLEND 1992	GEARCASE - STANDARD ROTATION
E300PLEOR 1995	GEARCASE - STANDARD ROTATION
E300PLERC 1994	GEARCASE - STANDARD ROTATION
E300PLESB 1990	GEARCASE - STANDARD ROTATION
E300PLETF 1993	GEARCASE - STANDARD ROTATION
E300PLETS 1993	GEARCASE - STANDARD ROTATION
E300PXCCA 1988	GEARCASE - STANDARD ROTATION
E300PXCEM 1989	GEARCASE - STANDARD ROTATION
E300PXCUR 1987	GEARCASE
E300PXEIE 1991	GEARCASE - STANDARD ROTATION
E300PXEND 1992	GEARCASE - STANDARD ROTATION
E300PXEOR 1995	GEARCASE - STANDARD ROTATION
E300PXERC 1994	GEARCASE - STANDARD ROTATION
E300PXESB 1990	GEARCASE - STANDARD ROTATION
E300PXETF 1993	GEARCASE - STANDARD ROTATION
E300PXETS 1993	GEARCASE - STANDARD ROTATION
E300TLCDC 1986	GEARCASE
E300TLCOS 1985	GEARCASE
E300TXCDC 1986	GEARCASE
E300TXCOS 1985	GEARCASE
E60HGLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type

E60HSLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HSLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HSLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E75DPGLAFA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFC	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFD	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFF	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFG	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLIIS	GEARCASE, S-Type
E75DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLINC	GEARCASE, S-Type
E75DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLISD	GEARCASE - PL, SL MODELS
E75DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLISF	GEARCASE - PL, SL MODELS
E75DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S

E75DPLSCB	GEARCASE - PL, SL MODELS
E75DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSDA	GEARCASE - PL, SL MODELS
E75DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E75DPLSEE	GEARCASE - PL, SL MODELS
E75DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSOR	GEARCASE PL & SL MODELS
E75DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES
E75DPLSRC	GEARCASE PL & SL MODELS
E75DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E75DPLSUM	GEARCASE - PL, SL MODELS
E75DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFD	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFD	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFG	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFG	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLIIA	GEARCASE, S-Type
E75DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLINM	GEARCASE, S-Type
E75DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLISF	GEARCASE - PL, SL MODELS
E75DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLISR	GEARCASE - PL, SL MODELS
E75DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLSCS	GEARCASE - PL, SL MODELS
E75DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLSEC	GEARCASE - PL, SL MODELS
E75DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS

E75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E75FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL
E75FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E75FPLSTA	GEARCASE - FPL, FSL MODELS
E75FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E75FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E75FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E85MLCSA 1980	GEARCASE
E85STLCSA 1980	GEARCASE
E85STXCSEA 1980	GEARCASE
E85TTLEIE 1991	GEARCASE
E85TTLEND 1992	GEARCASE
E85TTLEOR 1995	GEARCASE
E85TTLERC 1994	GEARCASE
E85TTLETS 1993	GEARCASE
E88MSLCCC 1988	GEARCASE
E88MSLCER 1989	GEARCASE
E88MSLCUS 1987	GEARCASE
E88MSLEDC 1996	GEARCASE
E88MSLEIM 1991	GEARCASE
E88MSLENB 1992	GEARCASE
E88MSLEOS 1995	GEARCASE
E88MSLERD 1994	GEARCASE
E88MSLESA 1990	GEARCASE
E88MSLETE 1993	GEARCASE
E88TSLEDR 1996	GEARCASE
E88TSLEOC 1995	GEARCASE
E88TSLERS 1994	GEARCASE
E90DGXAFA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type

E90DGXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DHLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90DHLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90DMXSES	GEARCASE - DMX
E90DPGLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLIIS	GEARCASE, S-Type
E90DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLINC	GEARCASE, S-Type
E90DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLISD	GEARCASE - PL, SL MODELS
E90DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLISF	GEARCASE - PL, SL MODELS
E90DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSCB	GEARCASE - PL, SL MODELS
E90DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSDA	GEARCASE - PL, SL MODELS
E90DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E90DPLSEE	GEARCASE - PL, SL MODELS
E90DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSOR	GEARCASE PL & SL MODELS
E90DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES
E90DPLSRC	GEARCASE PL & SL MODELS
E90DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E90DPLSUM	GEARCASE - PL, SL MODELS
E90DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S

E90DPXAAA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXABA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXABB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPX AFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXIIS	GEARCASE, O-Type
E90DPXIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXINC	GEARCASE, O-Type
E90DPXINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXISD	GEARCASE - PX MODELS
E90DPXISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXISF	GEARCASE - PX MODELS
E90DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSCB	GEARCASE - PX MODELS
E90DPXSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSDA	GEARCASE - PX MODELS
E90DPXSDA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E90DPXSEE	GEARCASE - PX MODELS
E90DPXSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSOR	GEARCASE PX , W MODELS
E90DPXSOR - FR	07-1_BOÎTIER D'ENGRENAGES PX , W MODELES
E90DPXSRC	GEARCASE PX MODELS
E90DPXSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E90DPXSUM	GEARCASE - PX MODELS
E90DPXSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DSLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLafa	07-1_GEARCASE, (0.42 Ratio) S2-Type

E90DSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL AFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL AFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL AFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL I ID	GEARCASE, S-Type
E90DSL I ID - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL I NS	GEARCASE, S-Type
E90DSL I NS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL I SE	GEARCASE - PL, SL MODELS
E90DSL I SE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL I SF	GEARCASE - PL, SL MODELS
E90DSL I SF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL S CM	GEARCASE - PL, SL MODELS
E90DSL S CM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL S DR	GEARCASE - PL, SL MODELS
E90DSL S DR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E90DSL S EB	GEARCASE - PL, SL MODELS
E90DSL S EB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL S OC	GEARCASE PL & SL MODELS
E90DSL S OR - FR	07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES
E90DSL S RC	GEARCASE PL & SL MODELS
E90DSL S RC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E90DSL S UA	GEARCASE - PL, SL MODELS
E90DSL S UM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E90ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
E90ELEDR 1996	GEARCASE - 20 IN. MODELS
E90ELEDR 1996	GEARCASE - 25 IN. MODELS
E90ELEOC 1995	GEARCASE - 20 IN. MODELS
E90ELEOC 1995	GEARCASE - 25 IN. MODELS
E90ELEUA 1997	GEARCASE - 20 IN. MODELS
E90ELEUA 1997	GEARCASE - 25 IN. MODELS
E90ELEUC 1997	GEARCASE - 20 IN. MODELS
E90ELEUC 1997	GEARCASE - 25 IN. MODELS

E90EXEOC 1995	GEARCASE - 20 IN. MODELS
E90EXEOC 1995	GEARCASE - 25 IN. MODELS
E90FPLEEC 1999	GEARCASE -- FPL, FSL MODELS
E90FPLEEC 1999	GEARCASE -- FPX MODELS
E90FPLEEN 1999	GEARCASE -- FPL, FSL MODELS
E90FPLEEN 1999	GEARCASE -- FPX MODELS
E90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E90FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL
E90FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E90FPLSTB	GEARCASE - FPL, FSL MODELS
E90FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E90FSLECS 1998	GEARCASE -- FSL, FTL MODELS
E90FSLECS 1998	GEARCASE -- FSX MODELS
E90FSLSTB	GEARCASE - FPL, FSL MODELS
E90FSLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E90FTLECS 1998	GEARCASE -- FSL, FTL MODELS
E90FTLECS 1998	GEARCASE -- FSX MODELS
E90FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E90FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E90GLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90HGLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type

E90HGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGXAFF	07-1_GEARCASE, O-Type
E90HGXAFF	07-1_GEARCASE, O-Type
E90HGXAFFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSXAFA	07-1_GEARCASE, O-Type
E90HSXAFF	07-1_GEARCASE, O-Type
E90HSXAFFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E90JLEIE 1991	GEARCASE
E90JLEND 1992	GEARCASE
E90JLEOR 1995	GEARCASE
E90JLERC 1994	GEARCASE
E90JLETS 1993	GEARCASE
E90MLCDC 1986	GEARCASE
E90MLCIH 1981	GEARCASE
E90MLCIM 1981	GEARCASE
E90MLCNB 1982	GEARCASE
E90MLCOS 1985	GEARCASE

E90MLCRD 1984	GEARCASE
E90MLCTE 1983	GEARCASE
E90MLCUR 1987	GEARCASE
E90MLEOR 1995	GEARCASE
E90MLERC 1994	GEARCASE
E90SLABA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E90SLEDR 1996	GEARCASE - 20 IN. MODELS
E90SLEDR 1996	GEARCASE - 25 IN. MODELS
E90SLEOC 1995	GEARCASE - 20 IN. MODELS
E90SLEOC 1995	GEARCASE - 25 IN. MODELS
E90SLEUA 1997	GEARCASE - 20 IN. MODELS
E90SLEUA 1997	GEARCASE - 25 IN. MODELS
E90SLEUC 1997	GEARCASE - 20 IN. MODELS
E90SLEUC 1997	GEARCASE - 25 IN. MODELS
E90SNLABA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90TLCCA 1988	GEARCASE
E90TLCDC 1986	GEARCASE
E90TLCEM 1989	GEARCASE
E90TLCIH 1981	GEARCASE
E90TLCIM 1981	GEARCASE
E90TLCNB 1982	GEARCASE
E90TLCOS 1985	GEARCASE

E90TLCRD 1984	GEARCASE
E90TLCTE 1983	GEARCASE
E90TLCUR 1987	GEARCASE
E90TLEDA 1996	GEARCASE
E90TLEIE 1991	GEARCASE
E90TLEND 1992	GEARCASE
E90TLEOR 1995	GEARCASE
E90TLERC 1994	GEARCASE
E90TLESB 1990	GEARCASE
E90TLETS 1993	GEARCASE
E90TSLECM 1998	GEARCASE
E90TSLEUA 1997	GEARCASE
E90TXARC 1994	GEARCASE
E90TXATS 1993	GEARCASE
E90TXCDC 1986	GEARCASE
E90TXCIH 1981	GEARCASE
E90TXCIM 1981	GEARCASE
E90TXCNB 1982	GEARCASE
E90TXCOS 1985	GEARCASE
E90TXCRD 1984	GEARCASE
E90TXCTE 1983	GEARCASE
E90WDELIIA	GEARCASE, S-Type
E90WDELIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELINM	GEARCASE, S-Type
E90WDELINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELISF	GEARCASE - PL, SL MODELS
E90WDELISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELISR	GEARCASE - PL, SL MODELS
E90WDELISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELSCS	GEARCASE - PL, SL MODELS
E90WDELSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELSEC	GEARCASE - PL, SL MODELS
E90WDELSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDEXIIA	GEARCASE, O-Type
E90WDEXIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E90WDEXINM	GEARCASE, O-Type
E90WDEXINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXISF	GEARCASE - PX MODELS
E90WDEXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXISR	GEARCASE - PX MODELS
E90WDEXISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXSCS	GEARCASE - PX MODELS
E90WDEXSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXSEC	GEARCASE - PX MODELS
E90WDEXSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDPLSOS	GEARCASE PX , W MODELS
E90WDPLSOS - FR	07-1_BOÎTIER D'ENGRENAGES PX , W MODELES
HE115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
HE115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
HE115SLEDR 1996	GEARCASE - 20 IN. MODELS
HE115SLEDR 1996	GEARCASE - 25 IN. MODELS
HE115SLEUA 1997	GEARCASE - 20 IN. MODELS
HE115SLEUA 1997	GEARCASE - 25 IN. MODELS
HE115SLEUC 1997	GEARCASE - 20 IN. MODELS
HE115SLEUC 1997	GEARCASE - 25 IN. MODELS
HE115TXADA 1996	GEARCASE
HE130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130CXAUUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130TXACB 1998	GEARCASE
HE130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130TXAUUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE88MSLEDC 1996	GEARCASE
HE90MLEDA 1996	GEARCASE
HE90TXADA 1996	GEARCASE
HJ115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
HJ115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
HJ115SLEDR 1996	GEARCASE - 20 IN. MODELS
HJ115SLEDR 1996	GEARCASE - 25 IN. MODELS
HJ115SLEUA 1997	GEARCASE - 20 IN. MODELS
HJ115SLEUA 1997	GEARCASE - 25 IN. MODELS

HJ115SLEUC 1997	GEARCASE - 20 IN. MODELS
HJ115SLEUC 1997	GEARCASE - 25 IN. MODELS
HJ115TXADA 1996	GEARCASE
HJ130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130CXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130TXACB 1998	GEARCASE
HJ130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ88MSLEDC 1996	GEARCASE
HJ90MLEDA 1996	GEARCASE
HJ90TXADA 1996	GEARCASE
J100MLCSC 1980	GEARCASE
J100STLCCA 1988	GEARCASE
J100STLCEM 1989	GEARCASE
J100STLEIE 1991	GEARCASE
J100STLEND 1992	GEARCASE
J100STLERC 1994	GEARCASE
J100STLESB 1990	GEARCASE
J100STLETS 1993	GEARCASE
J100TRLCSC 1980	GEARCASE
J100TRXCSC 1980	GEARCASE
J100WMLCDR 1986	GEARCASE
J100WMLCOC 1985	GEARCASE
J100WMLCRS 1984	GEARCASE
J100WPLEEC 1999	GEARCASE
J100WPLSIF commercial, elec start, 20 in shaft 2001	GEARCASE
J100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J100WPXEEC 1999	GEARCASE
J100WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J100WQLECS 1998	GEARCASE -- 100WQL MODELS
J100WQLECS 1998	GEARCASE -- 100WQX MODELS
J100WQXECS 1998	GEARCASE -- 100WQL MODELS
J100WQXECS 1998	GEARCASE -- 100WQX MODELS
J100WTLCDR 1986	GEARCASE

J100WTLCOG 1985	GEARCASE
J100WTLCRS 1984	GEARCASE
J100WTLCUA 1987	GEARCASE
J100WTLEDR 1996	GEARCASE
J100WTLEIB 1991	GEARCASE
J100WTLENE 1992	GEARCASE
J100WTLEOC 1995	GEARCASE
J100WTLERS 1994	GEARCASE
J100WTLESM 1990	GEARCASE EARLY PRODUCTION
J100WTLESM 1990	GEARCASE LATE PRODUCTION
J100WTLETD 1993	GEARCASE
J100WTLEUA 1997	GEARCASE
J100WTLZ 1989	GEARCASE
J100WTXCDR 1986	GEARCASE
J100WTXCUA 1987	GEARCASE
J100WTXEDR 1996	GEARCASE
J100WTXEIB 1991	GEARCASE
J100WTXENE 1992	GEARCASE
J100WTXEOC 1995	GEARCASE
J100WTXERS 1994	GEARCASE
J100WTXESM 1990	GEARCASE EARLY PRODUCTION
J100WTXESM 1990	GEARCASE LATE PRODUCTION
J100WTXETD 1993	GEARCASE
J100WTXEUA 1997	GEARCASE
J100WTXZ 1989	GEARCASE
J105WELEEN 1999	GEARCASE
J105WELEES 1999	GEARCASE
J105WELSIF commercial, elec start, 20 in shaft 2001	GEARCASE
J105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
J105WPLEEN 1999	GEARCASE
J105WPLEES 1999	GEARCASE
J105WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
J105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J105WPXEEN 1999	GEARCASE
J105WPXEES 1999	GEARCASE

J105WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J105WRLEES 1999	GEARCASE
J105WRLSIF commercial, rope start, 20 in shaft 2001	GEARCASE
J105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
J105WRYEES 1999	GEARCASE
J105WRYSIF commercial, rope start, 22.5 in shaft 2001	GEARCASE
J105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
J110MLCCA 1988	GEARCASE
J110MLCDC 1986	GEARCASE
J110MLCEM 1989	GEARCASE
J110MLCUR 1987	GEARCASE
J110TLAEM 1989	GEARCASE
J110TLCCA 1988	GEARCASE
J110TLCDC 1986	GEARCASE
J110TLCDF 1986	GEARCASE
J110TLCEM 1989	GEARCASE
J110TLCUR 1987	GEARCASE
J110TXCCA 1988	GEARCASE
J110TXCEM 1989	GEARCASE
J110TXCUR 1987	GEARCASE
J112TSLEDR 1996	GEARCASE
J112TSLEOC 1995	GEARCASE
J112TSLERS 1994	GEARCASE
J112TSXEDR 1996	GEARCASE
J112TSXEOC 1995	GEARCASE
J112TSXERS 1994	GEARCASE
J115ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115ELEDR 1996	GEARCASE - 20 IN. MODELS
J115ELEDR 1996	GEARCASE - 25 IN. MODELS
J115ELEOC 1995	GEARCASE - 20 IN. MODELS
J115ELEOC 1995	GEARCASE - 25 IN. MODELS
J115ELEUA 1997	GEARCASE - 20 IN. MODELS
J115ELEUA 1997	GEARCASE - 25 IN. MODELS

J115ELEUC 1997	GEARCASE - 20 IN. MODELS
J115ELEUC 1997	GEARCASE - 25 IN. MODELS
J115FSLECS 1998	GEARCASE -- FSL, FTL MODELS
J115FSLECS 1998	GEARCASE -- FSX MODELS
J115FSXECS 1998	GEARCASE -- FSL, FTL MODELS
J115FSXECS 1998	GEARCASE -- FSX MODELS
J115FTLECS 1998	GEARCASE -- FSL, FTL MODELS
J115FTLECS 1998	GEARCASE -- FSX MODELS
J115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115GLEDR 1996	GEARCASE - 20 IN. MODELS
J115GLEDR 1996	GEARCASE - 25 IN. MODELS
J115GLEOC 1995	GEARCASE - 20 IN. MODELS
J115GLEOC 1995	GEARCASE - 25 IN. MODELS
J115GLEUA 1997	GEARCASE - 20 IN. MODELS
J115GLEUA 1997	GEARCASE - 25 IN. MODELS
J115GLEUC 1997	GEARCASE - 20 IN. MODELS
J115GLEUC 1997	GEARCASE - 25 IN. MODELS
J115GLSDE	GEARCASE - PL, GL MODELS
J115GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J115GLSOB	GEARCASE - PL, GL MODELS
J115GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115GLSRC	GEARCASE - PL, GL MODELS
J115GLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115GLSTA	GEARCASE - PL, GL MODELS
J115GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J115JKLEOC 1995	GEARCASE
J115JKLERS 1994	GEARCASE
J115JLEDA 1996	GEARCASE
J115JLEIE 1991	GEARCASE
J115JLEND 1992	GEARCASE
J115JLEOR 1995	GEARCASE
J115JLERC 1994	GEARCASE
J115JLETS 1993	GEARCASE
J115JPLEEC 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS

J115JPLEEC 1999	GEARCASE -- 90 & 115 PX MODELS
J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115JTLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115JTLECS 1998	GEARCASE -- 90 & 115 SX MODELS
J115MLCIH 1981	GEARCASE
J115MLCIM 1981	GEARCASE
J115MLCNB 1982	GEARCASE
J115MLCOS 1985	GEARCASE
J115MLCRD 1984	GEARCASE
J115MLCSA 1980	GEARCASE
J115MLCTE 1983	GEARCASE
J115MLEIE 1991	GEARCASE
J115MLEND 1992	GEARCASE
J115MLEOR 1995	GEARCASE
J115MLERS 1994	GEARCASE
J115MLESB 1990	GEARCASE
J115MLETS 1993	GEARCASE
J115PLEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115PLEEM 1999	GEARCASE -- 90 & 115 PX MODELS
J115PLSDA	GEARCASE - PL, GL MODELS
J115PLSDA - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J115PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J115PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J115PLSOR	GEARCASE - PL, GL MODELS
J115PLSOR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115PLSRC	GEARCASE - PL, GL MODELS
J115PLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS

J115PLSTS	GEARCASE - PL, GL MODELS
J115PLSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J115PXEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115PXEEM 1999	GEARCASE -- 90 & 115 PX MODELS
J115PXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J115PXSNF Carbureted, 25 in. shaft, White, Remote, Elec, TNT, 2002	GEARCASE - PLS, VLS MODELS
J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115PXSTS	GEARCASE - PL, GL MODELS
J115PXSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115SLEDR 1996	GEARCASE - 20 IN. MODELS
J115SLEDR 1996	GEARCASE - 25 IN. MODELS
J115SLEOC 1995	GEARCASE - 20 IN. MODELS
J115SLEOC 1995	GEARCASE - 25 IN. MODELS
J115SLEUA 1997	GEARCASE - 20 IN. MODELS
J115SLEUA 1997	GEARCASE - 25 IN. MODELS
J115SLEUC 1997	GEARCASE - 20 IN. MODELS
J115SLEUC 1997	GEARCASE - 25 IN. MODELS
J115SPLEES 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115SPLEES 1999	GEARCASE -- 90 & 115 PX MODELS
J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115SXEDR 1996	GEARCASE - 20 IN. MODELS
J115SXEDR 1996	GEARCASE - 25 IN. MODELS
J115SXEOC 1995	GEARCASE - 20 IN. MODELS
J115SXEOC 1995	GEARCASE - 25 IN. MODELS
J115SXEUA 1997	GEARCASE - 20 IN. MODELS
J115SXEUA 1997	GEARCASE - 25 IN. MODELS
J115SXEUC 1997	GEARCASE - 20 IN. MODELS
J115SXEUC 1997	GEARCASE - 25 IN. MODELS

J115TLAIE 1991	GEARCASE
J115TLAND 1992	GEARCASE
J115TLARC 1994	GEARCASE
J115TLASB 1990	GEARCASE
J115TLATS 1993	GEARCASE
J115TLCIH 1981	GEARCASE
J115TLCIM 1981	GEARCASE
J115TLCNB 1982	GEARCASE
J115TLCOS 1985	GEARCASE
J115TLCRD 1984	GEARCASE
J115TLCSA 1980	GEARCASE
J115TLCTE 1983	GEARCASE
J115TLEDA 1996	GEARCASE
J115TLEIE 1991	GEARCASE
J115TLEND 1992	GEARCASE
J115TLEOR 1995	GEARCASE
J115TLERC 1994	GEARCASE
J115TLESB 1990	GEARCASE
J115TLETS 1993	GEARCASE
J115TSLECM 1998	GEARCASE
J115TSLEUA 1997	GEARCASE
J115TSXECM 1998	GEARCASE
J115TSXEUA 1997	GEARCASE
J115TXADA 1996	GEARCASE
J115TXAOR 1995	GEARCASE
J115TXARS 1994	GEARCASE
J115TXATS 1993	GEARCASE
J115TXCIH 1981	GEARCASE
J115TXCIM 1981	GEARCASE
J115TXCNB 1982	GEARCASE
J115TXCRD 1984	GEARCASE
J115TXCSA 1980	GEARCASE
J115TXCTE 1983	GEARCASE
J115TXEIE 1991	GEARCASE
J115TXEND 1992	GEARCASE

J115TXESB 1990	GEARCASE
J115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J115VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J115VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J115VLSSS Elec. Start, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115VLSSS Elec. Start, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J120TLAEM 1989	GEARCASE - 120TL & TX/140 TL
J120TLAEM 1989	GEARCASE - 140TX STANDARD ROTATION
J120TLAIE 1991	GEARCASE - 120TL & TX/140 TL
J120TLAIE 1991	GEARCASE - 140TX STANDARD ROTATION
J120TLAND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TLAND 1992	GEARCASE - 140TX STANDARD ROTATION
J120TLARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLASB 1990	GEARCASE - 120TL & TX/140 TL
J120TLASB 1990	GEARCASE - 140TX STANDARD ROTATION
J120TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLCCA 1988	GEARCASE - 120TL & TX/140 TL
J120TLCCA 1988	GEARCASE - 140TX STANDARD ROTATION
J120TLCDC 1986	GEARCASE
J120TLCEM 1989	GEARCASE - 120TL & TX/140 TL
J120TLCEM 1989	GEARCASE - 140TX STANDARD ROTATION
J120TLCOS 1985	GEARCASE

J120TLCUR 1987	GEARCASE
J120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
J120TLEIE 1991	GEARCASE - 140TX STANDARD ROTATION
J120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TLEND 1992	GEARCASE - 140TX STANDARD ROTATION
J120TLERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLERC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLESB 1990	GEARCASE - 120TL & TX/140 TL
J120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
J120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXCCA 1988	GEARCASE - 120TL & TX/140 TL
J120TXCCA 1988	GEARCASE - 140TX STANDARD ROTATION
J120TXCDC 1986	GEARCASE
J120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
J120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
J120XCCOS 1985	GEARCASE
J120TXCUR 1987	GEARCASE
J120TXEIE 1991	GEARCASE - 120TL & TX/140 TL

J120TXEIE 1991	GEARCASE - 140TX STANDARD ROTATION
J120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TXEND 1992	GEARCASE - 140TX STANDARD ROTATION
J120TXERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXERC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXESB 1990	GEARCASE - 120TL & TX/140 TL
J120TXESB 1990	GEARCASE - 140TX STANDARD ROTATION
J120TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125ESXENR 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J125ESXENR 1992	GEARCASE - 140TX STANDARD ROTATION
J125ESXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J125ESXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J125ESXESS 1990	GEARCASE - ESX MODELS ONLY
J125ESXETA 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J125ESXETA 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125ESXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J125ESXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125ESXW 1989	GEARCASE - ESX MODELS ONLY
J125WTPLE 1995	GEARCASE
J130CXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130PLEED 1999	GEARCASE
J130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J130PXEEED 1999	GEARCASE
J130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J130TLECE 1998	GEARCASE
J130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION

J130TLEOA 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXACB 1998	GEARCASE
J130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE
J135PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J135VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J135VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE
J140CXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140CXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140CXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXCCS 1988	GEARCASE - 120TL & TX/140 TL
J140CXCCS 1988	GEARCASE - 140TX STANDARD ROTATION
J140CXCEC 1989	GEARCASE - 120TL & TX/140 TL
J140CXCEC 1989	GEARCASE - 140TX STANDARD ROTATION
J140CXEIA 1991	GEARCASE - 120TL & TX/140 TL
J140CXEIA 1991	GEARCASE - 140TX STANDARD ROTATION
J140CXENM 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140CXENM 1992	GEARCASE - 140TX STANDARD ROTATION
J140CXERE 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXERE 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXESR 1990	GEARCASE - 120TL & TX/140 TL
J140CXESR 1990	GEARCASE - 140TX STANDARD ROTATION
J140CXETB 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

J140CXETB 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140CXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140MLCIH 1981	GEARCASE
J140MLCIM 1981	GEARCASE
J140MLCNB 1982	GEARCASE
J140MLCSA 1980	GEARCASE
J140MLCTE 1983	GEARCASE
J140TLAEB 1989	GEARCASE - 120TL & TX/140 TL
J140TLAEB 1989	GEARCASE - 140TX STANDARD ROTATION
J140TLANS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TLANS 1992	GEARCASE - 140TX STANDARD ROTATION
J140TLARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLARR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLARR 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLASE 1990	GEARCASE - 120TL & TX/140 TL
J140TLASE 1990	GEARCASE - 140TX STANDARD ROTATION
J140TLATC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLATC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLCCM 1988	GEARCASE - 120TL & TX/140 TL
J140TLCCM 1988	GEARCASE - 140TX STANDARD ROTATION
J140TLCDC 1986	GEARCASE
J140TLCEB 1989	GEARCASE - 120TL & TX/140 TL
J140TLCEB 1989	GEARCASE - 140TX STANDARD ROTATION
J140TLCIH 1981	GEARCASE
J140TLCIM 1981	GEARCASE
J140TLCNB 1982	GEARCASE
J140TLCOS 1985	GEARCASE
J140TLCRD 1984	GEARCASE

J140TLCSA 1980	GEARCASE
J140TLCTE 1983	GEARCASE
J140TLCUA 1987	GEARCASE
J140TLEID 1991	GEARCASE - 120TL & TX/140 TL
J140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
J140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
J140TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLERR 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLESE 1990	GEARCASE - 120TL & TX/140 TL
J140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
J140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXCCM 1988	GEARCASE - 120TL & TX/140 TL
J140TXCCM 1988	GEARCASE - 140TX STANDARD ROTATION
J140TXCDC 1986	GEARCASE
J140TXCEB 1989	GEARCASE - 120TL & TX/140 TL
J140TXCEB 1989	GEARCASE - 140TX STANDARD ROTATION
J140TXCIH 1981	GEARCASE

J140TXCIM 1981	GEARCASE
J140TXCNB 1982	GEARCASE
J140TXCOS 1985	GEARCASE
J140TXCRD 1984	GEARCASE
J140TXCSA 1980	GEARCASE
J140TXCTE 1983	GEARCASE
J140TXCUA 1987	GEARCASE
J140TXEID 1991	GEARCASE - 120TL & TX/140 TL
J140TXEID 1991	GEARCASE - 140TX STANDARD ROTATION
J140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TXENS 1992	GEARCASE - 140TX STANDARD ROTATION
J140TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXERR 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXESE 1990	GEARCASE - 120TL & TX/140 TL
J140TXESE 1990	GEARCASE - 140TX STANDARD ROTATION
J140TXETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J150CXCCA 1988	GEARCASE - STANDARD ROTATION
J150CXCEM 1989	GEARCASE - STANDARD ROTATION
J150CXEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150CXEIE 1991	GEARCASE - STANDARD ROTATION
J150CXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J150CXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150ELAIS 1991	GEARCASE - STANDARD ROTATION
J150ELANC 1992	GEARCASE - STANDARD ROTATION

J150ELARA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELARA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELATR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELATR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEIS 1991	GEARCASE - STANDARD ROTATION
J150ELENC 1992	GEARCASE - STANDARD ROTATION
J150ELEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150ELERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

J150EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEIS 1991	GEARCASE - STANDARD ROTATION
J150EXENC 1992	GEARCASE - STANDARD ROTATION
J150EXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS

J150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEIS 1991	GEARCASE - STANDARD ROTATION
J150GLENC 1992	GEARCASE - STANDARD ROTATION
J150GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150GLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150GLSDE	GEARCASE - PL - GL MODELS
J150GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J150GLSOB	GEARCASE - PL - SL MODELS
J150GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J150GLSRM	GEARCASE - PL - GL MODELS
J150GLSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J150GLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J150GLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard

J150GTLCUR 1987	GEARCASE
J150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150ILECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150ILECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150JLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150JLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150JLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150JLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEIE 1991	GEARCASE - STANDARD ROTATION
J150JLENC 1992	GEARCASE - STANDARD ROTATION
J150JLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150JLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150JLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150JLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150JLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150JLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150JLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150JPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150JPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS

J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXCED 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150NXCED 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEIS 1991	GEARCASE - STANDARD ROTATION
J150NXENC 1992	GEARCASE - STANDARD ROTATION
J150NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXCUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150PLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150PLSDD	GEARCASE - PL - GL MODELS
J150PLSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150PLSOE	GEARCASE - PL - SL MODELS
J150PLSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J150PLSRB	GEARCASE - PL - GL MODELS
J150PLSRB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150PLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J150PLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard
J150PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J150SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150STLACA 1988	GEARCASE
J150STLCCA 1988	GEARCASE
J150STLCDC 1986	GEARCASE
J150STLCEM 1989	GEARCASE
J150STLCOH 1985	GEARCASE
J150STLCOS 1985	GEARCASE
J150STLCRD 1984	GEARCASE
J150STLCTE 1983	GEARCASE
J150STLCUR 1987	GEARCASE
J150STLEIE 1991	GEARCASE
J150STLESB 1990	GEARCASE EARLY PRODUCTION
J150STLESB 1990	GEARCASE LATE PRODUCTION
J150TLAEM 1989	GEARCASE - STANDARD ROTATION
J150TLAIE 1991	GEARCASE - STANDARD ROTATION
J150TLASB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J150TLASB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150TLCCA 1988	GEARCASE - STANDARD ROTATION
J150TLCDC 1986	GEARCASE
J150TLCEM 1989	GEARCASE - STANDARD ROTATION
J150TLCIA 1981	GEARCASE
J150TLCIH 1981	GEARCASE
J150TLCNM 1982	GEARCASE
J150TLCOS 1985	GEARCASE
J150TLCRD 1984	GEARCASE
J150TLCSF 1980	GEARCASE
J150TLCSR 1980	GEARCASE
J150TLCTB 1983	GEARCASE

J150TLCTE 1983	GEARCASE
J150TLCUR 1987	GEARCASE
J150TLEIE 1991	GEARCASE - STANDARD ROTATION
J150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150TXCCA 1988	GEARCASE - STANDARD ROTATION
J150TXCDC 1986	GEARCASE
J150TXCEM 1989	GEARCASE - STANDARD ROTATION
J150TXCIA 1981	GEARCASE
J150TXCIH 1981	GEARCASE
J150TXCNM 1982	GEARCASE
J150XCCOS 1985	GEARCASE
J150TXCRD 1984	GEARCASE
J150TXCSF 1980	GEARCASE
J150TXCSR 1980	GEARCASE
J150TXCTB 1983	GEARCASE
J150TXCTE 1983	GEARCASE
J150TXCUR 1987	GEARCASE
J150TXEIE 1991	GEARCASE - STANDARD ROTATION
J150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS

J150WPLEES 1999	GEARCASE
J150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
J150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J150WTLEOR 1995	GEARCASE
J150WTLERC 1994	GEARCASE
J150WTLERV 1994	GEARCASE
J150WTLETG 1993	GEARCASE - 20" MODELS
J150WTLETG 1993	GEARCASE - 25" MODELS
J150WTLETS 1993	GEARCASE - 20" MODELS
J150WTLETS 1993	GEARCASE - 25" MODELS
J150WTXEOR 1995	GEARCASE
J150WTXERC 1994	GEARCASE
J150WTXERV 1994	GEARCASE
J150WTXETG 1993	GEARCASE - 20" MODELS
J150WTXETG 1993	GEARCASE - 25" MODELS
J150WTXETS 1993	GEARCASE - 20" MODELS
J150WTXETS 1993	GEARCASE - 25" MODELS
J155WTLCDR 1986	GEARCASE
J155WTLCOG 1985	GEARCASE
J155WTLCRS 1984	GEARCASE
J155WTLCUA 1987	GEARCASE
J155WTLEIB 1991	GEARCASE
J155WTLENE 1992	GEARCASE
J155WTLISM 1990	GEARCASE
J155WTLZ 1989	GEARCASE
J155WTXCDR 1986	GEARCASE
J155WTXCOC 1985	GEARCASE
J155WTXCRS 1984	GEARCASE
J155WTXCUA 1987	GEARCASE
J155WTXEIB 1991	GEARCASE
J155WTXENE 1992	GEARCASE
J155WTXISM 1990	GEARCASE
J155WTXZ 1989	GEARCASE
J175CXEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS

J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEIS 1991	GEARCASE - STANDARD ROTATION
J175EXENC 1992	GEARCASE - STANDARD ROTATION
J175EXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175FCXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FCXECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEIS 1991	GEARCASE - STANDARD ROTATION
J175GLENC 1992	GEARCASE - STANDARD ROTATION
J175GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175GLSDE	GEARCASE - PL - GL MODELS
J175GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J175GLSOB	GEARCASE - PL - SL MODELS

J175GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J175GLSRM	GEARCASE - PL - GL MODELS
J175GLSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J175GLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J175GLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard
J175NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175NXENC 1992	GEARCASE - STANDARD ROTATION
J175NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J175NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175PLSDD	GEARCASE - PL - GL MODELS
J175PLSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175PLSOE	GEARCASE - PL - SL MODELS
J175PLSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J175PLSRB	GEARCASE - PL - GL MODELS
J175PLSRB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175PLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J175PLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard
J175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J175SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175SLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175SLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J175SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175STLACM 1988	GEARCASE - STANDARD ROTATION
J175STLCCM 1988	GEARCASE - STANDARD ROTATION
J175STLCEB 1989	GEARCASE - STANDARD ROTATION
J175STLEID 1991	GEARCASE - STANDARD ROTATION
J175STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J175STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J175TLCCM 1988	GEARCASE - STANDARD ROTATION
J175TLCDR 1986	GEARCASE
J175TLCIH 1981	GEARCASE
J175TLCIM 1981	GEARCASE
J175TLCNB 1982	GEARCASE
J175TLCOC 1985	GEARCASE
J175TLCSA 1980	GEARCASE
J175TLCSF 1980	GEARCASE
J175TLCTD 1983	GEARCASE
J175TLCTE 1983	GEARCASE
J175TLCUA 1987	GEARCASE
J175TXCCM 1988	GEARCASE - STANDARD ROTATION
J175TXCDR 1986	GEARCASE
J175TXCEB 1989	GEARCASE - STANDARD ROTATION
J175TXCIH 1981	GEARCASE
J175TXCIM 1981	GEARCASE
J175TXCNB 1982	GEARCASE
J175TXCOC 1985	GEARCASE
J175TXCSA 1980	GEARCASE
J175TXCSF 1980	GEARCASE
J175TXCTD 1983	GEARCASE
J175TXCTE 1983	GEARCASE
J175TXCUA 1987	GEARCASE

J175TXEID 1991	GEARCASE - STANDARD ROTATION
J175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J185ESERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J185ESERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXENR 1992	GEARCASE - STANDARD ROTATION
J185ESXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J185ESXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J185ESXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J185ESXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J185ESXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXW 1989	GEARCASE - STANDARD ROTATION
J185TLCOC 1985	GEARCASE
J185TLCRS 1984	GEARCASE
J185TXCOC 1985	GEARCASE
J185TXCR 1984	GEARCASE
J200CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXCCR 1988	GEARCASE - STANDARD ROTATION
J200CXCEA 1989	GEARCASE - STANDARD ROTATION
J200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200CXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200CXEIB 1991	GEARCASE - STANDARD ROTATION
J200CXENE 1992	GEARCASE - STANDARD ROTATION
J200CXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J200CXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J200CXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200CXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS

J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200STLACM 1988	GEARCASE - STANDARD ROTATION
J200STLCCM 1988	GEARCASE - STANDARD ROTATION
J200STLCDR 1986	GEARCASE
J200STLCEB 1989	GEARCASE - STANDARD ROTATION
J200STLCUA 1987	GEARCASE
J200STLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200STLECE 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J200STLEDM 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLEID 1991	GEARCASE - STANDARD ROTATION
J200STLENS 1992	GEARCASE - STANDARD ROTATION
J200STLEOA 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLEOA 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLERR 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLERR 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J200STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J200STLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200STLEUB 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLEUB 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TLCIH 1981	GEARCASE
J200TLCNE 1982	GEARCASE
J200TLCSF 1980	GEARCASE
J200TLCSM 1980	GEARCASE
J200TLCTD 1983	GEARCASE
J200TLCTS 1983	GEARCASE
J200TLECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200TLECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J200TXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXCCR 1988	GEARCASE - STANDARD ROTATION
J200TXCDS 1986	GEARCASE
J200TXCEA 1989	GEARCASE - STANDARD ROTATION
J200TXCIB 1981	GEARCASE
J200TXCIH 1981	GEARCASE
J200TXCNE 1982	GEARCASE
J200TXCSF 1980	GEARCASE
J200TXCSM 1980	GEARCASE
J200TXCTD 1983	GEARCASE
J200TXCTS 1983	GEARCASE
J200TXCUC 1987	GEARCASE
J200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200TXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS

J200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXEIB 1991	GEARCASE - STANDARD ROTATION
J200TXENE 1992	GEARCASE - STANDARD ROTATION
J200TXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

J200TZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200WPXEEN 1999	GEARCASE
J200WPXEES 1999	GEARCASE
J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	GEARCASE
J225CLCUB 1987	GEARCASE
J225CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XCCE 1988	GEARCASE - STANDARD ROTATION
J225XCED 1989	GEARCASE - STANDARD ROTATION
J225XCUB 1987	GEARCASE
J225XECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225XECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225XEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225XEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XEED 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225XEED 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225XEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225XEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225XEIC 1991	GEARCASE - STANDARD ROTATION
J225XENR 1992	GEARCASE - STANDARD ROTATION
J225XEOb 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225XEOb 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225CXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225CXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

J225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225CZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225CZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS

J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225HPLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225HPLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225HPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225HPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225PLAED 1989	GEARCASE - STANDARD ROTATION
J225PLASS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225PLASS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225PLCCE 1988	GEARCASE - STANDARD ROTATION
J225PLCED 1989	GEARCASE - STANDARD ROTATION
J225PLCUB 1987	GEARCASE
J225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PLEIC 1991	GEARCASE - STANDARD ROTATION
J225PLENR 1992	GEARCASE - STANDARD ROTATION
J225PLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225PTLCDA 1986	GEARCASE
J225PTXCDA 1986	GEARCASE
J225PXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXCE 1988	GEARCASE - STANDARD ROTATION
J225PXCED 1989	GEARCASE - STANDARD ROTATION
J225PXCUB 1987	GEARCASE
J225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PXEIC 1991	GEARCASE - STANDARD ROTATION
J225PXENR 1992	GEARCASE - STANDARD ROTATION
J225PXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225PXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225PZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225STLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225STLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225STLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLERC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLAED 1989	GEARCASE - STANDARD ROTATION
J225TLASS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225TLASS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225TLCCE 1988	GEARCASE - STANDARD ROTATION
J225TLCDA 1986	GEARCASE
J225TLCED 1989	GEARCASE - STANDARD ROTATION
J225TLCUB 1987	GEARCASE
J225TLEIC 1991	GEARCASE - STANDARD ROTATION
J225TLENR 1992	GEARCASE - STANDARD ROTATION
J225TLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

J225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXCCE 1988	GEARCASE - STANDARD ROTATION
J225TXCDA 1986	GEARCASE
J225TXCED 1989	GEARCASE - STANDARD ROTATION
J225TXCUB 1987	GEARCASE
J225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225TXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225TXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXEIC 1991	GEARCASE - STANDARD ROTATION
J225TXENR 1992	GEARCASE - STANDARD ROTATION
J225TXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION

J225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225XEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225ZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225ZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225ZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225ZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225ZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225ZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225ZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225ZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J235STLCOR 1985	GEARCASE
J235STLCRC 1984	GEARCASE
J235STLCTS 1983	GEARCASE
J235TLCIB 1981	GEARCASE
J235TLCIH 1981	GEARCASE
J235TLCNE 1982	GEARCASE
J235TLCOR 1985	GEARCASE
J235TLCRC 1984	GEARCASE
J235TLCSM 1980	GEARCASE
J235TLCTD 1983	GEARCASE
J235TLCTS 1983	GEARCASE
J235TXCIB 1981	GEARCASE
J235TXCIH 1981	GEARCASE
J235TXCNE 1982	GEARCASE
J235TXCOR 1985	GEARCASE
J235TXCRC 1984	GEARCASE
J235TXCSM 1980	GEARCASE

J235TXCTD 1983	GEARCASE
J235TXCTS 1983	GEARCASE
J250CXARC 1994	GEARCASE - STANDARD ROTATION
J250CXATF 1993	GEARCASE - STANDARD ROTATION
J250CXATS 1993	GEARCASE - STANDARD ROTATION
J250CXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250CXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CXEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CXEIE 1991	GEARCASE - STANDARD ROTATION
J250CXEND 1992	GEARCASE - STANDARD ROTATION
J250CXEOR 1995	GEARCASE - STANDARD ROTATION
J250CXERC 1994	GEARCASE - STANDARD ROTATION
J250CXETF 1993	GEARCASE - STANDARD ROTATION
J250CXETS 1993	GEARCASE - STANDARD ROTATION
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250CZATF 1993	GEARCASE - STANDARD ROTATION
J250CZATS 1993	GEARCASE - STANDARD ROTATION
J250CZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250CZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250CZEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CZEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CZEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CZEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CZEND 1992	GEARCASE - STANDARD ROTATION
J250CZEOR 1995	GEARCASE - STANDARD ROTATION
J250CZERC 1994	GEARCASE - STANDARD ROTATION
J250CZETF 1993	GEARCASE - STANDARD ROTATION

J250CZETS 1993	GEARCASE - STANDARD ROTATION
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250PXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250PXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250PXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250PZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250PZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250PZEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PZEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PZEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PZEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250TXARC 1994	GEARCASE - STANDARD ROTATION
J250TXATF 1993	GEARCASE - STANDARD ROTATION
J250TXATS 1993	GEARCASE - STANDARD ROTATION
J250TXEIE 1991	GEARCASE - STANDARD ROTATION
J250TXEND 1992	GEARCASE - STANDARD ROTATION
J250TXEOR 1995	GEARCASE - STANDARD ROTATION
J250TXERC 1994	GEARCASE - STANDARD ROTATION
J250TXETF 1993	GEARCASE - STANDARD ROTATION
J250TXETS 1993	GEARCASE - STANDARD ROTATION
J250TZATF 1993	GEARCASE - STANDARD ROTATION

J250TZATS 1993	GEARCASE - STANDARD ROTATION
J250TZEND 1992	GEARCASE - STANDARD ROTATION
J250TZEOR 1995	GEARCASE - STANDARD ROTATION
J250TZERC 1994	GEARCASE - STANDARD ROTATION
J250TZETF 1993	GEARCASE - STANDARD ROTATION
J250TZETS 1993	GEARCASE - STANDARD ROTATION
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J275CLCUR 1987	GEARCASE
J275CXCCA 1988	GEARCASE - STANDARD ROTATION
J275CXCUR 1987	GEARCASE
J275PLCCA 1988	GEARCASE - STANDARD ROTATION

J275PLCUR 1987	GEARCASE
J275PTLCDC 1986	GEARCASE
J275PTXCDC 1986	GEARCASE
J275PXCCA 1988	GEARCASE - STANDARD ROTATION
J275PXCUR 1987	GEARCASE
J275TLCOS 1985	GEARCASE
J275TXCOS 1985	GEARCASE
J300CLCUR 1987	GEARCASE
J300CXCCA 1988	GEARCASE - STANDARD ROTATION
J300CXCEM 1989	GEARCASE - STANDARD ROTATION
J300CXCUR 1987	GEARCASE
J300CXEIE 1991	GEARCASE - STANDARD ROTATION
J300CXEND 1992	GEARCASE - STANDARD ROTATION
J300CXEOR 1995	GEARCASE - STANDARD ROTATION
J300CXERC 1994	GEARCASE - STANDARD ROTATION
J300CXESB 1990	GEARCASE - STANDARD ROTATION
J300CXETF 1993	GEARCASE - STANDARD ROTATION
J300CXETS 1993	GEARCASE - STANDARD ROTATION
J300PLCCA 1988	GEARCASE - STANDARD ROTATION
J300PLCEM 1989	GEARCASE - STANDARD ROTATION
J300PLCUR 1987	GEARCASE
J300PLEIE 1991	GEARCASE - STANDARD ROTATION
J300PLEND 1992	GEARCASE - STANDARD ROTATION
J300PLEOR 1995	GEARCASE - STANDARD ROTATION
J300PLERC 1994	GEARCASE - STANDARD ROTATION
J300PLESB 1990	GEARCASE - STANDARD ROTATION
J300PLETF 1993	GEARCASE - STANDARD ROTATION
J300PLETS 1993	GEARCASE - STANDARD ROTATION
J300PXCCA 1988	GEARCASE - STANDARD ROTATION
J300PXCEM 1989	GEARCASE - STANDARD ROTATION
J300PXCUR 1987	GEARCASE
J300PXEIE 1991	GEARCASE - STANDARD ROTATION
J300PXEND 1992	GEARCASE - STANDARD ROTATION
J300PXEOR 1995	GEARCASE - STANDARD ROTATION
J300PXERC 1994	GEARCASE - STANDARD ROTATION

J300PXESB 1990	GEARCASE - STANDARD ROTATION
J300PXETF 1993	GEARCASE - STANDARD ROTATION
J300PXETS 1993	GEARCASE - STANDARD ROTATION
J300TLCDC 1986	GEARCASE
J300TLCOS 1985	GEARCASE
J300TXCDC 1986	GEARCASE
J300TXCOS 1985	GEARCASE
J85MLCSA 1980	GEARCASE
J85TLCSA 1980	GEARCASE
J85TTLEIE 1991	GEARCASE
J85TTLEND 1992	GEARCASE
J85TTLEOR 1995	GEARCASE
J85TTLERC 1994	GEARCASE
J85TTLETS 1993	GEARCASE
J85TXCSA 1980	GEARCASE
J88MSLCCC 1988	GEARCASE
J88MSLCER 1989	GEARCASE
J88MSLCUS 1987	GEARCASE
J88MSLEDC 1996	GEARCASE
J88MSLEIM 1991	GEARCASE
J88MSLENB 1992	GEARCASE
J88MSLEOS 1995	GEARCASE
J88MSLERD 1994	GEARCASE
J88MSLESA 1990	GEARCASE
J88MSLETE 1993	GEARCASE
J88TSLEDR 1996	GEARCASE
J88TSLEOC 1995	GEARCASE
J88TSLERS 1994	GEARCASE
J90ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J90ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
J90ELEDR 1996	GEARCASE - 20 IN. MODELS
J90ELEDR 1996	GEARCASE - 25 IN. MODELS
J90ELEOC 1995	GEARCASE - 20 IN. MODELS
J90ELEOC 1995	GEARCASE - 25 IN. MODELS
J90ELEUA 1997	GEARCASE - 20 IN. MODELS

J90ELEUA 1997	GEARCASE - 25 IN. MODELS
J90ELEUC 1997	GEARCASE - 20 IN. MODELS
J90ELEUC 1997	GEARCASE - 25 IN. MODELS
J90EXEOC 1995	GEARCASE - 20 IN. MODELS
J90EXEOC 1995	GEARCASE - 25 IN. MODELS
J90FSLECS 1998	GEARCASE -- FSL, FTL MODELS
J90FSLECS 1998	GEARCASE -- FSX MODELS
J90FTLECS 1998	GEARCASE -- FSL, FTL MODELS
J90FTLECS 1998	GEARCASE -- FSX MODELS
J90GLSDE	GEARCASE - PL, GL MODELS
J90GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J90GLSOB	GEARCASE - PL, GL MODELS
J90GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90GLSRM	GEARCASE - PL, GL MODELS
J90GLSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90GLSTA	GEARCASE - PL, GL MODELS
J90GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J90JLEIE 1991	GEARCASE
J90JLEND 1992	GEARCASE
J90JLEOR 1995	GEARCASE
J90JLERC 1994	GEARCASE
J90JLETS 1993	GEARCASE
J90MLCDC 1986	GEARCASE
J90MLCIH 1981	GEARCASE
J90MLCIM 1981	GEARCASE
J90MLCNB 1982	GEARCASE
J90MLCOS 1985	GEARCASE
J90MLCRD 1984	GEARCASE
J90MLCTE 1983	GEARCASE
J90MLCUR 1987	GEARCASE
J90MLEOR 1995	GEARCASE
J90MLERC 1994	GEARCASE
J90PLEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J90PLEEB 1999	GEARCASE -- 90 & 115 PX MODELS
J90PLSDM	GEARCASE - PL, GL MODELS

J90PLSDM - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J90PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J90PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J90PLSOA	GEARCASE - PL, GL MODELS
J90PLSOA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90PLSRR	GEARCASE - PL, GL MODELS
J90PLSRR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J90PLSTC	GEARCASE - PL, GL MODELS
J90PLSTC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J90SLEDR 1996	GEARCASE - 20 IN. MODELS
J90SLEDR 1996	GEARCASE - 25 IN. MODELS
J90SLEOC 1995	GEARCASE - 20 IN. MODELS
J90SLEOC 1995	GEARCASE - 25 IN. MODELS
J90SLEUA 1997	GEARCASE - 20 IN. MODELS
J90SLEUA 1997	GEARCASE - 25 IN. MODELS
J90SLEUC 1997	GEARCASE - 20 IN. MODELS
J90SLEUC 1997	GEARCASE - 25 IN. MODELS
J90SPLEES 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J90SPLEES 1999	GEARCASE -- 90 & 115 PX MODELS
J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J90TLAEM 1989	GEARCASE
J90TLAIE 1991	GEARCASE
J90TLAND 1992	GEARCASE
J90TLARC 1994	GEARCASE
J90TLASB 1990	GEARCASE
J90TLATS 1993	GEARCASE
J90TLCCA 1988	GEARCASE

J90TLCDC 1986	GEARCASE
J90TLCEM 1989	GEARCASE
J90TLCIH 1981	GEARCASE
J90TLCIM 1981	GEARCASE
J90TLCNB 1982	GEARCASE
J90TLCOS 1985	GEARCASE
J90TLCRD 1984	GEARCASE
J90TLCTE 1983	GEARCASE
J90TLCUR 1987	GEARCASE
J90TLEDA 1996	GEARCASE
J90TLEIE 1991	GEARCASE
J90TLEND 1992	GEARCASE
J90TLEOR 1995	GEARCASE
J90TLERC 1994	GEARCASE
J90TLESB 1990	GEARCASE
J90TLETS 1993	GEARCASE
J90TSLECM 1998	GEARCASE
J90TSLEUA 1997	GEARCASE
J90TXARC 1994	GEARCASE
J90TXATS 1993	GEARCASE
J90TXCDC 1986	GEARCASE
J90TXCIH 1981	GEARCASE
J90TXCIM 1981	GEARCASE
J90TXCNB 1982	GEARCASE
J90TXCOS 1985	GEARCASE
J90TXCRD 1984	GEARCASE
J90TXCTE 1983	GEARCASE
J90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J90VLSNF - FR	27-1_BÔÎTIER D'ENGRENAGES - Modèles PLS et VLS
J90VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
L115GLECA 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS

L115GLECA 1998	GEARCASE -- 90 & 115 SX MODELS
L115GLEDC 1996	GEARCASE - 20 IN. MODELS
L115GLEDC 1996	GEARCASE - 25 IN. MODELS
L115GLEOS 1995	GEARCASE - 20 IN. MODELS
L115GLEOS 1995	GEARCASE - 25 IN. MODELS
L115GLEUC 1997	GEARCASE - 20 IN. MODELS
L115GLEUC 1997	GEARCASE - 25 IN. MODELS
L115GLEUR 1997	GEARCASE - 20 IN. MODELS
L115GLEUR 1997	GEARCASE - 25 IN. MODELS
L150GLECA 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
L150GLECA 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
L150GLEDC 1996	GEARCASE - STANDARD ROTATION - GL MODELS
L150GLEDC 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEOS 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
L150GLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
L150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
L150GLEUR 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEUR 1997	GEARCASE - STANDARD ROTATION - GL MODELS
L90GLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
L90GLECS 1998	GEARCASE -- 90 & 115 SX MODELS
LE200SLEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LE200SLEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LE200SLEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LE200SLEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LJ200SLEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LJ200SLEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LJ200SLEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LJ200SLEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
RE115FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE115FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS

RE115FLSSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FLSSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FLSSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FLSSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE115FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
RE115FSSSH FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FSSSH FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FSSSR FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FSSSR FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE115FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
RE115FXSSH FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FXSSH FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FXSSR FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FXSSR FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS

RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS

RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS

RE200FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FGSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FGSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FHSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS

RE225FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FZSSH FFI, Elec Start, TNT, 30 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RJ115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
RJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
RJ130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE
RJ135PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE

RJ135VXSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS

RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225CX SIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225CX SIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225CX SIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS

RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS

RJ90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ90VLSSE Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ90VLSSE Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
SE100WMPLM 1996	GEARCASE
SE100WMPLZ 1997	GEARCASE
SE100WTPLM 1996	GEARCASE
SE100WTPLZ 1997	GEARCASE
SE105RWLH 1998	GEARCASE
SE105RWLP 1997	GEARCASE
SE105RWYH 1998	GEARCASE
SE105RWYP 1997	GEARCASE
SE105WELV 1998	GEARCASE
SE105WEXV 1998	GEARCASE
SE105WRPLV 1998	GEARCASE
SE105WRPXV 1998	GEARCASE
SE125RWYJ 1997	GEARCASE
SE125RWYN 1998	GEARCASE
SE125RWYV 1996	GEARCASE
SE125WTPLJ 1997	GEARCASE
SE125WTPLN 1998	GEARCASE
SE125WTPLV 1996	GEARCASE
SE125WTPXJ 1997	GEARCASE
SE125WTPXN 1998	GEARCASE
SE125WTPXV 1996	GEARCASE
SE150WTPLB 1996	GEARCASE
SE150WTPLT 1997	GEARCASE
SE150WTPLT4 1997	GEARCASE
SE150WTPLY 1998	GEARCASE
SE150WTPXB 1996	GEARCASE
SE150WTPXT 1997	GEARCASE
SE150WTPXT4 1997	GEARCASE

SE150WTPXY 1998	GEARCASE
SE200WTPLA 1996	GEARCASE
SE200WTPLG 1998	GEARCASE
SE200WTPLS 1997	GEARCASE
SE200WTPXA 1996	GEARCASE
SE200WTPXG 1998	GEARCASE
SE200WTPXS 1997	GEARCASE
SE225GLECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225GLECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SE225NXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225NXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SE225NZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225NZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SE225QXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225QXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SE225QZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225QZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ100WMPLM 1996	GEARCASE
SJ100WMPLZ 1997	GEARCASE
SJ100WTPLM 1996	GEARCASE
SJ100WTPLZ 1997	GEARCASE
SJ105RWLH 1998	GEARCASE
SJ105RWLP 1997	GEARCASE
SJ105RWYH 1998	GEARCASE
SJ105RWYP 1997	GEARCASE
SJ105WELV 1998	GEARCASE
SJ105WEXV 1998	GEARCASE
SJ105WRPLV 1998	GEARCASE
SJ105WRPXV 1998	GEARCASE
SJ115ELEDR 1996	GEARCASE - 20 IN. MODELS

SJ115ELED R 1996	GEARCASE - 25 IN. MODELS
SJ125RWYJ 1997	GEARCASE
SJ125RWYN 1998	GEARCASE
SJ125RWYV 1996	GEARCASE
SJ125WTPLJ 1997	GEARCASE
SJ125WTPLN 1998	GEARCASE
SJ125WTPLV 1996	GEARCASE
SJ125WTPXJ 1997	GEARCASE
SJ125WTPXN 1998	GEARCASE
SJ125WTPXV 1996	GEARCASE
SJ130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ130TLED M 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ150ELED B 1996	GEARCASE - STANDARD ROTATION - GL MODELS
SJ150ELED B 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
SJ150WTPL B 1996	GEARCASE
SJ150WTPL T 1997	GEARCASE
SJ150WTPL T4 1997	GEARCASE
SJ150WTPL Y 1998	GEARCASE
SJ150WTPX B 1996	GEARCASE
SJ150WTPX T 1997	GEARCASE
SJ150WTPX T4 1997	GEARCASE
SJ150WTPX Y 1998	GEARCASE
SJ200CXEC M 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200CXEC M 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ200CXEU A 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200CXEU A 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200SLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200SLECE 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ200SLED M 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200SLED M 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

SJ200SLEUB 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200SLEUB 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200TXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200WTPLA 1996	GEARCASE
SJ200WTPLG 1998	GEARCASE
SJ200WTPLS 1997	GEARCASE
SJ200WTPXA 1996	GEARCASE
SJ200WTPXG 1998	GEARCASE
SJ200WTPXS 1997	GEARCASE
SJ225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225CXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225CXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225CXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225GLECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225GLECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225NXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225NXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225NZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225NZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225QXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

SJ225QXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225QZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225QZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225SLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225SLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225SLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225SLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225SLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225SLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225TXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225TXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225TXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ90ELEDR 1996	GEARCASE - 20 IN. MODELS
SJ90ELEDR 1996	GEARCASE - 25 IN. MODELS
TE110TLCEM 1989	GEARCASE
TE110TLESF 1989	GEARCASE
TE110TXCEM 1989	GEARCASE
TE115TLEIE 1991	GEARCASE
TE115TLEND 1992	GEARCASE
TE115TLESB 1990	GEARCASE
TE115TLETS 1993	GEARCASE
TE120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
TE120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
TE150GLEIS 1991	GEARCASE - STANDARD ROTATION
TE150GLENC 1992	GEARCASE - STANDARD ROTATION
TE150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TE150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

TE150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TE150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TE150SLCEM 1989	GEARCASE
TE150SLEIE 1991	GEARCASE
TE150SLESB 1990	GEARCASE EARLY PRODUCTION
TE150SLESB 1990	GEARCASE LATE PRODUCTION
TE150TXCEM 1989	GEARCASE - STANDARD ROTATION
TE200TXCEA 1989	GEARCASE - STANDARD ROTATION
TE90TLCEM 1989	GEARCASE
TE90TLEIE 1991	GEARCASE
TE90TLEND 1992	GEARCASE
TE90TLESB 1990	GEARCASE
TE90TLESF 1989	GEARCASE
TE90TLESF 1990	GEARCASE
TE90TLETS 1993	GEARCASE
TJ110TLCEM 1989	GEARCASE
TJ110TXCEM 1989	GEARCASE
TJ115TLEIE 1991	GEARCASE
TJ115TLEND 1992	GEARCASE
TJ115TLESB 1990	GEARCASE
TJ115TLETS 1993	GEARCASE
TJ120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
TJ120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
TJ150GLEIS 1991	GEARCASE - STANDARD ROTATION
TJ150GLENC 1992	GEARCASE - STANDARD ROTATION
TJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TJ150SLCEM 1989	GEARCASE
TJ150SLEIE 1991	GEARCASE
TJ150SLESB 1990	GEARCASE EARLY PRODUCTION
TJ150SLESB 1990	GEARCASE LATE PRODUCTION
TJ150TXCEM 1989	GEARCASE - STANDARD ROTATION
TJ200TXCEA 1989	GEARCASE - STANDARD ROTATION

TJ90TLCEM 1989	GEARCASE
TJ90TLEIE 1991	GEARCASE
TJ90TLEND 1992	GEARCASE
TJ90TLESB 1990	GEARCASE
TJ90TLETS 1993	GEARCASE
V115SHLETS 1993	GEARCASE
V115SLEIE 1991	GEARCASE
V115SLEND 1992	GEARCASE
V115SLETS 1993	GEARCASE
V150SLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
V150SLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
V150SLETS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
V150SLETS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
V90SLEIE 1991	GEARCASE
V90SLEND 1992	GEARCASE
V90SLETE 1993	GEARCASE
VE100SLEIE 1991	GEARCASE
VE100SLEND 1992	GEARCASE
VE100SLESB 1990	GEARCASE
VE100SLETS 1993	GEARCASE
VE115TLEIE 1991	GEARCASE
VE115TLESB 1990	GEARCASE
VE115TLETS 1993	GEARCASE
VE115TXEIE 1991	GEARCASE
VE115TXESB 1990	GEARCASE
VE120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
VE120TLEIE 1991	GEARCASE - 140TX STANDARD ROTATION
VE120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE120TLEND 1992	GEARCASE - 140TX STANDARD ROTATION
VE120TLESB 1990	GEARCASE - 120TL & TX/140 TL
VE120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
VE120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

VE120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
VE120TXEIE 1991	GEARCASE - 140TX STANDARD ROTATION
VE120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE120TXEND 1992	GEARCASE - 140TX STANDARD ROTATION
VE120TXESB 1990	GEARCASE - 120TL & TX/140 TL
VE120TXESB 1990	GEARCASE - 140TX STANDARD ROTATION
VE120TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TXETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TLEID 1991	GEARCASE - 120TL & TX/140 TL
VE140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
VE140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
VE140TLESE 1990	GEARCASE - 120TL & TX/140 TL
VE140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
VE140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TXEID 1991	GEARCASE - 120TL & TX/140 TL
VE140TXEID 1991	GEARCASE - 140TX STANDARD ROTATION
VE140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE140TXENS 1992	GEARCASE - 140TX STANDARD ROTATION
VE140TXESE 1990	GEARCASE - 120TL & TX/140 TL
VE140TXESE 1990	GEARCASE - 140TX STANDARD ROTATION
VE140TXETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX

VE140TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE150ELEIS 1991	GEARCASE - STANDARD ROTATION
VE150ELENC 1992	GEARCASE - STANDARD ROTATION
VE150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150EXEIS 1991	GEARCASE - STANDARD ROTATION
VE150EXENC 1992	GEARCASE - STANDARD ROTATION
VE150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150GLEIS 1991	GEARCASE - STANDARD ROTATION
VE150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150HLEOS 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150HLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
VE150SLEIE 1991	GEARCASE
VE150SLESB 1990	GEARCASE EARLY PRODUCTION
VE150SLESB 1990	GEARCASE LATE PRODUCTION
VE150TLEIE 1991	GEARCASE - STANDARD ROTATION
VE150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE150TXEIE 1991	GEARCASE - STANDARD ROTATION
VE150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE175EXEIS 1991	GEARCASE - STANDARD ROTATION
VE175EXENC 1992	GEARCASE - STANDARD ROTATION
VE175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

VE175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175GLEIS 1991	GEARCASE - STANDARD ROTATION
VE175GLENC 1992	GEARCASE - STANDARD ROTATION
VE175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175SLEID 1991	GEARCASE - STANDARD ROTATION
VE175SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE175SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE175TXEID 1991	GEARCASE - STANDARD ROTATION
VE175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE200SLEID 1991	GEARCASE - STANDARD ROTATION
VE200SLENS 1992	GEARCASE - STANDARD ROTATION
VE200SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE200SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE200SLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200SLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200SLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200SLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TXEIB 1991	GEARCASE - STANDARD ROTATION
VE200TXENE 1992	GEARCASE - STANDARD ROTATION
VE200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

VE200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PLEIC 1991	GEARCASE - STANDARD ROTATION
VE225PLENR 1992	GEARCASE - STANDARD ROTATION
VE225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PXEIC 1991	GEARCASE - STANDARD ROTATION
VE225PXENR 1992	GEARCASE - STANDARD ROTATION
VE225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TLEIC 1991	GEARCASE - STANDARD ROTATION
VE225TLENR 1992	GEARCASE - STANDARD ROTATION
VE225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

VE225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TXEIC 1991	GEARCASE - STANDARD ROTATION
VE225TXENR 1992	GEARCASE - STANDARD ROTATION
VE225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE88MSLCCC 1988	GEARCASE
VE88MSLCER 1989	GEARCASE
VE88MSLESA 1990	GEARCASE
VE90MLEIE 1991	GEARCASE
VE90MLEND 1992	GEARCASE
VE90MLESB 1990	GEARCASE
VE90MLETS 1993	GEARCASE
VE90TLEIE 1991	GEARCASE
VE90TLEND 1992	GEARCASE
VE90TLESB 1990	GEARCASE
VE90TLETS 1993	GEARCASE
VJ100SLEIE 1991	GEARCASE
VJ100SLEND 1992	GEARCASE
VJ100SLESB 1990	GEARCASE
VJ100SLETS 1993	GEARCASE
VJ115TLAIE 1991	GEARCASE
VJ115TLAND 1992	GEARCASE
VJ115TLASB 1990	GEARCASE
VJ115TLATS 1993	GEARCASE

VJ115TLEIE 1991	GEARCASE
VJ115TLESB 1990	GEARCASE
VJ115TLETS 1993	GEARCASE
VJ115TXEIE 1991	GEARCASE
VJ115TXESB 1990	GEARCASE
VJ120TLAIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TLAIE 1991	GEARCASE - 140TX STANDARD ROTATION
VJ120TLAND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TLAND 1992	GEARCASE - 140TX STANDARD ROTATION
VJ120TLASB 1990	GEARCASE - 120TL & TX/140 TL
VJ120TLASB 1990	GEARCASE - 140TX STANDARD ROTATION
VJ120TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TLEIE 1991	GEARCASE - 140TX STANDARD ROTATION
VJ120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TLEND 1992	GEARCASE - 140TX STANDARD ROTATION
VJ120TLESB 1990	GEARCASE - 120TL & TX/140 TL
VJ120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
VJ120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TXEIE 1991	GEARCASE - 140TX STANDARD ROTATION
VJ120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TXEND 1992	GEARCASE - 140TX STANDARD ROTATION
VJ120TXESB 1990	GEARCASE - 120TL & TX/140 TL
VJ120TXESB 1990	GEARCASE - 140TX STANDARD ROTATION

VJ120TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TXETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TLAID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TLAID 1991	GEARCASE - 140TX STANDARD ROTATION
VJ140TLANS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TLANS 1992	GEARCASE - 140TX STANDARD ROTATION
VJ140TLASE 1990	GEARCASE - 120TL & TX/140 TL
VJ140TLASE 1990	GEARCASE - 140TX STANDARD ROTATION
VJ140TLEID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
VJ140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
VJ140TLESE 1990	GEARCASE - 120TL & TX/140 TL
VJ140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
VJ140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TXEID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TXEID 1991	GEARCASE - 140TX STANDARD ROTATION
VJ140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TXENS 1992	GEARCASE - 140TX STANDARD ROTATION
VJ140TXESE 1990	GEARCASE - 120TL & TX/140 TL
VJ140TXESE 1990	GEARCASE - 140TX STANDARD ROTATION
VJ140TXETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

VJ140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ150ELANC 1992	GEARCASE - STANDARD ROTATION
VJ150ELATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELATR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELATR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELEIS 1991	GEARCASE - STANDARD ROTATION
VJ150ELENC 1992	GEARCASE - STANDARD ROTATION
VJ150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150EXEIS 1991	GEARCASE - STANDARD ROTATION
VJ150EXENC 1992	GEARCASE - STANDARD ROTATION
VJ150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150GLEIS 1991	GEARCASE - STANDARD ROTATION
VJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150HLEOS 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150HLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
VJ150SLEIE 1991	GEARCASE
VJ150SLESB 1990	GEARCASE EARLY PRODUCTION
VJ150SLESB 1990	GEARCASE LATE PRODUCTION
VJ150TLEIE 1991	GEARCASE - STANDARD ROTATION
VJ150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ150TXEIE 1991	GEARCASE - STANDARD ROTATION
VJ150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION

VJ175EXEIS 1991	GEARCASE - STANDARD ROTATION
VJ175EXENC 1992	GEARCASE - STANDARD ROTATION
VJ175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175GLEIS 1991	GEARCASE - STANDARD ROTATION
VJ175GLENC 1992	GEARCASE - STANDARD ROTATION
VJ175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175SLEID 1991	GEARCASE - STANDARD ROTATION
VJ175SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ175SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ175TXEID 1991	GEARCASE - STANDARD ROTATION
VJ175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ200SLEID 1991	GEARCASE - STANDARD ROTATION
VJ200SLENS 1992	GEARCASE - STANDARD ROTATION
VJ200SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ200SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ200SLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200SLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200SLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200SLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TXEIB 1991	GEARCASE - STANDARD ROTATION
VJ200TXENE 1992	GEARCASE - STANDARD ROTATION
VJ200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

VJ200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PLEIC 1991	GEARCASE - STANDARD ROTATION
VJ225PLENR 1992	GEARCASE - STANDARD ROTATION
VJ225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PXEIC 1991	GEARCASE - STANDARD ROTATION
VJ225PXENR 1992	GEARCASE - STANDARD ROTATION
VJ225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TLASS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225TLASS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225TLEIC 1991	GEARCASE - STANDARD ROTATION
VJ225TLENR 1992	GEARCASE - STANDARD ROTATION
VJ225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION

VJ225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TXEIC 1991	GEARCASE - STANDARD ROTATION
VJ225TXENR 1992	GEARCASE - STANDARD ROTATION
VJ225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ88MSLCCC 1988	GEARCASE
VJ88MSLCER 1989	GEARCASE
VJ88MSLESA 1990	GEARCASE
VJ90MLEIE 1991	GEARCASE
VJ90MLEND 1992	GEARCASE
VJ90MLESB 1990	GEARCASE
VJ90MLETS 1993	GEARCASE
VJ90TLAIE 1991	GEARCASE
VJ90TLAND 1992	GEARCASE
VJ90TLASB 1990	GEARCASE
VJ90TLATS 1993	GEARCASE
VJ90TLEIE 1991	GEARCASE
VJ90TLEND 1992	GEARCASE
VJ90TLESB 1990	GEARCASE
VJ90TLETS 1993	GEARCASE

W100WTLM 1988	GEARCASE
W100WTXM 1988	GEARCASE
X155WTLM 1988	GEARCASE
X155WTXM 1988	GEARCASE
XE112TSLEDR 1996	GEARCASE
XE112TSLEOC 1995	GEARCASE
XE112TSLERS 1994	GEARCASE
XE112TSXEDR 1996	GEARCASE
XE112TSXEOC 1995	GEARCASE
XE112TSXERS 1994	GEARCASE
XE115HLECM 1998	GEARCASE
XE115HLEUA 1997	GEARCASE
XE115HXECM 1998	GEARCASE
XE115HXEUA 1997	GEARCASE
XE88TSLEDR 1996	GEARCASE
XE88TSLEOC 1995	GEARCASE
XE88TSLERS 1994	GEARCASE
XE90TSLECM 1998	GEARCASE
XE90TSLEUA 1997	GEARCASE
XJ112TSLEDR 1996	GEARCASE
XJ112TSLEOC 1995	GEARCASE
XJ112TSLERS 1994	GEARCASE
XJ112TSXEDR 1996	GEARCASE
XJ112TSXEOC 1995	GEARCASE
XJ112TSXERS 1994	GEARCASE
XJ115HLECM 1998	GEARCASE
XJ115HLEUA 1997	GEARCASE
XJ115HXECM 1998	GEARCASE
XJ115HXEUA 1997	GEARCASE
XJ88TSLEDR 1996	GEARCASE
XJ88TSLEOC 1995	GEARCASE
XJ88TSLERS 1994	GEARCASE
XJ90TSLECM 1998	GEARCASE
XJ90TSLEUA 1997	GEARCASE