

Where Used: Part Number 0316075

Model Name	Diagram
50172S 1971	INTAKE MANIFOLD
50173S 1971	INTAKE MANIFOLD
50202C 1972	INTAKE MANIFOLD
50203C 1972	INTAKE MANIFOLD
50272C 1972	INTAKE MANIFOLD
50273C 1972	INTAKE MANIFOLD
50302R 1973	INTAKE MANIFOLD
50303R 1973	INTAKE MANIFOLD
50372R 1973	INTAKE MANIFOLD
50373R 1973	INTAKE MANIFOLD
50442M 1974	INTAKE MANIFOLD
50443M 1974	INTAKE MANIFOLD
50472M 1974	INTAKE MANIFOLD
50473M 1974	INTAKE MANIFOLD
50542B 1975	INTAKE MANIFOLD
50543B 1975	INTAKE MANIFOLD
50572B 1975	INTAKE MANIFOLD
50573B 1975	INTAKE MANIFOLD
50902C 1979	INTAKE MANIFOLD
50903C 1979	INTAKE MANIFOLD
50ES71S 1971	INTAKE MANIFOLD
50ES72C 1972	INTAKE MANIFOLD
50ES73R 1973	INTAKE MANIFOLD
50ES74M 1974	INTAKE MANIFOLD
50ES75B 1975	INTAKE MANIFOLD
50ESL71S 1971	INTAKE MANIFOLD
50ESL72C 1972	INTAKE MANIFOLD
50ESL73R 1973	INTAKE MANIFOLD
50ESL74M 1974	INTAKE MANIFOLD
50ESL75B 1975	INTAKE MANIFOLD
50R72C 1972	INTAKE MANIFOLD
50R73R 1973	INTAKE MANIFOLD
50R79C 1979	INTAKE MANIFOLD

50RL72C 1972	INTAKE MANIFOLD
50RL73R 1973	INTAKE MANIFOLD
50RL79C 1979	INTAKE MANIFOLD
55642E 1976	INTAKE MANIFOLD
55643E 1976	INTAKE MANIFOLD
55672E 1976	INTAKE MANIFOLD
55673E 1976	INTAKE MANIFOLD
55772D 1977	INTAKE MANIFOLD
55773D 1977	INTAKE MANIFOLD
55874S 1978	INTAKE MANIFOLD
55875S 1978	INTAKE MANIFOLD
55974C 1979	INTAKE MANIFOLD
55975C 1979	INTAKE MANIFOLD
55E76E 1976	INTAKE MANIFOLD
55E77D 1977	INTAKE MANIFOLD
55E78S 1978	INTAKE MANIFOLD
55E79C 1979	INTAKE MANIFOLD
55EL76E 1976	INTAKE MANIFOLD
55EL77D 1977	INTAKE MANIFOLD
55EL78S 1978	INTAKE MANIFOLD
55EL79C 1979	INTAKE MANIFOLD
E50BECIC 1981	INTAKE MANIFOLD
E50BECNR 1982	INTAKE MANIFOLD
E50BELCIC 1981	INTAKE MANIFOLD
E50BELCNR 1982	INTAKE MANIFOLD
E50ECSR 1980	INTAKE MANIFOLD
E50ELCSR 1980	INTAKE MANIFOLD
E55RCIM 1981	INTAKE MANIFOLD
E55RLCSA 1980	INTAKE MANIFOLD
E55TLCIM 1981	INTAKE MANIFOLD
E60ECIA 1981	INTAKE MANIFOLD
E60ECIH 1981	INTAKE MANIFOLD
E60ECNM 1982	INTAKE MANIFOLD
E60ECSR 1980	INTAKE MANIFOLD
E60ELCIA 1981	INTAKE MANIFOLD

E60ELCIH 1981	INTAKE MANIFOLD
E60ELCNM 1982	INTAKE MANIFOLD
E60ELCSR 1980	INTAKE MANIFOLD
E60TLCIA 1981	INTAKE MANIFOLD
E60TLCIH 1981	INTAKE MANIFOLD
E60TLCNM 1982	INTAKE MANIFOLD
J50BECIC 1981	INTAKE MANIFOLD
J50BECNR 1982	INTAKE MANIFOLD
J50BELCIC 1981	INTAKE MANIFOLD
J50BELCNR 1982	INTAKE MANIFOLD
J50ECSR 1980	INTAKE MANIFOLD
J50ELCSR 1980	INTAKE MANIFOLD
J55RCIM 1981	INTAKE MANIFOLD
J55RLCIM 1981	INTAKE MANIFOLD
J55RLCSA 1980	INTAKE MANIFOLD
J60ECIA 1981	INTAKE MANIFOLD
J60ECIH 1981	INTAKE MANIFOLD
J60ECNM 1982	INTAKE MANIFOLD
J60ECSR 1980	INTAKE MANIFOLD
J60ELCIA 1981	INTAKE MANIFOLD
J60ELCIH 1981	INTAKE MANIFOLD
J60ELCNM 1982	INTAKE MANIFOLD
J60ELCSR 1980	INTAKE MANIFOLD
J60TLCIA 1981	INTAKE MANIFOLD
J60TLCIH 1981	INTAKE MANIFOLD
J60TLCNM 1982	INTAKE MANIFOLD