

Where Used: Part Number 0317212

| Model Name | Diagram |
|-------------|-----------------|
| 6102E 1971 | INTAKE MANIFOLD |
| 6102G 1971 | INTAKE MANIFOLD |
| 6103E 1971 | INTAKE MANIFOLD |
| 6103G 1971 | INTAKE MANIFOLD |
| 6202D 1972 | INTAKE MANIFOLD |
| 6203D 1972 | INTAKE MANIFOLD |
| 6302S 1973 | INTAKE MANIFOLD |
| 6303S 1973 | INTAKE MANIFOLD |
| 6402C 1974 | INTAKE MANIFOLD |
| 6403C 1974 | INTAKE MANIFOLD |
| 6504R 1975 | INTAKE MANIFOLD |
| 6505R 1975 | INTAKE MANIFOLD |
| 6604A 1976 | INTAKE MANIFOLD |
| 6605A 1976 | INTAKE MANIFOLD |
| 6704M 1977 | INTAKE MANIFOLD |
| 6705M 1977 | INTAKE MANIFOLD |
| 6804B 1978 | INTAKE MANIFOLD |
| 6805B 1978 | INTAKE MANIFOLD |
| 6904E 1979 | INTAKE MANIFOLD |
| 6905E 1979 | INTAKE MANIFOLD |
| 6R71E 1971 | INTAKE MANIFOLD |
| 6R71G 1971 | INTAKE MANIFOLD |
| 6R72D 1972 | INTAKE MANIFOLD |
| 6R73S 1973 | INTAKE MANIFOLD |
| 6R74C 1974 | INTAKE MANIFOLD |
| 6R75R 1975 | INTAKE MANIFOLD |
| 6R76A 1976 | INTAKE MANIFOLD |
| 6R77M 1977 | INTAKE MANIFOLD |
| 6R78B 1978 | INTAKE MANIFOLD |
| 6R79E 1979 | INTAKE MANIFOLD |
| 6RL71E 1971 | INTAKE MANIFOLD |
| 6RL71G 1971 | INTAKE MANIFOLD |
| 6RL72 1972 | INTAKE MANIFOLD |

| | |
|-------------|-----------------|
| 6RL73S 1973 | INTAKE MANIFOLD |
| 6RL74C 1974 | INTAKE MANIFOLD |
| 6RL75R 1975 | INTAKE MANIFOLD |
| 6RL76A 1976 | INTAKE MANIFOLD |
| 6RL77M 1977 | INTAKE MANIFOLD |
| 6RL78B 1978 | INTAKE MANIFOLD |
| 6RL79E 1979 | INTAKE MANIFOLD |