

Where Used: Part Number 0318324

Model Name	Diagram
100990S 1979	REMOTE CONTROL
100993S 1979	REMOTE CONTROL
100999S 1979	REMOTE CONTROL
100ML79S 1979	REMOTE CONTROL
100TLR79S 1979	REMOTE CONTROL
100TXLR79S 1979	REMOTE CONTROL
115393M 1973	REMOTE CONTROL
115493B 1974	REMOTE CONTROL
115593 1975	REMOTE CONTROL
115693D 1976	REMOTE CONTROL
115693G 1976	REMOTE CONTROL
115699D 1976	REMOTE CONTROL
115699G 1976	REMOTE CONTROL
115790S 1977	REMOTE CONTROL
115793S 1977	REMOTE CONTROL
115799S 1977	REMOTE CONTROL
115890C 1978	REMOTE CONTROL
115893C 1978	REMOTE CONTROL
115899C 1978	REMOTE CONTROL
115990R 1979	REMOTE CONTROL
115993R 1979	REMOTE CONTROL
115999R 1979	REMOTE CONTROL
115EL77S 1977	REMOTE CONTROL
115ESL73M 1973	REMOTE CONTROL
115ESL74B 1974	REMOTE CONTROL
115ESL75E 1975	REMOTE CONTROL
115ETL74B 1974	REMOTE CONTROL
115ETL75E 1975	REMOTE CONTROL
115ETL77 1977	REMOTE CONTROL
115ETZ78C 1978	REMOTE CONTROL
115ML78C 1978	REMOTE CONTROL
115ML79R 1979	REMOTE CONTROL
115TL79R 1979	REMOTE CONTROL

115TXL77S 1977	REMOTE CONTROL
115TXL78C 1978	REMOTE CONTROL
115TXL79R 1979	REMOTE CONTROL
135383M 1973	REMOTE CONTROL
135443B 1974	REMOTE CONTROL
135483B 1974	REMOTE CONTROL
135489B 1974	REMOTE CONTROL
135543E 1975	REMOTE CONTROL
135583E 1975	REMOTE CONTROL
135589E 1975	REMOTE CONTROL
135643D 1976	REMOTE CONTROL
135643G 1976	REMOTE CONTROL
135683D 1976	REMOTE CONTROL
135683G 1976	REMOTE CONTROL
135ESL73M 1973	REMOTE CONTROL
135ESL74B 1974	REMOTE CONTROL
135ESL75E 1975	REMOTE CONTROL
135ETL74B 1974	REMOTE CONTROL
135ETL75E 1975	REMOTE CONTROL
140740S 1977	REMOTE CONTROL
140743S 1977	REMOTE CONTROL
140783S 1977	REMOTE CONTROL
140840C 1978	REMOTE CONTROL
140843C 1978	REMOTE CONTROL
140883C 1978	REMOTE CONTROL
140940R 1979	REMOTE CONTROL
140943R 1979	REMOTE CONTROL
140983R 1979	REMOTE CONTROL
140ML77S 1977	REMOTE CONTROL
140ML78C 1978	REMOTE CONTROL
140ML79R 1979	REMOTE CONTROL
140TL77S 1977	REMOTE CONTROL
140TL78C 1978	REMOTE CONTROL
140TL79R 1979	REMOTE CONTROL
140TX78C 1978	REMOTE CONTROL

140TXL77S 1977	REMOTE CONTROL
140TXL79R 1979	REMOTE CONTROL
150840S 1978	REMOTE CONTROL
150849S 1978	REMOTE CONTROL
150940C 1979	REMOTE CONTROL
150949C 1979	REMOTE CONTROL
150TL78S 1978	REMOTE CONTROL
150TL79C 1979	REMOTE CONTROL
150TXL78S 1978	REMOTE CONTROL
150TXL79C 1979	REMOTE CONTROL
175740S 1977	REMOTE CONTROL
175749S 1977	REMOTE CONTROL
175840C 1978	REMOTE CONTROL
175840S 1978	REMOTE CONTROL
175940R 1979	REMOTE CONTROL
175949R 1979	REMOTE CONTROL
175TL77S 1977	REMOTE CONTROL
175TL78C 1978	REMOTE CONTROL
175TL79R 1979	REMOTE CONTROL
175TX78C 1978	REMOTE CONTROL
175TXL77S 1977	REMOTE CONTROL
175TXL79R 1979	REMOTE CONTROL
200490A 1979	REMOTE CONTROL
200640S 1976	REMOTE CONTROL
200649S 1976	REMOTE CONTROL
200740C 1977	REMOTE CONTROL
200749C 1977	REMOTE CONTROL
200840R 1978	REMOTE CONTROL
200849R 1978	REMOTE CONTROL
200940A 1979	REMOTE CONTROL
200949A 1979	REMOTE CONTROL
200TL76S 1976	REMOTE CONTROL
200TL77C 1977	REMOTE CONTROL
200TL78R 1978	REMOTE CONTROL
200TL79A 1979	REMOTE CONTROL

200TX78R 1978	REMOTE CONTROL
200TXL76S 1976	REMOTE CONTROL
200TXL77C 1977	REMOTE CONTROL
200TXL79A 1979	REMOTE CONTROL
235840R 1978	REMOTE CONTROL
235849R 1978	REMOTE CONTROL
235940A 1979	REMOTE CONTROL
235949A 1979	REMOTE CONTROL
235TL70A 1979	REMOTE CONTROL
235TL78R 1978	REMOTE CONTROL
235TX78R 1978	REMOTE CONTROL
235TXL79A 1979	REMOTE CONTROL
50302R 1973	REMOTE CONTROL
50303R 1973	REMOTE CONTROL
50372R 1973	REMOTE CONTROL
50373R 1973	REMOTE CONTROL
50442M 1974	REMOTE CONTROL
50443M 1974	REMOTE CONTROL
50472M 1974	REMOTE CONTROL
50473M 1974	REMOTE CONTROL
50542B 1975	REMOTE CONTROL
50543B 1975	REMOTE CONTROL
50572B 1975	REMOTE CONTROL
50573B 1975	REMOTE CONTROL
50902C 1979	REMOTE CONTROL
50903C 1979	REMOTE CONTROL
50ES73R 1973	REMOTE CONTROL
50ES74M 1974	REMOTE CONTROL
50ES75B 1975	REMOTE CONTROL
50ESL73R 1973	REMOTE CONTROL
50ESL74M 1974	REMOTE CONTROL
50ESL75B 1975	REMOTE CONTROL
50R73R 1973	REMOTE CONTROL
50R79C 1979	REMOTE CONTROL
50RL73R 1973	REMOTE CONTROL

50RL79C 1979	REMOTE CONTROL
55642E 1976	REMOTE CONTROL
55643E 1976	REMOTE CONTROL
55672E 1976	REMOTE CONTROL
55673E 1976	REMOTE CONTROL
55772D 1977	REMOTE CONTROL
55773D 1977	REMOTE CONTROL
55874S 1978	REMOTE CONTROL
55875S 1978	REMOTE CONTROL
55974C 1979	REMOTE CONTROL
55975C 1979	REMOTE CONTROL
55E76E 1976	REMOTE CONTROL
55E77D 1977	REMOTE CONTROL
55E78S 1978	REMOTE CONTROL
55E79C 1979	REMOTE CONTROL
55EL76E 1976	REMOTE CONTROL
55EL77D 1977	REMOTE CONTROL
55EL78S 1978	REMOTE CONTROL
55EL79C 1979	REMOTE CONTROL
65372R 1973	REMOTE CONTROL
65373R 1973	REMOTE CONTROL
65ES73R 1973	REMOTE CONTROL
65ESL73R 1973	REMOTE CONTROL
70442M 1974	REMOTE CONTROL
70443M 1974	REMOTE CONTROL
70472M 1974	REMOTE CONTROL
70473M 1974	REMOTE CONTROL
70572B 1975	REMOTE CONTROL
70572E 1975	REMOTE CONTROL
70573B 1975	REMOTE CONTROL
70573E 1975	REMOTE CONTROL
70673D 1976	REMOTE CONTROL
70773S 1977	REMOTE CONTROL
70873C 1978	REMOTE CONTROL
70973R 1979	REMOTE CONTROL

70EL76D 1976	REMOTE CONTROL
70EL77S 1977	REMOTE CONTROL
70EL78C 1978	REMOTE CONTROL
70EL79R 1979	REMOTE CONTROL
70ES74M 1974	REMOTE CONTROL
70ES75B 1975	REMOTE CONTROL
70ES75E 1975	REMOTE CONTROL
70ESL74M 1974	REMOTE CONTROL
70ESL75B 1975	REMOTE CONTROL
70ESL75E 1975	REMOTE CONTROL
70ESLR74M 1974	REMOTE CONTROL
75542B 1975	REMOTE CONTROL
75543B 1975	REMOTE CONTROL
75642D 1976	REMOTE CONTROL
75643D 1976	REMOTE CONTROL
75742S 1977	REMOTE CONTROL
75743S 1977	REMOTE CONTROL
75842C 1978	REMOTE CONTROL
75843C 1978	REMOTE CONTROL
75942R 1979	REMOTE CONTROL
75943R 1979	REMOTE CONTROL
75ELR76D 1976	REMOTE CONTROL
75ELR77S 1977	REMOTE CONTROL
75ELR78C 1978	REMOTE CONTROL
75ELR79R 1979	REMOTE CONTROL
75ER76D 1976	REMOTE CONTROL
75ER77S 1977	REMOTE CONTROL
75ER78C 1978	REMOTE CONTROL
75ER79R 1979	REMOTE CONTROL
75ESLR75B 1975	REMOTE CONTROL
75ESR75B 1975	REMOTE CONTROL
85393M 1973	REMOTE CONTROL
85493B 1974	REMOTE CONTROL
85593E 1975	REMOTE CONTROL
85693D 1976	REMOTE CONTROL

85693G 1976	REMOTE CONTROL
85699G 1976	REMOTE CONTROL
85790S 1977	REMOTE CONTROL
85793S 1977	REMOTE CONTROL
85799S 1977	REMOTE CONTROL
85890C 1978	REMOTE CONTROL
85895C 1978	REMOTE CONTROL
85899C 1978	REMOTE CONTROL
85990R 1979	REMOTE CONTROL
85995R 1979	REMOTE CONTROL
85999R 1979	REMOTE CONTROL
85EL76D 1976	REMOTE CONTROL
85EL76G 1976	REMOTE CONTROL
85EL77S 1977	REMOTE CONTROL
85ESL73M 1973	REMOTE CONTROL
85ESL74B 1974	REMOTE CONTROL
85ESL75E 1975	REMOTE CONTROL
85ETLR76D 1976	REMOTE CONTROL
85ETLR76G 1976	REMOTE CONTROL
85ETLR77S 1977	REMOTE CONTROL
85ETLR78C 1978	REMOTE CONTROL
85ML78C 1978	REMOTE CONTROL
85ML79R 1979	REMOTE CONTROL
85TL79R 1979	REMOTE CONTROL
85TXL79R 1979	REMOTE CONTROL
85TXLR77S 1977	REMOTE CONTROL
85TXLR78C 1978	REMOTE CONTROL
C155WTLM 1988	REMOTE CONTROL
C155WTXM 1988	REMOTE CONTROL
CE275TLCDC 1986	REMOTE CONTROL
CE275TLCDC 1986	VRO PUMP
CE275TLCOS 1985	REMOTE CONTROL
CE275TLCOS 1985	VRO PUMP
CE275TXCDC 1986	REMOTE CONTROL
CE275TXCDC 1986	VRO PUMP

CE275TXCOS 1985	REMOTE CONTROL
CE275TXCOS 1985	VRO PUMP
CE300TLCDC 1986	REMOTE CONTROL
CE300TLCDC 1986	VRO PUMP
CE300TLCOS 1985	REMOTE CONTROL
CE300TLCOS 1985	VRO PUMP
CE300TXCDC 1986	REMOTE CONTROL
CE300TXCDC 1986	VRO PUMP
CE300TXCOS 1985	REMOTE CONTROL
CE300TXCOS 1985	VRO PUMP
CJ275TLCDC 1986	REMOTE CONTROL
CJ275TLCDC 1986	VRO PUMP
CJ275TLCOS 1985	REMOTE CONTROL
CJ275TLCOS 1985	VRO PUMP
CJ275TXCDC 1986	REMOTE CONTROL
CJ275TXCDC 1986	VRO PUMP
CJ275TXCOS 1985	REMOTE CONTROL
CJ275TXCOS 1985	VRO PUMP
CJ300TLCDC 1986	REMOTE CONTROL
CJ300TLCDC 1986	VRO PUMP
CJ300TLCOS 1985	REMOTE CONTROL
CJ300TLCOS 1985	VRO PUMP
CJ300TXCDC 1986	REMOTE CONTROL
CJ300TXCDC 1986	VRO PUMP
CJ300TXCOS 1985	REMOTE CONTROL
CJ300TXCOS 1985	VRO PUMP
D100WTLM 1988	REMOTE CONTROL
D100WTXM 1988	REMOTE CONTROL
E100MLCSC 1980	REMOTE CONTROL
E100STLCCA 1988	REMOTE CONTROL
E100STLCEM 1989	REMOTE CONTROL
E100STLESB 1990	REMOTE CONTROL
E100TLCSC 1980	REMOTE CONTROL
E100TXCSC 1980	REMOTE CONTROL
E100WMLCDR 1986	REMOTE CONTROL

E100WMLCOC 1985	POWER TRIM/TILT ELECTRICAL
E100WMLCOC 1985	REMOTE CONTROL
E100WMLCRS 1984	REMOTE CONTROL
E100WTLCDR 1986	REMOTE CONTROL
E100WTLCOE 1985	POWER TRIM/TILT ELECTRICAL
E100WTLCOE 1985	REMOTE CONTROL
E100WTLCRS 1984	REMOTE CONTROL
E100WTLCUA 1987	REMOTE CONTROL
E100WTLSE 1990	REMOTE CONTROL
E100WTLZ 1989	REMOTE CONTROL
E100WTXCDR 1986	REMOTE CONTROL
E100WTXCUA 1987	REMOTE CONTROL
E100WTXSE 1990	REMOTE CONTROL
E100WTXZ 1989	REMOTE CONTROL
E10EESC 1990	REMOTE CONTROL
E10EESC 1990	REMOTE CONTROL
E10REESC 1990	REMOTE CONTROL
E10RESC 1990	REMOTE CONTROL
E10RESC 1990	REMOTE CONTROL
E10RESC 1990	REMOTE CONTROL
E10SEESC 1990	REMOTE CONTROL
E110MLCCA 1988	REMOTE CONTROL
E110MLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
E110MLCDC 1986	REMOTE CONTROL
E110MLCEM 1989	REMOTE CONTROL
E110MLCUR 1987	REMOTE CONTROL
E110TLCCA 1988	REMOTE CONTROL
E110TLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
E110TLCDC 1986	REMOTE CONTROL
E110TLCDF 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
E110TLCDF 1986	REMOTE CONTROL
E110TLCEM 1989	REMOTE CONTROL
E110TLCUR 1987	REMOTE CONTROL
E110TXCCA 1988	REMOTE CONTROL
E110TXCEM 1989	REMOTE CONTROL
E110TXCUR 1987	REMOTE CONTROL

E115MLCIH 1981	REMOTE CONTROL
E115MLCIM 1981	REMOTE CONTROL
E115MLCNB 1982	REMOTE CONTROL
E115MLCOS 1985	POWER TRIM/TILT ELECTRICAL
E115MLCOS 1985	REMOTE CONTROL
E115MLCRD 1984	REMOTE CONTROL
E115MLCSA 1980	REMOTE CONTROL
E115MLCTE 1983	REMOTE CONTROL
E115MLESB 1990	REMOTE CONTROL
E115TLCIH 1981	REMOTE CONTROL
E115TLCIM 1981	REMOTE CONTROL
E115TLCNB 1982	REMOTE CONTROL
E115TLCOS 1985	POWER TRIM/TILT ELECTRICAL
E115TLCOS 1985	REMOTE CONTROL
E115TLCRD 1984	REMOTE CONTROL
E115TLCSA 1980	REMOTE CONTROL
E115TLCTE 1983	REMOTE CONTROL
E115TLESB 1990	REMOTE CONTROL
E115TXCIH 1981	REMOTE CONTROL
E115TXCIM 1981	REMOTE CONTROL
E115TXCNB 1982	REMOTE CONTROL
E115TXCRD 1984	REMOTE CONTROL
E115TXCSA 1980	REMOTE CONTROL
E115TXCTE 1983	REMOTE CONTROL
E115TXESB 1990	REMOTE CONTROL
E120TLCDC 1986	REMOTE CONTROL
E120TLCEM 1989	REMOTE CONTROL
E120TLCOS 1985	POWER TRIM/TILT ELECTRICAL
E120TLCOS 1985	REMOTE CONTROL
E120TLCUR 1987	REMOTE CONTROL
E120TLESB 1990	REMOTE CONTROL
E120TXCDC 1986	REMOTE CONTROL
E120TXCEM 1989	REMOTE CONTROL
E120TXCOS 1985	POWER TRIM/TILT ELECTRICAL
E120TXCOS 1985	REMOTE CONTROL

E120TXCUR 1987	REMOTE CONTROL
E120TXESB 1990	REMOTE CONTROL
E125ESXESS 1990	REMOTE CONTROL
E125ESXW 1989	REMOTE CONTROL
E125WTPLE 1995	REMOTE CONTROL
E140CXCEC 1989	REMOTE CONTROL
E140CXESR 1990	REMOTE CONTROL
E140MLCIH 1981	REMOTE CONTROL
E140MLCIM 1981	REMOTE CONTROL
E140MLCNB 1982	REMOTE CONTROL
E140MLCSA 1980	REMOTE CONTROL
E140MLCTE 1983	REMOTE CONTROL
E140TLCDC 1986	REMOTE CONTROL
E140TLCEB 1989	REMOTE CONTROL
E140TLCOS 1985	POWER TRIM/TILT ELECTRICAL
E140TLCOS 1985	REMOTE CONTROL
E140TLCRD 1984	REMOTE CONTROL
E140TLCUA 1987	REMOTE CONTROL
E140TLESE 1990	REMOTE CONTROL
E140TRLCIH 1981	REMOTE CONTROL
E140TRLCIM 1981	REMOTE CONTROL
E140TRLCNB 1982	REMOTE CONTROL
E140TRLCSA 1980	REMOTE CONTROL
E140TRLCTE 1983	REMOTE CONTROL
E140TRXCIH 1981	REMOTE CONTROL
E140TRXCIM 1981	REMOTE CONTROL
E140TRXCNB 1982	REMOTE CONTROL
E140TRXCSA 1980	REMOTE CONTROL
E140TRXCTE 1983	REMOTE CONTROL
E140TXCDC 1986	REMOTE CONTROL
E140TXCEB 1989	REMOTE CONTROL
E140TXCOS 1985	POWER TRIM/TILT ELECTRICAL
E140TXCOS 1985	REMOTE CONTROL
E140TXCRD 1984	REMOTE CONTROL
E140TXCUA 1987	REMOTE CONTROL

E140TXESE 1990	REMOTE CONTROL
E150ANCRS 1984	REMOTE CONTROL
E150CXCCA 1988	REMOTE CONTROL
E150CXCEM 1989	REMOTE CONTROL
E150CXESB 1990	REMOTE CONTROL
E150STLCCA 1988	REMOTE CONTROL
E150STLCDC 1986	REMOTE CONTROL
E150STLCEM 1989	REMOTE CONTROL
E150STLCOH 1985	REMOTE CONTROL
E150STLCOS 1985	REMOTE CONTROL
E150STLCRD 1984	REMOTE CONTROL
E150STLCTE 1983	REMOTE CONTROL
E150STLCUR 1987	REMOTE CONTROL
E150STLESB 1990	REMOTE CONTROL
E150TLCCA 1988	REMOTE CONTROL
E150TLCDC 1986	REMOTE CONTROL
E150TLCEM 1989	REMOTE CONTROL
E150TLCOS 1985	REMOTE CONTROL
E150TLCRD 1984	REMOTE CONTROL
E150TLCUR 1987	REMOTE CONTROL
E150TLESB 1990	REMOTE CONTROL
E150TRLCIA 1981	REMOTE CONTROL
E150TRLCIH 1981	REMOTE CONTROL
E150TRLCNM 1982	REMOTE CONTROL
E150TRLCSF 1980	REMOTE CONTROL
E150TRLCSR 1980	REMOTE CONTROL
E150TRLCTB 1983	REMOTE CONTROL
E150TRLCTE 1983	REMOTE CONTROL
E150TRXCIA 1981	REMOTE CONTROL
E150TRXCIH 1981	REMOTE CONTROL
E150TRXCNM 1982	REMOTE CONTROL
E150TRXCSF 1980	REMOTE CONTROL
E150TRXCSR 1980	REMOTE CONTROL
E150TRXCTB 1983	REMOTE CONTROL
E150TRXCTE 1983	REMOTE CONTROL

E150TXCCA 1988	REMOTE CONTROL
E150TXCDC 1986	REMOTE CONTROL
E150TXCEM 1989	REMOTE CONTROL
E150TXCOS 1985	REMOTE CONTROL
E150TXCRD 1984	REMOTE CONTROL
E150TXCUR 1987	REMOTE CONTROL
E150TXESB 1990	REMOTE CONTROL
E150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	REMOTE CONTROL
E150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	REMOTE CONTROL
E150WTLEOR 1995	REMOTE CONTROL
E150WTLERC 1994	REMOTE CONTROL
E150WTLERV 1994	REMOTE CONTROL
E150WTLETG 1993	REMOTE CONTROL
E150WTLETS 1993	REMOTE CONTROL
E150WTXEOR 1995	REMOTE CONTROL
E150WTXERC 1994	REMOTE CONTROL
E150WTXERV 1994	REMOTE CONTROL
E150WTXETG 1993	REMOTE CONTROL
E150WTXETS 1993	REMOTE CONTROL
E155WTLCDR 1986	REMOTE CONTROL
E155WTLCOG 1985	POWER TRIM/TILT ELECTRICAL
E155WTLCOG 1985	REMOTE CONTROL
E155WTLCRS 1984	REMOTE CONTROL
E155WTLCUA 1987	REMOTE CONTROL
E155WTLISM 1990	REMOTE CONTROL
E155WTLZ 1989	REMOTE CONTROL
E155WTXCDR 1986	REMOTE CONTROL
E155WTXCOC 1985	POWER TRIM/TILT ELECTRICAL
E155WTXCOC 1985	REMOTE CONTROL
E155WTXCRS 1984	REMOTE CONTROL
E155WTXCUA 1987	REMOTE CONTROL
E155WTXESM 1990	REMOTE CONTROL
E155WTXZ 1989	REMOTE CONTROL
E15EESR 1990	REMOTE CONTROL

E15ELESR 1990	REMOTE CONTROL
E15RELESR 1990	REMOTE CONTROL
E15RESR 1990	REMOTE CONTROL
E15RLESR 1990	REMOTE CONTROL
E175STLCCM 1988	REMOTE CONTROL
E175STLCEB 1989	REMOTE CONTROL
E175STLESE 1990	REMOTE CONTROL
E175TLCCM 1988	REMOTE CONTROL
E175TLCDR 1986	REMOTE CONTROL
E175TLCOC 1985	REMOTE CONTROL
E175TLCUA 1987	REMOTE CONTROL
E175TRLCIM 1981	REMOTE CONTROL
E175TRLCNB 1982	REMOTE CONTROL
E175TRLCSA 1980	REMOTE CONTROL
E175TRLCSF 1980	REMOTE CONTROL
E175TRLCTD 1983	REMOTE CONTROL
E175TRLCTE 1983	REMOTE CONTROL
E175TRXCIH 1981	REMOTE CONTROL
E175TRXCIM 1981	REMOTE CONTROL
E175TRXCNB 1982	REMOTE CONTROL
E175TRXCSA 1980	REMOTE CONTROL
E175TRXCSF 1980	REMOTE CONTROL
E175TRXCTD 1983	REMOTE CONTROL
E175TRXCTE 1983	REMOTE CONTROL
E175TXCCM 1988	REMOTE CONTROL
E175TXCDR 1986	REMOTE CONTROL
E175TXCEB 1989	REMOTE CONTROL
E175TXCOC 1985	REMOTE CONTROL
E175TXCUA 1987	REMOTE CONTROL
E175TXESE 1990	REMOTE CONTROL
E185ESXESS 1990	REMOTE CONTROL
E185ESXW 1989	REMOTE CONTROL
E185TLCOC 1985	REMOTE CONTROL
E185TLCRS 1984	REMOTE CONTROL
E185TXCOC 1985	REMOTE CONTROL

E20CRLCUR 1987	REMOTE CONTROL
E20ECDC 1986	REMOTE CONTROL
E20ECEM 1989	REMOTE CONTROL
E20ECOS 1985	REMOTE CONTROL
E20ECUR 1987	REMOTE CONTROL
E20EESB 1990	REMOTE CONTROL
E20ELCDC 1986	REMOTE CONTROL
E20ELCEM 1989	REMOTE CONTROL
E20ELCOS 1985	REMOTE CONTROL
E20ELCUR 1987	REMOTE CONTROL
E20ELESB 1990	REMOTE CONTROL
E20TECDC 1986	REMOTE CONTROL
E225CLCUB 1987	REMOTE CONTROL
E225CXCED 1989	REMOTE CONTROL
E225XCUB 1987	REMOTE CONTROL
E225XCESS 1990	REMOTE CONTROL
E225PLCED 1989	REMOTE CONTROL
E225PLCUB 1987	REMOTE CONTROL
E225PLESS 1990	REMOTE CONTROL
E225PTLCDA 1986	VRO PUMP
E225PTXCDA 1986	VRO PUMP
E225PXCED 1989	REMOTE CONTROL
E225PXCUB 1987	REMOTE CONTROL
E225PXESS 1990	REMOTE CONTROL
E225TLCDA 1986	VRO PUMP
E225TLCED 1989	REMOTE CONTROL
E225TLCUB 1987	REMOTE CONTROL
E225TLESS 1990	REMOTE CONTROL
E225TXCDA 1986	VRO PUMP
E225TXCED 1989	REMOTE CONTROL
E225TXCUB 1987	REMOTE CONTROL
E225TXESS 1990	REMOTE CONTROL
E235STLCOR 1985	REMOTE CONTROL
E235STLCRC 1984	REMOTE CONTROL
E235STLCTS 1983	REMOTE CONTROL

E235TLCOR 1985	REMOTE CONTROL
E235TLCRC 1984	REMOTE CONTROL
E235TRLCIB 1981	REMOTE CONTROL
E235TRLCIH 1981	REMOTE CONTROL
E235TRLCNE 1982	REMOTE CONTROL
E235TRLCSM 1980	REMOTE CONTROL
E235TRLCTD 1983	REMOTE CONTROL
E235TRLCTS 1983	REMOTE CONTROL
E235TRXCIB 1981	REMOTE CONTROL
E235TRXCIH 1981	REMOTE CONTROL
E235TRXCNE 1982	REMOTE CONTROL
E235TRXCSM 1980	REMOTE CONTROL
E235TRXCTD 1983	REMOTE CONTROL
E235TRXCTS 1983	REMOTE CONTROL
E235TXCOR 1985	REMOTE CONTROL
E235TXCRC 1984	REMOTE CONTROL
E25-A 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS
E25-B 1981	STEERING HOUSING GROUP/FOOT CONTROL
E25-B 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
E25-C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
E25CNE 1982	REMOTE CONTROL
E25-D 1982	STEERING HOUSING GROUP/FOOT CONTROL
E25-D 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E25-D 1982	TRANSOM MOUNT MODEL
E25-E 1982	STEERING HOUSING GROUP/FOOT CONTROL
E25-E 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E25-E 1982	TRANSOM MOUNT MODEL
E25ECDR 1986	REMOTE CONTROL
E25ECEB 1989	REMOTE CONTROL
E25ECOC 1985	REMOTE CONTROL
E25ECSR 1984	REMOTE CONTROL
E25ECTD 1983	REMOTE CONTROL
E25ECUA 1987	REMOTE CONTROL
E25EESE 1990	REMOTE CONTROL
E25ELCDR 1986	REMOTE CONTROL

E25ELCEB 1989	REMOTE CONTROL
E25ELCNE 1982	REMOTE CONTROL
E25ELCOC 1985	REMOTE CONTROL
E25ELCRS 1984	REMOTE CONTROL
E25ELCTD 1983	REMOTE CONTROL
E25ELCUA 1987	REMOTE CONTROL
E25ELESE 1990	REMOTE CONTROL
E25-M 1980	STEERING HOUSING GROUP/FOOT CONTROL
E25-M 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
E25-R 1978	STEERING HOUSING GROUP
E25RCDC 1986	REMOTE CONTROL
E25RCNB 1982	REMOTE CONTROL
E25RCOS 1985	REMOTE CONTROL
E25RCRD 1984	REMOTE CONTROL
E25RCTE 1983	REMOTE CONTROL
E25RCUR 1987	REMOTE CONTROL
E25RLCDC 1986	REMOTE CONTROL
E25RLCNB 1982	REMOTE CONTROL
E25RLCOS 1985	REMOTE CONTROL
E25RLCRD 1984	REMOTE CONTROL
E25RLCTE 1983	REMOTE CONTROL
E25RLCUR 1987	REMOTE CONTROL
E25TECDC 1986	REMOTE CONTROL
E25TECNB 1982	REMOTE CONTROL
E25TECOS 1985	REMOTE CONTROL
E25TECRD 1984	REMOTE CONTROL
E25TECTE 1983	REMOTE CONTROL
E25TECUR 1987	REMOTE CONTROL
E25TELCDC 1986	REMOTE CONTROL
E25TELCNB 1982	REMOTE CONTROL
E25TELCOS 1985	REMOTE CONTROL
E25TELCRD 1984	REMOTE CONTROL
E25TELCTE 1983	REMOTE CONTROL
E25TELCUR 1987	REMOTE CONTROL
E275CLCUR 1987	REMOTE CONTROL

E275CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275CXCUR 1987	REMOTE CONTROL
E275PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275PLCUR 1987	REMOTE CONTROL
E275PTLCDC 1986	REMOTE CONTROL
E275PTLCDC 1986	VRO PUMP
E275PTXCDC 1986	REMOTE CONTROL
E275PTXCDC 1986	VRO PUMP
E275PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275PXCUR 1987	REMOTE CONTROL
E275TLCOS 1985	REMOTE CONTROL
E275TLCOS 1985	VRO PUMP
E275TXCOS 1985	REMOTE CONTROL
E275TXCOS 1985	VRO PUMP
E28-A 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS
E28-B 1981	STEERING HOUSING GROUP/FOOT CONTROL
E28-B 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
E28-C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
E28-D 1982	STEERING HOUSING GROUP/FOOT CONTROL
E28-D 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E28-D 1982	TRANSOM MOUNT MODEL
E28-E 1982	STEERING HOUSING GROUP/FOOT CONTROL
E28-E 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E28-E 1982	TRANSOM MOUNT MODEL
E28ELCDS 1986	REMOTE CONTROL - SURFACE MOUNT
E28ESLCCR 1988	REMOTE CONTROL - SURFACE MOUNT
E28ESLCEA 1989	REMOTE CONTROL
E28ESLCUC 1987	REMOTE CONTROL - SURFACE MOUNT
E28ESLESM 1990	REMOTE CONTROL
E28-M 1980	STEERING HOUSING GROUP/FOOT CONTROL
E28-M 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
E28-R 1978	STEERING HOUSING GROUP
E2BS 1974	STEERING HOUSING GROUP
E2B-S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E2B-S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS

E2B-S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E2B-S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
E2H-C 1981	STEERING HOUSING GROUP/FOOT CONTROL
E2H-C 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
E2R-S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E2R-S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
E2T-C 1982	STEERING HOUSING GROUP/FOOT CONTROL
E2T-C 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E2T-C 1982	TRANSOM MOUNT MODEL
E2T-C 1983	STEERING HOUSING GROUP/FOOT CONTROL
E2T-C 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
E2T-C 1983	TRANSOM MOUNT MODEL
E2T-S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E2T-S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS
E2T-S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E2T-S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
E300CLCUR 1987	REMOTE CONTROL
E300CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300CXCEM 1989	REMOTE CONTROL
E300XCXUR 1987	REMOTE CONTROL
E300CXESB 1990	REMOTE CONTROL
E300PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300PLCEM 1989	REMOTE CONTROL
E300PLCUR 1987	REMOTE CONTROL
E300PLESB 1990	REMOTE CONTROL
E300PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300PXCEM 1989	REMOTE CONTROL
E300PXCUR 1987	REMOTE CONTROL
E300PXESB 1990	REMOTE CONTROL
E300TLCDC 1986	REMOTE CONTROL
E300TLCDC 1986	VRO PUMP
E300TLCOS 1985	REMOTE CONTROL
E300TLCOS 1985	VRO PUMP
E300TXCDC 1986	REMOTE CONTROL
E300TXCDC 1986	VRO PUMP

E300TXCOS 1985	REMOTE CONTROL
E300TXCOS 1985	VRO PUMP
E30ECCE 1988	REMOTE CONTROL
E30ECDM 1986	REMOTE CONTROL
E30ECED 1989	REMOTE CONTROL
E30EOCA 1985	REMOTE CONTROL
E30ECRR 1984	REMOTE CONTROL
E30ECUB 1987	REMOTE CONTROL
E30EESS 1990	REMOTE CONTROL
E30ELCCE 1988	REMOTE CONTROL
E30ELCDM 1986	REMOTE CONTROL
E30ELCED 1989	REMOTE CONTROL
E30ELCOA 1985	REMOTE CONTROL
E30ELCRR 1984	REMOTE CONTROL
E30ELCUB 1987	REMOTE CONTROL
E30ELESS 1990	REMOTE CONTROL
E30RCCE 1988	REMOTE CONTROL
E30RCDM 1986	REMOTE CONTROL
E30RCOA 1985	REMOTE CONTROL
E30RCUB 1987	REMOTE CONTROL
E30RLCCE 1988	REMOTE CONTROL
E30RLCDM 1986	REMOTE CONTROL
E30RLCOA 1985	REMOTE CONTROL
E30RLCUB 1987	REMOTE CONTROL
E30TECCE 1988	REMOTE CONTROL
E30TECDM 1986	REMOTE CONTROL
E30TECOA 1985	REMOTE CONTROL
E30TECUB 1987	REMOTE CONTROL
E30TELCCE 1988	REMOTE CONTROL
E30TELCDM 1986	REMOTE CONTROL
E30TELCOA 1985	REMOTE CONTROL
E30TELCUB 1987	REMOTE CONTROL
E35AELCDE 1986	REMOTE CONTROL
E35AELCUD 1987	REMOTE CONTROL
E35ARLCDE 1986	REMOTE CONTROL

E35ARLCUD 1987	REMOTE CONTROL
E35ECND 1982	REMOTE CONTROL
E35ECRR 1984	REMOTE CONTROL
E35ECTS 1983	REMOTE CONTROL
E35ELCND 1982	REMOTE CONTROL
E35ELCRR 1984	REMOTE CONTROL
E35ELCTS 1983	REMOTE CONTROL
E35RCCE 1988	REMOTE CONTROL
E35RCDM 1986	REMOTE CONTROL
E35RCND 1982	REMOTE CONTROL
E35RCRR 1984	REMOTE CONTROL
E35RCTS 1983	REMOTE CONTROL
E35RCUB 1987	REMOTE CONTROL
E35RLCCE 1988	REMOTE CONTROL
E35RLCDM 1986	REMOTE CONTROL
E35RLCND 1982	REMOTE CONTROL
E35RLCRR 1984	REMOTE CONTROL
E35RLCTS 1983	REMOTE CONTROL
E35RLCUB 1987	REMOTE CONTROL
E35TELCNB 1982	REMOTE CONTROL
E35TELCRR 1984	REMOTE CONTROL
E35TELCTS 1983	REMOTE CONTROL
E40AELCCS 1988	REMOTE CONTROL
E40ARLCCS 1988	REMOTE CONTROL
E40ATLCCS 1988	REMOTE CONTROL
E40ECCS 1988	REMOTE CONTROL
E40ECDE 1986	REMOTE CONTROL
E40ECEC 1989	REMOTE CONTROL
E40ECOB 1985	REMOTE CONTROL
E40ECRM 1984	REMOTE CONTROL
E40ECUD 1987	REMOTE CONTROL
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

E40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EESR 1990	REMOTE CONTROL
E40ELCCS 1988	REMOTE CONTROL
E40ELCDE 1986	REMOTE CONTROL
E40ELCEC 1989	REMOTE CONTROL
E40ELCOB 1985	REMOTE CONTROL
E40ELCRM 1984	REMOTE CONTROL
E40ELCUD 1987	REMOTE CONTROL
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELESR 1990	REMOTE CONTROL
E40RCCS 1988	REMOTE CONTROL
E40RCDE 1986	REMOTE CONTROL
E40RCEC 1989	REMOTE CONTROL
E40RCOB 1985	REMOTE CONTROL
E40RCRM 1984	REMOTE CONTROL
E40RCUD 1987	REMOTE CONTROL
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RESR 1990	REMOTE CONTROL
E40RLCCS 1988	REMOTE CONTROL
E40RLCDE 1986	REMOTE CONTROL
E40RLCEC 1989	REMOTE CONTROL
E40RLCOB 1985	REMOTE CONTROL
E40RLCRM 1984	REMOTE CONTROL
E40RLCUD 1987	REMOTE CONTROL
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLESR 1990	REMOTE CONTROL

E40TECCS 1988	REMOTE CONTROL
E40TECDE 1986	REMOTE CONTROL
E40TECEC 1989	REMOTE CONTROL
E40TECOB 1985	REMOTE CONTROL
E40TECRM 1984	REMOTE CONTROL
E40TECUD 1987	REMOTE CONTROL
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEESR 1990	REMOTE CONTROL
E40TELCCS 1988	REMOTE CONTROL
E40TELCDE 1986	REMOTE CONTROL
E40TELCEC 1989	REMOTE CONTROL
E40TELCOB 1985	REMOTE CONTROL
E40TELCRM 1984	REMOTE CONTROL
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELESR 1990	REMOTE CONTROL
E40TLCCS 1988	REMOTE CONTROL
E40TLCDE 1986	REMOTE CONTROL
E40TLCEC 1989	REMOTE CONTROL
E40TLCUD 1987	REMOTE CONTROL
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLESR 1990	REMOTE CONTROL
E40TTLCCS 1988	REMOTE CONTROL
E40TTLCEC 1989	REMOTE CONTROL

E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLESR 1990	REMOTE CONTROL
E45-A 1981	STEERING HOUSING GROUP/FOOT CONTROL
E45-A 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
E45-B 1982	STEERING HOUSING GROUP/FOOT CONTROL
E45-B 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E45-B 1982	TRANSOM MOUNT MODEL
E45-C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
E45-C 1978	STEERING HOUSING GROUP
E45-C 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS
E45-M 1982	STEERING HOUSING GROUP/FOOT CONTROL
E45-M 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E45-M 1982	TRANSOM MOUNT MODEL
E45-R 1980	STEERING HOUSING GROUP/FOOT CONTROL
E45-R 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
E45RCE 1989	REMOTE CONTROL - ELECTRIC START
E45RCEIA 1991	REMOTE CONTROL
E45RCENM 1992	REMOTE CONTROL
E45RCESR 1990	REMOTE CONTROL
E45RCLE 1989	REMOTE CONTROL - ELECTRIC START
E45RCLEIA 1991	REMOTE CONTROL
E45RCLENM 1992	REMOTE CONTROL
E45RCLESR 1990	REMOTE CONTROL
E45WMLE 1989	REMOTE CONTROL - ELECTRIC START
E45WMLEIA 1991	REMOTE CONTROL
E45WMLENM 1992	REMOTE CONTROL
E45WMLESR 1990	REMOTE CONTROL
E48-A 1981	STEERING HOUSING GROUP/FOOT CONTROL
E48-A 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
E48-C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
E48-C 1978	STEERING HOUSING GROUP
E48-C 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS

E48ESLCCC 1988	REMOTE CONTROL
E48ESLCER 1989	REMOTE CONTROL
E48ESLCUS 1987	REMOTE CONTROL - SURFACE MOUNT
E48ESLESA 1990	REMOTE CONTROL
E48-R 1980	STEERING HOUSING GROUP/FOOT CONTROL
E48-R 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
E4B-S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E4B-S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS
E4B-S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E4B-S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
E4H-A 1982	STEERING HOUSING GROUP/FOOT CONTROL
E4H-A 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E4H-A 1982	TRANSOM MOUNT MODEL
E4H-R 1982	STEERING HOUSING GROUP/FOOT CONTROL
E4H-R 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
E4H-R 1982	TRANSOM MOUNT MODEL
E4H-S 1980	STEERING HOUSING GROUP/FOOT CONTROL
E4H-S 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
E4R-S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E4R-S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
E4T-S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E4T-S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS
E4T-S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
E4T-S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
E50BECCS 1988	REMOTE CONTROL
E50BECDE 1986	REMOTE CONTROL
E50BECEC 1989	REMOTE CONTROL
E50BECIC 1981	REMOTE CONTROL
E50BECNR 1982	REMOTE CONTROL
E50BECOB 1985	REMOTE CONTROL
E50BECRM 1984	REMOTE CONTROL
E50BECTA 1983	REMOTE CONTROL
E50BECUD 1987	REMOTE CONTROL
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEESR 1990	REMOTE CONTROL
E50BELCCS 1988	REMOTE CONTROL
E50BELCDE 1986	REMOTE CONTROL
E50BELCEC 1989	REMOTE CONTROL
E50BELCIC 1981	REMOTE CONTROL
E50BELCNR 1982	REMOTE CONTROL
E50BELCOB 1985	REMOTE CONTROL
E50BELCRM 1984	REMOTE CONTROL
E50BELCTA 1983	REMOTE CONTROL
E50BELCUD 1987	REMOTE CONTROL
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELESR 1990	REMOTE CONTROL
E50ECSR 1980	REMOTE CONTROL
E50ELCSR 1980	REMOTE CONTROL
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50RNLIA 1990	REMOTE CONTROL
E50TELCCS 1988	REMOTE CONTROL
E50TELCDE 1986	REMOTE CONTROL
E50TELCEC 1989	REMOTE CONTROL
E50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELCOB 1985	REMOTE CONTROL
E50TELCRM 1984	REMOTE CONTROL
E50TELCTA 1983	REMOTE CONTROL
E50TELCUD 1987	REMOTE CONTROL
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

E50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELESR 1990	REMOTE CONTROL
E50TLCCS 1988	REMOTE CONTROL
E50TLCDE 1986	REMOTE CONTROL
E50TLCEC 1989	REMOTE CONTROL
E50TLCOB 1985	REMOTE CONTROL
E50TLCRM 1984	REMOTE CONTROL
E50TLCUD 1987	REMOTE CONTROL
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TLESR 1990	REMOTE CONTROL
E55RCIM 1981	REMOTE CONTROL
E55RLCSA 1980	REMOTE CONTROL
E55RWLE 1989	REMOTE CONTROL - ELECTRIC START
E55RWLEIA 1991	REMOTE CONTROL
E55RWLENM 1992	REMOTE CONTROL
E55RWLESR 1990	REMOTE CONTROL
E55TLCIM 1981	REMOTE CONTROL
E60ECIA 1981	REMOTE CONTROL
E60ECIH 1981	REMOTE CONTROL
E60ECNM 1982	REMOTE CONTROL
E60ECSR 1980	REMOTE CONTROL
E60ECTB 1983	REMOTE CONTROL
E60ELCCR 1988	REMOTE CONTROL
E60ELCDS 1986	REMOTE CONTROL
E60ELCEA 1989	REMOTE CONTROL
E60ELCIA 1981	REMOTE CONTROL
E60ELCIH 1981	REMOTE CONTROL
E60ELCNM 1982	REMOTE CONTROL
E60ELCOD 1985	REMOTE CONTROL
E60ELCRE 1984	REMOTE CONTROL
E60ELCSR 1980	REMOTE CONTROL

E60ELCTB 1983	REMOTE CONTROL
E60ELCUC 1987	REMOTE CONTROL
E60ELES 1990	REMOTE CONTROL
E60TLCCR 1988	REMOTE CONTROL
E60TLCDS 1986	REMOTE CONTROL
E60TLCEA 1989	REMOTE CONTROL
E60TLCIA 1981	REMOTE CONTROL
E60TLCIH 1981	REMOTE CONTROL
E60TLCNM 1982	REMOTE CONTROL
E60TLCOD 1985	REMOTE CONTROL
E60TLCRE 1984	REMOTE CONTROL
E60TLCTB 1983	REMOTE CONTROL
E60TLCUC 1987	REMOTE CONTROL
E60TLES 1990	REMOTE CONTROL
E60TTLCCR 1988	REMOTE CONTROL
E60TTLCEA 1989	REMOTE CONTROL
E60TTLES 1990	REMOTE CONTROL
E65RWLCRS 1984	REMOTE CONTROL
E65TELCRS 1984	REMOTE CONTROL
E65WELSIR Commercial, elec start, 20 in shaft 2001	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
E65WMLCDR 1986	REMOTE CONTROL
E65WMLCOC 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
E65WMLCOC 1985	REMOTE CONTROL
E65WMLCUA 1987	REMOTE CONTROL
E65WMLLES 1990	REMOTE CONTROL
E65WMLZ 1989	REMOTE CONTROL
E65WTLCOC 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
E65WTLCOC 1985	REMOTE CONTROL
E65WTLCRS 1984	REMOTE CONTROL
E70ELCCA 1988	REMOTE CONTROL
E70ELCDC 1986	REMOTE CONTROL
E70ELCEM 1989	REMOTE CONTROL
E70ELCIH 1981	REMOTE CONTROL
E70ELCIM 1981	REMOTE CONTROL

E70ELCNB 1982	REMOTE CONTROL
E70ELCOS 1985	REMOTE CONTROL
E70ELCRD 1984	REMOTE CONTROL
E70ELCSA 1980	REMOTE CONTROL
E70ELCTE 1983	REMOTE CONTROL
E70ELCUR 1987	REMOTE CONTROL
E70ELESB 1990	REMOTE CONTROL
E70TLCCA 1988	REMOTE CONTROL
E70TLCDC 1986	REMOTE CONTROL
E70TLCEM 1989	REMOTE CONTROL
E70TLCIM 1981	REMOTE CONTROL
E70TLCNB 1982	REMOTE CONTROL
E70TLCOS 1985	REMOTE CONTROL
E70TLCRD 1984	REMOTE CONTROL
E70TLCTE 1983	REMOTE CONTROL
E70TLCUR 1987	REMOTE CONTROL
E70TLESB 1990	REMOTE CONTROL
E75ECCA 1988	REMOTE CONTROL
E75ECDC 1986	REMOTE CONTROL
E75ECOS 1985	REMOTE CONTROL
E75ECDR 1984	REMOTE CONTROL
E75ECUR 1987	REMOTE CONTROL
E75ELCRD 1984	REMOTE CONTROL
E75ERICIH 1981	REMOTE CONTROL
E75ERCIM 1981	REMOTE CONTROL
E75ERCNB 1982	REMOTE CONTROL
E75ERCSA 1980	REMOTE CONTROL
E75ERCTE 1983	REMOTE CONTROL
E75ERLCIH 1981	REMOTE CONTROL
E75ERLCIM 1981	REMOTE CONTROL
E75ERLCNB 1982	REMOTE CONTROL
E75ERLCSA 1980	REMOTE CONTROL
E75ERLCTE 1983	REMOTE CONTROL
E75TLCRD 1984	REMOTE CONTROL
E75TRLCIH 1981	REMOTE CONTROL

E75TRLCIM 1981	REMOTE CONTROL
E75TRLCNB 1982	REMOTE CONTROL
E75TRLCSA 1980	REMOTE CONTROL
E75TRLCTE 1983	REMOTE CONTROL
E85MLCSA 1980	REMOTE CONTROL
E85STLCSA 1980	REMOTE CONTROL
E85STXCSA 1980	REMOTE CONTROL
E88MSLCCC 1988	REMOTE CONTROL
E88MSLCER 1989	REMOTE CONTROL
E88MSLCUS 1987	REMOTE CONTROL - SURFACE MOUNT
E88MSLESA 1990	REMOTE CONTROL
E90MLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
E90MLCDC 1986	REMOTE CONTROL
E90MLCIH 1981	REMOTE CONTROL
E90MLCIM 1981	REMOTE CONTROL
E90MLCNB 1982	REMOTE CONTROL
E90MLCOS 1985	POWER TRIM/TILT ELECTRICAL
E90MLCOS 1985	REMOTE CONTROL
E90MLCRD 1984	REMOTE CONTROL
E90MLCTE 1983	REMOTE CONTROL
E90MLCUR 1987	REMOTE CONTROL
E90TLCCA 1988	REMOTE CONTROL
E90TLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
E90TLCDC 1986	REMOTE CONTROL
E90TLCEM 1989	REMOTE CONTROL
E90TLCIH 1981	REMOTE CONTROL
E90TLCIM 1981	REMOTE CONTROL
E90TLCNB 1982	REMOTE CONTROL
E90TLCOS 1985	POWER TRIM/TILT ELECTRICAL
E90TLCOS 1985	REMOTE CONTROL
E90TLCRD 1984	REMOTE CONTROL
E90TLCTE 1983	REMOTE CONTROL
E90TLCUR 1987	REMOTE CONTROL
E90TLESB 1990	REMOTE CONTROL
E90TXCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY

E90TXCDC 1986	REMOTE CONTROL
E90TXCIH 1981	REMOTE CONTROL
E90TXCIM 1981	REMOTE CONTROL
E90TXCNB 1982	REMOTE CONTROL
E90TXCOS 1985	POWER TRIM/TILT ELECTRICAL
E90TXCOS 1985	REMOTE CONTROL
E90TXCRD 1984	REMOTE CONTROL
E90TXCTE 1983	REMOTE CONTROL
EB12S 1974	STEERING HOUSING GROUP
EB12S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
EB12S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS
EB12S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
EB12S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
EB14S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
EB14S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS
EB14S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
EB14S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
EB52A 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS
EB52B 1981	STEERING HOUSING GROUP/FOOT CONTROL
EB52B 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
EB52C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
EB52D 1982	STEERING HOUSING GROUP/FOOT CONTROL
EB52D 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EB52D 1982	TRANSOM MOUNT MODEL
EB52E 1982	STEERING HOUSING GROUP/FOOT CONTROL
EB52E 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EB52E 1982	TRANSOM MOUNT MODEL
EB52M 1980	STEERING HOUSING GROUP/FOOT CONTROL
EB52M 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
EB52R 1978	STEERING HOUSING GROUP
EB54A 1980	STEERING HOUSING GROUP/FOOT CONTROL
EB54A 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
EB54B 1982	STEERING HOUSING GROUP/FOOT CONTROL
EB54B 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EB54B 1982	TRANSOM MOUNT MODEL

EB54C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
EB54E 1982	STEERING HOUSING GROUP/FOOT CONTROL
EB54E 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EB54E 1982	TRANSOM MOUNT MODEL
EB54M 1981	STEERING HOUSING GROUP/FOOT CONTROL
EB54M 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
EB54R 1978	STEERING HOUSING GROUP
EB54R 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS
EB82A 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS
EB82B 1981	STEERING HOUSING GROUP/FOOT CONTROL
EB82B 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
EB82C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
EB82D 1982	STEERING HOUSING GROUP/FOOT CONTROL
EB82D 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EB82D 1982	TRANSOM MOUNT MODEL
EB82E 1982	STEERING HOUSING GROUP/FOOT CONTROL
EB82E 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EB82E 1982	TRANSOM MOUNT MODEL
EB82M 1980	STEERING HOUSING GROUP/FOOT CONTROL
EB82M 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
EB82R 1978	STEERING HOUSING GROUP
EB84A 1980	STEERING HOUSING GROUP/FOOT CONTROL
EB84A 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
EB84C 1977	STEERING HOUSING GROUP BOW MOUNT MODELS
EB84M 1981	STEERING HOUSING GROUP/FOOT CONTROL
EB84M 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
EB84R 1978	STEERING HOUSING GROUP
EB84R 1979	STEERING HOUSING GROUP/BOW MOUNT MODELS
EBF2B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
EBF2B 1986	STEERING HOUSING GROUP / FOOT CONTROL
EBF2H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
EBF2H 1985	STEERING HOUSING GROUP / FOOT CONTROL
EBF2P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
EBF2P 1984	STEERING HOUSING GROUP / FOOT CONTROL
EBF2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL

EBF2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
EBF2V 1983	STEERING HOUSING GROUP/FOOT CONTROL
EBF2V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
EBF2V 1983	TRANSOM MOUNT MODEL
EBF4B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
EBF4B 1986	STEERING HOUSING GROUP / FOOT CONTROL
EBF4H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
EBF4H 1985	STEERING HOUSING GROUP / FOOT CONTROL
EBF4P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
EBF4P 1984	STEERING HOUSING GROUP / FOOT CONTROL
EBF4V 1983	STEERING HOUSING GROUP/FOOT CONTROL
EBF4V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
EBF4V 1983	TRANSOM MOUNT MODEL
EBFL2H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
EBFL2H 1985	STEERING HOUSING GROUP / FOOT CONTROL
EBFL2P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
EBFL2P 1984	STEERING HOUSING GROUP / FOOT CONTROL
EBFL2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
EBFL2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
EBFL2V 1983	STEERING HOUSING GROUP/FOOT CONTROL
EBFL2V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
EBFL2V 1983	TRANSOM MOUNT MODEL
EBFL4B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
EBFL4B 1986	STEERING HOUSING GROUP / FOOT CONTROL
EBFL4H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
EBFL4H 1985	STEERING HOUSING GROUP / FOOT CONTROL
EBFL4P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
EBFL4P 1984	STEERING HOUSING GROUP / FOOT CONTROL
EBH2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
EBH2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
EBH4A 1982	STEERING HOUSING GROUP/FOOT CONTROL
EBH4A 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EBH4A 1982	TRANSOM MOUNT MODEL
EBH4C 1981	STEERING HOUSING GROUP/FOOT CONTROL
EBH4C 1981	STEERING HOUSING GROUP/HAND STEERING MODEL

EBH4P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
EBH4P 1984	STEERING HOUSING GROUP / FOOT CONTROL
EBH4R 1982	STEERING HOUSING GROUP/FOOT CONTROL
EBH4R 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EBH4R 1982	TRANSOM MOUNT MODEL
EBH4S 1980	STEERING HOUSING GROUP/FOOT CONTROL
EBH4S 1980	STEERING HOUSING GROUP/HAND STEERING MODEL
EBH4V 1983	STEERING HOUSING GROUP/FOOT CONTROL
EBH4V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
EBH4V 1983	TRANSOM MOUNT MODEL
EBHL2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
EBHL2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
EBHL4H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
EBHL4H 1985	STEERING HOUSING GROUP / FOOT CONTROL
EBL52B 1981	STEERING HOUSING GROUP/FOOT CONTROL
EBL52B 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
EBL52D 1982	STEERING HOUSING GROUP/FOOT CONTROL
EBL52D 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EBL52D 1982	TRANSOM MOUNT MODEL
EBL52E 1982	STEERING HOUSING GROUP/FOOT CONTROL
EBL52E 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EBL52E 1982	TRANSOM MOUNT MODEL
EBL84B 1982	STEERING HOUSING GROUP/FOOT CONTROL
EBL84B 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EBL84B 1982	TRANSOM MOUNT MODEL
EBL84G 1982	STEERING HOUSING GROUP/FOOT CONTROL
EBL84G 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EBL84G 1982	TRANSOM MOUNT MODEL
EBL84G 1983	STEERING HOUSING GROUP/FOOT CONTROL
EBL84G 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
EBL84G 1983	TRANSOM MOUNT MODEL
EBL84M 1981	STEERING HOUSING GROUP/FOOT CONTROL
EBL84M 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
EL25-B 1981	STEERING HOUSING GROUP/FOOT CONTROL
EL25-B 1981	STEERING HOUSING GROUP/HAND STEERING MODEL

EL25-D 1982	STEERING HOUSING GROUP/FOOT CONTROL
EL25-D 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EL25-D 1982	TRANSOM MOUNT MODEL
EL25-E 1982	STEERING HOUSING GROUP/FOOT CONTROL
EL25-E 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EL25-E 1982	TRANSOM MOUNT MODEL
EL48-A 1981	STEERING HOUSING GROUP/FOOT CONTROL
EL48-A 1981	STEERING HOUSING GROUP/HAND STEERING MODEL
EL48-G 1982	STEERING HOUSING GROUP/FOOT CONTROL
EL48-G 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EL48-G 1982	TRANSOM MOUNT MODEL
EL48-G 1983	STEERING HOUSING GROUP/FOOT CONTROL
EL48-G 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
EL48-G 1983	TRANSOM MOUNT MODEL
EL48-M 1982	STEERING HOUSING GROUP/FOOT CONTROL
EL48-M 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
EL48-M 1982	TRANSOM MOUNT MODEL
ET12C 1982	STEERING HOUSING GROUP/FOOT CONTROL
ET12C 1982	STEERING HOUSING GROUP/HAND STEERING MODEL
ET12C 1982	TRANSOM MOUNT MODEL
ET12C 1983	STEERING HOUSING GROUP/FOOT CONTROL
ET12C 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
ET12C 1983	TRANSOM MOUNT MODEL
ET12S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
ET12S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS
ET12S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
ET12S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
ET14S 1975	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
ET14S 1975	STEERING HOUSING GROUP BOW MOUNT MODELS
ET14S 1976	ELECTRIC OUTBOARD TRANSOM MOUNT MODELS
ET14S 1976	STEERING HOUSING GROUP BOW MOUNT MODELS
ETH2B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
ETH2B 1986	STEERING HOUSING GROUP / FOOT CONTROL
ETH2H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
ETH2H 1985	STEERING HOUSING GROUP / FOOT CONTROL

ETH2P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
ETH2P 1984	STEERING HOUSING GROUP / FOOT CONTROL
HE55WMLM 1996	REMOTE CONTROL
HE55WMLZ 1997	REMOTE CONTROL
HJ55WMLM 1996	REMOTE CONTROL
HJ55WMLZ 1997	REMOTE CONTROL
J100MLCSC 1980	REMOTE CONTROL
J100STLCCA 1988	REMOTE CONTROL
J100STLCEM 1989	REMOTE CONTROL
J100STLESB 1990	REMOTE CONTROL
J100TRLCSC 1980	REMOTE CONTROL
J100TRXCSC 1980	REMOTE CONTROL
J100WMLCDR 1986	REMOTE CONTROL
J100WMLCOC 1985	POWER TRIM/TILT ELECTRICAL
J100WMLCOC 1985	REMOTE CONTROL
J100WMLCRS 1984	REMOTE CONTROL
J100WTLCDR 1986	REMOTE CONTROL
J100WTLCOC 1985	POWER TRIM/TILT ELECTRICAL
J100WTLCOC 1985	REMOTE CONTROL
J100WTLCRS 1984	REMOTE CONTROL
J100WTLCUA 1987	REMOTE CONTROL
J100WTLESM 1990	REMOTE CONTROL
J100WTLZ 1989	REMOTE CONTROL
J100WTXCDR 1986	REMOTE CONTROL
J100WTXCUA 1987	REMOTE CONTROL
J100WTXESM 1990	REMOTE CONTROL
J100WTXZ 1989	REMOTE CONTROL
J10EESC 1990	REMOTE CONTROL
J10EDESC 1990	REMOTE CONTROL
J10REESC 1990	REMOTE CONTROL
J10RESC 1990	REMOTE CONTROL
J10RLESC 1990	REMOTE CONTROL
J10SEESC 1990	REMOTE CONTROL
J110MLCCA 1988	REMOTE CONTROL
J110MLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY

J110MLCDC 1986	REMOTE CONTROL
J110MLCEM 1989	REMOTE CONTROL
J110MLCUR 1987	REMOTE CONTROL
J110TLAEM 1989	REMOTE CONTROL
J110TLCCA 1988	REMOTE CONTROL
J110TLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
J110TLCDC 1986	REMOTE CONTROL
J110TLCDF 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
J110TLCDF 1986	REMOTE CONTROL
J110TLCEM 1989	REMOTE CONTROL
J110TLCUR 1987	REMOTE CONTROL
J110TXCCA 1988	REMOTE CONTROL
J110TXCEM 1989	REMOTE CONTROL
J110TXCUR 1987	REMOTE CONTROL
J115MLCIH 1981	REMOTE CONTROL
J115MLCIM 1981	REMOTE CONTROL
J115MLCNB 1982	REMOTE CONTROL
J115MLCOS 1985	POWER TRIM/TILT ELECTRICAL
J115MLCOS 1985	REMOTE CONTROL
J115MLCRD 1984	REMOTE CONTROL
J115MLCSA 1980	REMOTE CONTROL
J115MLCTE 1983	REMOTE CONTROL
J115MLESB 1990	REMOTE CONTROL
J115TLASB 1990	REMOTE CONTROL
J115TLCIH 1981	REMOTE CONTROL
J115TLCIM 1981	REMOTE CONTROL
J115TLCNB 1982	REMOTE CONTROL
J115TLCOS 1985	POWER TRIM/TILT ELECTRICAL
J115TLCOS 1985	REMOTE CONTROL
J115TLCRD 1984	REMOTE CONTROL
J115TLCSA 1980	REMOTE CONTROL
J115TLCTE 1983	REMOTE CONTROL
J115TLESB 1990	REMOTE CONTROL
J115TXCIH 1981	REMOTE CONTROL
J115TXCIM 1981	REMOTE CONTROL

J115TXCNB 1982	REMOTE CONTROL
J115TXCRD 1984	REMOTE CONTROL
J115TXCSA 1980	REMOTE CONTROL
J115TXCTE 1983	REMOTE CONTROL
J115TXESB 1990	REMOTE CONTROL
J120TLAEM 1989	REMOTE CONTROL
J120TLASB 1990	REMOTE CONTROL
J120TLCDC 1986	REMOTE CONTROL
J120TLCEM 1989	REMOTE CONTROL
J120TLCOS 1985	POWER TRIM/TILT ELECTRICAL
J120TLCOS 1985	REMOTE CONTROL
J120TLCUR 1987	REMOTE CONTROL
J120TLESB 1990	REMOTE CONTROL
J120TXCDC 1986	REMOTE CONTROL
J120TXCEM 1989	REMOTE CONTROL
J120TXCOS 1985	POWER TRIM/TILT ELECTRICAL
J120TXCOS 1985	REMOTE CONTROL
J120TXCUR 1987	REMOTE CONTROL
J120TXESB 1990	REMOTE CONTROL
J125ESXESS 1990	REMOTE CONTROL
J125ESXW 1989	REMOTE CONTROL
J125WTPLE 1995	REMOTE CONTROL
J140CXCEC 1989	REMOTE CONTROL
J140CXESR 1990	REMOTE CONTROL
J140MLCIH 1981	REMOTE CONTROL
J140MLCIM 1981	REMOTE CONTROL
J140MLCNB 1982	REMOTE CONTROL
J140MLCSA 1980	REMOTE CONTROL
J140MLCTE 1983	REMOTE CONTROL
J140TLAEB 1989	REMOTE CONTROL
J140TLASE 1990	REMOTE CONTROL
J140TLCDC 1986	REMOTE CONTROL
J140TLCEB 1989	REMOTE CONTROL
J140TLCIH 1981	REMOTE CONTROL
J140TLCIM 1981	REMOTE CONTROL

J140TLCNB 1982	REMOTE CONTROL
J140TLCOS 1985	POWER TRIM/TILT ELECTRICAL
J140TLCOS 1985	REMOTE CONTROL
J140TLCRD 1984	REMOTE CONTROL
J140TLCSA 1980	REMOTE CONTROL
J140TLCTE 1983	REMOTE CONTROL
J140TLCUA 1987	REMOTE CONTROL
J140TLESE 1990	REMOTE CONTROL
J140TXCDC 1986	REMOTE CONTROL
J140TXCEB 1989	REMOTE CONTROL
J140TXCIH 1981	REMOTE CONTROL
J140TXCIM 1981	REMOTE CONTROL
J140TXCNB 1982	REMOTE CONTROL
J140TXCOS 1985	POWER TRIM/TILT ELECTRICAL
J140TXCOS 1985	REMOTE CONTROL
J140TXCRD 1984	REMOTE CONTROL
J140TXCSA 1980	REMOTE CONTROL
J140TXCTE 1983	REMOTE CONTROL
J140TXCUA 1987	REMOTE CONTROL
J140TXESE 1990	REMOTE CONTROL
J150CXCCA 1988	REMOTE CONTROL
J150CXCEM 1989	REMOTE CONTROL
J150CXESB 1990	REMOTE CONTROL
J150GTLCUR 1987	REMOTE CONTROL
J150STLACA 1988	REMOTE CONTROL
J150STLCCA 1988	REMOTE CONTROL
J150STLCDC 1986	REMOTE CONTROL
J150STLCEM 1989	REMOTE CONTROL
J150STLCOH 1985	REMOTE CONTROL
J150STLCOS 1985	REMOTE CONTROL
J150STLCRD 1984	REMOTE CONTROL
J150STLCTE 1983	REMOTE CONTROL
J150STLCUR 1987	REMOTE CONTROL
J150STLESB 1990	REMOTE CONTROL
J150TLAEM 1989	REMOTE CONTROL

J150TLASB 1990	REMOTE CONTROL
J150TLCCA 1988	REMOTE CONTROL
J150TLCDC 1986	REMOTE CONTROL
J150TLCEM 1989	REMOTE CONTROL
J150TLCIA 1981	REMOTE CONTROL
J150TLCIH 1981	REMOTE CONTROL
J150TLCNM 1982	REMOTE CONTROL
J150TLCOS 1985	REMOTE CONTROL
J150TLCRD 1984	REMOTE CONTROL
J150TLCSF 1980	REMOTE CONTROL
J150TLCSR 1980	REMOTE CONTROL
J150TLCTB 1983	REMOTE CONTROL
J150TLCTE 1983	REMOTE CONTROL
J150TLCUR 1987	REMOTE CONTROL
J150TLESB 1990	REMOTE CONTROL
J150TXCCA 1988	REMOTE CONTROL
J150TXCDC 1986	REMOTE CONTROL
J150TXCEM 1989	REMOTE CONTROL
J150TXCIA 1981	REMOTE CONTROL
J150TXCIH 1981	REMOTE CONTROL
J150TXCNM 1982	REMOTE CONTROL
J150TXCOS 1985	REMOTE CONTROL
J150TXCRD 1984	REMOTE CONTROL
J150TXCSF 1980	REMOTE CONTROL
J150TXCSR 1980	REMOTE CONTROL
J150TXCTB 1983	REMOTE CONTROL
J150TXCTE 1983	REMOTE CONTROL
J150TXCUR 1987	REMOTE CONTROL
J150TXESB 1990	REMOTE CONTROL
J150WPLEES 1999	REMOTE CONTROL
J150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	REMOTE CONTROL
J150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	REMOTE CONTROL
J150WTLEOR 1995	REMOTE CONTROL
J150WTLERC 1994	REMOTE CONTROL

J150WTLERV 1994	REMOTE CONTROL
J150WTLETG 1993	REMOTE CONTROL
J150WTLETS 1993	REMOTE CONTROL
J150WTXEOR 1995	REMOTE CONTROL
J150WTXERC 1994	REMOTE CONTROL
J150WTXERV 1994	REMOTE CONTROL
J150WTXETG 1993	REMOTE CONTROL
J150WTXETS 1993	REMOTE CONTROL
J155WTLCDR 1986	REMOTE CONTROL
J155WTLCOG 1985	POWER TRIM/TILT ELECTRICAL
J155WTLCOG 1985	REMOTE CONTROL
J155WTLCRS 1984	REMOTE CONTROL
J155WTLCUA 1987	REMOTE CONTROL
J155WTLESM 1990	REMOTE CONTROL
J155WTLZ 1989	REMOTE CONTROL
J155WTXCDR 1986	REMOTE CONTROL
J155WTXCOC 1985	POWER TRIM/TILT ELECTRICAL
J155WTXCOC 1985	REMOTE CONTROL
J155WTXCRS 1984	REMOTE CONTROL
J155WTXCUA 1987	REMOTE CONTROL
J155WTXESM 1990	REMOTE CONTROL
J155WTXZ 1989	REMOTE CONTROL
J15EESR 1990	REMOTE CONTROL
J15ELESR 1990	REMOTE CONTROL
J15RELESR 1990	REMOTE CONTROL
J15RESR 1990	REMOTE CONTROL
J15RLESR 1990	REMOTE CONTROL
J175STLACM 1988	REMOTE CONTROL
J175STLCCM 1988	REMOTE CONTROL
J175STLCEB 1989	REMOTE CONTROL
J175STLESE 1990	REMOTE CONTROL
J175TLCCM 1988	REMOTE CONTROL
J175TLCDR 1986	REMOTE CONTROL
J175TLCIH 1981	REMOTE CONTROL
J175TLCIM 1981	REMOTE CONTROL

J175TLCNB 1982	REMOTE CONTROL
J175TLCOC 1985	REMOTE CONTROL
J175TLCSA 1980	REMOTE CONTROL
J175TLCSF 1980	REMOTE CONTROL
J175TLCTD 1983	REMOTE CONTROL
J175TLCTE 1983	REMOTE CONTROL
J175TLCUA 1987	REMOTE CONTROL
J175TXCCM 1988	REMOTE CONTROL
J175TXCDR 1986	REMOTE CONTROL
J175TXCEB 1989	REMOTE CONTROL
J175TXCIH 1981	REMOTE CONTROL
J175TXCIM 1981	REMOTE CONTROL
J175TXCNB 1982	REMOTE CONTROL
J175TXCOC 1985	REMOTE CONTROL
J175TXCSA 1980	REMOTE CONTROL
J175TXCSF 1980	REMOTE CONTROL
J175TXCTD 1983	REMOTE CONTROL
J175TXCTE 1983	REMOTE CONTROL
J175TXCUA 1987	REMOTE CONTROL
J175TXESE 1990	REMOTE CONTROL
J185ESXESS 1990	REMOTE CONTROL
J185ESXW 1989	REMOTE CONTROL
J185TLCOC 1985	REMOTE CONTROL
J185TLCRS 1984	REMOTE CONTROL
J185TXCOC 1985	REMOTE CONTROL
J185TXCR 1984	REMOTE CONTROL
J200CXCEA 1989	REMOTE CONTROL
J200CXESM 1990	REMOTE CONTROL
J200STLCDR 1986	VRO PUMP
J200STLCEB 1989	REMOTE CONTROL
J200STLCUA 1987	REMOTE CONTROL
J200STLESE 1990	REMOTE CONTROL
J200TLCIH 1981	REMOTE CONTROL
J200TLCNE 1982	REMOTE CONTROL
J200TLCSF 1980	REMOTE CONTROL

J200TLCSM 1980	REMOTE CONTROL
J200TLCTD 1983	REMOTE CONTROL
J200TLCTS 1983	REMOTE CONTROL
J200TXCDS 1986	VRO PUMP
J200TXCEA 1989	REMOTE CONTROL
J200TXCIB 1981	REMOTE CONTROL
J200TXCIH 1981	REMOTE CONTROL
J200TXCNE 1982	REMOTE CONTROL
J200TXCSF 1980	REMOTE CONTROL
J200TXCSM 1980	REMOTE CONTROL
J200TXCTD 1983	REMOTE CONTROL
J200TXCTS 1983	REMOTE CONTROL
J200TXCUC 1987	REMOTE CONTROL
J200TXESM 1990	REMOTE CONTROL
J200WPXEEN 1999	REMOTE CONTROL
J200WPXEES 1999	REMOTE CONTROL
J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	REMOTE CONTROL
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	REMOTE CONTROL
J20CRCDC 1986	REMOTE CONTROL
J20CRCOS 1985	REMOTE CONTROL
J20CRCUR 1987	REMOTE CONTROL
J20CRLCDC 1986	REMOTE CONTROL
J20CRLCOS 1985	REMOTE CONTROL
J20CRLCUR 1987	REMOTE CONTROL
J20ECDC 1986	REMOTE CONTROL
J20ECEM 1989	REMOTE CONTROL
J20ECOS 1985	REMOTE CONTROL
J20ECUR 1987	REMOTE CONTROL
J20EESB 1990	REMOTE CONTROL
J20ELCDC 1986	REMOTE CONTROL
J20ELCEM 1989	REMOTE CONTROL
J20ELCOS 1985	REMOTE CONTROL
J20ELCUR 1987	REMOTE CONTROL
J20ELESB 1990	REMOTE CONTROL
J20TECDC 1986	REMOTE CONTROL

J225CLCUB 1987	REMOTE CONTROL
J225CXCED 1989	REMOTE CONTROL
J225CXCUB 1987	REMOTE CONTROL
J225CXESS 1990	REMOTE CONTROL
J225PLAED 1989	REMOTE CONTROL
J225PLASS 1990	REMOTE CONTROL
J225PLCED 1989	REMOTE CONTROL
J225PLCUB 1987	REMOTE CONTROL
J225PLESS 1990	REMOTE CONTROL
J225PTLCDA 1986	VRO PUMP
J225PTXCDA 1986	VRO PUMP
J225PXCED 1989	REMOTE CONTROL
J225PXCUB 1987	REMOTE CONTROL
J225PXESS 1990	REMOTE CONTROL
J225TLAED 1989	REMOTE CONTROL
J225TLASS 1990	REMOTE CONTROL
J225TLCDA 1986	VRO PUMP
J225TLCED 1989	REMOTE CONTROL
J225TLCUB 1987	REMOTE CONTROL
J225TLESS 1990	REMOTE CONTROL
J225TXCDA 1986	VRO PUMP
J225TXCED 1989	REMOTE CONTROL
J225TXCUB 1987	REMOTE CONTROL
J225TXESS 1990	REMOTE CONTROL
J235STLCOR 1985	REMOTE CONTROL
J235STLCRC 1984	REMOTE CONTROL
J235STLCTS 1983	REMOTE CONTROL
J235TLCIB 1981	REMOTE CONTROL
J235TLCIH 1981	REMOTE CONTROL
J235TLCNE 1982	REMOTE CONTROL
J235TLCOR 1985	REMOTE CONTROL
J235TLCRC 1984	REMOTE CONTROL
J235TLCSM 1980	REMOTE CONTROL
J235TLCTD 1983	REMOTE CONTROL
J235TLCTS 1983	REMOTE CONTROL

J235TXCIB 1981	REMOTE CONTROL
J235TXCIH 1981	REMOTE CONTROL
J235TXCNE 1982	REMOTE CONTROL
J235TXCOR 1985	REMOTE CONTROL
J235TXCRC 1984	REMOTE CONTROL
J235TXCSM 1980	REMOTE CONTROL
J235TXCTD 1983	REMOTE CONTROL
J235TXCTS 1983	REMOTE CONTROL
J25ECDR 1986	REMOTE CONTROL
J25ECEB 1989	REMOTE CONTROL
J25ECNE 1982	REMOTE CONTROL
J25ECOC 1985	REMOTE CONTROL
J25ECRS 1984	REMOTE CONTROL
J25ECTD 1983	REMOTE CONTROL
J25ECUA 1987	REMOTE CONTROL
J25EESE 1990	REMOTE CONTROL
J25ELCDR 1986	REMOTE CONTROL
J25ELCEB 1989	REMOTE CONTROL
J25ELCNE 1982	REMOTE CONTROL
J25ELCOC 1985	REMOTE CONTROL
J25ELCRS 1984	REMOTE CONTROL
J25ELCTD 1983	REMOTE CONTROL
J25ELCUA 1987	REMOTE CONTROL
J25ELESE 1990	REMOTE CONTROL
J25RCDC 1986	REMOTE CONTROL
J25RCNB 1982	REMOTE CONTROL
J25RCOS 1985	REMOTE CONTROL
J25RCRD 1984	REMOTE CONTROL
J25RCTE 1983	REMOTE CONTROL
J25RCUR 1987	REMOTE CONTROL
J25RELCNB 1982	REMOTE CONTROL
J25RLCDC 1986	REMOTE CONTROL
J25RLCNB 1982	REMOTE CONTROL
J25RLCOS 1985	REMOTE CONTROL
J25RLCRD 1984	REMOTE CONTROL

J25RLCTE 1983	REMOTE CONTROL
J25RLCUR 1987	REMOTE CONTROL
J25TECDC 1986	REMOTE CONTROL
J25TECNB 1982	REMOTE CONTROL
J25TECOS 1985	REMOTE CONTROL
J25TECRD 1984	REMOTE CONTROL
J25TECTE 1983	REMOTE CONTROL
J25TECUR 1987	REMOTE CONTROL
J25TELCDC 1986	REMOTE CONTROL
J25TELCOS 1985	REMOTE CONTROL
J25TELCRD 1984	REMOTE CONTROL
J25TELCCTE 1983	REMOTE CONTROL
J25TELCUR 1987	REMOTE CONTROL
J275CLCUR 1987	REMOTE CONTROL
J275CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275CXCUR 1987	REMOTE CONTROL
J275PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275PLCUR 1987	REMOTE CONTROL
J275PTLCDC 1986	REMOTE CONTROL
J275PTLCDC 1986	VRO PUMP
J275PTXCDC 1986	REMOTE CONTROL
J275PTXCDC 1986	VRO PUMP
J275PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275PXCUR 1987	REMOTE CONTROL
J275TLCOS 1985	REMOTE CONTROL
J275TLCOS 1985	VRO PUMP
J275TXCOS 1985	REMOTE CONTROL
J275TXCOS 1985	VRO PUMP
J28ELCDS 1986	REMOTE CONTROL - SURFACE MOUNT
J28ESLCCR 1988	REMOTE CONTROL - SURFACE MOUNT
J28ESLCEA 1989	REMOTE CONTROL
J28ESLCUC 1987	REMOTE CONTROL - SURFACE MOUNT
J28ESLESM 1990	REMOTE CONTROL
J300CLCUR 1987	REMOTE CONTROL
J300CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION

J300CXCEM 1989	REMOTE CONTROL
J300CXCUR 1987	REMOTE CONTROL
J300CXESB 1990	REMOTE CONTROL
J300PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300PLCEM 1989	REMOTE CONTROL
J300PLCUR 1987	REMOTE CONTROL
J300PLESB 1990	REMOTE CONTROL
J300PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300PXCEM 1989	REMOTE CONTROL
J300PXCUR 1987	REMOTE CONTROL
J300PXESB 1990	REMOTE CONTROL
J300TLCDC 1986	REMOTE CONTROL
J300TLCDC 1986	VRO PUMP
J300TLCOS 1985	REMOTE CONTROL
J300TLCOS 1985	VRO PUMP
J300TXCDC 1986	REMOTE CONTROL
J300TXCDC 1986	VRO PUMP
J300TXCOS 1985	REMOTE CONTROL
J300TXCOS 1985	VRO PUMP
J30ECCE 1988	REMOTE CONTROL
J30ECDM 1986	REMOTE CONTROL
J30ECED 1989	REMOTE CONTROL
J30EOA 1985	REMOTE CONTROL
J30ECRR 1984	REMOTE CONTROL
J30ECUB 1987	REMOTE CONTROL
J30EES 1990	REMOTE CONTROL
J30ELCCE 1988	REMOTE CONTROL
J30ELCDM 1986	REMOTE CONTROL
J30ELCED 1989	REMOTE CONTROL
J30ELCOA 1985	REMOTE CONTROL
J30ELCRR 1984	REMOTE CONTROL
J30ELCUB 1987	REMOTE CONTROL
J30ELESS 1990	REMOTE CONTROL
J30RCCE 1988	REMOTE CONTROL
J30RCDM 1986	REMOTE CONTROL

J30RCOA 1985	REMOTE CONTROL
J30RCUB 1987	REMOTE CONTROL
J30RLCCE 1988	REMOTE CONTROL
J30RLCDM 1986	REMOTE CONTROL
J30RLCOA 1985	REMOTE CONTROL
J30RLCUB 1987	REMOTE CONTROL
J30TECCE 1988	REMOTE CONTROL
J30TECDM 1986	REMOTE CONTROL
J30TECOA 1985	REMOTE CONTROL
J30TECUB 1987	REMOTE CONTROL
J30TELCCE 1988	REMOTE CONTROL
J30TELCDM 1986	REMOTE CONTROL
J30TELCOA 1985	REMOTE CONTROL
J30TELCUB 1987	REMOTE CONTROL
J35AELCDE 1986	REMOTE CONTROL
J35AELCUD 1987	REMOTE CONTROL
J35ARLCDE 1986	REMOTE CONTROL
J35ARLCUD 1987	REMOTE CONTROL
J35ECND 1982	REMOTE CONTROL
J35ECRR 1984	REMOTE CONTROL
J35ECTS 1983	REMOTE CONTROL
J35ELCND 1982	REMOTE CONTROL
J35ELCRR 1984	REMOTE CONTROL
J35ELCTS 1983	REMOTE CONTROL
J35RCCE 1988	REMOTE CONTROL
J35RCDM 1986	REMOTE CONTROL
J35RCND 1982	REMOTE CONTROL
J35RCRR 1984	REMOTE CONTROL
J35RCTS 1983	REMOTE CONTROL
J35RCUB 1987	REMOTE CONTROL
J35RLCCE 1988	REMOTE CONTROL
J35RLCDM 1986	REMOTE CONTROL
J35RLCND 1982	REMOTE CONTROL
J35RLCRR 1984	REMOTE CONTROL
J35RLCTS 1983	REMOTE CONTROL

J35RLCUB 1987	REMOTE CONTROL
J35TELCNB 1982	REMOTE CONTROL
J35TELCRR 1984	REMOTE CONTROL
J35TELCCTS 1983	REMOTE CONTROL
J40AELCCS 1988	REMOTE CONTROL
J40ARLCCS 1988	REMOTE CONTROL
J40ATLCCS 1988	REMOTE CONTROL
J40ECCS 1988	REMOTE CONTROL
J40ECDE 1986	REMOTE CONTROL
J40ECEC 1989	REMOTE CONTROL
J40ECOB 1985	REMOTE CONTROL
J40ECRM 1984	REMOTE CONTROL
J40ECUD 1987	REMOTE CONTROL
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EESR 1990	REMOTE CONTROL
J40ELCCS 1988	REMOTE CONTROL
J40ELCDE 1986	REMOTE CONTROL
J40ELCEC 1989	REMOTE CONTROL
J40ELCOB 1985	REMOTE CONTROL
J40ELCRM 1984	REMOTE CONTROL
J40ELCUD 1987	REMOTE CONTROL
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELESR 1990	REMOTE CONTROL
J40RCCS 1988	REMOTE CONTROL
J40RCDE 1986	REMOTE CONTROL
J40RCEC 1989	REMOTE CONTROL
J40RCOB 1985	REMOTE CONTROL

J40RCRM 1984	REMOTE CONTROL
J40RCUD 1987	REMOTE CONTROL
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RESR 1990	REMOTE CONTROL
J40RLCCS 1988	REMOTE CONTROL
J40RLCDE 1986	REMOTE CONTROL
J40RLCEC 1989	REMOTE CONTROL
J40RLCOB 1985	REMOTE CONTROL
J40RLCRM 1984	REMOTE CONTROL
J40RLCUD 1987	REMOTE CONTROL
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLESR 1990	REMOTE CONTROL
J40TECCS 1988	REMOTE CONTROL
J40TECDE 1986	REMOTE CONTROL
J40TECEC 1989	REMOTE CONTROL
J40TECOB 1985	REMOTE CONTROL
J40TECRM 1984	REMOTE CONTROL
J40TECUD 1987	REMOTE CONTROL
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEESR 1990	REMOTE CONTROL
J40TELCCS 1988	REMOTE CONTROL
J40TELCDE 1986	REMOTE CONTROL
J40TELCEC 1989	REMOTE CONTROL
J40TELCOB 1985	REMOTE CONTROL
J40TELCRM 1984	REMOTE CONTROL
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELESR 1990	REMOTE CONTROL
J40TLCCS 1988	REMOTE CONTROL
J40TLCDE 1986	REMOTE CONTROL
J40TLCEC 1989	REMOTE CONTROL
J40TLCUD 1987	REMOTE CONTROL
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLESR 1990	REMOTE CONTROL
J40TTLCCS 1988	REMOTE CONTROL
J40TTLCEC 1989	REMOTE CONTROL
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLESR 1990	REMOTE CONTROL
J45RCE 1989	REMOTE CONTROL - ELECTRIC START
J45RCEIA 1991	REMOTE CONTROL
J45RCENM 1992	REMOTE CONTROL
J45RCESR 1990	REMOTE CONTROL
J45RCLE 1989	REMOTE CONTROL - ELECTRIC START
J45RCLEIA 1991	REMOTE CONTROL
J45RCLENM 1992	REMOTE CONTROL
J45RCLESR 1990	REMOTE CONTROL
J45WMLE 1989	REMOTE CONTROL - ELECTRIC START
J45WMLEIA 1991	REMOTE CONTROL
J45WMLENM 1992	REMOTE CONTROL
J45WMLESR 1990	REMOTE CONTROL
J48ESLCCC 1988	REMOTE CONTROL
J48ESLCER 1989	REMOTE CONTROL

J48ESLCUS 1987	REMOTE CONTROL - SURFACE MOUNT
J48ESLESA 1990	REMOTE CONTROL
J50BECCS 1988	REMOTE CONTROL
J50BECDE 1986	REMOTE CONTROL
J50BECEC 1989	REMOTE CONTROL
J50BECIC 1981	REMOTE CONTROL
J50BECNR 1982	REMOTE CONTROL
J50BECOB 1985	REMOTE CONTROL
J50BECRM 1984	REMOTE CONTROL
J50BECTA 1983	REMOTE CONTROL
J50BECUD 1987	REMOTE CONTROL
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEESR 1990	REMOTE CONTROL
J50BELCCS 1988	REMOTE CONTROL
J50BELCDE 1986	REMOTE CONTROL
J50BELCEC 1989	REMOTE CONTROL
J50BELCIC 1981	REMOTE CONTROL
J50BELCNR 1982	REMOTE CONTROL
J50BELCOB 1985	REMOTE CONTROL
J50BELCRM 1984	REMOTE CONTROL
J50BELCTA 1983	REMOTE CONTROL
J50BELCUD 1987	REMOTE CONTROL
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELESR 1990	REMOTE CONTROL
J50ECSR 1980	REMOTE CONTROL
J50ELCSR 1980	REMOTE CONTROL
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TELCCS 1988	REMOTE CONTROL
J50TELCDE 1986	REMOTE CONTROL
J50TELCEC 1989	REMOTE CONTROL
J50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELCOB 1985	REMOTE CONTROL
J50TELCRM 1984	REMOTE CONTROL
J50TELECTA 1983	REMOTE CONTROL
J50TELCUD 1987	REMOTE CONTROL
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELESR 1990	REMOTE CONTROL
J50TLCCS 1988	REMOTE CONTROL
J50TLCDE 1986	REMOTE CONTROL
J50TLCEC 1989	REMOTE CONTROL
J50TLCOB 1985	REMOTE CONTROL
J50TLCRM 1984	REMOTE CONTROL
J50TLCUD 1987	REMOTE CONTROL
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLESR 1990	REMOTE CONTROL
J55RCIM 1981	REMOTE CONTROL
J55RLCIM 1981	REMOTE CONTROL
J55RLCSA 1980	REMOTE CONTROL
J55RWLE 1989	REMOTE CONTROL - ELECTRIC START
J55RWLEIA 1991	REMOTE CONTROL
J55RWLENM 1992	REMOTE CONTROL
J55RWLESR 1990	REMOTE CONTROL
J60ECIA 1981	REMOTE CONTROL

J60ECIH 1981	REMOTE CONTROL
J60ECNM 1982	REMOTE CONTROL
J60ECSR 1980	REMOTE CONTROL
J60ECTB 1983	REMOTE CONTROL
J60ELCCR 1988	REMOTE CONTROL
J60ELCDS 1986	REMOTE CONTROL
J60ELCEA 1989	REMOTE CONTROL
J60ELCIA 1981	REMOTE CONTROL
J60ELCIH 1981	REMOTE CONTROL
J60ELCNM 1982	REMOTE CONTROL
J60ELCOD 1985	REMOTE CONTROL
J60ELCRE 1984	REMOTE CONTROL
J60ELCSR 1980	REMOTE CONTROL
J60ELCTB 1983	REMOTE CONTROL
J60ELCUC 1987	REMOTE CONTROL
J60ELES 1990	REMOTE CONTROL
J60TLCCR 1988	REMOTE CONTROL
J60TLCDS 1986	REMOTE CONTROL
J60TLCEA 1989	REMOTE CONTROL
J60TLCIA 1981	REMOTE CONTROL
J60TLCIH 1981	REMOTE CONTROL
J60TLCNM 1982	REMOTE CONTROL
J60TLCOD 1985	REMOTE CONTROL
J60TLCRE 1984	REMOTE CONTROL
J60TLCTB 1983	REMOTE CONTROL
J60TLCUC 1987	REMOTE CONTROL
J60TLES 1990	REMOTE CONTROL
J60TTLCCR 1988	REMOTE CONTROL
J60TTLCEA 1989	REMOTE CONTROL
J60TTLES 1990	REMOTE CONTROL
J65RWLCRS 1984	REMOTE CONTROL
J65TELCRS 1984	REMOTE CONTROL
J65WELSIR Commercial, elec start, 20 in shaft 2001	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
J65WMLCDR 1986	REMOTE CONTROL

J65WMLCOC 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
J65WMLCOC 1985	REMOTE CONTROL
J65WMLCUA 1987	REMOTE CONTROL
J65WMLESM 1990	REMOTE CONTROL
J65WMLZ 1989	REMOTE CONTROL
J65WTLCOC 1985	FUEL PUMP & FILTER - WMLP & WMYP MODELS ONLY
J65WTLCOC 1985	REMOTE CONTROL
J65WTLCRS 1984	REMOTE CONTROL
J70ELCCA 1988	REMOTE CONTROL
J70ELCDC 1986	REMOTE CONTROL
J70ELCEM 1989	REMOTE CONTROL
J70ELCIH 1981	REMOTE CONTROL
J70ELCIM 1981	REMOTE CONTROL
J70ELCNB 1982	REMOTE CONTROL
J70ELCOS 1985	REMOTE CONTROL
J70ELCRD 1984	REMOTE CONTROL
J70ELCSA 1980	REMOTE CONTROL
J70ELCTE 1983	REMOTE CONTROL
J70ELCUR 1987	REMOTE CONTROL
J70ELESB 1990	REMOTE CONTROL
J70TLCCA 1988	REMOTE CONTROL
J70TLCDC 1986	REMOTE CONTROL
J70TLCEM 1989	REMOTE CONTROL
J70TLCIM 1981	REMOTE CONTROL
J70TLCNB 1982	REMOTE CONTROL
J70TLCOS 1985	REMOTE CONTROL
J70TLCRD 1984	REMOTE CONTROL
J70TLCTE 1983	REMOTE CONTROL
J70TLCUR 1987	REMOTE CONTROL
J70TLESB 1990	REMOTE CONTROL
J75ECCA 1988	REMOTE CONTROL
J75ECDC 1986	REMOTE CONTROL
J75ECNB 1982	REMOTE CONTROL
J75ECOS 1985	REMOTE CONTROL
J75ECDRD 1984	REMOTE CONTROL

J75ECTE 1983	REMOTE CONTROL
J75ECUR 1987	REMOTE CONTROL
J75ELCNB 1982	REMOTE CONTROL
J75ELCRD 1984	REMOTE CONTROL
J75ELCTE 1983	REMOTE CONTROL
J75ERCIH 1981	REMOTE CONTROL
J75ERCIM 1981	REMOTE CONTROL
J75ERCSA 1980	REMOTE CONTROL
J75ERLCIH 1981	REMOTE CONTROL
J75ERLCIM 1981	REMOTE CONTROL
J75ERLCSA 1980	REMOTE CONTROL
J75TELCIM 1981	REMOTE CONTROL
J75TLCNB 1982	REMOTE CONTROL
J75TLCRD 1984	REMOTE CONTROL
J75TLCTE 1983	REMOTE CONTROL
J75TRLCIH 1981	REMOTE CONTROL
J75TRLCSA 1980	REMOTE CONTROL
J85MLCSA 1980	REMOTE CONTROL
J85TLCSA 1980	REMOTE CONTROL
J85TXCSA 1980	REMOTE CONTROL
J88MSLCCC 1988	REMOTE CONTROL
J88MSLCER 1989	REMOTE CONTROL
J88MSLCUS 1987	REMOTE CONTROL - SURFACE MOUNT
J88MSLESA 1990	REMOTE CONTROL
J90MLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
J90MLCDC 1986	REMOTE CONTROL
J90MLCIH 1981	REMOTE CONTROL
J90MLCIM 1981	REMOTE CONTROL
J90MLCNB 1982	REMOTE CONTROL
J90MLCOS 1985	POWER TRIM/TILT ELECTRICAL
J90MLCOS 1985	REMOTE CONTROL
J90MLCRD 1984	REMOTE CONTROL
J90MLCTE 1983	REMOTE CONTROL
J90MLCUR 1987	REMOTE CONTROL
J90TLAEM 1989	REMOTE CONTROL

J90TLASB 1990	REMOTE CONTROL
J90TLCCA 1988	REMOTE CONTROL
J90TLCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
J90TLCDC 1986	REMOTE CONTROL
J90TLCEM 1989	REMOTE CONTROL
J90TLCIH 1981	REMOTE CONTROL
J90TLCIM 1981	REMOTE CONTROL
J90TLCNB 1982	REMOTE CONTROL
J90TLCOS 1985	POWER TRIM/TILT ELECTRICAL
J90TLCOS 1985	REMOTE CONTROL
J90TLCRD 1984	REMOTE CONTROL
J90TLCTE 1983	REMOTE CONTROL
J90TLCUR 1987	REMOTE CONTROL
J90TLESB 1990	REMOTE CONTROL
J90TXCDC 1986	POWER TRIM/TILT ELECTRICAL - 110TLCDF MODELS ONLY
J90TXCDC 1986	REMOTE CONTROL
J90TXCIH 1981	REMOTE CONTROL
J90TXCIM 1981	REMOTE CONTROL
J90TXCNB 1982	REMOTE CONTROL
J90TXCOS 1985	POWER TRIM/TILT ELECTRICAL
J90TXCOS 1985	REMOTE CONTROL
J90TXCRD 1984	REMOTE CONTROL
J90TXCTE 1983	REMOTE CONTROL
JBF2B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
JBF2B 1986	STEERING HOUSING GROUP / FOOT CONTROL
JBF2H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
JBF2H 1985	STEERING HOUSING GROUP / FOOT CONTROL
JBF2P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
JBF2P 1984	STEERING HOUSING GROUP / FOOT CONTROL
JBF2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
JBF2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
JBF2V 1983	STEERING HOUSING GROUP/FOOT CONTROL
JBF2V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
JBF2V 1983	TRANSOM MOUNT MODEL
JBF4B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL

JBF4B 1986	STEERING HOUSING GROUP / FOOT CONTROL
JBF4H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
JBF4H 1985	STEERING HOUSING GROUP / FOOT CONTROL
JBF4P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
JBF4P 1984	STEERING HOUSING GROUP / FOOT CONTROL
JBF4V 1983	STEERING HOUSING GROUP/FOOT CONTROL
JBF4V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
JBF4V 1983	TRANSOM MOUNT MODEL
JBFL2H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
JBFL2H 1985	STEERING HOUSING GROUP / FOOT CONTROL
JBFL2P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
JBFL2P 1984	STEERING HOUSING GROUP / FOOT CONTROL
JBFL2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
JBFL2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
JBFL2V 1983	STEERING HOUSING GROUP/FOOT CONTROL
JBFL2V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
JBFL2V 1983	TRANSOM MOUNT MODEL
JBFL4B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
JBFL4B 1986	STEERING HOUSING GROUP / FOOT CONTROL
JBFL4H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
JBFL4H 1985	STEERING HOUSING GROUP / FOOT CONTROL
JBFL4P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
JBFL4P 1984	STEERING HOUSING GROUP / FOOT CONTROL
JBH2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
JBH2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
JBH4P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
JBH4P 1984	STEERING HOUSING GROUP / FOOT CONTROL
JBH4V 1983	STEERING HOUSING GROUP/FOOT CONTROL
JBH4V 1983	STEERING HOUSING GROUP/HAND STEERING MODEL
JBH4V 1983	TRANSOM MOUNT MODEL
JBHL2TB 1986	STEERING HOUSING GROUP / HAND STEERING MODEL
JBHL2TB 1986	STEERING HOUSING GROUP / FOOT CONTROL
JBHL4H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
JBHL4H 1985	STEERING HOUSING GROUP / FOOT CONTROL
JTH2B 1986	STEERING HOUSING GROUP / HAND STEERING MODEL

JTH2B 1986	STEERING HOUSING GROUP / FOOT CONTROL
JTH2H 1985	STEERING HOUSING GROUP / HAND STEERING MODEL
JTH2H 1985	STEERING HOUSING GROUP / FOOT CONTROL
JTH2P 1984	STEERING HOUSING GROUP / HAND STEERING MODEL
JTH2P 1984	STEERING HOUSING GROUP / FOOT CONTROL
MISCELLANEOUS 1977	TILT AND TRIM LEVER ASSEMBLY 55-200 HP SINGLE ENGINE
MISCELLANEOUS 1978	TILT AND TRIM CONVERSION KIT DUAL ENGINE
MISCELLANEOUS 1978	TILT AND TRIM LEVER ASSEMBLY SINGLE ENGINE 55 - 235 HP
N65WMLM 1988	REMOTE CONTROL
REMOTE CONTROL 1995	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROL 1995	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROL 1996	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
REMOTE CONTROL 1996	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS	REMOTE CONTROL - SURFACE MOUNT WITH KEY SWITCH
REMOTE CONTROLS	REMOTE CONTROL - SURFACE MOUNT, NO KEY
REMOTE CONTROLS	REMOTE CONTROL - SURFACE MOUNT, NO KEY
REMOTE CONTROLS 1986	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1987	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1988	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1989	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1990	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1991	REMOTE CONTROL
REMOTE CONTROLS 1991	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1992	REMOTE CONTROL
REMOTE CONTROLS 1992	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1993	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROLS 1993	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1994	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROLS 1994	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1997	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
REMOTE CONTROLS 1997	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS 1998	REMOTE CONTROL -- SIDE MOUNT -- KEY SWITCH
REMOTE CONTROLS 1998	REMOTE CONTROL -- SURFACE MOUNT
REMOTE CONTROLS 1999	REMOTE CONTROL -- SIDE MOUNT -- KEY SWITCH

REMOTE CONTROLS 1999	REMOTE CONTROL -- SURFACE MOUNT
REMOTE CONTROLS 2000	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH (SYSTEM CHECK)
REMOTE CONTROLS 2000	REMOTE CONTROL - SURFACE MOUNT
REMOTE CONTROLS and CABLES	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
REMOTE CONTROLS and CABLES	REMOTE CONTROL - SURFACE MOUNT
SE125WTPLJ 1997	REMOTE CONTROL
SE125WTPLN 1998	REMOTE CONTROL
SE125WTPLV 1996	REMOTE CONTROL
SE125WTPXJ 1997	REMOTE CONTROL
SE125WTPXN 1998	REMOTE CONTROL
SE125WTPXV 1996	REMOTE CONTROL
SE150WTPLB 1996	REMOTE CONTROL
SE150WTPLT 1997	REMOTE CONTROL
SE150WTPLT4 1997	REMOTE CONTROL
SE150WTPLY 1998	REMOTE CONTROL
SE150WTPXB 1996	REMOTE CONTROL
SE150WTPXT 1997	REMOTE CONTROL
SE150WTPXT4 1997	REMOTE CONTROL
SE150WTPXY 1998	REMOTE CONTROL
SE200WTPLA 1996	REMOTE CONTROL
SE200WTPLG 1998	REMOTE CONTROL
SE200WTPLS 1997	REMOTE CONTROL
SE200WTPXA 1996	REMOTE CONTROL
SE200WTPXG 1998	REMOTE CONTROL
SE200WTPXS 1997	REMOTE CONTROL
SJ125WTPLJ 1997	REMOTE CONTROL
SJ125WTPLN 1998	REMOTE CONTROL
SJ125WTPLV 1996	REMOTE CONTROL
SJ125WTPXJ 1997	REMOTE CONTROL
SJ125WTPXN 1998	REMOTE CONTROL
SJ125WTPXV 1996	REMOTE CONTROL
SJ150WTPLB 1996	REMOTE CONTROL
SJ150WTPLT 1997	REMOTE CONTROL
SJ150WTPLT4 1997	REMOTE CONTROL

SJ150WTPLY 1998	REMOTE CONTROL
SJ150WTPXB 1996	REMOTE CONTROL
SJ150WTPXT 1997	REMOTE CONTROL
SJ150WTPXT4 1997	REMOTE CONTROL
SJ150WTPXY 1998	REMOTE CONTROL
SJ200WTPLA 1996	REMOTE CONTROL
SJ200WTPLG 1998	REMOTE CONTROL
SJ200WTPLS 1997	REMOTE CONTROL
SJ200WTPXA 1996	REMOTE CONTROL
SJ200WTPXG 1998	REMOTE CONTROL
SJ200WTPXS 1997	REMOTE CONTROL
T65WMLM 1988	REMOTE CONTROL
TE10ELESC 1990	REMOTE CONTROL
TE10RELESC 1990	REMOTE CONTROL
TE10RLESC 1990	REMOTE CONTROL
TE110TLCEM 1989	REMOTE CONTROL
TE110TLESF 1989	REMOTE CONTROL
TE110TXCEM 1989	REMOTE CONTROL
TE115TLESB 1990	REMOTE CONTROL
TE120TXCEM 1989	REMOTE CONTROL
TE150SLCEM 1989	REMOTE CONTROL
TE150SLESB 1990	REMOTE CONTROL
TE150TXCEM 1989	REMOTE CONTROL
TE200TXCEA 1989	REMOTE CONTROL
TE25ELCEB 1989	REMOTE CONTROL
TE25ELESE 1990	REMOTE CONTROL
TE25ELESF 1989	REMOTE CONTROL
TE30ELCED 1989	REMOTE CONTROL
TE30ELESF 1989	REMOTE CONTROL
TE30ELESS 1990	REMOTE CONTROL
TE40ELCEC 1989	REMOTE CONTROL
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

TE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELESR 1990	REMOTE CONTROL
TE40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40TELESF 1990	REMOTE CONTROL
TE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40TELESR 1990	REMOTE CONTROL
TE50TLCEC 1989	REMOTE CONTROL
TE50TLESF 1989	REMOTE CONTROL
TE50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE50TLESF 1990	REMOTE CONTROL
TE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE50TLESR 1990	REMOTE CONTROL
TE60TLCEA 1989	REMOTE CONTROL
TE60TLESF 1989	REMOTE CONTROL
TE60TLESF 1990	REMOTE CONTROL
TE60TLESM 1990	REMOTE CONTROL
TE70TLCEM 1989	REMOTE CONTROL
TE70TLESB 1990	REMOTE CONTROL
TE70TLESF 1989	REMOTE CONTROL
TE70TLESF 1990	REMOTE CONTROL
TE90TLCEM 1989	REMOTE CONTROL
TE90TLESB 1990	REMOTE CONTROL
TE90TLESF 1989	REMOTE CONTROL
TE90TLESF 1990	REMOTE CONTROL
TJ10ELESC 1990	REMOTE CONTROL
TJ10RELESC 1990	REMOTE CONTROL
TJ10RLESC 1990	REMOTE CONTROL
TJ110TLCEM 1989	REMOTE CONTROL
TJ110TXCEM 1989	REMOTE CONTROL
TJ115TLESB 1990	REMOTE CONTROL
TJ120TXCEM 1989	REMOTE CONTROL
TJ150SLCEM 1989	REMOTE CONTROL
TJ150SLESB 1990	REMOTE CONTROL
TJ150TXCEM 1989	REMOTE CONTROL
TJ200TXCEA 1989	REMOTE CONTROL

TJ25ELCEB 1989	REMOTE CONTROL
TJ25ELESE 1990	REMOTE CONTROL
TJ25ELESF 1989	REMOTE CONTROL
TJ30ELCED 1989	REMOTE CONTROL
TJ30ELESF 1989	REMOTE CONTROL
TJ30ELESS 1990	REMOTE CONTROL
TJ40ELCEC 1989	REMOTE CONTROL
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELESF 1990	REMOTE CONTROL
TJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELESR 1990	REMOTE CONTROL
TJ40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40TELESF 1990	REMOTE CONTROL
TJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40TELESR 1990	REMOTE CONTROL
TJ50TLCEC 1989	REMOTE CONTROL
TJ50TLESF 1989	REMOTE CONTROL
TJ50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ50TLESF 1990	REMOTE CONTROL
TJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ50TLESR 1990	REMOTE CONTROL
TJ60TLCEA 1989	REMOTE CONTROL
TJ60TLESF 1989	REMOTE CONTROL
TJ60TLESF 1990	REMOTE CONTROL
TJ60TLESM 1990	REMOTE CONTROL
TJ70TLCEM 1989	REMOTE CONTROL
TJ70TLESB 1990	REMOTE CONTROL
TJ70TLESF 1989	REMOTE CONTROL
TJ70TLESF 1990	REMOTE CONTROL
TJ90TLCEM 1989	REMOTE CONTROL
TJ90TLESB 1990	REMOTE CONTROL

VE100SLESB 1990	REMOTE CONTROL
VE115TLESB 1990	REMOTE CONTROL
VE115TXESB 1990	REMOTE CONTROL
VE120TLESB 1990	REMOTE CONTROL
VE120TXESB 1990	REMOTE CONTROL
VE140TLESE 1990	REMOTE CONTROL
VE140TXESE 1990	REMOTE CONTROL
VE150SLESB 1990	REMOTE CONTROL
VE150TLESB 1990	REMOTE CONTROL
VE150TXESB 1990	REMOTE CONTROL
VE175SLESE 1990	REMOTE CONTROL
VE175TXESE 1990	REMOTE CONTROL
VE200SLESE 1990	REMOTE CONTROL
VE200TXESM 1990	REMOTE CONTROL
VE225PLESS 1990	REMOTE CONTROL
VE225PXESS 1990	REMOTE CONTROL
VE225TLESS 1990	REMOTE CONTROL
VE225TXESS 1990	REMOTE CONTROL
VE25ELESE 1990	REMOTE CONTROL
VE28ESLCCR 1988	REMOTE CONTROL - SURFACE MOUNT
VE28ESLCEA 1989	REMOTE CONTROL
VE28ESLESM 1990	REMOTE CONTROL
VE30EES 1990	REMOTE CONTROL
VE30ELESS 1990	REMOTE CONTROL
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EESR 1990	REMOTE CONTROL
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

VE40ELESR 1990	REMOTE CONTROL
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELESR 1990	REMOTE CONTROL
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLESR 1990	REMOTE CONTROL
VE48ESLCCC 1988	REMOTE CONTROL
VE48ESLCER 1989	REMOTE CONTROL
VE48ESLESA 1990	REMOTE CONTROL
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEESR 1990	REMOTE CONTROL
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELESR 1990	REMOTE CONTROL
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLESR 1990	REMOTE CONTROL

VE60ELES M 1990	REMOTE CONTROL
VE60TLES M 1990	REMOTE CONTROL
VE70ELES B 1990	REMOTE CONTROL
VE70TLES B 1990	REMOTE CONTROL
VE88MSLCCC 1988	REMOTE CONTROL
VE88MSLCER 1989	REMOTE CONTROL
VE88MSLESA 1990	REMOTE CONTROL
VE90MLES B 1990	REMOTE CONTROL
VE90TLES B 1990	REMOTE CONTROL
VJ100SLES B 1990	REMOTE CONTROL
VJ115TLAS B 1990	REMOTE CONTROL
VJ115TLES B 1990	REMOTE CONTROL
VJ115TXES B 1990	REMOTE CONTROL
VJ120TLAS B 1990	REMOTE CONTROL
VJ120TLES B 1990	REMOTE CONTROL
VJ120TXES B 1990	REMOTE CONTROL
VJ140TLASE 1990	REMOTE CONTROL
VJ140TLESE 1990	REMOTE CONTROL
VJ140TXESE 1990	REMOTE CONTROL
VJ150SLES B 1990	REMOTE CONTROL
VJ150TLES B 1990	REMOTE CONTROL
VJ150TXES B 1990	REMOTE CONTROL
VJ175SLESE 1990	REMOTE CONTROL
VJ175TXESE 1990	REMOTE CONTROL
VJ200SLESE 1990	REMOTE CONTROL
VJ200TXES M 1990	REMOTE CONTROL
VJ225PLESS 1990	REMOTE CONTROL
VJ225PXESS 1990	REMOTE CONTROL
VJ225TLASS 1990	REMOTE CONTROL
VJ225TLESS 1990	REMOTE CONTROL
VJ225TXESS 1990	REMOTE CONTROL
VJ25ELESE 1990	REMOTE CONTROL
VJ28ESLCCR 1988	REMOTE CONTROL - SURFACE MOUNT
VJ28ESLCEA 1989	REMOTE CONTROL
VJ28ESLES M 1990	REMOTE CONTROL

VJ30EESS 1990	REMOTE CONTROL
VJ30ELESS 1990	REMOTE CONTROL
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EESR 1990	REMOTE CONTROL
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELESR 1990	REMOTE CONTROL
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELESR 1990	REMOTE CONTROL
VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLESR 1990	REMOTE CONTROL
VJ48ESLCCC 1988	REMOTE CONTROL
VJ48ESLCER 1989	REMOTE CONTROL
VJ48ESLESA 1990	REMOTE CONTROL
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEESR 1990	REMOTE CONTROL

VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELESR 1990	REMOTE CONTROL
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLESR 1990	REMOTE CONTROL
VJ60ELESB 1990	REMOTE CONTROL
VJ60TLESB 1990	REMOTE CONTROL
VJ70ELESB 1990	REMOTE CONTROL
VJ70TLESB 1990	REMOTE CONTROL
VJ88MSLCCC 1988	REMOTE CONTROL
VJ88MSLCER 1989	REMOTE CONTROL
VJ88MSLESA 1990	REMOTE CONTROL
VJ90MLESB 1990	REMOTE CONTROL
VJ90TLASB 1990	REMOTE CONTROL
VJ90TLESB 1990	REMOTE CONTROL
W100WTLM 1988	REMOTE CONTROL
W100WTXM 1988	REMOTE CONTROL
X155WTLM 1988	REMOTE CONTROL
X155WTXM 1988	REMOTE CONTROL