

Where Used: Part Number 0319682

Model Name	Diagram
100990S 1979	EXHAUST HOUSING
100990S 1979	IGNITION SYSTEM
100993S 1979	EXHAUST HOUSING
100993S 1979	IGNITION SYSTEM
100999S 1979	EXHAUST HOUSING
100999S 1979	IGNITION SYSTEM
100ML79S 1979	EXHAUST HOUSING
100ML79S 1979	IGNITION SYSTEM
100TLR79S 1979	EXHAUST HOUSING
100TLR79S 1979	IGNITION SYSTEM
100TXLR79S 1979	EXHAUST HOUSING
100TXLR79S 1979	IGNITION SYSTEM
115890C 1978	EXHAUST HOUSING
115893C 1978	EXHAUST HOUSING
115899C 1978	EXHAUST HOUSING
115990R 1979	EXHAUST HOUSING
115990R 1979	IGNITION SYSTEM
115993R 1979	EXHAUST HOUSING
115993R 1979	IGNITION SYSTEM
115999R 1979	EXHAUST HOUSING
115999R 1979	IGNITION SYSTEM
115ETZ78C 1978	EXHAUST HOUSING
115ML78C 1978	EXHAUST HOUSING
115ML79R 1979	EXHAUST HOUSING
115ML79R 1979	IGNITION SYSTEM
115TL79R 1979	EXHAUST HOUSING
115TL79R 1979	IGNITION SYSTEM
115TXL78C 1978	EXHAUST HOUSING
115TXL79R 1979	EXHAUST HOUSING
115TXL79R 1979	IGNITION SYSTEM
140840C 1978	EXHAUST HOUSING
140843C 1978	EXHAUST HOUSING
140883C 1978	EXHAUST HOUSING

140940R 1979	EXHAUST HOUSING
140940R 1979	IGNITION SYSTEM
140943R 1979	EXHAUST HOUSING
140943R 1979	IGNITION SYSTEM
140983R 1979	EXHAUST HOUSING
140983R 1979	IGNITION SYSTEM
140ML78C 1978	EXHAUST HOUSING
140ML79R 1979	EXHAUST HOUSING
140ML79R 1979	IGNITION SYSTEM
140TL78C 1978	EXHAUST HOUSING
140TL79R 1979	EXHAUST HOUSING
140TL79R 1979	IGNITION SYSTEM
140TX78C 1978	EXHAUST HOUSING
140TXL79R 1979	EXHAUST HOUSING
140TXL79R 1979	IGNITION SYSTEM
150840S 1978	EXHAUST HOUSING
150849S 1978	EXHAUST HOUSING
150940C 1979	EXHAUST HOUSING
150940C 1979	IGNITION SYSTEM
150949C 1979	EXHAUST HOUSING
150949C 1979	IGNITION SYSTEM
150TL78S 1978	EXHAUST HOUSING
150TL79C 1979	EXHAUST HOUSING
150TL79C 1979	IGNITION SYSTEM
150TXL78S 1978	EXHAUST HOUSING
150TXL79C 1979	EXHAUST HOUSING
150TXL79C 1979	IGNITION SYSTEM
175840C 1978	EXHAUST HOUSING
175840S 1978	EXHAUST HOUSING
175940R 1979	EXHAUST HOUSING
175940R 1979	IGNITION SYSTEM
175949R 1979	EXHAUST HOUSING
175949R 1979	IGNITION SYSTEM
175TL78C 1978	EXHAUST HOUSING
175TL79R 1979	EXHAUST HOUSING

175TL79R 1979	IGNITION SYSTEM
175TX78C 1978	EXHAUST HOUSING
175TXL79R 1979	EXHAUST HOUSING
175TXL79R 1979	IGNITION SYSTEM
200490A 1979	EXHAUST HOUSING
200490A 1979	IGNITION SYSTEM
200840R 1978	EXHAUST HOUSING
200849R 1978	EXHAUST HOUSING
200940A 1979	EXHAUST HOUSING
200940A 1979	IGNITION SYSTEM
200949A 1979	EXHAUST HOUSING
200949A 1979	IGNITION SYSTEM
200TL78R 1978	EXHAUST HOUSING
200TL79A 1979	EXHAUST HOUSING
200TL79A 1979	IGNITION SYSTEM
200TX78R 1978	EXHAUST HOUSING
200TXL79A 1979	EXHAUST HOUSING
200TXL79A 1979	IGNITION SYSTEM
235840R 1978	EXHAUST HOUSING
235849R 1978	EXHAUST HOUSING
235940A 1979	EXHAUST HOUSING
235940A 1979	IGNITION SYSTEM
235949A 1979	EXHAUST HOUSING
235949A 1979	IGNITION SYSTEM
235TL70A 1979	EXHAUST HOUSING
235TL70A 1979	IGNITION SYSTEM
235TL78R 1978	EXHAUST HOUSING
235TX78R 1978	EXHAUST HOUSING
235TXL79A 1979	EXHAUST HOUSING
235TXL79A 1979	IGNITION SYSTEM
85890C 1978	EXHAUST HOUSING
85895C 1978	EXHAUST HOUSING
85899C 1978	EXHAUST HOUSING
85990R 1979	EXHAUST HOUSING
85990R 1979	IGNITION SYSTEM

85995R 1979	EXHAUST HOUSING
85995R 1979	IGNITION SYSTEM
85999R 1979	EXHAUST HOUSING
85999R 1979	IGNITION SYSTEM
85ETLR78C 1978	EXHAUST HOUSING
85ML78C 1978	EXHAUST HOUSING
85ML79R 1979	EXHAUST HOUSING
85ML79R 1979	IGNITION SYSTEM
85TL79R 1979	EXHAUST HOUSING
85TL79R 1979	IGNITION SYSTEM
85TXL79R 1979	EXHAUST HOUSING
85TXL79R 1979	IGNITION SYSTEM
85TXLR78C 1978	EXHAUST HOUSING
AM55RSLD 1999	IGNITION SYSTEM
B25JREUR 1997	IGNITION
BE10EEDD 1996	IGNITION - ROPE
BE10ELEDD 1996	IGNITION - ROPE
BE10REDD 1996	IGNITION - ROPE
BE10RELEDD 1996	IGNITION - ROPE
BE10RELEUS 1997	IGNITION - ROPE
BE10RLEDD 1996	IGNITION - ROPE
BE10SELEDD 1996	IGNITION - ROPE
BE15EEDS 1996	IGNITION - ROPE
BE15ELEDS 1996	IGNITION - ROPE
BE15REDS 1996	IGNITION - ROPE
BE15RELEUC 1997	IGNITION - ROPE
BE15RLEDS 1996	IGNITION - ROPE
BE20SEECB 1998	IGNITION
BE20SEEDA 1996	IGNITION
BE20SEEUM 1997	IGNITION
BE20SELECB 1998	IGNITION
BE20SELEDA 1996	IGNITION
BE20SELEUM 1997	IGNITION
BE20SRECB 1998	IGNITION
BE20SREDA 1996	IGNITION

BE20SREUM 1997	IGNITION
BE20SRLECB 1998	IGNITION
BE20SRLEDA 1996	IGNITION
BE20SRLEUM 1997	IGNITION
BE25BAECM 1998	IGNITION
BE25BAEDR 1996	IGNITION
BE25BAEUA 1997	IGNITION
BE25BALECM 1998	IGNITION
BE25BALEDR 1996	IGNITION
BE25BALEUA 1997	IGNITION
BE25BREDC 1996	IGNITION
BE25BRLEDC 1996	IGNITION
BE25EECE 1998	IGNITION
BE25EEDM 1996	IGNITION
BE25EEUB 1997	IGNITION
BE25ELECE 1998	IGNITION
BE25ELEDM 1996	IGNITION
BE25ELEUB 1997	IGNITION
BE25EREDEC 1996	IGNITION
BE25ERLEDC 1996	IGNITION
BE30BAECS 1998	IGNITION
BE30BAEDE 1996	IGNITION
BE30BAESEC 1999	IGNITION
BE30BAEEN 1999	IGNITION
BE30BAEUD 1997	IGNITION
BE30BALECS 1998	IGNITION
BE30BALEDE 1996	IGNITION
BE30BALEUD 1997	IGNITION
BE30BASIA rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
BE30BASSR Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
BE30EECS 1998	IGNITION
BE30EEDE 1996	IGNITION
BE30EEUD 1997	IGNITION
BE30ELECS 1998	IGNITION
BE30ELEDE 1996	IGNITION

BE30ELEUD 1997	IGNITION
BE40EECR 1998	IGNITION SYSTEM -- ROPE START
BE40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40EEUC 1997	IGNITION SYSTEM - ROPE START
BE40ELECR 1998	IGNITION SYSTEM -- ROPE START
BE40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40ELEUC 1997	IGNITION SYSTEM - ROPE START
BE40TLECR 1998	IGNITION SYSTEM -- ROPE START
BE40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40TLEUC 1997	IGNITION SYSTEM - ROPE START
BE4RDHEDS 1996	MAGNETO
BE4RDHLEDS 1996	MAGNETO
BE50BEEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE50BELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE50ESECC 1998	IGNITION SYSTEM -- ROPE START
BE50RLECR 1998	IGNITION SYSTEM -- ROPE START
BE50RLEUC 1997	IGNITION SYSTEM - ROPE START
BE50TLECR 1998	IGNITION SYSTEM -- ROPE START
BE50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE50TLEUC 1997	IGNITION SYSTEM - ROPE START
BE50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BE50TSLEUS 1997	IGNITION SYSTEM - ROPE START
BE5DREDS 1996	IGNITION
BE5DREUC 1997	IGNITION
BE5DRLEDS 1996	IGNITION
BE5DRLEUC 1997	IGNITION
BE6DRECR 1998	IGNITION
BE6DREDS 1996	IGNITION
BE6DREUC 1997	IGNITION
BE6DRLECR 1998	IGNITION
BE6DRLEDS 1996	IGNITION
BE6DRLEUC 1997	IGNITION
BE6REDS 1996	IGNITION
BE6RLEDS 1996	IGNITION
BE8RCB 1997	IGNITION

BE8RCH 1996	IGNITION
BE8RCLB 1997	IGNITION
BE8RCLH 1996	IGNITION
BE8RCLT 1998	IGNITION
BE8RCT 1998	IGNITION
BE8REDS 1996	IGNITION
BE8RLEDS 1996	IGNITION
BE8SRLEDS 1996	IGNITION
BJ10EEDD 1996	IGNITION - ROPE
BJ10ELEDD 1996	IGNITION - ROPE
BJ10REDD 1996	IGNITION - ROPE
BJ10RELEDD 1996	IGNITION - ROPE
BJ10RELEUS 1997	IGNITION - ROPE
BJ10RHLSDA	IGNITION
BJ10RHLSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSOR	IGNITION
BJ10RHLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSRC	IGNITION
BJ10RHLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSTS	IGNITION
BJ10RHLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSDA	IGNITION
BJ10RHSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSOR	IGNITION
BJ10RHSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSRC	IGNITION
BJ10RHSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSTS	IGNITION
BJ10RHSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RLEDD 1996	IGNITION - ROPE
BJ10SELEDD 1996	IGNITION - ROPE
BJ15EEDS 1996	IGNITION - ROPE
BJ15ELEDS 1996	IGNITION - ROPE
BJ15REDS 1996	IGNITION - ROPE
BJ15RELEUC 1997	IGNITION - ROPE

BJ15RLEDS 1996	IGNITION - ROPE
BJ20SEECB 1998	IGNITION
BJ20SEEDA 1996	IGNITION
BJ20SEEUM 1997	IGNITION
BJ20SELECB 1998	IGNITION
BJ20SELEDA 1996	IGNITION
BJ20SELEUM 1997	IGNITION
BJ20SRECB 1998	IGNITION
BJ20SREDA 1996	IGNITION
BJ20SREUM 1997	IGNITION
BJ20SRLECB 1998	IGNITION
BJ20SRLEDA 1996	IGNITION
BJ20SRLEUM 1997	IGNITION
BJ25BAECM 1998	IGNITION
BJ25BAEDR 1996	IGNITION
BJ25BAEUA 1997	IGNITION
BJ25BALECM 1998	IGNITION
BJ25BALEDR 1996	IGNITION
BJ25BALEUA 1997	IGNITION
BJ25BREDC 1996	IGNITION
BJ25BRLEDC 1996	IGNITION
BJ25EECE 1998	IGNITION
BJ25EEDM 1996	IGNITION
BJ25EEED 1999	IGNITION
BJ25EEEN 1999	IGNITION
BJ25EEUB 1997	IGNITION
BJ25ELECE 1998	IGNITION
BJ25ELEDM 1996	IGNITION
BJ25ELEED 1999	IGNITION
BJ25ELEEN 1999	IGNITION
BJ25ELEUB 1997	IGNITION
BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ25EREDC 1996	IGNITION
BJ25ERLEDC 1996	IGNITION

BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ25EVLSIC elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ30BAECS 1998	IGNITION
BJ30BAEDE 1996	IGNITION
BJ30BAEEC 1999	IGNITION
BJ30BAEEN 1999	IGNITION
BJ30BAEUD 1997	IGNITION
BJ30BALECS 1998	IGNITION
BJ30BALEDE 1996	IGNITION
BJ30BALEUD 1997	IGNITION
BJ30EECS 1998	IGNITION
BJ30EEDE 1996	IGNITION
BJ30EEEC 1999	IGNITION
BJ30EEEN 1999	IGNITION
BJ30EEUD 1997	IGNITION
BJ30ELECS 1998	IGNITION
BJ30ELEDE 1996	IGNITION
BJ30ELEEC 1999	IGNITION
BJ30ELEEN 1999	IGNITION
BJ30ELEUD 1997	IGNITION
BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ30EVLSIA elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ40EECR 1998	IGNITION SYSTEM -- ROPE START
BJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40EEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40EEUC 1997	IGNITION SYSTEM - ROPE START
BJ40ELECR 1998	IGNITION SYSTEM -- ROPE START
BJ40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40ELEEA 1999	IGNITION SYSTEM -- ROPE START

BJ40ELEUC 1997	IGNITION SYSTEM - ROPE START
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ4RDHEDS 1996	MAGNETO
BJ4RDHLEDS 1996	MAGNETO
BJ50BEEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50BELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50EEER 1999	IGNITION SYSTEM -- ROPE START
BJ50ELEER 1999	IGNITION SYSTEM -- ROPE START
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50ESECC 1998	IGNITION SYSTEM -- ROPE START
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50RLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50RLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50RLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BJ50TSLEUS 1997	IGNITION SYSTEM - ROPE START

BJ5DREDS 1996	IGNITION
BJ5DREUC 1997	IGNITION
BJ5DRLEDS 1996	IGNITION
BJ5DRLEUC 1997	IGNITION
BJ6DRECR 1998	IGNITION
BJ6DREDS 1996	IGNITION
BJ6DREUC 1997	IGNITION
BJ6DRLECR 1998	IGNITION
BJ6DRLEDS 1996	IGNITION
BJ6DRLEUC 1997	IGNITION
BJ6REDS 1996	IGNITION
BJ6RLEDS 1996	IGNITION
BJ8RCB 1997	IGNITION
BJ8RCH 1996	IGNITION
BJ8RCLB 1997	IGNITION
BJ8RCLH 1996	IGNITION
BJ8RCLT 1998	IGNITION
BJ8RCT 1998	IGNITION
BJ8REDS 1996	IGNITION
BJ8RLEDS 1996	IGNITION
BJ8SRLEDS 1996	IGNITION
CE275TLCDC 1986	MIDSECTION
CE275TLCOS 1985	MIDSECTION
CE275TXCDC 1986	MIDSECTION
CE275TXCOS 1985	MIDSECTION
CE300TLCDC 1986	MIDSECTION
CE300TLCOS 1985	MIDSECTION
CE300TXCDC 1986	MIDSECTION
CE300TXCOS 1985	MIDSECTION
CJ275TLCDC 1986	MIDSECTION
CJ275TLCOS 1985	MIDSECTION
CJ275TXCDC 1986	MIDSECTION
CJ275TXCOS 1985	MIDSECTION
CJ300TLCDC 1986	MIDSECTION
CJ300TLCOS 1985	MIDSECTION

CJ300TXCDC 1986	MIDSECTION
CJ300TXCOS 1985	MIDSECTION
E100MLCSC 1980	EXHAUST HOUSING
E100MLCSC 1980	IGNITION SYSTEM
E100TLCSC 1980	EXHAUST HOUSING
E100TLCSC 1980	IGNITION SYSTEM
E100TXCSC 1980	EXHAUST HOUSING
E100TXCSC 1980	IGNITION SYSTEM
E100WMLCDR 1986	CARBURETOR
E100WMLCDR 1986	MIDSECTION
E100WMLCOC 1985	CARBURETOR
E100WMLCOC 1985	MIDSECTION
E100WMLCRS 1984	CARBURETOR, FUEL PUMP AND FILTER
E100WMLCRS 1984	MIDSECTION
E100WTLCDR 1986	CARBURETOR
E100WTLCDR 1986	MIDSECTION
E100WTLcoc 1985	CARBURETOR
E100WTLcoc 1985	MIDSECTION
E100WTLCRS 1984	CARBURETOR, FUEL PUMP AND FILTER
E100WTLCRS 1984	MIDSECTION
E100WTLCUA 1987	MIDSECTION
E100WTXCDR 1986	CARBURETOR
E100WTXCDR 1986	MIDSECTION
E100WTXCUA 1987	MIDSECTION
E10EECC 1998	IGNITION -- ROPE
E10EEDD 1996	IGNITION - ROPE
E10EEOE 1995	IGNITION - ROPE
E10EERB 1994	IGNITION - ROPE
E10EEUS 1997	IGNITION - ROPE
E10ELECC 1998	IGNITION -- ROPE
E10ELEDD 1996	IGNITION - ROPE
E10ELEOE 1995	IGNITION - ROPE
E10ELERB 1994	IGNITION - ROPE
E10ELEUS 1997	IGNITION - ROPE
E10RECC 1998	IGNITION -- ROPE

E10REDD 1996	IGNITION - ROPE
E10RELECC 1998	IGNITION -- ROPE
E10RELEDD 1996	IGNITION - ROPE
E10RELEOE 1995	IGNITION - ROPE
E10RELEROB 1994	IGNITION - ROPE
E10RELEUS 1997	IGNITION - ROPE
E10REOE 1995	IGNITION - ROPE
E10RERB 1994	IGNITION - ROPE
E10REUS 1997	IGNITION - ROPE
E10RLECC 1998	IGNITION -- ROPE
E10RLEDD 1996	IGNITION - ROPE
E10RLEOE 1995	IGNITION - ROPE
E10RLEROB 1994	IGNITION - ROPE
E10RLEUS 1997	IGNITION - ROPE
E10SELECC 1998	IGNITION -- ROPE
E10SELEDD 1996	IGNITION - ROPE
E10SELEOE 1995	IGNITION - ROPE
E10SELERB 1994	IGNITION - ROPE
E10SELEUS 1997	IGNITION - ROPE
E110MLCDC 1986	CARBURETOR
E110MLCDC 1986	MIDSECTION
E110MLCUR 1987	MIDSECTION
E110TLCDC 1986	CARBURETOR
E110TLCDC 1986	MIDSECTION
E110TLCDF 1986	CARBURETOR
E110TLCDF 1986	MIDSECTION
E110TLCUR 1987	MIDSECTION
E110TXCUR 1987	MIDSECTION
E115MLCIH 1981	EXHAUST HOUSING
E115MLCIH 1981	IGNITION SYSTEM
E115MLCIM 1981	EXHAUST HOUSING
E115MLCIM 1981	IGNITION SYSTEM
E115MLCNB 1982	EXHAUST HOUSING
E115MLCNB 1982	IGNITION SYSTEM
E115MLCOS 1985	CARBURETOR

E115MLCOS 1985	MIDSECTION
E115MLCRD 1984	CARBURETOR
E115MLCRD 1984	MIDSECTION
E115MLCSA 1980	EXHAUST HOUSING
E115MLCSA 1980	IGNITION SYSTEM
E115MLCTE 1983	EXHAUST HOUSING
E115TLCIH 1981	EXHAUST HOUSING
E115TLCIH 1981	IGNITION SYSTEM
E115TLCIM 1981	EXHAUST HOUSING
E115TLCIM 1981	IGNITION SYSTEM
E115TLCNB 1982	EXHAUST HOUSING
E115TLCNB 1982	IGNITION SYSTEM
E115TLCOS 1985	CARBURETOR
E115TLCOS 1985	MIDSECTION
E115TLCRD 1984	CARBURETOR
E115TLCRD 1984	MIDSECTION
E115TLCSA 1980	EXHAUST HOUSING
E115TLCSA 1980	IGNITION SYSTEM
E115TLCTE 1983	EXHAUST HOUSING
E115TXXIH 1981	EXHAUST HOUSING
E115TXXIH 1981	IGNITION SYSTEM
E115TXXIM 1981	EXHAUST HOUSING
E115TXXIM 1981	IGNITION SYSTEM
E115TXXNB 1982	EXHAUST HOUSING
E115TXXNB 1982	IGNITION SYSTEM
E115TXXRD 1984	CARBURETOR
E115TXXRD 1984	MIDSECTION
E115TXXSA 1980	EXHAUST HOUSING
E115TXXSA 1980	IGNITION SYSTEM
E115TXXTE 1983	EXHAUST HOUSING
E120TLCDC 1986	MIDSECTION
E120TLCOS 1985	MIDSECTION
E120TLCUR 1987	MIDSECTION
E120TXXCDC 1986	MIDSECTION
E120TXXCOS 1985	MIDSECTION

E120TXCUR 1987	MIDSECTION
E140MLCIH 1981	EXHAUST HOUSING
E140MLCIH 1981	IGNITION SYSTEM
E140MLCIM 1981	EXHAUST HOUSING
E140MLCIM 1981	IGNITION SYSTEM
E140MLCNB 1982	EXHAUST HOUSING
E140MLCNB 1982	IGNITION SYSTEM
E140MLCSA 1980	EXHAUST HOUSING
E140MLCSA 1980	IGNITION SYSTEM
E140MLCTE 1983	EXHAUST HOUSING
E140TLCDC 1986	MIDSECTION
E140TLCOS 1985	MIDSECTION
E140TLCRD 1984	CARBURETOR
E140TLCRD 1984	MIDSECTION
E140TLCUA 1987	MIDSECTION
E140TRLCIH 1981	EXHAUST HOUSING
E140TRLCIH 1981	IGNITION SYSTEM
E140TRLCIM 1981	EXHAUST HOUSING
E140TRLCIM 1981	IGNITION SYSTEM
E140TRLCNB 1982	EXHAUST HOUSING
E140TRLCNB 1982	IGNITION SYSTEM
E140TRLCSA 1980	EXHAUST HOUSING
E140TRLCSA 1980	IGNITION SYSTEM
E140TRLCTE 1983	EXHAUST HOUSING
E140TRXCIH 1981	EXHAUST HOUSING
E140TRXCIH 1981	IGNITION SYSTEM
E140TRXCIM 1981	EXHAUST HOUSING
E140TRXCIM 1981	IGNITION SYSTEM
E140TRXCNB 1982	EXHAUST HOUSING
E140TRXCNB 1982	IGNITION SYSTEM
E140TRXCSA 1980	EXHAUST HOUSING
E140TRXCSA 1980	IGNITION SYSTEM
E140TRXCTE 1983	EXHAUST HOUSING
E140TXCDC 1986	MIDSECTION
E140TXCOS 1985	MIDSECTION

E140TXCRD 1984	CARBURETOR
E140TXCRD 1984	MIDSECTION
E140TXYUA 1987	MIDSECTION
E150ANCRS 1984	CARBURETOR
E150ANCRS 1984	MIDSECTION
E150STLCDC 1986	CARBURETOR
E150STLCDC 1986	MIDSECTION
E150STLCOH 1985	CARBURETOR
E150STLCOH 1985	MIDSECTION
E150STLCOS 1985	CARBURETOR
E150STLCOS 1985	MIDSECTION
E150STLCRD 1984	CARBURETOR
E150STLCRD 1984	MIDSECTION
E150STLCTE 1983	MID-SECTION
E150STLCUR 1987	MIDSECTION
E150TLCDC 1986	CARBURETOR
E150TLCDC 1986	MIDSECTION
E150TLCOS 1985	CARBURETOR
E150TLCOS 1985	MIDSECTION
E150TLCRD 1984	CARBURETOR
E150TLCRD 1984	MIDSECTION
E150TLCUR 1987	MIDSECTION
E150TRLCIA 1981	EXHAUST HOUSING
E150TRLCIH 1981	EXHAUST HOUSING
E150TRLCNM 1982	EXHAUST HOUSING
E150TRLCSF 1980	EXHAUST HOUSING
E150TRLCSF 1980	IGNITION SYSTEM
E150TRLCSR 1980	EXHAUST HOUSING
E150TRLCSR 1980	IGNITION SYSTEM
E150TRLCTB 1983	EXHAUST HOUSING
E150TRLCTE 1983	EXHAUST HOUSING
E150TRXCIA 1981	EXHAUST HOUSING
E150TRXCIH 1981	EXHAUST HOUSING
E150TRXCNM 1982	EXHAUST HOUSING
E150TRXCSF 1980	EXHAUST HOUSING

E150TRXCSF 1980	IGNITION SYSTEM
E150TRXCSR 1980	EXHAUST HOUSING
E150TRXCSR 1980	IGNITION SYSTEM
E150TRXCTB 1983	EXHAUST HOUSING
E150TRXCTE 1983	EXHAUST HOUSING
E150TXCDC 1986	CARBURETOR
E150TXCDC 1986	MIDSECTION
E150TXCOS 1985	CARBURETOR
E150TXCOS 1985	MIDSECTION
E150TXCRD 1984	CARBURETOR
E150TXCRD 1984	MIDSECTION
E150TXYCUR 1987	MIDSECTION
E155WTLCDR 1986	CARBURETOR
E155WTLCDR 1986	MIDSECTION
E155WTLCCOC 1985	CARBURETOR
E155WTLCCOC 1985	MIDSECTION
E155WTLCCRS 1984	CARBURETOR
E155WTLCCRS 1984	MIDSECTION
E155WTLCUA 1987	MIDSECTION
E155WTXCDR 1986	CARBURETOR
E155WTXCDR 1986	MIDSECTION
E155WTXCOC 1985	CARBURETOR
E155WTXCOC 1985	MIDSECTION
E155WTXCRS 1984	CARBURETOR
E155WTXCRS 1984	MIDSECTION
E155WTXCUA 1987	MIDSECTION
E15EECR 1998	IGNITION -- ROPE
E15EEDS 1996	IGNITION - ROPE
E15EEOD 1995	IGNITION - ROPE
E15EEERE 1994	IGNITION - ROPE
E15EEUC 1997	IGNITION - ROPE
E15ELECR 1998	IGNITION -- ROPE
E15ELEDS 1996	IGNITION - ROPE
E15ELEOD 1995	IGNITION - ROPE
E15ELERERE 1994	IGNITION - ROPE

E15ELEUC 1997	IGNITION - ROPE
E15RECR 1998	IGNITION -- ROPE
E15REDS 1996	IGNITION - ROPE
E15RELECR 1998	IGNITION -- ROPE
E15RELEDS 1996	IGNITION - ROPE
E15RELEOD 1995	IGNITION - ROPE
E15RELERE 1994	IGNITION - ROPE
E15RELEUC 1997	IGNITION - ROPE
E15REOD 1995	IGNITION - ROPE
E15RERE 1994	IGNITION - ROPE
E15REUC 1997	IGNITION - ROPE
E15RLECR 1998	IGNITION -- ROPE
E15RLEDS 1996	IGNITION - ROPE
E15RLEOD 1995	IGNITION - ROPE
E15RLERE 1994	IGNITION - ROPE
E15RLEUC 1997	IGNITION - ROPE
E15WREES 1999	IGNITION
E15WRLEES 1999	IGNITION
E15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
E15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
E175TLCDR 1986	CARBURETOR
E175TLCDR 1986	MIDSECTION
E175TLCOC 1985	CARBURETOR
E175TLCOC 1985	MIDSECTION
E175TLCUA 1987	MIDSECTION
E175TRLCIM 1981	EXHAUST HOUSING
E175TRLCNB 1982	EXHAUST HOUSING
E175TRLCSA 1980	EXHAUST HOUSING
E175TRLCSA 1980	IGNITION SYSTEM
E175TRLCSF 1980	EXHAUST HOUSING
E175TRLCSF 1980	IGNITION SYSTEM
E175TRLCTD 1983	EXHAUST HOUSING
E175TRLCTE 1983	EXHAUST HOUSING

E175TRXCIH 1981	EXHAUST HOUSING
E175TRXCIM 1981	EXHAUST HOUSING
E175TRXCNB 1982	EXHAUST HOUSING
E175TRXCSA 1980	EXHAUST HOUSING
E175TRXCSA 1980	IGNITION SYSTEM
E175TRXCSF 1980	EXHAUST HOUSING
E175TRXCSF 1980	IGNITION SYSTEM
E175TRXCTD 1983	EXHAUST HOUSING
E175TRXCTE 1983	EXHAUST HOUSING
E175TXCDR 1986	CARBURETOR
E175TXCDR 1986	MIDSECTION
E175TXCOC 1985	CARBURETOR
E175TXCOC 1985	MIDSECTION
E175TXCUA 1987	MIDSECTION
E185TLCOC 1985	CARBURETOR
E185TLCOC 1985	MIDSECTION
E185TLCRS 1984	CARBURETOR
E185TLCRS 1984	MIDSECTION
E185TXCOC 1985	CARBURETOR
E185TXCOC 1985	MIDSECTION
E185TXCRS 1984	CARBURETOR
E185TXCRS 1984	MIDSECTION
E200STLCDR 1986	MIDSECTION
E200STLCUA 1987	MIDSECTION
E200TRLCIB 1981	EXHAUST HOUSING
E200TRLCIH 1981	EXHAUST HOUSING
E200TRLCNE 1982	EXHAUST HOUSING
E200TRLCSF 1980	EXHAUST HOUSING
E200TRLCSF 1980	IGNITION SYSTEM
E200TRLCSM 1980	EXHAUST HOUSING
E200TRLCSM 1980	IGNITION SYSTEM
E200TRLCTD 1983	EXHAUST HOUSING
E200TRLCTS 1983	EXHAUST HOUSING
E200TRXCIB 1981	EXHAUST HOUSING
E200TRXCIH 1981	EXHAUST HOUSING

E200TRXCNE 1982	EXHAUST HOUSING
E200TRXCSF 1980	EXHAUST HOUSING
E200TRXCSF 1980	IGNITION SYSTEM
E200TRXCSM 1980	EXHAUST HOUSING
E200TRXCSM 1980	IGNITION SYSTEM
E200TRXCTD 1983	EXHAUST HOUSING
E200TRXCTS 1983	EXHAUST HOUSING
E200TXCDS 1986	MIDSECTION
E200TXCUC 1987	MIDSECTION
E20CRCOS 1985	CARBURETOR
E20CREDA 1996	IGNITION
E20CREOR 1995	IGNITION
E20CRERC 1994	IGNITION
E20CRETS 1993	IGNITION
E20CREUM 1997	IGNITION
E20CRLCOS 1985	CARBURETOR
E20CRLEDA 1996	IGNITION
E20CRLEOR 1995	IGNITION
E20CRLERC 1994	IGNITION
E20CRLETS 1993	IGNITION
E20CRLEUM 1997	IGNITION
E20ECOS 1985	CARBURETOR
E20EEOR 1995	IGNITION
E20EERC 1994	IGNITION
E20EETS 1993	IGNITION
E20ELCOS 1985	CARBURETOR
E20ELEOR 1995	IGNITION
E20ELERC 1994	IGNITION
E20ELETS 1993	IGNITION
E225CLCUB 1987	MIDSECTION
E225CXCUB 1987	MIDSECTION
E225PLCUB 1987	MIDSECTION
E225PTLCDA 1986	MIDSECTION
E225PTXCD A 1986	MIDSECTION
E225PXCUB 1987	MIDSECTION

E225TLCDA 1986	MIDSECTION
E225TLCUB 1987	MIDSECTION
E225TXCDA 1986	MIDSECTION
E225TXCUB 1987	MIDSECTION
E235STLCOR 1985	CARBURETOR
E235STLCOR 1985	MIDSECTION
E235STLCRC 1984	CARBURETOR
E235STLCRC 1984	MIDSECTION
E235STLCTS 1983	MID-SECTION
E235TLCOR 1985	CARBURETOR
E235TLCOR 1985	MIDSECTION
E235TLCRC 1984	CARBURETOR
E235TLCRC 1984	MIDSECTION
E235TRLCIB 1981	EXHAUST HOUSING
E235TRLCIH 1981	EXHAUST HOUSING
E235TRLCNE 1982	EXHAUST HOUSING
E235TRLCSM 1980	EXHAUST HOUSING
E235TRLCSM 1980	IGNITION SYSTEM
E235TRLCTD 1983	EXHAUST HOUSING
E235TRLCTS 1983	EXHAUST HOUSING
E235TRXCIB 1981	EXHAUST HOUSING
E235TRXCIH 1981	EXHAUST HOUSING
E235TRXCNE 1982	EXHAUST HOUSING
E235TRXCSM 1980	EXHAUST HOUSING
E235TRXCSM 1980	IGNITION SYSTEM
E235TRXCTD 1983	EXHAUST HOUSING
E235TRXCTS 1983	EXHAUST HOUSING
E235TXCOR 1985	CARBURETOR
E235TXCOR 1985	MIDSECTION
E235TXCRC 1984	CARBURETOR
E235TXCRC 1984	MIDSECTION
E25ECOC 1985	CARBURETOR
E25ECRS 1984	CARBURETOR
E25EECE 1998	IGNITION
E25EEDM 1996	IGNITION

E25EEOA 1995	IGNITION
E25EERR 1994	IGNITION
E25EETC 1993	IGNITION
E25EEUB 1997	IGNITION
E25ELCOC 1985	CARBURETOR
E25ELCRS 1984	CARBURETOR
E25ELECE 1998	IGNITION
E25ELEDM 1996	IGNITION
E25ELEOA 1995	IGNITION
E25ELERR 1994	IGNITION
E25ELETC 1993	IGNITION
E25ELEUB 1997	IGNITION
E25JRECA 1998	IGNITION
E25JREDC 1996	IGNITION
E25JREOS 1995	IGNITION
E25RCOS 1985	CARBURETOR
E25RCRD 1984	CARBURETOR
E25RECB 1998	IGNITION
E25REDA 1996	IGNITION
E25REOR 1995	IGNITION
E25RERC 1994	IGNITION
E25RETS 1993	IGNITION
E25REUM 1997	IGNITION
E25RLCOS 1985	CARBURETOR
E25RLCRD 1984	CARBURETOR
E25RLECB 1998	IGNITION
E25RLEDA 1996	IGNITION
E25RLEOR 1995	IGNITION
E25RLERC 1994	IGNITION
E25RLETS 1993	IGNITION
E25RLEUM 1997	IGNITION
E25RWCOS 1985	CARBURETOR
E25RWEDC 1996	IGNITION - H25FP
E25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWENB 1992	IGNITION

E25RWEOS 1995	IGNITION - H25FP
E25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP
E25RWERD 1994	IGNITION - 25RW
E25RWETE 1993	IGNITION - 25RW
E25RWEUR 1997	IGNITION - H25FP
E25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25RWLCOS 1985	CARBURETOR
E25RWLEDC 1996	IGNITION - H25FP
E25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWLENB 1992	IGNITION
E25RWLEOS 1995	IGNITION - H25FP
E25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
E25RWLERD 1994	IGNITION - 25RW
E25RWLETE 1993	IGNITION - 25RW
E25RWLEUR 1997	IGNITION - H25FP
E25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25TECOS 1985	CARBURETOR
E25TECRD 1984	CARBURETOR
E25TEECB 1998	IGNITION
E25TEEDA 1996	IGNITION
E25TEEOR 1995	IGNITION
E25TEERC 1994	IGNITION
E25TEETS 1993	IGNITION
E25TEEUUM 1997	IGNITION
E25TEL COS 1985	CARBURETOR
E25TEL CRD 1984	CARBURETOR
E25TELECB 1998	IGNITION
E25TELEDA 1996	IGNITION
E25TELEOR 1995	IGNITION
E25TELETS 1993	IGNITION
E25TELEUM 1997	IGNITION
E25WREEN 1999	IGNITION
E25WREES 1999	IGNITION
E25WRLEEN 1999	IGNITION
E25WRLEES 1999	IGNITION

E25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
E25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
E275CLCUR 1987	MIDSECTION
E275CXCCA 1988	MIDSECTION
E275CXCUR 1987	MIDSECTION
E275PLCCA 1988	MIDSECTION
E275PLCUR 1987	MIDSECTION
E275PTLCDC 1986	MIDSECTION
E275PTXCDC 1986	MIDSECTION
E275PXCCA 1988	MIDSECTION
E275PXCUR 1987	MIDSECTION
E275TLCOS 1985	MIDSECTION
E275TXCOS 1985	MIDSECTION
E28ESLEDR 1996	IGNITION
E28ESLEOC 1995	IGNITION
E28ESLERS 1994	IGNITION
E28ESLETD 1993	IGNITION
E300CLCUR 1987	MIDSECTION
E300CXCCA 1988	MIDSECTION
E300CXCUR 1987	MIDSECTION
E300PLCCA 1988	MIDSECTION
E300PLCUR 1987	MIDSECTION
E300PXCCA 1988	MIDSECTION
E300PXCUR 1987	MIDSECTION
E300TLCDC 1986	MIDSECTION
E300TLCOS 1985	MIDSECTION
E300TXCDC 1986	MIDSECTION
E300TXCOS 1985	MIDSECTION
E30ECOA 1985	CARBURETOR
E30ECRR 1984	CARBURETOR
E30EECS 1998	IGNITION
E30EEDE 1996	IGNITION
E30EEOB 1995	IGNITION

E30EERM 1994	IGNITION
E30EETA 1993	IGNITION
E30EEUD 1997	IGNITION
E30ELCOA 1985	CARBURETOR
E30ELCRR 1984	CARBURETOR
E30ELECS 1998	IGNITION
E30ELEDE 1996	IGNITION
E30ELEOB 1995	IGNITION
E30ELERM 1994	IGNITION
E30ELETA 1993	IGNITION
E30ELEUD 1997	IGNITION
E30RCOA 1985	CARBURETOR
E30REDE 1996	IGNITION
E30REOB 1995	IGNITION
E30RERM 1994	IGNITION
E30RETA 1993	IGNITION
E30REUD 1997	IGNITION
E30RLCOA 1985	CARBURETOR
E30RLEDE 1996	IGNITION
E30RLEOB 1995	IGNITION
E30RLERM 1994	IGNITION
E30RLETA 1993	IGNITION
E30RLEUD 1997	IGNITION
E30TECOA 1985	CARBURETOR
E30TEECS 1998	IGNITION
E30TEEDE 1996	IGNITION
E30TEEOB 1995	IGNITION
E30TEERM 1994	IGNITION
E30TEETA 1993	IGNITION
E30TEEUD 1997	IGNITION
E30TELCOA 1985	CARBURETOR
E30TELECB 1998	IGNITION
E30TELEDE 1996	IGNITION
E30TELEOB 1995	IGNITION
E30TELERM 1994	IGNITION

E30TELETA 1993	IGNITION
E30TELEUD 1997	IGNITION
E35AELCDE 1986	CARBURETOR
E35ARLCDE 1986	CARBURETOR
E35ECRR 1984	CARBURETOR
E35ELCRR 1984	CARBURETOR
E35RCRR 1984	CARBURETOR
E35RERM 1994	IGNITION
E35RETA 1993	IGNITION
E35RLCRR 1984	CARBURETOR
E35RLERM 1994	IGNITION
E35RLETA 1993	IGNITION
E35TELCCR 1984	CARBURETOR
E40ECDE 1986	CARBURETOR
E40ECOB 1985	CARBURETOR
E40ECRM 1984	CARBURETOR
E40EEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40EERE 1994	IGNITION SYSTEM - 40 ROPE START
E40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40EETB 1993	IGNITION SYSTEM - 40 ROPE START
E40ELCDE 1986	CARBURETOR
E40ELCOB 1985	CARBURETOR
E40ELCRM 1984	CARBURETOR
E40ELECR 1998	IGNITION SYSTEM -- ROPE START
E40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40ELEUC 1997	IGNITION SYSTEM - ROPE START
E40JRECA 1998	IGNITION SYSTEM

E40JREDC 1996	IGNITION SYSTEM
E40JREOS 1995	IGNITION SYSTEM
E40JREUR 1997	IGNITION SYSTEM
E40RCDE 1986	CARBURETOR
E40RCOB 1985	CARBURETOR
E40RCRM 1984	CARBURETOR
E40RECR 1998	IGNITION SYSTEM -- ROPE START
E40REDS 1996	IGNITION SYSTEM - 40 ROPE START
E40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RETB 1993	IGNITION SYSTEM - 40 ROPE START
E40REUC 1997	IGNITION SYSTEM - ROPE START
E40RLCDE 1986	CARBURETOR
E40RLCOB 1985	CARBURETOR
E40RLCRM 1984	CARBURETOR
E40RLECR 1998	IGNITION SYSTEM -- ROPE START
E40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40RLEUC 1997	IGNITION SYSTEM - ROPE START
E40RWCDDB 1986	CARBURETOR & PRIMER SYSTEM
E40RWCOM 1985	CARBURETOR & PRIMER SYSTEM
E40RWCRD 1984	CARBURETOR & PRIMER SYSTEM
E40RWLCDB 1986	CARBURETOR & PRIMER SYSTEM
E40RWLCOM 1985	CARBURETOR & PRIMER SYSTEM
E40RWLCRA 1984	CARBURETOR & PRIMER SYSTEM
E40TECDE 1986	CARBURETOR
E40TECOB 1985	CARBURETOR

E40TECRM 1984	CARBURETOR
E40TEECR 1998	IGNITION SYSTEM -- ROPE START
E40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TEEUC 1997	IGNITION SYSTEM - ROPE START
E40TELCDE 1986	CARBURETOR
E40TELCOB 1985	CARBURETOR
E40TELCRM 1984	CARBURETOR
E40TELECR 1998	IGNITION SYSTEM -- ROPE START
E40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TELEUC 1997	IGNITION SYSTEM - ROPE START
E40TLCDE 1986	CARBURETOR
E40TLECR 1998	IGNITION SYSTEM -- ROPE START
E40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TLEUC 1997	IGNITION SYSTEM - ROPE START
E40TTLECR 1998	IGNITION SYSTEM -- ROPE START
E40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START

E40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLIEUC 1997	IGNITION SYSTEM - ROPE START
E40WREES 1999	IGNITION SYSTEM
E40WRLEES 1999	IGNITION SYSTEM
E40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRYEES 1999	IGNITION SYSTEM
E40WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E45RCCDS 1986	CARBURETOR - ALL 45 MODELS
E45RCCDS 1986	CARBURETOR - ALL 55 MODELS
E45RCENM 1992	IGNITION SYSTEM - ROPE START
E45RCEOD 1995	IGNITION SYSTEM
E45RCERE 1994	IGNITION SYSTEM
E45RCETB 1993	IGNITION SYSTEM
E45RCLCDS 1986	CARBURETOR - ALL 45 MODELS
E45RCLCDS 1986	CARBURETOR - ALL 55 MODELS
E45RCLEDS 1996	IGNITION SYSTEM
E45RCLENM 1992	IGNITION SYSTEM - ROPE START
E45RCLEOD 1995	IGNITION SYSTEM
E45RCLERE 1994	IGNITION SYSTEM
E45RCLETB 1993	IGNITION SYSTEM
E45RCLEUC 1997	IGNITION SYSTEM
E45WMLENM 1992	IGNITION SYSTEM - ROPE START
E48ESLEDC 1996	IGNITION SYSTEM
E48ESLEOS 1995	IGNITION SYSTEM
E48ESLERD 1994	IGNITION SYSTEM

E4RDHEOD 1995	MAGNETO
E4RDHERE 1994	MAGNETO
E4RDHLEOD 1995	MAGNETO
E4RDHLERE 1994	MAGNETO
E50BECDE 1986	CARBURETOR
E50BECOB 1985	CARBURETOR
E50BECRM 1984	CARBURETOR
E50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
E50BELCDE 1986	CARBURETOR
E50BELCOB 1985	CARBURETOR
E50BELCRM 1984	CARBURETOR
E50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50ESLECC 1998	IGNITION SYSTEM -- ROPE START
E50ESLEUR 1997	IGNITION SYSTEM - ROPE START
E50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50JERE 1994	IGNITION SYSTEM - 40 ROPE START
E50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JETB 1993	IGNITION SYSTEM - 40 ROPE START
E50JEUC 1997	IGNITION SYSTEM - ROPE START
E50TELCDE 1986	CARBURETOR
E50TELCOB 1985	CARBURETOR
E50TELCRM 1984	CARBURETOR

E50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TLCDE 1986	CARBURETOR
E50TLCOB 1985	CARBURETOR
E50TLCRM 1984	CARBURETOR
E50TLECR 1998	IGNITION SYSTEM -- ROPE START
E50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E50TLEUC 1997	IGNITION SYSTEM - ROPE START
E50TSLECC 1998	IGNITION SYSTEM -- ROPE START
E50TSLEUS 1997	IGNITION SYSTEM - ROPE START
E50TTLECA 1998	IGNITION SYSTEM
E50TTLEDC 1996	IGNITION SYSTEM
E50TTLEOS 1995	IGNITION SYSTEM
E50TTLEUR 1997	IGNITION SYSTEM
E55RSLC 1997	IGNITION SYSTEM
E55RSLG 1995	IGNITION SYSTEM
E55RSLN 1983	CARBURETOR
E55RSLN-2 1983	CARBURETOR
E55RSLW 1996	IGNITION SYSTEM
E55RSN 1983	CARBURETOR
E55RSN-2 1983	CARBURETOR
E55RSYN 1983	CARBURETOR
E55RSYN-2 1983	CARBURETOR
E55RWLCDC 1986	CARBURETOR - ALL 45 MODELS

E55RWLCDC 1986	CARBURETOR - ALL 55 MODELS
E55RWLCOS 1985	CARBURETOR - ALL 55 MODELS
E55RWLCRD 1984	CARBURETOR
E55RWLENM 1992	IGNITION SYSTEM - ROPE START
E55RWLERE 1994	IGNITION SYSTEM
E55RWLETB 1993	IGNITION SYSTEM
E55WREES 1999	IGNITION SYSTEM
E55WRLEES 1999	IGNITION SYSTEM
E55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
E55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E55WRYEES 1999	IGNITION SYSTEM
E55WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E5DRECR 1998	IGNITION
E5DRLECR 1998	IGNITION
E60ELCCR 1988	IGNITION SYSTEM
E60ELCDS 1986	MIDSECTION - 20" TRANSOM
E60ELCEA 1989	IGNITION SYSTEM 60TTL
E60ELCOD 1985	CARBURETOR
E60ELCRE 1984	CARBURETOR
E60ELCUC 1987	MIDSECTION - 20" TRANSOM
E60ELESM 1990	IGNITION SYSTEM 60TTL
E60TLCCR 1988	IGNITION SYSTEM
E60TLCDS 1986	MIDSECTION - 20" TRANSOM
E60TLCEA 1989	IGNITION SYSTEM 60TTL
E60TLCOD 1985	CARBURETOR
E60TLCRE 1984	CARBURETOR
E60TLCUC 1987	MIDSECTION - 20" TRANSOM
E60TLESM 1990	IGNITION SYSTEM 60TTL
E60TTLCCR 1988	IGNITION SYSTEM
E60TTLCEA 1989	IGNITION SYSTEM 60TTL
E60TTLECM 1998	IGNITION SYSTEM
E60TTLEDR 1996	IGNITION SYSTEM

E60TTLEIB 1991	IGNITION SYSTEM
E60TTLENE 1992	IGNITION SYSTEM
E60TTLEOC 1995	IGNITION SYSTEM
E60TTLERS 1994	IGNITION SYSTEM
E60TTLERV 1994	IGNITION SYSTEM
E60TTLES 1990	IGNITION SYSTEM 60TTL
E60TTLETD 1993	IGNITION SYSTEM
E60TTLEUA 1997	IGNITION SYSTEM
E65RSLC 1995	IGNITION SYSTEM
E65RSLM 1996	IGNITION SYSTEM
E65RSLZ2 1997	IGNITION SYSTEM
E65RWLCDR 1986	CARBURETOR
E65RWLCDR 1986	IGNITION SYSTEM
E65RWLCOC 1985	CARBURETOR
E65RWLCOC 1985	IGNITION SYSTEM
E65RWLCRS 1984	CARBURETOR
E65TELCDR 1986	CARBURETOR
E65TELCDR 1986	IGNITION SYSTEM
E65TELCOC 1985	CARBURETOR
E65TELCOC 1985	IGNITION SYSTEM
E65TELCRS 1984	CARBURETOR
E65WMLCDR 1986	CARBURETOR
E65WMLCOC 1985	CARBURETOR
E65WMLCUA 1987	IGNITION SYSTEM
E65WRLEEO 1999	IGNITION SYSTEM
E65WRLEES 1999	IGNITION SYSTEM
E65WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION SYSTEM
E65WRYEEO 1999	IGNITION SYSTEM
E65WRYEES 1999	IGNITION SYSTEM
E65WRYSIR commercial, rope start, 22.5 in shaft 2001	IGNITION SYSTEM
E65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	IGNITION SYSTEM
E65WTLCOC 1985	CARBURETOR
E65WTLCRS 1984	CARBURETOR
E6RECR 1998	IGNITION

E6REDS 1996	IGNITION
E6REOD 1995	IGNITION
E6RERE 1994	IGNITION
E6RETB 1993	IGNITION
E6REUC 1997	IGNITION
E6RLECR 1998	IGNITION
E6RLEDS 1996	IGNITION
E6RLEOD 1995	IGNITION
E6RLERE 1994	IGNITION
E6RLETB 1993	IGNITION
E6RLEUC 1997	IGNITION
E6SLEDS 1996	IGNITION
E6SLEOD 1995	IGNITION
E6SLERE 1994	IGNITION
E6SLETB 1993	IGNITION
E70ELCCA 1988	MIDSECTION
E70ELCDC 1986	CARBURETOR
E70ELCDC 1986	MIDSECTION
E70ELCIH 1981	EXHAUST HOUSING-20" TRANSOM
E70ELCIM 1981	EXHAUST HOUSING-20" TRANSOM
E70ELCNB 1982	EXHAUST HOUSING - 20" TRANSOM
E70ELCOS 1985	CARBURETOR
E70ELCOS 1985	MIDSECTION - 20" TRANSOM
E70ELCRD 1984	CARBURETOR
E70ELCRD 1984	MIDSECTION - 20" TRANSOM
E70ELCSA 1980	EXHAUST HOUSING-20" TRANSOM
E70ELCTE 1983	MID-SECTION-20" TRANSOM
E70ELCUR 1987	MIDSECTION
E70TLCCA 1988	MIDSECTION
E70TLCDC 1986	CARBURETOR
E70TLCDC 1986	MIDSECTION
E70TLCIM 1981	EXHAUST HOUSING-20" TRANSOM
E70TLCNB 1982	EXHAUST HOUSING - 20" TRANSOM
E70TLCOS 1985	CARBURETOR
E70TLCOS 1985	MIDSECTION - 20" TRANSOM

E70TLCRD 1984	CARBURETOR
E70TLCRD 1984	MIDSECTION - 20" TRANSOM
E70TLCTE 1983	MID-SECTION-20" TRANSOM
E70TLCUR 1987	MIDSECTION
E70TTLEIE 1991	IGNITION SYSTEM
E70TTLEND 1992	IGNITION SYSTEM
E70TTLEOR 1995	IGNITION SYSTEM
E70TTLERC 1994	IGNITION SYSTEM
E70TTLERV 1994	IGNITION SYSTEM
E70TTLETS 1993	IGNITION SYSTEM
E75ECDC 1986	MIDSECTION - 20" TRANSOM
E75ECOS 1985	CARBURETOR
E75ECOS 1985	MIDSECTION - 20" TRANSOM
E75ECRD 1984	CARBURETOR
E75ECDR 1984	MIDSECTION - 20" TRANSOM
E75ECUR 1987	MIDSECTION - 20" TRANSOM
E75ELCRD 1984	CARBURETOR
E75ELCRD 1984	MIDSECTION - 20" TRANSOM
E75ERCIH 1981	EXHAUST HOUSING-20" TRANSOM
E75ERCIH 1981	EXHAUST HOUSING-20" TRANSOM
E75ERCNB 1982	EXHAUST HOUSING - 20" TRANSOM
E75ERCSA 1980	EXHAUST HOUSING-20" TRANSOM
E75ERCTE 1983	MID-SECTION-20" TRANSOM
E75ERLCIH 1981	EXHAUST HOUSING-20" TRANSOM
E75ERLCIM 1981	EXHAUST HOUSING-20" TRANSOM
E75ERLCNB 1982	EXHAUST HOUSING - 20" TRANSOM
E75ERLCSA 1980	EXHAUST HOUSING-20" TRANSOM
E75ERLCTE 1983	MID-SECTION-20" TRANSOM
E75TLCRD 1984	CARBURETOR
E75TLCRD 1984	MIDSECTION - 20" TRANSOM
E75TRLCIH 1981	EXHAUST HOUSING-20" TRANSOM
E75TRLCIM 1981	EXHAUST HOUSING-20" TRANSOM
E75TRLCNB 1982	EXHAUST HOUSING - 20" TRANSOM
E75TRLCSA 1980	EXHAUST HOUSING-20" TRANSOM
E75TRLCTE 1983	MID-SECTION-20" TRANSOM

E85MLCSA 1980	EXHAUST HOUSING
E85MLCSA 1980	IGNITION SYSTEM
E85STLCSA 1980	EXHAUST HOUSING
E85STLCSA 1980	IGNITION SYSTEM
E85STXCSA 1980	EXHAUST HOUSING
E85STXCSA 1980	IGNITION SYSTEM
E8DREEA 1999	IGNITION
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
E8RECR 1998	IGNITION
E8REDS 1996	IGNITION
E8REOD 1995	IGNITION
E8RERE 1994	IGNITION
E8RETB 1993	IGNITION
E8REUC 1997	IGNITION
E8RLECR 1998	IGNITION
E8RLEDS 1996	IGNITION
E8RLEOD 1995	IGNITION
E8RLERE 1994	IGNITION
E8RLETB 1993	IGNITION
E8RLEUC 1997	IGNITION
E8SRLECA 1998	IGNITION
E8SRLEDS 1996	IGNITION
E8SRLEOD 1995	IGNITION
E8SRLERE 1994	IGNITION
E8SRLETB 1993	IGNITION
E8SRLEUC 1997	IGNITION
E8WREES 1999	IGNITION
E8WRLEES 1999	IGNITION
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
E90MLCDC 1986	CARBURETOR
E90MLCDC 1986	MIDSECTION
E90MLCIH 1981	EXHAUST HOUSING

E90MLCIH 1981	IGNITION SYSTEM
E90MLCIM 1981	EXHAUST HOUSING
E90MLCIM 1981	IGNITION SYSTEM
E90MLCNB 1982	EXHAUST HOUSING
E90MLCNB 1982	IGNITION SYSTEM
E90MLCOS 1985	CARBURETOR
E90MLCOS 1985	MIDSECTION
E90MLCRD 1984	CARBURETOR
E90MLCRD 1984	MIDSECTION
E90MLCTE 1983	EXHAUST HOUSING
E90MLCUR 1987	MIDSECTION
E90TLCDC 1986	CARBURETOR
E90TLCDC 1986	MIDSECTION
E90TLCIH 1981	EXHAUST HOUSING
E90TLCIH 1981	IGNITION SYSTEM
E90TLCIM 1981	EXHAUST HOUSING
E90TLCIM 1981	IGNITION SYSTEM
E90TLCNB 1982	EXHAUST HOUSING
E90TLCNB 1982	IGNITION SYSTEM
E90TLCOS 1985	CARBURETOR
E90TLCOS 1985	MIDSECTION
E90TLCRD 1984	CARBURETOR
E90TLCRD 1984	MIDSECTION
E90TLCTE 1983	EXHAUST HOUSING
E90TLCUR 1987	MIDSECTION
E90TXCDC 1986	CARBURETOR
E90TXCDC 1986	MIDSECTION
E90TXXIH 1981	EXHAUST HOUSING
E90TXXIH 1981	IGNITION SYSTEM
E90TXXIM 1981	EXHAUST HOUSING
E90TXXIM 1981	IGNITION SYSTEM
E90TXXNB 1982	EXHAUST HOUSING
E90TXXNB 1982	IGNITION SYSTEM
E90TXXCOS 1985	CARBURETOR
E90TXXCOS 1985	MIDSECTION

E90TXCRD 1984	CARBURETOR
E90TXCRD 1984	MIDSECTION
E90TXCTE 1983	EXHAUST HOUSING
HE15KCF 1997	IGNITION
HE15KCLF 1997	IGNITION
HE15KCLN 1996	IGNITION
HE15KCLO 1998	IGNITION
HE15KCN 1996	IGNITION
HE15KCO 1998	IGNITION
HE15RPLW 1997	IGNITION
HE15RPW 1997	IGNITION
HE20CREDA 1996	IGNITION
HE20CRLEDA 1996	IGNITION
HE25FPO 1996	IGNITION - H25FP
HE25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HE25FPV 1997	IGNITION - H25FP
HE25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HE25RAEDA 1996	IGNITION
HE25RAEUM 1997	IGNITION
HE25REDA 1996	IGNITION
HE25RLEDA 1996	IGNITION
HE25RSLO 1996	IGNITION - H25FP
HE25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HE25RSLV 1997	IGNITION - H25FP
HE25RSLV 1997	IGNITION - 25RS, 25RW, S25RP
HE25TELEDA 1996	IGNITION
HE30REDE 1996	IGNITION
HE30RLEDE 1996	IGNITION
HE40REDS 1996	IGNITION SYSTEM - 40 ROPE START
HE40REUC 1997	IGNITION SYSTEM - ROPE START
HE40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
HE40RLEUC 1997	IGNITION SYSTEM - ROPE START
HE45RCLEDS 1996	IGNITION SYSTEM
HE45RCLEUC 1997	IGNITION SYSTEM
HE55RSLC 1997	IGNITION SYSTEM

HE55RSLW 1996	IGNITION SYSTEM
HE55WMLM 1996	IGNITION SYSTEM
HE55WMLZ 1997	IGNITION SYSTEM
HJ15KCF 1997	IGNITION
HJ15KCLF 1997	IGNITION
HJ15KCLN 1996	IGNITION
HJ15KCLO 1998	IGNITION
HJ15KCN 1996	IGNITION
HJ15KCO 1998	IGNITION
HJ15RPLW 1997	IGNITION
HJ15RPW 1997	IGNITION
HJ20CREDA 1996	IGNITION
HJ20CRLEDA 1996	IGNITION
HJ25FPO 1996	IGNITION - H25FP
HJ25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25FPV 1997	IGNITION - H25FP
HJ25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RAEDA 1996	IGNITION
HJ25RAEUM 1997	IGNITION
HJ25RLEDA 1996	IGNITION
HJ25RLSV 1997	IGNITION - H25FP
HJ25RLSV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RSLO 1996	IGNITION - H25FP
HJ25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25TELEDA 1996	IGNITION
HJ30REDE 1996	IGNITION
HJ30RLEDE 1996	IGNITION
HJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START
HJ40REUC 1997	IGNITION SYSTEM - ROPE START
HJ40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
HJ40RLEUC 1997	IGNITION SYSTEM - ROPE START
HJ45RCLEDS 1996	IGNITION SYSTEM
HJ45RCLEUC 1997	IGNITION SYSTEM
HJ55RSLC 1997	IGNITION SYSTEM
HJ55RSLW 1996	IGNITION SYSTEM

HJ55WMLM 1996	IGNITION SYSTEM
HJ55WMLZ 1997	IGNITION SYSTEM
J100MLCSC 1980	EXHAUST HOUSING
J100MLCSC 1980	IGNITION SYSTEM
J100TRLCSC 1980	EXHAUST HOUSING
J100TRLCSC 1980	IGNITION SYSTEM
J100TRXCSC 1980	EXHAUST HOUSING
J100TRXCSC 1980	IGNITION SYSTEM
J100WMLCDR 1986	CARBURETOR
J100WMLCDR 1986	MIDSECTION
J100WMLCOC 1985	CARBURETOR
J100WMLCOC 1985	MIDSECTION
J100WMLCRS 1984	CARBURETOR, FUEL PUMP AND FILTER
J100WMLCRS 1984	MIDSECTION
J100WTLCDR 1986	CARBURETOR
J100WTLCDR 1986	MIDSECTION
J100WTLCOC 1985	CARBURETOR
J100WTLCOC 1985	MIDSECTION
J100WTLCRS 1984	CARBURETOR, FUEL PUMP AND FILTER
J100WTLCRS 1984	MIDSECTION
J100WTLCUA 1987	MIDSECTION
J100WTXCDR 1986	CARBURETOR
J100WTXCDR 1986	MIDSECTION
J100WTXCUA 1987	MIDSECTION
J10EECC 1998	IGNITION -- ROPE
J10EEDD 1996	IGNITION - ROPE
J10EEOE 1995	IGNITION - ROPE
J10EERB 1994	IGNITION - ROPE
J10EEUS 1997	IGNITION - ROPE
J10ELECC 1998	IGNITION -- ROPE
J10ELEDD 1996	IGNITION - ROPE
J10ELEER 1999	IGNITION -- ROPE
J10ELEOE 1995	IGNITION - ROPE
J10ELERB 1994	IGNITION - ROPE
J10ELEUS 1997	IGNITION - ROPE

J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION - ROPE
J10EVLSIC elec start, 20 in shaft, wht 2001	IGNITION - ROPE
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10RECC 1998	IGNITION -- ROPE
J10REDD 1996	IGNITION - ROPE
J10REER 1999	IGNITION -- ROPE
J10RELECC 1998	IGNITION -- ROPE
J10RELEDD 1996	IGNITION - ROPE
J10RELEOE 1995	IGNITION - ROPE
J10RELEROB 1994	IGNITION - ROPE
J10RELEUS 1997	IGNITION - ROPE
J10REOE 1995	IGNITION - ROPE
J10RERB 1994	IGNITION - ROPE
J10REUS 1997	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ROPE
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RLECC 1998	IGNITION -- ROPE
J10RLEDD 1996	IGNITION - ROPE
J10RLEER 1999	IGNITION -- ROPE
J10RLEOE 1995	IGNITION - ROPE
J10RLEROB 1994	IGNITION - ROPE
J10RLEUS 1997	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ROPE
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RLSDC	IGNITION
J10RLSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10RLSOS	IGNITION
J10RLSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSRD	IGNITION
J10RLSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10RLSTE	IGNITION
J10RLSTE - FR	22-5_SYSTÈME D'ALLUMAGE

J10RLSUR	IGNITION
J10RLSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RSDC	IGNITION
J10RSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10RSOS	IGNITION
J10RSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSRD	IGNITION
J10RSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10RSTE	IGNITION
J10RSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSUR	IGNITION
J10RSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J10SELECC 1998	IGNITION -- ROPE
J10SELEDD 1996	IGNITION - ROPE
J10SELEOE 1995	IGNITION - ROPE
J10SELERB 1994	IGNITION - ROPE
J10SELEUS 1997	IGNITION - ROPE
J10TEEER 1999	IGNITION -- ROPE
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TELEER 1999	IGNITION -- ROPE
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J110MLCDC 1986	CARBURETOR
J110MLCDC 1986	MIDSECTION
J110MLCUR 1987	MIDSECTION

J110TLCDC 1986	CARBURETOR
J110TLCDC 1986	MIDSECTION
J110TLCDF 1986	CARBURETOR
J110TLCDF 1986	MIDSECTION
J110TLCUR 1987	MIDSECTION
J110TXCUR 1987	MIDSECTION
J115MLCIH 1981	EXHAUST HOUSING
J115MLCIH 1981	IGNITION SYSTEM
J115MLCIM 1981	EXHAUST HOUSING
J115MLCIM 1981	IGNITION SYSTEM
J115MLCNB 1982	EXHAUST HOUSING
J115MLCNB 1982	IGNITION SYSTEM
J115MLCOS 1985	CARBURETOR
J115MLCOS 1985	MIDSECTION
J115MLCRD 1984	CARBURETOR
J115MLCRD 1984	MIDSECTION
J115MLCSA 1980	EXHAUST HOUSING
J115MLCSA 1980	IGNITION SYSTEM
J115MLCTE 1983	EXHAUST HOUSING
J115TLCIH 1981	EXHAUST HOUSING
J115TLCIH 1981	IGNITION SYSTEM
J115TLCIM 1981	EXHAUST HOUSING
J115TLCIM 1981	IGNITION SYSTEM
J115TLCNB 1982	EXHAUST HOUSING
J115TLCNB 1982	IGNITION SYSTEM
J115TLCOS 1985	CARBURETOR
J115TLCOS 1985	MIDSECTION
J115TLCRD 1984	CARBURETOR
J115TLCRD 1984	MIDSECTION
J115TLCSA 1980	EXHAUST HOUSING
J115TLCSA 1980	IGNITION SYSTEM
J115TLCTE 1983	EXHAUST HOUSING
J115TXXIH 1981	EXHAUST HOUSING
J115TXXIH 1981	IGNITION SYSTEM
J115TXXIM 1981	EXHAUST HOUSING

J115TXCIM 1981	IGNITION SYSTEM
J115TXCNB 1982	EXHAUST HOUSING
J115TXCNB 1982	IGNITION SYSTEM
J115TXC RD 1984	CARBURETOR
J115TXC RD 1984	MIDSECTION
J115TXCSA 1980	EXHAUST HOUSING
J115TXCSA 1980	IGNITION SYSTEM
J115TXCTE 1983	EXHAUST HOUSING
J120TLCDC 1986	MIDSECTION
J120TLCOS 1985	MIDSECTION
J120TLCUR 1987	MIDSECTION
J120TXC DC 1986	MIDSECTION
J120T XCOS 1985	MIDSECTION
J120T XCUR 1987	MIDSECTION
J140MLCIH 1981	EXHAUST HOUSING
J140MLCIH 1981	IGNITION SYSTEM
J140MLCIM 1981	EXHAUST HOUSING
J140MLCIM 1981	IGNITION SYSTEM
J140MLCNB 1982	EXHAUST HOUSING
J140MLCNB 1982	IGNITION SYSTEM
J140MLCSA 1980	EXHAUST HOUSING
J140MLCSA 1980	IGNITION SYSTEM
J140MLCTE 1983	EXHAUST HOUSING
J140TLCDC 1986	MIDSECTION
J140TLCIH 1981	EXHAUST HOUSING
J140TLCIH 1981	IGNITION SYSTEM
J140TLCIM 1981	EXHAUST HOUSING
J140TLCIM 1981	IGNITION SYSTEM
J140TLCNB 1982	EXHAUST HOUSING
J140TLCNB 1982	IGNITION SYSTEM
J140TLCOS 1985	MIDSECTION
J140TLC RD 1984	CARBURETOR
J140TLC RD 1984	MIDSECTION
J140TL CSA 1980	EXHAUST HOUSING
J140TL CSA 1980	IGNITION SYSTEM

J140TLCTE 1983	EXHAUST HOUSING
J140TLCUA 1987	MIDSECTION
J140TXCDC 1986	MIDSECTION
J140TXXIH 1981	EXHAUST HOUSING
J140TXXIH 1981	IGNITION SYSTEM
J140TXXIM 1981	EXHAUST HOUSING
J140TXXIM 1981	IGNITION SYSTEM
J140TXXNB 1982	EXHAUST HOUSING
J140TXXNB 1982	IGNITION SYSTEM
J140TXXCOS 1985	MIDSECTION
J140TXXCRD 1984	CARBURETOR
J140TXXRD 1984	MIDSECTION
J140TXXCSA 1980	EXHAUST HOUSING
J140TXXSA 1980	IGNITION SYSTEM
J140TXXCTE 1983	EXHAUST HOUSING
J140TXXCUA 1987	MIDSECTION
J150GTLCUR 1987	MIDSECTION
J150STLCDC 1986	CARBURETOR
J150STLCDC 1986	MIDSECTION
J150STLCOH 1985	CARBURETOR
J150STLCOH 1985	MIDSECTION
J150STLCOS 1985	CARBURETOR
J150STLCOS 1985	MIDSECTION
J150STLCRD 1984	CARBURETOR
J150STLCRD 1984	MIDSECTION
J150STLCTE 1983	MID-SECTION
J150STLCUR 1987	MIDSECTION
J150TLCDC 1986	CARBURETOR
J150TLCDC 1986	MIDSECTION
J150TLCIA 1981	EXHAUST HOUSING
J150TLCIH 1981	EXHAUST HOUSING
J150TLCNM 1982	EXHAUST HOUSING
J150TLCOS 1985	CARBURETOR
J150TLCOS 1985	MIDSECTION
J150TLCRD 1984	CARBURETOR

J150TLCRD 1984	MIDSECTION
J150TLCSF 1980	EXHAUST HOUSING
J150TLCSF 1980	IGNITION SYSTEM
J150TLCsr 1980	EXHAUST HOUSING
J150TLCsr 1980	IGNITION SYSTEM
J150TLCTB 1983	EXHAUST HOUSING
J150TLCTE 1983	EXHAUST HOUSING
J150TLCUR 1987	MIDSECTION
J150TXCDC 1986	CARBURETOR
J150TXCDC 1986	MIDSECTION
J150TXCIA 1981	EXHAUST HOUSING
J150TXCIH 1981	EXHAUST HOUSING
J150TXCNM 1982	EXHAUST HOUSING
J150TXCOS 1985	CARBURETOR
J150TXCOS 1985	MIDSECTION
J150TXCRD 1984	CARBURETOR
J150TXCRD 1984	MIDSECTION
J150TXCSF 1980	EXHAUST HOUSING
J150TXCSF 1980	IGNITION SYSTEM
J150TXCSR 1980	EXHAUST HOUSING
J150TXCSR 1980	IGNITION SYSTEM
J150TXCTB 1983	EXHAUST HOUSING
J150TXCTE 1983	EXHAUST HOUSING
J150TLCUR 1987	MIDSECTION
J155WTLCDR 1986	CARBURETOR
J155WTLCDR 1986	MIDSECTION
J155WTLcoc 1985	CARBURETOR
J155WTLcoc 1985	MIDSECTION
J155WTLcrs 1984	CARBURETOR
J155WTLcrs 1984	MIDSECTION
J155WTLcuA 1987	MIDSECTION
J155WTXCDR 1986	CARBURETOR
J155WTXCDR 1986	MIDSECTION
J155WTXCOC 1985	CARBURETOR
J155WTXCOC 1985	MIDSECTION

J155WTXCRS 1984	CARBURETOR
J155WTXCRS 1984	MIDSECTION
J155WTXCUA 1987	MIDSECTION
J15EECR 1998	IGNITION -- ROPE
J15EEDS 1996	IGNITION - ROPE
J15EEOD 1995	IGNITION - ROPE
J15EEERE 1994	IGNITION - ROPE
J15EEUC 1997	IGNITION - ROPE
J15ELECR 1998	IGNITION -- ROPE
J15ELEDS 1996	IGNITION - ROPE
J15ELEEA 1999	IGNITION -- ROPE
J15ELEOD 1995	IGNITION - ROPE
J15ELERE 1994	IGNITION - ROPE
J15ELEUC 1997	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION - ROPE
J15EVLSIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ROPE
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15RECR 1998	IGNITION -- ROPE
J15REDS 1996	IGNITION - ROPE
J15REEA 1999	IGNITION -- ROPE
J15RELECR 1998	IGNITION -- ROPE
J15RELEDS 1996	IGNITION - ROPE
J15RELEOD 1995	IGNITION - ROPE
J15RELERE 1994	IGNITION - ROPE
J15RELEUC 1997	IGNITION - ROPE
J15REOD 1995	IGNITION - ROPE
J15RERE 1994	IGNITION - ROPE
J15REUC 1997	IGNITION - ROPE
J15RLECR 1998	IGNITION -- ROPE
J15RLEDS 1996	IGNITION - ROPE
J15RLEEA 1999	IGNITION -- ROPE
J15RLEOD 1995	IGNITION - ROPE
J15RLERE 1994	IGNITION - ROPE
J15RLEUC 1997	IGNITION - ROPE

J15RLSDR	IGNITION
J15RLSDR - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15RLSOC	IGNITION
J15RLSOC - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSRS	IGNITION
J15RLSRS - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15RLSTD	IGNITION
J15RLSTD - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSUA	IGNITION
J15RLSUA - FR	02-5_SYSTEME D'ALLUMAGE
J15RSDR	IGNITION
J15RSDR - FR	22-5_SYSTEME D'ALLUMAGE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15RSOC	IGNITION
J15RSOC - FR	22-5_SYSTEME D'ALLUMAGE
J15RSRS	IGNITION
J15RSRS - FR	22-5_SYSTEME D'ALLUMAGE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15RSTD	IGNITION
J15RSTD - FR	22-5_SYSTEME D'ALLUMAGE
J15RSUA	IGNITION
J15RSUA - FR	02-5_SYSTEME D'ALLUMAGE
J15RTSDC	IGNITION
J15RTSDC - FR	22-5_SYSTEME D'ALLUMAGE
J15RTSOS	IGNITION
J15RTSOS - FR	22-5_SYSTEME D'ALLUMAGE
J15RTSUR	IGNITION
J15RTSUR - FR	02-5_SYSTEME D'ALLUMAGE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J15TEEEA 1999	IGNITION -- ROPE

J15TELEEA 1999	IGNITION -- ROPE
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15WREES 1999	IGNITION
J15WRLEES 1999	IGNITION
J15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J15WRLSOB	IGNITION
J15WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSRM	IGNITION
J15WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
J15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J15WRSOB	IGNITION
J15WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSRM	IGNITION
J15WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
J175TLCDR 1986	CARBURETOR
J175TLCDR 1986	MIDSECTION
J175TLCIH 1981	EXHAUST HOUSING
J175TLCIM 1981	EXHAUST HOUSING
J175TLCNB 1982	EXHAUST HOUSING
J175TLCOC 1985	CARBURETOR
J175TLCOC 1985	MIDSECTION
J175TLCSA 1980	EXHAUST HOUSING
J175TLCSA 1980	IGNITION SYSTEM
J175TLCSF 1980	EXHAUST HOUSING
J175TLCSF 1980	IGNITION SYSTEM
J175TLCTD 1983	EXHAUST HOUSING
J175TLCTE 1983	EXHAUST HOUSING
J175TLCUA 1987	MIDSECTION
J175TXCDR 1986	CARBURETOR

J175TXCDR 1986	MIDSECTION
J175TXXIH 1981	EXHAUST HOUSING
J175TXXIM 1981	EXHAUST HOUSING
J175TXXCNB 1982	EXHAUST HOUSING
J175TXXCOC 1985	CARBURETOR
J175TXXCOC 1985	MIDSECTION
J175TXXCSA 1980	EXHAUST HOUSING
J175TXXCSA 1980	IGNITION SYSTEM
J175TXXCSF 1980	EXHAUST HOUSING
J175TXXCSF 1980	IGNITION SYSTEM
J175TXXCTD 1983	EXHAUST HOUSING
J175TXXCTE 1983	EXHAUST HOUSING
J175TXXCUA 1987	MIDSECTION
J185TLCOC 1985	CARBURETOR
J185TLCOC 1985	MIDSECTION
J185TLCRS 1984	CARBURETOR
J185TLCRS 1984	MIDSECTION
J185TXXCOC 1985	CARBURETOR
J185TXXCOC 1985	MIDSECTION
J185TXXCR 1984	CARBURETOR
J185TXXCR 1984	MIDSECTION
J200STLCDR 1986	MIDSECTION
J200STLCUA 1987	MIDSECTION
J200TLCIH 1981	EXHAUST HOUSING
J200TLCNE 1982	EXHAUST HOUSING
J200TLCNF 1980	EXHAUST HOUSING
J200TLCNF 1980	IGNITION SYSTEM
J200TLCNM 1980	EXHAUST HOUSING
J200TLCNM 1980	IGNITION SYSTEM
J200TLCTD 1983	EXHAUST HOUSING
J200TLCTS 1983	EXHAUST HOUSING
J200TXXCDS 1986	MIDSECTION
J200TXXCIB 1981	EXHAUST HOUSING
J200TXXIH 1981	EXHAUST HOUSING
J200TXXCNE 1982	EXHAUST HOUSING

J200TXCSF 1980	EXHAUST HOUSING
J200TXCSF 1980	IGNITION SYSTEM
J200TXCSM 1980	EXHAUST HOUSING
J200TXCSM 1980	IGNITION SYSTEM
J200TXCTD 1983	EXHAUST HOUSING
J200TXCTS 1983	EXHAUST HOUSING
J200TXCUC 1987	MIDSECTION
J20CRCOS 1985	CARBURETOR
J20CREDA 1996	IGNITION
J20CREOR 1995	IGNITION
J20CRERC 1994	IGNITION
J20CRETS 1993	IGNITION
J20CREUM 1997	IGNITION
J20CRLCOS 1985	CARBURETOR
J20CRLEDA 1996	IGNITION
J20CRLEOR 1995	IGNITION
J20CRLERC 1994	IGNITION
J20CRLETS 1993	IGNITION
J20CRLEUM 1997	IGNITION
J20ECOS 1985	CARBURETOR
J20EEOR 1995	IGNITION
J20EERC 1994	IGNITION
J20EETS 1993	IGNITION
J20ELCOS 1985	CARBURETOR
J20ELEOR 1995	IGNITION
J20ELERC 1994	IGNITION
J20ELETS 1993	IGNITION
J225CLCUB 1987	MIDSECTION
J225CXCUB 1987	MIDSECTION
J225PLCUB 1987	MIDSECTION
J225PTLCDA 1986	MIDSECTION
J225PTXCD A 1986	MIDSECTION
J225PXCUB 1987	MIDSECTION
J225TLCDA 1986	MIDSECTION
J225TLCUB 1987	MIDSECTION

J225TXCDA 1986	MIDSECTION
J225TXCUB 1987	MIDSECTION
J235STLCOR 1985	CARBURETOR
J235STLCOR 1985	MIDSECTION
J235STLCRC 1984	CARBURETOR
J235STLCRC 1984	MIDSECTION
J235STLCTS 1983	MID-SECTION
J235TLCIB 1981	EXHAUST HOUSING
J235TLCIH 1981	EXHAUST HOUSING
J235TLCNE 1982	EXHAUST HOUSING
J235TLCOR 1985	CARBURETOR
J235TLCOR 1985	MIDSECTION
J235TLCRC 1984	CARBURETOR
J235TLCRC 1984	MIDSECTION
J235TLCSTM 1980	EXHAUST HOUSING
J235TLCSTM 1980	IGNITION SYSTEM
J235TLCTD 1983	EXHAUST HOUSING
J235TLCTS 1983	EXHAUST HOUSING
J235TXCIB 1981	EXHAUST HOUSING
J235TXCIH 1981	EXHAUST HOUSING
J235TXCNE 1982	EXHAUST HOUSING
J235TXCOR 1985	CARBURETOR
J235TXCOR 1985	MIDSECTION
J235TXCRC 1984	CARBURETOR
J235TXCRC 1984	MIDSECTION
J235TXXSM 1980	EXHAUST HOUSING
J235TXXSM 1980	IGNITION SYSTEM
J235TXCTD 1983	EXHAUST HOUSING
J235TXCTS 1983	EXHAUST HOUSING
J25ECOC 1985	CARBURETOR
J25ECRS 1984	CARBURETOR
J25EECE 1998	IGNITION
J25EEDM 1996	IGNITION
J25EEED 1999	IGNITION
J25EEEN 1999	IGNITION

J25EEOA 1995	IGNITION
J25EERR 1994	IGNITION
J25EETC 1993	IGNITION
J25EEUB 1997	IGNITION
J25ELCOC 1985	CARBURETOR
J25ELCRS 1984	CARBURETOR
J25ELECE 1998	IGNITION
J25ELEDM 1996	IGNITION
J25ELEED 1999	IGNITION
J25ELEEN 1999	IGNITION
J25ELEOA 1995	IGNITION
J25ELERR 1994	IGNITION
J25ELET C 1993	IGNITION
J25ELEUB 1997	IGNITION
J25ELSIC elec start, remote, 20 in shaft 2001	IGNITION
J25ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002	IGNITION
J25ELSOB	IGNITION
J25ELSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSRM	IGNITION
J25ELSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSSS Elec. Start, 20 IN. shaft 2000	IGNITION
J25ELSTA	IGNITION
J25ELSTA - FR	22-5_SYSTÈME D'ALLUMAGE
J25ESIC elec start, remote, 15 in shaft 2001	IGNITION
J25ESSS Elec. Start, 15 IN. shaft 2000	IGNITION
J25EVLSIC elec start, remote, 120 in shaft, wht 2001	IGNITION
J25EVSIC elec start, remote, 15 in shaft, wht 2001	IGNITION
J25GTESOC	IGNITION
J25GTESOC - FR	22-5_SYSTÈME D'ALLUMAGE
J25GTESRS	IGNITION
J25GTESRS - FR	22-5_SYSTÈME D'ALLUMAGE
J25JRECA 1998	IGNITION
J25JREDC 1996	IGNITION

J25JREEM 1999	IGNITION
J25JREEN 1999	IGNITION
J25JREOS 1995	IGNITION
J25JREUR 1997	IGNITION
J25JRSIE jet drive, rope start, tiller, 15 in shaft 2001	IGNITION
J25JRSSB Jet Drive,Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J25RCOS 1985	CARBURETOR
J25RCRD 1984	CARBURETOR
J25RECB 1998	IGNITION
J25REDA 1996	IGNITION
J25REEB 1999	IGNITION
J25REEN 1999	IGNITION
J25REOR 1995	IGNITION
J25RERC 1994	IGNITION
J25RETS 1993	IGNITION
J25REUM 1997	IGNITION
J25RLCOS 1985	CARBURETOR
J25RLCRD 1984	CARBURETOR
J25RLECB 1998	IGNITION
J25RLEDA 1996	IGNITION
J25RLEEB 1999	IGNITION
J25RLEEN 1999	IGNITION
J25RLEOR 1995	IGNITION
J25RLERC 1994	IGNITION
J25RLETS 1993	IGNITION
J25RLEUM 1997	IGNITION
J25RLSID rope start, tiller, 20 in shaft 2001	IGNITION
J25RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J25RLSOA	IGNITION
J25RLSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSRR	IGNITION
J25RLSRR - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSSE Rope Start, Tiller, 20 IN. shaft 2000	IGNITION

J25RLSTC	IGNITION
J25RLSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSID rope start, tiller, 15 in shaft 2001	IGNITION
J25RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSNF Rope start, White, Tiller, 15 in. shaft, A/C Light 2002	IGNITION
J25RSOA	IGNITION
J25RSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSRR	IGNITION
J25RSRR - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSSE Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J25RSTC	IGNITION
J25RSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RTSOS	IGNITION
J25RTSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J25RVLSID rope start, tiller, 20 in shaft, wht 2001	IGNITION
J25RVSID rope start, tiller, 15 in shaft, wht 2001	IGNITION
J25RWCO 1985	CARBURETOR
J25RWEDC 1996	IGNITION - H25FP
J25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWENB 1992	IGNITION
J25RWEOS 1995	IGNITION - H25FP
J25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWERD 1994	IGNITION - 25RW
J25RWETE 1993	IGNITION - 25RW
J25RWEUR 1997	IGNITION - H25FP
J25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25RWLCO 1985	CARBURETOR
J25RWLEDC 1996	IGNITION - H25FP
J25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWLENB 1992	IGNITION
J25RWLEOS 1995	IGNITION - H25FP
J25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWLERD 1994	IGNITION - 25RW
J25RWLETE 1993	IGNITION - 25RW
J25RWLEUR 1997	IGNITION - H25FP

J25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25TECOS 1985	CARBURETOR
J25TECRD 1984	CARBURETOR
J25TEECB 1998	IGNITION
J25TEEDA 1996	IGNITION
J25TEEEE 1999	IGNITION
J25TEEEN 1999	IGNITION
J25TEEOR 1995	IGNITION
J25TEERC 1994	IGNITION
J25TEETS 1993	IGNITION
J25TEEUM 1997	IGNITION
J25TEL COS 1985	CARBURETOR
J25TEL CRD 1984	CARBURETOR
J25TELCB 1998	IGNITION
J25TELEDA 1996	IGNITION
J25TELEEE 1999	IGNITION
J25TELEEN 1999	IGNITION
J25TELEOR 1995	IGNITION
J25TELERC	IGNITION
J25TELETS 1993	IGNITION
J25TELEM 1997	IGNITION
J25TELSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSNF Electric strart, White, Tiller, 20 in., 4 Amp Alt 2002	IGNITION
J25TELSOM	IGNITION
J25TELSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSRA	IGNITION
J25TELSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSSD Elec. Start, Tiller, 20 IN. shaft 2000	IGNITION
J25TELSTR	IGNITION
J25TELSTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESIS elec start, tiller, 15 in shaft 2001	IGNITION
J25TESNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESNF Electric strart, White, Tiller,15 in. shaft, 4 Amp Alt 2002	IGNITION

J25TESOM	IGNITION
J25TESOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESRA	IGNITION
J25TESRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESSD Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION
J25TESTR	IGNITION
J25TESTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TVLSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TVSIS elec start, tiller, 15 in shaft 2001	IGNITION
J25WREEN 1999	IGNITION
J25WREES 1999	IGNITION
J25WRLEEN 1999	IGNITION
J25WRLEES 1999	IGNITION
J25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J25WRLSOB	IGNITION
J25WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSRM	IGNITION
J25WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
J25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J25WRSOB	IGNITION
J25WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSRM	IGNITION
J25WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
J275CLCUR 1987	MIDSECTION
J275CXCCA 1988	MIDSECTION
J275CXCUR 1987	MIDSECTION
J275PLCCA 1988	MIDSECTION
J275PLCUR 1987	MIDSECTION
J275PTLCDC 1986	MIDSECTION
J275PTXCDC 1986	MIDSECTION
J275PXCCA 1988	MIDSECTION
J275PXCUR 1987	MIDSECTION
J275TLCOS 1985	MIDSECTION

J275TXCOS 1985	MIDSECTION
J28ESLEDR 1996	IGNITION
J28ESLEOC 1995	IGNITION
J28ESLERS 1994	IGNITION
J28ESLETD 1993	IGNITION
J300CLCUR 1987	MIDSECTION
J300CXCCA 1988	MIDSECTION
J300CXCUR 1987	MIDSECTION
J300PLCCA 1988	MIDSECTION
J300PLCUR 1987	MIDSECTION
J300PXCCA 1988	MIDSECTION
J300PXCUR 1987	MIDSECTION
J300TLCDC 1986	MIDSECTION
J300TLCOS 1985	MIDSECTION
J300TXCDC 1986	MIDSECTION
J300TXCOS 1985	MIDSECTION
J30ECOA 1985	CARBURETOR
J30ECRR 1984	CARBURETOR
J30EECS 1998	IGNITION
J30EEDE 1996	IGNITION
J30EEEC 1999	IGNITION
J30EEEN 1999	IGNITION
J30EEOB 1995	IGNITION
J30EERM 1994	IGNITION
J30EETA 1993	IGNITION
J30EEUD 1997	IGNITION
J30ELCOA 1985	CARBURETOR
J30ELCRR 1984	CARBURETOR
J30ELECS 1998	IGNITION
J30ELEDE 1996	IGNITION
J30ELEEC 1999	IGNITION
J30ELEEN 1999	IGNITION
J30ELEOB 1995	IGNITION
J30ELERM 1994	IGNITION
J30ELETA 1993	IGNITION

J30ELEUD 1997	IGNITION
J30ELSLIA elec start, remote, 20 in shaft 2001	IGNITION
J30ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002	IGNITION
J30ELSOD	IGNITION
J30ELSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSRE	IGNITION
J30ELSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSSR Elec. Start, 20 IN. shaft 2000	IGNITION
J30ELSTB	IGNITION
J30ELSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30ESIA elec start, remote, 15 in shaft 2001	IGNITION
J30ESSR Elec. Start, 15 IN. shaft 2000	IGNITION
J30EVLSIA elec start, remote, 20 in shaft, wht 2001	IGNITION
J30JREEM 1999	IGNITION SYSTEM
J30JRSIE jet drive, rope start, 15 in shaft 2001	IGNITION SYSTEM
J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J30MLSRC	IGNITION
J30MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J30MLSTS	IGNITION
J30MLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J30RCOA 1985	CARBURETOR
J30REDE 1996	IGNITION
J30REEC 1999	IGNITION
J30REEN 1999	IGNITION
J30REOB 1995	IGNITION
J30RERM 1994	IGNITION
J30RETA 1993	IGNITION
J30REUD 1997	IGNITION
J30RLCOA 1985	CARBURETOR
J30RLEDE 1996	IGNITION
J30RLEEC 1999	IGNITION
J30RLEEN 1999	IGNITION
J30RLEOB 1995	IGNITION

J30RLERM 1994	IGNITION
J30RLETA 1993	IGNITION
J30RLEUD 1997	IGNITION
J30RLSIA rope start, tiller, 20 in shaft 2001	IGNITION
J30RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J30RLSOD	IGNITION
J30RLSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSRE	IGNITION
J30RLSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSSR Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J30RLSTB	IGNITION
J30RLSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSIA rope start, tiller, 15 in shaft 2001	IGNITION
J30RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSNF Rope start, White, Tiller,15 in. shaft, A/C Light 2002	IGNITION
J30RSOD	IGNITION
J30RSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSRE	IGNITION
J30RSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSSR Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J30RSTB	IGNITION
J30RSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30RVLSIA rope start, tiller, 20 in shaft, wht 2001	IGNITION
J30RVSIA rope start, tiller, 15 in shaft, wht 2001	IGNITION
J30TECOA 1985	CARBURETOR
J30TEECS 1998	IGNITION
J30TEEDE 1996	IGNITION
J30TEEOB 1995	IGNITION
J30TEERM 1994	IGNITION
J30TEETA 1993	IGNITION
J30TEEUD 1997	IGNITION
J30TELCOA 1985	CARBURETOR
J30TELECS 1998	IGNITION
J30TELEDE 1996	IGNITION

J30TELEOB 1995	IGNITION
J30TELERM 1994	IGNITION
J30TELETA 1993	IGNITION
J30TELEUD 1997	IGNITION
J35AELCDE 1986	CARBURETOR
J35ARLCDE 1986	CARBURETOR
J35ECRR 1984	CARBURETOR
J35ELCRR 1984	CARBURETOR
J35RCRR 1984	CARBURETOR
J35RERM 1994	IGNITION
J35RETA 1993	IGNITION
J35RLCRR 1984	CARBURETOR
J35RLERM 1994	IGNITION
J35RLETA 1993	IGNITION
J35TELCCR 1984	CARBURETOR
J40ECDE 1986	CARBURETOR
J40ECOB 1985	CARBURETOR
J40ECRM 1984	CARBURETOR
J40EEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40EERE 1994	IGNITION SYSTEM - 40 ROPE START
J40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40EETB 1993	IGNITION SYSTEM - 40 ROPE START
J40ELCDE 1986	CARBURETOR
J40ELCOB 1985	CARBURETOR
J40ELCRM 1984	CARBURETOR
J40ELECR 1998	IGNITION SYSTEM -- ROPE START
J40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELETB 1993	IGNITION SYSTEM - 40 ROPE START

J40ELEUC 1997	IGNITION SYSTEM - ROPE START
J40JRECA 1998	IGNITION SYSTEM
J40JREDC 1996	IGNITION SYSTEM
J40JREOS 1995	IGNITION SYSTEM
J40JREUR 1997	IGNITION SYSTEM
J40PLEEA 1999	IGNITION SYSTEM -- ROPE START
J40PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RCDE 1986	CARBURETOR
J40RCOB 1985	CARBURETOR
J40RCRM 1984	CARBURETOR
J40RECR 1998	IGNITION SYSTEM -- ROPE START
J40REDS 1996	IGNITION SYSTEM - 40 ROPE START
J40REEA 1999	IGNITION SYSTEM -- ROPE START
J40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RETB 1993	IGNITION SYSTEM - 40 ROPE START
J40REUC 1997	IGNITION SYSTEM - ROPE START
J40RLCDE 1986	CARBURETOR
J40RLCOB 1985	CARBURETOR
J40RLCRM 1984	CARBURETOR
J40RLECR 1998	IGNITION SYSTEM -- ROPE START
J40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40RLEEA 1999	IGNITION SYSTEM -- ROPE START
J40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40RLEUC 1997	IGNITION SYSTEM - ROPE START
J40RLSIF rope start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START

J40RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RLSOC	IGNITION SYSTEM
J40RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSRS	IGNITION SYSTEM
J40RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RLSTD	IGNITION SYSTEM
J40RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSIF rope start, 15 in shaft 2001	IGNITION SYSTEM - ROPE START
J40RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RSOC	IGNITION SYSTEM
J40RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSRS	IGNITION SYSTEM
J40RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RSTD	IGNITION SYSTEM
J40RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40RWCD 1986	CARBURETOR & PRIMER SYSTEM
J40RWCOM 1985	CARBURETOR & PRIMER SYSTEM
J40RWCR 1984	CARBURETOR & PRIMER SYSTEM
J40RWLCDB 1986	CARBURETOR & PRIMER SYSTEM
J40RWLCOM 1985	CARBURETOR & PRIMER SYSTEM
J40RWLCRA 1984	CARBURETOR & PRIMER SYSTEM
J40TECDE 1986	CARBURETOR
J40TECOB 1985	CARBURETOR
J40TECRM 1984	CARBURETOR
J40TEECR 1998	IGNITION SYSTEM -- ROPE START
J40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TEEUC 1997	IGNITION SYSTEM - ROPE START
J40TELCD 1986	CARBURETOR
J40TELCOB 1985	CARBURETOR
J40TELCRM 1984	CARBURETOR
J40TELECR 1998	IGNITION SYSTEM -- ROPE START
J40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TELEUC 1997	IGNITION SYSTEM - ROPE START
J40TLCDE 1986	CARBURETOR
J40TLECR 1998	IGNITION SYSTEM -- ROPE START
J40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TLEUC 1997	IGNITION SYSTEM - ROPE START
J40TPLEA 1999	IGNITION SYSTEM -- ROPE START
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40TTLECR 1998	IGNITION SYSTEM -- ROPE START
J40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40TTLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TTLEUC 1997	IGNITION SYSTEM - ROPE START
J40WREES 1999	IGNITION SYSTEM
J40WRLEES 1999	IGNITION SYSTEM
J40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J40WRYEES 1999	IGNITION SYSTEM
J40WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J45RCCDS 1986	CARBURETOR - ALL 45 MODELS
J45RCCDS 1986	CARBURETOR - ALL 55 MODELS
J45RCENM 1992	IGNITION SYSTEM - ROPE START
J45RCEOD 1995	IGNITION SYSTEM
J45RCERE 1994	IGNITION SYSTEM
J45RCETB 1993	IGNITION SYSTEM
J45RCLCDS 1986	CARBURETOR - ALL 45 MODELS
J45RCLCDS 1986	CARBURETOR - ALL 55 MODELS
J45RCLEDS 1996	IGNITION SYSTEM
J45RCLENM 1992	IGNITION SYSTEM - ROPE START
J45RCLEOD 1995	IGNITION SYSTEM
J45RCLERE 1994	IGNITION SYSTEM
J45RCLETB 1993	IGNITION SYSTEM
J45RCLEUC 1997	IGNITION SYSTEM
J45WMLENM 1992	IGNITION SYSTEM - ROPE START
J48ESLEDC 1996	IGNITION SYSTEM
J48ESLEOS 1995	IGNITION SYSTEM
J48ESLERD 1994	IGNITION SYSTEM
J4RDHEOD 1995	MAGNETO
J4RDHERE 1994	MAGNETO
J4RDHLEOD 1995	MAGNETO
J4RDHLERE 1994	MAGNETO
J50BECDE 1986	CARBURETOR

J50BECOB 1985	CARBURETOR
J50BECRM 1984	CARBURETOR
J50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
J50BELCDE 1986	CARBURETOR
J50BELCOB 1985	CARBURETOR
J50BELCRM 1984	CARBURETOR
J50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
J50ELEER 1999	IGNITION SYSTEM -- ROPE START
J50ELSIF elec start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50ESLECC 1998	IGNITION SYSTEM -- ROPE START
J50ESLEUR 1997	IGNITION SYSTEM - ROPE START
J50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
J50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50JERE 1994	IGNITION SYSTEM - 40 ROPE START
J50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JETB 1993	IGNITION SYSTEM - 40 ROPE START
J50JEUC 1997	IGNITION SYSTEM - ROPE START
J50PLEEA 1999	IGNITION SYSTEM -- ROPE START
J50PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50TELCDE 1986	CARBURETOR
J50TELCOB 1985	CARBURETOR

J50TELCRM 1984	CARBURETOR
J50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TLCDE 1986	CARBURETOR
J50TLCOB 1985	CARBURETOR
J50TLCRM 1984	CARBURETOR
J50TLECR 1998	IGNITION SYSTEM -- ROPE START
J50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J50TLEUC 1997	IGNITION SYSTEM - ROPE START
J50TSLECC 1998	IGNITION SYSTEM -- ROPE START
J50TSLEUS 1997	IGNITION SYSTEM - ROPE START
J50TTLECA 1998	IGNITION SYSTEM
J50TTLEDC 1996	IGNITION SYSTEM
J50TTLEOS 1995	IGNITION SYSTEM
J50TTLEUR 1997	IGNITION SYSTEM
J55APRL	IGNITION & ELECTRICAL
J55APRL - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSOM	IGNITION & ELECTRICAL
J55APRLSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRA	IGNITION & ELECTRICAL
J55APRLSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRG	IGNITION & ELECTRICAL
J55APRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSOR	IGNITION & ELECTRICAL

J55MLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRC	IGNITION & ELECTRICAL
J55MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRG	IGNITION & ELECTRICAL
J55MLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55MRL	IGNITION & ELECTRICAL
J55MRL - FR	22-5_SYSTÈME D'ALLUMAGE
J55RSLC 1997	IGNITION SYSTEM
J55RSLG 1995	IGNITION SYSTEM
J55RSLN 1983	CARBURETOR
J55RSLN-2 1983	CARBURETOR
J55RSLW 1996	IGNITION SYSTEM
J55RSN 1983	CARBURETOR
J55RSN-2 1983	CARBURETOR
J55RSYN 1983	CARBURETOR
J55RSYN-2 1983	CARBURETOR
J55RWLCDC 1986	CARBURETOR - ALL 45 MODELS
J55RWLCDC 1986	CARBURETOR - ALL 55 MODELS
J55RWLCOS 1985	CARBURETOR - ALL 55 MODELS
J55RWLCRD 1984	CARBURETOR
J55RWLENM 1992	IGNITION SYSTEM - ROPE START
J55RWLERE 1994	IGNITION SYSTEM
J55RWLETB 1993	IGNITION SYSTEM
J55WRREES 1999	IGNITION SYSTEM
J55WRLEES 1999	IGNITION SYSTEM
J55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J55WRLSOE	IGNITION SYSTEM
J55WRLSOE - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRB	IGNITION SYSTEM
J55WRLSRB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRG	IGNITION SYSTEM
J55WRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J55WRLSTM	IGNITION SYSTEM
J55WRLSTM - FR	22-5_SYSTÈME D'ALLUMAGE

J55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J55WRYEES 1999	IGNITION SYSTEM
J55WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J55WRYSOB	IGNITION SYSTEM
J55WRYSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSRM	IGNITION SYSTEM
J55WRYSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J5DRECR 1998	IGNITION
J5DRLECR 1998	IGNITION
J60ELCCR 1988	IGNITION SYSTEM
J60ELCDS 1986	MIDSECTION - 20" TRANSOM
J60ELCEA 1989	IGNITION SYSTEM 60TTL
J60ELCOD 1985	CARBURETOR
J60ELCRE 1984	CARBURETOR
J60ELCUC 1987	MIDSECTION - 20" TRANSOM
J60ELESM 1990	IGNITION SYSTEM 60TTL
J60TLCCR 1988	IGNITION SYSTEM
J60TLCDS 1986	MIDSECTION - 20" TRANSOM
J60TLCEA 1989	IGNITION SYSTEM 60TTL
J60TLCOD 1985	CARBURETOR
J60TLCRE 1984	CARBURETOR
J60TLCUC 1987	MIDSECTION - 20" TRANSOM
J60TLESM 1990	IGNITION SYSTEM 60TTL
J60TLLCCR 1988	IGNITION SYSTEM
J60TTLCEA 1989	IGNITION SYSTEM 60TTL
J60TTLECM 1998	IGNITION SYSTEM
J60TTLEDR 1996	IGNITION SYSTEM
J60TTLEIB 1991	IGNITION SYSTEM
J60TTLENE 1992	IGNITION SYSTEM
J60TTLEOC 1995	IGNITION SYSTEM
J60TTLERS 1994	IGNITION SYSTEM
J60TTLERV 1994	IGNITION SYSTEM
J60TTLESM 1990	IGNITION SYSTEM 60TTL

J60TTLETD 1993	IGNITION SYSTEM
J60TTLEUA 1997	IGNITION SYSTEM
J65RSLC 1995	IGNITION SYSTEM
J65RSLM 1996	IGNITION SYSTEM
J65RSLZ2 1997	IGNITION SYSTEM
J65RWLCDR 1986	CARBURETOR
J65RWLCDR 1986	IGNITION SYSTEM
J65RWLCOC 1985	CARBURETOR
J65RWLCOC 1985	IGNITION SYSTEM
J65RWLCRS 1984	CARBURETOR
J65TELCDR 1986	CARBURETOR
J65TELCDR 1986	IGNITION SYSTEM
J65TELCOC 1985	CARBURETOR
J65TELCOC 1985	IGNITION SYSTEM
J65TELCRS 1984	CARBURETOR
J65WMLCDR 1986	CARBURETOR
J65WMLCOC 1985	CARBURETOR
J65WMLCUA 1987	IGNITION SYSTEM
J65WRLEO 1999	IGNITION SYSTEM
J65WRLEES 1999	IGNITION SYSTEM
J65WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION SYSTEM
J65WRYEEO 1999	IGNITION SYSTEM
J65WRYEES 1999	IGNITION SYSTEM
J65WRYSIR commercial, rope start, 22.5 in shaft 2001	IGNITION SYSTEM
J65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	IGNITION SYSTEM
J65WTLCOC 1985	CARBURETOR
J65WTLCRS 1984	CARBURETOR
J6RECR 1998	IGNITION
J6REDS 1996	IGNITION
J6REEA 1999	IGNITION
J6REOD 1995	IGNITION
J6RERE 1994	IGNITION
J6RETB 1993	IGNITION
J6REUC 1997	IGNITION

J6RLECR 1998	IGNITION
J6RLEDS 1996	IGNITION
J6RLEEA 1999	IGNITION
J6RLEOD 1995	IGNITION
J6RLERE 1994	IGNITION
J6RLETB 1993	IGNITION
J6RLEUC 1997	IGNITION
J6RLSIB rope start, tiller, 20 in shaft 2001	IGNITION
J6RLSOC	IGNITION
J6RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLSRS	IGNITION
J6RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J6RLSTD	IGNITION
J6RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	IGNITION
J6RSIB rope start, tiller, 15 in shaft 2001	IGNITION
J6RSOC	IGNITION
J6RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSRS	IGNITION
J6RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J6RSTD	IGNITION
J6RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	IGNITION
J6SLEDS 1996	IGNITION
J6SLEOD 1995	IGNITION
J6SLERE 1994	IGNITION
J6SLETB 1993	IGNITION
J70ELCCA 1988	MIDSECTION
J70ELCDC 1986	CARBURETOR
J70ELCDC 1986	MIDSECTION
J70ELCIH 1981	EXHAUST HOUSING-20" TRANSOM
J70ELCIM 1981	EXHAUST HOUSING-20" TRANSOM
J70ELCNB 1982	EXHAUST HOUSING - 20" TRANSOM

J70ELCOS 1985	CARBURETOR
J70ELCOS 1985	MIDSECTION - 20" TRANSOM
J70ELCRD 1984	CARBURETOR
J70ELCRD 1984	MIDSECTION - 20" TRANSOM
J70ELCSA 1980	EXHAUST HOUSING-20" TRANSOM
J70ELCTE 1983	MID-SECTION-20" TRANSOM
J70ELCUR 1987	MIDSECTION
J70TLCCA 1988	MIDSECTION
J70TLCDC 1986	CARBURETOR
J70TLCDC 1986	MIDSECTION
J70TLCIM 1981	EXHAUST HOUSING-20" TRANSOM
J70TLCNB 1982	EXHAUST HOUSING - 20" TRANSOM
J70TLCOS 1985	CARBURETOR
J70TLCOS 1985	MIDSECTION - 20" TRANSOM
J70TLCRD 1984	CARBURETOR
J70TLCRD 1984	MIDSECTION - 20" TRANSOM
J70TLCTE 1983	MID-SECTION-20" TRANSOM
J70TLCUR 1987	MIDSECTION
J70TTLIE 1991	IGNITION SYSTEM
J70TTLEND 1992	IGNITION SYSTEM
J70TTLER 1995	IGNITION SYSTEM
J70TTLERC 1994	IGNITION SYSTEM
J70TTLERV 1994	IGNITION SYSTEM
J70TTLETS 1993	IGNITION SYSTEM
J75ECDC 1986	MIDSECTION - 20" TRANSOM
J75ECNB 1982	EXHAUST HOUSING - 20" TRANSOM
J75ECOS 1985	CARBURETOR
J75ECOS 1985	MIDSECTION - 20" TRANSOM
J75ECRD 1984	CARBURETOR
J75ECRD 1984	MIDSECTION - 20" TRANSOM
J75ECTE 1983	MID-SECTION-20" TRANSOM
J75ECUR 1987	MIDSECTION - 20" TRANSOM
J75ELCNB 1982	EXHAUST HOUSING - 20" TRANSOM
J75ELCRD 1984	CARBURETOR
J75ELCRD 1984	MIDSECTION - 20" TRANSOM

J75ELCTE 1983	MID-SECTION-20" TRANSOM
J75ERCIH 1981	EXHAUST HOUSING-20" TRANSOM
J75ERCIM 1981	EXHAUST HOUSING-20" TRANSOM
J75ERCSA 1980	EXHAUST HOUSING-20" TRANSOM
J75ERLCIH 1981	EXHAUST HOUSING-20" TRANSOM
J75ERLCIM 1981	EXHAUST HOUSING-20" TRANSOM
J75ERLCSA 1980	EXHAUST HOUSING-20" TRANSOM
J75TELCIM 1981	EXHAUST HOUSING-20" TRANSOM
J75TLCNB 1982	EXHAUST HOUSING - 20" TRANSOM
J75TLCRD 1984	CARBURETOR
J75TLCRD 1984	MIDSECTION - 20" TRANSOM
J75TLCTE 1983	MID-SECTION-20" TRANSOM
J75TRLCIH 1981	EXHAUST HOUSING-20" TRANSOM
J75TRLCSA 1980	EXHAUST HOUSING-20" TRANSOM
J85MLCSA 1980	EXHAUST HOUSING
J85MLCSA 1980	IGNITION SYSTEM
J85TLCSA 1980	EXHAUST HOUSING
J85TLCSA 1980	IGNITION SYSTEM
J85TXCSA 1980	EXHAUST HOUSING
J85TXCSA 1980	IGNITION SYSTEM
J8DREEA 1999	IGNITION
J8RECR 1998	IGNITION
J8REDS 1996	IGNITION
J8REEM 1999	IGNITION
J8REOD 1995	IGNITION
J8RERE 1994	IGNITION
J8RETB 1993	IGNITION
J8REUC 1997	IGNITION
J8RLECR 1998	IGNITION
J8RLEDS 1996	IGNITION
J8RLEEM 1999	IGNITION
J8RLEOD 1995	IGNITION
J8RLERE 1994	IGNITION
J8RLETB 1993	IGNITION
J8RLEUC 1997	IGNITION

J8RLSIE rope start, tiller, 20 in shaft 2001	IGNITION
J8RLSOR	IGNITION
J8RLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSRC	IGNITION
J8RLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8RLSTS	IGNITION
J8RLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	IGNITION
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	IGNITION
J8RSIE rope start, tiller, 15 in shaft 2001	IGNITION
J8RSOR	IGNITION
J8RSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSRC	IGNITION
J8RSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J8RSTD	IGNITION
J8RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	IGNITION
J8RXEEM 1999	IGNITION
J8RXSIE rope start, tiller, 25 in shaft 2001	IGNITION
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	IGNITION
J8SRLECA 1998	IGNITION
J8SRLEDS 1996	IGNITION
J8SRLEOD 1995	IGNITION
J8SRLERE 1994	IGNITION
J8SRLETB 1993	IGNITION
J8SRLEUC 1997	IGNITION
J8WREES 1999	IGNITION
J8WRLEES 1999	IGNITION
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J90MLCDC 1986	CARBURETOR

J90MLCDC 1986	MIDSECTION
J90MLCIH 1981	EXHAUST HOUSING
J90MLCIH 1981	IGNITION SYSTEM
J90MLCIM 1981	EXHAUST HOUSING
J90MLCIM 1981	IGNITION SYSTEM
J90MLCNB 1982	EXHAUST HOUSING
J90MLCNB 1982	IGNITION SYSTEM
J90MLCOS 1985	CARBURETOR
J90MLCOS 1985	MIDSECTION
J90MLCRD 1984	CARBURETOR
J90MLCRD 1984	MIDSECTION
J90MLCTE 1983	EXHAUST HOUSING
J90MLCUR 1987	MIDSECTION
J90TLCDC 1986	CARBURETOR
J90TLCDC 1986	MIDSECTION
J90TLCIH 1981	EXHAUST HOUSING
J90TLCIH 1981	IGNITION SYSTEM
J90TLCIM 1981	EXHAUST HOUSING
J90TLCIM 1981	IGNITION SYSTEM
J90TLCNB 1982	EXHAUST HOUSING
J90TLCNB 1982	IGNITION SYSTEM
J90TLCOS 1985	CARBURETOR
J90TLCOS 1985	MIDSECTION
J90TLCRD 1984	CARBURETOR
J90TLCRD 1984	MIDSECTION
J90TLCTE 1983	EXHAUST HOUSING
J90TLCUR 1987	MIDSECTION
J90TXCDC 1986	CARBURETOR
J90TXCDC 1986	MIDSECTION
J90TXXIH 1981	EXHAUST HOUSING
J90TXXIH 1981	IGNITION SYSTEM
J90TXXIM 1981	EXHAUST HOUSING
J90TXXIM 1981	IGNITION SYSTEM
J90TXXNB 1982	EXHAUST HOUSING
J90TXXNB 1982	IGNITION SYSTEM

J90TXCOS 1985	CARBURETOR
J90TXCOS 1985	MIDSECTION
J90TXCRD 1984	CARBURETOR
J90TXCRD 1984	MIDSECTION
J90TXCTE 1983	EXHAUST HOUSING
POWER TILT/TRIM 1978	POWER TILT AND TRIM 70 - 140 HP MODELS
POWER TILT/TRIM 1979	POWER TILT AND TRIM 70 THRU 140 MODEL
POWER TILT/TRIM 1980	POWER TILT AND TRIM
POWER TILT/TRIM 1981	POWER TILT AND TRIM (70 THRU 140 MODELS)
POWER TILT/TRIM 1982	POWER TILT AND TRIM 70 THRU V-6
POWER TILT/TRIM 1983	POWER TILT AND TRIM 70 - V-6
POWER TRIM/TILT 1984	POWER TRIM/TILT 65 THRU V-6
POWER TRIM/TILT 1985	POWER TRIM/TILT 65 THRU 115
POWER TRIM/TILT 1986	POWER TRIM/TILT 60 THRU 110
POWER TRIM/TILT 1987	POWER TRIM/TILT 60 THRU 110
POWER TRIM/TILT 1988	POWER TRIM/TILT 60 THRU 110
POWER TRIM/TILT 1989	POWER TRIM/TILT 60 THRU 110
POWER TRIM/TILT 1990	POWER TRIM/TILT - 60 THRU 115
POWER TRIM/TILT 1991	POWER TRIM/TILT - 60 THRU 115
POWER TRIM/TILT 1992	POWER TRIM/TILT - 60 THRU 115
POWER TRIM/TILT 1993	POWER TRIM/TILT - 60 THRU 115
POWER TRIM/TILT 1994	POWER TRIM/TILT - 60 THRU 115
POWER TRIM/TILT 1995	POWER TRIM/TILT - 60 THRU 115
POWER TRIM/TILT 1996	POWER TRIM/TILT KIT - 88 & 90 MODELS
POWER TRIM/TILT 1997	POWER TRIM/TILT KIT - 100 MODELS
REMOTE CONTROL 1974	BINNACLE MOUNT CONTROL & WIRING KIT 50 THRU 135 HP
REMOTE CONTROL 1975	BINNACLE MOUNT CTRL & WIRING KIT 50 HP THRU 135 HP
REMOTE CONTROL 1976	BINNACLE MOUNT CONTROL AND WIRING KIT 55 THRU 200 HP
REMOTE CONTROL 1977	BINNACLE MOUNT CONTROL AND WIRING KIT 55 - 200
REMOTE CONTROL 1978	BINNACLE MOUNT CONTROL AND WIRING KIT 55 - 235 HP
RJ50ELSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
SE10RPB 1996	IGNITION
SE10RPLB 1996	IGNITION

SE10RPLT 1997	IGNITION
SE10RPLY 1998	IGNITION
SE10RPT 1997	IGNITION
SE10RPY 1998	IGNITION
SE15BAECA 1998	IGNITION -- ROPE
SE15BAEDC 1996	IGNITION - ROPE
SE15BAEEM 1999	IGNITION -- ROPE
SE15BAEUR 1997	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SE15RPC 1998	IGNITION
SE15RPG 1996	IGNITION
SE15RPLC 1998	IGNITION
SE15RPLG 1996	IGNITION
SE15RPLW 1997	IGNITION
SE15RPW 1997	IGNITION
SE25RDECA 1998	IGNITION
SE25RDEDC 1996	IGNITION
SE25RDEEM 1999	IGNITION
SE25RDEEN 1999	IGNITION
SE25RDEUR 1997	IGNITION
SE25RDSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SE25RDSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SE25RPLP 1998	IGNITION
SE25RPLV 1997	IGNITION - H25FP
SE25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SE25RPP 1998	IGNITION
SE25RPV 1997	IGNITION - H25FP
SE25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SE35REDE 1996	IGNITION
SE35RLEDE 1996	IGNITION
SE40RPB 1997	IGNITION SYSTEM
SE40RPH 1996	IGNITION SYSTEM
SE40RPLB 1997	IGNITION SYSTEM
SE40RPLH 1996	IGNITION SYSTEM

SE40RPLT2 1998	IGNITION SYSTEM
SE40RPT2 1998	IGNITION SYSTEM
SE40RPYB 1997	IGNITION SYSTEM
SE40RPYH 1996	IGNITION SYSTEM
SE40RPYT2 1998	IGNITION SYSTEM
SE40RSLD 1997	IGNITION SYSTEM
SE40RSLR 1998	IGNITION SYSTEM
SE40RSLZ 1996	IGNITION SYSTEM
SE45RSLB 1997	IGNITION SYSTEM
SE45RSLH 1996	IGNITION SYSTEM
SE50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
SE55RSC 1997	IGNITION SYSTEM
SE55RSLC 1997	IGNITION SYSTEM
SE55RSLM2 1998	IGNITION SYSTEM
SE55RSLW 1996	IGNITION SYSTEM
SE55RSM2 1998	IGNITION SYSTEM
SE55RSW 1996	IGNITION SYSTEM
SE55RSYC 1997	IGNITION SYSTEM
SE55RSYM2 1998	IGNITION SYSTEM
SE55RSYW 1996	IGNITION SYSTEM
SE65RSLD 1998	IGNITION SYSTEM
SE65RSLM 1996	IGNITION SYSTEM
SE65RSLZ2 1997	IGNITION SYSTEM
SE65RSYD 1998	IGNITION SYSTEM
SE65RSYM 1996	IGNITION SYSTEM
SE65RSYZ2 1997	IGNITION SYSTEM
SJ10REDD 1996	IGNITION - ROPE
SJ10RLEDD 1996	IGNITION - ROPE
SJ10RPB 1996	IGNITION
SJ10RPLB 1996	IGNITION
SJ10RPLT 1997	IGNITION
SJ10RPLY 1998	IGNITION
SJ10RPT 1997	IGNITION
SJ10RPY 1998	IGNITION
SJ10SELEDD 1996	IGNITION - ROPE

SJ15BAECA 1998	IGNITION -- ROPE
SJ15BAEDC 1996	IGNITION - ROPE
SJ15BAEEM 1999	IGNITION -- ROPE
SJ15BAEUR 1997	IGNITION - ROPE
SJ15REDS 1996	IGNITION - ROPE
SJ15RLEDS 1996	IGNITION - ROPE
SJ15RPC 1998	IGNITION
SJ15RPG 1996	IGNITION
SJ15RPLC 1998	IGNITION
SJ15RPLG 1996	IGNITION
SJ15RPLW 1997	IGNITION
SJ15RPW 1997	IGNITION
SJ15RTEEM 1999	IGNITION -- ROPE
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SJ25RDECA 1998	IGNITION
SJ25RDEDCA 1996	IGNITION
SJ25RDEEM 1999	IGNITION
SJ25RDEEMN 1999	IGNITION
SJ25RDEUR 1997	IGNITION
SJ25REDA 1996	IGNITION
SJ25RLEDA 1996	IGNITION
SJ25RPLP 1998	IGNITION
SJ25RPLV 1997	IGNITION - H25FP
SJ25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RPP 1998	IGNITION
SJ25RPV 1997	IGNITION - H25FP
SJ25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RTEEM 1999	IGNITION
SJ25RTSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SJ25RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SJ25TEEDA 1996	IGNITION
SJ25TEEUM 1997	IGNITION
SJ30EEDE 1996	IGNITION
SJ30REDE 1996	IGNITION

SJ30RLEDE 1996	IGNITION
SJ30TEEUD 1997	IGNITION
SJ35REDE 1996	IGNITION
SJ35RLEDE 1996	IGNITION
SJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40RPB 1997	IGNITION SYSTEM
SJ40RPH 1996	IGNITION SYSTEM
SJ40RPLB 1997	IGNITION SYSTEM
SJ40RPLH 1996	IGNITION SYSTEM
SJ40RPLT2 1998	IGNITION SYSTEM
SJ40RPT2 1998	IGNITION SYSTEM
SJ40RPYB 1997	IGNITION SYSTEM
SJ40RPYH 1996	IGNITION SYSTEM
SJ40RPYT2 1998	IGNITION SYSTEM
SJ40RSLD 1997	IGNITION SYSTEM
SJ40RSLR 1998	IGNITION SYSTEM
SJ40RSLZ 1996	IGNITION SYSTEM
SJ45RSLB 1997	IGNITION SYSTEM
SJ45RSLH 1996	IGNITION SYSTEM
SJ55RSC 1997	IGNITION SYSTEM
SJ55RSCLC 1997	IGNITION SYSTEM
SJ55RSLM2 1998	IGNITION SYSTEM
SJ55RSLW 1996	IGNITION SYSTEM
SJ55RSM2 1998	IGNITION SYSTEM
SJ55RSW 1996	IGNITION SYSTEM
SJ55RSYC 1997	IGNITION SYSTEM
SJ55RSYM2 1998	IGNITION SYSTEM
SJ55RSYW 1996	IGNITION SYSTEM
SJ65RSLD 1998	IGNITION SYSTEM
SJ65RSLM 1996	IGNITION SYSTEM
SJ65RSLZ2 1997	IGNITION SYSTEM
SJ65RSYD 1998	IGNITION SYSTEM
SJ65RSYM 1996	IGNITION SYSTEM

SJ65RSYZ2 1997	IGNITION SYSTEM
SJ6REDS 1996	IGNITION
SJ6RLEDS 1996	IGNITION
SJ8REDS 1996	IGNITION
SJ8RLEDS 1996	IGNITION
TE20CRETS 1993	IGNITION
TE20CRLETS 1993	IGNITION
TE25ELET C 1993	IGNITION
TE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TE60TLCEA 1989	IGNITION SYSTEM 60TTL
TE60TLESF 1989	IGNITION SYSTEM 60TTL
TE60TLESF 1990	IGNITION SYSTEM 60TTL
TE60TLESM 1990	IGNITION SYSTEM 60TTL
TJ20CRETS 1993	IGNITION
TJ20CRLETS 1993	IGNITION
TJ25ELET C 1993	IGNITION
TJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TJ60TLCEA 1989	IGNITION SYSTEM 60TTL
TJ60TLESF 1989	IGNITION SYSTEM 60TTL
TJ60TLESF 1990	IGNITION SYSTEM 60TTL
TJ60TLESM 1990	IGNITION SYSTEM 60TTL
VE25ELET C 1993	IGNITION
VE30EETA 1993	IGNITION
VE30ELETA 1993	IGNITION
VE40EETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE60ELESM 1990	IGNITION SYSTEM 60TTL
VE60TLESM 1990	IGNITION SYSTEM 60TTL

VJ25ELET C 1993	IGNITION
VJ30EE TA 1993	IGNITION
VJ30ELE TA 1993	IGNITION
VJ40EE TB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40ELET B 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TE LETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLET B 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLET F 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BE ETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BE LETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLET B 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLET F 1993	IGNITION SYSTEM - 40 ROPE START
VJ60ELES M 1990	IGNITION SYSTEM 60TTL
VJ60TLES M 1990	IGNITION SYSTEM 60TTL
X50ESL ECC 1998	IGNITION SYSTEM -- ROPE START