

## Where Used: Part Number 0319771

| Model Name      | Diagram         |
|-----------------|-----------------|
| 100990S 1979    | INTAKE MANIFOLD |
| 100993S 1979    | INTAKE MANIFOLD |
| 100999S 1979    | INTAKE MANIFOLD |
| 100ML79S 1979   | INTAKE MANIFOLD |
| 100TLR79S 1979  | INTAKE MANIFOLD |
| 100TXLR79S 1979 | INTAKE MANIFOLD |
| 115990R 1979    | INTAKE MANIFOLD |
| 115993R 1979    | INTAKE MANIFOLD |
| 115999R 1979    | INTAKE MANIFOLD |
| 115JEEOB 1995   | INTAKE MANIFOLD |
| 115JEERA 1994   | INTAKE MANIFOLD |
| 115ML79R 1979   | INTAKE MANIFOLD |
| 115TJEDB 1996   | INTAKE MANIFOLD |
| 115TJEOA 1995   | INTAKE MANIFOLD |
| 115TJEUC 1997   | INTAKE MANIFOLD |
| 115TL79R 1979   | INTAKE MANIFOLD |
| 115TXL79R 1979  | INTAKE MANIFOLD |
| 140940R 1979    | INTAKE MANIFOLD |
| 140943R 1979    | INTAKE MANIFOLD |
| 140983R 1979    | INTAKE MANIFOLD |
| 140ML79R 1979   | INTAKE MANIFOLD |
| 140TL79R 1979   | INTAKE MANIFOLD |
| 140TXL79R 1979  | INTAKE MANIFOLD |
| 150840S 1978    | INTAKE MANIFOLD |
| 150849S 1978    | INTAKE MANIFOLD |
| 150940C 1979    | INTAKE MANIFOLD |
| 150949C 1979    | INTAKE MANIFOLD |
| 150TL78S 1978   | INTAKE MANIFOLD |
| 150TL79C 1979   | INTAKE MANIFOLD |
| 150TXL78S 1978  | INTAKE MANIFOLD |
| 150TXL79C 1979  | INTAKE MANIFOLD |
| 175740S 1977    | INTAKE MANIFOLD |
| 175749S 1977    | INTAKE MANIFOLD |

|                |                 |
|----------------|-----------------|
| 175840C 1978   | INTAKE MANIFOLD |
| 175840S 1978   | INTAKE MANIFOLD |
| 175940R 1979   | INTAKE MANIFOLD |
| 175949R 1979   | INTAKE MANIFOLD |
| 175TL77S 1977  | INTAKE MANIFOLD |
| 175TL78C 1978  | INTAKE MANIFOLD |
| 175TL79R 1979  | INTAKE MANIFOLD |
| 175TX78C 1978  | INTAKE MANIFOLD |
| 175TXL77S 1977 | INTAKE MANIFOLD |
| 175TXL79R 1979 | INTAKE MANIFOLD |
| 200490A 1979   | INTAKE MANIFOLD |
| 200640S 1976   | INTAKE MANIFOLD |
| 200649S 1976   | INTAKE MANIFOLD |
| 200740C 1977   | INTAKE MANIFOLD |
| 200749C 1977   | INTAKE MANIFOLD |
| 200840R 1978   | INTAKE MANIFOLD |
| 200849R 1978   | INTAKE MANIFOLD |
| 200940A 1979   | INTAKE MANIFOLD |
| 200949A 1979   | INTAKE MANIFOLD |
| 200TL77C 1977  | INTAKE MANIFOLD |
| 200TL78R 1978  | INTAKE MANIFOLD |
| 200TL79A 1979  | INTAKE MANIFOLD |
| 200TX78R 1978  | INTAKE MANIFOLD |
| 200TXL77C 1977 | INTAKE MANIFOLD |
| 200TXL79A 1979 | INTAKE MANIFOLD |
| 235840R 1978   | INTAKE MANIFOLD |
| 235849R 1978   | INTAKE MANIFOLD |
| 235940A 1979   | INTAKE MANIFOLD |
| 235949A 1979   | INTAKE MANIFOLD |
| 235TL70A 1979  | INTAKE MANIFOLD |
| 235TL78R 1978  | INTAKE MANIFOLD |
| 235TX78R 1978  | INTAKE MANIFOLD |
| 235TXL79A 1979 | INTAKE MANIFOLD |
| 85990R 1979    | INTAKE MANIFOLD |
| 85995R 1979    | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| 85999R 1979     | INTAKE MANIFOLD |
| 85ML79R 1979    | INTAKE MANIFOLD |
| 85TL79R 1979    | INTAKE MANIFOLD |
| 85TXL79R 1979   | INTAKE MANIFOLD |
| 90JEEOB 1995    | INTAKE MANIFOLD |
| 90JEERA 1994    | INTAKE MANIFOLD |
| BE115TLEDA 1996 | INTAKE MANIFOLD |
| BE90TLEDA 1996  | INTAKE MANIFOLD |
| BJ115TLEDA 1996 | INTAKE MANIFOLD |
| BJ90TLEDA 1996  | INTAKE MANIFOLD |
| C155WTLM 1988   | INTAKE MANIFOLD |
| C155WTXM 1988   | INTAKE MANIFOLD |
| D100WTLM 1988   | INTAKE MANIFOLD |
| D100WTXM 1988   | INTAKE MANIFOLD |
| E100MLCSC 1980  | INTAKE MANIFOLD |
| E100STLCCA 1988 | INTAKE MANIFOLD |
| E100STLCEM 1989 | INTAKE MANIFOLD |
| E100STLEIE 1991 | INTAKE MANIFOLD |
| E100STLEND 1992 | INTAKE MANIFOLD |
| E100STLERC 1994 | INTAKE MANIFOLD |
| E100STLESB 1990 | INTAKE MANIFOLD |
| E100STLETS 1993 | INTAKE MANIFOLD |
| E100TLCSC 1980  | INTAKE MANIFOLD |
| E100TXCSC 1980  | INTAKE MANIFOLD |
| E100WMLCDR 1986 | INTAKE MANIFOLD |
| E100WMLCOC 1985 | INTAKE MANIFOLD |
| E100WMLCRS 1984 | INTAKE MANIFOLD |
| E100WTLCDR 1986 | INTAKE MANIFOLD |
| E100WTLCOC 1985 | INTAKE MANIFOLD |
| E100WTLCRS 1984 | INTAKE MANIFOLD |
| E100WTLCUA 1987 | INTAKE MANIFOLD |
| E100WTLEDR 1996 | INTAKE MANIFOLD |
| E100WTLEIB 1991 | INTAKE MANIFOLD |
| E100WTLENE 1992 | INTAKE MANIFOLD |
| E100WTLEOC 1995 | INTAKE MANIFOLD |

|                  |                 |
|------------------|-----------------|
| E100WTLERS 1994  | INTAKE MANIFOLD |
| E100WTLESM 1990  | INTAKE MANIFOLD |
| E100WTLETD 1993  | INTAKE MANIFOLD |
| E100WTL EUA 1997 | INTAKE MANIFOLD |
| E100WTLZ 1989    | INTAKE MANIFOLD |
| E100WTXCDR 1986  | INTAKE MANIFOLD |
| E100WTXCUA 1987  | INTAKE MANIFOLD |
| E100WTXEDR 1996  | INTAKE MANIFOLD |
| E100WTXEIB 1991  | INTAKE MANIFOLD |
| E100WTXENE 1992  | INTAKE MANIFOLD |
| E100WTXEOC 1995  | INTAKE MANIFOLD |
| E100WTXERS 1994  | INTAKE MANIFOLD |
| E100WTXESM 1990  | INTAKE MANIFOLD |
| E100WTXETD 1993  | INTAKE MANIFOLD |
| E100WTXEUA 1997  | INTAKE MANIFOLD |
| E100WTXZ 1989    | INTAKE MANIFOLD |
| E110MLCCA 1988   | INTAKE MANIFOLD |
| E110MLCDC 1986   | INTAKE MANIFOLD |
| E110MLCEM 1989   | INTAKE MANIFOLD |
| E110MLCUR 1987   | INTAKE MANIFOLD |
| E110TLCCA 1988   | INTAKE MANIFOLD |
| E110TLCDC 1986   | INTAKE MANIFOLD |
| E110TLCDF 1986   | INTAKE MANIFOLD |
| E110TLCEM 1989   | INTAKE MANIFOLD |
| E110TLCUR 1987   | INTAKE MANIFOLD |
| E110TXCCA 1988   | INTAKE MANIFOLD |
| E110TXCEM 1989   | INTAKE MANIFOLD |
| E110TXCUR 1987   | INTAKE MANIFOLD |
| E112TSLEDR 1996  | INTAKE MANIFOLD |
| E112TSLEOC 1995  | INTAKE MANIFOLD |
| E112TSLERS 1994  | INTAKE MANIFOLD |
| E112TSXEDR 1996  | INTAKE MANIFOLD |
| E112TSXEOC 1995  | INTAKE MANIFOLD |
| E112TSXERS 1994  | INTAKE MANIFOLD |
| E115JKLEOC 1995  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| E115JKLERS 1994 | INTAKE MANIFOLD |
| E115JLEDA 1996  | INTAKE MANIFOLD |
| E115JLEIE 1991  | INTAKE MANIFOLD |
| E115JLEND 1992  | INTAKE MANIFOLD |
| E115JLEOR 1995  | INTAKE MANIFOLD |
| E115JLERC 1994  | INTAKE MANIFOLD |
| E115JLETS 1993  | INTAKE MANIFOLD |
| E115JLEUM 1997  | INTAKE MANIFOLD |
| E115MLCIH 1981  | INTAKE MANIFOLD |
| E115MLCIM 1981  | INTAKE MANIFOLD |
| E115MLCNB 1982  | INTAKE MANIFOLD |
| E115MLCOS 1985  | INTAKE MANIFOLD |
| E115MLCRD 1984  | INTAKE MANIFOLD |
| E115MLCSA 1980  | INTAKE MANIFOLD |
| E115MLCTE 1983  | INTAKE MANIFOLD |
| E115MLEIE 1991  | INTAKE MANIFOLD |
| E115MLEND 1992  | INTAKE MANIFOLD |
| E115MLEOR 1995  | INTAKE MANIFOLD |
| E115MLERS 1994  | INTAKE MANIFOLD |
| E115MLESB 1990  | INTAKE MANIFOLD |
| E115MLETS 1993  | INTAKE MANIFOLD |
| E115TLCIH 1981  | INTAKE MANIFOLD |
| E115TLCIM 1981  | INTAKE MANIFOLD |
| E115TLCNB 1982  | INTAKE MANIFOLD |
| E115TLCOS 1985  | INTAKE MANIFOLD |
| E115TLCRD 1984  | INTAKE MANIFOLD |
| E115TLCSA 1980  | INTAKE MANIFOLD |
| E115TLCTE 1983  | INTAKE MANIFOLD |
| E115TLEDA 1996  | INTAKE MANIFOLD |
| E115TLEIE 1991  | INTAKE MANIFOLD |
| E115TLEND 1992  | INTAKE MANIFOLD |
| E115TLEOR 1995  | INTAKE MANIFOLD |
| E115TLERC 1994  | INTAKE MANIFOLD |
| E115TLESB 1990  | INTAKE MANIFOLD |
| E115TLETS 1993  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| E115TSLECM 1998 | INTAKE MANIFOLD |
| E115TSLEUA 1997 | INTAKE MANIFOLD |
| E115TSXECM 1998 | INTAKE MANIFOLD |
| E115TSXEUA 1997 | INTAKE MANIFOLD |
| E115TXADA 1996  | INTAKE MANIFOLD |
| E115TXAOR 1995  | INTAKE MANIFOLD |
| E115TXARS 1994  | INTAKE MANIFOLD |
| E115TXATS 1993  | INTAKE MANIFOLD |
| E115TXCIH 1981  | INTAKE MANIFOLD |
| E115TXCIM 1981  | INTAKE MANIFOLD |
| E115TXCNB 1982  | INTAKE MANIFOLD |
| E115TXCRD 1984  | INTAKE MANIFOLD |
| E115TXCSA 1980  | INTAKE MANIFOLD |
| E115TXCTE 1983  | INTAKE MANIFOLD |
| E115TXEIE 1991  | INTAKE MANIFOLD |
| E115TXEND 1992  | INTAKE MANIFOLD |
| E115TXESB 1990  | INTAKE MANIFOLD |
| E140MLCIH 1981  | INTAKE MANIFOLD |
| E140MLCIM 1981  | INTAKE MANIFOLD |
| E140MLCNB 1982  | INTAKE MANIFOLD |
| E140MLCSA 1980  | INTAKE MANIFOLD |
| E140MLCTE 1983  | INTAKE MANIFOLD |
| E140TLCRD 1984  | INTAKE MANIFOLD |
| E140TRLCIH 1981 | INTAKE MANIFOLD |
| E140TRLCIM 1981 | INTAKE MANIFOLD |
| E140TRLCNB 1982 | INTAKE MANIFOLD |
| E140TRLCSA 1980 | INTAKE MANIFOLD |
| E140TRLCTE 1983 | INTAKE MANIFOLD |
| E140TRXCIH 1981 | INTAKE MANIFOLD |
| E140TRXCIM 1981 | INTAKE MANIFOLD |
| E140TRXCNB 1982 | INTAKE MANIFOLD |
| E140TRXCSA 1980 | INTAKE MANIFOLD |
| E140TRXCTE 1983 | INTAKE MANIFOLD |
| E140TXCRD 1984  | INTAKE MANIFOLD |
| E150ANCRS 1984  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| E150CXCCA 1988  | INTAKE MANIFOLD |
| E150CXCEM 1989  | INTAKE MANIFOLD |
| E150CXEIE 1991  | INTAKE MANIFOLD |
| E150CXESB 1990  | INTAKE MANIFOLD |
| E150JLEIE 1991  | INTAKE MANIFOLD |
| E150STLCCA 1988 | INTAKE MANIFOLD |
| E150STLCDC 1986 | INTAKE MANIFOLD |
| E150STLCEM 1989 | INTAKE MANIFOLD |
| E150STLCOH 1985 | INTAKE MANIFOLD |
| E150STLCOS 1985 | INTAKE MANIFOLD |
| E150STLCRD 1984 | INTAKE MANIFOLD |
| E150STLCTE 1983 | INTAKE MANIFOLD |
| E150STLCUR 1987 | INTAKE MANIFOLD |
| E150STLEIE 1991 | INTAKE MANIFOLD |
| E150STLESB 1990 | INTAKE MANIFOLD |
| E150TLCCA 1988  | INTAKE MANIFOLD |
| E150TLCDC 1986  | INTAKE MANIFOLD |
| E150TLCEM 1989  | INTAKE MANIFOLD |
| E150TLCOS 1985  | INTAKE MANIFOLD |
| E150TLCRD 1984  | INTAKE MANIFOLD |
| E150TLCUR 1987  | INTAKE MANIFOLD |
| E150TLEIE 1991  | INTAKE MANIFOLD |
| E150TLESB 1990  | INTAKE MANIFOLD |
| E150TRLCIA 1981 | INTAKE MANIFOLD |
| E150TRLCIH 1981 | INTAKE MANIFOLD |
| E150TRLCNM 1982 | INTAKE MANIFOLD |
| E150TRLCSF 1980 | INTAKE MANIFOLD |
| E150TRLCSR 1980 | INTAKE MANIFOLD |
| E150TRLCTB 1983 | INTAKE MANIFOLD |
| E150TRLCTE 1983 | INTAKE MANIFOLD |
| E150TRXCIA 1981 | INTAKE MANIFOLD |
| E150TRXCIH 1981 | INTAKE MANIFOLD |
| E150TRXCNM 1982 | INTAKE MANIFOLD |
| E150TRXCSF 1980 | INTAKE MANIFOLD |
| E150TRXCSR 1980 | INTAKE MANIFOLD |





|                 |                 |
|-----------------|-----------------|
| E175TRLCNB 1982 | INTAKE MANIFOLD |
| E175TRLCSA 1980 | INTAKE MANIFOLD |
| E175TRLCSE 1980 | INTAKE MANIFOLD |
| E175TRLCTD 1983 | INTAKE MANIFOLD |
| E175TRLCTE 1983 | INTAKE MANIFOLD |
| E175TRXCIH 1981 | INTAKE MANIFOLD |
| E175TRXCIM 1981 | INTAKE MANIFOLD |
| E175TRXCNB 1982 | INTAKE MANIFOLD |
| E175TRXCSA 1980 | INTAKE MANIFOLD |
| E175TRXCSE 1980 | INTAKE MANIFOLD |
| E175TRXCTD 1983 | INTAKE MANIFOLD |
| E175TRXCTE 1983 | INTAKE MANIFOLD |
| E175TXCCM 1988  | INTAKE MANIFOLD |
| E175TXCDR 1986  | INTAKE MANIFOLD |
| E175TXCEB 1989  | INTAKE MANIFOLD |
| E175TXCOC 1985  | INTAKE MANIFOLD |
| E175TXCUA 1987  | INTAKE MANIFOLD |
| E175TXEID 1991  | INTAKE MANIFOLD |
| E175TXESE 1990  | INTAKE MANIFOLD |
| E185TLCOC 1985  | INTAKE MANIFOLD |
| E185TLCRS 1984  | INTAKE MANIFOLD |
| E185TXCOC 1985  | INTAKE MANIFOLD |
| E185TXCRS 1984  | INTAKE MANIFOLD |
| E200TRLCIB 1981 | INTAKE MANIFOLD |
| E200TRLCIH 1981 | INTAKE MANIFOLD |
| E200TRLCNE 1982 | INTAKE MANIFOLD |
| E200TRLCSE 1980 | INTAKE MANIFOLD |
| E200TRLCSE 1980 | INTAKE MANIFOLD |
| E200TRLCTD 1983 | INTAKE MANIFOLD |
| E200TRLCTS 1983 | INTAKE MANIFOLD |
| E200TRXCIB 1981 | INTAKE MANIFOLD |
| E200TRXCIH 1981 | INTAKE MANIFOLD |
| E200TRXCNE 1982 | INTAKE MANIFOLD |
| E200TRXCSE 1980 | INTAKE MANIFOLD |
| E200TRXCSE 1980 | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| E200TRXCTD 1983 | INTAKE MANIFOLD |
| E200TRXCTS 1983 | INTAKE MANIFOLD |
| E235STLCOR 1985 | INTAKE MANIFOLD |
| E235STLCRC 1984 | INTAKE MANIFOLD |
| E235STLCTS 1983 | INTAKE MANIFOLD |
| E235TLCOR 1985  | INTAKE MANIFOLD |
| E235TLCRC 1984  | INTAKE MANIFOLD |
| E235TRLCIB 1981 | INTAKE MANIFOLD |
| E235TRLCIH 1981 | INTAKE MANIFOLD |
| E235TRLCNE 1982 | INTAKE MANIFOLD |
| E235TRLCSM 1980 | INTAKE MANIFOLD |
| E235TRLCTD 1983 | INTAKE MANIFOLD |
| E235TRLCTS 1983 | INTAKE MANIFOLD |
| E235TRXCIB 1981 | INTAKE MANIFOLD |
| E235TRXCIH 1981 | INTAKE MANIFOLD |
| E235TRXCNE 1982 | INTAKE MANIFOLD |
| E235TRXCSM 1980 | INTAKE MANIFOLD |
| E235TRXCTD 1983 | INTAKE MANIFOLD |
| E235TRXCTS 1983 | INTAKE MANIFOLD |
| E235TXCOR 1985  | INTAKE MANIFOLD |
| E235TXCRC 1984  | INTAKE MANIFOLD |
| E85MLCSA 1980   | INTAKE MANIFOLD |
| E85STLCSA 1980  | INTAKE MANIFOLD |
| E85STXCSA 1980  | INTAKE MANIFOLD |
| E85TTLEIE 1991  | INTAKE MANIFOLD |
| E85TTLEND 1992  | INTAKE MANIFOLD |
| E85TTLEOR 1995  | INTAKE MANIFOLD |
| E85TTLERC 1994  | INTAKE MANIFOLD |
| E85TTLETS 1993  | INTAKE MANIFOLD |
| E88MSLCCC 1988  | INTAKE MANIFOLD |
| E88MSLCER 1989  | INTAKE MANIFOLD |
| E88MSLCUS 1987  | INTAKE MANIFOLD |
| E88MSLEDC 1996  | INTAKE MANIFOLD |
| E88MSLEIM 1991  | INTAKE MANIFOLD |
| E88MSLENB 1992  | INTAKE MANIFOLD |

|                |                 |
|----------------|-----------------|
| E88MSLEOS 1995 | INTAKE MANIFOLD |
| E88MSLERD 1994 | INTAKE MANIFOLD |
| E88MSLESA 1990 | INTAKE MANIFOLD |
| E88MSLETE 1993 | INTAKE MANIFOLD |
| E88TSLEDR 1996 | INTAKE MANIFOLD |
| E88TSLEOC 1995 | INTAKE MANIFOLD |
| E88TSLERS 1994 | INTAKE MANIFOLD |
| E90JLEIE 1991  | INTAKE MANIFOLD |
| E90JLEND 1992  | INTAKE MANIFOLD |
| E90JLEOR 1995  | INTAKE MANIFOLD |
| E90JLERC 1994  | INTAKE MANIFOLD |
| E90JLETS 1993  | INTAKE MANIFOLD |
| E90MLCDC 1986  | INTAKE MANIFOLD |
| E90MLCIH 1981  | INTAKE MANIFOLD |
| E90MLCIM 1981  | INTAKE MANIFOLD |
| E90MLCNB 1982  | INTAKE MANIFOLD |
| E90MLCOS 1985  | INTAKE MANIFOLD |
| E90MLCRD 1984  | INTAKE MANIFOLD |
| E90MLCTE 1983  | INTAKE MANIFOLD |
| E90MLCUR 1987  | INTAKE MANIFOLD |
| E90MLEOR 1995  | INTAKE MANIFOLD |
| E90MLERC 1994  | INTAKE MANIFOLD |
| E90TLCCA 1988  | INTAKE MANIFOLD |
| E90TLCDC 1986  | INTAKE MANIFOLD |
| E90TLCEM 1989  | INTAKE MANIFOLD |
| E90TLCIH 1981  | INTAKE MANIFOLD |
| E90TLCIM 1981  | INTAKE MANIFOLD |
| E90TLCNB 1982  | INTAKE MANIFOLD |
| E90TLCOS 1985  | INTAKE MANIFOLD |
| E90TLCRD 1984  | INTAKE MANIFOLD |
| E90TLCTE 1983  | INTAKE MANIFOLD |
| E90TLCUR 1987  | INTAKE MANIFOLD |
| E90TLEDA 1996  | INTAKE MANIFOLD |
| E90TLEIE 1991  | INTAKE MANIFOLD |
| E90TLEND 1992  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| E90TLEOR 1995   | INTAKE MANIFOLD |
| E90TLERC 1994   | INTAKE MANIFOLD |
| E90TLESB 1990   | INTAKE MANIFOLD |
| E90TLETS 1993   | INTAKE MANIFOLD |
| E90TSLECM 1998  | INTAKE MANIFOLD |
| E90TSLEUA 1997  | INTAKE MANIFOLD |
| E90TXARC 1994   | INTAKE MANIFOLD |
| E90TXATS 1993   | INTAKE MANIFOLD |
| E90TXCDC 1986   | INTAKE MANIFOLD |
| E90TXCIH 1981   | INTAKE MANIFOLD |
| E90TXCIM 1981   | INTAKE MANIFOLD |
| E90TXCNB 1982   | INTAKE MANIFOLD |
| E90TXCOS 1985   | INTAKE MANIFOLD |
| E90TXCRD 1984   | INTAKE MANIFOLD |
| E90TXCTE 1983   | INTAKE MANIFOLD |
| HE115TXADA 1996 | INTAKE MANIFOLD |
| HE88MSLEDC 1996 | INTAKE MANIFOLD |
| HE90MLEDA 1996  | INTAKE MANIFOLD |
| HE90TXADA 1996  | INTAKE MANIFOLD |
| HJ115TXADA 1996 | INTAKE MANIFOLD |
| HJ88MSLEDC 1996 | INTAKE MANIFOLD |
| HJ90MLEDA 1996  | INTAKE MANIFOLD |
| HJ90TXADA 1996  | INTAKE MANIFOLD |
| J100MLCSC 1980  | INTAKE MANIFOLD |
| J100STLCCA 1988 | INTAKE MANIFOLD |
| J100STLCEM 1989 | INTAKE MANIFOLD |
| J100STLEIE 1991 | INTAKE MANIFOLD |
| J100STLEND 1992 | INTAKE MANIFOLD |
| J100STLERC 1994 | INTAKE MANIFOLD |
| J100STLESB 1990 | INTAKE MANIFOLD |
| J100STLETS 1993 | INTAKE MANIFOLD |
| J100TRLCSC 1980 | INTAKE MANIFOLD |
| J100TRXCSC 1980 | INTAKE MANIFOLD |
| J100WMLCDR 1986 | INTAKE MANIFOLD |
| J100WMLCOC 1985 | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| J100WMLCRS 1984 | INTAKE MANIFOLD |
| J100WTLCDR 1986 | INTAKE MANIFOLD |
| J100WTLCOC 1985 | INTAKE MANIFOLD |
| J100WTLCRS 1984 | INTAKE MANIFOLD |
| J100WTLCUA 1987 | INTAKE MANIFOLD |
| J100WTLEDR 1996 | INTAKE MANIFOLD |
| J100WTLEIB 1991 | INTAKE MANIFOLD |
| J100WTLENE 1992 | INTAKE MANIFOLD |
| J100WTLEOC 1995 | INTAKE MANIFOLD |
| J100WTLERS 1994 | INTAKE MANIFOLD |
| J100WTLESM 1990 | INTAKE MANIFOLD |
| J100WTLETD 1993 | INTAKE MANIFOLD |
| J100WTLEUA 1997 | INTAKE MANIFOLD |
| J100WTLZ 1989   | INTAKE MANIFOLD |
| J100WTXCDR 1986 | INTAKE MANIFOLD |
| J100WTXCUA 1987 | INTAKE MANIFOLD |
| J100WTXEDR 1996 | INTAKE MANIFOLD |
| J100WTXEIB 1991 | INTAKE MANIFOLD |
| J100WTXENE 1992 | INTAKE MANIFOLD |
| J100WTXEOC 1995 | INTAKE MANIFOLD |
| J100WTXERS 1994 | INTAKE MANIFOLD |
| J100WTXESM 1990 | INTAKE MANIFOLD |
| J100WTXETD 1993 | INTAKE MANIFOLD |
| J100WTXEUA 1997 | INTAKE MANIFOLD |
| J100WTXZ 1989   | INTAKE MANIFOLD |
| J110MLCCA 1988  | INTAKE MANIFOLD |
| J110MLCDC 1986  | INTAKE MANIFOLD |
| J110MLCEM 1989  | INTAKE MANIFOLD |
| J110MLCUR 1987  | INTAKE MANIFOLD |
| J110TLAEM 1989  | INTAKE MANIFOLD |
| J110TLCCA 1988  | INTAKE MANIFOLD |
| J110TLCDC 1986  | INTAKE MANIFOLD |
| J110TLCDF 1986  | INTAKE MANIFOLD |
| J110TLCEM 1989  | INTAKE MANIFOLD |
| J110TLCUR 1987  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| J110TXCCA 1988  | INTAKE MANIFOLD |
| J110TXCEM 1989  | INTAKE MANIFOLD |
| J110TXCUR 1987  | INTAKE MANIFOLD |
| J112TSLEDR 1996 | INTAKE MANIFOLD |
| J112TSLEOC 1995 | INTAKE MANIFOLD |
| J112TSLERS 1994 | INTAKE MANIFOLD |
| J112TSXEDR 1996 | INTAKE MANIFOLD |
| J112TSXEOC 1995 | INTAKE MANIFOLD |
| J112TSXERS 1994 | INTAKE MANIFOLD |
| J115JKLEOC 1995 | INTAKE MANIFOLD |
| J115JKLERS 1994 | INTAKE MANIFOLD |
| J115JLEDA 1996  | INTAKE MANIFOLD |
| J115JLEIE 1991  | INTAKE MANIFOLD |
| J115JLEND 1992  | INTAKE MANIFOLD |
| J115JLEOR 1995  | INTAKE MANIFOLD |
| J115JLERC 1994  | INTAKE MANIFOLD |
| J115JLETS 1993  | INTAKE MANIFOLD |
| J115JLEUM 1997  | INTAKE MANIFOLD |
| J115MLCIH 1981  | INTAKE MANIFOLD |
| J115MLCIM 1981  | INTAKE MANIFOLD |
| J115MLCNB 1982  | INTAKE MANIFOLD |
| J115MLCOS 1985  | INTAKE MANIFOLD |
| J115MLCRD 1984  | INTAKE MANIFOLD |
| J115MLCSA 1980  | INTAKE MANIFOLD |
| J115MLCTE 1983  | INTAKE MANIFOLD |
| J115MLEIE 1991  | INTAKE MANIFOLD |
| J115MLEND 1992  | INTAKE MANIFOLD |
| J115MLEOR 1995  | INTAKE MANIFOLD |
| J115MLERS 1994  | INTAKE MANIFOLD |
| J115MLESB 1990  | INTAKE MANIFOLD |
| J115MLETS 1993  | INTAKE MANIFOLD |
| J115TLAIE 1991  | INTAKE MANIFOLD |
| J115TLAND 1992  | INTAKE MANIFOLD |
| J115TLARC 1994  | INTAKE MANIFOLD |
| J115TLASB 1990  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| J115TLATS 1993  | INTAKE MANIFOLD |
| J115TLCIH 1981  | INTAKE MANIFOLD |
| J115TLCIM 1981  | INTAKE MANIFOLD |
| J115TLCNB 1982  | INTAKE MANIFOLD |
| J115TLCOS 1985  | INTAKE MANIFOLD |
| J115TLCRD 1984  | INTAKE MANIFOLD |
| J115TLCSA 1980  | INTAKE MANIFOLD |
| J115TLCTE 1983  | INTAKE MANIFOLD |
| J115TLEDA 1996  | INTAKE MANIFOLD |
| J115TLEIE 1991  | INTAKE MANIFOLD |
| J115TLEND 1992  | INTAKE MANIFOLD |
| J115TLEOR 1995  | INTAKE MANIFOLD |
| J115TLERC 1994  | INTAKE MANIFOLD |
| J115TLESB 1990  | INTAKE MANIFOLD |
| J115TLETS 1993  | INTAKE MANIFOLD |
| J115TSLECM 1998 | INTAKE MANIFOLD |
| J115TSLEUA 1997 | INTAKE MANIFOLD |
| J115TSXECM 1998 | INTAKE MANIFOLD |
| J115TSXEUA 1997 | INTAKE MANIFOLD |
| J115TXADA 1996  | INTAKE MANIFOLD |
| J115TXAOR 1995  | INTAKE MANIFOLD |
| J115TXARS 1994  | INTAKE MANIFOLD |
| J115TXATS 1993  | INTAKE MANIFOLD |
| J115TXCIH 1981  | INTAKE MANIFOLD |
| J115TXCIM 1981  | INTAKE MANIFOLD |
| J115TXCNB 1982  | INTAKE MANIFOLD |
| J115TXCRD 1984  | INTAKE MANIFOLD |
| J115TXCSA 1980  | INTAKE MANIFOLD |
| J115TXCTE 1983  | INTAKE MANIFOLD |
| J115TXEIE 1991  | INTAKE MANIFOLD |
| J115TXEND 1992  | INTAKE MANIFOLD |
| J115TXESB 1990  | INTAKE MANIFOLD |
| J140MLCIH 1981  | INTAKE MANIFOLD |
| J140MLCIM 1981  | INTAKE MANIFOLD |
| J140MLCNB 1982  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| J140MLCSA 1980  | INTAKE MANIFOLD |
| J140MLCTE 1983  | INTAKE MANIFOLD |
| J140TLCIH 1981  | INTAKE MANIFOLD |
| J140TLCIM 1981  | INTAKE MANIFOLD |
| J140TLCNB 1982  | INTAKE MANIFOLD |
| J140TLCRD 1984  | INTAKE MANIFOLD |
| J140TLCSA 1980  | INTAKE MANIFOLD |
| J140TLCTE 1983  | INTAKE MANIFOLD |
| J140TXCIH 1981  | INTAKE MANIFOLD |
| J140TXCIM 1981  | INTAKE MANIFOLD |
| J140TXCNB 1982  | INTAKE MANIFOLD |
| J140TXCRD 1984  | INTAKE MANIFOLD |
| J140TXCSA 1980  | INTAKE MANIFOLD |
| J140TXCTE 1983  | INTAKE MANIFOLD |
| J150CXCCA 1988  | INTAKE MANIFOLD |
| J150CXCEM 1989  | INTAKE MANIFOLD |
| J150CXEIE 1991  | INTAKE MANIFOLD |
| J150CXESB 1990  | INTAKE MANIFOLD |
| J150GTLCUR 1987 | INTAKE MANIFOLD |
| J150JLEIE 1991  | INTAKE MANIFOLD |
| J150STLACA 1988 | INTAKE MANIFOLD |
| J150STLCCA 1988 | INTAKE MANIFOLD |
| J150STLCDC 1986 | INTAKE MANIFOLD |
| J150STLCEM 1989 | INTAKE MANIFOLD |
| J150STLCOH 1985 | INTAKE MANIFOLD |
| J150STLCOS 1985 | INTAKE MANIFOLD |
| J150STLCRD 1984 | INTAKE MANIFOLD |
| J150STLCTE 1983 | INTAKE MANIFOLD |
| J150STLCUR 1987 | INTAKE MANIFOLD |
| J150STLEIE 1991 | INTAKE MANIFOLD |
| J150STLESB 1990 | INTAKE MANIFOLD |
| J150TLAEM 1989  | INTAKE MANIFOLD |
| J150TLAIE 1991  | INTAKE MANIFOLD |
| J150TLASB 1990  | INTAKE MANIFOLD |
| J150TLCCA 1988  | INTAKE MANIFOLD |



|                 |                 |
|-----------------|-----------------|
| J150TLCDC 1986  | INTAKE MANIFOLD |
| J150TLCEM 1989  | INTAKE MANIFOLD |
| J150TLCIA 1981  | INTAKE MANIFOLD |
| J150TLCIH 1981  | INTAKE MANIFOLD |
| J150TLCNM 1982  | INTAKE MANIFOLD |
| J150TLCOS 1985  | INTAKE MANIFOLD |
| J150TLCRD 1984  | INTAKE MANIFOLD |
| J150TLCSF 1980  | INTAKE MANIFOLD |
| J150TLCSR 1980  | INTAKE MANIFOLD |
| J150TLCTB 1983  | INTAKE MANIFOLD |
| J150TLCTE 1983  | INTAKE MANIFOLD |
| J150TLCUR 1987  | INTAKE MANIFOLD |
| J150TLEIE 1991  | INTAKE MANIFOLD |
| J150TLESB 1990  | INTAKE MANIFOLD |
| J150TXCCA 1988  | INTAKE MANIFOLD |
| J150TXCDC 1986  | INTAKE MANIFOLD |
| J150TXCEM 1989  | INTAKE MANIFOLD |
| J150TXCIA 1981  | INTAKE MANIFOLD |
| J150TXCIH 1981  | INTAKE MANIFOLD |
| J150TXCNM 1982  | INTAKE MANIFOLD |
| J150TXCOS 1985  | INTAKE MANIFOLD |
| J150TXCRD 1984  | INTAKE MANIFOLD |
| J150TXCSF 1980  | INTAKE MANIFOLD |
| J150TXCSR 1980  | INTAKE MANIFOLD |
| J150TXCTB 1983  | INTAKE MANIFOLD |
| J150TXCTE 1983  | INTAKE MANIFOLD |
| J150TXCUR 1987  | INTAKE MANIFOLD |
| J150TXEIE 1991  | INTAKE MANIFOLD |
| J150TXESB 1990  | INTAKE MANIFOLD |
| J155WTLCDR 1986 | INTAKE MANIFOLD |
| J155WTLCOG 1985 | INTAKE MANIFOLD |
| J155WTLCRS 1984 | INTAKE MANIFOLD |
| J155WTLCUA 1987 | INTAKE MANIFOLD |
| J155WTLEIB 1991 | INTAKE MANIFOLD |
| J155WTLENE 1992 | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| J155WTLESM 1990 | INTAKE MANIFOLD |
| J155WTLZ 1989   | INTAKE MANIFOLD |
| J155WTXCDR 1986 | INTAKE MANIFOLD |
| J155WTXCOC 1985 | INTAKE MANIFOLD |
| J155WTXCRS 1984 | INTAKE MANIFOLD |
| J155WTXCUA 1987 | INTAKE MANIFOLD |
| J155WTXEIB 1991 | INTAKE MANIFOLD |
| J155WTXENE 1992 | INTAKE MANIFOLD |
| J155WTXESM 1990 | INTAKE MANIFOLD |
| J155WTXZ 1989   | INTAKE MANIFOLD |
| J175STLACM 1988 | INTAKE MANIFOLD |
| J175STLCCM 1988 | INTAKE MANIFOLD |
| J175STLCEB 1989 | INTAKE MANIFOLD |
| J175STLEID 1991 | INTAKE MANIFOLD |
| J175STLESE 1990 | INTAKE MANIFOLD |
| J175TLCCM 1988  | INTAKE MANIFOLD |
| J175TLCDR 1986  | INTAKE MANIFOLD |
| J175TLCIH 1981  | INTAKE MANIFOLD |
| J175TLCIM 1981  | INTAKE MANIFOLD |
| J175TLCNB 1982  | INTAKE MANIFOLD |
| J175TLCOC 1985  | INTAKE MANIFOLD |
| J175TLCSA 1980  | INTAKE MANIFOLD |
| J175TLCSF 1980  | INTAKE MANIFOLD |
| J175TLCTD 1983  | INTAKE MANIFOLD |
| J175TLCTE 1983  | INTAKE MANIFOLD |
| J175TLCUA 1987  | INTAKE MANIFOLD |
| J175TXCCM 1988  | INTAKE MANIFOLD |
| J175TXCDR 1986  | INTAKE MANIFOLD |
| J175TXCEB 1989  | INTAKE MANIFOLD |
| J175TXCIH 1981  | INTAKE MANIFOLD |
| J175TXCIM 1981  | INTAKE MANIFOLD |
| J175TXCNB 1982  | INTAKE MANIFOLD |
| J175TXCOC 1985  | INTAKE MANIFOLD |
| J175TXCSA 1980  | INTAKE MANIFOLD |
| J175TXCSF 1980  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| J175TXCTD 1983  | INTAKE MANIFOLD |
| J175TXCTE 1983  | INTAKE MANIFOLD |
| J175TXCUA 1987  | INTAKE MANIFOLD |
| J175TXEID 1991  | INTAKE MANIFOLD |
| J175TXESE 1990  | INTAKE MANIFOLD |
| J185TLCOC 1985  | INTAKE MANIFOLD |
| J185TLCRS 1984  | INTAKE MANIFOLD |
| J185TXCOC 1985  | INTAKE MANIFOLD |
| J185TXCR 1984   | INTAKE MANIFOLD |
| J200TLCIH 1981  | INTAKE MANIFOLD |
| J200TLCNE 1982  | INTAKE MANIFOLD |
| J200TLCSF 1980  | INTAKE MANIFOLD |
| J200TLCSM 1980  | INTAKE MANIFOLD |
| J200TLCTD 1983  | INTAKE MANIFOLD |
| J200TLCTS 1983  | INTAKE MANIFOLD |
| J200TXCIB 1981  | INTAKE MANIFOLD |
| J200TXCIH 1981  | INTAKE MANIFOLD |
| J200TXCNE 1982  | INTAKE MANIFOLD |
| J200TXCSF 1980  | INTAKE MANIFOLD |
| J200TXCSM 1980  | INTAKE MANIFOLD |
| J200TXCTD 1983  | INTAKE MANIFOLD |
| J200TXCTS 1983  | INTAKE MANIFOLD |
| J235STLCOR 1985 | INTAKE MANIFOLD |
| J235STLCRC 1984 | INTAKE MANIFOLD |
| J235STLCTS 1983 | INTAKE MANIFOLD |
| J235TLCIB 1981  | INTAKE MANIFOLD |
| J235TLCIH 1981  | INTAKE MANIFOLD |
| J235TLCNE 1982  | INTAKE MANIFOLD |
| J235TLCOR 1985  | INTAKE MANIFOLD |
| J235TLCRC 1984  | INTAKE MANIFOLD |
| J235TLCSM 1980  | INTAKE MANIFOLD |
| J235TLCTD 1983  | INTAKE MANIFOLD |
| J235TLCTS 1983  | INTAKE MANIFOLD |
| J235TXCIB 1981  | INTAKE MANIFOLD |
| J235TXCIH 1981  | INTAKE MANIFOLD |

|                |                 |
|----------------|-----------------|
| J235TXCNE 1982 | INTAKE MANIFOLD |
| J235TXCOR 1985 | INTAKE MANIFOLD |
| J235TXCRC 1984 | INTAKE MANIFOLD |
| J235TXCSM 1980 | INTAKE MANIFOLD |
| J235TXCTD 1983 | INTAKE MANIFOLD |
| J235TXCTS 1983 | INTAKE MANIFOLD |
| J85MLCSA 1980  | INTAKE MANIFOLD |
| J85TLCSA 1980  | INTAKE MANIFOLD |
| J85TTLEIE 1991 | INTAKE MANIFOLD |
| J85TTLEND 1992 | INTAKE MANIFOLD |
| J85TTLEOR 1995 | INTAKE MANIFOLD |
| J85TTLERC 1994 | INTAKE MANIFOLD |
| J85TTLETS 1993 | INTAKE MANIFOLD |
| J85TXCSA 1980  | INTAKE MANIFOLD |
| J88MSLCCC 1988 | INTAKE MANIFOLD |
| J88MSLCER 1989 | INTAKE MANIFOLD |
| J88MSLCUS 1987 | INTAKE MANIFOLD |
| J88MSLEDC 1996 | INTAKE MANIFOLD |
| J88MSLEIM 1991 | INTAKE MANIFOLD |
| J88MSLENB 1992 | INTAKE MANIFOLD |
| J88MSLEOS 1995 | INTAKE MANIFOLD |
| J88MSLERD 1994 | INTAKE MANIFOLD |
| J88MSLESA 1990 | INTAKE MANIFOLD |
| J88MSLETE 1993 | INTAKE MANIFOLD |
| J88TSLEDR 1996 | INTAKE MANIFOLD |
| J88TSLEOC 1995 | INTAKE MANIFOLD |
| J88TSLERS 1994 | INTAKE MANIFOLD |
| J90JLEIE 1991  | INTAKE MANIFOLD |
| J90JLEND 1992  | INTAKE MANIFOLD |
| J90JLEOR 1995  | INTAKE MANIFOLD |
| J90JLERC 1994  | INTAKE MANIFOLD |
| J90JLETS 1993  | INTAKE MANIFOLD |
| J90MLCDC 1986  | INTAKE MANIFOLD |
| J90MLCIH 1981  | INTAKE MANIFOLD |
| J90MLCIM 1981  | INTAKE MANIFOLD |

|                |                 |
|----------------|-----------------|
| J90MLCNB 1982  | INTAKE MANIFOLD |
| J90MLCOS 1985  | INTAKE MANIFOLD |
| J90MLCRD 1984  | INTAKE MANIFOLD |
| J90MLCTE 1983  | INTAKE MANIFOLD |
| J90MLCUR 1987  | INTAKE MANIFOLD |
| J90MLEOR 1995  | INTAKE MANIFOLD |
| J90MLERC 1994  | INTAKE MANIFOLD |
| J90TLAEM 1989  | INTAKE MANIFOLD |
| J90TLAIE 1991  | INTAKE MANIFOLD |
| J90TLAND 1992  | INTAKE MANIFOLD |
| J90TLARC 1994  | INTAKE MANIFOLD |
| J90TLASB 1990  | INTAKE MANIFOLD |
| J90TLATS 1993  | INTAKE MANIFOLD |
| J90TLCCA 1988  | INTAKE MANIFOLD |
| J90TLCDC 1986  | INTAKE MANIFOLD |
| J90TLCEM 1989  | INTAKE MANIFOLD |
| J90TLCIH 1981  | INTAKE MANIFOLD |
| J90TLCIM 1981  | INTAKE MANIFOLD |
| J90TLCNB 1982  | INTAKE MANIFOLD |
| J90TLCOS 1985  | INTAKE MANIFOLD |
| J90TLCRD 1984  | INTAKE MANIFOLD |
| J90TLCTE 1983  | INTAKE MANIFOLD |
| J90TLCUR 1987  | INTAKE MANIFOLD |
| J90TLEDA 1996  | INTAKE MANIFOLD |
| J90TLEIE 1991  | INTAKE MANIFOLD |
| J90TLEND 1992  | INTAKE MANIFOLD |
| J90TLEOR 1995  | INTAKE MANIFOLD |
| J90TLERC 1994  | INTAKE MANIFOLD |
| J90TLESB 1990  | INTAKE MANIFOLD |
| J90TLETS 1993  | INTAKE MANIFOLD |
| J90TSLECM 1998 | INTAKE MANIFOLD |
| J90TSLEUA 1997 | INTAKE MANIFOLD |
| J90TXARC 1994  | INTAKE MANIFOLD |
| J90TXATS 1993  | INTAKE MANIFOLD |
| J90TXCDC 1986  | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| J90TXCIH 1981   | INTAKE MANIFOLD |
| J90TXCIM 1981   | INTAKE MANIFOLD |
| J90TXCNB 1982   | INTAKE MANIFOLD |
| J90TXCOS 1985   | INTAKE MANIFOLD |
| J90TXCRD 1984   | INTAKE MANIFOLD |
| J90TXCTE 1983   | INTAKE MANIFOLD |
| SE100WMPLM 1996 | INTAKE MANIFOLD |
| SE100WMPLZ 1997 | INTAKE MANIFOLD |
| SE100WTPLM 1996 | INTAKE MANIFOLD |
| SE100WTPLZ 1997 | INTAKE MANIFOLD |
| SJ100WMPLM 1996 | INTAKE MANIFOLD |
| SJ100WMPLZ 1997 | INTAKE MANIFOLD |
| SJ100WTPLM 1996 | INTAKE MANIFOLD |
| SJ100WTPLZ 1997 | INTAKE MANIFOLD |
| TE110TLCEM 1989 | INTAKE MANIFOLD |
| TE110TLESF 1989 | INTAKE MANIFOLD |
| TE110TXCEM 1989 | INTAKE MANIFOLD |
| TE115TLEIE 1991 | INTAKE MANIFOLD |
| TE115TLEND 1992 | INTAKE MANIFOLD |
| TE115TLESB 1990 | INTAKE MANIFOLD |
| TE115TLETS 1993 | INTAKE MANIFOLD |
| TE150SLCEM 1989 | INTAKE MANIFOLD |
| TE150SLEIE 1991 | INTAKE MANIFOLD |
| TE150SLESB 1990 | INTAKE MANIFOLD |
| TE150TXCEM 1989 | INTAKE MANIFOLD |
| TE90TLCEM 1989  | INTAKE MANIFOLD |
| TE90TLEIE 1991  | INTAKE MANIFOLD |
| TE90TLEND 1992  | INTAKE MANIFOLD |
| TE90TLESB 1990  | INTAKE MANIFOLD |
| TE90TLESF 1989  | INTAKE MANIFOLD |
| TE90TLESF 1990  | INTAKE MANIFOLD |
| TE90TLETS 1993  | INTAKE MANIFOLD |
| TJ110TLCEM 1989 | INTAKE MANIFOLD |
| TJ110TXCEM 1989 | INTAKE MANIFOLD |
| TJ115TLEIE 1991 | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| TJ115TLEND 1992 | INTAKE MANIFOLD |
| TJ115TLESB 1990 | INTAKE MANIFOLD |
| TJ115TLETS 1993 | INTAKE MANIFOLD |
| TJ150SLCEM 1989 | INTAKE MANIFOLD |
| TJ150SLEIE 1991 | INTAKE MANIFOLD |
| TJ150SLESB 1990 | INTAKE MANIFOLD |
| TJ150TXCEM 1989 | INTAKE MANIFOLD |
| TJ90TLCEM 1989  | INTAKE MANIFOLD |
| TJ90TLEIE 1991  | INTAKE MANIFOLD |
| TJ90TLEND 1992  | INTAKE MANIFOLD |
| TJ90TLESB 1990  | INTAKE MANIFOLD |
| TJ90TLETS 1993  | INTAKE MANIFOLD |
| V115SHLETS 1993 | INTAKE MANIFOLD |
| V115SLEIE 1991  | INTAKE MANIFOLD |
| V115SLEND 1992  | INTAKE MANIFOLD |
| V115SLETS 1993  | INTAKE MANIFOLD |
| V90SLEIE 1991   | INTAKE MANIFOLD |
| V90SLEND 1992   | INTAKE MANIFOLD |
| V90SLETE 1993   | INTAKE MANIFOLD |
| VE100SLEIE 1991 | INTAKE MANIFOLD |
| VE100SLEND 1992 | INTAKE MANIFOLD |
| VE100SLESB 1990 | INTAKE MANIFOLD |
| VE100SLETS 1993 | INTAKE MANIFOLD |
| VE115TLEIE 1991 | INTAKE MANIFOLD |
| VE115TLESB 1990 | INTAKE MANIFOLD |
| VE115TLETS 1993 | INTAKE MANIFOLD |
| VE115TXEIE 1991 | INTAKE MANIFOLD |
| VE115TXESB 1990 | INTAKE MANIFOLD |
| VE150SLEIE 1991 | INTAKE MANIFOLD |
| VE150SLESB 1990 | INTAKE MANIFOLD |
| VE150TLEIE 1991 | INTAKE MANIFOLD |
| VE150TLESB 1990 | INTAKE MANIFOLD |
| VE150TXEIE 1991 | INTAKE MANIFOLD |
| VE150TXESB 1990 | INTAKE MANIFOLD |
| VE175SLEID 1991 | INTAKE MANIFOLD |

|                 |                 |
|-----------------|-----------------|
| VE175SLESE 1990 | INTAKE MANIFOLD |
| VE175TXEID 1991 | INTAKE MANIFOLD |
| VE175TXESE 1990 | INTAKE MANIFOLD |
| VE88MSLCCC 1988 | INTAKE MANIFOLD |
| VE88MSLCER 1989 | INTAKE MANIFOLD |
| VE88MSLESA 1990 | INTAKE MANIFOLD |
| VE90MLEIE 1991  | INTAKE MANIFOLD |
| VE90MLEND 1992  | INTAKE MANIFOLD |
| VE90MLESB 1990  | INTAKE MANIFOLD |
| VE90MLETS 1993  | INTAKE MANIFOLD |
| VE90TLEIE 1991  | INTAKE MANIFOLD |
| VE90TLEND 1992  | INTAKE MANIFOLD |
| VE90TLESB 1990  | INTAKE MANIFOLD |
| VE90TLETS 1993  | INTAKE MANIFOLD |
| VJ100SLEIE 1991 | INTAKE MANIFOLD |
| VJ100SLEND 1992 | INTAKE MANIFOLD |
| VJ100SLESB 1990 | INTAKE MANIFOLD |
| VJ100SLETS 1993 | INTAKE MANIFOLD |
| VJ115TLAIE 1991 | INTAKE MANIFOLD |
| VJ115TLAND 1992 | INTAKE MANIFOLD |
| VJ115TLASB 1990 | INTAKE MANIFOLD |
| VJ115TLATS 1993 | INTAKE MANIFOLD |
| VJ115TLEIE 1991 | INTAKE MANIFOLD |
| VJ115TLESB 1990 | INTAKE MANIFOLD |
| VJ115TLETS 1993 | INTAKE MANIFOLD |
| VJ115TXEIE 1991 | INTAKE MANIFOLD |
| VJ115TXESB 1990 | INTAKE MANIFOLD |
| VJ150SLEIE 1991 | INTAKE MANIFOLD |
| VJ150SLESB 1990 | INTAKE MANIFOLD |
| VJ150TLEIE 1991 | INTAKE MANIFOLD |
| VJ150TLESB 1990 | INTAKE MANIFOLD |
| VJ150TXEIE 1991 | INTAKE MANIFOLD |
| VJ150TXESB 1990 | INTAKE MANIFOLD |
| VJ175SLEID 1991 | INTAKE MANIFOLD |
| VJ175SLESE 1990 | INTAKE MANIFOLD |



|                  |                 |
|------------------|-----------------|
| VJ175TXEID 1991  | INTAKE MANIFOLD |
| VJ175TXESE 1990  | INTAKE MANIFOLD |
| VJ88MSLCCC 1988  | INTAKE MANIFOLD |
| VJ88MSLCER 1989  | INTAKE MANIFOLD |
| VJ88MSLESA 1990  | INTAKE MANIFOLD |
| VJ90MLEIE 1991   | INTAKE MANIFOLD |
| VJ90MLEND 1992   | INTAKE MANIFOLD |
| VJ90MLESB 1990   | INTAKE MANIFOLD |
| VJ90MLETS 1993   | INTAKE MANIFOLD |
| VJ90TLAIE 1991   | INTAKE MANIFOLD |
| VJ90TLAND 1992   | INTAKE MANIFOLD |
| VJ90TLASB 1990   | INTAKE MANIFOLD |
| VJ90TLATS 1993   | INTAKE MANIFOLD |
| VJ90TLEIE 1991   | INTAKE MANIFOLD |
| VJ90TLEND 1992   | INTAKE MANIFOLD |
| VJ90TLESB 1990   | INTAKE MANIFOLD |
| VJ90TLETS 1993   | INTAKE MANIFOLD |
| W100WTLM 1988    | INTAKE MANIFOLD |
| W100WTXM 1988    | INTAKE MANIFOLD |
| X155WTLM 1988    | INTAKE MANIFOLD |
| X155WTXM 1988    | INTAKE MANIFOLD |
| XE112TSLEDR 1996 | INTAKE MANIFOLD |
| XE112TSLEOC 1995 | INTAKE MANIFOLD |
| XE112TSLERS 1994 | INTAKE MANIFOLD |
| XE112TSXEDR 1996 | INTAKE MANIFOLD |
| XE112TSXEOC 1995 | INTAKE MANIFOLD |
| XE112TSXERS 1994 | INTAKE MANIFOLD |
| XE115HLECM 1998  | INTAKE MANIFOLD |
| XE115HLEUA 1997  | INTAKE MANIFOLD |
| XE115HXECM 1998  | INTAKE MANIFOLD |
| XE115HXEUA 1997  | INTAKE MANIFOLD |
| XE88TSLEDR 1996  | INTAKE MANIFOLD |
| XE88TSLEOC 1995  | INTAKE MANIFOLD |
| XE88TSLERS 1994  | INTAKE MANIFOLD |
| XE90TSLECM 1998  | INTAKE MANIFOLD |

|                  |                 |
|------------------|-----------------|
| XE90TSLEUA 1997  | INTAKE MANIFOLD |
| XJ112TSLEDR 1996 | INTAKE MANIFOLD |
| XJ112TSLEOC 1995 | INTAKE MANIFOLD |
| XJ112TSLERS 1994 | INTAKE MANIFOLD |
| XJ112TSXEDR 1996 | INTAKE MANIFOLD |
| XJ112TSXEOC 1995 | INTAKE MANIFOLD |
| XJ112TSXERS 1994 | INTAKE MANIFOLD |
| XJ115HLECM 1998  | INTAKE MANIFOLD |
| XJ115HLEUA 1997  | INTAKE MANIFOLD |
| XJ115HXECM 1998  | INTAKE MANIFOLD |
| XJ115HXEUA 1997  | INTAKE MANIFOLD |
| XJ88TSLEDR 1996  | INTAKE MANIFOLD |
| XJ88TSLEOC 1995  | INTAKE MANIFOLD |
| XJ88TSLERS 1994  | INTAKE MANIFOLD |
| XJ90TSLECM 1998  | INTAKE MANIFOLD |
| XJ90TSLEUA 1997  | INTAKE MANIFOLD |