

## Where Used: Part Number 0320679

Model Name	Diagram
50902C 1979	INTAKE MANIFOLD
50903C 1979	INTAKE MANIFOLD
50R79C 1979	INTAKE MANIFOLD
50RL79C 1979	INTAKE MANIFOLD
55642E 1976	INTAKE MANIFOLD
55643E 1976	INTAKE MANIFOLD
55672E 1976	INTAKE MANIFOLD
55673E 1976	INTAKE MANIFOLD
55772D 1977	INTAKE MANIFOLD
55773D 1977	INTAKE MANIFOLD
55874S 1978	INTAKE MANIFOLD
55875S 1978	INTAKE MANIFOLD
55974C 1979	INTAKE MANIFOLD
55975C 1979	INTAKE MANIFOLD
55E76E 1976	INTAKE MANIFOLD
55E77D 1977	INTAKE MANIFOLD
55E78S 1978	INTAKE MANIFOLD
55E79C 1979	INTAKE MANIFOLD
55EL76E 1976	INTAKE MANIFOLD
55EL77D 1977	INTAKE MANIFOLD
55EL78S 1978	INTAKE MANIFOLD
55EL79C 1979	INTAKE MANIFOLD
E40ECRM 1984	INTAKE MANIFOLD
E40ELCRM 1984	INTAKE MANIFOLD
E40RCRM 1984	INTAKE MANIFOLD
E40RLCRM 1984	INTAKE MANIFOLD
E40TECRM 1984	INTAKE MANIFOLD
E40TELCRM 1984	INTAKE MANIFOLD
E50BECIC 1981	INTAKE MANIFOLD
E50BECNR 1982	INTAKE MANIFOLD
E50BECRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BECTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BELCIC 1981	INTAKE MANIFOLD

E50BELCNR 1982	INTAKE MANIFOLD
E50BELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50ECSR 1980	INTAKE MANIFOLD
E50ELCSR 1980	INTAKE MANIFOLD
E50TELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E50TELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50TLCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E55RCIM 1981	INTAKE MANIFOLD
E55RLCSA 1980	INTAKE MANIFOLD
E55TLCIM 1981	INTAKE MANIFOLD
E60ECIA 1981	INTAKE MANIFOLD
E60ECIH 1981	INTAKE MANIFOLD
E60ECNM 1982	INTAKE MANIFOLD
E60ECSR 1980	INTAKE MANIFOLD
E60ECTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E60ELCIA 1981	INTAKE MANIFOLD
E60ELCIH 1981	INTAKE MANIFOLD
E60ELCNM 1982	INTAKE MANIFOLD
E60ELCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E60ELCSR 1980	INTAKE MANIFOLD
E60ELCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E60TLCIA 1981	INTAKE MANIFOLD
E60TLCIH 1981	INTAKE MANIFOLD
E60TLCNM 1982	INTAKE MANIFOLD
E60TLCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E60TLCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J40ECRM 1984	INTAKE MANIFOLD
J40ELCRM 1984	INTAKE MANIFOLD
J40RCRM 1984	INTAKE MANIFOLD
J40RLCRM 1984	INTAKE MANIFOLD
J40TECRM 1984	INTAKE MANIFOLD
J40TELCRM 1984	INTAKE MANIFOLD
J50BECIC 1981	INTAKE MANIFOLD
J50BECNR 1982	INTAKE MANIFOLD

J50BECRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BECTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BELCIC 1981	INTAKE MANIFOLD
J50BELCNR 1982	INTAKE MANIFOLD
J50BELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50ECSR 1980	INTAKE MANIFOLD
J50ELCSR 1980	INTAKE MANIFOLD
J50TELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J50TELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50TLCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J55RCIM 1981	INTAKE MANIFOLD
J55RLCIM 1981	INTAKE MANIFOLD
J55RLCSA 1980	INTAKE MANIFOLD
J60ECIA 1981	INTAKE MANIFOLD
J60ECIH 1981	INTAKE MANIFOLD
J60ECNM 1982	INTAKE MANIFOLD
J60ECSR 1980	INTAKE MANIFOLD
J60ECTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J60ELCIA 1981	INTAKE MANIFOLD
J60ELCIH 1981	INTAKE MANIFOLD
J60ELCNM 1982	INTAKE MANIFOLD
J60ELCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J60ELCSR 1980	INTAKE MANIFOLD
J60ELCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J60TLCIA 1981	INTAKE MANIFOLD
J60TLCIH 1981	INTAKE MANIFOLD
J60TLCNM 1982	INTAKE MANIFOLD
J60TLCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J60TLCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM