

Where Used: Part Number 0320978

Model Name	Diagram
20/35HP	REMOTE ELECTRIC START KIT
25904R 1979	CARBURETOR
25905R 1979	CARBURETOR
25952R 1979	CARBURETOR
25953R 1979	CARBURETOR
25E79R 1979	CARBURETOR
25EL79R 1979	CARBURETOR
25R79R 1979	CARBURETOR
25RL79R 1979	CARBURETOR
35902A 1979	CARBURETOR
35903A 1979	CARBURETOR
35952A 1979	CARBURETOR
35953A 1979	CARBURETOR
35E79A 1979	CARBURETOR
35EL79A 1979	CARBURETOR
35R79A 1979	CARBURETOR
35RL79A 1979	CARBURETOR
50902C 1979	INTAKE MANIFOLD
50903C 1979	INTAKE MANIFOLD
50R79C 1979	INTAKE MANIFOLD
50RL79C 1979	INTAKE MANIFOLD
55642E 1976	INTAKE MANIFOLD
55643E 1976	INTAKE MANIFOLD
55672E 1976	INTAKE MANIFOLD
55673E 1976	INTAKE MANIFOLD
55772D 1977	INTAKE MANIFOLD
55773D 1977	INTAKE MANIFOLD
55874S 1978	INTAKE MANIFOLD
55875S 1978	INTAKE MANIFOLD
55974C 1979	INTAKE MANIFOLD
55975C 1979	INTAKE MANIFOLD
55E76E 1976	INTAKE MANIFOLD
55E77D 1977	INTAKE MANIFOLD

55E78S 1978	INTAKE MANIFOLD
55E79C 1979	INTAKE MANIFOLD
55EL76E 1976	INTAKE MANIFOLD
55EL77D 1977	INTAKE MANIFOLD
55EL78S 1978	INTAKE MANIFOLD
55EL79C 1979	INTAKE MANIFOLD
AM55RSLD 1999	REWIND STARTER
BE40EECR 1998	REWIND STARTER
BE40EEDS 1996	REWIND STARTER
BE40EEUC 1997	REWIND STARTER
BE40LECR 1998	REWIND STARTER
BE40LEDS 1996	REWIND STARTER
BE40LEUC 1997	REWIND STARTER
BE40TLECR 1998	REWIND STARTER
BE40TLEDS 1996	REWIND STARTER
BE40TLEUC 1997	REWIND STARTER
BE50BEEDS 1996	REWIND STARTER
BE50BELEDS 1996	REWIND STARTER
BE50ESECC 1998	REWIND STARTER
BE50RLECR 1998	REWIND STARTER
BE50RLEUC 1997	REWIND STARTER
BE50TLECR 1998	REWIND STARTER
BE50TLEDS 1996	REWIND STARTER
BE50TLEUC 1997	REWIND STARTER
BE50TSLECC 1998	REWIND STARTER
BE50TSLEUS 1997	REWIND STARTER
BJ40EECR 1998	REWIND STARTER
BJ40EEDS 1996	REWIND STARTER
BJ40EEEA 1999	REWIND STARTER
BJ40EEUC 1997	REWIND STARTER
BJ40LECR 1998	REWIND STARTER
BJ40LEDS 1996	REWIND STARTER
BJ40LEEA 1999	REWIND STARTER
BJ40LEUC 1997	REWIND STARTER
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	REWIND STARTER

BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	REWIND STARTER
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	REWIND STARTER
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	REWIND STARTER
BJ40PLEEA 1999	REWIND STARTER
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	REWIND STARTER
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	REWIND STARTER
BJ40TLECR 1998	REWIND STARTER
BJ40TLEDS 1996	REWIND STARTER
BJ40TLEUC 1997	REWIND STARTER
BJ50BEEEDS 1996	REWIND STARTER
BJ50BELEDS 1996	REWIND STARTER
BJ50EEER 1999	REWIND STARTER
BJ50ELEER 1999	REWIND STARTER
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	REWIND STARTER
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	REWIND STARTER
BJ50ESECC 1998	REWIND STARTER
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	REWIND STARTER
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	REWIND STARTER
BJ50PLEEA 1999	REWIND STARTER
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	REWIND STARTER
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	REWIND STARTER
BJ50RLECR 1998	REWIND STARTER
BJ50RLEEA 1999	REWIND STARTER
BJ50RLEUC 1997	REWIND STARTER
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	REWIND STARTER
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	REWIND STARTER
BJ50TLECR 1998	REWIND STARTER
BJ50TLEDS 1996	REWIND STARTER
BJ50TLEUC 1997	REWIND STARTER
BJ50TSLECC 1998	REWIND STARTER
BJ50TSLEUS 1997	REWIND STARTER
C155WTLM 1988	REMOTE CONTROL
C155WTXM 1988	REMOTE CONTROL
CE275TLCDC 1986	REMOTE CONTROL

CE275TXCDC 1986	REMOTE CONTROL
CE300TLCDC 1986	REMOTE CONTROL
CE300TXCDC 1986	REMOTE CONTROL
CJ275TLCDC 1986	REMOTE CONTROL
CJ275TXCDC 1986	REMOTE CONTROL
CJ300TLCDC 1986	REMOTE CONTROL
CJ300TXCDC 1986	REMOTE CONTROL
D100WTLM 1988	REMOTE CONTROL
D100WTXM 1988	REMOTE CONTROL
E100STLCCA 1988	REMOTE CONTROL
E100STLCEM 1989	REMOTE CONTROL
E100STLESB 1990	REMOTE CONTROL
E100WMLCDR 1986	REMOTE CONTROL
E100WTLCDR 1986	REMOTE CONTROL
E100WTLCUA 1987	REMOTE CONTROL
E100WTLESM 1990	REMOTE CONTROL
E100WTLZ 1989	REMOTE CONTROL
E100WTXCDR 1986	REMOTE CONTROL
E100WTXCUA 1987	REMOTE CONTROL
E100WTXESM 1990	REMOTE CONTROL
E100WTXZ 1989	REMOTE CONTROL
E10EEESC 1990	REMOTE CONTROL
E10ELESC 1990	REMOTE CONTROL
E10RELESC 1990	REMOTE CONTROL
E10RESC 1990	REMOTE CONTROL
E10RLESC 1990	REMOTE CONTROL
E10SELESC 1990	REMOTE CONTROL
E110MLCCA 1988	REMOTE CONTROL
E110MLCDC 1986	REMOTE CONTROL
E110MLCEM 1989	REMOTE CONTROL
E110MLCUR 1987	REMOTE CONTROL
E110TLCCA 1988	REMOTE CONTROL
E110TLCDC 1986	REMOTE CONTROL
E110TLCDF 1986	REMOTE CONTROL
E110TLCEM 1989	REMOTE CONTROL

E110TLCUR 1987	REMOTE CONTROL
E110TXCCA 1988	REMOTE CONTROL
E110TXCEM 1989	REMOTE CONTROL
E110TXCUR 1987	REMOTE CONTROL
E115MLESB 1990	REMOTE CONTROL
E115TLESB 1990	REMOTE CONTROL
E115TXESB 1990	REMOTE CONTROL
E120TLCCA 1988	REMOTE CONTROL
E120TLCDC 1986	REMOTE CONTROL
E120TLCEM 1989	REMOTE CONTROL
E120TLCUR 1987	REMOTE CONTROL
E120TLESB 1990	REMOTE CONTROL
E120TXCCA 1988	REMOTE CONTROL
E120TXCDC 1986	REMOTE CONTROL
E120TXCEM 1989	REMOTE CONTROL
E120TXCUR 1987	REMOTE CONTROL
E120TXESB 1990	REMOTE CONTROL
E125ESXESS 1990	REMOTE CONTROL
E125ESXW 1989	REMOTE CONTROL
E125WTPLE 1995	REMOTE CONTROL
E140CXCCS 1988	REMOTE CONTROL
E140CXCEC 1989	REMOTE CONTROL
E140CXESR 1990	REMOTE CONTROL
E140TLCCM 1988	REMOTE CONTROL
E140TLCDC 1986	REMOTE CONTROL
E140TLCEB 1989	REMOTE CONTROL
E140TLCUA 1987	REMOTE CONTROL
E140TLESE 1990	REMOTE CONTROL
E140TXCCM 1988	REMOTE CONTROL
E140TXCDC 1986	REMOTE CONTROL
E140TXCEB 1989	REMOTE CONTROL
E140TXCUA 1987	REMOTE CONTROL
E140TXESE 1990	REMOTE CONTROL
E150CXCCA 1988	REMOTE CONTROL
E150CXCEM 1989	REMOTE CONTROL

E150CXESB 1990	REMOTE CONTROL
E150STLCCA 1988	REMOTE CONTROL
E150STLCDC 1986	REMOTE CONTROL
E150STLCEM 1989	REMOTE CONTROL
E150STLCUR 1987	REMOTE CONTROL
E150STLESB 1990	REMOTE CONTROL
E150TLCCA 1988	REMOTE CONTROL
E150TLCDC 1986	REMOTE CONTROL
E150TLCEM 1989	REMOTE CONTROL
E150TLCUR 1987	REMOTE CONTROL
E150TLESB 1990	REMOTE CONTROL
E150TXCCA 1988	REMOTE CONTROL
E150TXCDC 1986	REMOTE CONTROL
E150TXCEM 1989	REMOTE CONTROL
E150TXCUR 1987	REMOTE CONTROL
E150TXESB 1990	REMOTE CONTROL
E150WTLEOR 1995	REMOTE CONTROL
E150WTLERC 1994	REMOTE CONTROL
E150WTLERV 1994	REMOTE CONTROL
E150WTLETG 1993	REMOTE CONTROL
E150WTLETS 1993	REMOTE CONTROL
E150WTXEOR 1995	REMOTE CONTROL
E150WTXERC 1994	REMOTE CONTROL
E150WTXERV 1994	REMOTE CONTROL
E150WTXETG 1993	REMOTE CONTROL
E150WTXETS 1993	REMOTE CONTROL
E155WTLCDR 1986	REMOTE CONTROL
E155WTLCUA 1987	REMOTE CONTROL
E155WTLESM 1990	REMOTE CONTROL
E155WTLZ 1989	REMOTE CONTROL
E155WTXCDR 1986	REMOTE CONTROL
E155WTXCUA 1987	REMOTE CONTROL
E155WTXESM 1990	REMOTE CONTROL
E155WTXZ 1989	REMOTE CONTROL
E15EESR 1990	REMOTE CONTROL

E15ELESR 1990	REMOTE CONTROL
E15RELESR 1990	REMOTE CONTROL
E15RESR 1990	REMOTE CONTROL
E15RLESR 1990	REMOTE CONTROL
E175STLCCM 1988	REMOTE CONTROL
E175STLCEB 1989	REMOTE CONTROL
E175STLESE 1990	REMOTE CONTROL
E175TLCCM 1988	REMOTE CONTROL
E175TLCDR 1986	REMOTE CONTROL
E175TLCUA 1987	REMOTE CONTROL
E175TXCCM 1988	REMOTE CONTROL
E175TXCDR 1986	REMOTE CONTROL
E175TXCEB 1989	REMOTE CONTROL
E175TXCUA 1987	REMOTE CONTROL
E175TXESE 1990	REMOTE CONTROL
E185ESXESS 1990	REMOTE CONTROL
E185ESXW 1989	REMOTE CONTROL
E200CXCCR 1988	REMOTE CONTROL
E200CXCEA 1989	REMOTE CONTROL
E200CXESM 1990	REMOTE CONTROL
E200STLCCM 1988	REMOTE CONTROL
E200STLCEB 1989	REMOTE CONTROL
E200STLCUA 1987	REMOTE CONTROL
E200STLESE 1990	REMOTE CONTROL
E200TXCCR 1988	REMOTE CONTROL
E200TXCEA 1989	REMOTE CONTROL
E200TXCUC 1987	REMOTE CONTROL
E200TXESM 1990	REMOTE CONTROL
E20CRCCA 1988	REMOTE CONTROL
E20CRCDC 1986	REMOTE CONTROL
E20CRCUR 1987	REMOTE CONTROL
E20CRLCCA 1988	REMOTE CONTROL
E20CRLCDC 1986	REMOTE CONTROL
E20CRLCUR 1987	REMOTE CONTROL
E20ECCA 1988	REMOTE CONTROL

E20ECDC 1986	REMOTE CONTROL
E20ECEM 1989	REMOTE CONTROL
E20ECUR 1987	REMOTE CONTROL
E20EESB 1990	REMOTE CONTROL
E20ELCCA 1988	REMOTE CONTROL
E20ELCDC 1986	REMOTE CONTROL
E20ELCEM 1989	REMOTE CONTROL
E20ELCUR 1987	REMOTE CONTROL
E20ELESB 1990	REMOTE CONTROL
E20TECDC 1986	REMOTE CONTROL
E225CLCUB 1987	REMOTE CONTROL
E225CXCCCE 1988	REMOTE CONTROL
E225CXCCED 1989	REMOTE CONTROL
E225CXCCUB 1987	REMOTE CONTROL
E225CXCESS 1990	REMOTE CONTROL
E225PLCCCE 1988	REMOTE CONTROL
E225PLCCED 1989	REMOTE CONTROL
E225PLCCUB 1987	REMOTE CONTROL
E225PLESS 1990	REMOTE CONTROL
E225PXCCCE 1988	REMOTE CONTROL
E225PXCCED 1989	REMOTE CONTROL
E225PXCCUB 1987	REMOTE CONTROL
E225PXCESS 1990	REMOTE CONTROL
E225TLCCCE 1988	REMOTE CONTROL
E225TLCCED 1989	REMOTE CONTROL
E225TLCCUB 1987	REMOTE CONTROL
E225TLESS 1990	REMOTE CONTROL
E225TXCCCE 1988	REMOTE CONTROL
E225TXCCED 1989	REMOTE CONTROL
E225TXCCUB 1987	REMOTE CONTROL
E225TXCESS 1990	REMOTE CONTROL
E25ECCM 1988	REMOTE CONTROL
E25ECDR 1986	REMOTE CONTROL
E25ECEB 1989	REMOTE CONTROL
E25ECIB 1981	CARBURETOR

E25ECIM 1981	CARBURETOR
E25ECUA 1987	REMOTE CONTROL
E25EESE 1990	REMOTE CONTROL
E25ELCCM 1988	REMOTE CONTROL
E25ELCDR 1986	REMOTE CONTROL
E25ELCEB 1989	REMOTE CONTROL
E25ELCIB 1981	CARBURETOR
E25ELCIM 1981	CARBURETOR
E25ELCUA 1987	REMOTE CONTROL
E25ELESE 1990	REMOTE CONTROL
E25RCCA 1988	REMOTE CONTROL
E25RCDC 1986	REMOTE CONTROL
E25RCIM 1981	CARBURETOR
E25RCSA 1980	CARBURETOR
E25RCUR 1987	REMOTE CONTROL
E25RLCCA 1988	REMOTE CONTROL
E25RLCDC 1986	REMOTE CONTROL
E25RLCIM 1981	CARBURETOR
E25RLCSA 1980	CARBURETOR
E25RLCUR 1987	REMOTE CONTROL
E25RSA 1981	CARBURETOR
E25RSLA 1981	CARBURETOR
E25RWCIM 1981	CARBURETOR
E25RWLCIM 1981	CARBURETOR
E25TECCA 1988	REMOTE CONTROL
E25TECDC 1986	REMOTE CONTROL
E25TECIM 1981	CARBURETOR
E25TECSA 1980	CARBURETOR
E25TECUR 1987	REMOTE CONTROL
E25TELCCA 1988	REMOTE CONTROL
E25TELCDC 1986	REMOTE CONTROL
E25TELCIM 1981	CARBURETOR
E25TELCSA 1980	CARBURETOR
E25TELCUR 1987	REMOTE CONTROL
E275CLCUR 1987	REMOTE CONTROL

E275CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275CXCUR 1987	REMOTE CONTROL
E275PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275PLCUR 1987	REMOTE CONTROL
E275PTLCDC 1986	REMOTE CONTROL
E275PTXCDC 1986	REMOTE CONTROL
E275PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275PXCUR 1987	REMOTE CONTROL
E28ESLCEA 1989	REMOTE CONTROL
E28ESLESM 1990	REMOTE CONTROL
E300CLCUR 1987	REMOTE CONTROL
E300CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300CXCEM 1989	REMOTE CONTROL
E300CXCUR 1987	REMOTE CONTROL
E300CXESB 1990	REMOTE CONTROL
E300PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300PLCEM 1989	REMOTE CONTROL
E300PLCUR 1987	REMOTE CONTROL
E300PLESB 1990	REMOTE CONTROL
E300PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300PXCEM 1989	REMOTE CONTROL
E300PXCUR 1987	REMOTE CONTROL
E300PXESB 1990	REMOTE CONTROL
E300TLCDC 1986	REMOTE CONTROL
E300TXCDC 1986	REMOTE CONTROL
E30ECCE 1988	REMOTE CONTROL
E30ECDM 1986	REMOTE CONTROL
E30ECED 1989	REMOTE CONTROL
E30ECUB 1987	REMOTE CONTROL
E30EESS 1990	REMOTE CONTROL
E30ELCCE 1988	REMOTE CONTROL
E30ELCDM 1986	REMOTE CONTROL
E30ELCED 1989	REMOTE CONTROL
E30ELCUB 1987	REMOTE CONTROL
E30ELESS 1990	REMOTE CONTROL

E30RCCE 1988	REMOTE CONTROL
E30RCDM 1986	REMOTE CONTROL
E30RCUB 1987	REMOTE CONTROL
E30RLCCE 1988	REMOTE CONTROL
E30RLCDM 1986	REMOTE CONTROL
E30RLCUB 1987	REMOTE CONTROL
E30TECCE 1988	REMOTE CONTROL
E30TECDM 1986	REMOTE CONTROL
E30TECUB 1987	REMOTE CONTROL
E30TELCCE 1988	REMOTE CONTROL
E30TELCDM 1986	REMOTE CONTROL
E30TELCUB 1987	REMOTE CONTROL
E35AELCDE 1986	REMOTE CONTROL
E35AELCUD 1987	REMOTE CONTROL
E35ARLCDE 1986	REMOTE CONTROL
E35ARLCUD 1987	REMOTE CONTROL
E35ECIG 1981	CARBURETOR
E35ECSM 1980	CARBURETOR
E35ELCIG 1981	CARBURETOR
E35ELCSM 1980	CARBURETOR
E35RCCE 1988	REMOTE CONTROL
E35RCDM 1986	REMOTE CONTROL
E35RCIG 1981	CARBURETOR
E35RCUB 1987	REMOTE CONTROL
E35RLCCE 1988	REMOTE CONTROL
E35RLCDM 1986	REMOTE CONTROL
E35RLCIG 1981	CARBURETOR
E35RLCUB 1987	REMOTE CONTROL
E35TCSM 1980	CARBURETOR
E35TLESM 1980	CARBURETOR
E40AELCCS 1988	REMOTE CONTROL
E40ARLCCS 1988	REMOTE CONTROL
E40ATLCCS 1988	REMOTE CONTROL
E40ECCS 1988	REMOTE CONTROL
E40ECDE 1986	REMOTE CONTROL

E40ECEC 1989	REMOTE CONTROL
E40ECRM 1984	INTAKE MANIFOLD
E40ECUD 1987	REMOTE CONTROL
E40EEOD 1995	REWIND STARTER
E40EERE 1994	REWIND STARTER
E40EESR 1990	REMOTE CONTROL
E40ELCCS 1988	REMOTE CONTROL
E40ELCDE 1986	REMOTE CONTROL
E40ELCEC 1989	REMOTE CONTROL
E40ELCRM 1984	INTAKE MANIFOLD
E40ELCUD 1987	REMOTE CONTROL
E40ELECR 1998	REWIND STARTER
E40ELEDs 1996	REWIND STARTER
E40ELEOD 1995	REWIND STARTER
E40ELERE 1994	REWIND STARTER
E40ELESR 1990	REMOTE CONTROL
E40ELEUC 1997	REWIND STARTER
E40JRECA 1998	REWIND STARTER
E40JREDC 1996	REWIND STARTER
E40JREOS 1995	REWIND STARTER
E40JREUR 1997	REWIND STARTER
E40RCCS 1988	REMOTE CONTROL
E40RCDE 1986	REMOTE CONTROL
E40RCEC 1989	REMOTE CONTROL
E40RCRM 1984	INTAKE MANIFOLD
E40RCUD 1987	REMOTE CONTROL
E40RECR 1998	REWIND STARTER
E40REDS 1996	REWIND STARTER
E40REOD 1995	REWIND STARTER
E40RERE 1994	REWIND STARTER
E40RESR 1990	REMOTE CONTROL
E40REUC 1997	REWIND STARTER
E40RLCCS 1988	REMOTE CONTROL
E40RLCDE 1986	REMOTE CONTROL
E40RLCEC 1989	REMOTE CONTROL

E40RLCRM 1984	INTAKE MANIFOLD
E40RLCUD 1987	REMOTE CONTROL
E40RLECR 1998	REWIND STARTER
E40RLEDS 1996	REWIND STARTER
E40RLEOD 1995	REWIND STARTER
E40RLERE 1994	REWIND STARTER
E40RLESR 1990	REMOTE CONTROL
E40RLEUC 1997	REWIND STARTER
E40TECCS 1988	REMOTE CONTROL
E40TECDE 1986	REMOTE CONTROL
E40TECEC 1989	REMOTE CONTROL
E40TECRM 1984	INTAKE MANIFOLD
E40TECUD 1987	REMOTE CONTROL
E40TEECR 1998	REWIND STARTER
E40TEEDS 1996	REWIND STARTER
E40TEEOD 1995	REWIND STARTER
E40TEERE 1994	REWIND STARTER
E40TEESR 1990	REMOTE CONTROL
E40TEEUC 1997	REWIND STARTER
E40TELCCS 1988	REMOTE CONTROL
E40TELCDE 1986	REMOTE CONTROL
E40TELCEC 1989	REMOTE CONTROL
E40TELCRM 1984	INTAKE MANIFOLD
E40TELECR 1998	REWIND STARTER
E40TELEDS 1996	REWIND STARTER
E40TELEOD 1995	REWIND STARTER
E40TELERE 1994	REWIND STARTER
E40TELESR 1990	REMOTE CONTROL
E40TELEUC 1997	REWIND STARTER
E40TLCCS 1988	REMOTE CONTROL
E40TLCDE 1986	REMOTE CONTROL
E40TLCEC 1989	REMOTE CONTROL
E40TLCUD 1987	REMOTE CONTROL
E40TLECR 1998	REWIND STARTER
E40TLEDS 1996	REWIND STARTER

E40TLEOD 1995	REWIND STARTER
E40TLERE 1994	REWIND STARTER
E40TLESR 1990	REMOTE CONTROL
E40TLEUC 1997	REWIND STARTER
E40TTLCCS 1988	REMOTE CONTROL
E40TTLCEC 1989	REMOTE CONTROL
E40TTLECR 1998	REWIND STARTER
E40TTLEDS 1996	REWIND STARTER
E40TTLEOD 1995	REWIND STARTER
E40TTLERE 1994	REWIND STARTER
E40TTLESR 1990	REMOTE CONTROL
E40TTLEUC 1997	REWIND STARTER
E40WREES 1999	REWIND STARTER
E40WRLEES 1999	REWIND STARTER
E40WRLSIR commercial, rope start, 20 in shaft 2001	REWIND STARTER
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
E40WRSIR commercial, rope start, 15 in shaft 2001	REWIND STARTER
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
E40WRYEES 1999	REWIND STARTER
E40WRYSIR commercial, rope start, 25 in shaft 2001	REWIND STARTER
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	REWIND STARTER
E45RCE 1989	REMOTE CONTROL - ELECTRIC START
E45RCEIA 1991	REMOTE CONTROL
E45RCENM 1992	REMOTE CONTROL
E45RCEOD 1995	REWIND STARTER
E45RCERE 1994	REWIND STARTER
E45RCESR 1990	REMOTE CONTROL
E45RCLE 1989	REMOTE CONTROL - ELECTRIC START
E45RCLEDS 1996	REWIND STARTER
E45RCLEIA 1991	REMOTE CONTROL
E45RCLENM 1992	REMOTE CONTROL
E45RCLEOD 1995	REWIND STARTER
E45RCLERE 1994	REWIND STARTER
E45RCLESR 1990	REMOTE CONTROL

E45RCLEUC 1997	REWIND STARTER
E45WMLE 1989	REMOTE CONTROL - ELECTRIC START
E45WMLEIA 1991	REMOTE CONTROL
E45WMLENM 1992	REMOTE CONTROL
E45WMLSR 1990	REMOTE CONTROL
E48ESLCCC 1988	REMOTE CONTROL
E48ESLCER 1989	REMOTE CONTROL (CONTINUED)
E48ESLESA 1990	REMOTE CONTROL
E50BECCS 1988	REMOTE CONTROL
E50BECDE 1986	REMOTE CONTROL
E50BECEC 1989	REMOTE CONTROL
E50BECIC 1981	INTAKE MANIFOLD
E50BECNR 1982	INTAKE MANIFOLD
E50BECRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BECTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BECUD 1987	REMOTE CONTROL
E50BEEOD 1995	REWIND STARTER
E50BEERE 1994	REWIND STARTER
E50BEESR 1990	REMOTE CONTROL
E50BELCCS 1988	REMOTE CONTROL
E50BELCDE 1986	REMOTE CONTROL
E50BELCEC 1989	REMOTE CONTROL
E50BELCIC 1981	INTAKE MANIFOLD
E50BELCNR 1982	INTAKE MANIFOLD
E50BELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BELCUD 1987	REMOTE CONTROL
E50BELEOD 1995	REWIND STARTER
E50BELERE 1994	REWIND STARTER
E50BELESR 1990	REMOTE CONTROL
E50ECSR 1980	INTAKE MANIFOLD
E50ELCSR 1980	INTAKE MANIFOLD
E50ESLECC 1998	REWIND STARTER
E50ESLEUR 1997	REWIND STARTER
E50JEDS 1996	REWIND STARTER

E50JEOD 1995	REWIND STARTER
E50JERE 1994	REWIND STARTER
E50JEUC 1997	REWIND STARTER
E50RNLIA 1990	REMOTE CONTROL
E50TELCCS 1988	REMOTE CONTROL
E50TELCDE 1986	REMOTE CONTROL
E50TELCEC 1989	REMOTE CONTROL
E50TELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E50TELCCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50TELCUD 1987	REMOTE CONTROL
E50TELEOD 1995	REWIND STARTER
E50TELERE 1994	REWIND STARTER
E50TELESR 1990	REMOTE CONTROL
E50TLCCS 1988	REMOTE CONTROL
E50TLCDE 1986	REMOTE CONTROL
E50TLCEC 1989	REMOTE CONTROL
E50TLCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E50TLCUD 1987	REMOTE CONTROL
E50TLECR 1998	REWIND STARTER
E50TLEDS 1996	REWIND STARTER
E50TLEOD 1995	REWIND STARTER
E50TLERE 1994	REWIND STARTER
E50TLESR 1990	REMOTE CONTROL
E50TLEUC 1997	REWIND STARTER
E50TSLECC 1998	REWIND STARTER
E50TSLEUS 1997	REWIND STARTER
E55RCIM 1981	INTAKE MANIFOLD
E55RLCSA 1980	INTAKE MANIFOLD
E55RSLC 1997	REWIND STARTER
E55RSLG 1995	REWIND STARTER
E55RSLW 1996	REWIND STARTER
E55RWLE 1989	REMOTE CONTROL - ELECTRIC START
E55RWLEIA 1991	REMOTE CONTROL
E55RWLENM 1992	REMOTE CONTROL
E55RWLERE 1994	REWIND STARTER

E55RWLESR 1990	REMOTE CONTROL
E55TLCIM 1981	INTAKE MANIFOLD
E55WREES 1999	REWIND STARTER
E55WRLEES 1999	REWIND STARTER
E55WRLSIR commercial, rope start, 20 in shaft 2001	REWIND STARTER
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	REWIND STARTER
E55WRSIR commercial, rope start, 15 in shaft 2001	REWIND STARTER
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
E55WRYEES 1999	REWIND STARTER
E55WRYSIR commercial, rope start, 25 in shaft 2001	REWIND STARTER
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	REWIND STARTER
E60ECIA 1981	INTAKE MANIFOLD
E60ECIH 1981	INTAKE MANIFOLD
E60ECNM 1982	INTAKE MANIFOLD
E60ECSR 1980	INTAKE MANIFOLD
E60ECTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E60ELCCR 1988	REMOTE CONTROL
E60ELCDS 1986	REMOTE CONTROL
E60ELCEA 1989	REMOTE CONTROL
E60ELCIA 1981	INTAKE MANIFOLD
E60ELCIH 1981	INTAKE MANIFOLD
E60ELCNM 1982	INTAKE MANIFOLD
E60ELCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
E60ELCSR 1980	INTAKE MANIFOLD
E60ELCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E60ELCUC 1987	REMOTE CONTROL
E60ELES 1990	REMOTE CONTROL
E60TLCCR 1988	REMOTE CONTROL
E60TLCDS 1986	REMOTE CONTROL
E60TLCEA 1989	REMOTE CONTROL
E60TLCIA 1981	INTAKE MANIFOLD
E60TLCIH 1981	INTAKE MANIFOLD
E60TLCNM 1982	INTAKE MANIFOLD
E60TLCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM

E60TLCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E60TLCUC 1987	REMOTE CONTROL
E60TLESM 1990	REMOTE CONTROL
E60TTLCCR 1988	REMOTE CONTROL
E60TTLCEA 1989	REMOTE CONTROL
E60TTLESM 1990	REMOTE CONTROL
E65RSLC 1995	REWIND STARTER
E65RSLM 1996	REWIND STARTER
E65RSLZ2 1997	REWIND STARTER
E65WMLCDR 1986	REMOTE CONTROL
E65WMLCOC 1985	REMOTE CONTROL
E65WMLCUA 1987	REMOTE CONTROL
E65WMLESM 1990	REMOTE CONTROL
E65WMLZ 1989	REMOTE CONTROL
E65WRLEEO 1999	REWIND STARTER
E65WRLEES 1999	REWIND STARTER
E65WRLSIR commercial, rope start, 20 in shaft 2001	REWIND STARTER
E65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	REWIND STARTER
E65WRYEEO 1999	REWIND STARTER
E65WRYEES 1999	REWIND STARTER
E65WRYSIR commercial, rope start, 22.5 in shaft 2001	REWIND STARTER
E65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	REWIND STARTER
E65WTLCOC 1985	REMOTE CONTROL
E70ELCCA 1988	REMOTE CONTROL
E70ELCDC 1986	REMOTE CONTROL
E70ELCEM 1989	REMOTE CONTROL
E70ELCUR 1987	REMOTE CONTROL
E70ELESB 1990	REMOTE CONTROL
E70TLCCA 1988	REMOTE CONTROL
E70TLCDC 1986	REMOTE CONTROL
E70TLCEM 1989	REMOTE CONTROL
E70TLCUR 1987	REMOTE CONTROL
E70TLESB 1990	REMOTE CONTROL
E75ECCA 1988	REMOTE CONTROL

E75ECDC 1986	REMOTE CONTROL
E75ECUR 1987	REMOTE CONTROL
E88MSLCCC 1988	REMOTE CONTROL
E88MSLCER 1989	REMOTE CONTROL
E88MSLESA 1990	REMOTE CONTROL
E90MLCDC 1986	REMOTE CONTROL
E90MLCUR 1987	REMOTE CONTROL
E90TLCCA 1988	REMOTE CONTROL
E90TLCDC 1986	REMOTE CONTROL
E90TLCEM 1989	REMOTE CONTROL
E90TLCUR 1987	REMOTE CONTROL
E90TLESB 1990	REMOTE CONTROL
E90TXCDC 1986	REMOTE CONTROL
ELECTRICAL	REMOTE START KIT - 25,30 HP (2-Stroke)
ELECTRICAL 1980	REMOTE ELECTRIC STARTING KIT 25 MODELS
ELECTRICAL 1981	REMOTE ELECTRIC STARTING KIT
ELECTRICAL 1982	REMOTE ELECTRIC STARTING KIT
ELECTRICAL 1983	REMOTE ELECTRIC STARTING KIT 25 MODELS
ELECTRICAL 1985	REMOTE ELECTRIC STARTING KIT - 25 & 30TE
ELECTRICAL 1986	REMOTE ELECTRIC STARTING KIT - 25 & 30TE
ELECTRICAL 1987	REMOTE ELECTRIC STARTING KIT - 25 & 30TE
ELECTRICAL 1988	REMOTE ELECTRIC STARTING KIT 25, 30, 35 TE
ELECTRICAL 1989	REMOTE ELECTRIC STARTING KIT 20, 25, 30, 35TE
ELECTRICAL 1990	REMOTE ELECTRIC START KIT 20, 25, 30 & 35 ROPE, TE MODELS
ELECTRICAL 1991	REMOTE ELECTRIC START KIT 20, 25, 30 & 35 ROPE, TE MODELS
ELECTRICAL 1992	REMOTE ELECTRIC START KIT 20, 25, 30 & 35 ROPE, TE MODELS
ELECTRICAL 1993	REMOTE ELECTRIC START KIT 20, 25, 30 & 35 ROPE, TE MODELS
ELECTRICAL 1994	REMOTE ELECTRIC START KIT 20, 25, 30 & 35 ROPE, TE MODELS
ELECTRICAL 1995	REMOTE ELECTRIC START KIT 20,25,30,35 ROPE & TE (2-CYL)
ELECTRICAL 1996	REMOTE ELEC. START KIT 20, 25, 30, & 35 ROPE & TE (2-CYL.)
ELECTRICAL 1997	REMOTE ELECTRIC START KIT 20, 25, 30, 35 ROPE & TE (2-CYL)
ELECTRICAL 1998	REMOTE ELECTRIC START KIT 20/25/30/35 ROPE, TE MODELS-2-CYL.
ELECTRICAL 1999	REMOTE ELECTRIC START KIT 20, 25, 30, & 35 ROPE & TE MODELS (2-CYL)
ELECTRICAL 2000	REMOTE ELECTRIC START KIT - 20, 25, 30, & 35 ROPE & TE MODELS (2-CYLINDER)

HE40REDS 1996	REWIND STARTER
HE40REUC 1997	REWIND STARTER
HE40RLEDS 1996	REWIND STARTER
HE40RLEUC 1997	REWIND STARTER
HE45RCLEDS 1996	REWIND STARTER
HE45RCLEUC 1997	REWIND STARTER
HE55RSLC 1997	REWIND STARTER
HE55RSLW 1996	REWIND STARTER
HE55WMLM 1996	REMOTE CONTROL
HJ40REDS 1996	REWIND STARTER
HJ40REUC 1997	REWIND STARTER
HJ40RLEDS 1996	REWIND STARTER
HJ40RLEUC 1997	REWIND STARTER
HJ45RCLEDS 1996	REWIND STARTER
HJ45RCLEUC 1997	REWIND STARTER
HJ55RSLC 1997	REWIND STARTER
HJ55RSLW 1996	REWIND STARTER
HJ55WMLM 1996	REMOTE CONTROL
J100STLCCA 1988	REMOTE CONTROL
J100STLCEM 1989	REMOTE CONTROL
J100STLESB 1990	REMOTE CONTROL
J100WMLCDR 1986	REMOTE CONTROL
J100WTLCDR 1986	REMOTE CONTROL
J100WTLCUA 1987	REMOTE CONTROL
J100WTLESM 1990	REMOTE CONTROL
J100WTLZ 1989	REMOTE CONTROL
J100WTXCDR 1986	REMOTE CONTROL
J100WTXCUA 1987	REMOTE CONTROL
J100WTXESM 1990	REMOTE CONTROL
J100WTXZ 1989	REMOTE CONTROL
J10EESC 1990	REMOTE CONTROL
J10EDESC 1990	REMOTE CONTROL
J10RELESC 1990	REMOTE CONTROL
J10RESC 1990	REMOTE CONTROL
J10RLESC 1990	REMOTE CONTROL

J10SELESC 1990	REMOTE CONTROL
J110MLCCA 1988	REMOTE CONTROL
J110MLCDC 1986	REMOTE CONTROL
J110MLCEM 1989	REMOTE CONTROL
J110MLCUR 1987	REMOTE CONTROL
J110TLAEM 1989	REMOTE CONTROL
J110TLCCA 1988	REMOTE CONTROL
J110TLCDC 1986	REMOTE CONTROL
J110TLCDF 1986	REMOTE CONTROL
J110TLCEM 1989	REMOTE CONTROL
J110TLCUR 1987	REMOTE CONTROL
J110TXCCA 1988	REMOTE CONTROL
J110TXCEM 1989	REMOTE CONTROL
J110TXCUR 1987	REMOTE CONTROL
J115MLESB 1990	REMOTE CONTROL
J115TLASB 1990	REMOTE CONTROL
J115TLESB 1990	REMOTE CONTROL
J115TXESB 1990	REMOTE CONTROL
J120TLAEM 1989	REMOTE CONTROL
J120TLASB 1990	REMOTE CONTROL
J120TLCCA 1988	REMOTE CONTROL
J120TLCDC 1986	REMOTE CONTROL
J120TLCEM 1989	REMOTE CONTROL
J120TLCUR 1987	REMOTE CONTROL
J120TLESB 1990	REMOTE CONTROL
J120TXCCA 1988	REMOTE CONTROL
J120TXCDC 1986	REMOTE CONTROL
J120TXCEM 1989	REMOTE CONTROL
J120TXCUR 1987	REMOTE CONTROL
J120TXESB 1990	REMOTE CONTROL
J125ESXESS 1990	REMOTE CONTROL
J125ESXW 1989	REMOTE CONTROL
J125WTPLE 1995	REMOTE CONTROL
J140CXCCS 1988	REMOTE CONTROL
J140CXCEC 1989	REMOTE CONTROL

J140CXESR 1990	REMOTE CONTROL
J140TLAEB 1989	REMOTE CONTROL
J140TLASE 1990	REMOTE CONTROL
J140TLCCM 1988	REMOTE CONTROL
J140TLCDC 1986	REMOTE CONTROL
J140TLCEB 1989	REMOTE CONTROL
J140TLCUA 1987	REMOTE CONTROL
J140TLESE 1990	REMOTE CONTROL
J140TXCCM 1988	REMOTE CONTROL
J140TXCDC 1986	REMOTE CONTROL
J140TXCEB 1989	REMOTE CONTROL
J140TXCUA 1987	REMOTE CONTROL
J140TXESE 1990	REMOTE CONTROL
J150CXCCA 1988	REMOTE CONTROL
J150CXCEM 1989	REMOTE CONTROL
J150CXESB 1990	REMOTE CONTROL
J150GTLCUR 1987	REMOTE CONTROL
J150STLACA 1988	REMOTE CONTROL
J150STLCCA 1988	REMOTE CONTROL
J150STLCDC 1986	REMOTE CONTROL
J150STLCEM 1989	REMOTE CONTROL
J150STLCUR 1987	REMOTE CONTROL
J150STLESB 1990	REMOTE CONTROL
J150TLAEM 1989	REMOTE CONTROL
J150TLASB 1990	REMOTE CONTROL
J150TLCCA 1988	REMOTE CONTROL
J150TLCDC 1986	REMOTE CONTROL
J150TLCEM 1989	REMOTE CONTROL
J150TLCUR 1987	REMOTE CONTROL
J150TLESB 1990	REMOTE CONTROL
J150TXCCA 1988	REMOTE CONTROL
J150TXCDC 1986	REMOTE CONTROL
J150TXCEM 1989	REMOTE CONTROL
J150TXCUR 1987	REMOTE CONTROL
J150TXESB 1990	REMOTE CONTROL

J150WTLEOR 1995	REMOTE CONTROL
J150WTLERC 1994	REMOTE CONTROL
J150WTLERV 1994	REMOTE CONTROL
J150WTLETG 1993	REMOTE CONTROL
J150WTLETS 1993	REMOTE CONTROL
J150WTXEOR 1995	REMOTE CONTROL
J150WTXERC 1994	REMOTE CONTROL
J150WTXERV 1994	REMOTE CONTROL
J150WTXETG 1993	REMOTE CONTROL
J150WTXETS 1993	REMOTE CONTROL
J155WTLCDR 1986	REMOTE CONTROL
J155WTLCUA 1987	REMOTE CONTROL
J155WTLESM 1990	REMOTE CONTROL
J155WTLZ 1989	REMOTE CONTROL
J155WTXCDR 1986	REMOTE CONTROL
J155WTXCUA 1987	REMOTE CONTROL
J155WTXESM 1990	REMOTE CONTROL
J155WTXZ 1989	REMOTE CONTROL
J15EESR 1990	REMOTE CONTROL
J15ELESR 1990	REMOTE CONTROL
J15RELESR 1990	REMOTE CONTROL
J15RESR 1990	REMOTE CONTROL
J15RLESR 1990	REMOTE CONTROL
J175STLACM 1988	REMOTE CONTROL
J175STLCCM 1988	REMOTE CONTROL
J175STLCEB 1989	REMOTE CONTROL
J175STLESE 1990	REMOTE CONTROL
J175TLCCM 1988	REMOTE CONTROL
J175TLCDR 1986	REMOTE CONTROL
J175TLCUA 1987	REMOTE CONTROL
J175TXCCM 1988	REMOTE CONTROL
J175TXCDR 1986	REMOTE CONTROL
J175TXCEB 1989	REMOTE CONTROL
J175TXCUA 1987	REMOTE CONTROL
J175TXESE 1990	REMOTE CONTROL

J185ESXESS 1990	REMOTE CONTROL
J185ESXW 1989	REMOTE CONTROL
J200CXCCR 1988	REMOTE CONTROL
J200CXCEA 1989	REMOTE CONTROL
J200CXESM 1990	REMOTE CONTROL
J200STLACM 1988	REMOTE CONTROL
J200STLCCM 1988	REMOTE CONTROL
J200STLCEB 1989	REMOTE CONTROL
J200STLCUA 1987	REMOTE CONTROL
J200STLESE 1990	REMOTE CONTROL
J200TXCCR 1988	REMOTE CONTROL
J200TXCEA 1989	REMOTE CONTROL
J200TXCUC 1987	REMOTE CONTROL
J200TXESM 1990	REMOTE CONTROL
J20CRCCA 1988	REMOTE CONTROL
J20CRCDC 1986	REMOTE CONTROL
J20CRCUR 1987	REMOTE CONTROL
J20CRLCCA 1988	REMOTE CONTROL
J20CRLCDC 1986	REMOTE CONTROL
J20CRLCUR 1987	REMOTE CONTROL
J20ECCA 1988	REMOTE CONTROL
J20ECDC 1986	REMOTE CONTROL
J20ECEM 1989	REMOTE CONTROL
J20ECUR 1987	REMOTE CONTROL
J20EESB 1990	REMOTE CONTROL
J20ELCCA 1988	REMOTE CONTROL
J20ELCDC 1986	REMOTE CONTROL
J20ELCEM 1989	REMOTE CONTROL
J20ELCUR 1987	REMOTE CONTROL
J20ELESB 1990	REMOTE CONTROL
J20TECDC 1986	REMOTE CONTROL
J225CLCUB 1987	REMOTE CONTROL
J225CXCE 1988	REMOTE CONTROL
J225CXCED 1989	REMOTE CONTROL
J225CXCUB 1987	REMOTE CONTROL

J225CXESS 1990	REMOTE CONTROL
J225PLAED 1989	REMOTE CONTROL
J225PLASS 1990	REMOTE CONTROL
J225PLCCE 1988	REMOTE CONTROL
J225PLCED 1989	REMOTE CONTROL
J225PLCUB 1987	REMOTE CONTROL
J225PLESS 1990	REMOTE CONTROL
J225PXCCE 1988	REMOTE CONTROL
J225PXCED 1989	REMOTE CONTROL
J225PXCUB 1987	REMOTE CONTROL
J225PXESS 1990	REMOTE CONTROL
J225TLAED 1989	REMOTE CONTROL
J225TLASS 1990	REMOTE CONTROL
J225TLCCCE 1988	REMOTE CONTROL
J225TLCED 1989	REMOTE CONTROL
J225TLCUB 1987	REMOTE CONTROL
J225TLESS 1990	REMOTE CONTROL
J225TXCCE 1988	REMOTE CONTROL
J225TXCED 1989	REMOTE CONTROL
J225TXCUB 1987	REMOTE CONTROL
J225TXESS 1990	REMOTE CONTROL
J25ECCM 1988	REMOTE CONTROL
J25ECDR 1986	REMOTE CONTROL
J25ECEB 1989	REMOTE CONTROL
J25ECIB 1981	CARBURETOR
J25ECIM 1981	CARBURETOR
J25ECUA 1987	REMOTE CONTROL
J25EESE 1990	REMOTE CONTROL
J25ELCCM 1988	REMOTE CONTROL
J25ELCDR 1986	REMOTE CONTROL
J25ELCEB 1989	REMOTE CONTROL
J25ELCIB 1981	CARBURETOR
J25ELCIM 1981	CARBURETOR
J25ELCUA 1987	REMOTE CONTROL
J25ELESE 1990	REMOTE CONTROL

J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
J25RCCA 1988	REMOTE CONTROL
J25RCDC 1986	REMOTE CONTROL
J25RCIM 1981	CARBURETOR
J25RCSA 1980	CARBURETOR
J25RCUR 1987	REMOTE CONTROL
J25RLCCA 1988	REMOTE CONTROL
J25RLCDC 1986	REMOTE CONTROL
J25RLCIM 1981	CARBURETOR
J25RLCSA 1980	CARBURETOR
J25RLCUR 1987	REMOTE CONTROL
J25RSA 1981	CARBURETOR
J25RSLA 1981	CARBURETOR
J25RWCIM 1981	CARBURETOR
J25RWLCIM 1981	CARBURETOR
J25TECCA 1988	REMOTE CONTROL
J25TECDC 1986	REMOTE CONTROL
J25TECIM 1981	CARBURETOR
J25TECSA 1980	CARBURETOR
J25TECUR 1987	REMOTE CONTROL
J25TELCCA 1988	REMOTE CONTROL
J25TELCDC 1986	REMOTE CONTROL
J25TELCIM 1981	CARBURETOR
J25TELCSA 1980	CARBURETOR
J25TELCUR 1987	REMOTE CONTROL
J275CLCUR 1987	REMOTE CONTROL
J275CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275CXCUR 1987	REMOTE CONTROL
J275PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275PLCUR 1987	REMOTE CONTROL
J275PTLCDC 1986	REMOTE CONTROL
J275PTXCDC 1986	REMOTE CONTROL
J275PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275PXCUR 1987	REMOTE CONTROL

J28ESLCEA 1989	REMOTE CONTROL
J28ESLESM 1990	REMOTE CONTROL
J300CLCUR 1987	REMOTE CONTROL
J300CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300CXCEM 1989	REMOTE CONTROL
J300CXCUR 1987	REMOTE CONTROL
J300CXESB 1990	REMOTE CONTROL
J300PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300PLCEM 1989	REMOTE CONTROL
J300PLCUR 1987	REMOTE CONTROL
J300PLESB 1990	REMOTE CONTROL
J300PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300PXCEM 1989	REMOTE CONTROL
J300PXCUR 1987	REMOTE CONTROL
J300PXESB 1990	REMOTE CONTROL
J300TLCDC 1986	REMOTE CONTROL
J300TXCDC 1986	REMOTE CONTROL
J30ECCE 1988	REMOTE CONTROL
J30ECDM 1986	REMOTE CONTROL
J30ECED 1989	REMOTE CONTROL
J30ECUB 1987	REMOTE CONTROL
J30EESS 1990	REMOTE CONTROL
J30ELCCE 1988	REMOTE CONTROL
J30ELCDM 1986	REMOTE CONTROL
J30ELCED 1989	REMOTE CONTROL
J30ELCUB 1987	REMOTE CONTROL
J30ELESS 1990	REMOTE CONTROL
J30JREEM 1999	REWIND STARTER
J30JRSIE jet drive, rope start, 15 in shaft 2001	REWIND STARTER
J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
J30RCCE 1988	REMOTE CONTROL
J30RCDM 1986	REMOTE CONTROL
J30RCUB 1987	REMOTE CONTROL
J30RLCCE 1988	REMOTE CONTROL

J30RLCDM 1986	REMOTE CONTROL
J30RLCUB 1987	REMOTE CONTROL
J30TECCE 1988	REMOTE CONTROL
J30TECDM 1986	REMOTE CONTROL
J30TECUB 1987	REMOTE CONTROL
J30TELCCE 1988	REMOTE CONTROL
J30TELCDM 1986	REMOTE CONTROL
J30TELCUB 1987	REMOTE CONTROL
J35AELCDE 1986	REMOTE CONTROL
J35AELCUD 1987	REMOTE CONTROL
J35ARLCDE 1986	REMOTE CONTROL
J35ARLCUD 1987	REMOTE CONTROL
J35ECIG 1981	CARBURETOR
J35ECSM 1980	CARBURETOR
J35ELCIG 1981	CARBURETOR
J35ELCSM 1980	CARBURETOR
J35RCCE 1988	REMOTE CONTROL
J35RCDM 1986	REMOTE CONTROL
J35RCIG 1981	CARBURETOR
J35RCSM 1980	CARBURETOR
J35RCUB 1987	REMOTE CONTROL
J35RLCCE 1988	REMOTE CONTROL
J35RLCDM 1986	REMOTE CONTROL
J35RLCIG 1981	CARBURETOR
J35RLCSM 1980	CARBURETOR
J35RLCUB 1987	REMOTE CONTROL
J40AELCCS 1988	REMOTE CONTROL
J40ARLCCS 1988	REMOTE CONTROL
J40ATLCCS 1988	REMOTE CONTROL
J40ECCS 1988	REMOTE CONTROL
J40ECDE 1986	REMOTE CONTROL
J40ECEC 1989	REMOTE CONTROL
J40ECRM 1984	INTAKE MANIFOLD
J40ECUD 1987	REMOTE CONTROL
J40EEOD 1995	REWIND STARTER

J40EERE 1994	REWIND STARTER
J40EESR 1990	REMOTE CONTROL
J40ELCCS 1988	REMOTE CONTROL
J40ELCDE 1986	REMOTE CONTROL
J40ELCEC 1989	REMOTE CONTROL
J40ELCRM 1984	INTAKE MANIFOLD
J40ELCUD 1987	REMOTE CONTROL
J40ELECR 1998	REWIND STARTER
J40ELEDs 1996	REWIND STARTER
J40ELEOD 1995	REWIND STARTER
J40ELERE 1994	REWIND STARTER
J40EESR 1990	REMOTE CONTROL
J40ELEUC 1997	REWIND STARTER
J40JRECA 1998	REWIND STARTER
J40JREDC 1996	REWIND STARTER
J40JREOS 1995	REWIND STARTER
J40JREUR 1997	REWIND STARTER
J40PLEEA 1999	REWIND STARTER
J40PLSIF elec start, TNT, 20 in shaft 2001	REWIND STARTER
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	REWIND STARTER
J40RCCS 1988	REMOTE CONTROL
J40RCDE 1986	REMOTE CONTROL
J40RCEC 1989	REMOTE CONTROL
J40RCRM 1984	INTAKE MANIFOLD
J40RCUD 1987	REMOTE CONTROL
J40RECR 1998	REWIND STARTER
J40REDS 1996	REWIND STARTER
J40REEA 1999	REWIND STARTER
J40REOD 1995	REWIND STARTER
J40RERE 1994	REWIND STARTER
J40RESR 1990	REMOTE CONTROL
J40REUC 1997	REWIND STARTER
J40RLCCS 1988	REMOTE CONTROL
J40RLCDE 1986	REMOTE CONTROL
J40RLCEC 1989	REMOTE CONTROL

J40RLCRM 1984	INTAKE MANIFOLD
J40RLCUD 1987	REMOTE CONTROL
J40RLECR 1998	REWIND STARTER
J40RLEDS 1996	REWIND STARTER
J40RLEEA 1999	REWIND STARTER
J40RLEOD 1995	REWIND STARTER
J40RLERE 1994	REWIND STARTER
J40RLESR 1990	REMOTE CONTROL
J40RLEUC 1997	REWIND STARTER
J40RLSIF rope start, 20 in shaft 2001	REWIND STARTER
J40RLSNF - FR	25-0_LANCEUR MANUEL
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	REWIND STARTER
J40RLSOC	REWIND STARTER
J40RLSOC - FR	25-0_LANCEUR MANUEL
J40RLSRS	REWIND STARTER
J40RLSRS - FR	25-0_LANCEUR MANUEL
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	REWIND STARTER
J40RLSTD	REWIND STARTER
J40RLSTD - FR	25-0_LANCEUR MANUEL
J40RSIF rope start, 15 in shaft 2001	REWIND STARTER
J40RSNF - FR	25-0_LANCEUR MANUEL
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	REWIND STARTER
J40RSOC	REWIND STARTER
J40RSOC - FR	25-0_LANCEUR MANUEL
J40RSRS	REWIND STARTER
J40RSRS - FR	25-0_LANCEUR MANUEL
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
J40RSTD	REWIND STARTER
J40RSTD - FR	25-0_LANCEUR MANUEL
J40TECCS 1988	REMOTE CONTROL
J40TECDE 1986	REMOTE CONTROL
J40TECEC 1989	REMOTE CONTROL
J40TECRM 1984	INTAKE MANIFOLD
J40TECUD 1987	REMOTE CONTROL

J40TEECR 1998	REWIND STARTER
J40TEEDS 1996	REWIND STARTER
J40TEEOD 1995	REWIND STARTER
J40TEERE 1994	REWIND STARTER
J40TEESR 1990	REMOTE CONTROL
J40TEEUC 1997	REWIND STARTER
J40TELCCS 1988	REMOTE CONTROL
J40TELCDE 1986	REMOTE CONTROL
J40TELCEC 1989	REMOTE CONTROL
J40TELCRM 1984	INTAKE MANIFOLD
J40TELECR 1998	REWIND STARTER
J40TELEDS 1996	REWIND STARTER
J40TELEOD 1995	REWIND STARTER
J40TELERE 1994	REWIND STARTER
J40TELESR 1990	REMOTE CONTROL
J40TELEUC 1997	REWIND STARTER
J40TLCCS 1988	REMOTE CONTROL
J40TLCDE 1986	REMOTE CONTROL
J40TLCEC 1989	REMOTE CONTROL
J40TLCUD 1987	REMOTE CONTROL
J40TLECR 1998	REWIND STARTER
J40TLEDS 1996	REWIND STARTER
J40TLEOD 1995	REWIND STARTER
J40TLERE 1994	REWIND STARTER
J40TLESR 1990	REMOTE CONTROL
J40TLEUC 1997	REWIND STARTER
J40TPLEEA 1999	REWIND STARTER
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	REWIND STARTER
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	REWIND STARTER
J40TTLCCS 1988	REMOTE CONTROL
J40TTLCEC 1989	REMOTE CONTROL
J40TTLECR 1998	REWIND STARTER
J40TTLEDS 1996	REWIND STARTER
J40TTLEOD 1995	REWIND STARTER
J40TTLERE 1994	REWIND STARTER

J40TTLESR 1990	REMOTE CONTROL
J40TTLEUC 1997	REWIND STARTER
J40WREES 1999	REWIND STARTER
J40WRLEES 1999	REWIND STARTER
J40WRLSIR commercial, rope start, 20 in shaft 2001	REWIND STARTER
J40WRSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	REWIND STARTER
J40WRSIR commercial, rope start, 15 in shaft 2001	REWIND STARTER
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
J40WRYEES 1999	REWIND STARTER
J40WRYSIR commercial, rope start, 25 in shaft 2001	REWIND STARTER
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	REWIND STARTER
J45RCE 1989	REMOTE CONTROL - ELECTRIC START
J45RCEIA 1991	REMOTE CONTROL
J45RCENM 1992	REMOTE CONTROL
J45RCEOD 1995	REWIND STARTER
J45RCERE 1994	REWIND STARTER
J45RCESR 1990	REMOTE CONTROL
J45RCLE 1989	REMOTE CONTROL - ELECTRIC START
J45RCLEDS 1996	REWIND STARTER
J45RCLEIA 1991	REMOTE CONTROL
J45RCLENM 1992	REMOTE CONTROL
J45RCLEOD 1995	REWIND STARTER
J45RCLERE 1994	REWIND STARTER
J45RCLESR 1990	REMOTE CONTROL
J45RCLEUC 1997	REWIND STARTER
J45WMLE 1989	REMOTE CONTROL - ELECTRIC START
J45WMLEIA 1991	REMOTE CONTROL
J45WMLENM 1992	REMOTE CONTROL
J45WMLESR 1990	REMOTE CONTROL
J48ESLCCC 1988	REMOTE CONTROL
J48ESLCER 1989	REMOTE CONTROL (CONTINUED)
J48ESLESA 1990	REMOTE CONTROL
J50BECCS 1988	REMOTE CONTROL
J50BECDE 1986	REMOTE CONTROL

J50BECEC 1989	REMOTE CONTROL
J50BECIC 1981	INTAKE MANIFOLD
J50BECNR 1982	INTAKE MANIFOLD
J50BECRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BECTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BECUD 1987	REMOTE CONTROL
J50BEEOD 1995	REWIND STARTER
J50BEERE 1994	REWIND STARTER
J50BEESR 1990	REMOTE CONTROL
J50BELCCS 1988	REMOTE CONTROL
J50BELCDE 1986	REMOTE CONTROL
J50BELCEC 1989	REMOTE CONTROL
J50BELCIC 1981	INTAKE MANIFOLD
J50BELCNR 1982	INTAKE MANIFOLD
J50BELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BELCUD 1987	REMOTE CONTROL
J50BELEOD 1995	REWIND STARTER
J50BELERE 1994	REWIND STARTER
J50BELESR 1990	REMOTE CONTROL
J50ECSR 1980	INTAKE MANIFOLD
J50ELCSR 1980	INTAKE MANIFOLD
J50ELEER 1999	REWIND STARTER
J50ELSIF elec start, 20 in shaft 2001	REWIND STARTER
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
J50ESLECC 1998	REWIND STARTER
J50ESLEUR 1997	REWIND STARTER
J50JEDS 1996	REWIND STARTER
J50JEOD 1995	REWIND STARTER
J50JERE 1994	REWIND STARTER
J50JEUC 1997	REWIND STARTER
J50PLEEA 1999	REWIND STARTER
J50PLSIF elec start, TNT, 20 in shaft 2001	REWIND STARTER
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	REWIND STARTER
J50TELCCS 1988	REMOTE CONTROL

J50TELCDE 1986	REMOTE CONTROL
J50TELCEC 1989	REMOTE CONTROL
J50TELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J50TELCCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50TELCUD 1987	REMOTE CONTROL
J50TELEOD 1995	REWIND STARTER
J50TELERE 1994	REWIND STARTER
J50TELESR 1990	REMOTE CONTROL
J50TLCCS 1988	REMOTE CONTROL
J50TLCDE 1986	REMOTE CONTROL
J50TLCEC 1989	REMOTE CONTROL
J50TELCRM 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J50TLCUD 1987	REMOTE CONTROL
J50TLECR 1998	REWIND STARTER
J50TLEDS 1996	REWIND STARTER
J50TLEOD 1995	REWIND STARTER
J50TLERE 1994	REWIND STARTER
J50TLESR 1990	REMOTE CONTROL
J50TLEUC 1997	REWIND STARTER
J50TSLECC 1998	REWIND STARTER
J50TSLEUS 1997	REWIND STARTER
J55RCIM 1981	INTAKE MANIFOLD
J55RLCIM 1981	INTAKE MANIFOLD
J55RLCSA 1980	INTAKE MANIFOLD
J55RSLC 1997	REWIND STARTER
J55RSLG 1995	REWIND STARTER
J55RSLW 1996	REWIND STARTER
J55RWLE 1989	REMOTE CONTROL - ELECTRIC START
J55RWLEIA 1991	REMOTE CONTROL
J55RWLENM 1992	REMOTE CONTROL
J55RWLERE 1994	REWIND STARTER
J55RWLESR 1990	REMOTE CONTROL
J55WREES 1999	REWIND STARTER
J55WRLEES 1999	REWIND STARTER
J55WRLSIR commercial, rope start, 20 in shaft 2001	REWIND STARTER

J55WRLSOE	REWIND STARTER
J55WRLSOE - FR	25-0_LANCEUR MANUEL
J55WRLSRB	REWIND STARTER
J55WRLSRB - FR	25-0_LANCEUR MANUEL
J55WRLSRG	REWIND STARTER
J55WRLSRG - FR	25-0_LANCEUR MANUEL
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	REWIND STARTER
J55WRLSTM	REWIND STARTER
J55WRLSTM - FR	25-0_LANCEUR MANUEL
J55WRSIR commercial, rope start, 15 in shaft 2001	REWIND STARTER
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	REWIND STARTER
J55WRYEES 1999	REWIND STARTER
J55WRYSIR commercial, rope start, 25 in shaft 2001	REWIND STARTER
J55WRYSOB	REWIND STARTER
J55WRYSOB - FR	25-0_LANCEUR MANUEL
J55WRYSRM	REWIND STARTER
J55WRYSRM - FR	25-0_LANCEUR MANUEL
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	REWIND STARTER
J60ECIA 1981	INTAKE MANIFOLD
J60ECIH 1981	INTAKE MANIFOLD
J60ECNM 1982	INTAKE MANIFOLD
J60ECSR 1980	INTAKE MANIFOLD
J60ECTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J60ELCCR 1988	REMOTE CONTROL
J60ELCDS 1986	REMOTE CONTROL
J60ELCEA 1989	REMOTE CONTROL
J60ELCIA 1981	INTAKE MANIFOLD
J60ELCIH 1981	INTAKE MANIFOLD
J60ELCNM 1982	INTAKE MANIFOLD
J60ELCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J60ELCSR 1980	INTAKE MANIFOLD
J60ELCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J60ELCUC 1987	REMOTE CONTROL
J60ELES 1990	REMOTE CONTROL

J60TLCCR 1988	REMOTE CONTROL
J60TLCDS 1986	REMOTE CONTROL
J60TLCEA 1989	REMOTE CONTROL
J60TLCIA 1981	INTAKE MANIFOLD
J60TLCIH 1981	INTAKE MANIFOLD
J60TLCNM 1982	INTAKE MANIFOLD
J60TLCRE 1984	INTAKE MANIFOLD AND PRIMER SYSTEM
J60TLCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J60TLCUC 1987	REMOTE CONTROL
J60TLESM 1990	REMOTE CONTROL
J60TTLCCR 1988	REMOTE CONTROL
J60TTLCEA 1989	REMOTE CONTROL
J60TTLESM 1990	REMOTE CONTROL
J65RSLC 1995	REWIND STARTER
J65RSLM 1996	REWIND STARTER
J65RSLZ2 1997	REWIND STARTER
J65WMLCDR 1986	REMOTE CONTROL
J65WMLCOC 1985	REMOTE CONTROL
J65WMLCUA 1987	REMOTE CONTROL
J65WMLESM 1990	REMOTE CONTROL
J65WMLZ 1989	REMOTE CONTROL
J65WRLEEO 1999	REWIND STARTER
J65WRLEES 1999	REWIND STARTER
J65WRLSIR commercial, rope start, 20 in shaft 2001	REWIND STARTER
J65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	REWIND STARTER
J65WRYEEO 1999	REWIND STARTER
J65WRYEES 1999	REWIND STARTER
J65WRYSIR commercial, rope start, 22.5 in shaft 2001	REWIND STARTER
J65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	REWIND STARTER
J65WTLCOC 1985	REMOTE CONTROL
J70ELCCA 1988	REMOTE CONTROL
J70ELCDC 1986	REMOTE CONTROL
J70ELCEM 1989	REMOTE CONTROL
J70ELCUR 1987	REMOTE CONTROL

J70ELESB 1990	REMOTE CONTROL
J70TLCCA 1988	REMOTE CONTROL
J70TLCDC 1986	REMOTE CONTROL
J70TLCEM 1989	REMOTE CONTROL
J70TLCUR 1987	REMOTE CONTROL
J70TLESB 1990	REMOTE CONTROL
J75ECCA 1988	REMOTE CONTROL
J75ECDC 1986	REMOTE CONTROL
J75ECUR 1987	REMOTE CONTROL
J88MSLCCC 1988	REMOTE CONTROL
J88MSLCER 1989	REMOTE CONTROL
J88MSLESA 1990	REMOTE CONTROL
J90MLCDC 1986	REMOTE CONTROL
J90MLCUR 1987	REMOTE CONTROL
J90TLAEM 1989	REMOTE CONTROL
J90TLASB 1990	REMOTE CONTROL
J90TLCCA 1988	REMOTE CONTROL
J90TLCDC 1986	REMOTE CONTROL
J90TLCEM 1989	REMOTE CONTROL
J90TLCUR 1987	REMOTE CONTROL
J90TLESB 1990	REMOTE CONTROL
J90TXCDC 1986	REMOTE CONTROL
N65WMLM 1988	REMOTE CONTROL
REMOTE CONTROL 1995	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROLS 1991	REMOTE CONTROL
REMOTE CONTROLS 1992	REMOTE CONTROL
REMOTE CONTROLS 1993	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROLS 1994	REMOTE CONTROL - SIDE MOUNT - PREWIRED
RJ50ELSIF elec start, TNT, 20 in shaft 2001	REWIND STARTER
SE125WTPLV 1996	REMOTE CONTROL
SE125WTPXV 1996	REMOTE CONTROL
SE40RPB 1997	REWIND STARTER
SE40RPH 1996	REWIND STARTER
SE40RPLB 1997	REWIND STARTER
SE40RPLH 1996	REWIND STARTER

SE40RPLT2 1998	REWIND STARTER
SE40RPT2 1998	REWIND STARTER
SE40RPYB 1997	REWIND STARTER
SE40RPYH 1996	REWIND STARTER
SE40RPYT2 1998	REWIND STARTER
SE45RSLB 1997	REWIND STARTER
SE45RSLH 1996	REWIND STARTER
SE50TLEDS 1996	REWIND STARTER
SE55RSC 1997	REWIND STARTER
SE55RSLC 1997	REWIND STARTER
SE55RSLM2 1998	REWIND STARTER
SE55RSLW 1996	REWIND STARTER
SE55RSM2 1998	REWIND STARTER
SE55RSW 1996	REWIND STARTER
SE55RSYC 1997	REWIND STARTER
SE55RSYM2 1998	REWIND STARTER
SE55RSYW 1996	REWIND STARTER
SE65RSLD 1998	REWIND STARTER
SE65RSLM 1996	REWIND STARTER
SE65RSLZ2 1997	REWIND STARTER
SE65RSYD 1998	REWIND STARTER
SE65RSYM 1996	REWIND STARTER
SE65RSYZ2 1997	REWIND STARTER
SJ125WTPLV 1996	REMOTE CONTROL
SJ125WTPXV 1996	REMOTE CONTROL
SJ40EEDS 1996	REWIND STARTER
SJ40REDS 1996	REWIND STARTER
SJ40RLEDS 1996	REWIND STARTER
SJ40RPB 1997	REWIND STARTER
SJ40RPH 1996	REWIND STARTER
SJ40RPLB 1997	REWIND STARTER
SJ40RPLH 1996	REWIND STARTER
SJ40RPLT2 1998	REWIND STARTER
SJ40RPT2 1998	REWIND STARTER
SJ40RPYB 1997	REWIND STARTER

SJ40RPYH 1996	REWIND STARTER
SJ40RPYT2 1998	REWIND STARTER
SJ45RSLB 1997	REWIND STARTER
SJ45RSLH 1996	REWIND STARTER
SJ55RSC 1997	REWIND STARTER
SJ55RSLC 1997	REWIND STARTER
SJ55RSLM2 1998	REWIND STARTER
SJ55RSLW 1996	REWIND STARTER
SJ55RSM2 1998	REWIND STARTER
SJ55RSW 1996	REWIND STARTER
SJ55RSYC 1997	REWIND STARTER
SJ55RSYM2 1998	REWIND STARTER
SJ55RSYW 1996	REWIND STARTER
SJ65RSLD 1998	REWIND STARTER
SJ65RSLM 1996	REWIND STARTER
SJ65RSLZ2 1997	REWIND STARTER
SJ65RSYD 1998	REWIND STARTER
SJ65RSYM 1996	REWIND STARTER
SJ65RSYZ2 1997	REWIND STARTER
T65WMLM 1988	REMOTE CONTROL
TE10ELESC 1990	REMOTE CONTROL
TE10RELESC 1990	REMOTE CONTROL
TE10RLESC 1990	REMOTE CONTROL
TE110TLCEM 1989	REMOTE CONTROL
TE110TLESF 1989	REMOTE CONTROL
TE110TXCEM 1989	REMOTE CONTROL
TE115TLESB 1990	REMOTE CONTROL
TE120TXCEM 1989	REMOTE CONTROL
TE150SLCEM 1989	REMOTE CONTROL
TE150SLESB 1990	REMOTE CONTROL
TE150TXCEM 1989	REMOTE CONTROL
TE200TXCEA 1989	REMOTE CONTROL
TE25ELCEB 1989	REMOTE CONTROL
TE25ELESE 1990	REMOTE CONTROL
TE25ELESF 1989	REMOTE CONTROL

TE30ELCED 1989	REMOTE CONTROL
TE30ELESF 1989	REMOTE CONTROL
TE30ELESS 1990	REMOTE CONTROL
TE40ELCEC 1989	REMOTE CONTROL
TE40ELESR 1990	REMOTE CONTROL
TE40TELESF 1990	REMOTE CONTROL
TE40TELESR 1990	REMOTE CONTROL
TE50TLCEC 1989	REMOTE CONTROL
TE50TLESF 1989	REMOTE CONTROL
TE50TLESF 1990	REMOTE CONTROL
TE50TLESR 1990	REMOTE CONTROL
TE60TLCEA 1989	REMOTE CONTROL
TE60TLESF 1989	REMOTE CONTROL
TE60TLESF 1990	REMOTE CONTROL
TE60TLESM 1990	REMOTE CONTROL
TE70TLCEM 1989	REMOTE CONTROL
TE70TLESB 1990	REMOTE CONTROL
TE70TLESF 1989	REMOTE CONTROL
TE70TLESF 1990	REMOTE CONTROL
TE90TLCEM 1989	REMOTE CONTROL
TE90TLESB 1990	REMOTE CONTROL
TE90TLESF 1989	REMOTE CONTROL
TE90TLESF 1990	REMOTE CONTROL
TJ10ELESC 1990	REMOTE CONTROL
TJ10RELESC 1990	REMOTE CONTROL
TJ10RLESC 1990	REMOTE CONTROL
TJ110TLCEM 1989	REMOTE CONTROL
TJ110TXCEM 1989	REMOTE CONTROL
TJ115TLESB 1990	REMOTE CONTROL
TJ120TXCEM 1989	REMOTE CONTROL
TJ150SLCEM 1989	REMOTE CONTROL
TJ150SLESB 1990	REMOTE CONTROL
TJ150TXCEM 1989	REMOTE CONTROL
TJ200TXCEA 1989	REMOTE CONTROL
TJ25ELCEB 1989	REMOTE CONTROL

TJ25ELESE 1990	REMOTE CONTROL
TJ25ELESF 1989	REMOTE CONTROL
TJ30ELCED 1989	REMOTE CONTROL
TJ30ELESF 1989	REMOTE CONTROL
TJ30ELESS 1990	REMOTE CONTROL
TJ40ELCEC 1989	REMOTE CONTROL
TJ40ELESF 1990	REMOTE CONTROL
TJ40ELESR 1990	REMOTE CONTROL
TJ40TELESF 1990	REMOTE CONTROL
TJ40TELESR 1990	REMOTE CONTROL
TJ50TLCEC 1989	REMOTE CONTROL
TJ50TLESF 1989	REMOTE CONTROL
TJ50TLESF 1990	REMOTE CONTROL
TJ50TLESR 1990	REMOTE CONTROL
TJ60TLCEA 1989	REMOTE CONTROL
TJ60TLESF 1989	REMOTE CONTROL
TJ60TLESF 1990	REMOTE CONTROL
TJ60TLESM 1990	REMOTE CONTROL
TJ70TLCEM 1989	REMOTE CONTROL
TJ70TLESB 1990	REMOTE CONTROL
TJ70TLESF 1989	REMOTE CONTROL
TJ70TLESF 1990	REMOTE CONTROL
TJ90TLCEM 1989	REMOTE CONTROL
TJ90TLESB 1990	REMOTE CONTROL
VE100SLESB 1990	REMOTE CONTROL
VE115TLESB 1990	REMOTE CONTROL
VE115TXESB 1990	REMOTE CONTROL
VE120TLESB 1990	REMOTE CONTROL
VE120TXESB 1990	REMOTE CONTROL
VE140LESE 1990	REMOTE CONTROL
VE140TXESE 1990	REMOTE CONTROL
VE150SLESB 1990	REMOTE CONTROL
VE150TLESB 1990	REMOTE CONTROL
VE150TXESB 1990	REMOTE CONTROL
VE175SLESE 1990	REMOTE CONTROL

VE175TXESE 1990	REMOTE CONTROL
VE200SLESE 1990	REMOTE CONTROL
VE200TXESM 1990	REMOTE CONTROL
VE225PLESS 1990	REMOTE CONTROL
VE225PXESS 1990	REMOTE CONTROL
VE225TLESS 1990	REMOTE CONTROL
VE225TXESS 1990	REMOTE CONTROL
VE25ELESE 1990	REMOTE CONTROL
VE28ESLCEA 1989	REMOTE CONTROL
VE28ESLESM 1990	REMOTE CONTROL
VE30EESS 1990	REMOTE CONTROL
VE30ELESS 1990	REMOTE CONTROL
VE40EESR 1990	REMOTE CONTROL
VE40ELESR 1990	REMOTE CONTROL
VE40TELESR 1990	REMOTE CONTROL
VE40TLESR 1990	REMOTE CONTROL
VE48ESLCCC 1988	REMOTE CONTROL
VE48ESLCER 1989	REMOTE CONTROL (CONTINUED)
VE48ESLESA 1990	REMOTE CONTROL
VE50BEESR 1990	REMOTE CONTROL
VE50BELESR 1990	REMOTE CONTROL
VE50TLESR 1990	REMOTE CONTROL
VE60ELESM 1990	REMOTE CONTROL
VE60TLESM 1990	REMOTE CONTROL
VE70ELESB 1990	REMOTE CONTROL
VE70TLESB 1990	REMOTE CONTROL
VE88MSLCCC 1988	REMOTE CONTROL
VE88MSLCER 1989	REMOTE CONTROL
VE88MSLESA 1990	REMOTE CONTROL
VE90MLESB 1990	REMOTE CONTROL
VE90TLESB 1990	REMOTE CONTROL
VJ100SLESB 1990	REMOTE CONTROL
VJ115TLASB 1990	REMOTE CONTROL
VJ115TLESB 1990	REMOTE CONTROL
VJ115TXESB 1990	REMOTE CONTROL

VJ120TLASB 1990	REMOTE CONTROL
VJ120TLESB 1990	REMOTE CONTROL
VJ120TXESB 1990	REMOTE CONTROL
VJ140TLASE 1990	REMOTE CONTROL
VJ140TLESE 1990	REMOTE CONTROL
VJ140TXESE 1990	REMOTE CONTROL
VJ150SLESB 1990	REMOTE CONTROL
VJ150TLESB 1990	REMOTE CONTROL
VJ150TXESB 1990	REMOTE CONTROL
VJ175SLESE 1990	REMOTE CONTROL
VJ175TXESE 1990	REMOTE CONTROL
VJ200SLESE 1990	REMOTE CONTROL
VJ200TXESM 1990	REMOTE CONTROL
VJ225PLESS 1990	REMOTE CONTROL
VJ225PXESS 1990	REMOTE CONTROL
VJ225TLASS 1990	REMOTE CONTROL
VJ225TLESS 1990	REMOTE CONTROL
VJ225TXESS 1990	REMOTE CONTROL
VJ25ELESE 1990	REMOTE CONTROL
VJ28ESLCEA 1989	REMOTE CONTROL
VJ28ESLESB 1990	REMOTE CONTROL
VJ30EESS 1990	REMOTE CONTROL
VJ30ELESS 1990	REMOTE CONTROL
VJ40EESR 1990	REMOTE CONTROL
VJ40ELESR 1990	REMOTE CONTROL
VJ40TELESR 1990	REMOTE CONTROL
VJ40TLESR 1990	REMOTE CONTROL
VJ48ESLCCC 1988	REMOTE CONTROL
VJ48ESLCER 1989	REMOTE CONTROL (CONTINUED)
VJ48ESLESA 1990	REMOTE CONTROL
VJ50BEESR 1990	REMOTE CONTROL
VJ50BELESR 1990	REMOTE CONTROL
VJ50TLESR 1990	REMOTE CONTROL
VJ60ELESB 1990	REMOTE CONTROL
VJ60TLESB 1990	REMOTE CONTROL

VJ70ELESB 1990	REMOTE CONTROL
VJ70TLESB 1990	REMOTE CONTROL
VJ88MSLCCC 1988	REMOTE CONTROL
VJ88MSLCER 1989	REMOTE CONTROL
VJ88MSLESA 1990	REMOTE CONTROL
VJ90MLESB 1990	REMOTE CONTROL
VJ90TLASB 1990	REMOTE CONTROL
VJ90TLESB 1990	REMOTE CONTROL
W100WTLM 1988	REMOTE CONTROL
W100WTXM 1988	REMOTE CONTROL
X155WTLM 1988	REMOTE CONTROL
X155WTXM 1988	REMOTE CONTROL
X50ESLECC 1998	REWIND STARTER