

Where Used: Part Number 0321786

Model Name	Diagram
25802C 1978	GEARCASE- 35 HP
25803C 1978	GEARCASE- 35 HP
25852C 1978	GEARCASE- 35 HP
25853C 1978	GEARCASE- 35 HP
25904R 1979	GEARCASE - 25
25904R 1979	GEARCASE - 35
25905R 1979	GEARCASE - 25
25905R 1979	GEARCASE - 35
25952R 1979	GEARCASE - 25
25952R 1979	GEARCASE - 35
25953R 1979	GEARCASE - 25
25953R 1979	GEARCASE - 35
25E78C 1978	GEARCASE - 35
25E79R 1979	GEARCASE - 25
25E79R 1979	GEARCASE - 35
25EL78C 1978	GEARCASE - 35
25EL79R 1979	GEARCASE - 25
25EL79R 1979	GEARCASE - 35
25R78C 1978	GEARCASE - 35
25R79R 1979	GEARCASE - 25
25R79R 1979	GEARCASE - 35
25RL78C 1978	GEARCASE - 35
25RL79R 1979	GEARCASE - 25
25RL79R 1979	GEARCASE - 35
35802R 1978	GEARCASE- 35 HP
35803R 1978	GEARCASE- 35 HP
35852R 1978	GEARCASE- 35 HP
35853R 1978	GEARCASE- 35 HP
35902A 1979	GEARCASE - 25
35902A 1979	GEARCASE - 35
35903A 1979	GEARCASE - 25
35903A 1979	GEARCASE - 35
35952A 1979	GEARCASE - 25

35952A 1979	GEARCASE - 35
35953A 1979	GEARCASE - 25
35953A 1979	GEARCASE - 35
35E78R 1978	GEARCASE - 35
35E79A 1979	GEARCASE - 25
35E79A 1979	GEARCASE - 35
35EL78R 1978	GEARCASE - 35
35EL79A 1979	GEARCASE - 25
35EL79A 1979	GEARCASE - 35
35R78R 1978	GEARCASE - 35
35R79A 1979	GEARCASE - 25
35R79A 1979	GEARCASE - 35
35RL78R 1978	GEARCASE - 35
35RL79A 1979	GEARCASE - 25
35RL79A 1979	GEARCASE - 35
B25JREUR 1997	JET DRIVE UNIT
BE20SRECB 1998	JET DRIVE UNIT
BE20SREUM 1997	JET DRIVE UNIT
BE20SRLECB 1998	JET DRIVE UNIT
BE20SRLEUM 1997	JET DRIVE UNIT
BE25BAECM 1998	JET DRIVE UNIT
BE25BAEUA 1997	JET DRIVE UNIT
BE25BALECM 1998	JET DRIVE UNIT
BE25BALEUA 1997	JET DRIVE UNIT
BE30BAECS 1998	JET DRIVE UNIT
BE30BAEEC 1999	JET DRIVE UNIT -- 25JR
BE30BAEEN 1999	JET DRIVE UNIT -- 25JR
BE30BAEUD 1997	JET DRIVE UNIT
BE30BALECS 1998	JET DRIVE UNIT
BE30BALEUD 1997	JET DRIVE UNIT
BE30BASIA rope start, tiller, 15 in shaft, n/a usa 2001	JET DRIVE UNIT - 25JR
BE30BASSR Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	JET DRIVE UNIT - 25JR
BJ20SRECB 1998	JET DRIVE UNIT
BJ20SREUM 1997	JET DRIVE UNIT
BJ20SRLECB 1998	JET DRIVE UNIT

BJ20SRLEUM 1997	JET DRIVE UNIT
BJ25BAECM 1998	JET DRIVE UNIT
BJ25BAEUA 1997	JET DRIVE UNIT
BJ25BALECM 1998	JET DRIVE UNIT
BJ25BALEUA 1997	JET DRIVE UNIT
BJ30BAECS 1998	JET DRIVE UNIT
BJ30BAEEC 1999	JET DRIVE UNIT -- 25JR
BJ30BAEEN 1999	JET DRIVE UNIT -- 25JR
BJ30BAEUD 1997	JET DRIVE UNIT
BJ30BALECS 1998	JET DRIVE UNIT
BJ30BALEUD 1997	JET DRIVE UNIT
E20CREUM 1997	JET DRIVE UNIT
E20CRLEUM 1997	JET DRIVE UNIT
E25CNE 1982	GEARCASE
E25ECIB 1981	GEARCASE
E25ECIM 1981	GEARCASE
E25ECRS 1984	GEARCASE
E25ECTD 1983	GEARCASE
E25ELCIB 1981	GEARCASE
E25ELCIM 1981	GEARCASE
E25ELCNE 1982	GEARCASE
E25ELCRS 1984	GEARCASE
E25ELCTD 1983	GEARCASE
E25JRECA 1998	JET DRIVE UNIT
E25JREDC 1996	JET DRIVE UNIT
E25JREOS 1995	JET DRIVE UNIT
E25RCIM 1981	GEARCASE
E25RCNB 1982	GEARCASE
E25RCRD 1984	GEARCASE
E25RCSA 1980	GEARCASE - 25
E25RCSA 1980	GEARCASE - 35
E25RCTE 1983	GEARCASE
E25RECB 1998	JET DRIVE UNIT
E25REUM 1997	JET DRIVE UNIT
E25RLCIM 1981	GEARCASE

E25RLCNB 1982	GEARCASE
E25RLCRD 1984	GEARCASE
E25RLCSA 1980	GEARCASE - 25
E25RLCSA 1980	GEARCASE - 35
E25RLCTE 1983	GEARCASE
E25RLECB 1998	JET DRIVE UNIT
E25RLEUM 1997	JET DRIVE UNIT
E25RSA 1981	GEARCASE
E25RSLA 1981	GEARCASE
E25RSLS 1983	GEARCASE
E25RSS 1983	GEARCASE
E25RWCIM 1981	GEARCASE
E25RWCRD 1984	GEARCASE
E25RWCTE 1983	GEARCASE
E25RWLCIM 1981	GEARCASE
E25RWLCRD 1984	GEARCASE
E25RWLCTE 1983	GEARCASE
E25TECIM 1981	GEARCASE
E25TECNB 1982	GEARCASE
E25TECRD 1984	GEARCASE
E25TECSA 1980	GEARCASE - 25
E25TECSA 1980	GEARCASE - 35
E25TECTE 1983	GEARCASE
E25TELCIM 1981	GEARCASE
E25TELCNB 1982	GEARCASE
E25TELCRD 1984	GEARCASE
E25TELCSA 1980	GEARCASE - 25
E25TELCSA 1980	GEARCASE - 35
E25TELCTE 1983	GEARCASE
E30REUD 1997	JET DRIVE UNIT
E30RLEUD 1997	JET DRIVE UNIT
E35ECIG 1981	GEARCASE
E35ECND 1982	GEARCASE
E35ECSM 1980	GEARCASE - 25
E35ECSM 1980	GEARCASE - 35

E35ELCIG 1981	GEARCASE
E35ELCND 1982	GEARCASE
E35ELCSM 1980	GEARCASE - 25
E35ELCSM 1980	GEARCASE - 35
E35RCIG 1981	GEARCASE
E35RCND 1982	GEARCASE
E35RLCIG 1981	GEARCASE
E35RLCND 1982	GEARCASE
E35TCSM 1980	GEARCASE - 25
E35TCSM 1980	GEARCASE - 35
E35TELCNB 1982	GEARCASE
E35TLESM 1980	GEARCASE - 25
E35TLESM 1980	GEARCASE - 35
HE25RAEUM 1997	JET DRIVE UNIT
HJ25RAEUM 1997	JET DRIVE UNIT
J20CREUM 1997	JET DRIVE UNIT
J20CRLEUM 1997	JET DRIVE UNIT
J25ECIB 1981	GEARCASE
J25ECIM 1981	GEARCASE
J25ECNE 1982	GEARCASE
J25ECRS 1984	GEARCASE
J25ECTD 1983	GEARCASE
J25ELCIB 1981	GEARCASE
J25ELCIM 1981	GEARCASE
J25ELCNE 1982	GEARCASE
J25ELCRS 1984	GEARCASE
J25ELCTD 1983	GEARCASE
J25JRECA 1998	JET DRIVE UNIT
J25JREDC 1996	JET DRIVE UNIT
J25JREEM 1999	JET DRIVE UNIT -- 25JR
J25JREEN 1999	JET DRIVE UNIT -- 25JR
J25JREOS 1995	JET DRIVE UNIT
J25JREUR 1997	JET DRIVE UNIT
J25JRSIE jet drive, rope start, tiller, 15 in shaft 2001	JET DRIVE UNIT - 25JR
J25JRSSB Jet Drive,Rope Start, Tiller, 20 IN. shaft 2000	JET DRIVE UNIT - 25JR

J25RCIM 1981	GEARCASE
J25RCNB 1982	GEARCASE
J25RCRD 1984	GEARCASE
J25RCSA 1980	GEARCASE - 25
J25RCSA 1980	GEARCASE - 35
J25RCTE 1983	GEARCASE
J25RECB 1998	JET DRIVE UNIT
J25REEB 1999	JET DRIVE UNIT -- 25JR
J25REEN 1999	JET DRIVE UNIT -- 25JR
J25RELCNB 1982	GEARCASE
J25REUM 1997	JET DRIVE UNIT
J25RLCIM 1981	GEARCASE
J25RLCNB 1982	GEARCASE
J25RLCRD 1984	GEARCASE
J25RLCSA 1980	GEARCASE - 25
J25RLCSA 1980	GEARCASE - 35
J25RLCTE 1983	GEARCASE
J25RLECB 1998	JET DRIVE UNIT
J25RLEEB 1999	JET DRIVE UNIT -- 25JR
J25RLEEN 1999	JET DRIVE UNIT -- 25JR
J25RLEUM 1997	JET DRIVE UNIT
J25RLSID rope start, tiller, 20 in shaft 2001	JET DRIVE UNIT - 25JR
J25RLSSE Rope Start, Tiller, 20 IN. shaft 2000	JET DRIVE UNIT - 25JR
J25RSA 1981	GEARCASE
J25RSID rope start, tiller, 15 in shaft 2001	JET DRIVE UNIT - 25JR
J25RSLA 1981	GEARCASE
J25RSLS 1983	GEARCASE
J25RSS 1983	GEARCASE
J25RSSE Rope Start, Tiller, 15 IN. shaft 2000	JET DRIVE UNIT - 25JR
J25RVLSID rope start, tiller, 20 in shaft, wht 2001	JET DRIVE UNIT - 25JR
J25RVSID rope start, tiller, 15 in shaft, wht 2001	JET DRIVE UNIT - 25JR
J25RWCM 1981	GEARCASE
J25RWCRD 1984	GEARCASE
J25RWCTE 1983	GEARCASE
J25RWLCIM 1981	GEARCASE

J25RWLCRD 1984	GEARCASE
J25RWLCTE 1983	GEARCASE
J25TECIM 1981	GEARCASE
J25TECNB 1982	GEARCASE
J25TECRD 1984	GEARCASE
J25TECSA 1980	GEARCASE - 25
J25TECSA 1980	GEARCASE - 35
J25TECTE 1983	GEARCASE
J25TELCIM 1981	GEARCASE
J25TELCRD 1984	GEARCASE
J25TELCSA 1980	GEARCASE - 25
J25TELCSA 1980	GEARCASE - 35
J25TELCTE 1983	GEARCASE
J30REEC 1999	JET DRIVE UNIT -- 25JR
J30REEN 1999	JET DRIVE UNIT -- 25JR
J30REUD 1997	JET DRIVE UNIT
J30RLEEC 1999	JET DRIVE UNIT -- 25JR
J30RLEEN 1999	JET DRIVE UNIT -- 25JR
J30RLEUD 1997	JET DRIVE UNIT
J30RLSIA rope start, tiller, 20 in shaft 2001	JET DRIVE UNIT - 25JR
J30RLSSR Rope Start, Tiller, 20 IN. shaft 2000	JET DRIVE UNIT - 25JR
J30RSIA rope start, tiller, 15 in shaft 2001	JET DRIVE UNIT - 25JR
J30RSSR Rope Start, Tiller, 15 IN. shaft 2000	JET DRIVE UNIT - 25JR
J30RVLSIA rope start, tiller, 20 in shaft, wht 2001	JET DRIVE UNIT - 25JR
J30RVSIA rope start, tiller, 15 in shaft, wht 2001	JET DRIVE UNIT - 25JR
J35ECIG 1981	GEARCASE
J35ECND 1982	GEARCASE
J35ECSM 1980	GEARCASE - 25
J35ECSM 1980	GEARCASE - 35
J35ELCIG 1981	GEARCASE
J35ELCND 1982	GEARCASE
J35ELCSM 1980	GEARCASE - 25
J35ELCSM 1980	GEARCASE - 35
J35RCIG 1981	GEARCASE
J35RCND 1982	GEARCASE

J35RCSM 1980	GEARCASE - 25
J35RCSM 1980	GEARCASE - 35
J35RLCIG 1981	GEARCASE
J35RLCND 1982	GEARCASE
J35RLCSM 1980	GEARCASE - 25
J35RLCSM 1980	GEARCASE - 35
J35TELCNB 1982	GEARCASE
SE25RDECA 1998	JET DRIVE UNIT
SE25RDEEM 1999	JET DRIVE UNIT -- 25JR
SE25RDEEN 1999	JET DRIVE UNIT -- 25JR
SE25RDEUR 1997	JET DRIVE UNIT
SE25RDSIE rope start, tiller, 15 in shaft, n/a usa 2001	JET DRIVE UNIT - 25JR
SE25RDSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	JET DRIVE UNIT - 25JR
SJ25RDECA 1998	JET DRIVE UNIT
SJ25RDEEM 1999	JET DRIVE UNIT -- 25JR
SJ25RDEEMN 1999	JET DRIVE UNIT -- 25JR
SJ25RDEUR 1997	JET DRIVE UNIT
SJ25RTEEM 1999	JET DRIVE UNIT -- 25JR
SJ25RTSIE rope start, tiller, 15 in shaft, n/a usa 2001	JET DRIVE UNIT - 25JR
SJ25RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	JET DRIVE UNIT - 25JR