

Where Used: Part Number 0322435

Model Name	Diagram
10624G 1976	MAGNETO
10624H 1976	MAGNETO
10624R 1976	MAGNETO
10625G 1976	MAGNETO
10625H 1976	MAGNETO
10625R 1976	MAGNETO
10654G 1976	MAGNETO
10654H 1976	MAGNETO
10654R 1976	MAGNETO
10655G 1976	MAGNETO
10655H 1976	MAGNETO
10655R 1976	MAGNETO
10724A 1977	MAGNETO
10725A 1977	MAGNETO
10754A 1977	MAGNETO
10755A 1977	MAGNETO
10824M 1978	MAGNETO
10825M 1978	MAGNETO
10835M 1978	MAGNETO
10854M 1978	MAGNETO
10855M 1978	MAGNETO
10924B 1979	MAGNETO
10925B 1979	MAGNETO
10935B 1979	MAGNETO
10955B 1979	MAGNETO
10E76G 1976	MAGNETO
10E76H 1976	MAGNETO
10E76R 1976	MAGNETO
10E77A 1977	MAGNETO
10E78M 1978	MAGNETO
10EL76G 1976	MAGNETO
10EL76H 1976	MAGNETO
10EL76R 1976	MAGNETO

10EL77A 1977	MAGNETO
10EL78M 1978	MAGNETO
10EL79B 1979	MAGNETO
10R76G 1976	MAGNETO
10R76H 1976	MAGNETO
10R76R 1976	MAGNETO
10R77A 1977	MAGNETO
10R78M 1978	MAGNETO
10R79B 1979	MAGNETO
10RL76G 1976	MAGNETO
10RL76H 1976	MAGNETO
10RL76R 1976	MAGNETO
10RL77A 1977	MAGNETO
10RL78M 1978	MAGNETO
10RL79B 1979	MAGNETO
10SEL78M 1978	MAGNETO
10SEL79B 1979	MAGNETO
15604A 1976	MAGNETO
15604R 1976	MAGNETO
15605A 1976	MAGNETO
15605R 1976	MAGNETO
15654A 1976	MAGNETO
15654R 1976	MAGNETO
15655A 1976	MAGNETO
15655R 1976	MAGNETO
15704M 1977	MAGNETO
15705M 1977	MAGNETO
15754M 1977	MAGNETO
15804B 1978	MAGNETO
15805B 1978	MAGNETO
15854B 1978	MAGNETO
15855B 1978	MAGNETO
15904E 1979	MAGNETO
15905E 1979	MAGNETO
15954E 1979	MAGNETO

15955E 1979	MAGNETO
15E76A 1976	MAGNETO
15E76R 1976	MAGNETO
15E77M 1977	MAGNETO
15E78B 1978	MAGNETO
15E79E 1979	MAGNETO
15EL76A 1976	MAGNETO
15EL76R 1976	MAGNETO
15EL77M 1977	MAGNETO
15EL78B 1978	MAGNETO
15EL79E 1979	MAGNETO
15R76A 1976	MAGNETO
15R76R 1976	MAGNETO
15R77M 1977	MAGNETO
15R78B 1978	MAGNETO
15R79E 1979	MAGNETO
15RL76A 1976	MAGNETO
15RL76R 1976	MAGNETO
15RL77M 1977	MAGNETO
15RL78B 1978	MAGNETO
15RL79E 1979	MAGNETO
25702H 1977	MAGNETO
25702S 1977	MAGNETO
25703H 1977	MAGNETO
25703S 1977	MAGNETO
25752H 1977	MAGNETO
25752S 1977	MAGNETO
25753H 1977	MAGNETO
25753S 1977	MAGNETO
25802C 1978	MAGNETO
25803C 1978	MAGNETO
25852C 1978	MAGNETO
25853C 1978	MAGNETO
25904R 1979	MAGNETO
25905R 1979	MAGNETO

25952R 1979	MAGNETO
25953R 1979	MAGNETO
25E77S 1977	MAGNETO
25E78C 1978	MAGNETO
25E79R 1979	MAGNETO
25EL77H 1977	MAGNETO
25EL77S 1977	MAGNETO
25EL78C 1978	MAGNETO
25EL79R 1979	MAGNETO
25R77H 1977	MAGNETO
25R77S 1977	MAGNETO
25R78C 1978	MAGNETO
25R79R 1979	MAGNETO
25RL77H 1977	MAGNETO
25RL77S 1977	MAGNETO
25RL78C 1978	MAGNETO
25RL79R 1979	MAGNETO
35602G 1976	MAGNETO
35602S 1976	MAGNETO
35603G 1976	MAGNETO
35603S 1976	MAGNETO
35652G 1976	MAGNETO
35652S 1976	MAGNETO
35653G 1976	MAGNETO
35653S 1976	MAGNETO
35702C 1977	MAGNETO
35702H 1977	MAGNETO
35703C 1977	MAGNETO
35703H 1977	MAGNETO
35752C 1977	MAGNETO
35752H 1977	MAGNETO
35753C 1977	MAGNETO
35753H 1977	MAGNETO
35802R 1978	MAGNETO
35803R 1978	MAGNETO

35852R 1978	MAGNETO
35853R 1978	MAGNETO
35902A 1979	MAGNETO
35903A 1979	MAGNETO
35952A 1979	MAGNETO
35953A 1979	MAGNETO
35E76G 1976	MAGNETO
35E76S 1976	MAGNETO
35E77C 1977	MAGNETO
35E77H 1977	MAGNETO
35E78R 1978	MAGNETO
35E79A 1979	MAGNETO
35EL76G 1976	MAGNETO
35EL76S 1976	MAGNETO
35EL77C 1977	MAGNETO
35EL77H 1977	MAGNETO
35EL78R 1978	MAGNETO
35EL79A 1979	MAGNETO
35R76G 1976	MAGNETO
35R76S 1976	MAGNETO
35R77C 1977	MAGNETO
35R77H 1977	MAGNETO
35R78R 1978	MAGNETO
35R79A 1979	MAGNETO
35RL76G 1976	MAGNETO
35RL76S 1976	MAGNETO
35RL77C 1977	MAGNETO
35RL77H 1977	MAGNETO
35RL78R 1978	MAGNETO
35RL79A 1979	MAGNETO
40604A 1976	MAGNETO
40604R 1976	MAGNETO
40605A 1976	MAGNETO
40605R 1976	MAGNETO
40654A 1976	MAGNETO

40654R 1976	MAGNETO
40655A 1976	MAGNETO
40655R 1976	MAGNETO
40E76A 1976	MAGNETO
40E76R 1976	MAGNETO
40EL76A 1976	MAGNETO
40EL76R 1976	MAGNETO
40R76A 1976	MAGNETO
40R76R 1976	MAGNETO
40RL76A 1976	MAGNETO
40RL76R 1976	MAGNETO
4706B 1977	MAGNETO
4736B 1977	MAGNETO
4806E 1978	MAGNETO
4836E 1978	MAGNETO
4837E 1978	MAGNETO
4904D 1979	MAGNETO
4932D 1979	MAGNETO
4933D 1979	MAGNETO
4R77B 1977	MAGNETO
4R78E 1978	MAGNETO
4R79D 1979	MAGNETO
4RL78E 1978	MAGNETO
4RL79D 1979	MAGNETO
4W77B 1977	MAGNETO
4W78E 1978	MAGNETO
4W79D 1979	MAGNETO
50902C 1979	IGNITION SYSTEM
50903C 1979	IGNITION SYSTEM
50R79C 1979	IGNITION SYSTEM
50RL79C 1979	IGNITION SYSTEM
55874S 1978	IGNITION SYSTEM
55875S 1978	IGNITION SYSTEM
55974C 1979	IGNITION SYSTEM
55975C 1979	IGNITION SYSTEM

55E78S 1978	IGNITION SYSTEM
55E79C 1979	IGNITION SYSTEM
55EL78S 1978	IGNITION SYSTEM
55EL79C 1979	IGNITION SYSTEM
6704M 1977	MAGNETO
6705M 1977	MAGNETO
6804B 1978	MAGNETO
6805B 1978	MAGNETO
6904E 1979	MAGNETO
6905E 1979	MAGNETO
6R77M 1977	MAGNETO
6R78B 1978	MAGNETO
6R79E 1979	MAGNETO
6RL77M 1977	MAGNETO
6RL78B 1978	MAGNETO
6RL79E 1979	MAGNETO
AM55RSLD 1999	IGNITION SYSTEM
BE10EEDD 1996	IGNITION - ELECTRIC
BE10EEDD 1996	IGNITION - ROPE
BE10ELEDD 1996	IGNITION - ELECTRIC
BE10ELEDD 1996	IGNITION - ROPE
BE10REDD 1996	IGNITION - ELECTRIC
BE10REDD 1996	IGNITION - ROPE
BE10RELEDD 1996	IGNITION - ELECTRIC
BE10RELEDD 1996	IGNITION - ROPE
BE10RELEUS 1997	IGNITION - ELECTRIC
BE10RELEUS 1997	IGNITION - ROPE
BE10RLEDD 1996	IGNITION - ELECTRIC
BE10RLEDD 1996	IGNITION - ROPE
BE10SELEDD 1996	IGNITION - ELECTRIC
BE10SELEDD 1996	IGNITION - ROPE
BE15EEDS 1996	IGNITION - ELECTRIC
BE15EEDS 1996	IGNITION - ROPE
BE15ELEDS 1996	IGNITION - ELECTRIC
BE15ELEDS 1996	IGNITION - ROPE

BE15REDS 1996	IGNITION - ELECTRIC
BE15REDS 1996	IGNITION - ROPE
BE15RELEUC 1997	IGNITION - ELECTRIC
BE15RELEUC 1997	IGNITION - ROPE
BE15RLEDS 1996	IGNITION - ELECTRIC
BE15RLEDS 1996	IGNITION - ROPE
BE3REDS 1996	IGNITION
BE40EECR 1998	IGNITION SYSTEM -- ROPE START
BE40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40EEUC 1997	IGNITION SYSTEM - ROPE START
BE40ELECR 1998	IGNITION SYSTEM -- ROPE START
BE40ELEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE40ELEUC 1997	IGNITION SYSTEM - ROPE START
BE40TLECR 1998	IGNITION SYSTEM -- ROPE START
BE40TLEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE40TLEUC 1997	IGNITION SYSTEM - ROPE START
BE4BREDS 1996	IGNITION
BE4BREUC 1997	IGNITION
BE4BRLEDs 1996	IGNITION
BE4BRLEUC 1997	IGNITION
BE4RDHEDs 1996	MAGNETO
BE4RDHLEDs 1996	MAGNETO
BE4REDS 1996	IGNITION
BE4RLEDs 1996	IGNITION
BE50BEEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE50BELEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE50ESECC 1998	IGNITION SYSTEM -- ROPE START
BE50RLECR 1998	IGNITION SYSTEM -- ROPE START
BE50RLEUC 1997	IGNITION SYSTEM - ROPE START
BE50TLECR 1998	IGNITION SYSTEM -- ROPE START
BE50TLEDs 1996	IGNITION SYSTEM - 40 ROPE START
BE50TLEUC 1997	IGNITION SYSTEM - ROPE START
BE50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BE50TSLEUS 1997	IGNITION SYSTEM - ROPE START
BE5DREDS 1996	IGNITION

BE5DREUC 1997	IGNITION
BE5DRLEDS 1996	IGNITION
BE5DRLEUC 1997	IGNITION
BE6DRECR 1998	IGNITION
BE6DREDS 1996	IGNITION
BE6DREUC 1997	IGNITION
BE6DRLECR 1998	IGNITION
BE6DRLEDS 1996	IGNITION
BE6DRLEUC 1997	IGNITION
BE6REDS 1996	IGNITION
BE6RLEDS 1996	IGNITION
BE8RCB 1997	IGNITION
BE8RCH 1996	IGNITION
BE8RCLB 1997	IGNITION
BE8RCLH 1996	IGNITION
BE8RCLT 1998	IGNITION
BE8RCT 1998	IGNITION
BE8REDS 1996	IGNITION
BE8RLEDS 1996	IGNITION
BE8SRLEDS 1996	IGNITION
BJ10EEDD 1996	IGNITION - ELECTRIC
BJ10EEDD 1996	IGNITION - ROPE
BJ10ELEDD 1996	IGNITION - ELECTRIC
BJ10ELEDD 1996	IGNITION - ROPE
BJ10REDD 1996	IGNITION - ELECTRIC
BJ10REDD 1996	IGNITION - ROPE
BJ10RELEDD 1996	IGNITION - ELECTRIC
BJ10RELEDD 1996	IGNITION - ROPE
BJ10RELEUS 1997	IGNITION - ELECTRIC
BJ10RELEUS 1997	IGNITION - ROPE
BJ10RHLSDA	IGNITION
BJ10RHLSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSOR	IGNITION
BJ10RHLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSRC	IGNITION

BJ10RHLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSTS	IGNITION
BJ10RHLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSDA	IGNITION
BJ10RHSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSOR	IGNITION
BJ10RHSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSRC	IGNITION
BJ10RHSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSTS	IGNITION
BJ10RHSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RLEDD 1996	IGNITION - ELECTRIC
BJ10RLEDD 1996	IGNITION - ROPE
BJ10SELEDD 1996	IGNITION - ELECTRIC
BJ10SELEDD 1996	IGNITION - ROPE
BJ15EEDS 1996	IGNITION - ELECTRIC
BJ15EEDS 1996	IGNITION - ROPE
BJ15ELEDs 1996	IGNITION - ELECTRIC
BJ15ELEDs 1996	IGNITION - ROPE
BJ15REDS 1996	IGNITION - ELECTRIC
BJ15REDS 1996	IGNITION - ROPE
BJ15RELEUC 1997	IGNITION - ELECTRIC
BJ15RELEUC 1997	IGNITION - ROPE
BJ15RLEDs 1996	IGNITION - ELECTRIC
BJ15RLEDs 1996	IGNITION - ROPE
BJ3REDS 1996	IGNITION
BJ40EECR 1998	IGNITION SYSTEM -- ROPE START
BJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40EEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40EEUC 1997	IGNITION SYSTEM - ROPE START
BJ40ELECR 1998	IGNITION SYSTEM -- ROPE START
BJ40ELEDs 1996	IGNITION SYSTEM - 40 ROPE START
BJ40ELEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40ELEUC 1997	IGNITION SYSTEM - ROPE START
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START

BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ4BREDS 1996	IGNITION
BJ4BREUC 1997	IGNITION
BJ4BRLEDS 1996	IGNITION
BJ4BRLEUC 1997	IGNITION
BJ4RDHEDS 1996	MAGNETO
BJ4RDHLEDS 1996	MAGNETO
BJ4REDS 1996	IGNITION
BJ4RLEDS 1996	IGNITION
BJ50BEEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50BELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50EEER 1999	IGNITION SYSTEM -- ROPE START
BJ50ELEER 1999	IGNITION SYSTEM -- ROPE START
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50ESECC 1998	IGNITION SYSTEM -- ROPE START
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50RLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50RLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50RLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START

BJ50TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BJ50TSLEUS 1997	IGNITION SYSTEM - ROPE START
BJ5DREDS 1996	IGNITION
BJ5DREUC 1997	IGNITION
BJ5DRLEDS 1996	IGNITION
BJ5DRLEUC 1997	IGNITION
BJ6DRECR 1998	IGNITION
BJ6DREDS 1996	IGNITION
BJ6DREUC 1997	IGNITION
BJ6DRLECR 1998	IGNITION
BJ6DRLEDS 1996	IGNITION
BJ6DRLEUC 1997	IGNITION
BJ6REDS 1996	IGNITION
BJ6RLEDS 1996	IGNITION
BJ8RCB 1997	IGNITION
BJ8RCH 1996	IGNITION
BJ8RCLB 1997	IGNITION
BJ8RCLH 1996	IGNITION
BJ8RCLT 1998	IGNITION
BJ8RCT 1998	IGNITION
BJ8REDS 1996	IGNITION
BJ8RLEDS 1996	IGNITION
BJ8SRLEDS 1996	IGNITION
D25RWA 1988	MAGNETO
D25RWLA 1988	MAGNETO
E10ECCD 1988	IGNITION
E10ECDB 1986	IGNITION
E10ECES 1989	IGNITION
E10ECOM 1985	IGNITION
E10ECSE 1980	MAGNETO
E10ECUE 1987	IGNITION
E10EECC 1998	IGNITION -- ELECTRIC

E10EECC 1998	IGNITION -- ROPE
E10EEDD 1996	IGNITION - ELECTRIC
E10EEDD 1996	IGNITION - ROPE
E10EEIR 1991	IGNITION
E10EENA 1992	IGNITION
E10EEOE 1995	IGNITION - ELECTRIC
E10EEOE 1995	IGNITION - ROPE
E10EERB 1994	IGNITION - ELECTRIC
E10EERB 1994	IGNITION - ROPE
E10EESC 1990	IGNITION
E10EETM 1993	IGNITION - ELECTRIC
E10EETM 1993	IGNITION - ROPE
E10EEUS 1997	IGNITION - ELECTRIC
E10EEUS 1997	IGNITION - ROPE
E10ELCCD 1988	IGNITION
E10ELCDB 1986	IGNITION
E10ELCES 1989	IGNITION
E10ELCID 1981	MAGNETO
E10ELCNS 1982	MAGNETO
E10ELCOM 1985	IGNITION
E10ELCRA 1984	MAGNETO
E10ELCSE 1980	MAGNETO
E10ELCTC 1983	MAGNETO
E10ELCUE 1987	IGNITION
E10ELECC 1998	IGNITION -- ELECTRIC
E10ELECC 1998	IGNITION -- ROPE
E10ELEDD 1996	IGNITION - ELECTRIC
E10ELEDD 1996	IGNITION - ROPE
E10ELEIR 1991	IGNITION
E10ELENA 1992	IGNITION
E10ELEOE 1995	IGNITION - ELECTRIC
E10ELEOE 1995	IGNITION - ROPE
E10ELERB 1994	IGNITION - ELECTRIC
E10ELERB 1994	IGNITION - ROPE
E10ELESC 1990	IGNITION

E10ELETM 1993	IGNITION - ELECTRIC
E10ELETM 1993	IGNITION - ROPE
E10ELEUS 1997	IGNITION - ELECTRIC
E10ELEUS 1997	IGNITION - ROPE
E10RCCD 1988	IGNITION
E10RCDB 1986	IGNITION
E10RCES 1989	IGNITION
E10RCID 1981	MAGNETO
E10RCNS 1982	MAGNETO
E10RCOM 1985	IGNITION
E10RCRA 1984	MAGNETO
E10RCSE 1980	MAGNETO
E10RCTC 1983	MAGNETO
E10RCTR 1983	MAGNETO
E10RCUE 1987	IGNITION
E10RECC 1998	IGNITION -- ELECTRIC
E10RECC 1998	IGNITION -- ROPE
E10REDD 1996	IGNITION - ELECTRIC
E10REDD 1996	IGNITION - ROPE
E10REIR 1991	IGNITION
E10RELECC 1998	IGNITION -- ELECTRIC
E10RELECC 1998	IGNITION -- ROPE
E10RELEDD 1996	IGNITION - ELECTRIC
E10RELEDD 1996	IGNITION - ROPE
E10RELEIR 1991	IGNITION
E10RELENA 1992	IGNITION
E10RELEOE 1995	IGNITION - ELECTRIC
E10RELEOE 1995	IGNITION - ROPE
E10RELERB 1994	IGNITION - ELECTRIC
E10RELERB 1994	IGNITION - ROPE
E10RELESC 1990	IGNITION
E10RELETM 1993	IGNITION - ELECTRIC
E10RELETM 1993	IGNITION - ROPE
E10RELEUS 1997	IGNITION - ELECTRIC
E10RELEUS 1997	IGNITION - ROPE

E10RENA 1992	IGNITION
E10REOE 1995	IGNITION - ELECTRIC
E10REOE 1995	IGNITION - ROPE
E10RERB 1994	IGNITION - ELECTRIC
E10RERB 1994	IGNITION - ROPE
E10RESC 1990	IGNITION
E10RETM 1993	IGNITION - ELECTRIC
E10RETM 1993	IGNITION - ROPE
E10REUS 1997	IGNITION - ELECTRIC
E10REUS 1997	IGNITION - ROPE
E10RLCCD 1988	IGNITION
E10RLCDB 1986	IGNITION
E10RLCES 1989	IGNITION
E10RLCID 1981	MAGNETO
E10RLCNS 1982	MAGNETO
E10RLCOM 1985	IGNITION
E10RLCRA 1984	MAGNETO
E10RLCSE 1980	MAGNETO
E10RLCTC 1983	MAGNETO
E10RLCUE 1987	IGNITION
E10RLECC 1998	IGNITION -- ELECTRIC
E10RLECC 1998	IGNITION -- ROPE
E10RLEDD 1996	IGNITION - ELECTRIC
E10RLEDD 1996	IGNITION - ROPE
E10RLEIR 1991	IGNITION
E10RLENA 1992	IGNITION
E10RLEOE 1995	IGNITION - ELECTRIC
E10RLEOE 1995	IGNITION - ROPE
E10RLERB 1994	IGNITION - ELECTRIC
E10RLERB 1994	IGNITION - ROPE
E10RLESC 1990	IGNITION
E10RLETM 1993	IGNITION - ELECTRIC
E10RLETM 1993	IGNITION - ROPE
E10RLEUS 1997	IGNITION - ELECTRIC
E10RLEUS 1997	IGNITION - ROPE

E10SELCCD 1988	IGNITION
E10SELCDB 1986	IGNITION
E10SELCES 1989	IGNITION
E10SELCID 1981	MAGNETO
E10SELCNS 1982	MAGNETO
E10SELCOM 1985	IGNITION
E10SELCRA 1984	MAGNETO
E10SELCSE 1980	MAGNETO
E10SELCTC 1983	MAGNETO
E10SELCUE 1987	IGNITION
E10SELECC 1998	IGNITION -- ELECTRIC
E10SELECC 1998	IGNITION -- ROPE
E10SELEDD 1996	IGNITION - ELECTRIC
E10SELEDD 1996	IGNITION - ROPE
E10SELEIR 1991	IGNITION
E10SELENA 1992	IGNITION
E10SELEOE 1995	IGNITION - ELECTRIC
E10SELEOE 1995	IGNITION - ROPE
E10SELERB 1994	IGNITION - ELECTRIC
E10SELERB 1994	IGNITION - ROPE
E10SELESC 1990	IGNITION
E10SELETM 1993	IGNITION - ELECTRIC
E10SELETM 1993	IGNITION - ROPE
E10SELEUS 1997	IGNITION - ELECTRIC
E10SELEUS 1997	IGNITION - ROPE
E15ECCS 1988	IGNITION
E15ECDE 1986	IGNITION
E15ECEC 1989	IGNITION
E15ECIS 1981	MAGNETO
E15ECNC 1982	MAGNETO
E15ECOB 1985	IGNITION
E15ECRM 1984	MAGNETO
E15ECSD 1980	MAGNETO
E15ECTR 1983	MAGNETO
E15ECUD 1987	IGNITION

E15EECR 1998	IGNITION -- ELECTRIC
E15EECR 1998	IGNITION -- ROPE
E15EEDS 1996	IGNITION - ELECTRIC
E15EEDS 1996	IGNITION - ROPE
E15EEIA 1991	IGNITION
E15EENM 1992	IGNITION
E15EEOD 1995	IGNITION - ELECTRIC
E15EEOD 1995	IGNITION - ROPE
E15EERE 1994	IGNITION - ELECTRIC
E15EERE 1994	IGNITION - ROPE
E15EESR 1990	IGNITION
E15EETB 1993	IGNITION - ELECTRIC
E15EETB 1993	IGNITION - ROPE
E15EEUC 1997	IGNITION - ELECTRIC
E15EEUC 1997	IGNITION - ROPE
E15ELCCS 1988	IGNITION
E15ELCDE 1986	IGNITION
E15ELCEC 1989	IGNITION
E15ELCOB 1985	IGNITION
E15ELCRM 1984	MAGNETO
E15ELCSD 1980	MAGNETO
E15ELCTR 1983	MAGNETO
E15ELCUD 1987	IGNITION
E15ELECR 1998	IGNITION -- ELECTRIC
E15ELECR 1998	IGNITION -- ROPE
E15ELEDS 1996	IGNITION - ELECTRIC
E15ELEDS 1996	IGNITION - ROPE
E15ELEIA 1991	IGNITION
E15ELENM 1992	IGNITION
E15ELEOD 1995	IGNITION - ELECTRIC
E15ELEOD 1995	IGNITION - ROPE
E15ELERE 1994	IGNITION - ELECTRIC
E15ELERE 1994	IGNITION - ROPE
E15ELESR 1990	IGNITION
E15ELETB 1993	IGNITION - ELECTRIC

E15ELETB 1993	IGNITION - ROPE
E15ELEUC 1997	IGNITION - ELECTRIC
E15ELEUC 1997	IGNITION - ROPE
E15RCCS 1988	IGNITION
E15RCDE 1986	IGNITION
E15RCEC 1989	IGNITION
E15RCIS 1981	MAGNETO
E15RCNC 1982	MAGNETO
E15RCOB 1985	IGNITION
E15RCRM 1984	MAGNETO
E15RCSD 1980	MAGNETO
E15RCTA 1983	MAGNETO
E15RCTR 1983	MAGNETO
E15RCUD 1987	IGNITION
E15RECR 1998	IGNITION -- ELECTRIC
E15RECR 1998	IGNITION -- ROPE
E15REDS 1996	IGNITION - ELECTRIC
E15REDS 1996	IGNITION - ROPE
E15REIA 1991	IGNITION
E15RELECR 1998	IGNITION -- ELECTRIC
E15RELECR 1998	IGNITION -- ROPE
E15RELEDS 1996	IGNITION - ELECTRIC
E15RELEDS 1996	IGNITION - ROPE
E15RELEIA 1991	IGNITION
E15RELENM 1992	IGNITION
E15RELEOD 1995	IGNITION - ELECTRIC
E15RELEOD 1995	IGNITION - ROPE
E15RELERE 1994	IGNITION - ELECTRIC
E15RELERE 1994	IGNITION - ROPE
E15RELESR 1990	IGNITION
E15RELETB 1993	IGNITION - ELECTRIC
E15RELETB 1993	IGNITION - ROPE
E15RELEUC 1997	IGNITION - ELECTRIC
E15RELEUC 1997	IGNITION - ROPE
E15RENM 1992	IGNITION

E15REOD 1995	IGNITION - ELECTRIC
E15REOD 1995	IGNITION - ROPE
E15RERE 1994	IGNITION - ELECTRIC
E15RERE 1994	IGNITION - ROPE
E15RESR 1990	IGNITION
E15RETB 1993	IGNITION - ELECTRIC
E15RETB 1993	IGNITION - ROPE
E15REUC 1997	IGNITION - ELECTRIC
E15REUC 1997	IGNITION - ROPE
E15RLCCS 1988	IGNITION
E15RLCDE 1986	IGNITION
E15RLCEC 1989	IGNITION
E15RLCIS 1981	MAGNETO
E15RLCNC 1982	MAGNETO
E15RLCOB 1985	IGNITION
E15RLCRM 1984	MAGNETO
E15RLCSD 1980	MAGNETO
E15RLCTA 1983	MAGNETO
E15RLCTR 1983	MAGNETO
E15RLCUD 1987	IGNITION
E15RLECR 1998	IGNITION -- ELECTRIC
E15RLECR 1998	IGNITION -- ROPE
E15RLEDS 1996	IGNITION - ELECTRIC
E15RLEDS 1996	IGNITION - ROPE
E15RLEIA 1991	IGNITION
E15RLENM 1992	IGNITION
E15RLEOD 1995	IGNITION - ELECTRIC
E15RLEOD 1995	IGNITION - ROPE
E15RLERE 1994	IGNITION - ELECTRIC
E15RLERE 1994	IGNITION - ROPE
E15RLESR 1990	IGNITION
E15RLETB 1993	IGNITION - ELECTRIC
E15RLETB 1993	IGNITION - ROPE
E15RLEUC 1997	IGNITION - ELECTRIC
E15RLEUC 1997	IGNITION - ROPE

E15WREES 1999	IGNITION
E15WRLEES 1999	IGNITION
E15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
E15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
E20CRCCA 1988	IGNITION
E20CRCDC 1986	IGNITION
E20CRCEM 1989	IGNITION
E20CRCOS 1985	IGNITION
E20CRCUR 1987	IGNITION
E20CREIE 1991	IGNITION
E20CREND 1992	IGNITION
E20CRESB 1990	IGNITION
E20CRLCCA 1988	IGNITION
E20CRLCDC 1986	IGNITION
E20CRLCEM 1989	IGNITION
E20CRLCOS 1985	IGNITION
E20CRLCUR 1987	IGNITION
E20CRLEIE 1991	IGNITION
E20CRLEND 1992	IGNITION
E20CRLESB 1990	IGNITION
E20ECCA 1988	IGNITION
E20ECDC 1986	IGNITION
E20ECEM 1989	IGNITION
E20ECOS 1985	IGNITION
E20ECUR 1987	IGNITION
E20EEIE 1991	IGNITION
E20EEND 1992	IGNITION
E20EESB 1990	IGNITION
E20ELCCA 1988	IGNITION
E20ELCDC 1986	IGNITION
E20ELCEM 1989	IGNITION
E20ELCOS 1985	IGNITION
E20ELCUR 1987	IGNITION

E20ELEIE 1991	IGNITION
E20ELEND 1992	IGNITION
E20ELESB 1990	IGNITION
E20TECDC 1986	IGNITION
E25CNE 1982	MAGNETO
E25ECCM 1988	IGNITION
E25ECDR 1986	IGNITION
E25ECEB 1989	IGNITION
E25ECIB 1981	MAGNETO
E25ECIM 1981	MAGNETO
E25ECOC 1985	IGNITION
E25ECRS 1984	IGNITION
E25ECTD 1983	MAGNETO
E25ECUA 1987	IGNITION
E25EEID 1991	IGNITION
E25EENS 1992	IGNITION
E25EESE 1990	IGNITION
E25ELCCM 1988	IGNITION
E25ELCDR 1986	IGNITION
E25ELCEB 1989	IGNITION
E25ELCIB 1981	MAGNETO
E25ELCIM 1981	MAGNETO
E25ELCNE 1982	MAGNETO
E25ELCOC 1985	IGNITION
E25ELCRS 1984	IGNITION
E25ELCTD 1983	MAGNETO
E25ELCUA 1987	IGNITION
E25ELEID 1991	IGNITION
E25ELENS 1992	IGNITION
E25ELESE 1990	IGNITION
E25RCCA 1988	IGNITION
E25RCDC 1986	IGNITION
E25RCEM 1989	IGNITION
E25RCIM 1981	MAGNETO
E25RCNB 1982	MAGNETO

E25RCOS 1985	IGNITION
E25RCRD 1984	IGNITION
E25RCSA 1980	MAGNETO
E25RCTE 1983	MAGNETO
E25RCUR 1987	IGNITION
E25REIE 1991	IGNITION
E25REND 1992	IGNITION
E25RESB 1990	IGNITION
E25RLCCA 1988	IGNITION
E25RLCDC 1986	IGNITION
E25RLCEM 1989	IGNITION
E25RLCIM 1981	MAGNETO
E25RLCNB 1982	MAGNETO
E25RLCOS 1985	IGNITION
E25RLCRD 1984	IGNITION
E25RLCSA 1980	MAGNETO
E25RLCTE 1983	MAGNETO
E25RLCUR 1987	IGNITION
E25RLEIE 1991	IGNITION
E25RLEND 1992	IGNITION
E25RLESB 1990	IGNITION
E25RSA 1981	MAGNETO
E25RSLA 1981	MAGNETO
E25RSLS 1983	MAGNETO
E25RSS 1983	MAGNETO
E25RWCDC 1986	MAGNETO
E25RWCIM 1981	MAGNETO
E25RWCOS 1985	MAGNETO
E25RWCRD 1984	MAGNETO
E25RWCTE 1983	MAGNETO
E25RWCUR 1987	MAGNETO
E25RWEIM 1991	IGNITION
E25RWENB 1992	IGNITION
E25RWESA 1990	IGNITION
E25RWK 1989	IGNITION

E25RWLCDC 1986	MAGNETO
E25RWLCIM 1981	MAGNETO
E25RWLCOS 1985	MAGNETO
E25RWLCRD 1984	MAGNETO
E25RWLCTE 1983	MAGNETO
E25RWLCUR 1987	MAGNETO
E25RWLEIM 1991	IGNITION
E25RWLENB 1992	IGNITION
E25RWLESA 1990	IGNITION
E25RWLK 1989	IGNITION
E25TECCA 1988	IGNITION
E25TECDC 1986	IGNITION
E25TECEM 1989	IGNITION
E25TECIM 1981	MAGNETO
E25TECNB 1982	MAGNETO
E25TECOS 1985	IGNITION
E25TECRD 1984	IGNITION
E25TECSA 1980	MAGNETO
E25TECTE 1983	MAGNETO
E25TECUR 1987	IGNITION
E25TEEIE 1991	IGNITION
E25TEEND 1992	IGNITION
E25TEESB 1990	IGNITION
E25TELCCA 1988	IGNITION
E25TELCDC 1986	IGNITION
E25TELCEM 1989	IGNITION
E25TELCIM 1981	MAGNETO
E25TELCNB 1982	MAGNETO
E25TELCOS 1985	IGNITION
E25TELCRD 1984	IGNITION
E25TELCSA 1980	MAGNETO
E25TELCTE 1983	MAGNETO
E25TELCUR 1987	IGNITION
E25TELEIE 1991	IGNITION
E25TELEND 1992	IGNITION

E25TELESB 1990	IGNITION
E25WREEN 1999	IGNITION
E25WREES 1999	IGNITION
E25WRLEEN 1999	IGNITION
E25WRLEES 1999	IGNITION
E25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
E25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
E28ELCDS 1986	MAGNETO
E28ESLCCR 1988	IGNITION
E28ESLCEA 1989	IGNITION
E28ESLCUC 1987	MAGNETO
E28ESLEIB 1991	IGNITION
E28ESLENE 1992	IGNITION
E28ESLESM 1990	IGNITION
E30ECCE 1988	IGNITION
E30ECDM 1986	IGNITION
E30ECED 1989	IGNITION
E30ECOA 1985	IGNITION
E30ECRR 1984	IGNITION
E30ECUB 1987	IGNITION
E30EEIC 1991	IGNITION
E30EENR 1992	IGNITION
E30EESS 1990	IGNITION
E30ELCCE 1988	IGNITION
E30ELCDM 1986	IGNITION
E30ELCED 1989	IGNITION
E30ELCOA 1985	IGNITION
E30ELCRR 1984	IGNITION
E30ELCUB 1987	IGNITION
E30ELEIC 1991	IGNITION
E30ELENR 1992	IGNITION
E30ELESS 1990	IGNITION
E30RCCE 1988	IGNITION

E30RCDM 1986	IGNITION
E30RCED 1989	IGNITION
E30RCOA 1985	IGNITION
E30RCUB 1987	IGNITION
E30REIC 1991	IGNITION
E30RENr 1992	IGNITION
E30RESS 1990	IGNITION
E30RLCCE 1988	IGNITION
E30RLCDM 1986	IGNITION
E30RLCED 1989	IGNITION
E30RLCOA 1985	IGNITION
E30RLCUB 1987	IGNITION
E30RLEIC 1991	IGNITION
E30RLENr 1992	IGNITION
E30RLESS 1990	IGNITION
E30TECCE 1988	IGNITION
E30TECDM 1986	IGNITION
E30TECED 1989	IGNITION
E30TECOA 1985	IGNITION
E30TECUB 1987	IGNITION
E30TEEIC 1991	IGNITION
E30TEENr 1992	IGNITION
E30TEESS 1990	IGNITION
E30TELCCE 1988	IGNITION
E30TELCDM 1986	IGNITION
E30TELCED 1989	IGNITION
E30TELCOA 1985	IGNITION
E30TELCUB 1987	IGNITION
E30TELEIC 1991	IGNITION
E30TELENr 1992	IGNITION
E30TELESS 1990	IGNITION
E35AELCDE 1986	IGNITION SYSTEM
E35AELCUD 1987	IGNITION SYSTEM
E35ARLCDE 1986	IGNITION SYSTEM
E35ARLCUD 1987	IGNITION SYSTEM

E35ECIG 1981	MAGNETO
E35ECND 1982	MAGNETO
E35ECRR 1984	IGNITION
E35ECSM 1980	MAGNETO
E35ECTS 1983	MAGNETO
E35ELCIG 1981	MAGNETO
E35ELCND 1982	MAGNETO
E35ELCRR 1984	IGNITION
E35ELCSM 1980	MAGNETO
E35ELCTS 1983	MAGNETO
E35RCCE 1988	IGNITION
E35RCDM 1986	IGNITION
E35RCED 1989	IGNITION
E35RCIG 1981	MAGNETO
E35RCND 1982	MAGNETO
E35RCRR 1984	IGNITION
E35RCTS 1983	MAGNETO
E35RCUB 1987	IGNITION
E35REIC 1991	IGNITION
E35RENr 1992	IGNITION
E35RESS 1990	IGNITION
E35RLCCE 1988	IGNITION
E35RLCDM 1986	IGNITION
E35RLCED 1989	IGNITION
E35RLCIG 1981	MAGNETO
E35RLCND 1982	MAGNETO
E35RLCRR 1984	IGNITION
E35RLCTS 1983	MAGNETO
E35RLCUB 1987	IGNITION
E35RLEIC 1991	IGNITION
E35RLENr 1992	IGNITION
E35RLESS 1990	IGNITION
E35TCSM 1980	MAGNETO
E35TELCNB 1982	MAGNETO
E35TELCRR 1984	IGNITION

E35TELCTS 1983	MAGNETO
E35TLESM 1980	MAGNETO
E3REIA 1991	IGNITION
E3RENM 1992	IGNITION
E3REOD 1995	IGNITION
E3RERE 1994	IGNITION
E3RETB 1993	IGNITION
E3REUC 1997	IGNITION
E40AELCCS 1988	IGNITION SYSTEM
E40ARLCCS 1988	IGNITION SYSTEM
E40ATLCCS 1988	IGNITION SYSTEM
E40ECCS 1988	IGNITION SYSTEM
E40ECDE 1986	IGNITION SYSTEM
E40ECEC 1989	IGNITION SYSTEM - ROPE START
E40ECEC 1989	IGNITION SYSTEM - ELECTRIC START
E40ECEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40ECEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40ECOB 1985	IGNITION SYSTEM
E40ECRM 1984	IGNITION SYSTEM
E40ECUD 1987	IGNITION SYSTEM
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EEIA 1991	IGNITION SYSTEM - ROPE START
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EENJ 1992	IGNITION SYSTEM - ROPE START
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40EENM 1992	IGNITION SYSTEM - ROPE START
E40EEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40EERE 1994	IGNITION SYSTEM - 40 ROPE START
E40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

E40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40EESR 1990	IGNITION SYSTEM - ROPE START
E40EETB 1993	IGNITION SYSTEM - 40 ROPE START
E40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELCCS 1988	IGNITION SYSTEM
E40ELCDE 1986	IGNITION SYSTEM
E40ELCEC 1989	IGNITION SYSTEM - ROPE START
E40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40ELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40ELCOB 1985	IGNITION SYSTEM
E40ELCRM 1984	IGNITION SYSTEM
E40ELCUD 1987	IGNITION SYSTEM
E40ELECR 1998	IGNITION SYSTEM -- ROPE START
E40ELEDs 1996	IGNITION SYSTEM - 40 ROPE START
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELEIA 1991	IGNITION SYSTEM - ROPE START
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENJ 1992	IGNITION SYSTEM - ROPE START
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40ELENM 1992	IGNITION SYSTEM - ROPE START
E40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40ELESR 1990	IGNITION SYSTEM - ROPE START

E40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELEUC 1997	IGNITION SYSTEM - ROPE START
E40JRECA 1998	IGNITION SYSTEM
E40JREDC 1996	IGNITION SYSTEM
E40JREOS 1995	IGNITION SYSTEM
E40JREUR 1997	IGNITION SYSTEM
E40RCCS 1988	IGNITION SYSTEM
E40RCDE 1986	IGNITION SYSTEM
E40RCEC 1989	IGNITION SYSTEM - ROPE START
E40RCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40RCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40RCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40RCOB 1985	IGNITION SYSTEM
E40RCRM 1984	IGNITION SYSTEM
E40RCUD 1987	IGNITION SYSTEM
E40RECR 1998	IGNITION SYSTEM -- ROPE START
E40REDS 1996	IGNITION SYSTEM - 40 ROPE START
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40REIA 1991	IGNITION SYSTEM - ROPE START
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RENM 1992	IGNITION SYSTEM - ROPE START
E40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RESR 1990	IGNITION SYSTEM - ROPE START
E40RETB 1993	IGNITION SYSTEM - 40 ROPE START
E40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

E40REUC 1997	IGNITION SYSTEM - ROPE START
E40RLCCS 1988	IGNITION SYSTEM
E40RLCDE 1986	IGNITION SYSTEM
E40RLCEC 1989	IGNITION SYSTEM - ROPE START
E40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40RLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40RLCOB 1985	IGNITION SYSTEM
E40RLCRM 1984	IGNITION SYSTEM
E40RLCUD 1987	IGNITION SYSTEM
E40RLECR 1998	IGNITION SYSTEM -- ROPE START
E40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLEIA 1991	IGNITION SYSTEM - ROPE START
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40RLENM 1992	IGNITION SYSTEM - ROPE START
E40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40RLESR 1990	IGNITION SYSTEM - ROPE START
E40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLEUC 1997	IGNITION SYSTEM - ROPE START
E40RSLR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RSR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RWADB 1986	IGNITION
E40RWCOM 1985	IGNITION
E40RWCRA 1984	IGNITION

E40RWLCDB 1986	IGNITION
E40RWLCOM 1985	IGNITION
E40RWLCRA 1984	IGNITION
E40RWLCTR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RWLTR 1983	MAGNETO-RS AND RW MODELS ONLY
E40TECCS 1988	IGNITION SYSTEM
E40TECDE 1986	IGNITION SYSTEM
E40TECEC 1989	IGNITION SYSTEM - ROPE START
E40TECEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TECEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40TECEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40TECOB 1985	IGNITION SYSTEM
E40TECRM 1984	IGNITION SYSTEM
E40TECUD 1987	IGNITION SYSTEM
E40TEECR 1998	IGNITION SYSTEM -- ROPE START
E40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEEIA 1991	IGNITION SYSTEM - ROPE START
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENJ 1992	IGNITION SYSTEM - ROPE START
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TEENM 1992	IGNITION SYSTEM - ROPE START
E40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TEESR 1990	IGNITION SYSTEM - ROPE START

E40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEEUC 1997	IGNITION SYSTEM - ROPE START
E40TELCCS 1988	IGNITION SYSTEM
E40TELCDE 1986	IGNITION SYSTEM
E40TELCEC 1989	IGNITION SYSTEM - ROPE START
E40TELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40TELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40TELCOB 1985	IGNITION SYSTEM
E40TELCRM 1984	IGNITION SYSTEM
E40TELECR 1998	IGNITION SYSTEM -- ROPE START
E40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELEIA 1991	IGNITION SYSTEM - ROPE START
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENJ 1992	IGNITION SYSTEM - ROPE START
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TELENM 1992	IGNITION SYSTEM - ROPE START
E40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TELESR 1990	IGNITION SYSTEM - ROPE START
E40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

E40TELEUC 1997	IGNITION SYSTEM - ROPE START
E40TLCCS 1988	IGNITION SYSTEM
E40TLCDE 1986	IGNITION SYSTEM
E40TLCEC 1989	IGNITION SYSTEM - ROPE START
E40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40TLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40TLCUD 1987	IGNITION SYSTEM
E40TLECR 1998	IGNITION SYSTEM -- ROPE START
E40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLEIA 1991	IGNITION SYSTEM - ROPE START
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENJ 1992	IGNITION SYSTEM - ROPE START
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TLENM 1992	IGNITION SYSTEM - ROPE START
E40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TLESR 1990	IGNITION SYSTEM - ROPE START
E40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLEUC 1997	IGNITION SYSTEM - ROPE START

E40TTLCCS 1988	IGNITION SYSTEM
E40TTLCEC 1989	IGNITION SYSTEM - ROPE START
E40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E40TTLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E40TTLECR 1998	IGNITION SYSTEM -- ROPE START
E40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLEIA 1991	IGNITION SYSTEM - ROPE START
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E40TTLENM 1992	IGNITION SYSTEM - ROPE START
E40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E40TTLESR 1990	IGNITION SYSTEM - ROPE START
E40TTLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLEUC 1997	IGNITION SYSTEM - ROPE START
E40WREES 1999	IGNITION SYSTEM
E40WRLEES 1999	IGNITION SYSTEM
E40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRYEES 1999	IGNITION SYSTEM

E40WRYISIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E45RCCDS 1986	IGNITION SYSTEM
E45RCCUC 1987	IGNITION SYSTEM
E45RCE 1989	IGNITION
E45RCEIA 1991	IGNITION SYSTEM
E45RCENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCENM 1992	IGNITION SYSTEM - ROPE START
E45RCEOD 1995	IGNITION SYSTEM
E45RCERE 1994	IGNITION SYSTEM
E45RCESR 1990	IGNITION
E45RCETB 1993	IGNITION SYSTEM
E45RCLCDS 1986	IGNITION SYSTEM
E45RCLCUC 1987	IGNITION SYSTEM
E45RCLE 1989	IGNITION
E45RCLEDS 1996	IGNITION SYSTEM
E45RCLEIA 1991	IGNITION SYSTEM
E45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCLENM 1992	IGNITION SYSTEM - ROPE START
E45RCLEOD 1995	IGNITION SYSTEM
E45RCLERE 1994	IGNITION SYSTEM
E45RCLESR 1990	IGNITION
E45RCLETB 1993	IGNITION SYSTEM
E45RCLEUC 1997	IGNITION SYSTEM
E45WMLE 1989	IGNITION
E45WMLEIA 1991	IGNITION SYSTEM
E45WMLENM 1992	IGNITION SYSTEM - ELECTRIC
E45WMLENM 1992	IGNITION SYSTEM - ROPE START
E45WMLESR 1990	IGNITION
E48ESLCCC 1988	IGNITION SYSTEM
E48ESLCER 1989	IGNITION SYSTEM (CONTINUED)
E48ESLCUS 1987	IGNITION SYSTEM
E48ESLEDC 1996	IGNITION SYSTEM
E48ESLEIM 1991	IGNITION SYSTEM

E48ESLENB 1992	IGNITION SYSTEM
E48ESLEOS 1995	IGNITION SYSTEM
E48ESLERD 1994	IGNITION SYSTEM
E48ESLESA 1990	IGNITION SYSTEM
E48ESLETE 1993	IGNITION SYSTEM
E4BRECRJ 1998	IGNITION
E4BRLECRJ 1998	IGNITION
E4RDHCCS 1988	MAGNETO
E4RDHCDE 1986	MAGNETO
E4RDHCEC 1989	IGNITION
E4RDHCUD 1987	MAGNETO
E4RDHEIA 1991	IGNITION
E4RDHENM 1992	IGNITION
E4RDHEOD 1995	MAGNETO
E4RDHERE 1994	MAGNETO
E4RDHESR 1990	IGNITION
E4RDHETB 1993	IGNITION
E4RDHLCCS 1988	MAGNETO
E4RDHLCEC 1989	IGNITION
E4RDHLCUD 1987	MAGNETO
E4RDHLEIA 1991	IGNITION
E4RDHLENM 1992	IGNITION
E4RDHLEOD 1995	MAGNETO
E4RDHLERE 1994	MAGNETO
E4RDHLESR 1990	IGNITION
E4RDHLETB 1993	IGNITION
E4REDS 1996	IGNITION
E4REIA 1991	IGNITION
E4RENM 1992	IGNITION
E4REOD 1995	IGNITION
E4RERE 1994	IGNITION
E4RETB 1993	IGNITION
E4REUC 1997	IGNITION
E4RLCSS 1980	MAGNETO
E4RLEDs 1996	IGNITION

E4RLEIA 1991	IGNITION
E4RLENM 1992	IGNITION
E4RLEOD 1995	IGNITION
E4RLERE 1994	IGNITION
E4RLETB 1993	IGNITION
E4RLEUC 1997	IGNITION
E4WCSS 1980	MAGNETO
E50BECCS 1988	IGNITION SYSTEM
E50BECDE 1986	IGNITION SYSTEM
E50BECEC 1989	IGNITION SYSTEM - ROPE START
E50BECEC 1989	IGNITION SYSTEM - ELECTRIC START
E50BECEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E50BECEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E50BECIC 1981	IGNITION SYSTEM
E50BECNR 1982	IGNITION SYSTEM
E50BECOB 1985	IGNITION SYSTEM
E50BECRM 1984	IGNITION SYSTEM
E50BECTA 1983	IGNITION SYSTEM
E50BECUD 1987	IGNITION SYSTEM
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEEIA 1991	IGNITION SYSTEM - ROPE START
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEENJ 1992	IGNITION SYSTEM - ROPE START
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BEENM 1992	IGNITION SYSTEM - ROPE START
E50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

E50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BEESR 1990	IGNITION SYSTEM - ROPE START
E50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
E50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELCCS 1988	IGNITION SYSTEM
E50BELCDE 1986	IGNITION SYSTEM
E50BELCEC 1989	IGNITION SYSTEM - ROPE START
E50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START
E50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E50BELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E50BELCIC 1981	IGNITION SYSTEM
E50BELCNR 1982	IGNITION SYSTEM
E50BELCOB 1985	IGNITION SYSTEM
E50BELCRM 1984	IGNITION SYSTEM
E50BELCTA 1983	IGNITION SYSTEM
E50BELCUD 1987	IGNITION SYSTEM
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50BELEIA 1991	IGNITION SYSTEM - ROPE START
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENJ 1992	IGNITION SYSTEM - ROPE START
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50BELENM 1992	IGNITION SYSTEM - ROPE START
E50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

E50BELESR 1990	IGNITION SYSTEM - ROPE START
E50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50ECSR 1980	IGNITION SYSTEM
E50ELCSR 1980	IGNITION SYSTEM
E50ESLECC 1998	IGNITION SYSTEM -- ROPE START
E50ESLEUR 1997	IGNITION SYSTEM - ROPE START
E50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50JEIA 1991	IGNITION SYSTEM - ROPE START
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENJ 1992	IGNITION SYSTEM - ROPE START
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50JENM 1992	IGNITION SYSTEM - ROPE START
E50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50JERE 1994	IGNITION SYSTEM - 40 ROPE START
E50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JETB 1993	IGNITION SYSTEM - 40 ROPE START
E50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JEUC 1997	IGNITION SYSTEM - ROPE START
E50RNLIA 1990	IGNITION SYSTEM
E50RNLIB 1992	IGNITION SYSTEM
E50TELCCS 1988	IGNITION SYSTEM
E50TELCDE 1986	IGNITION SYSTEM
E50TELCEC 1989	IGNITION SYSTEM - ROPE START
E50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)

E50TELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E50TELCOB 1985	IGNITION SYSTEM
E50TELCRM 1984	IGNITION SYSTEM
E50TELECTA 1983	IGNITION SYSTEM
E50TELCUD 1987	IGNITION SYSTEM
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELEIA 1991	IGNITION SYSTEM - ROPE START
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TELENM 1992	IGNITION SYSTEM - ROPE START
E50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TELESR 1990	IGNITION SYSTEM - ROPE START
E50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLCCS 1988	IGNITION SYSTEM
E50TLCDE 1986	IGNITION SYSTEM
E50TLCEC 1989	IGNITION SYSTEM - ROPE START
E50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
E50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
E50TLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
E50TLCOB 1985	IGNITION SYSTEM
E50TELCRM 1984	IGNITION SYSTEM
E50TLCUD 1987	IGNITION SYSTEM
E50TLECR 1998	IGNITION SYSTEM -- ROPE START
E50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

E50TLEIA 1991	IGNITION SYSTEM - ROPE START
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENJ 1992	IGNITION SYSTEM - ROPE START
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
E50TLENM 1992	IGNITION SYSTEM - ROPE START
E50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
E50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
E50TLESR 1990	IGNITION SYSTEM - ROPE START
E50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLEUC 1997	IGNITION SYSTEM - ROPE START
E50TSLECC 1998	IGNITION SYSTEM -- ROPE START
E50TSLEUS 1997	IGNITION SYSTEM - ROPE START
E55RCIM 1981	IGNITION SYSTEM
E55RLCSA 1980	IGNITION SYSTEM
E55RSLC 1997	IGNITION SYSTEM
E55RSLG 1995	IGNITION SYSTEM
E55RSLN 1983	IGNITION SYSTEM
E55RSLN-2 1983	IGNITION SYSTEM
E55RSLW 1996	IGNITION SYSTEM
E55RSN 1983	IGNITION SYSTEM
E55RSN-2 1983	IGNITION SYSTEM
E55RSYN 1983	IGNITION SYSTEM

E55RSYN-2 1983	IGNITION SYSTEM
E55RWLCDC 1986	IGNITION SYSTEM
E55RWLCOS 1985	IGNITION SYSTEM
E55RWLCRD 1984	IGNITION SYSTEM
E55RWLCUC 1987	IGNITION SYSTEM
E55RWLE 1989	IGNITION
E55RWLEIA 1991	IGNITION SYSTEM
E55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
E55RWLENM 1992	IGNITION SYSTEM - ROPE START
E55RWLERE 1994	IGNITION SYSTEM
E55RWLESR 1990	IGNITION
E55RWLETB 1993	IGNITION SYSTEM
E55TLCIM 1981	IGNITION SYSTEM
E55WREES 1999	IGNITION SYSTEM
E55WRLEES 1999	IGNITION SYSTEM
E55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
E55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E55WRYEES 1999	IGNITION SYSTEM
E55WRY SIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E5DRECR 1998	IGNITION
E5DRLECR 1998	IGNITION
E5RCIC 1981	MAGNETO - 7.5
E5RCIC 1981	MAGNETO-4.5
E5RCSS 1980	MAGNETO - 7.5
E5RCSS 1980	MAGNETO-4.5
E5RHCIC 1981	MAGNETO - 7.5
E5RHCIC 1981	MAGNETO-4.5
E5RHCNR 1982	MAGNETO - 4.5
E5RHCNR 1982	MAGNETO - 7.5
E5RHCSS 1980	MAGNETO - 7.5
E5RHCSS 1980	MAGNETO-4.5

E5RHCTA 1983	MAGNETO-4.5
E5RHCTA 1983	MAGNETO-7.5
E5RHLCIC 1981	MAGNETO - 7.5
E5RHLCIC 1981	MAGNETO-4.5
E5RHLCNR 1982	MAGNETO - 4.5
E5RHLCNR 1982	MAGNETO - 7.5
E5RHLCSS 1980	MAGNETO - 7.5
E5RHLCSS 1980	MAGNETO-4.5
E5RHLCTA 1983	MAGNETO-4.5
E5RHLCTA 1983	MAGNETO-7.5
E5RLCIC 1981	MAGNETO - 7.5
E5RLCIC 1981	MAGNETO-4.5
E5RLCSS 1980	MAGNETO - 7.5
E5RLCSS 1980	MAGNETO-4.5
E60ECIA 1981	IGNITION SYSTEM
E60ECIH 1981	IGNITION SYSTEM
E60ECNM 1982	IGNITION SYSTEM
E60ECSR 1980	IGNITION SYSTEM
E60ECTB 1983	IGNITION SYSTEM
E60ELCIA 1981	IGNITION SYSTEM
E60ELCIH 1981	IGNITION SYSTEM
E60ELCNM 1982	IGNITION SYSTEM
E60ELCOD 1985	IGNITION SYSTEM
E60ELCRE 1984	IGNITION SYSTEM
E60ELCSR 1980	IGNITION SYSTEM
E60ELCTB 1983	IGNITION SYSTEM
E60TLCIA 1981	IGNITION SYSTEM
E60TLCIH 1981	IGNITION SYSTEM
E60TLCNM 1982	IGNITION SYSTEM
E60TLCOD 1985	IGNITION SYSTEM
E60TLCRE 1984	IGNITION SYSTEM
E60TLCTB 1983	IGNITION SYSTEM
E6RCCS 1988	IGNITION
E6RCDE 1986	MAGNETO
E6RCEC 1989	IGNITION

E6RCOB 1985	MAGNETO
E6RCRM 1984	MAGNETO - 6/8
E6RCUD 1987	IGNITION
E6RECR 1998	IGNITION
E6REDS 1996	IGNITION
E6REIA 1991	IGNITION
E6RENM 1992	IGNITION
E6REOD 1995	IGNITION
E6RERE 1994	IGNITION
E6RESR 1990	IGNITION
E6RETB 1993	IGNITION
E6REUC 1997	IGNITION
E6RLCCS 1988	IGNITION
E6RLCDE 1986	MAGNETO
E6RLCEC 1989	IGNITION
E6RLCOB 1985	MAGNETO
E6RLCRM 1984	MAGNETO - 6/8
E6RLCUD 1987	IGNITION
E6RLECR 1998	IGNITION
E6RLEDS 1996	IGNITION
E6RLEIA 1991	IGNITION
E6RLENM 1992	IGNITION
E6RLEOD 1995	IGNITION
E6RLERE 1994	IGNITION
E6RLESR 1990	IGNITION
E6RLETB 1993	IGNITION
E6RLEUC 1997	IGNITION
E6SLCCS 1988	IGNITION
E6SLCDE 1986	MAGNETO
E6SLCEC 1989	IGNITION
E6SLCOB 1985	MAGNETO
E6SLCRM 1984	MAGNETO - 6/8
E6SLCUD 1987	IGNITION
E6SLEDs 1996	IGNITION
E6SLEIA 1991	IGNITION

E6SLENM 1992	IGNITION
E6SLEOD 1995	IGNITION
E6SLERE 1994	IGNITION
E6SLESR 1990	IGNITION
E6SLETB 1993	IGNITION
E8DREEA 1999	IGNITION
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
E8RCCS 1988	IGNITION
E8RCDE 1986	MAGNETO
E8RCEC 1989	IGNITION
E8RCIC 1981	MAGNETO - 7.5
E8RCIC 1981	MAGNETO-4.5
E8RCNR 1982	MAGNETO - 4.5
E8RCNR 1982	MAGNETO - 7.5
E8RCOB 1985	MAGNETO
E8RCRM 1984	MAGNETO - 6/8
E8RCSS 1980	MAGNETO - 7.5
E8RCSS 1980	MAGNETO-4.5
E8RCTA 1983	MAGNETO-4.5
E8RCTA 1983	MAGNETO-7.5
E8RCUD 1987	IGNITION
E8RECR 1998	IGNITION
E8REDS 1996	IGNITION
E8REIA 1991	IGNITION
E8RENM 1992	IGNITION
E8REOD 1995	IGNITION
E8RERE 1994	IGNITION
E8RESR 1990	IGNITION
E8RETB 1993	IGNITION
E8REUC 1997	IGNITION
E8RLCCS 1988	IGNITION
E8RLCDE 1986	MAGNETO
E8RLCEC 1989	IGNITION
E8RLCIC 1981	MAGNETO - 7.5
E8RLCIC 1981	MAGNETO-4.5

E8RLCNR 1982	MAGNETO - 4.5
E8RLCNR 1982	MAGNETO - 7.5
E8RLCOB 1985	MAGNETO
E8RLCRM 1984	MAGNETO - 6/8
E8RLCSS 1980	MAGNETO - 7.5
E8RLCSS 1980	MAGNETO-4.5
E8RLCTA 1983	MAGNETO-4.5
E8RLCTA 1983	MAGNETO-7.5
E8RLCUD 1987	IGNITION
E8RLECR 1998	IGNITION
E8RLEDS 1996	IGNITION
E8RLEIA 1991	IGNITION
E8RLENM 1992	IGNITION
E8RLEOD 1995	IGNITION
E8RLERE 1994	IGNITION
E8RLESR 1990	IGNITION
E8RLETB 1993	IGNITION
E8RLEUC 1997	IGNITION
E8SRLCCS 1988	IGNITION
E8SRLCDE 1986	MAGNETO
E8SRLCEC 1989	IGNITION
E8SRLCNR 1982	MAGNETO - 4.5
E8SRLCNR 1982	MAGNETO - 7.5
E8SRLCOB 1985	MAGNETO
E8SRLCRM 1984	MAGNETO - 6/8
E8SRLCTA 1983	MAGNETO-4.5
E8SRLCTA 1983	MAGNETO-7.5
E8SRLCUD 1987	IGNITION
E8SRLECA 1998	IGNITION
E8SRLEDS 1996	IGNITION
E8SRLEIA 1991	IGNITION
E8SRLENM 1992	IGNITION
E8SRLEOD 1995	IGNITION
E8SRLERE 1994	IGNITION
E8SRLESR 1990	IGNITION

E8SRLETB 1993	IGNITION
E8SRLEUC 1997	IGNITION
E8WREES 1999	IGNITION
E8WRLEES 1999	IGNITION
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
HE15KCF 1997	IGNITION
HE15KCLF 1997	IGNITION
HE15KCLN 1996	IGNITION
HE15KCLO 1998	IGNITION
HE15KCN 1996	IGNITION
HE15KCO 1998	IGNITION
HE15RPLW 1997	IGNITION
HE15RPW 1997	IGNITION
HE40REDS 1996	IGNITION SYSTEM - 40 ROPE START
HE40REUC 1997	IGNITION SYSTEM - ROPE START
HE40RLEDs 1996	IGNITION SYSTEM - 40 ROPE START
HE40REUC 1997	IGNITION SYSTEM - ROPE START
HE45RCLEDs 1996	IGNITION SYSTEM
HE45RCLEUC 1997	IGNITION SYSTEM
HE55RSLC 1997	IGNITION SYSTEM
HE55RSLW 1996	IGNITION SYSTEM
HE55WMLM 1996	IGNITION SYSTEM
HE55WMLZ 1997	IGNITION SYSTEM
HJ15KCF 1997	IGNITION
HJ15KCLF 1997	IGNITION
HJ15KCLN 1996	IGNITION
HJ15KCLO 1998	IGNITION
HJ15KCN 1996	IGNITION
HJ15KCO 1998	IGNITION
HJ15RPLW 1997	IGNITION
HJ15RPW 1997	IGNITION
HJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START

HJ40REUC 1997	IGNITION SYSTEM - ROPE START
HJ40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
HJ40RLEUC 1997	IGNITION SYSTEM - ROPE START
HJ45RCLEDS 1996	IGNITION SYSTEM
HJ45RCLEUC 1997	IGNITION SYSTEM
HJ55RSLC 1997	IGNITION SYSTEM
HJ55RSLW 1996	IGNITION SYSTEM
HJ55WMLM 1996	IGNITION SYSTEM
HJ55WMLZ 1997	IGNITION SYSTEM
J10ECCD 1988	IGNITION
J10ECDB 1986	IGNITION
J10ECES 1989	IGNITION
J10ECOM 1985	IGNITION
J10ECSE 1980	MAGNETO
J10ECUE 1987	IGNITION
J10EECC 1998	IGNITION -- ELECTRIC
J10EECC 1998	IGNITION -- ROPE
J10EEDD 1996	IGNITION - ELECTRIC
J10EEDD 1996	IGNITION - ROPE
J10EEIR 1991	IGNITION
J10EENA 1992	IGNITION
J10EEOE 1995	IGNITION - ELECTRIC
J10EEOE 1995	IGNITION - ROPE
J10EERB 1994	IGNITION - ELECTRIC
J10EERB 1994	IGNITION - ROPE
J10EESC 1990	IGNITION
J10EETM 1993	IGNITION - ELECTRIC
J10EETM 1993	IGNITION - ROPE
J10EEUS 1997	IGNITION - ELECTRIC
J10EEUS 1997	IGNITION - ROPE
J10ELCCD 1988	IGNITION
J10ELCDB 1986	IGNITION
J10ELCES 1989	IGNITION
J10ELCID 1981	MAGNETO
J10ELCNS 1982	MAGNETO

J10ELCOM 1985	IGNITION
J10ELCRA 1984	MAGNETO
J10ELCSE 1980	MAGNETO
J10ELCTC 1983	MAGNETO
J10ELCUE 1987	IGNITION
J10ELECC 1998	IGNITION -- ELECTRIC
J10ELECC 1998	IGNITION -- ROPE
J10ELEDD 1996	IGNITION - ELECTRIC
J10ELEDD 1996	IGNITION - ROPE
J10ELEER 1999	IGNITION -- ROPE
J10ELEER 1999	IGNITION -- ELECTRIC
J10ELEIR 1991	IGNITION
J10ELENA 1992	IGNITION
J10ELEOE 1995	IGNITION - ELECTRIC
J10ELEOE 1995	IGNITION - ROPE
J10ELERB 1994	IGNITION - ELECTRIC
J10ELERB 1994	IGNITION - ROPE
J10ELESC 1990	IGNITION
J10ELETM 1993	IGNITION - ELECTRIC
J10ELETM 1993	IGNITION - ROPE
J10ELEUS 1997	IGNITION - ELECTRIC
J10ELEUS 1997	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION - ROPE
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10EVLSIC elec start, 20 in shaft, wht 2001	IGNITION - ROPE
J10EVLSIC elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10RCCD 1988	IGNITION
J10RCDB 1986	IGNITION
J10RCES 1989	IGNITION
J10RCID 1981	MAGNETO
J10RCNS 1982	MAGNETO

J10RCOM 1985	IGNITION
J10RCRA 1984	MAGNETO
J10RCSE 1980	MAGNETO
J10RCTC 1983	MAGNETO
J10RCTR 1983	MAGNETO
J10RCUE 1987	IGNITION
J10RECC 1998	IGNITION -- ELECTRIC
J10RECC 1998	IGNITION -- ROPE
J10REDD 1996	IGNITION - ELECTRIC
J10REDD 1996	IGNITION - ROPE
J10REER 1999	IGNITION -- ROPE
J10REER 1999	IGNITION -- ELECTRIC
J10REIR 1991	IGNITION
J10RELECC 1998	IGNITION -- ELECTRIC
J10RELECC 1998	IGNITION -- ROPE
J10RELEDD 1996	IGNITION - ELECTRIC
J10RELEDD 1996	IGNITION - ROPE
J10RELEIR 1991	IGNITION
J10RELENA 1992	IGNITION
J10RELEOE 1995	IGNITION - ELECTRIC
J10RELEOE 1995	IGNITION - ROPE
J10RELERB 1994	IGNITION - ELECTRIC
J10RELERB 1994	IGNITION - ROPE
J10RELESC 1990	IGNITION
J10RELETM 1993	IGNITION - ELECTRIC
J10RELETM 1993	IGNITION - ROPE
J10RELEUS 1997	IGNITION - ELECTRIC
J10RELEUS 1997	IGNITION - ROPE
J10RENA 1992	IGNITION
J10REOE 1995	IGNITION - ELECTRIC
J10REOE 1995	IGNITION - ROPE
J10RERB 1994	IGNITION - ELECTRIC
J10RERB 1994	IGNITION - ROPE
J10RESC 1990	IGNITION
J10RETM 1993	IGNITION - ELECTRIC

J10RETM 1993	IGNITION - ROPE
J10REUS 1997	IGNITION - ELECTRIC
J10REUS 1997	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10RLCCD 1988	IGNITION
J10RLCDB 1986	IGNITION
J10RLCES 1989	IGNITION
J10RLCID 1981	MAGNETO
J10RLCNS 1982	MAGNETO
J10RLCOM 1985	IGNITION
J10RLCRA 1984	MAGNETO
J10RLCSE 1980	MAGNETO
J10RLCTC 1983	MAGNETO
J10RLCTR 1983	MAGNETO
J10RLCUE 1987	IGNITION
J10RLECC 1998	IGNITION -- ELECTRIC
J10RLECC 1998	IGNITION -- ROPE
J10RLEDD 1996	IGNITION - ELECTRIC
J10RLEDD 1996	IGNITION - ROPE
J10RLEER 1999	IGNITION -- ROPE
J10RLEER 1999	IGNITION -- ELECTRIC
J10RLEIR 1991	IGNITION
J10RLENA 1992	IGNITION
J10RLEOE 1995	IGNITION - ELECTRIC
J10RLEOE 1995	IGNITION - ROPE
J10RLERB 1994	IGNITION - ELECTRIC
J10RLERB 1994	IGNITION - ROPE
J10RLESC 1990	IGNITION
J10RLETM 1993	IGNITION - ELECTRIC
J10RLETM 1993	IGNITION - ROPE
J10RLEUS 1997	IGNITION - ELECTRIC
J10RLEUS 1997	IGNITION - ROPE

J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ELECTRIC
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10RLSDC	IGNITION
J10RLSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10RLSOS	IGNITION
J10RLSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSRD	IGNITION
J10RLSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10RLSTE	IGNITION
J10RLSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSUR	IGNITION
J10RLSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RSDC	IGNITION
J10RSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10RSOS	IGNITION
J10RSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSRD	IGNITION
J10RSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10RSTE	IGNITION
J10RSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSUR	IGNITION
J10RSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE

J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10SELCCD 1988	IGNITION
J10SELCDB 1986	IGNITION
J10SELCES 1989	IGNITION
J10SELCID 1981	MAGNETO
J10SELCNS 1982	MAGNETO
J10SELCOM 1985	IGNITION
J10SELCRA 1984	MAGNETO
J10SELCSE 1980	MAGNETO
J10SELCTC 1983	MAGNETO
J10SELCUE 1987	IGNITION
J10SELECC 1998	IGNITION -- ELECTRIC
J10SELECC 1998	IGNITION -- ROPE
J10SELEDD 1996	IGNITION - ELECTRIC
J10SELEDD 1996	IGNITION - ROPE
J10SELEIR 1991	IGNITION
J10SELENA 1992	IGNITION
J10SELEOE 1995	IGNITION - ELECTRIC
J10SELEOE 1995	IGNITION - ROPE
J10SELERB 1994	IGNITION - ELECTRIC
J10SELERB 1994	IGNITION - ROPE
J10SELESC 1990	IGNITION
J10SELETM 1993	IGNITION - ELECTRIC
J10SELETM 1993	IGNITION - ROPE
J10SELEUS 1997	IGNITION - ELECTRIC
J10SELEUS 1997	IGNITION - ROPE
J10TEEER 1999	IGNITION -- ROPE
J10TEEER 1999	IGNITION -- ELECTRIC
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE

J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10TELEER 1999	IGNITION -- ROPE
J10TELEER 1999	IGNITION -- ELECTRIC
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15ECCS 1988	IGNITION
J15ECDE 1986	IGNITION
J15ECEC 1989	IGNITION
J15ECIS 1981	MAGNETO
J15ECNC 1982	MAGNETO
J15ECOB 1985	IGNITION
J15ECRM 1984	MAGNETO
J15ECSD 1980	MAGNETO
J15ECTR 1983	MAGNETO
J15ECUD 1987	IGNITION
J15EECR 1998	IGNITION -- ELECTRIC
J15EECR 1998	IGNITION -- ROPE
J15EEDS 1996	IGNITION - ELECTRIC
J15EEDS 1996	IGNITION - ROPE
J15EEIA 1991	IGNITION
J15EENM 1992	IGNITION
J15EEOD 1995	IGNITION - ELECTRIC
J15EEOD 1995	IGNITION - ROPE
J15EERE 1994	IGNITION - ELECTRIC
J15EERE 1994	IGNITION - ROPE
J15EESR 1990	IGNITION
J15EETB 1993	IGNITION - ELECTRIC

J15EETB 1993	IGNITION - ROPE
J15EEUC 1997	IGNITION - ELECTRIC
J15EEUC 1997	IGNITION - ROPE
J15ELCCS 1988	IGNITION
J15ELCDE 1986	IGNITION
J15ELCEC 1989	IGNITION
J15ELCOB 1985	IGNITION
J15ELCRM 1984	MAGNETO
J15ELCSD 1980	MAGNETO
J15ELCTR 1983	MAGNETO
J15ELCUD 1987	IGNITION
J15ELECR 1998	IGNITION -- ELECTRIC
J15ELECR 1998	IGNITION -- ROPE
J15ELEDS 1996	IGNITION - ELECTRIC
J15ELEDS 1996	IGNITION - ROPE
J15ELEEA 1999	IGNITION -- ROPE
J15ELEEA 1999	IGNITION -- ELECTRIC
J15ELEIA 1991	IGNITION
J15ELENM 1992	IGNITION
J15ELEOD 1995	IGNITION - ELECTRIC
J15ELEOD 1995	IGNITION - ROPE
J15ELERE 1994	IGNITION - ELECTRIC
J15ELERE 1994	IGNITION - ROPE
J15ELSR 1990	IGNITION
J15ELETB 1993	IGNITION - ELECTRIC
J15ELETB 1993	IGNITION - ROPE
J15ELEUC 1997	IGNITION - ELECTRIC
J15ELEUC 1997	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION - ROPE
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15EVLSIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ROPE
J15EVLSIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE

J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15RCCS 1988	IGNITION
J15RCDE 1986	IGNITION
J15RCEC 1989	IGNITION
J15RCIS 1981	MAGNETO
J15RCNC 1982	MAGNETO
J15RCOB 1985	IGNITION
J15RCRM 1984	MAGNETO
J15RCSD 1980	MAGNETO
J15RCTA 1983	MAGNETO
J15RCTR 1983	MAGNETO
J15RCUD 1987	IGNITION
J15RECR 1998	IGNITION -- ELECTRIC
J15RECR 1998	IGNITION -- ROPE
J15REDS 1996	IGNITION - ELECTRIC
J15REDS 1996	IGNITION - ROPE
J15REEA 1999	IGNITION -- ROPE
J15REEA 1999	IGNITION -- ELECTRIC
J15REIA 1991	IGNITION
J15RELECR 1998	IGNITION -- ELECTRIC
J15RELECR 1998	IGNITION -- ROPE
J15RELEDS 1996	IGNITION - ELECTRIC
J15RELEDS 1996	IGNITION - ROPE
J15RELEIA 1991	IGNITION
J15RELENM 1992	IGNITION
J15RELEOD 1995	IGNITION - ELECTRIC
J15RELEOD 1995	IGNITION - ROPE
J15RELERE 1994	IGNITION - ELECTRIC
J15RELERE 1994	IGNITION - ROPE
J15RELESR 1990	IGNITION
J15RELETB 1993	IGNITION - ELECTRIC
J15RELETB 1993	IGNITION - ROPE
J15RELEUC 1997	IGNITION - ELECTRIC
J15RELEUC 1997	IGNITION - ROPE
J15RENM 1992	IGNITION

J15REOD 1995	IGNITION - ELECTRIC
J15REOD 1995	IGNITION - ROPE
J15RERE 1994	IGNITION - ELECTRIC
J15RERE 1994	IGNITION - ROPE
J15RESR 1990	IGNITION
J15RETB 1993	IGNITION - ELECTRIC
J15RETB 1993	IGNITION - ROPE
J15REUC 1997	IGNITION - ELECTRIC
J15REUC 1997	IGNITION - ROPE
J15RLCCS 1988	IGNITION
J15RLCDE 1986	IGNITION
J15RLCEC 1989	IGNITION
J15RLCIS 1981	MAGNETO
J15RLCNC 1982	MAGNETO
J15RLCOB 1985	IGNITION
J15RLCRM 1984	MAGNETO
J15RLCSD 1980	MAGNETO
J15RLCTA 1983	MAGNETO
J15RLCTR 1983	MAGNETO
J15RLCUD 1987	IGNITION
J15RLECR 1998	IGNITION -- ELECTRIC
J15RLECR 1998	IGNITION -- ROPE
J15RLEDS 1996	IGNITION - ELECTRIC
J15RLEDS 1996	IGNITION - ROPE
J15RLEEA 1999	IGNITION -- ROPE
J15RLEEA 1999	IGNITION -- ELECTRIC
J15RLEIA 1991	IGNITION
J15RLENM 1992	IGNITION
J15RLEOD 1995	IGNITION - ELECTRIC
J15RLEOD 1995	IGNITION - ROPE
J15RLERE 1994	IGNITION - ELECTRIC
J15RLERE 1994	IGNITION - ROPE
J15RLESR 1990	IGNITION
J15RLETB 1993	IGNITION - ELECTRIC
J15RLETB 1993	IGNITION - ROPE

J15RLEUC 1997	IGNITION - ELECTRIC
J15RLEUC 1997	IGNITION - ROPE
J15RLSDR	IGNITION
J15RLSDR - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15RLSOC	IGNITION
J15RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSRS	IGNITION
J15RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15RLSTD	IGNITION
J15RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J15RLSUA	IGNITION
J15RLSUA - FR	02-5_SYSTÈME D'ALLUMAGE
J15RSDR	IGNITION
J15RSDR - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15RSOC	IGNITION
J15RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSRS	IGNITION
J15RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15RSTD	IGNITION
J15RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J15RSUA	IGNITION
J15RSUA - FR	02-5_SYSTÈME D'ALLUMAGE
J15RTSDC	IGNITION
J15RTSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J15RTSOS	IGNITION
J15RTSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J15RTSUR	IGNITION

J15RTSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15TEEEA 1999	IGNITION -- ROPE
J15TEEEA 1999	IGNITION -- ELECTRIC
J15TELEEA 1999	IGNITION -- ROPE
J15TELEEA 1999	IGNITION -- ELECTRIC
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15WREES 1999	IGNITION
J15WRLEES 1999	IGNITION
J15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J15WRLSOB	IGNITION
J15WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSRM	IGNITION
J15WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
J15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J15WRSOB	IGNITION
J15WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSRM	IGNITION

J15WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
J20CRCCA 1988	IGNITION
J20CRCDC 1986	IGNITION
J20CRCEM 1989	IGNITION
J20CRCOS 1985	IGNITION
J20CRCUR 1987	IGNITION
J20CREIE 1991	IGNITION
J20CREND 1992	IGNITION
J20CRESB 1990	IGNITION
J20CRLCCA 1988	IGNITION
J20CRLCDC 1986	IGNITION
J20CRLCEM 1989	IGNITION
J20CRLCOS 1985	IGNITION
J20CRLCUR 1987	IGNITION
J20CRLEIE 1991	IGNITION
J20CRLEND 1992	IGNITION
J20CRLESB 1990	IGNITION
J20ECCA 1988	IGNITION
J20ECDC 1986	IGNITION
J20ECEM 1989	IGNITION
J20ECOS 1985	IGNITION
J20ECUR 1987	IGNITION
J20EEIE 1991	IGNITION
J20EEND 1992	IGNITION
J20EESB 1990	IGNITION
J20ELCCA 1988	IGNITION
J20ELCDC 1986	IGNITION
J20ELCEM 1989	IGNITION
J20ELCOS 1985	IGNITION
J20ELCUR 1987	IGNITION
J20ELEIE 1991	IGNITION
J20ELEND 1992	IGNITION
J20ELESB 1990	IGNITION
J20TECDC 1986	IGNITION

J25ECCM 1988	IGNITION
J25ECDR 1986	IGNITION
J25ECEB 1989	IGNITION
J25ECIB 1981	MAGNETO
J25ECIM 1981	MAGNETO
J25ECNE 1982	MAGNETO
J25ECOC 1985	IGNITION
J25ECRS 1984	IGNITION
J25ECTD 1983	MAGNETO
J25ECUA 1987	IGNITION
J25EEID 1991	IGNITION
J25EENS 1992	IGNITION
J25EESE 1990	IGNITION
J25ELCCM 1988	IGNITION
J25ELCDR 1986	IGNITION
J25ELCEB 1989	IGNITION
J25ELCIB 1981	MAGNETO
J25ELCIM 1981	MAGNETO
J25ELCNE 1982	MAGNETO
J25ELCOC 1985	IGNITION
J25ELCRS 1984	IGNITION
J25ELCTD 1983	MAGNETO
J25ELCUA 1987	IGNITION
J25ELEID 1991	IGNITION
J25ELENS 1992	IGNITION
J25ELESE 1990	IGNITION
J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J25RCCA 1988	IGNITION
J25RCDC 1986	IGNITION
J25RCEM 1989	IGNITION
J25RCIM 1981	MAGNETO
J25RCNB 1982	MAGNETO
J25RCOS 1985	IGNITION
J25RCRD 1984	IGNITION
J25RCSA 1980	MAGNETO

J25RCTE 1983	MAGNETO
J25RCUR 1987	IGNITION
J25REIE 1991	IGNITION
J25RELCNB 1982	MAGNETO
J25REND 1992	IGNITION
J25RESB 1990	IGNITION
J25RLCCA 1988	IGNITION
J25RLCDC 1986	IGNITION
J25RLCEM 1989	IGNITION
J25RLCIM 1981	MAGNETO
J25RLCNB 1982	MAGNETO
J25RLCOS 1985	IGNITION
J25RLCRD 1984	IGNITION
J25RLCSA 1980	MAGNETO
J25RLCTE 1983	MAGNETO
J25RLCUR 1987	IGNITION
J25RLEIE 1991	IGNITION
J25REND 1992	IGNITION
J25RLESB 1990	IGNITION
J25RSA 1981	MAGNETO
J25RSLA 1981	MAGNETO
J25RSLS 1983	MAGNETO
J25RSS 1983	MAGNETO
J25RWCDC 1986	MAGNETO
J25RWCIM 1981	MAGNETO
J25RWCOS 1985	MAGNETO
J25RWCRD 1984	MAGNETO
J25RWCTE 1983	MAGNETO
J25RWCUR 1987	MAGNETO
J25RWEIM 1991	IGNITION
J25RWENB 1992	IGNITION
J25RWESA 1990	IGNITION
J25RWK 1989	IGNITION
J25RWLCDC 1986	MAGNETO
J25RWLCIM 1981	MAGNETO

J25RWLCOS 1985	MAGNETO
J25RWLCRD 1984	MAGNETO
J25RWLCTE 1983	MAGNETO
J25RWLCUR 1987	MAGNETO
J25RWLEIM 1991	IGNITION
J25RWLENB 1992	IGNITION
J25RWLESA 1990	IGNITION
J25RWLK 1989	IGNITION
J25TECCA 1988	IGNITION
J25TECDC 1986	IGNITION
J25TECEM 1989	IGNITION
J25TECIM 1981	MAGNETO
J25TECNB 1982	MAGNETO
J25TECOS 1985	IGNITION
J25TECRD 1984	IGNITION
J25TECSA 1980	MAGNETO
J25TECTE 1983	MAGNETO
J25TECUR 1987	IGNITION
J25TEEIE 1991	IGNITION
J25TEEND 1992	IGNITION
J25TEESB 1990	IGNITION
J25TELCCA 1988	IGNITION
J25TELCDC 1986	IGNITION
J25TELCEM 1989	IGNITION
J25TELCIM 1981	MAGNETO
J25TELCOS 1985	IGNITION
J25TELCRD 1984	IGNITION
J25TELCSA 1980	MAGNETO
J25TELCTE 1983	MAGNETO
J25TELCUR 1987	IGNITION
J25TELEIE 1991	IGNITION
J25TELEND 1992	IGNITION
J25TELESB 1990	IGNITION
J25WREEN 1999	IGNITION
J25WREES 1999	IGNITION

J25WRLEEN 1999	IGNITION
J25WRLEES 1999	IGNITION
J25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
J25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
J28ELCDS 1986	MAGNETO
J28ESLCCR 1988	IGNITION
J28ESLCEA 1989	IGNITION
J28ESLCUC 1987	MAGNETO
J28ESLEIB 1991	IGNITION
J28ESLENE 1992	IGNITION
J28ESLESM 1990	IGNITION
J30ECCE 1988	IGNITION
J30ECDM 1986	IGNITION
J30ECED 1989	IGNITION
J30ECOA 1985	IGNITION
J30ECRR 1984	IGNITION
J30ECUB 1987	IGNITION
J30EEIC 1991	IGNITION
J30EENR 1992	IGNITION
J30EESS 1990	IGNITION
J30ELCCE 1988	IGNITION
J30ELCDM 1986	IGNITION
J30ELCED 1989	IGNITION
J30ELCOA 1985	IGNITION
J30ELCRR 1984	IGNITION
J30ELCUB 1987	IGNITION
J30ELEIC 1991	IGNITION
J30ELENR 1992	IGNITION
J30ELESS 1990	IGNITION
J30JREEM 1999	IGNITION SYSTEM
J30JRSIE jet drive, rope start, 15 in shaft 2001	IGNITION SYSTEM
J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J30RCCE 1988	IGNITION

J30RCDM 1986	IGNITION
J30RCED 1989	IGNITION
J30RCOA 1985	IGNITION
J30RCUB 1987	IGNITION
J30REIC 1991	IGNITION
J30RENr 1992	IGNITION
J30RESS 1990	IGNITION
J30RLCCE 1988	IGNITION
J30RLCDM 1986	IGNITION
J30RLCED 1989	IGNITION
J30RLCOA 1985	IGNITION
J30RLCUB 1987	IGNITION
J30RLEIC 1991	IGNITION
J30RLENr 1992	IGNITION
J30RLESS 1990	IGNITION
J30TECCE 1988	IGNITION
J30TECDM 1986	IGNITION
J30TECED 1989	IGNITION
J30TECOA 1985	IGNITION
J30TECUB 1987	IGNITION
J30TEEIC 1991	IGNITION
J30TEENr 1992	IGNITION
J30TEESS 1990	IGNITION
J30TELCCE 1988	IGNITION
J30TELCDM 1986	IGNITION
J30TELCED 1989	IGNITION
J30TELCOA 1985	IGNITION
J30TELCUB 1987	IGNITION
J30TELEIC 1991	IGNITION
J30TELENr 1992	IGNITION
J30TELESS 1990	IGNITION
J35AELCDE 1986	IGNITION SYSTEM
J35AELCUD 1987	IGNITION SYSTEM
J35ARLCDE 1986	IGNITION SYSTEM
J35ARLCUD 1987	IGNITION SYSTEM

J35ECIG 1981	MAGNETO
J35ECND 1982	MAGNETO
J35ECRR 1984	IGNITION
J35ECSM 1980	MAGNETO
J35ECTS 1983	MAGNETO
J35ELCIG 1981	MAGNETO
J35ELCND 1982	MAGNETO
J35ELCRR 1984	IGNITION
J35ELCSM 1980	MAGNETO
J35ELCTS 1983	MAGNETO
J35RCCE 1988	IGNITION
J35RCDM 1986	IGNITION
J35RCED 1989	IGNITION
J35RCIG 1981	MAGNETO
J35RCND 1982	MAGNETO
J35RCRR 1984	IGNITION
J35RCSM 1980	MAGNETO
J35RCTS 1983	MAGNETO
J35RCUB 1987	IGNITION
J35REIC 1991	IGNITION
J35RENr 1992	IGNITION
J35RESS 1990	IGNITION
J35RLCCE 1988	IGNITION
J35RLCDM 1986	IGNITION
J35RLCED 1989	IGNITION
J35RLCIG 1981	MAGNETO
J35RLCND 1982	MAGNETO
J35RLCRR 1984	IGNITION
J35RLCSM 1980	MAGNETO
J35RLCTS 1983	MAGNETO
J35RLCUB 1987	IGNITION
J35RLEIC 1991	IGNITION
J35RLENr 1992	IGNITION
J35RLESS 1990	IGNITION
J35TELCNB 1982	MAGNETO

J35TELCRR 1984	IGNITION
J35TELCTS 1983	MAGNETO
J3REIA 1991	IGNITION
J3RENM 1992	IGNITION
J3REOD 1995	IGNITION
J3RERE 1994	IGNITION
J3RETB 1993	IGNITION
J3REUC 1997	IGNITION
J40AELCCS 1988	IGNITION SYSTEM
J40ARLCCS 1988	IGNITION SYSTEM
J40ATLCCS 1988	IGNITION SYSTEM
J40ECCS 1988	IGNITION SYSTEM
J40ECDE 1986	IGNITION SYSTEM
J40ECEC 1989	IGNITION SYSTEM - ROPE START
J40ECEC 1989	IGNITION SYSTEM - ELECTRIC START
J40ECEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40ECEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J40ECOB 1985	IGNITION SYSTEM
J40ECRM 1984	IGNITION SYSTEM
J40ECUD 1987	IGNITION SYSTEM
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EEIA 1991	IGNITION SYSTEM - ROPE START
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENJ 1992	IGNITION SYSTEM - ROPE START
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40EENM 1992	IGNITION SYSTEM - ROPE START
J40EEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40EERE 1994	IGNITION SYSTEM - 40 ROPE START
J40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40EESR 1990	IGNITION SYSTEM - ROPE START
J40EETB 1993	IGNITION SYSTEM - 40 ROPE START
J40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELCCS 1988	IGNITION SYSTEM
J40ELCDE 1986	IGNITION SYSTEM
J40ELCEC 1989	IGNITION SYSTEM - ROPE START
J40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40ELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J40ELCOB 1985	IGNITION SYSTEM
J40ELCRM 1984	IGNITION SYSTEM
J40ELCUD 1987	IGNITION SYSTEM
J40ELECR 1998	IGNITION SYSTEM -- ROPE START
J40ELEDs 1996	IGNITION SYSTEM - 40 ROPE START
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELEIA 1991	IGNITION SYSTEM - ROPE START
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENJ 1992	IGNITION SYSTEM - ROPE START
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40ELENM 1992	IGNITION SYSTEM - ROPE START
J40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40ELESR 1990	IGNITION SYSTEM - ROPE START

J40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
J40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELEUC 1997	IGNITION SYSTEM - ROPE START
J40JRECA 1998	IGNITION SYSTEM
J40JREDC 1996	IGNITION SYSTEM
J40JREOS 1995	IGNITION SYSTEM
J40JREUR 1997	IGNITION SYSTEM
J40PLEEA 1999	IGNITION SYSTEM -- ROPE START
J40PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RCCS 1988	IGNITION SYSTEM
J40RCDE 1986	IGNITION SYSTEM
J40RCEC 1989	IGNITION SYSTEM - ROPE START
J40RCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40RCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40RCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J40RCOB 1985	IGNITION SYSTEM
J40RCRM 1984	IGNITION SYSTEM
J40RCUD 1987	IGNITION SYSTEM
J40RECR 1998	IGNITION SYSTEM -- ROPE START
J40REDS 1996	IGNITION SYSTEM - 40 ROPE START
J40REEA 1999	IGNITION SYSTEM -- ROPE START
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40REIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40REIA 1991	IGNITION SYSTEM - ROPE START
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RENM 1992	IGNITION SYSTEM - ROPE START
J40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40RESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RESR 1990	IGNITION SYSTEM - ROPE START
J40RETB 1993	IGNITION SYSTEM - 40 ROPE START
J40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40REUC 1997	IGNITION SYSTEM - ROPE START
J40RLCCS 1988	IGNITION SYSTEM
J40RLCDE 1986	IGNITION SYSTEM
J40RLCEC 1989	IGNITION SYSTEM - ROPE START
J40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40RLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40RLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J40RLCOB 1985	IGNITION SYSTEM
J40RLCRM 1984	IGNITION SYSTEM
J40RLCUD 1987	IGNITION SYSTEM
J40RLECR 1998	IGNITION SYSTEM -- ROPE START
J40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40RLEEA 1999	IGNITION SYSTEM -- ROPE START
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLEIA 1991	IGNITION SYSTEM - ROPE START
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40RLENM 1992	IGNITION SYSTEM - ROPE START
J40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40RLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40RLESR 1990	IGNITION SYSTEM - ROPE START
J40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40RLEUC 1997	IGNITION SYSTEM - ROPE START
J40RLSIF rope start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RLSOC	IGNITION SYSTEM
J40RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSRS	IGNITION SYSTEM
J40RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RLSTD	IGNITION SYSTEM
J40RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSIF rope start, 15 in shaft 2001	IGNITION SYSTEM - ROPE START
J40RSLR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RSOC	IGNITION SYSTEM
J40RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RSRS	IGNITION SYSTEM
J40RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RSTD	IGNITION SYSTEM
J40RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40RWADB 1986	IGNITION
J40RWCOM 1985	IGNITION
J40RWCRA 1984	IGNITION
J40RWCTR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RWLCDB 1986	IGNITION
J40RWLCOM 1985	IGNITION
J40RWLCRA 1984	IGNITION
J40RWLCTR 1983	MAGNETO-RS AND RW MODELS ONLY
J40TECCS 1988	IGNITION SYSTEM
J40TECDE 1986	IGNITION SYSTEM
J40TECEC 1989	IGNITION SYSTEM - ROPE START
J40TECEC 1989	IGNITION SYSTEM - ELECTRIC START

J40TECEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40TECEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J40TECOB 1985	IGNITION SYSTEM
J40TECRM 1984	IGNITION SYSTEM
J40TECUD 1987	IGNITION SYSTEM
J40TEECR 1998	IGNITION SYSTEM -- ROPE START
J40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEEIA 1991	IGNITION SYSTEM - ROPE START
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENJ 1992	IGNITION SYSTEM - ROPE START
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TEENM 1992	IGNITION SYSTEM - ROPE START
J40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TEESR 1990	IGNITION SYSTEM - ROPE START
J40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TEEUC 1997	IGNITION SYSTEM - ROPE START
J40TELCES 1988	IGNITION SYSTEM
J40TELCDE 1986	IGNITION SYSTEM
J40TELCCEC 1989	IGNITION SYSTEM - ROPE START
J40TELCCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TELCCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40TELCCEC 1989	IGNITION SYSTEM - ROPE START (Continued)

J40TELCOB 1985	IGNITION SYSTEM
J40TELCRM 1984	IGNITION SYSTEM
J40TELECR 1998	IGNITION SYSTEM -- ROPE START
J40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELEIA 1991	IGNITION SYSTEM - ROPE START
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENJ 1992	IGNITION SYSTEM - ROPE START
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TELENM 1992	IGNITION SYSTEM - ROPE START
J40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TELESR 1990	IGNITION SYSTEM - ROPE START
J40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELEUC 1997	IGNITION SYSTEM - ROPE START
J40TLCCS 1988	IGNITION SYSTEM
J40TLCDE 1986	IGNITION SYSTEM
J40TLCEC 1989	IGNITION SYSTEM - ROPE START
J40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40TLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J40TLCUD 1987	IGNITION SYSTEM
J40TLECR 1998	IGNITION SYSTEM -- ROPE START
J40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START

J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLEIA 1991	IGNITION SYSTEM - ROPE START
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENJ 1992	IGNITION SYSTEM - ROPE START
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TLENM 1992	IGNITION SYSTEM - ROPE START
J40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TLESR 1990	IGNITION SYSTEM - ROPE START
J40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLEUC 1997	IGNITION SYSTEM - ROPE START
J40TPLEEA 1999	IGNITION SYSTEM -- ROPE START
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40TTLCCS 1988	IGNITION SYSTEM
J40TTLCEC 1989	IGNITION SYSTEM - ROPE START
J40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J40TTLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J40TTLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J40TTLECR 1998	IGNITION SYSTEM -- ROPE START
J40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START

J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLEIA 1991	IGNITION SYSTEM - ROPE START
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J40TTLENM 1992	IGNITION SYSTEM - ROPE START
J40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J40TTLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J40TTLESR 1990	IGNITION SYSTEM - ROPE START
J40TTLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLEUC 1997	IGNITION SYSTEM - ROPE START
J40WREES 1999	IGNITION SYSTEM
J40WRLEES 1999	IGNITION SYSTEM
J40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J40WRYEES 1999	IGNITION SYSTEM
J40WRY SIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J45RCCDS 1986	IGNITION SYSTEM
J45RCCUC 1987	IGNITION SYSTEM
J45RCE 1989	IGNITION
J45RCEIA 1991	IGNITION SYSTEM
J45RCENM 1992	IGNITION SYSTEM - ELECTRIC

J45RCENM 1992	IGNITION SYSTEM - ROPE START
J45RCEOD 1995	IGNITION SYSTEM
J45RCERE 1994	IGNITION SYSTEM
J45RCESR 1990	IGNITION
J45RCETB 1993	IGNITION SYSTEM
J45RCLCDS 1986	IGNITION SYSTEM
J45RCLCUC 1987	IGNITION SYSTEM
J45RCLE 1989	IGNITION
J45RCLEDS 1996	IGNITION SYSTEM
J45RCLEIA 1991	IGNITION SYSTEM
J45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCLENM 1992	IGNITION SYSTEM - ROPE START
J45RCLEOD 1995	IGNITION SYSTEM
J45RCLERE 1994	IGNITION SYSTEM
J45RCLESR 1990	IGNITION
J45RCLETB 1993	IGNITION SYSTEM
J45RCLEUC 1997	IGNITION SYSTEM
J45WMLE 1989	IGNITION
J45WMLEIA 1991	IGNITION SYSTEM
J45WMLENM 1992	IGNITION SYSTEM - ELECTRIC
J45WMLENM 1992	IGNITION SYSTEM - ROPE START
J45WMLESR 1990	IGNITION
J48ESLCCC 1988	IGNITION SYSTEM
J48ESLCER 1989	IGNITION SYSTEM (CONTINUED)
J48ESLCUS 1987	IGNITION SYSTEM
J48ESLEDC 1996	IGNITION SYSTEM
J48ESLEIM 1991	IGNITION SYSTEM
J48ESLENB 1992	IGNITION SYSTEM
J48ESLEOS 1995	IGNITION SYSTEM
J48ESLERD 1994	IGNITION SYSTEM
J48ESLESA 1990	IGNITION SYSTEM
J48ESLETE 1993	IGNITION SYSTEM
J4BRECRJ 1998	IGNITION
J4BRLECRJ 1998	IGNITION
J4RDHCCS 1988	MAGNETO

J4RDHCDE 1986	MAGNETO
J4RDHCEC 1989	IGNITION
J4RDHCUD 1987	MAGNETO
J4RDHEIA 1991	IGNITION
J4RDHENM 1992	IGNITION
J4RDHEOD 1995	MAGNETO
J4RDHERE 1994	MAGNETO
J4RDHESR 1990	IGNITION
J4RDHETB 1993	IGNITION
J4RDHLCCS 1988	MAGNETO
J4RDHLCEC 1989	IGNITION
J4RDHLCUD 1987	MAGNETO
J4RDHLEIA 1991	IGNITION
J4RDHLENM 1992	IGNITION
J4RDHLEOD 1995	MAGNETO
J4RDHLERE 1994	MAGNETO
J4RDHLESR 1990	IGNITION
J4RDHLETB 1993	IGNITION
J4REDS 1996	IGNITION
J4REEA 1999	IGNITION
J4REIA 1991	IGNITION
J4RENM 1992	IGNITION
J4REOD 1995	IGNITION
J4RERE 1994	IGNITION
J4RETB 1993	IGNITION
J4REUC 1997	IGNITION
J4RLCSS 1980	MAGNETO
J4RLEDs 1996	IGNITION
J4RLEEA 1999	IGNITION
J4RLEIA 1991	IGNITION
J4RLENM 1992	IGNITION
J4RLEOD 1995	IGNITION
J4RLERE 1994	IGNITION
J4RLETB 1993	IGNITION
J4RLEUC 1997	IGNITION

J4RLSIB Rope Start, Tiller, 20 IN. shaft 2001	IGNITION
J4RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J4RSIB Rope Start, Tiller, 15 IN. shaft 2001	IGNITION
J4RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J4WCSS 1980	MAGNETO
J50BECCS 1988	IGNITION SYSTEM
J50BECDE 1986	IGNITION SYSTEM
J50BECEC 1989	IGNITION SYSTEM - ROPE START
J50BECEC 1989	IGNITION SYSTEM - ELECTRIC START
J50BECEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J50BECEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J50BECIC 1981	IGNITION SYSTEM
J50BECNR 1982	IGNITION SYSTEM
J50BECOB 1985	IGNITION SYSTEM
J50BECRM 1984	IGNITION SYSTEM
J50BECTA 1983	IGNITION SYSTEM
J50BECUD 1987	IGNITION SYSTEM
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BEEIA 1991	IGNITION SYSTEM - ROPE START
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENJ 1992	IGNITION SYSTEM - ROPE START
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BEENM 1992	IGNITION SYSTEM - ROPE START
J50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

J50BEESR 1990	IGNITION SYSTEM - ROPE START
J50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
J50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELCCS 1988	IGNITION SYSTEM
J50BELCDE 1986	IGNITION SYSTEM
J50BELCEC 1989	IGNITION SYSTEM - ROPE START
J50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START
J50BELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J50BELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J50BELCIC 1981	IGNITION SYSTEM
J50BELCNR 1982	IGNITION SYSTEM
J50BELCOB 1985	IGNITION SYSTEM
J50BELCRM 1984	IGNITION SYSTEM
J50BELCTA 1983	IGNITION SYSTEM
J50BELCUD 1987	IGNITION SYSTEM
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELEIA 1991	IGNITION SYSTEM - ROPE START
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENJ 1992	IGNITION SYSTEM - ROPE START
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50BELENM 1992	IGNITION SYSTEM - ROPE START
J50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50BELESR 1990	IGNITION SYSTEM - ROPE START
J50BELETB 1993	IGNITION SYSTEM - 40 ROPE START

J50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50ECSR 1980	IGNITION SYSTEM
J50ELCSR 1980	IGNITION SYSTEM
J50ELEER 1999	IGNITION SYSTEM -- ROPE START
J50ELSIF elec start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50ESLECC 1998	IGNITION SYSTEM -- ROPE START
J50ESLEUR 1997	IGNITION SYSTEM - ROPE START
J50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50JEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50JEIA 1991	IGNITION SYSTEM - ROPE START
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENJ 1992	IGNITION SYSTEM - ROPE START
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50JENM 1992	IGNITION SYSTEM - ROPE START
J50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50JERE 1994	IGNITION SYSTEM - 40 ROPE START
J50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JETB 1993	IGNITION SYSTEM - 40 ROPE START
J50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JEUC 1997	IGNITION SYSTEM - ROPE START
J50PLEEA 1999	IGNITION SYSTEM -- ROPE START
J50PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50TELCCS 1988	IGNITION SYSTEM
J50TELCDE 1986	IGNITION SYSTEM
J50TELCEC 1989	IGNITION SYSTEM - ROPE START

J50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J50TELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J50TELCOB 1985	IGNITION SYSTEM
J50TELCRM 1984	IGNITION SYSTEM
J50TELCCTA 1983	IGNITION SYSTEM
J50TELCUD 1987	IGNITION SYSTEM
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELEIA 1991	IGNITION SYSTEM - ROPE START
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TELENM 1992	IGNITION SYSTEM - ROPE START
J50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TELESR 1990	IGNITION SYSTEM - ROPE START
J50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLCCS 1988	IGNITION SYSTEM
J50TLCDE 1986	IGNITION SYSTEM
J50TLCEC 1989	IGNITION SYSTEM - ROPE START
J50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
J50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
J50TLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
J50TLCOB 1985	IGNITION SYSTEM
J50TELCRM 1984	IGNITION SYSTEM
J50TLCUD 1987	IGNITION SYSTEM
J50TLECR 1998	IGNITION SYSTEM -- ROPE START
J50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START

J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLEIA 1991	IGNITION SYSTEM - ROPE START
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENJ 1992	IGNITION SYSTEM - ROPE START
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
J50TLENM 1992	IGNITION SYSTEM - ROPE START
J50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
J50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
J50TLESR 1990	IGNITION SYSTEM - ROPE START
J50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLEUC 1997	IGNITION SYSTEM - ROPE START
J50TSLECC 1998	IGNITION SYSTEM -- ROPE START
J50TSLEUS 1997	IGNITION SYSTEM - ROPE START
J55APRL	IGNITION & ELECTRICAL
J55APRL - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSOM	IGNITION & ELECTRICAL
J55APRLSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRA	IGNITION & ELECTRICAL
J55APRLSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRG	IGNITION & ELECTRICAL
J55APRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE

J55MLSOR	IGNITION & ELECTRICAL
J55MLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRC	IGNITION & ELECTRICAL
J55MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRG	IGNITION & ELECTRICAL
J55MLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55MRL	IGNITION & ELECTRICAL
J55MRL - FR	22-5_SYSTÈME D'ALLUMAGE
J55RCIM 1981	IGNITION SYSTEM
J55RLCIM 1981	IGNITION SYSTEM
J55RLCSA 1980	IGNITION SYSTEM
J55RSLC 1997	IGNITION SYSTEM
J55RSLG 1995	IGNITION SYSTEM
J55RSLN 1983	IGNITION SYSTEM
J55RSLN-2 1983	IGNITION SYSTEM
J55RSLW 1996	IGNITION SYSTEM
J55RSN 1983	IGNITION SYSTEM
J55RSN-2 1983	IGNITION SYSTEM
J55RSYN 1983	IGNITION SYSTEM
J55RSYN-2 1983	IGNITION SYSTEM
J55RWLCDC 1986	IGNITION SYSTEM
J55RWLCOS 1985	IGNITION SYSTEM
J55RWLCRD 1984	IGNITION SYSTEM
J55RWLCUC 1987	IGNITION SYSTEM
J55RWLE 1989	IGNITION
J55RWLEIA 1991	IGNITION SYSTEM
J55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
J55RWLENM 1992	IGNITION SYSTEM - ROPE START
J55RWLERE 1994	IGNITION SYSTEM
J55RWLESR 1990	IGNITION
J55RWLETB 1993	IGNITION SYSTEM
J55WREES 1999	IGNITION SYSTEM
J55WRLEES 1999	IGNITION SYSTEM
J55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J55WRLSOE	IGNITION SYSTEM

J55WRLSOE - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRB	IGNITION SYSTEM
J55WRLSRB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRG	IGNITION SYSTEM
J55WRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J55WRLSTM	IGNITION SYSTEM
J55WRLSTM - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J55WRYEES 1999	IGNITION SYSTEM
J55WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J55WRYSOB	IGNITION SYSTEM
J55WRYSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSRM	IGNITION SYSTEM
J55WRYSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J5DRECR 1998	IGNITION
J5DRLECR 1998	IGNITION
J5RCIC 1981	MAGNETO - 7.5
J5RCIC 1981	MAGNETO-4.5
J5RCSS 1980	MAGNETO - 7.5
J5RCSS 1980	MAGNETO-4.5
J5RHCIC 1981	MAGNETO - 7.5
J5RHCIC 1981	MAGNETO-4.5
J5RHCNR 1982	MAGNETO - 4.5
J5RHCNR 1982	MAGNETO - 7.5
J5RHCSS 1980	MAGNETO - 7.5
J5RHCSS 1980	MAGNETO-4.5
J5RHCTA 1983	MAGNETO-4.5
J5RHCTA 1983	MAGNETO-7.5
J5RHLCIC 1981	MAGNETO - 7.5
J5RHLCIC 1981	MAGNETO-4.5
J5RHLCNR 1982	MAGNETO - 4.5

J5RHLCNR 1982	MAGNETO - 7.5
J5RHLCSS 1980	MAGNETO - 7.5
J5RHLCSS 1980	MAGNETO-4.5
J5RHLCTA 1983	MAGNETO-4.5
J5RHLCTA 1983	MAGNETO-7.5
J5RLCIC 1981	MAGNETO - 7.5
J5RLCIC 1981	MAGNETO-4.5
J5RLCSS 1980	MAGNETO - 7.5
J5RLCSS 1980	MAGNETO-4.5
J60ECIA 1981	IGNITION SYSTEM
J60ECIH 1981	IGNITION SYSTEM
J60ECNM 1982	IGNITION SYSTEM
J60ECSR 1980	IGNITION SYSTEM
J60ECTB 1983	IGNITION SYSTEM
J60ELCIA 1981	IGNITION SYSTEM
J60ELCIH 1981	IGNITION SYSTEM
J60ELCNM 1982	IGNITION SYSTEM
J60ELCOD 1985	IGNITION SYSTEM
J60ELCRE 1984	IGNITION SYSTEM
J60ELCSR 1980	IGNITION SYSTEM
J60ELCTB 1983	IGNITION SYSTEM
J60TLCIA 1981	IGNITION SYSTEM
J60TLCIH 1981	IGNITION SYSTEM
J60TLCNM 1982	IGNITION SYSTEM
J60TLCOD 1985	IGNITION SYSTEM
J60TLCRE 1984	IGNITION SYSTEM
J60TLCTB 1983	IGNITION SYSTEM
J6RCCS 1988	IGNITION
J6RCDE 1986	MAGNETO
J6RCEC 1989	IGNITION
J6RCOB 1985	MAGNETO
J6RCRM 1984	MAGNETO - 6/8
J6RCUD 1987	IGNITION
J6RECR 1998	IGNITION
J6REDS 1996	IGNITION

J6REEA 1999	IGNITION
J6REIA 1991	IGNITION
J6RENM 1992	IGNITION
J6REOD 1995	IGNITION
J6RERE 1994	IGNITION
J6RESR 1990	IGNITION
J6RETB 1993	IGNITION
J6REUC 1997	IGNITION
J6RLCCS 1988	IGNITION
J6RLCDE 1986	MAGNETO
J6RLCEC 1989	IGNITION
J6RLCOB 1985	MAGNETO
J6RLCRM 1984	MAGNETO - 6/8
J6RLCUD 1987	IGNITION
J6RLECR 1998	IGNITION
J6RLEDS 1996	IGNITION
J6RLEEA 1999	IGNITION
J6RLEIA 1991	IGNITION
J6RLENM 1992	IGNITION
J6RLEOD 1995	IGNITION
J6RLERE 1994	IGNITION
J6RLESR 1990	IGNITION
J6RLETB 1993	IGNITION
J6RLEUC 1997	IGNITION
J6RLSIB rope start, tiller, 20 in shaft 2001	IGNITION
J6RLSOC	IGNITION
J6RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLSRS	IGNITION
J6RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J6RLSTD	IGNITION
J6RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	IGNITION
J6RSIB rope start, tiller, 15 in shaft 2001	IGNITION
J6RSOC	IGNITION

J6RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSRS	IGNITION
J6RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J6RSTD	IGNITION
J6RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	IGNITION
J6SLCCS 1988	IGNITION
J6SLCDE 1986	MAGNETO
J6SLCEC 1989	IGNITION
J6SLCOB 1985	MAGNETO
J6SLCRM 1984	MAGNETO - 6/8
J6SLCUD 1987	IGNITION
J6SLEDS 1996	IGNITION
J6SLEIA 1991	IGNITION
J6SLENM 1992	IGNITION
J6SLEOD 1995	IGNITION
J6SLERE 1994	IGNITION
J6SLESR 1990	IGNITION
J6SLETB 1993	IGNITION
J8DREEA 1999	IGNITION
J8RCCS 1988	IGNITION
J8RCDE 1986	MAGNETO
J8RCEC 1989	IGNITION
J8RCIC 1981	MAGNETO - 7.5
J8RCIC 1981	MAGNETO-4.5
J8RCNR 1982	MAGNETO - 4.5
J8RCNR 1982	MAGNETO - 7.5
J8RCOB 1985	MAGNETO
J8RCRM 1984	MAGNETO - 6/8
J8RCSS 1980	MAGNETO - 7.5
J8RCSS 1980	MAGNETO-4.5
J8RCTA 1983	MAGNETO-4.5
J8RCTA 1983	MAGNETO-7.5
J8RCUD 1987	IGNITION

J8RECR 1998	IGNITION
J8REDS 1996	IGNITION
J8REEM 1999	IGNITION
J8REIA 1991	IGNITION
J8RENM 1992	IGNITION
J8REOD 1995	IGNITION
J8RERE 1994	IGNITION
J8RESR 1990	IGNITION
J8RETB 1993	IGNITION
J8REUC 1997	IGNITION
J8RLCCS 1988	IGNITION
J8RLCDE 1986	MAGNETO
J8RLCEC 1989	IGNITION
J8RLCIC 1981	MAGNETO - 7.5
J8RLCIC 1981	MAGNETO-4.5
J8RLCNR 1982	MAGNETO - 4.5
J8RLCNR 1982	MAGNETO - 7.5
J8RLCOB 1985	MAGNETO
J8RLCRM 1984	MAGNETO - 6/8
J8RLCSS 1980	MAGNETO - 7.5
J8RLCSS 1980	MAGNETO-4.5
J8RLCTA 1983	MAGNETO-4.5
J8RLCTA 1983	MAGNETO-7.5
J8RLCUD 1987	IGNITION
J8RLECR 1998	IGNITION
J8RLEDS 1996	IGNITION
J8RLEEM 1999	IGNITION
J8RLEIA 1991	IGNITION
J8RLENM 1992	IGNITION
J8RLEOD 1995	IGNITION
J8RLERE 1994	IGNITION
J8RLESR 1990	IGNITION
J8RLETB 1993	IGNITION
J8RLEUC 1997	IGNITION
J8RLSIE rope start, tiller, 20 in shaft 2001	IGNITION

J8RLSOR	IGNITION
J8RLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSRC	IGNITION
J8RLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8RLSTS	IGNITION
J8RLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	IGNITION
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	IGNITION
J8RSIE rope start, tiller, 15 in shaft 2001	IGNITION
J8RSOR	IGNITION
J8RSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSRC	IGNITION
J8RSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J8RSTD	IGNITION
J8RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	IGNITION
J8RXEEM 1999	IGNITION
J8RXSIE rope start, tiller, 25 in shaft 2001	IGNITION
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	IGNITION
J8SRLCCS 1988	IGNITION
J8SRLCDE 1986	MAGNETO
J8SRLCEC 1989	IGNITION
J8SRLCNR 1982	MAGNETO - 4.5
J8SRLCNR 1982	MAGNETO - 7.5
J8SRLCOB 1985	MAGNETO
J8SRLCRM 1984	MAGNETO - 6/8
J8SRLCTA 1983	MAGNETO-4.5
J8SRLCTA 1983	MAGNETO-7.5
J8SRLCUD 1987	IGNITION
J8SRLECA 1998	IGNITION
J8SRLEDS 1996	IGNITION
J8SRLEIA 1991	IGNITION
J8SRLENM 1992	IGNITION

J8SRLEOD 1995	IGNITION
J8SRLERE 1994	IGNITION
J8SRLESR 1990	IGNITION
J8SRLETB 1993	IGNITION
J8SRLEUC 1997	IGNITION
J8WREES 1999	IGNITION
J8WRLEES 1999	IGNITION
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
M55RWLR 1988	IGNITION SYSTEM
MISCELLANEOUS 1981	THERMOSTAT KIT 40 MODELS
MISCELLANEOUS 1982	THERMOSTAT KIT 40 MODELS
MISCELLANEOUS 1983	THERMOSTAT KIT 40 MODELS
R45RCLR 1988	IGNITION SYSTEM
R45RCR 1988	IGNITION SYSTEM
R55RWLR 1988	IGNITION SYSTEM
RJ50ELSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
S45RCLR 1988	IGNITION SYSTEM
S45RCR 1988	IGNITION SYSTEM
SE10RPB 1996	IGNITION
SE10RPLB 1996	IGNITION
SE10RPLT 1997	IGNITION
SE10RPLY 1998	IGNITION
SE10RPT 1997	IGNITION
SE10RPY 1998	IGNITION
SE15BAECA 1998	IGNITION -- ELECTRIC
SE15BAECA 1998	IGNITION -- ROPE
SE15BAEDC 1996	IGNITION - ELECTRIC
SE15BAEDC 1996	IGNITION - ROPE
SE15BAEEM 1999	IGNITION -- ROPE
SE15BAEEM 1999	IGNITION -- ELECTRIC
SE15BAEUR 1997	IGNITION - ELECTRIC
SE15BAEUR 1997	IGNITION - ROPE

SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
SE15RPC 1998	IGNITION
SE15RPG 1996	IGNITION
SE15RPLC 1998	IGNITION
SE15RPLG 1996	IGNITION
SE15RPLW 1997	IGNITION
SE15RPW 1997	IGNITION
SE40RPB 1997	IGNITION SYSTEM
SE40RPH 1996	IGNITION SYSTEM
SE40RPLB 1997	IGNITION SYSTEM
SE40RPLH 1996	IGNITION SYSTEM
SE40RPLT2 1998	IGNITION SYSTEM
SE40RPT2 1998	IGNITION SYSTEM
SE40RPYB 1997	IGNITION SYSTEM
SE40RPYH 1996	IGNITION SYSTEM
SE40RPYT2 1998	IGNITION SYSTEM
SE40RSLD 1997	IGNITION SYSTEM
SE40RSLR 1998	IGNITION SYSTEM
SE40RSLZ 1996	IGNITION SYSTEM
SE45RSLB 1997	IGNITION SYSTEM
SE45RSLH 1996	IGNITION SYSTEM
SE50TLED5 1996	IGNITION SYSTEM - 40 ROPE START
SE55RSC 1997	IGNITION SYSTEM
SE55RSLC 1997	IGNITION SYSTEM
SE55RSLM2 1998	IGNITION SYSTEM
SE55RSLW 1996	IGNITION SYSTEM
SE55RSM2 1998	IGNITION SYSTEM
SE55RSW 1996	IGNITION SYSTEM
SE55RSYC 1997	IGNITION SYSTEM
SE55RSYM2 1998	IGNITION SYSTEM
SE55RSYW 1996	IGNITION SYSTEM
SJ10REDD 1996	IGNITION - ELECTRIC

SJ10REDD 1996	IGNITION - ROPE
SJ10RLEDD 1996	IGNITION - ELECTRIC
SJ10RLEDD 1996	IGNITION - ROPE
SJ10RPB 1996	IGNITION
SJ10RPLB 1996	IGNITION
SJ10RPLT 1997	IGNITION
SJ10RPLY 1998	IGNITION
SJ10RPT 1997	IGNITION
SJ10RPY 1998	IGNITION
SJ10SELEDD 1996	IGNITION - ELECTRIC
SJ10SELEDD 1996	IGNITION - ROPE
SJ15BAECA 1998	IGNITION -- ELECTRIC
SJ15BAECA 1998	IGNITION -- ROPE
SJ15BAEDC 1996	IGNITION - ELECTRIC
SJ15BAEDC 1996	IGNITION - ROPE
SJ15BAEEM 1999	IGNITION -- ROPE
SJ15BAEEM 1999	IGNITION -- ELECTRIC
SJ15BAEUR 1997	IGNITION - ELECTRIC
SJ15BAEUR 1997	IGNITION - ROPE
SJ15REDS 1996	IGNITION - ELECTRIC
SJ15REDS 1996	IGNITION - ROPE
SJ15RLEDS 1996	IGNITION - ELECTRIC
SJ15RLEDS 1996	IGNITION - ROPE
SJ15RPC 1998	IGNITION
SJ15RPG 1996	IGNITION
SJ15RPLC 1998	IGNITION
SJ15RPLG 1996	IGNITION
SJ15RPLW 1997	IGNITION
SJ15RPW 1997	IGNITION
SJ15RTEEM 1999	IGNITION -- ROPE
SJ15RTEEM 1999	IGNITION -- ELECTRIC
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC

SJ3REDS 1996	IGNITION
SJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40RLEDs 1996	IGNITION SYSTEM - 40 ROPE START
SJ40RPB 1997	IGNITION SYSTEM
SJ40RPH 1996	IGNITION SYSTEM
SJ40RPLB 1997	IGNITION SYSTEM
SJ40RPLH 1996	IGNITION SYSTEM
SJ40RPLT2 1998	IGNITION SYSTEM
SJ40RPT2 1998	IGNITION SYSTEM
SJ40RPYB 1997	IGNITION SYSTEM
SJ40RPYH 1996	IGNITION SYSTEM
SJ40RPYT2 1998	IGNITION SYSTEM
SJ40RSLD 1997	IGNITION SYSTEM
SJ40RSLR 1998	IGNITION SYSTEM
SJ40RSLZ 1996	IGNITION SYSTEM
SJ45RSLB 1997	IGNITION SYSTEM
SJ45RSLH 1996	IGNITION SYSTEM
SJ4REDS 1996	IGNITION
SJ4RLEDs 1996	IGNITION
SJ55RSC 1997	IGNITION SYSTEM
SJ55RSLC 1997	IGNITION SYSTEM
SJ55RSLM2 1998	IGNITION SYSTEM
SJ55RSLW 1996	IGNITION SYSTEM
SJ55RSM2 1998	IGNITION SYSTEM
SJ55RSW 1996	IGNITION SYSTEM
SJ55RSYC 1997	IGNITION SYSTEM
SJ55RSYM2 1998	IGNITION SYSTEM
SJ55RSYW 1996	IGNITION SYSTEM
SJ6REDS 1996	IGNITION
SJ6RLEDs 1996	IGNITION
SJ8REDS 1996	IGNITION
SJ8RLEDs 1996	IGNITION
TE10ELCES 1989	IGNITION
TE10ELESC 1990	IGNITION

TE10RELEIR 1991	IGNITION
TE10RELENA 1992	IGNITION
TE10RELESC 1990	IGNITION
TE10RELETM 1993	IGNITION - ELECTRIC
TE10RELETM 1993	IGNITION - ROPE
TE10RLCES 1989	IGNITION
TE10RLESC 1990	IGNITION
TE15RLCEC 1989	IGNITION
TE20CRCEM 1989	IGNITION
TE20CREND 1992	IGNITION
TE20CRESB 1990	IGNITION
TE20CRLCEM 1989	IGNITION
TE20CRLEIE 1991	IGNITION
TE20CRLEND 1992	IGNITION
TE20CRLESB 1990	IGNITION
TE20CRLESF 1989	IGNITION
TE25ELCEB 1989	IGNITION
TE25ELEID 1991	IGNITION
TE25ELENS 1992	IGNITION
TE25ELESE 1990	IGNITION
TE25ELESF 1989	IGNITION
TE30ELCED 1989	IGNITION
TE30ELESF 1989	IGNITION
TE30ELESS 1990	IGNITION
TE40ELCEC 1989	IGNITION SYSTEM - ROPE START
TE40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
TE40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
TE40ELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELEIA 1991	IGNITION SYSTEM - ROPE START
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENJ 1992	IGNITION SYSTEM - ROPE START

TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TE40ELENM 1992	IGNITION SYSTEM - ROPE START
TE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40ELESR 1990	IGNITION SYSTEM - ROPE START
TE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TE40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40TELESF 1990	IGNITION SYSTEM - ROPE START
TE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE40TELESR 1990	IGNITION SYSTEM - ROPE START
TE48ESLETE 1993	IGNITION SYSTEM
TE50TLCEC 1989	IGNITION SYSTEM - ROPE START
TE50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
TE50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
TE50TLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
TE50TLESF 1989	IGNITION SYSTEM - ROPE START
TE50TLESF 1989	IGNITION SYSTEM - ELECTRIC START
TE50TLESF 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
TE50TLESF 1989	IGNITION SYSTEM - ROPE START (Continued)
TE50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE50TLESF 1990	IGNITION SYSTEM - ROPE START
TE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TE50TLESR 1990	IGNITION SYSTEM - ROPE START
TE8RCEC 1989	IGNITION
TE8RLCEC 1989	IGNITION
TE8RLESCF 1990	IGNITION
TJ10ELCES 1989	IGNITION
TJ10ELESC 1990	IGNITION

TJ10RELEIR 1991	IGNITION
TJ10RELENA 1992	IGNITION
TJ10RELESC 1990	IGNITION
TJ10RELETM 1993	IGNITION - ELECTRIC
TJ10RELETM 1993	IGNITION - ROPE
TJ10RLCES 1989	IGNITION
TJ10RLESC 1990	IGNITION
TJ15RLCEC 1989	IGNITION
TJ20CRCEM 1989	IGNITION
TJ20CREND 1992	IGNITION
TJ20CRESB 1990	IGNITION
TJ20CRLCEM 1989	IGNITION
TJ20CRLEIE 1991	IGNITION
TJ20CRLEND 1992	IGNITION
TJ20CRLESB 1990	IGNITION
TJ20CRLESF 1989	IGNITION
TJ25ELCEB 1989	IGNITION
TJ25ELEID 1991	IGNITION
TJ25ELENS 1992	IGNITION
TJ25ELESE 1990	IGNITION
TJ25ELESF 1989	IGNITION
TJ30ELCED 1989	IGNITION
TJ30ELESF 1989	IGNITION
TJ30ELESS 1990	IGNITION
TJ40ELCEC 1989	IGNITION SYSTEM - ROPE START
TJ40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START
TJ40ELCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
TJ40ELCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELEIA 1991	IGNITION SYSTEM - ROPE START
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENJ 1992	IGNITION SYSTEM - ROPE START

TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
TJ40ELENM 1992	IGNITION SYSTEM - ROPE START
TJ40ELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELESF 1990	IGNITION SYSTEM - ROPE START
TJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40ELESR 1990	IGNITION SYSTEM - ROPE START
TJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TJ40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40TELESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40TELESF 1990	IGNITION SYSTEM - ROPE START
TJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ40TELESR 1990	IGNITION SYSTEM - ROPE START
TJ48ESLETE 1993	IGNITION SYSTEM
TJ50TLCEC 1989	IGNITION SYSTEM - ROPE START
TJ50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START
TJ50TLCEC 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
TJ50TLCEC 1989	IGNITION SYSTEM - ROPE START (Continued)
TJ50TLESF 1989	IGNITION SYSTEM - ROPE START
TJ50TLESF 1989	IGNITION SYSTEM - ELECTRIC START
TJ50TLESF 1989	IGNITION SYSTEM - ELECTRIC START (Continued)
TJ50TLESF 1989	IGNITION SYSTEM - ROPE START (Continued)
TJ50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ50TLESF 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ50TLESF 1990	IGNITION SYSTEM - ROPE START
TJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
TJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
TJ50TLESR 1990	IGNITION SYSTEM - ROPE START
TJ8RCEC 1989	IGNITION
TJ8RLCEC 1989	IGNITION

U25RWA 1988	MAGNETO
U25RWLA 1988	MAGNETO
VE14RCCS 1988	MAGNETO
VE14RCEC 1989	IGNITION
VE25ELEID 1991	IGNITION
VE25ELENS 1992	IGNITION
VE25ELESE 1990	IGNITION
VE25REIE 1991	IGNITION
VE25RESB 1990	IGNITION
VE28ESLCCR 1988	IGNITION
VE28ESLCEA 1989	IGNITION
VE28ESLESM 1990	IGNITION
VE30EEIC 1991	IGNITION
VE30EENR 1992	IGNITION
VE30EESS 1990	IGNITION
VE30ELEIC 1991	IGNITION
VE30ELENR 1992	IGNITION
VE30ELESS 1990	IGNITION
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EEIA 1991	IGNITION SYSTEM - ROPE START
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EENJ 1992	IGNITION SYSTEM - ROPE START
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40EENM 1992	IGNITION SYSTEM - ROPE START
VE40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40EESR 1990	IGNITION SYSTEM - ROPE START
VE40EETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELEIA 1991	IGNITION SYSTEM - ROPE START
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENJ 1992	IGNITION SYSTEM - ROPE START
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40ELENM 1992	IGNITION SYSTEM - ROPE START
VE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40ELESR 1990	IGNITION SYSTEM - ROPE START
VE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELEIA 1991	IGNITION SYSTEM - ROPE START
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELENJ 1992	IGNITION SYSTEM - ROPE START
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TELENM 1992	IGNITION SYSTEM - ROPE START
VE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TELESR 1990	IGNITION SYSTEM - ROPE START
VE40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

VE40TLEIA 1991	IGNITION SYSTEM - ROPE START
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLENJ 1992	IGNITION SYSTEM - ROPE START
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE40TLENM 1992	IGNITION SYSTEM - ROPE START
VE40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE40TLESR 1990	IGNITION SYSTEM - ROPE START
VE40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE48ESLCCC 1988	IGNITION SYSTEM
VE48ESLCER 1989	IGNITION SYSTEM (CONTINUED)
VE48ESLENB 1992	IGNITION SYSTEM
VE48ESLESA 1990	IGNITION SYSTEM
VE48ESLETE 1993	IGNITION SYSTEM
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BEEIA 1991	IGNITION SYSTEM - ROPE START
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENJ 1992	IGNITION SYSTEM - ROPE START
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BEENM 1992	IGNITION SYSTEM - ROPE START
VE50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

VE50BEESR 1990	IGNITION SYSTEM - ROPE START
VE50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELEIA 1991	IGNITION SYSTEM - ROPE START
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENJ 1992	IGNITION SYSTEM - ROPE START
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50BELENM 1992	IGNITION SYSTEM - ROPE START
VE50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50BELESR 1990	IGNITION SYSTEM - ROPE START
VE50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TELENM 1992	IGNITION SYSTEM - ROPE START
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLEIA 1991	IGNITION SYSTEM - ROPE START
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENJ 1992	IGNITION SYSTEM - ROPE START
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VE50TLENM 1992	IGNITION SYSTEM - ROPE START

VE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VE50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VE50TLESR 1990	IGNITION SYSTEM - ROPE START
VE50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ14RCCS 1988	MAGNETO
VJ14RCEC 1989	IGNITION
VJ25ELEID 1991	IGNITION
VJ25ELENS 1992	IGNITION
VJ25ELESE 1990	IGNITION
VJ25REIE 1991	IGNITION
VJ25RESB 1990	IGNITION
VJ28ESLCCR 1988	IGNITION
VJ28ESLCEA 1989	IGNITION
VJ28ESLESM 1990	IGNITION
VJ30EEIC 1991	IGNITION
VJ30EENR 1992	IGNITION
VJ30EESS 1990	IGNITION
VJ30ELEIC 1991	IGNITION
VJ30ELENR 1992	IGNITION
VJ30ELESS 1990	IGNITION
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40EEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EEIA 1991	IGNITION SYSTEM - ROPE START
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EENJ 1992	IGNITION SYSTEM - ROPE START
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40EENM 1992	IGNITION SYSTEM - ROPE START

VJ40EESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40EESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40EESR 1990	IGNITION SYSTEM - ROPE START
VJ40EETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40ELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELEIA 1991	IGNITION SYSTEM - ROPE START
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENJ 1992	IGNITION SYSTEM - ROPE START
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40ELENM 1992	IGNITION SYSTEM - ROPE START
VJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40ELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40ELESR 1990	IGNITION SYSTEM - ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TELEIA 1991	IGNITION SYSTEM - ROPE START
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELENJ 1992	IGNITION SYSTEM - ROPE START
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TELENM 1992	IGNITION SYSTEM - ROPE START
VJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS

VJ40TELESR 1990	IGNITION SYSTEM - ROPE START
VJ40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLEIA 1991	IGNITION SYSTEM - ROPE START
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENJ 1992	IGNITION SYSTEM - ROPE START
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ40TLENM 1992	IGNITION SYSTEM - ROPE START
VJ40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ40TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ40TLESR 1990	IGNITION SYSTEM - ROPE START
VJ40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ48ESLCCC 1988	IGNITION SYSTEM
VJ48ESLCER 1989	IGNITION SYSTEM (CONTINUED)
VJ48ESLENB 1992	IGNITION SYSTEM
VJ48ESLESA 1990	IGNITION SYSTEM
VJ48ESLETE 1993	IGNITION SYSTEM
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BEEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEEIA 1991	IGNITION SYSTEM - ROPE START
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENJ 1992	IGNITION SYSTEM - ROPE START
VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)

VJ50BEENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BEENM 1992	IGNITION SYSTEM - ROPE START
VJ50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BEESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BEESR 1990	IGNITION SYSTEM - ROPE START
VJ50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BELEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELEIA 1991	IGNITION SYSTEM - ROPE START
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENJ 1992	IGNITION SYSTEM - ROPE START
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50BELENM 1992	IGNITION SYSTEM - ROPE START
VJ50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50BELESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50BELESR 1990	IGNITION SYSTEM - ROPE START
VJ50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TELENM 1992	IGNITION SYSTEM - ROPE START
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50TLEIA 1991	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLEIA 1991	IGNITION SYSTEM - ROPE START
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENJ 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)

VJ50TLENJ 1992	IGNITION SYSTEM - ROPE START
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START & TL MODELS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ELECTRIC START TE-TTL MDLS ("M" SUFFIX)
VJ50TLENM 1992	IGNITION SYSTEM - ROPE START
VJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TL MODELS
VJ50TLESR 1990	IGNITION SYSTEM - ELECTRIC START TE-TTL MODELS
VJ50TLESR 1990	IGNITION SYSTEM - ROPE START
VJ50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
X50ESLECC 1998	IGNITION SYSTEM -- ROPE START