

Where Used: Part Number 0324956

Model Name	Diagram
5/6HP	AUXILIARY STEERING KIT
6/8HP (2 Stroke)	STEERING BAR KIT, AUXILIARY MOTOR
6904E 1979	GEARCASE
6905E 1979	GEARCASE
6R79E 1979	GEARCASE
6RL79E 1979	GEARCASE
BE5DREDS 1996	CYLINDER & CRANKCASE
BE5DREDS 1996	STEERING HANDLE
BE5DREUC 1997	CYLINDER & CRANKCASE
BE5DREUC 1997	STEERING HANDLE
BE5DRLEDS 1996	CYLINDER & CRANKCASE
BE5DRLEDS 1996	STEERING HANDLE
BE5DRLEUC 1997	CYLINDER & CRANKCASE
BE5DRLEUC 1997	STEERING HANDLE
BE5FRBECC 1998	STEERING HANDLE
BE5FRBEUS 1997	STEERING HANDLE
BE5FRBLECC 1998	STEERING HANDLE
BE5FRBLEUS 1997	STEERING HANDLE
BE6DRECR 1998	CYLINDER & CRANKCASE
BE6DRECR 1998	STEERING HANDLE
BE6DREDS 1996	CYLINDER & CRANKCASE
BE6DREDS 1996	STEERING HANDLE
BE6DREUC 1997	CYLINDER & CRANKCASE
BE6DREUC 1997	STEERING HANDLE
BE6DRLECR 1998	CYLINDER & CRANKCASE
BE6DRLECR 1998	STEERING HANDLE
BE6DRLEDS 1996	CYLINDER & CRANKCASE
BE6DRLEDS 1996	STEERING HANDLE
BE6DRLEUC 1997	CYLINDER & CRANKCASE
BE6DRLEUC 1997	STEERING HANDLE
BE6REDS 1996	CYLINDER & CRANKCASE
BE6REDS 1996	STEERING HANDLE
BE6RLEDS 1996	CYLINDER & CRANKCASE

BE6RLEDS 1996	STEERING HANDLE
BE8RCB 1997	CYLINDER & CRANKCASE
BE8RCB 1997	STEERING HANDLE
BE8RCH 1996	STEERING HANDLE
BE8RCH 1996	CYLINDER & CRANKCASE
BE8RCLB 1997	CYLINDER & CRANKCASE
BE8RCLB 1997	STEERING HANDLE
BE8RCLH 1996	STEERING HANDLE
BE8RCLH 1996	CYLINDER & CRANKCASE
BE8RCLT 1998	CYLINDER & CRANKCASE
BE8RCLT 1998	STEERING HANDLE
BE8RCT 1998	CYLINDER & CRANKCASE
BE8RCT 1998	STEERING HANDLE
BE8REDS 1996	CYLINDER & CRANKCASE
BE8REDS 1996	STEERING HANDLE
BE8RLEDS 1996	CYLINDER & CRANKCASE
BE8RLEDS 1996	STEERING HANDLE
BE8SRLEDS 1996	CYLINDER & CRANKCASE
BE8SRLEDS 1996	STEERING HANDLE
BJ5DREDS 1996	CYLINDER & CRANKCASE
BJ5DREDS 1996	STEERING HANDLE
BJ5DREUC 1997	CYLINDER & CRANKCASE
BJ5DREUC 1997	STEERING HANDLE
BJ5DRLEDS 1996	CYLINDER & CRANKCASE
BJ5DRLEDS 1996	STEERING HANDLE
BJ5DRLEUC 1997	CYLINDER & CRANKCASE
BJ5DRLEUC 1997	STEERING HANDLE
BJ5FRBECC 1998	STEERING HANDLE
BJ5FRBEUS 1997	STEERING HANDLE
BJ5FRBLECC 1998	STEERING HANDLE
BJ5FRBLEUS 1997	STEERING HANDLE
BJ6DRECR 1998	CYLINDER & CRANKCASE
BJ6DRECR 1998	STEERING HANDLE
BJ6DREDS 1996	CYLINDER & CRANKCASE
BJ6DREDS 1996	STEERING HANDLE

BJ6DREUC 1997	CYLINDER & CRANKCASE
BJ6DREUC 1997	STEERING HANDLE
BJ6DRLECR 1998	CYLINDER & CRANKCASE
BJ6DRLECR 1998	STEERING HANDLE
BJ6DRLEDS 1996	CYLINDER & CRANKCASE
BJ6DRLEDS 1996	STEERING HANDLE
BJ6DRLEUC 1997	CYLINDER & CRANKCASE
BJ6DRLEUC 1997	STEERING HANDLE
BJ6REDS 1996	CYLINDER & CRANKCASE
BJ6REDS 1996	STEERING HANDLE
BJ6RLEDS 1996	CYLINDER & CRANKCASE
BJ6RLEDS 1996	STEERING HANDLE
BJ8RCB 1997	CYLINDER & CRANKCASE
BJ8RCB 1997	STEERING HANDLE
BJ8RCH 1996	CYLINDER & CRANKCASE
BJ8RCH 1996	STEERING HANDLE
BJ8RCLB 1997	CYLINDER & CRANKCASE
BJ8RCLB 1997	STEERING HANDLE
BJ8RCLH 1996	CYLINDER & CRANKCASE
BJ8RCLH 1996	STEERING HANDLE
BJ8RCLT 1998	CYLINDER & CRANKCASE
BJ8RCLT 1998	STEERING HANDLE
BJ8RCT 1998	CYLINDER & CRANKCASE
BJ8RCT 1998	STEERING HANDLE
BJ8REDS 1996	CYLINDER & CRANKCASE
BJ8REDS 1996	STEERING HANDLE
BJ8RLEDS 1996	CYLINDER & CRANKCASE
BJ8RLEDS 1996	STEERING HANDLE
BJ8SRLEDS 1996	CYLINDER & CRANKCASE
BJ8SRLEDS 1996	STEERING HANDLE
E10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL

E15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E25RWCOS 1985	MIDSECTION
E25RWLCOS 1985	MIDSECTION
E40RSLR 1983	GEARCASE
E40RSR 1983	GEARCASE
E40RWCDB 1986	GEARCASE
E40RWCOM 1985	GEARCASE
E40RWCRA 1984	GEARCASE
E40RWLCDB 1986	GEARCASE
E40RWLCOM 1985	GEARCASE
E40RWLCRA 1984	GEARCASE
E40RWLCTR 1983	GEARCASE
E40RWLTR 1983	GEARCASE
E5DRECR 1998	CYLINDER & CRANKCASE
E5DRECR 1998	STEERING HANDLE
E5DRLECR 1998	CYLINDER & CRANKCASE
E5DRLECR 1998	STEERING HANDLE
E5R4EEM 1999	STEERING HANDLE
E5R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	STEERING HANDLE
E5R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	STEERING HANDLE
E5RB4EER 1999	STEERING HANDLE
E5RBL4EER 1999	STEERING HANDLE
E5RL4EEM 1999	STEERING HANDLE
E5RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	STEERING HANDLE
E5RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	STEERING HANDLE
E6R4EEM 1999	STEERING HANDLE
E6R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	STEERING HANDLE
E6R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	STEERING HANDLE
E6RECR 1998	CYLINDER & CRANKCASE
E6RECR 1998	STEERING HANDLE
E6REDS 1996	CYLINDER & CRANKCASE
E6REDS 1996	STEERING HANDLE

E6REIA 1991	STEERING HANDLE
E6RENM 1992	STEERING HANDLE
E6REOD 1995	CYLINDER & CRANKCASE
E6REOD 1995	STEERING HANDLE
E6RERE 1994	STEERING HANDLE
E6RETB 1993	STEERING HANDLE
E6REUC 1997	CYLINDER & CRANKCASE
E6REUC 1997	STEERING HANDLE
E6RL4EEM 1999	STEERING HANDLE
E6RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	STEERING HANDLE
E6RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	STEERING HANDLE
E6RLECR 1998	CYLINDER & CRANKCASE
E6RLECR 1998	STEERING HANDLE
E6RLEDS 1996	CYLINDER & CRANKCASE
E6RLEDS 1996	STEERING HANDLE
E6RLEIA 1991	STEERING HANDLE
E6RLENM 1992	STEERING HANDLE
E6RLEOD 1995	CYLINDER & CRANKCASE
E6RLEOD 1995	STEERING HANDLE
E6RLERE 1994	STEERING HANDLE
E6RLETB 1993	STEERING HANDLE
E6RLEUC 1997	CYLINDER & CRANKCASE
E6RLEUC 1997	STEERING HANDLE
E6SLEDS 1996	CYLINDER & CRANKCASE
E6SLEDS 1996	STEERING HANDLE
E6SLEIA 1991	STEERING HANDLE
E6SLENM 1992	STEERING HANDLE
E6SLEOD 1995	CYLINDER & CRANKCASE
E6SLEOD 1995	STEERING HANDLE
E6SLERE 1994	STEERING HANDLE
E6SLETB 1993	STEERING HANDLE
E8DREEA 1999	CYLINDER & CRANKCASE
E8DREEA 1999	STEERING HANDLE
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	CYLINDER & CRANKCASE
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	STEERING HANDLE

E8RECR 1998	CYLINDER & CRANKCASE
E8RECR 1998	STEERING HANDLE
E8REDS 1996	CYLINDER & CRANKCASE
E8REDS 1996	STEERING HANDLE
E8REIA 1991	STEERING HANDLE
E8RENM 1992	STEERING HANDLE
E8REOD 1995	CYLINDER & CRANKCASE
E8REOD 1995	STEERING HANDLE
E8RERE 1994	STEERING HANDLE
E8RETB 1993	STEERING HANDLE
E8REUC 1997	CYLINDER & CRANKCASE
E8REUC 1997	STEERING HANDLE
E8RLECR 1998	CYLINDER & CRANKCASE
E8RLECR 1998	STEERING HANDLE
E8RLEDS 1996	CYLINDER & CRANKCASE
E8RLEDS 1996	STEERING HANDLE
E8RLEIA 1991	STEERING HANDLE
E8RLENM 1992	STEERING HANDLE
E8RLEOD 1995	CYLINDER & CRANKCASE
E8RLEOD 1995	STEERING HANDLE
E8RLERE 1994	STEERING HANDLE
E8RLETB 1993	STEERING HANDLE
E8RLEUC 1997	CYLINDER & CRANKCASE
E8RLEUC 1997	STEERING HANDLE
E8SRLECA 1998	CYLINDER & CRANKCASE
E8SRLECA 1998	STEERING HANDLE
E8SRLEDS 1996	CYLINDER & CRANKCASE
E8SRLEDS 1996	STEERING HANDLE
E8SRLEIA 1991	STEERING HANDLE
E8SRLENM 1992	STEERING HANDLE
E8SRLEOD 1995	CYLINDER & CRANKCASE
E8SRLEOD 1995	STEERING HANDLE
E8SRLERE 1994	STEERING HANDLE
E8SRLETB 1993	STEERING HANDLE
E8SRLEUC 1997	CYLINDER & CRANKCASE

E8SRLEUC 1997	STEERING HANDLE
E8WREES 1999	CYLINDER & CRANKCASE
E8WREES 1999	STEERING HANDLE
E8WRLEES 1999	CYLINDER & CRANKCASE
E8WRLEES 1999	STEERING HANDLE
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	CYLINDER & CRANKCASE
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	STEERING HANDLE
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	CYLINDER & CRANKCASE
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	STEERING HANDLE
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	CYLINDER & CRANKCASE
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	STEERING HANDLE
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	CYLINDER & CRANKCASE
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	STEERING HANDLE
HE5FRECA 1998	STEERING HANDLE
HE5FREUR 1997	STEERING HANDLE
HE5FRLECA 1998	STEERING HANDLE
HE5FRLEUR 1997	STEERING HANDLE
HE6FRECA 1998	STEERING HANDLE
HE6FREUR 1997	STEERING HANDLE
HE6FRLECA 1998	STEERING HANDLE
HE6FRLEUR 1997	STEERING HANDLE
HJ5FRECA 1998	STEERING HANDLE
HJ5FREUR 1997	STEERING HANDLE
HJ5FRLECA 1998	STEERING HANDLE
HJ5FRLEUR 1997	STEERING HANDLE
HJ6FRECA 1998	STEERING HANDLE
HJ6FREUR 1997	STEERING HANDLE
HJ6FRLECA 1998	STEERING HANDLE
HJ6FRLEUR 1997	STEERING HANDLE
iDock	JOYSTICK CONTROL
J10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL

J15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J25RWCOS 1985	MIDSECTION
J25RWLCOS 1985	MIDSECTION
J40RSLR 1983	GEARCASE
J40RSR 1983	GEARCASE
J40RWCDB 1986	GEARCASE
J40RWCOM 1985	GEARCASE
J40RWCRA 1984	GEARCASE
J40RWCTR 1983	GEARCASE
J40RWLCDB 1986	GEARCASE
J40RWLCOM 1985	GEARCASE
J40RWLCRA 1984	GEARCASE
J40RWLCTR 1983	GEARCASE
J5DRECR 1998	CYLINDER & CRANKCASE
J5DRECR 1998	STEERING HANDLE
J5DRLECR 1998	CYLINDER & CRANKCASE
J5DRLECR 1998	STEERING HANDLE
J6R4SRC	STEERING HANDLE
J6R4SRC - FR	16-6_BARRE
J6R4STS	STEERING HANDLE
J6R4STS - FR	16-6_BARRE
J6RECR 1998	CYLINDER & CRANKCASE
J6RECR 1998	STEERING HANDLE
J6REDS 1996	CYLINDER & CRANKCASE
J6REDS 1996	STEERING HANDLE
J6REEA 1999	CYLINDER & CRANKCASE
J6REEA 1999	STEERING HANDLE
J6REIA 1991	STEERING HANDLE
J6RENM 1992	STEERING HANDLE
J6REOD 1995	CYLINDER & CRANKCASE
J6REOD 1995	STEERING HANDLE
J6RERE 1994	STEERING HANDLE

J6RETB 1993	STEERING HANDLE
J6REUC 1997	CYLINDER & CRANKCASE
J6REUC 1997	STEERING HANDLE
J6RL4SRC	STEERING HANDLE
J6RL4SRC - FR	16-6_BARRE
J6RL4STS	STEERING HANDLE
J6RL4STS - FR	16-6_BARRE
J6RLECR 1998	CYLINDER & CRANKCASE
J6RLECR 1998	STEERING HANDLE
J6RLEDS 1996	CYLINDER & CRANKCASE
J6RLEDS 1996	STEERING HANDLE
J6RLEEA 1999	CYLINDER & CRANKCASE
J6RLEEA 1999	STEERING HANDLE
J6RLEIA 1991	STEERING HANDLE
J6RLENM 1992	STEERING HANDLE
J6RLEOD 1995	CYLINDER & CRANKCASE
J6RLEOD 1995	STEERING HANDLE
J6RLERE 1994	STEERING HANDLE
J6RLETB 1993	STEERING HANDLE
J6RLEUC 1997	CYLINDER & CRANKCASE
J6RLEUC 1997	STEERING HANDLE
J6RLSIB rope start, tiller, 20 in shaft 2001	CYLINDER & CRANKCASE
J6RLSIB rope start, tiller, 20 in shaft 2001	STEERING HANDLE
J6RLSOC	CYLINDER & CRANKCASE
J6RLSOC	STEERING HANDLE
J6RLSOC - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J6RLSOC - FR	26-6_BARRE
J6RLSRS	CYLINDER & CRANKCASE
J6RLSRS	STEERING HANDLE
J6RLSRS - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J6RLSRS - FR	26-6_BARRE
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	CYLINDER & CRANKCASE
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	STEERING HANDLE
J6RLSTD	CYLINDER & CRANKCASE
J6RLSTD	STEERING HANDLE

J6RLSTD - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J6RLSTD - FR	26-6_BARRE
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	STEERING HANDLE
J6RSIB rope start, tiller, 15 in shaft 2001	CYLINDER & CRANKCASE
J6RSIB rope start, tiller, 15 in shaft 2001	STEERING HANDLE
J6RSOC	CYLINDER & CRANKCASE
J6RSOC	STEERING HANDLE
J6RSOC - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J6RSOC - FR	26-6_BARRE
J6RSRS	CYLINDER & CRANKCASE
J6RSRS	STEERING HANDLE
J6RSRS - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J6RSRS - FR	26-6_BARRE
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	CYLINDER & CRANKCASE
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	STEERING HANDLE
J6RSTD	CYLINDER & CRANKCASE
J6RSTD	STEERING HANDLE
J6RSTD - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J6RSTD - FR	26-6_BARRE
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	CYLINDER & CRANKCASE
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	STEERING HANDLE
J6SLEDS 1996	CYLINDER & CRANKCASE
J6SLEDS 1996	STEERING HANDLE
J6SLEIA 1991	STEERING HANDLE
J6SLENM 1992	STEERING HANDLE
J6SLEOD 1995	CYLINDER & CRANKCASE
J6SLEOD 1995	STEERING HANDLE
J6SLERE 1994	STEERING HANDLE
J6SLETB 1993	STEERING HANDLE
J8DREEA 1999	CYLINDER & CRANKCASE
J8DREEA 1999	STEERING HANDLE
J8RECR 1998	CYLINDER & CRANKCASE
J8RECR 1998	STEERING HANDLE
J8REDS 1996	CYLINDER & CRANKCASE

J8REDS 1996	STEERING HANDLE
J8REEM 1999	CYLINDER & CRANKCASE
J8REEM 1999	STEERING HANDLE
J8REIA 1991	STEERING HANDLE
J8RENM 1992	STEERING HANDLE
J8REOD 1995	CYLINDER & CRANKCASE
J8REOD 1995	STEERING HANDLE
J8RERE 1994	STEERING HANDLE
J8RETB 1993	STEERING HANDLE
J8REUC 1997	CYLINDER & CRANKCASE
J8REUC 1997	STEERING HANDLE
J8RLECR 1998	CYLINDER & CRANKCASE
J8RLECR 1998	STEERING HANDLE
J8RLEDS 1996	CYLINDER & CRANKCASE
J8RLEDS 1996	STEERING HANDLE
J8RLEEM 1999	CYLINDER & CRANKCASE
J8RLEEM 1999	STEERING HANDLE
J8RLEIA 1991	STEERING HANDLE
J8RLENM 1992	STEERING HANDLE
J8RLEOD 1995	CYLINDER & CRANKCASE
J8RLEOD 1995	STEERING HANDLE
J8RLERE 1994	STEERING HANDLE
J8RLETB 1993	STEERING HANDLE
J8RLEUC 1997	CYLINDER & CRANKCASE
J8RLEUC 1997	STEERING HANDLE
J8RLSIE rope start, tiller, 20 in shaft 2001	CYLINDER & CRANKCASE
J8RLSIE rope start, tiller, 20 in shaft 2001	STEERING HANDLE
J8RLSOR	CYLINDER & CRANKCASE
J8RLSOR	STEERING HANDLE
J8RLSOR - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J8RLSOR - FR	26-6_BARRE
J8RLSRC	CYLINDER & CRANKCASE
J8RLSRC	STEERING HANDLE
J8RLSRC - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J8RLSRC - FR	26-6_BARRE

J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	CYLINDER & CRANKCASE
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	STEERING HANDLE
J8RLSTS	CYLINDER & CRANKCASE
J8RLSTS	STEERING HANDLE
J8RLSTS - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J8RLSTS - FR	26-6_BARRE
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	CYLINDER & CRANKCASE
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	STEERING HANDLE
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	CYLINDER & CRANKCASE
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	STEERING HANDLE
J8RSIE rope start, tiller, 15 in shaft 2001	CYLINDER & CRANKCASE
J8RSIE rope start, tiller, 15 in shaft 2001	STEERING HANDLE
J8RSOR	CYLINDER & CRANKCASE
J8RSOR	STEERING HANDLE
J8RSOR - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J8RSOR - FR	26-6_BARRE
J8RSRC	CYLINDER & CRANKCASE
J8RSRC	STEERING HANDLE
J8RSRC - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J8RSRC - FR	26-6_BARRE
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	CYLINDER & CRANKCASE
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	STEERING HANDLE
J8RSTD	CYLINDER & CRANKCASE
J8RSTD	STEERING HANDLE
J8RSTD - FR	25-3_CYLINDRES ET CARTER-MOTEUR
J8RSTD - FR	26-6_BARRE
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	CYLINDER & CRANKCASE
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	STEERING HANDLE
J8RXEEM 1999	CYLINDER & CRANKCASE
J8RXEEM 1999	STEERING HANDLE
J8RXSIE rope start, tiller, 25 in shaft 2001	CYLINDER & CRANKCASE
J8RXSIE rope start, tiller, 25 in shaft 2001	STEERING HANDLE
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	CYLINDER & CRANKCASE
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	STEERING HANDLE
J8SRLECA 1998	CYLINDER & CRANKCASE

J8SRLECA 1998	STEERING HANDLE
J8SRLEDS 1996	CYLINDER & CRANKCASE
J8SRLEDS 1996	STEERING HANDLE
J8SRLEIA 1991	STEERING HANDLE
J8SRLENM 1992	STEERING HANDLE
J8SRLEOD 1995	CYLINDER & CRANKCASE
J8SRLEOD 1995	STEERING HANDLE
J8SRLERE 1994	STEERING HANDLE
J8SRLETB 1993	STEERING HANDLE
J8SRLEUC 1997	CYLINDER & CRANKCASE
J8SRLEUC 1997	STEERING HANDLE
J8WREES 1999	CYLINDER & CRANKCASE
J8WREES 1999	STEERING HANDLE
J8WRLEES 1999	CYLINDER & CRANKCASE
J8WRLEES 1999	STEERING HANDLE
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	CYLINDER & CRANKCASE
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	STEERING HANDLE
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	CYLINDER & CRANKCASE
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	STEERING HANDLE
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	CYLINDER & CRANKCASE
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	STEERING HANDLE
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	CYLINDER & CRANKCASE
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	STEERING HANDLE
SJ6REDS 1996	CYLINDER & CRANKCASE
SJ6REDS 1996	STEERING HANDLE
SJ6RLEDS 1996	CYLINDER & CRANKCASE
SJ6RLEDS 1996	STEERING HANDLE
SJ8REDS 1996	CYLINDER & CRANKCASE
SJ8REDS 1996	STEERING HANDLE
SJ8RLEDS 1996	CYLINDER & CRANKCASE
SJ8RLEDS 1996	STEERING HANDLE
STEERING	AUXILIARY STEERING KIT - 6,8 HP (2-Stroke)
STEERING 1998	STEERING BAR KIT, AUXILIARY MOTOR -- 5, 6, 8 (2-CYCLE)
STEERING 1999	STEERING BAR KIT, AUXILIARY MOTOR -- 6, 8 (2-CYCLE)

STEERING 2000

STEERING BAR KIT, AUXILIARY MOTOR - 6, 8 (2-CYCLE)