

Where Used: Part Number 0324960

Model Name	Diagram
25904R 1979	GEARCASE - 25
25904R 1979	GEARCASE - 35
25905R 1979	GEARCASE - 25
25905R 1979	GEARCASE - 35
25952R 1979	GEARCASE - 25
25952R 1979	GEARCASE - 35
25953R 1979	GEARCASE - 25
25953R 1979	GEARCASE - 35
25E79R 1979	GEARCASE - 25
25E79R 1979	GEARCASE - 35
25EL79R 1979	GEARCASE - 25
25EL79R 1979	GEARCASE - 35
25R79R 1979	GEARCASE - 25
25R79R 1979	GEARCASE - 35
25RL79R 1979	GEARCASE - 25
25RL79R 1979	GEARCASE - 35
35902A 1979	GEARCASE - 25
35902A 1979	GEARCASE - 35
35903A 1979	GEARCASE - 25
35903A 1979	GEARCASE - 35
35952A 1979	GEARCASE - 25
35952A 1979	GEARCASE - 35
35953A 1979	GEARCASE - 25
35953A 1979	GEARCASE - 35
35E79A 1979	GEARCASE - 25
35E79A 1979	GEARCASE - 35
35EL79A 1979	GEARCASE - 25
35EL79A 1979	GEARCASE - 35
35R79A 1979	GEARCASE - 25
35R79A 1979	GEARCASE - 35
35RL79A 1979	GEARCASE - 25
35RL79A 1979	GEARCASE - 35
D25RWA 1988	GEARCASE

D25RWLA 1988	GEARCASE
E20CRCCA 1988	GEARCASE
E20CRCDC 1986	GEARCASE
E20CRCEM 1989	GEARCASE
E20CRCOS 1985	GEARCASE
E20CRCUR 1987	GEARCASE
E20CRESB 1990	GEARCASE
E20CRLCCA 1988	GEARCASE
E20CRLCDC 1986	GEARCASE
E20CRLCEM 1989	GEARCASE
E20CRLCOS 1985	GEARCASE
E20CRLCUR 1987	GEARCASE
E20CRLESB 1990	GEARCASE
E20ECCA 1988	GEARCASE
E20ECDC 1986	GEARCASE
E20ECEM 1989	GEARCASE
E20ECOS 1985	GEARCASE
E20ECUR 1987	GEARCASE
E20ELCCA 1988	GEARCASE
E20ELCDC 1986	GEARCASE
E20ELCEM 1989	GEARCASE
E20ELCOS 1985	GEARCASE
E20ELCUR 1987	GEARCASE
E20TECDC 1986	GEARCASE
E25CNE 1982	GEARCASE
E25ECCM 1988	GEARCASE
E25ECDR 1986	GEARCASE
E25ECEB 1989	GEARCASE
E25ECIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ECIB 1981	EXHAUST HOUSING - ROPE START ONLY
E25ECIB 1981	GEARCASE
E25ECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ECIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25ECIM 1981	GEARCASE
E25ECOC 1985	GEARCASE

E25ECRS 1984	GEARCASE
E25ECTD 1983	GEARCASE
E25ECUA 1987	GEARCASE
E25ELCCM 1988	GEARCASE
E25ELCDR 1986	GEARCASE
E25ELCEB 1989	GEARCASE
E25ELCIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ELCIB 1981	EXHAUST HOUSING - ROPE START ONLY
E25ELCIB 1981	GEARCASE
E25ELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25ELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25ELCIM 1981	GEARCASE
E25ELCNE 1982	GEARCASE
E25ELCOC 1985	GEARCASE
E25ELCRS 1984	GEARCASE
E25ELCTD 1983	GEARCASE
E25ELCUA 1987	GEARCASE
E25JREOS 1995	JET DRIVE UNIT
E25RCCA 1988	GEARCASE
E25RCDC 1986	GEARCASE
E25RCEM 1989	GEARCASE
E25RCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25RCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25RCIM 1981	GEARCASE
E25RCNB 1982	GEARCASE
E25RCOS 1985	GEARCASE
E25RCRD 1984	GEARCASE
E25RCSA 1980	GEARCASE - 25
E25RCSA 1980	GEARCASE - 35
E25RCTE 1983	GEARCASE
E25RCUR 1987	GEARCASE
E25RESB 1990	GEARCASE
E25RLCCA 1988	GEARCASE
E25RLCDC 1986	GEARCASE
E25RLCEM 1989	GEARCASE

E25RLCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25RLCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25RLCIM 1981	GEARCASE
E25RLCNB 1982	GEARCASE
E25RLCOS 1985	GEARCASE
E25RLCRD 1984	GEARCASE
E25RLCSA 1980	GEARCASE - 25
E25RLCSA 1980	GEARCASE - 35
E25RLCTE 1983	GEARCASE
E25RLCUR 1987	GEARCASE
E25RLESB 1990	GEARCASE
E25RSA 1981	EXHAUST HOUSING
E25RSA 1981	GEARCASE
E25RSLA 1981	EXHAUST HOUSING
E25RSLA 1981	GEARCASE
E25RSLS 1983	GEARCASE
E25RSS 1983	GEARCASE
E25RWDC 1986	GEARCASE
E25RWCIM 1981	EXHAUST HOUSING
E25RWCIM 1981	GEARCASE
E25RWCOS 1985	GEARCASE
E25RWCRD 1984	GEARCASE
E25RWCTE 1983	GEARCASE
E25RWCUR 1987	GEARCASE
E25RWK 1989	GEARCASE
E25RWLDC 1986	GEARCASE
E25RWLCIM 1981	EXHAUST HOUSING
E25RWLCIM 1981	GEARCASE
E25RWLCOS 1985	GEARCASE
E25RWLCRD 1984	GEARCASE
E25RWLCTE 1983	GEARCASE
E25RWLCUR 1987	GEARCASE
E25RWLK 1989	GEARCASE
E25TECCA 1988	GEARCASE
E25TECDC 1986	GEARCASE

E25TECEM 1989	GEARCASE
E25TECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25TECIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25TECIM 1981	GEARCASE
E25TECNB 1982	GEARCASE
E25TECOS 1985	GEARCASE
E25TECRD 1984	GEARCASE
E25TECSA 1980	GEARCASE - 25
E25TECSA 1980	GEARCASE - 35
E25TECTE 1983	GEARCASE
E25TECUR 1987	GEARCASE
E25TELCCA 1988	GEARCASE
E25TELCDC 1986	GEARCASE
E25TELCEM 1989	GEARCASE
E25TELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
E25TELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
E25TELCIM 1981	GEARCASE
E25TELCNB 1982	GEARCASE
E25TELCOS 1985	GEARCASE
E25TELCRD 1984	GEARCASE
E25TELCSA 1980	GEARCASE - 25
E25TELCSA 1980	GEARCASE - 35
E25TELCTE 1983	GEARCASE
E25TELCUR 1987	GEARCASE
E28ELCDS 1986	GEARCASE
E28ESLCCR 1988	GEARCASE
E28ESLCEA 1989	GEARCASE
E28ESLCUC 1987	GEARCASE
E30ECCE 1988	GEARCASE
E30ECDM 1986	GEARCASE
E30ECED 1989	GEARCASE
E30EOA 1985	GEARCASE
E30ECRR 1984	GEARCASE
E30ECUB 1987	GEARCASE
E30ELCCE 1988	GEARCASE

E30ELCDM 1986	GEARCASE
E30ELCED 1989	GEARCASE
E30ELCOA 1985	GEARCASE
E30ELCRR 1984	GEARCASE
E30ELCUB 1987	GEARCASE
E30RCCE 1988	GEARCASE
E30RCDM 1986	GEARCASE
E30RCED 1989	GEARCASE
E30RCOA 1985	GEARCASE
E30RCUB 1987	GEARCASE
E30RESS 1990	GEARCASE
E30RLCCE 1988	GEARCASE
E30RLCDM 1986	GEARCASE
E30RLCED 1989	GEARCASE
E30RLCOA 1985	GEARCASE
E30RLCUB 1987	GEARCASE
E30RLESS 1990	GEARCASE
E30TECCE 1988	GEARCASE
E30TECDM 1986	GEARCASE
E30TECED 1989	GEARCASE
E30TECOA 1985	GEARCASE
E30TECUB 1987	GEARCASE
E30TELCCE 1988	GEARCASE
E30TELCDM 1986	GEARCASE
E30TELCED 1989	GEARCASE
E30TELCOA 1985	GEARCASE
E30TELCUB 1987	GEARCASE
E35ECIG 1981	EXHAUST HOUSING
E35ECIG 1981	GEARCASE
E35ECND 1982	GEARCASE
E35ECRR 1984	GEARCASE
E35ECSM 1980	GEARCASE - 25
E35ECSM 1980	GEARCASE - 35
E35ECTS 1983	GEARCASE - 35
E35ELCIG 1981	EXHAUST HOUSING

E35ELCIG 1981	GEARCASE
E35ELCND 1982	GEARCASE
E35ELCRR 1984	GEARCASE
E35ELCSM 1980	GEARCASE - 25
E35ELCSM 1980	GEARCASE - 35
E35ELCTS 1983	GEARCASE - 35
E35RCCE 1988	GEARCASE
E35RCDM 1986	GEARCASE
E35RCED 1989	GEARCASE
E35RCIG 1981	EXHAUST HOUSING
E35RCIG 1981	GEARCASE
E35RCND 1982	GEARCASE
E35RCRR 1984	GEARCASE
E35RCTS 1983	GEARCASE - 35
E35RCUB 1987	GEARCASE
E35RESS 1990	GEARCASE
E35RLCCE 1988	GEARCASE
E35RLCDM 1986	GEARCASE
E35RLCED 1989	GEARCASE
E35RLCIG 1981	EXHAUST HOUSING
E35RLCIG 1981	GEARCASE
E35RLCND 1982	GEARCASE
E35RLCRR 1984	GEARCASE
E35RLCTS 1983	GEARCASE - 35
E35RLCUB 1987	GEARCASE
E35RLESS 1990	GEARCASE
E35TCSM 1980	GEARCASE - 25
E35TCSM 1980	GEARCASE - 35
E35TELCNB 1982	GEARCASE
E35TELCRR 1984	GEARCASE
E35TELCTS 1983	GEARCASE - 35
E35TLESM 1980	GEARCASE - 25
E35TLESM 1980	GEARCASE - 35
J20CRCCA 1988	GEARCASE
J20CRCDC 1986	GEARCASE

J20CRCEM 1989	GEARCASE
J20CRCOS 1985	GEARCASE
J20CRCUR 1987	GEARCASE
J20CRESB 1990	GEARCASE
J20CRLCCA 1988	GEARCASE
J20CRLCDC 1986	GEARCASE
J20CRLCEM 1989	GEARCASE
J20CRLCOS 1985	GEARCASE
J20CRLCUR 1987	GEARCASE
J20CRLESB 1990	GEARCASE
J20ECCA 1988	GEARCASE
J20ECDC 1986	GEARCASE
J20ECEM 1989	GEARCASE
J20ECOS 1985	GEARCASE
J20ECUR 1987	GEARCASE
J20ELCCA 1988	GEARCASE
J20ELCDC 1986	GEARCASE
J20ELCEM 1989	GEARCASE
J20ELCOS 1985	GEARCASE
J20ELCUR 1987	GEARCASE
J20TECDC 1986	GEARCASE
J25ECCM 1988	GEARCASE
J25ECDR 1986	GEARCASE
J25ECEB 1989	GEARCASE
J25ECIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ECIB 1981	EXHAUST HOUSING - ROPE START ONLY
J25ECIB 1981	GEARCASE
J25ECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ECIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25ECIM 1981	GEARCASE
J25ECNE 1982	GEARCASE
J25ECOC 1985	GEARCASE
J25ECRS 1984	GEARCASE
J25ECTD 1983	GEARCASE
J25ECUA 1987	GEARCASE

J25ELCCM 1988	GEARCASE
J25ELCDR 1986	GEARCASE
J25ELCEB 1989	GEARCASE
J25ELCIB 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ELCIB 1981	EXHAUST HOUSING - ROPE START ONLY
J25ELCIB 1981	GEARCASE
J25ELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25ELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25ELCIM 1981	GEARCASE
J25ELCNE 1982	GEARCASE
J25ELCOC 1985	GEARCASE
J25ELCRS 1984	GEARCASE
J25ELCTD 1983	GEARCASE
J25ELCUA 1987	GEARCASE
J25JREOS 1995	JET DRIVE UNIT
J25RCCA 1988	GEARCASE
J25RCDC 1986	GEARCASE
J25RCEM 1989	GEARCASE
J25RCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25RCIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25RCIM 1981	GEARCASE
J25RCNB 1982	GEARCASE
J25RCOS 1985	GEARCASE
J25RCRD 1984	GEARCASE
J25RCSA 1980	GEARCASE - 25
J25RCSA 1980	GEARCASE - 35
J25RCTE 1983	GEARCASE
J25RCUR 1987	GEARCASE
J25RELCNB 1982	GEARCASE
J25RESB 1990	GEARCASE
J25RLCCA 1988	GEARCASE
J25RLCDC 1986	GEARCASE
J25RLCEM 1989	GEARCASE
J25RLCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25RLCIM 1981	EXHAUST HOUSING - ROPE START ONLY

J25RLCIM 1981	GEARCASE
J25RLCNB 1982	GEARCASE
J25RLCOS 1985	GEARCASE
J25RLCRD 1984	GEARCASE
J25RLCSA 1980	GEARCASE - 25
J25RLCSA 1980	GEARCASE - 35
J25RLCTE 1983	GEARCASE
J25RLCUR 1987	GEARCASE
J25RLESB 1990	GEARCASE
J25RSA 1981	EXHAUST HOUSING
J25RSA 1981	GEARCASE
J25RSLA 1981	EXHAUST HOUSING
J25RSLA 1981	GEARCASE
J25RSLS 1983	GEARCASE
J25RSS 1983	GEARCASE
J25RWDC 1986	GEARCASE
J25RWCIM 1981	EXHAUST HOUSING
J25RWCIM 1981	GEARCASE
J25RWCOS 1985	GEARCASE
J25RWCRD 1984	GEARCASE
J25RWCTE 1983	GEARCASE
J25RWCUR 1987	GEARCASE
J25RWK 1989	GEARCASE
J25RWLDC 1986	GEARCASE
J25RWLCIM 1981	EXHAUST HOUSING
J25RWLCIM 1981	GEARCASE
J25RWLCOS 1985	GEARCASE
J25RWLCRD 1984	GEARCASE
J25RWLCTE 1983	GEARCASE
J25RWLCUR 1987	GEARCASE
J25RWLK 1989	GEARCASE
J25TECCA 1988	GEARCASE
J25TECDC 1986	GEARCASE
J25TECEM 1989	GEARCASE
J25TECIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY

J25TECIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25TECIM 1981	GEARCASE
J25TECNB 1982	GEARCASE
J25TECOS 1985	GEARCASE
J25TECRD 1984	GEARCASE
J25TECSA 1980	GEARCASE - 25
J25TECSA 1980	GEARCASE - 35
J25TECTE 1983	GEARCASE
J25TECUR 1987	GEARCASE
J25TELCCA 1988	GEARCASE
J25TELCDC 1986	GEARCASE
J25TELCEM 1989	GEARCASE
J25TELCIM 1981	EXHAUST HOUSING - ELECTRIC START ONLY
J25TELCIM 1981	EXHAUST HOUSING - ROPE START ONLY
J25TELCIM 1981	GEARCASE
J25TELCOS 1985	GEARCASE
J25TELCRD 1984	GEARCASE
J25TELCSA 1980	GEARCASE - 25
J25TELCSA 1980	GEARCASE - 35
J25TELCCTE 1983	GEARCASE
J25TELCUR 1987	GEARCASE
J28ELCDS 1986	GEARCASE
J28ESLCCR 1988	GEARCASE
J28ESLCEA 1989	GEARCASE
J28ESLCUC 1987	GEARCASE
J30ECCE 1988	GEARCASE
J30ECDM 1986	GEARCASE
J30ECED 1989	GEARCASE
J30EOA 1985	GEARCASE
J30ECRR 1984	GEARCASE
J30ECUB 1987	GEARCASE
J30EES 1990	GEARCASE
J30ELCCE 1988	GEARCASE
J30ELCDM 1986	GEARCASE
J30ELCED 1989	GEARCASE

J30ELCOA 1985	GEARCASE
J30ELCRR 1984	GEARCASE
J30ELCUB 1987	GEARCASE
J30ELESS 1990	GEARCASE
J30RCCE 1988	GEARCASE
J30RCDM 1986	GEARCASE
J30RCED 1989	GEARCASE
J30RCOA 1985	GEARCASE
J30RCUB 1987	GEARCASE
J30RESS 1990	GEARCASE
J30RLCCE 1988	GEARCASE
J30RLCDM 1986	GEARCASE
J30RLCED 1989	GEARCASE
J30RLCOA 1985	GEARCASE
J30RLCUB 1987	GEARCASE
J30RLESS 1990	GEARCASE
J30TECCE 1988	GEARCASE
J30TECDM 1986	GEARCASE
J30TECED 1989	GEARCASE
J30TECOA 1985	GEARCASE
J30TECUB 1987	GEARCASE
J30TELCCE 1988	GEARCASE
J30TELCDM 1986	GEARCASE
J30TELCED 1989	GEARCASE
J30TELCOA 1985	GEARCASE
J30TELCUB 1987	GEARCASE
J35ECIG 1981	EXHAUST HOUSING
J35ECIG 1981	GEARCASE
J35ECND 1982	GEARCASE
J35ECRR 1984	GEARCASE
J35ECSM 1980	GEARCASE - 25
J35ECSM 1980	GEARCASE - 35
J35ECTS 1983	GEARCASE - 35
J35ELCIG 1981	EXHAUST HOUSING
J35ELCIG 1981	GEARCASE

J35ELCND 1982	GEARCASE
J35ELCRR 1984	GEARCASE
J35ELCSM 1980	GEARCASE - 25
J35ELCSM 1980	GEARCASE - 35
J35ELCTS 1983	GEARCASE - 35
J35RCCE 1988	GEARCASE
J35RCDM 1986	GEARCASE
J35RCED 1989	GEARCASE
J35RCIG 1981	EXHAUST HOUSING
J35RCIG 1981	GEARCASE
J35RCND 1982	GEARCASE
J35RCRR 1984	GEARCASE
J35RCSM 1980	GEARCASE - 25
J35RCSM 1980	GEARCASE - 35
J35RCTS 1983	GEARCASE - 35
J35RCUB 1987	GEARCASE
J35RESS 1990	GEARCASE
J35RLCCE 1988	GEARCASE
J35RLCDM 1986	GEARCASE
J35RLCED 1989	GEARCASE
J35RLCIG 1981	EXHAUST HOUSING
J35RLCIG 1981	GEARCASE
J35RLCND 1982	GEARCASE
J35RLCRR 1984	GEARCASE
J35RLCSM 1980	GEARCASE - 25
J35RLCSM 1980	GEARCASE - 35
J35RLCTS 1983	GEARCASE - 35
J35RLCUB 1987	GEARCASE
J35RLESS 1990	GEARCASE
J35TELCNB 1982	GEARCASE
J35TELCRR 1984	GEARCASE
J35TELCTS 1983	GEARCASE - 35
TE20CRCEM 1989	GEARCASE
TE20CRESB 1990	GEARCASE
TE20CRLCEM 1989	GEARCASE

TE20CRLESB 1990	GEARCASE
TE20CRLESF 1989	GEARCASE
TE25ELCEB 1989	GEARCASE
TE25ELESF 1989	GEARCASE
TE30ELCED 1989	GEARCASE
TE30ELESF 1989	GEARCASE
TJ20CRCEM 1989	GEARCASE
TJ20CRESB 1990	GEARCASE
TJ20CRLCEM 1989	GEARCASE
TJ20CRLESB 1990	GEARCASE
TJ20CRLESF 1989	GEARCASE
TJ25ELCEB 1989	GEARCASE
TJ25ELESF 1989	GEARCASE
TJ30ELCED 1989	GEARCASE
TJ30ELESF 1989	GEARCASE
U25RWA 1988	GEARCASE
U25RWLA 1988	GEARCASE
VE14RCCS 1988	GEARCASE
VE14RCEC 1989	GEARCASE
VE25RESB 1990	GEARCASE
VE28ESLCCR 1988	GEARCASE
VE28ESLCEA 1989	GEARCASE
VJ14RCCS 1988	GEARCASE
VJ14RCEC 1989	GEARCASE
VJ25RESB 1990	GEARCASE
VJ28ESLCCR 1988	GEARCASE
VJ28ESLCEA 1989	GEARCASE