

Where Used: Part Number 0325040

Model Name	Diagram
5/6HP	CHROME WATER PUMP KIT
5/6HP	GEARCASE EXTENSION KIT
6/8HP (2 Stroke)	CHROME PUMP KIT 6, 8 MODELS
6/8HP (2 Stroke)	GEARCASE EXTENSION KIT
BE4RDHEDS 1996	GEARCASE
BE4RDHLEDS 1996	GEARCASE
BE5DREDS 1996	GEARCASE
BE5DREUC 1997	GEARCASE
BE5DRLEDS 1996	GEARCASE
BE5DRLEUC 1997	GEARCASE
BE5FRBECC 1998	GEARCASE
BE5FRBEUS 1997	GEARCASE
BE5FRBLECC 1998	GEARCASE
BE5FRBLEUS 1997	GEARCASE
BE6DRECR 1998	GEARCASE
BE6DREDS 1996	GEARCASE
BE6DREUC 1997	GEARCASE
BE6DRLECR 1998	GEARCASE
BE6DRLEDS 1996	GEARCASE
BE6DRLEUC 1997	GEARCASE
BE6REDS 1996	GEARCASE
BE6RLEDS 1996	GEARCASE
BE8RCB 1997	GEARCASE
BE8RCH 1996	GEARCASE
BE8RCLB 1997	GEARCASE
BE8RCLH 1996	GEARCASE
BE8RCT 1998	GEARCASE
BE8REDS 1996	GEARCASE
BE8RLEDS 1996	GEARCASE
BE8SRLEDS 1996	GEARCASE
BJ4RDHEDS 1996	GEARCASE
BJ4RDHLEDS 1996	GEARCASE

BJ5DREDS 1996	GEARCASE
BJ5DREUC 1997	GEARCASE
BJ5DRLEDS 1996	GEARCASE
BJ5DRLEUC 1997	GEARCASE
BJ5FRBECC 1998	GEARCASE
BJ5FRBEUS 1997	GEARCASE
BJ5FRBLECC 1998	GEARCASE
BJ5FRBLEUS 1997	GEARCASE
BJ6DRECR 1998	GEARCASE
BJ6DREDS 1996	GEARCASE
BJ6DREUC 1997	GEARCASE
BJ6DRLECR 1998	GEARCASE
BJ6DRLEDS 1996	GEARCASE
BJ6DRLEUC 1997	GEARCASE
BJ6REDS 1996	GEARCASE
BJ6RLEDS 1996	GEARCASE
BJ8RCB 1997	GEARCASE
BJ8RCH 1996	GEARCASE
BJ8RCLB 1997	GEARCASE
BJ8RCLH 1996	GEARCASE
BJ8RCLT 1998	GEARCASE
BJ8RCT 1998	GEARCASE
BJ8REDS 1996	GEARCASE
BJ8RLEDS 1996	GEARCASE
BJ8SRLEDS 1996	GEARCASE
E4RDHCCS 1988	GEARCASE
E4RDHCDE 1986	GEARCASE
E4RDHCEC 1989	GEARCASE
E4RDHCUD 1987	GEARCASE
E4RDHEIA 1991	GEARCASE
E4RDHENM 1992	GEARCASE
E4RDHEOD 1995	GEARCASE
E4RDHERE 1994	GEARCASE
E4RDHESR 1990	GEARCASE
E4RDHETB 1993	GEARCASE

E4RDHLCCS 1988	GEARCASE
E4RDHLCEC 1989	GEARCASE
E4RDHLCUD 1987	GEARCASE
E4RDHLEIA 1991	GEARCASE
E4RDHLENM 1992	GEARCASE
E4RDHLEOD 1995	GEARCASE
E4RDHLERE 1994	GEARCASE
E4RDHLESR 1990	GEARCASE
E4RDHLETB 1993	GEARCASE
E5DRECR 1998	GEARCASE
E5DRLECR 1998	GEARCASE
E5R4EEM 1999	GEARCASE
E5R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	GEARCASE
E5R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	GEARCASE
E5RB4EER 1999	GEARCASE
E5RBL4EER 1999	GEARCASE
E5RCIC 1981	GEARCASE
E5RCSS 1980	GEARCASE
E5RHCIC 1981	GEARCASE
E5RHCNR 1982	GEARCASE
E5RHCSS 1980	GEARCASE
E5RHCTA 1983	GEARCASE
E5RHLIC 1981	GEARCASE
E5RHLCNR 1982	GEARCASE
E5RHLCSS 1980	GEARCASE
E5RHLCTA 1983	GEARCASE
E5RL4EEM 1999	GEARCASE
E5RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	GEARCASE
E5RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	GEARCASE
E5RLCIC 1981	GEARCASE
E5RLCSS 1980	GEARCASE
E6R4EEM 1999	GEARCASE
E6R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	GEARCASE
E6R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	GEARCASE
E6RCCS 1988	GEARCASE

E6RCDE 1986	GEARCASE
E6RCEC 1989	GEARCASE
E6RCOB 1985	GEARCASE
E6RCRM 1984	GEARCASE
E6RCUD 1987	GEARCASE
E6RECR 1998	GEARCASE
E6REDS 1996	GEARCASE
E6REIA 1991	GEARCASE
E6RENM 1992	GEARCASE
E6REOD 1995	GEARCASE
E6RERE 1994	GEARCASE
E6RESR 1990	GEARCASE
E6RETB 1993	GEARCASE
E6REUC 1997	GEARCASE
E6RL4EEM 1999	GEARCASE
E6RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	GEARCASE
E6RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	GEARCASE
E6RLCCS 1988	GEARCASE
E6RLCDE 1986	GEARCASE
E6RLCEC 1989	GEARCASE
E6RLCOB 1985	GEARCASE
E6RLCRM 1984	GEARCASE
E6RLCUD 1987	GEARCASE
E6RLECR 1998	GEARCASE
E6RLEDS 1996	GEARCASE
E6RLEIA 1991	GEARCASE
E6RLENM 1992	GEARCASE
E6RLEOD 1995	GEARCASE
E6RLERE 1994	GEARCASE
E6RLESR 1990	GEARCASE
E6RLETB 1993	GEARCASE
E6RLEUC 1997	GEARCASE
E6SLCCS 1988	GEARCASE
E6SLCDE 1986	GEARCASE
E6SLCEC 1989	GEARCASE

E6SLCOB 1985	GEARCASE
E6SLCRM 1984	GEARCASE
E6SLCUD 1987	GEARCASE
E6SLEDS 1996	GEARCASE
E6SLEIA 1991	GEARCASE
E6SLENM 1992	GEARCASE
E6SLEOD 1995	GEARCASE
E6SLERE 1994	GEARCASE
E6SLESR 1990	GEARCASE
E6SLETB 1993	GEARCASE
E8DREEA 1999	GEARCASE
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	GEARCASE
E8RCCS 1988	GEARCASE
E8RCDE 1986	GEARCASE
E8RCEC 1989	GEARCASE
E8RCIC 1981	GEARCASE
E8RCNR 1982	GEARCASE
E8RCOB 1985	GEARCASE
E8RCRM 1984	GEARCASE
E8RCSS 1980	GEARCASE
E8RCTA 1983	GEARCASE
E8RCUD 1987	GEARCASE
E8RECR 1998	GEARCASE
E8REDS 1996	GEARCASE
E8REIA 1991	GEARCASE
E8RENM 1992	GEARCASE
E8REOD 1995	GEARCASE
E8RERE 1994	GEARCASE
E8RESR 1990	GEARCASE
E8RETB 1993	GEARCASE
E8REUC 1997	GEARCASE
E8RLCCS 1988	GEARCASE
E8RLCDE 1986	GEARCASE
E8RLCEC 1989	GEARCASE
E8RLCIC 1981	GEARCASE

E8RLCNR 1982	GEARCASE
E8RLCOB 1985	GEARCASE
E8RLCRM 1984	GEARCASE
E8RLCSS 1980	GEARCASE
E8RLCTA 1983	GEARCASE
E8RLCUD 1987	GEARCASE
E8RLECR 1998	GEARCASE
E8RLEDS 1996	GEARCASE
E8RLEIA 1991	GEARCASE
E8RLENM 1992	GEARCASE
E8RLEOD 1995	GEARCASE
E8RLERE 1994	GEARCASE
E8RLESR 1990	GEARCASE
E8RLETB 1993	GEARCASE
E8RLEUC 1997	GEARCASE
E8SRLCCS 1988	GEARCASE
E8SRLCDE 1986	GEARCASE
E8SRLCEC 1989	GEARCASE
E8SRLCNR 1982	GEARCASE
E8SRLCOB 1985	GEARCASE
E8SRLCRM 1984	GEARCASE
E8SRLCTA 1983	GEARCASE
E8SRLCUD 1987	GEARCASE
E8SRLECA 1998	GEARCASE
E8SRLEDS 1996	GEARCASE
E8SRLEIA 1991	GEARCASE
E8SRLENM 1992	GEARCASE
E8SRLEOD 1995	GEARCASE
E8SRLERE 1994	GEARCASE
E8SRLESR 1990	GEARCASE
E8SRLETB 1993	GEARCASE
E8SRLEUC 1997	GEARCASE
E8WREES 1999	GEARCASE
E8WRLEES 1999	GEARCASE
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	GEARCASE

E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	GEARCASE
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
HE5FRECA 1998	GEARCASE
HE5FREUR 1997	GEARCASE
HE5FRLECA 1998	GEARCASE
HE5FRLEUR 1997	GEARCASE
HE6FRECA 1998	GEARCASE
HE6FREUR 1997	GEARCASE
HE6FRLECA 1998	GEARCASE
HE6FRLEUR 1997	GEARCASE
HJ5FRECA 1998	GEARCASE
HJ5FREUR 1997	GEARCASE
HJ5FRLECA 1998	GEARCASE
HJ5FRLEUR 1997	GEARCASE
HJ6FRECA 1998	GEARCASE
HJ6FREUR 1997	GEARCASE
HJ6FRLECA 1998	GEARCASE
HJ6FRLEUR 1997	GEARCASE
J4RDHCCS 1988	GEARCASE
J4RDHCDE 1986	GEARCASE
J4RDHCEC 1989	GEARCASE
J4RDHCUD 1987	GEARCASE
J4RDHEIA 1991	GEARCASE
J4RDHENM 1992	GEARCASE
J4RDHEOD 1995	GEARCASE
J4RDHERE 1994	GEARCASE
J4RDHESR 1990	GEARCASE
J4RDHETB 1993	GEARCASE
J4RDHLCCS 1988	GEARCASE
J4RDHLCEC 1989	GEARCASE
J4RDHLCUD 1987	GEARCASE
J4RDHLEIA 1991	GEARCASE
J4RDHLENM 1992	GEARCASE
J4RDHLEOD 1995	GEARCASE

J4RDHLERE 1994	GEARCASE
J4RDHLESR 1990	GEARCASE
J4RDHLETB 1993	GEARCASE
J5DRECR 1998	GEARCASE
J5DRLECR 1998	GEARCASE
J5RCIC 1981	GEARCASE
J5RCSS 1980	GEARCASE
J5RHCIC 1981	GEARCASE
J5RHCNR 1982	GEARCASE
J5RHCSS 1980	GEARCASE
J5RHCTA 1983	GEARCASE
J5RHLCIC 1981	GEARCASE
J5RHLCNR 1982	GEARCASE
J5RHLCSS 1980	GEARCASE
J5RHLCTA 1983	GEARCASE
J5RLCIC 1981	GEARCASE
J5RLCSS 1980	GEARCASE
J6R4SRC	GEARCASE
J6R4SRC - FR	17-1_BOÎTIER D'ENGRENAGES
J6R4STS	GEARCASE
J6R4STS - FR	17-1_BOÎTIER D'ENGRENAGES
J6RCCS 1988	GEARCASE
J6RCDE 1986	GEARCASE
J6RCEC 1989	GEARCASE
J6RCOB 1985	GEARCASE
J6RCRM 1984	GEARCASE
J6RCUD 1987	GEARCASE
J6RECR 1998	GEARCASE
J6REDS 1996	GEARCASE
J6REEA 1999	GEARCASE
J6REIA 1991	GEARCASE
J6RENM 1992	GEARCASE
J6REOD 1995	GEARCASE
J6RERE 1994	GEARCASE
J6RESR 1990	GEARCASE

J6RETB 1993	GEARCASE
J6REUC 1997	GEARCASE
J6RL4SRC	GEARCASE
J6RL4SRC - FR	17-1_BOÎTIER D'ENGRENAGES
J6RL4STS	GEARCASE
J6RL4STS - FR	17-1_BOÎTIER D'ENGRENAGES
J6RLCCS 1988	GEARCASE
J6RLCDE 1986	GEARCASE
J6RLCEC 1989	GEARCASE
J6RLCOB 1985	GEARCASE
J6RLCRM 1984	GEARCASE
J6RLCUD 1987	GEARCASE
J6RLECR 1998	GEARCASE
J6RLEDS 1996	GEARCASE
J6RLEEA 1999	GEARCASE
J6RLEIA 1991	GEARCASE
J6RLENM 1992	GEARCASE
J6RLEOD 1995	GEARCASE
J6RLERE 1994	GEARCASE
J6RLESR 1990	GEARCASE
J6RLETB 1993	GEARCASE
J6RLEUC 1997	GEARCASE
J6RLSIB rope start, tiller, 20 in shaft 2001	GEARCASE
J6RLSOC	GEARCASE
J6RLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J6RLSRS	GEARCASE
J6RLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J6RLSTD	GEARCASE
J6RLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	GEARCASE
J6RSIB rope start, tiller, 15 in shaft 2001	GEARCASE
J6RSOC	GEARCASE
J6RSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J6RSRS	GEARCASE

J6RSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J6RSTD	GEARCASE
J6RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	GEARCASE
J6SLCCS 1988	GEARCASE
J6SLCDE 1986	GEARCASE
J6SLCEC 1989	GEARCASE
J6SLCOB 1985	GEARCASE
J6SLCRM 1984	GEARCASE
J6SLCUD 1987	GEARCASE
J6SLEDS 1996	GEARCASE
J6SLEIA 1991	GEARCASE
J6SLENM 1992	GEARCASE
J6SLEOD 1995	GEARCASE
J6SLERE 1994	GEARCASE
J6SLESR 1990	GEARCASE
J6SLETB 1993	GEARCASE
J8DREEA 1999	GEARCASE
J8RCCS 1988	GEARCASE
J8RCDE 1986	GEARCASE
J8RCEC 1989	GEARCASE
J8RCIC 1981	GEARCASE
J8RCNR 1982	GEARCASE
J8RCOB 1985	GEARCASE
J8RCRM 1984	GEARCASE
J8RCSS 1980	GEARCASE
J8RCTA 1983	GEARCASE
J8RCUD 1987	GEARCASE
J8RECR 1998	GEARCASE
J8REDS 1996	GEARCASE
J8REEM 1999	GEARCASE
J8REIA 1991	GEARCASE
J8RENM 1992	GEARCASE
J8REOD 1995	GEARCASE

J8RERE 1994	GEARCASE
J8RESR 1990	GEARCASE
J8RETB 1993	GEARCASE
J8REUC 1997	GEARCASE
J8RLCCS 1988	GEARCASE
J8RLCDE 1986	GEARCASE
J8RLCEC 1989	GEARCASE
J8RLCIC 1981	GEARCASE
J8RLCNR 1982	GEARCASE
J8RLCOB 1985	GEARCASE
J8RLCRM 1984	GEARCASE
J8RLCSS 1980	GEARCASE
J8RLCTA 1983	GEARCASE
J8RLCUD 1987	GEARCASE
J8RLECR 1998	GEARCASE
J8RLEDS 1996	GEARCASE
J8RLEEM 1999	GEARCASE
J8RLEIA 1991	GEARCASE
J8RLENM 1992	GEARCASE
J8RLEOD 1995	GEARCASE
J8RLERE 1994	GEARCASE
J8RLESR 1990	GEARCASE
J8RLETB 1993	GEARCASE
J8RLEUC 1997	GEARCASE
J8RLSIE rope start, tiller, 20 in shaft 2001	GEARCASE
J8RLSOR	GEARCASE
J8RLSOR - FR	27-1_BOÎTIER D'ENGRENAGES
J8RLSRC	GEARCASE
J8RLSRC - FR	27-1_BOÎTIER D'ENGRENAGES
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J8RLSTS	GEARCASE
J8RLSTS - FR	27-1_BOÎTIER D'ENGRENAGES
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	GEARCASE
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	GEARCASE
J8RSIE rope start, tiller, 15 in shaft 2001	GEARCASE

J8RSOR	GEARCASE
J8RSOR - FR	27-1_BOÎTIER D'ENGRENAGES
J8RSRC	GEARCASE
J8RSRC - FR	27-1_BOÎTIER D'ENGRENAGES
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J8RSTD	GEARCASE
J8RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	GEARCASE
J8RXEEM 1999	GEARCASE
J8RXSIE rope start, tiller, 25 in shaft 2001	GEARCASE
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	GEARCASE
J8SRLCCS 1988	GEARCASE
J8SRLCDE 1986	GEARCASE
J8SRLCEC 1989	GEARCASE
J8SRLCNR 1982	GEARCASE
J8SRLCOB 1985	GEARCASE
J8SRLCRM 1984	GEARCASE
J8SRLCTA 1983	GEARCASE
J8SRLCUD 1987	GEARCASE
J8SRLECA 1998	GEARCASE
J8SRLEDS 1996	GEARCASE
J8SRLEIA 1991	GEARCASE
J8SRLENM 1992	GEARCASE
J8SRLEOD 1995	GEARCASE
J8SRLERE 1994	GEARCASE
J8SRLESR 1990	GEARCASE
J8SRLETB 1993	GEARCASE
J8SRLEUC 1997	GEARCASE
J8WREES 1999	GEARCASE
J8WRLEES 1999	GEARCASE
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	GEARCASE
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	GEARCASE
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
MISCELLANEOUS	GEARCASE EXTENSION KIT - 6,8 HP (2-Stroke)

MISCELLANEOUS 1980	CHROME PUMP KITS - 4.5,7.5 MODELS
MISCELLANEOUS 1981	CHROME PUMP KITS 4.5,6.5,7.5 MODELS
MISCELLANEOUS 1982	CHROME PUMP KITS 4.5,6.5,7.5 MODELS
MISCELLANEOUS 1983	CHROME PUMP KITS 4.5, 6.5, 7.5 MODELS
MISCELLANEOUS 1984	CHROME PUMP KITS 4D, 4.5, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1985	CHROME PUMP KITS 4D, 4.5, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1986	CHROME PUMP KITS 4D, 4.5, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1987	CHROME PUMP KITS 4D, 4.5, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1988	CHROME PUMP KITS 4D, 4.5, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1989	CHROME PUMP KITS 4D, 4.5, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1990	CHROME PUMP KITS 4D, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1991	CHROME PUMP KITS 4D, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1992	CHROME PUMP KITS 4D, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1993	CHROME PUMP KITS 4D, 5, 6, 6.5 & 8 MODELS
MISCELLANEOUS 1994	CHROME PUMP KITS 4D, 5, 6, & 8 MODELS
MISCELLANEOUS 1995	CHROME PUMP KITS 4D, 5, 6, & 8 MODELS
MISCELLANEOUS 1996	CHROME PUMP KITS 4D, 5, 6, & 8 MODELS
MISCELLANEOUS 1997	CHROME PUMP KITS 5, 6, 8 MODELS
MISCELLANEOUS 1998	CHROME PUMP KITS 5, 6, 8 MODELS
MISCELLANEOUS 1999	CHROME PUMP KITS 6, 8 MODELS
SJ6REDS 1996	GEARCASE
SJ6RLEDS 1996	GEARCASE
SJ8REDS 1996	GEARCASE
SJ8RLEDS 1996	GEARCASE
TE8RCEC 1989	GEARCASE
TE8RLCEC 1989	GEARCASE
TE8RLESCF 1990	GEARCASE
TJ8RCEC 1989	GEARCASE
TJ8RLCEC 1989	GEARCASE