

Where Used: Part Number 0326048

Model Name	Diagram
10924B 1979	SHORTING SWITCH
10925B 1979	SHORTING SWITCH
10935B 1979	SHORTING SWITCH
10955B 1979	SHORTING SWITCH
10EL79B 1979	SHORTING SWITCH
10R79B 1979	SHORTING SWITCH
10RL79B 1979	SHORTING SWITCH
10SEL79B 1979	SHORTING SWITCH
15904E 1979	SHORTING SWITCH
15905E 1979	SHORTING SWITCH
15954E 1979	SHORTING SWITCH
15955E 1979	SHORTING SWITCH
15E79E 1979	SHORTING SWITCH
15EL79E 1979	SHORTING SWITCH
15R79E 1979	SHORTING SWITCH
15RL79E 1979	SHORTING SWITCH
20/35HP	REMOTE CONTROL ADAPTER KIT
25904R 1979	SHORTING SWITCH
25905R 1979	SHORTING SWITCH
25952R 1979	SHORTING SWITCH
25953R 1979	SHORTING SWITCH
25E79R 1979	SHORTING SWITCH
25EL79R 1979	SHORTING SWITCH
25R79R 1979	SHORTING SWITCH
25RL79R 1979	SHORTING SWITCH
35902A 1979	SHORTING SWITCH
35903A 1979	SHORTING SWITCH
35952A 1979	SHORTING SWITCH
35953A 1979	SHORTING SWITCH
35E79A 1979	SHORTING SWITCH
35EL79A 1979	SHORTING SWITCH
35R79A 1979	SHORTING SWITCH
35RL79A 1979	SHORTING SWITCH

50R79C 1979	SHORTING SWITCH
50RL79C 1979	SHORTING SWITCH
55E79C 1979	SHORTING SWITCH
55EL79C 1979	SHORTING SWITCH
6904E 1979	MAGNETO
6905E 1979	MAGNETO
6R79E 1979	MAGNETO
6RL79E 1979	MAGNETO
B25JREUR 1997	REMOTE CONTROL ADAPTER KIT
BE20SRECB 1998	REMOTE CONTROL ADAPTER KIT
BE20SREDA 1996	REMOTE CONTROL ADAPTER KIT
BE20SREUM 1997	REMOTE CONTROL ADAPTER KIT
BE20SRLECB 1998	REMOTE CONTROL ADAPTER KIT
BE20SRLEDA 1996	REMOTE CONTROL ADAPTER KIT
BE20SRLEUM 1997	REMOTE CONTROL ADAPTER KIT
BE25BAECM 1998	REMOTE CONTROL ADAPTER KIT
BE25BAEDR 1996	REMOTE CONTROL ADAPTER KIT
BE25BAEUA 1997	REMOTE CONTROL ADAPTER KIT
BE25BALECM 1998	REMOTE CONTROL ADAPTER KIT
BE25BALEDR 1996	REMOTE CONTROL ADAPTER KIT
BE25BALEUA 1997	REMOTE CONTROL ADAPTER KIT
BE25BREDC 1996	REMOTE CONTROL ADAPTER KIT
BE25BRLEDC 1996	REMOTE CONTROL ADAPTER KIT
BE30BAECS 1998	REMOTE CONTROL ADAPTER KIT
BE30BAEDE 1996	REMOTE CONTROL ADAPTER KIT
BE30BAEUD 1997	REMOTE CONTROL ADAPTER KIT
BE30BALECS 1998	REMOTE CONTROL ADAPTER KIT
BE30BALEDE 1996	REMOTE CONTROL ADAPTER KIT
BE30BALEUD 1997	REMOTE CONTROL ADAPTER KIT
BJ20SRECB 1998	REMOTE CONTROL ADAPTER KIT
BJ20SREDA 1996	REMOTE CONTROL ADAPTER KIT
BJ20SREUM 1997	REMOTE CONTROL ADAPTER KIT
BJ20SRLECB 1998	REMOTE CONTROL ADAPTER KIT
BJ20SRLEDA 1996	REMOTE CONTROL ADAPTER KIT
BJ20SRLEUM 1997	REMOTE CONTROL ADAPTER KIT

BJ25BAECM 1998	REMOTE CONTROL ADAPTER KIT
BJ25BAEDR 1996	REMOTE CONTROL ADAPTER KIT
BJ25BAEUA 1997	REMOTE CONTROL ADAPTER KIT
BJ25BALECM 1998	REMOTE CONTROL ADAPTER KIT
BJ25BALEDR 1996	REMOTE CONTROL ADAPTER KIT
BJ25BALEUA 1997	REMOTE CONTROL ADAPTER KIT
BJ25BREDC 1996	REMOTE CONTROL ADAPTER KIT
BJ25BRLEDC 1996	REMOTE CONTROL ADAPTER KIT
BJ30BAECS 1998	REMOTE CONTROL ADAPTER KIT
BJ30BAEDE 1996	REMOTE CONTROL ADAPTER KIT
BJ30BAEUD 1997	REMOTE CONTROL ADAPTER KIT
BJ30BALECS 1998	REMOTE CONTROL ADAPTER KIT
BJ30BALEDE 1996	REMOTE CONTROL ADAPTER KIT
BJ30BALEUD 1997	REMOTE CONTROL ADAPTER KIT
E10ECSE 1980	SHORTING SWITCH
E10ELCSE 1980	SHORTING SWITCH
E10RCSE 1980	SHORTING SWITCH
E10RLCSE 1980	SHORTING SWITCH
E10SELCSE 1980	SHORTING SWITCH
E15ECSD 1980	SHORTING SWITCH
E15ELCSD 1980	SHORTING SWITCH
E15RCSD 1980	SHORTING SWITCH
E15RLCSD 1980	SHORTING SWITCH
E20CRCOS 1985	SHORTING SWITCH
E20CREUM 1997	REMOTE CONTROL ADAPTER KIT
E20CRLCOS 1985	SHORTING SWITCH
E20CRLEUM 1997	REMOTE CONTROL ADAPTER KIT
E20ECOS 1985	SHORTING SWITCH
E20ELCOS 1985	SHORTING SWITCH
E25CNE 1982	SHORTING SWITCH
E25ECIB 1981	SHORTING SWITCH
E25ECIM 1981	SHORTING SWITCH
E25ECOC 1985	SHORTING SWITCH
E25ECRS 1984	SHORTING SWITCH
E25ECTD 1983	SHORTING SWITCH

E25ELCIB 1981	SHORTING SWITCH
E25ELCIM 1981	SHORTING SWITCH
E25ELCNE 1982	SHORTING SWITCH
E25ELCOC 1985	SHORTING SWITCH
E25ELCRS 1984	SHORTING SWITCH
E25ELCTD 1983	SHORTING SWITCH
E25JRECA 1998	REMOTE CONTROL ADAPTER KIT
E25RCIM 1981	SHORTING SWITCH
E25RCNB 1982	SHORTING SWITCH
E25RCOS 1985	SHORTING SWITCH
E25RCRD 1984	SHORTING SWITCH
E25RCSA 1980	SHORTING SWITCH
E25RCTE 1983	SHORTING SWITCH
E25RECB 1998	REMOTE CONTROL ADAPTER KIT
E25REUM 1997	REMOTE CONTROL ADAPTER KIT
E25RLCIM 1981	SHORTING SWITCH
E25RLCNB 1982	SHORTING SWITCH
E25RLCOS 1985	SHORTING SWITCH
E25RLCRD 1984	SHORTING SWITCH
E25RLCSA 1980	SHORTING SWITCH
E25RLCTE 1983	SHORTING SWITCH
E25RLECB 1998	REMOTE CONTROL ADAPTER KIT
E25RLEUM 1997	REMOTE CONTROL ADAPTER KIT
E25RSA 1981	SHORTING SWITCH
E25RSLA 1981	SHORTING SWITCH
E25RSLS 1983	SHORTING SWITCH
E25RSS 1983	SHORTING SWITCH
E25RWCIM 1981	SHORTING SWITCH
E25RWCOS 1985	MAGNETO
E25RWCRD 1984	SHORTING SWITCH
E25RWCTE 1983	SHORTING SWITCH
E25RWLCIM 1981	SHORTING SWITCH
E25RWLCOS 1985	MAGNETO
E25RWLCRD 1984	SHORTING SWITCH
E25RWLCTE 1983	SHORTING SWITCH

E25TECIM 1981	SHORTING SWITCH
E25TECNB 1982	SHORTING SWITCH
E25TECOS 1985	SHORTING SWITCH
E25TECRD 1984	SHORTING SWITCH
E25TECSA 1980	SHORTING SWITCH
E25TECTE 1983	SHORTING SWITCH
E25TELCIM 1981	SHORTING SWITCH
E25TELCNB 1982	SHORTING SWITCH
E25TELCOS 1985	SHORTING SWITCH
E25TELCRD 1984	SHORTING SWITCH
E25TELCSA 1980	SHORTING SWITCH
E25TELCTE 1983	SHORTING SWITCH
E30EOCA 1985	SHORTING SWITCH
E30ECRR 1984	SHORTING SWITCH
E30ELCOA 1985	SHORTING SWITCH
E30ELCRR 1984	SHORTING SWITCH
E30RCOA 1985	SHORTING SWITCH
E30REUD 1997	REMOTE CONTROL ADAPTER KIT
E30RLCOA 1985	SHORTING SWITCH
E30RLEUD 1997	REMOTE CONTROL ADAPTER KIT
E30TECOA 1985	SHORTING SWITCH
E30TELCOA 1985	SHORTING SWITCH
E35ECIG 1981	SHORTING SWITCH
E35ECND 1982	SHORTING SWITCH
E35ECRR 1984	SHORTING SWITCH
E35ECSM 1980	SHORTING SWITCH
E35ECTS 1983	SHORTING SWITCH
E35ELCIG 1981	SHORTING SWITCH
E35ELCND 1982	SHORTING SWITCH
E35ELCRR 1984	SHORTING SWITCH
E35ELCSM 1980	SHORTING SWITCH
E35ELCTS 1983	SHORTING SWITCH
E35RCIG 1981	SHORTING SWITCH
E35RCND 1982	SHORTING SWITCH
E35RCRR 1984	SHORTING SWITCH

E35RCTS 1983	SHORTING SWITCH
E35RLCIG 1981	SHORTING SWITCH
E35RLCND 1982	SHORTING SWITCH
E35RLCRR 1984	SHORTING SWITCH
E35RLCTS 1983	SHORTING SWITCH
E35TCSM 1980	SHORTING SWITCH
E35TELCNB 1982	SHORTING SWITCH
E35TELCRR 1984	SHORTING SWITCH
E35TELCST 1983	SHORTING SWITCH
E35TLESM 1980	SHORTING SWITCH
E40RSLR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RSR 1983	MAGNETO-RS AND RW MODELS ONLY
E40RWADB 1986	IGNITION
E40RWCOM 1985	IGNITION
E40RWCRA 1984	IGNITION
E40RWADB 1986	IGNITION
E40RWCOM 1985	IGNITION
E40RWLCRA 1984	IGNITION
E40RWLCST 1983	MAGNETO-RS AND RW MODELS ONLY
E40RWLST 1983	MAGNETO-RS AND RW MODELS ONLY
E50BECTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50BELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E50TELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E55RLCSA 1980	SHORTING SWITCH
E60ECSR 1980	SHORTING SWITCH
E60ECTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E60ELCSR 1980	SHORTING SWITCH
E60ELCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
E60TLCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
HE25RAEDA 1996	REMOTE CONTROL ADAPTER KIT
HE25RAEUM 1997	REMOTE CONTROL ADAPTER KIT
HJ25RAEDA 1996	REMOTE CONTROL ADAPTER KIT
HJ25RAEUM 1997	REMOTE CONTROL ADAPTER KIT
J10ECSE 1980	SHORTING SWITCH
J10ELCSE 1980	SHORTING SWITCH

J10RCSE 1980	SHORTING SWITCH
J10RLCSE 1980	SHORTING SWITCH
J10SELCSE 1980	SHORTING SWITCH
J15ECSD 1980	SHORTING SWITCH
J15ELCSD 1980	SHORTING SWITCH
J15RCSD 1980	SHORTING SWITCH
J15RLCSD 1980	SHORTING SWITCH
J20CRCOS 1985	SHORTING SWITCH
J20CREUM 1997	REMOTE CONTROL ADAPTER KIT
J20CRLCOS 1985	SHORTING SWITCH
J20CRLEUM 1997	REMOTE CONTROL ADAPTER KIT
J20ECOS 1985	SHORTING SWITCH
J20ELCOS 1985	SHORTING SWITCH
J25ECIB 1981	SHORTING SWITCH
J25ECIM 1981	SHORTING SWITCH
J25ECNE 1982	SHORTING SWITCH
J25ECOC 1985	SHORTING SWITCH
J25ECRS 1984	SHORTING SWITCH
J25ECTD 1983	SHORTING SWITCH
J25ELCIB 1981	SHORTING SWITCH
J25ELCIM 1981	SHORTING SWITCH
J25ELCNE 1982	SHORTING SWITCH
J25ELCOC 1985	SHORTING SWITCH
J25ELCRS 1984	SHORTING SWITCH
J25ELCTD 1983	SHORTING SWITCH
J25JRECA 1998	REMOTE CONTROL ADAPTER KIT
J25JREUR 1997	REMOTE CONTROL ADAPTER KIT
J25RCIM 1981	SHORTING SWITCH
J25RCNB 1982	SHORTING SWITCH
J25RCOS 1985	SHORTING SWITCH
J25RCRD 1984	SHORTING SWITCH
J25RCSA 1980	SHORTING SWITCH
J25RCTE 1983	SHORTING SWITCH
J25RECB 1998	REMOTE CONTROL ADAPTER KIT
J25RELCNB 1982	SHORTING SWITCH

J25REUM 1997	REMOTE CONTROL ADAPTER KIT
J25RLCIM 1981	SHORTING SWITCH
J25RLCNB 1982	SHORTING SWITCH
J25RLCOS 1985	SHORTING SWITCH
J25RLCRD 1984	SHORTING SWITCH
J25RLCSA 1980	SHORTING SWITCH
J25RLCTE 1983	SHORTING SWITCH
J25RLECB 1998	REMOTE CONTROL ADAPTER KIT
J25RLEUM 1997	REMOTE CONTROL ADAPTER KIT
J25RSA 1981	SHORTING SWITCH
J25RSLA 1981	SHORTING SWITCH
J25RSLS 1983	SHORTING SWITCH
J25RSS 1983	SHORTING SWITCH
J25RWCIM 1981	SHORTING SWITCH
J25RWCOS 1985	MAGNETO
J25RWCRD 1984	SHORTING SWITCH
J25RWCTE 1983	SHORTING SWITCH
J25RWLCIM 1981	SHORTING SWITCH
J25RWLCOS 1985	MAGNETO
J25RWLCRD 1984	SHORTING SWITCH
J25RWLCTE 1983	SHORTING SWITCH
J25TECIM 1981	SHORTING SWITCH
J25TECNB 1982	SHORTING SWITCH
J25TECOS 1985	SHORTING SWITCH
J25TECRD 1984	SHORTING SWITCH
J25TECSA 1980	SHORTING SWITCH
J25TECTE 1983	SHORTING SWITCH
J25TELCIM 1981	SHORTING SWITCH
J25TELCOS 1985	SHORTING SWITCH
J25TELCRD 1984	SHORTING SWITCH
J25TELCSA 1980	SHORTING SWITCH
J25TELCTE 1983	SHORTING SWITCH
J30ECOA 1985	SHORTING SWITCH
J30ECRR 1984	SHORTING SWITCH
J30ELCOA 1985	SHORTING SWITCH

J30ELCRR 1984	SHORTING SWITCH
J30RCOA 1985	SHORTING SWITCH
J30REUD 1997	REMOTE CONTROL ADAPTER KIT
J30RLCOA 1985	SHORTING SWITCH
J30RLEUD 1997	REMOTE CONTROL ADAPTER KIT
J30TECOA 1985	SHORTING SWITCH
J30TELCOA 1985	SHORTING SWITCH
J35ECIG 1981	SHORTING SWITCH
J35ECND 1982	SHORTING SWITCH
J35ECRR 1984	SHORTING SWITCH
J35ECSM 1980	SHORTING SWITCH
J35ECTS 1983	SHORTING SWITCH
J35ELCIG 1981	SHORTING SWITCH
J35ELCND 1982	SHORTING SWITCH
J35ELCRR 1984	SHORTING SWITCH
J35ELCSM 1980	SHORTING SWITCH
J35ELCTS 1983	SHORTING SWITCH
J35RCIG 1981	SHORTING SWITCH
J35RCND 1982	SHORTING SWITCH
J35RCRR 1984	SHORTING SWITCH
J35RCSM 1980	SHORTING SWITCH
J35RCTS 1983	SHORTING SWITCH
J35RLCIG 1981	SHORTING SWITCH
J35RLCND 1982	SHORTING SWITCH
J35RLCRR 1984	SHORTING SWITCH
J35RLCSM 1980	SHORTING SWITCH
J35RLCTS 1983	SHORTING SWITCH
J35TELCNB 1982	SHORTING SWITCH
J35TELCRR 1984	SHORTING SWITCH
J35TELCTS 1983	SHORTING SWITCH
J40RSLR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RSR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RWCDB 1986	IGNITION
J40RWCOM 1985	IGNITION
J40RWCRA 1984	IGNITION

J40RWCTR 1983	MAGNETO-RS AND RW MODELS ONLY
J40RWLCDB 1986	IGNITION
J40RWLCOM 1985	IGNITION
J40RWLCRA 1984	IGNITION
J40RWLCTR 1983	MAGNETO-RS AND RW MODELS ONLY
J50BECTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50BELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J50TELCTA 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J55RLCSA 1980	SHORTING SWITCH
J60ECSR 1980	SHORTING SWITCH
J60ECTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J60ELCSR 1980	SHORTING SWITCH
J60ELCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
J60TLCTB 1983	INTAKE MANIFOLD AND PRIMER SYSTEM
REMOTE CONTROL 1995	REMOTE CONTROL ADAPTER KIT - 20, 25, 30 & 35 (2-CYLINDER)
REMOTE CONTROL 1996	REMOTE CONTROL ADAPTER KIT - 20, 25, & 30 (2-CYLINDER)
REMOTE CONTROLS	ADAPTER KIT - 25,30 HP (2-Stroke)
REMOTE CONTROLS 1986	REMOTE CONTROL ADAPTER KIT 20, 25 & 30
REMOTE CONTROLS 1986	REMOTE CONTROL ADAPTER KIT - 9.9, 15
REMOTE CONTROLS 1986	REMOTE CONTROL ADAPTER KIT 65
REMOTE CONTROLS 1987	REMOTE CONTROL ADAPTER KIT 20, 25 & 30
REMOTE CONTROLS 1987	REMOTE CONTROL ADAPTER KIT - 9.9, 15
REMOTE CONTROLS 1987	REMOTE CONTROL ADAPTER KIT 65
REMOTE CONTROLS 1988	REMOTE CONTROL ADAPTER KIT 20, 25 & 30
REMOTE CONTROLS 1988	REMOTE CONTROL ADAPTER KIT - 9.9, 15
REMOTE CONTROLS 1988	REMOTE CONTROL ADAPTER KIT 40 - 55
REMOTE CONTROLS 1988	REMOTE CONTROL ADAPTER KIT 65
REMOTE CONTROLS 1989	REMOTE CONTROL ADAPTER KIT - 45, 55
REMOTE CONTROLS 1989	REMOTE CONTROL ADAPTER KIT 20, 25 & 30
REMOTE CONTROLS 1989	REMOTE CONTROL ADAPTER KIT - 9.9, 15
REMOTE CONTROLS 1989	REMOTE CONTROL ADAPTER KIT 65
REMOTE CONTROLS 1990	REMOTE CONTROL ADAPTER KIT - 45, 55
REMOTE CONTROLS 1990	REMOTE CONTROL ADAPTER KIT - 9.9, 15
REMOTE CONTROLS 1990	REMOTE CONTROL ADAPTER KIT 20,25,30,35 ROPE & TILLER ELEC.
REMOTE CONTROLS 1990	REMOTE CONTROL ADAPTER KIT 65

REMOTE CONTROLS 1991	REMOTE CONTROL ADAPTER KIT - 45, 55
REMOTE CONTROLS 1991	REMOTE CONTROL ADAPTER KIT - 9.9, 15
REMOTE CONTROLS 1991	REMOTE CONTROL ADAPTER KIT 20,25,30,35 ROPE & TILLER ELEC.
REMOTE CONTROLS 1991	REMOTE CONTROL ADAPTER KIT 65
REMOTE CONTROLS 1992	REMOTE CONTROL ADAPTER KIT - 9.9, 15
REMOTE CONTROLS 1992	REMOTE CONTROL ADAPTER KIT 20,25,30,35 ROPE & TILLER ELEC.
REMOTE CONTROLS 1993	REMOTE CONTROL ADAPTER KIT 20 THRU 35
REMOTE CONTROLS 1994	REMOTE CONTROL ADAPTER KIT 20 THRU 35
REMOTE CONTROLS 1997	REMOTE CONTROL ADAPTER KIT - 20, 25, & 30 (2-CYLINDER)
REMOTE CONTROLS 1998	REMOTE CONTROL ADAPTER KIT -- 20, 25, & 30 (2-CYLINDER)
REMOTE CONTROLS 1999	REMOTE CONTROL ADAPTER KIT -- 20, 25, & 30 (2-CYLINDER)
REMOTE CONTROLS 2000	REMOTE CONTROL ADAPTER KIT - 20, 25, & 30 (2-CYLINDER)
SE25RDECA 1998	REMOTE CONTROL ADAPTER KIT
SE25RDEDC 1996	REMOTE CONTROL ADAPTER KIT
SE25RDEUR 1997	REMOTE CONTROL ADAPTER KIT
SJ25RDECA 1998	REMOTE CONTROL ADAPTER KIT
SJ25RDEDC 1996	REMOTE CONTROL ADAPTER KIT
SJ25RDEUR 1997	REMOTE CONTROL ADAPTER KIT