

Where Used: Part Number 0326876

Model Name	Diagram
B25JREUR 1997	IGNITION
BE20SEECB 1998	IGNITION
BE20SEEDA 1996	IGNITION
BE20SEEUM 1997	IGNITION
BE20SELECB 1998	IGNITION
BE20SELEDA 1996	IGNITION
BE20SELEUM 1997	IGNITION
BE20SRECB 1998	IGNITION
BE20SREDA 1996	IGNITION
BE20SREUM 1997	IGNITION
BE20SRLECB 1998	IGNITION
BE20SRLEDA 1996	IGNITION
BE20SRLEUM 1997	IGNITION
BE25BAECM 1998	IGNITION
BE25BAEDR 1996	IGNITION
BE25BAEUA 1997	IGNITION
BE25BALECM 1998	IGNITION
BE25BALEDR 1996	IGNITION
BE25BALEUA 1997	IGNITION
BE25BREDC 1996	IGNITION
BE25BRLEDC 1996	IGNITION
BE25EECE 1998	IGNITION
BE25EEDM 1996	IGNITION
BE25EEUB 1997	IGNITION
BE25ELECE 1998	IGNITION
BE25ELEDM 1996	IGNITION
BE25ELEUB 1997	IGNITION
BE25EREDC 1996	IGNITION
BE25ERLEDC 1996	IGNITION
BE30BAECS 1998	IGNITION
BE30BAEDE 1996	IGNITION
BE30BAEEC 1999	IGNITION
BE30BAEEN 1999	IGNITION

BE30BAEUD 1997	IGNITION
BE30BALECS 1998	IGNITION
BE30BALEDE 1996	IGNITION
BE30BALEUD 1997	IGNITION
BE30BASIA rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
BE30BASSR Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
BE30EECS 1998	IGNITION
BE30EEDE 1996	IGNITION
BE30EEUD 1997	IGNITION
BE30ELECS 1998	IGNITION
BE30ELEDE 1996	IGNITION
BE30ELEUD 1997	IGNITION
BJ20SEECB 1998	IGNITION
BJ20SEEDA 1996	IGNITION
BJ20SEEUM 1997	IGNITION
BJ20SELECB 1998	IGNITION
BJ20SELEDA 1996	IGNITION
BJ20SELEUM 1997	IGNITION
BJ20SRECB 1998	IGNITION
BJ20SREDA 1996	IGNITION
BJ20SREUM 1997	IGNITION
BJ20SRLECB 1998	IGNITION
BJ20SRLEDA 1996	IGNITION
BJ20SRLEUM 1997	IGNITION
BJ25BAECM 1998	IGNITION
BJ25BAEDR 1996	IGNITION
BJ25BAEUA 1997	IGNITION
BJ25BALECM 1998	IGNITION
BJ25BALEDR 1996	IGNITION
BJ25BALEUA 1997	IGNITION
BJ25BREDC 1996	IGNITION
BJ25BRLEDC 1996	IGNITION
BJ25EECE 1998	IGNITION
BJ25EEDM 1996	IGNITION
BJ25EEED 1999	IGNITION

BJ25EEEN 1999	IGNITION
BJ25EEUB 1997	IGNITION
BJ25ELECE 1998	IGNITION
BJ25ELEDM 1996	IGNITION
BJ25ELEED 1999	IGNITION
BJ25ELEEN 1999	IGNITION
BJ25ELEUB 1997	IGNITION
BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ25EREDC 1996	IGNITION
BJ25ERLEDC 1996	IGNITION
BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ25EVSIC elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ30BAECS 1998	IGNITION
BJ30BAEDE 1996	IGNITION
BJ30BAEEC 1999	IGNITION
BJ30BAEEN 1999	IGNITION
BJ30BAEUD 1997	IGNITION
BJ30BALECS 1998	IGNITION
BJ30BALEDE 1996	IGNITION
BJ30BALEUD 1997	IGNITION
BJ30EECS 1998	IGNITION
BJ30EEDE 1996	IGNITION
BJ30EEEC 1999	IGNITION
BJ30EEEN 1999	IGNITION
BJ30EEUD 1997	IGNITION
BJ30ELECS 1998	IGNITION
BJ30ELEDE 1996	IGNITION
BJ30ELEEC 1999	IGNITION
BJ30ELEEN 1999	IGNITION
BJ30ELEUD 1997	IGNITION
BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION

BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ30EVLSIA elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
E20CRCCA 1988	IGNITION
E20CRCDC 1986	IGNITION
E20CRCEM 1989	IGNITION
E20CRCOS 1985	IGNITION
E20CRCUR 1987	IGNITION
E20CREDA 1996	IGNITION
E20CREIE 1991	IGNITION
E20CREND 1992	IGNITION
E20CREOR 1995	IGNITION
E20CRERC 1994	IGNITION
E20CRETS 1993	IGNITION
E20CREUM 1997	IGNITION
E20CRLCCA 1988	IGNITION
E20CRLCDC 1986	IGNITION
E20CRLCEM 1989	IGNITION
E20CRLCOS 1985	IGNITION
E20CRLCUR 1987	IGNITION
E20CRLEDA 1996	IGNITION
E20CRLEIE 1991	IGNITION
E20CRLEND 1992	IGNITION
E20CRLEOR 1995	IGNITION
E20CRLERC 1994	IGNITION
E20CRLETS 1993	IGNITION
E20CRLEUM 1997	IGNITION
E20ECCA 1988	IGNITION
E20ECDC 1986	IGNITION
E20ECEM 1989	IGNITION
E20ECOS 1985	IGNITION
E20ECUR 1987	IGNITION
E20EEIE 1991	IGNITION
E20EEND 1992	IGNITION

E20EEOR 1995	IGNITION
E20EERC 1994	IGNITION
E20EESB 1990	IGNITION
E20EETS 1993	IGNITION
E20ELCCA 1988	IGNITION
E20ELCDC 1986	IGNITION
E20ELCEM 1989	IGNITION
E20ELCOS 1985	IGNITION
E20ELCUR 1987	IGNITION
E20ELEIE 1991	IGNITION
E20ELEND 1992	IGNITION
E20ELEOR 1995	IGNITION
E20ELERC 1994	IGNITION
E20ELESB 1990	IGNITION
E20ELETs 1993	IGNITION
E20TECDC 1986	IGNITION
E25CNE 1982	MAGNETO
E25ECCM 1988	IGNITION
E25ECDR 1986	IGNITION
E25ECEB 1989	IGNITION
E25ECIB 1981	MAGNETO
E25ECIM 1981	MAGNETO
E25ECOC 1985	IGNITION
E25ECRS 1984	IGNITION
E25ECTD 1983	MAGNETO
E25ECUA 1987	IGNITION
E25EECE 1998	IGNITION
E25EEDM 1996	IGNITION
E25EEID 1991	IGNITION
E25EENS 1992	IGNITION
E25EEOA 1995	IGNITION
E25EERR 1994	IGNITION
E25EESE 1990	IGNITION
E25EETC 1993	IGNITION
E25EEUB 1997	IGNITION

E25ELCCM 1988	IGNITION
E25ELCDR 1986	IGNITION
E25ELCEB 1989	IGNITION
E25ELCIB 1981	MAGNETO
E25ELCIM 1981	MAGNETO
E25ELCNE 1982	MAGNETO
E25ELCOC 1985	IGNITION
E25ELCRS 1984	IGNITION
E25ELCTD 1983	MAGNETO
E25ELCUA 1987	IGNITION
E25ELECE 1998	IGNITION
E25ELEDM 1996	IGNITION
E25ELEID 1991	IGNITION
E25ELENS 1992	IGNITION
E25ELEOA 1995	IGNITION
E25ELERR 1994	IGNITION
E25ELESE 1990	IGNITION
E25ELETG 1993	IGNITION
E25ELEUB 1997	IGNITION
E25JRECA 1998	IGNITION
E25RCCA 1988	IGNITION
E25RCDC 1986	IGNITION
E25RCER 1989	IGNITION
E25RCIM 1981	MAGNETO
E25RCNB 1982	MAGNETO
E25RCOS 1985	IGNITION
E25RCRD 1984	IGNITION
E25RCTE 1983	MAGNETO
E25RCUR 1987	IGNITION
E25RECB 1998	IGNITION
E25REDA 1996	IGNITION
E25REIE 1991	IGNITION
E25REND 1992	IGNITION
E25REOR 1995	IGNITION
E25RERC 1994	IGNITION

E25RETS 1993	IGNITION
E25REUM 1997	IGNITION
E25RLCCA 1988	IGNITION
E25RLCDC 1986	IGNITION
E25RLCEM 1989	IGNITION
E25RLCIM 1981	MAGNETO
E25RLCNB 1982	MAGNETO
E25RLCOS 1985	IGNITION
E25RLCRD 1984	IGNITION
E25RLCTE 1983	MAGNETO
E25RLCUR 1987	IGNITION
E25RLECB 1998	IGNITION
E25RLEDA 1996	IGNITION
E25RLEIE 1991	IGNITION
E25RLEND 1992	IGNITION
E25RLEOR 1995	IGNITION
E25RLERC 1994	IGNITION
E25RLETS 1993	IGNITION
E25RLEUM 1997	IGNITION
E25RSA 1981	MAGNETO
E25RSLA 1981	MAGNETO
E25RSLS 1983	MAGNETO
E25RSS 1983	MAGNETO
E25RWCDC 1986	MAGNETO
E25RWCIM 1981	MAGNETO
E25RWCOS 1985	MAGNETO
E25RWCRD 1984	MAGNETO
E25RWCTE 1983	MAGNETO
E25RWCUR 1987	MAGNETO
E25RWEDC 1996	IGNITION - H25FP
E25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWEIM 1991	IGNITION
E25RWENB 1992	IGNITION
E25RWEOS 1995	IGNITION - H25FP
E25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP

E25RWERD 1994	IGNITION - 25RW
E25RWESA 1990	IGNITION
E25RWETE 1993	IGNITION - 25RW
E25RWEUR 1997	IGNITION - H25FP
E25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25RWLCDC 1986	MAGNETO
E25RWLCIM 1981	MAGNETO
E25RWLCOS 1985	MAGNETO
E25RWLCRD 1984	MAGNETO
E25RWLCTE 1983	MAGNETO
E25RWLCUR 1987	MAGNETO
E25RWLEDC 1996	IGNITION - H25FP
E25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWLEIM 1991	IGNITION
E25RWLENB 1992	IGNITION
E25RWLEOS 1995	IGNITION - H25FP
E25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
E25RWLERD 1994	IGNITION - 25RW
E25RWLESA 1990	IGNITION
E25RWLETE 1993	IGNITION - 25RW
E25RWLEUR 1997	IGNITION - H25FP
E25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25TECCA 1988	IGNITION
E25TECDC 1986	IGNITION
E25TECEM 1989	IGNITION
E25TECIM 1981	MAGNETO
E25TECNB 1982	MAGNETO
E25TECOS 1985	IGNITION
E25TECRD 1984	IGNITION
E25TECTE 1983	MAGNETO
E25TECUR 1987	IGNITION
E25TEECB 1998	IGNITION
E25TEEDA 1996	IGNITION
E25TEEIE 1991	IGNITION
E25TEEND 1992	IGNITION

E25TEEOR 1995	IGNITION
E25TEERC 1994	IGNITION
E25TEESB 1990	IGNITION
E25TEETS 1993	IGNITION
E25TEEUM 1997	IGNITION
E25TELCCA 1988	IGNITION
E25TELCDC 1986	IGNITION
E25TELCEM 1989	IGNITION
E25TELCIM 1981	MAGNETO
E25TELCNB 1982	MAGNETO
E25TELCOS 1985	IGNITION
E25TELCRD 1984	IGNITION
E25TELCTE 1983	MAGNETO
E25TELCUR 1987	IGNITION
E25TELECB 1998	IGNITION
E25TELEDA 1996	IGNITION
E25TELEIE 1991	IGNITION
E25TELEND 1992	IGNITION
E25TELEOR 1995	IGNITION
E25TELESB 1990	IGNITION
E25TELETS 1993	IGNITION
E25TELEUM 1997	IGNITION
E25WREEN 1999	IGNITION
E25WREES 1999	IGNITION
E25WRLEEN 1999	IGNITION
E25WRLEES 1999	IGNITION
E25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
E25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
E28ELCDS 1986	MAGNETO
E28ESLCCR 1988	IGNITION
E28ESLCEA 1989	IGNITION
E28ESLCUC 1987	MAGNETO
E28ESLEDR 1996	IGNITION

E28ESLEIB 1991	IGNITION
E28ESLENE 1992	IGNITION
E28ESLEOC 1995	IGNITION
E28ESLERS 1994	IGNITION
E28ESLESM 1990	IGNITION
E28ESLETD 1993	IGNITION
E30ECCE 1988	IGNITION
E30ECDM 1986	IGNITION
E30ECED 1989	IGNITION
E30EOCA 1985	IGNITION
E30ECRR 1984	IGNITION
E30ECUB 1987	IGNITION
E30EECS 1998	IGNITION
E30EEDE 1996	IGNITION
E30EEIC 1991	IGNITION
E30EENR 1992	IGNITION
E30EEOB 1995	IGNITION
E30EERM 1994	IGNITION
E30EESS 1990	IGNITION
E30EETA 1993	IGNITION
E30EEUD 1997	IGNITION
E30ELCCE 1988	IGNITION
E30ELCDM 1986	IGNITION
E30ELCED 1989	IGNITION
E30ELCOA 1985	IGNITION
E30ELCRR 1984	IGNITION
E30ELCUB 1987	IGNITION
E30ELECS 1998	IGNITION
E30ELEDE 1996	IGNITION
E30ELEIC 1991	IGNITION
E30ELENR 1992	IGNITION
E30ELEOB 1995	IGNITION
E30ELERM 1994	IGNITION
E30ELESS 1990	IGNITION
E30ELETA 1993	IGNITION

E30ELEUD 1997	IGNITION
E30RCCE 1988	IGNITION
E30RCDM 1986	IGNITION
E30RCED 1989	IGNITION
E30RCOA 1985	IGNITION
E30RCUB 1987	IGNITION
E30REDE 1996	IGNITION
E30REIC 1991	IGNITION
E30RENr 1992	IGNITION
E30REOB 1995	IGNITION
E30RERM 1994	IGNITION
E30RETA 1993	IGNITION
E30REUD 1997	IGNITION
E30RLCCE 1988	IGNITION
E30RLCDM 1986	IGNITION
E30RLCED 1989	IGNITION
E30RLCOA 1985	IGNITION
E30RLCUB 1987	IGNITION
E30RLEDE 1996	IGNITION
E30RLEIC 1991	IGNITION
E30RLENr 1992	IGNITION
E30RLEOB 1995	IGNITION
E30RLERM 1994	IGNITION
E30RLETA 1993	IGNITION
E30RLEUD 1997	IGNITION
E30TECCE 1988	IGNITION
E30TECDM 1986	IGNITION
E30TECED 1989	IGNITION
E30TECOA 1985	IGNITION
E30TECUB 1987	IGNITION
E30TEECS 1998	IGNITION
E30TEEDE 1996	IGNITION
E30TEEIC 1991	IGNITION
E30TEENr 1992	IGNITION
E30TEEOB 1995	IGNITION

E30TEERM 1994	IGNITION
E30TEESS 1990	IGNITION
E30TEETA 1993	IGNITION
E30TEEUD 1997	IGNITION
E30TELCCE 1988	IGNITION
E30TELCDM 1986	IGNITION
E30TELCED 1989	IGNITION
E30TELCOA 1985	IGNITION
E30TELCUB 1987	IGNITION
E30TELECB 1998	IGNITION
E30TELEDE 1996	IGNITION
E30TELEIC 1991	IGNITION
E30TELENR 1992	IGNITION
E30TELEOB 1995	IGNITION
E30TELERM 1994	IGNITION
E30TELESS 1990	IGNITION
E30TELETA 1993	IGNITION
E30TELEUD 1997	IGNITION
E35ECIG 1981	MAGNETO
E35ECND 1982	MAGNETO
E35ECRR 1984	IGNITION
E35ECTS 1983	MAGNETO
E35ELCIG 1981	MAGNETO
E35ELCND 1982	MAGNETO
E35ELCRR 1984	IGNITION
E35ELCTS 1983	MAGNETO
E35RCCE 1988	IGNITION
E35RCDM 1986	IGNITION
E35RCED 1989	IGNITION
E35RCIG 1981	MAGNETO
E35RCND 1982	MAGNETO
E35RCRR 1984	IGNITION
E35RCTS 1983	MAGNETO
E35RCUB 1987	IGNITION
E35REIC 1991	IGNITION

E35REN 1992	IGNITION
E35RERM 1994	IGNITION
E35RETA 1993	IGNITION
E35RLCCE 1988	IGNITION
E35RLCDM 1986	IGNITION
E35RLCED 1989	IGNITION
E35RLCIG 1981	MAGNETO
E35RLCND 1982	MAGNETO
E35RLCRR 1984	IGNITION
E35RLCTS 1983	MAGNETO
E35RLCUB 1987	IGNITION
E35RLEIC 1991	IGNITION
E35RLENR 1992	IGNITION
E35RLERM 1994	IGNITION
E35RLETA 1993	IGNITION
E35TELCNB 1982	MAGNETO
E35TELCRR 1984	IGNITION
E35TELCCTS 1983	MAGNETO
HE20CREDA 1996	IGNITION
HE20CRLEDA 1996	IGNITION
HE25FPO 1996	IGNITION - H25FP
HE25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HE25FPV 1997	IGNITION - H25FP
HE25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HE25RAEDA 1996	IGNITION
HE25RAEUM 1997	IGNITION
HE25REDA 1996	IGNITION
HE25RLEDA 1996	IGNITION
HE25RSLO 1996	IGNITION - H25FP
HE25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HE25RSLV 1997	IGNITION - H25FP
HE25RSLV 1997	IGNITION - 25RS, 25RW, S25RP
HE25TELEDA 1996	IGNITION
HE30REDE 1996	IGNITION
HE30RLEDE 1996	IGNITION

HJ20CREDA 1996	IGNITION
HJ20CRLEDA 1996	IGNITION
HJ25FPO 1996	IGNITION - H25FP
HJ25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25FPV 1997	IGNITION - H25FP
HJ25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RAEDA 1996	IGNITION
HJ25RAEUM 1997	IGNITION
HJ25RLEDA 1996	IGNITION
HJ25RLSV 1997	IGNITION - H25FP
HJ25RLSV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RSLO 1996	IGNITION - H25FP
HJ25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25TELEDA 1996	IGNITION
HJ30REDE 1996	IGNITION
HJ30RLEDE 1996	IGNITION
J20CRCCA 1988	IGNITION
J20CRCDC 1986	IGNITION
J20CRCEM 1989	IGNITION
J20CRCOS 1985	IGNITION
J20CRCUR 1987	IGNITION
J20CREDA 1996	IGNITION
J20CREIE 1991	IGNITION
J20CREND 1992	IGNITION
J20CREOR 1995	IGNITION
J20CRERC 1994	IGNITION
J20CRETS 1993	IGNITION
J20CREUM 1997	IGNITION
J20CRLCCA 1988	IGNITION
J20CRLCDC 1986	IGNITION
J20CRLCEM 1989	IGNITION
J20CRLCOS 1985	IGNITION
J20CRLCUR 1987	IGNITION
J20CRLEDA 1996	IGNITION
J20CRLEIE 1991	IGNITION

J20CRLEND 1992	IGNITION
J20CRLEOR 1995	IGNITION
J20CRLERC 1994	IGNITION
J20CRLETS 1993	IGNITION
J20CRLEUM 1997	IGNITION
J20ECCA 1988	IGNITION
J20ECDC 1986	IGNITION
J20ECEM 1989	IGNITION
J20ECOS 1985	IGNITION
J20ECUR 1987	IGNITION
J20EEIE 1991	IGNITION
J20EEND 1992	IGNITION
J20EEOR 1995	IGNITION
J20EERC 1994	IGNITION
J20EESB 1990	IGNITION
J20EETS 1993	IGNITION
J20ELCCA 1988	IGNITION
J20ELCDC 1986	IGNITION
J20ELCEM 1989	IGNITION
J20ELCOS 1985	IGNITION
J20ELCUR 1987	IGNITION
J20ELEIE 1991	IGNITION
J20ELEND 1992	IGNITION
J20ELEOR 1995	IGNITION
J20ELERC 1994	IGNITION
J20ELESB 1990	IGNITION
J20ELETS 1993	IGNITION
J20TECDC 1986	IGNITION
J25ECCM 1988	IGNITION
J25ECDR 1986	IGNITION
J25ECEB 1989	IGNITION
J25ECIB 1981	MAGNETO
J25ECIM 1981	MAGNETO
J25ECNE 1982	MAGNETO
J25ECOC 1985	IGNITION

J25ECRS 1984	IGNITION
J25ECTD 1983	MAGNETO
J25ECUA 1987	IGNITION
J25EECE 1998	IGNITION
J25EEDM 1996	IGNITION
J25EEED 1999	IGNITION
J25EEEN 1999	IGNITION
J25EEID 1991	IGNITION
J25EENS 1992	IGNITION
J25EEOA 1995	IGNITION
J25EERR 1994	IGNITION
J25EESE 1990	IGNITION
J25EETC 1993	IGNITION
J25EEUB 1997	IGNITION
J25ELCCM 1988	IGNITION
J25ELCDR 1986	IGNITION
J25ELCEB 1989	IGNITION
J25ELCIB 1981	MAGNETO
J25ELCIM 1981	MAGNETO
J25ELCNE 1982	MAGNETO
J25ELCOC 1985	IGNITION
J25ELCRS 1984	IGNITION
J25ELCTD 1983	MAGNETO
J25ELCUA 1987	IGNITION
J25ELECE 1998	IGNITION
J25ELEDM 1996	IGNITION
J25ELEED 1999	IGNITION
J25ELEEN 1999	IGNITION
J25ELEID 1991	IGNITION
J25ELENS 1992	IGNITION
J25ELEOA 1995	IGNITION
J25ELERR 1994	IGNITION
J25ELESE 1990	IGNITION
J25ELETC 1993	IGNITION
J25ELEUB 1997	IGNITION

J25ELSIC elec start, remote, 20 in shaft 2001	IGNITION
J25ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002	IGNITION
J25ELSOB	IGNITION
J25ELSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSRM	IGNITION
J25ELSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSSS Elec. Start, 20 IN. shaft 2000	IGNITION
J25ELSTA	IGNITION
J25ELSTA - FR	22-5_SYSTÈME D'ALLUMAGE
J25ESIC elec start, remote, 15 in shaft 2001	IGNITION
J25ESSS Elec. Start, 15 IN. shaft 2000	IGNITION
J25EVSIC elec start, remote, 120 in shaft, wht 2001	IGNITION
J25EVSIC elec start, remote, 15 in shaft, wht 2001	IGNITION
J25JRECA 1998	IGNITION
J25JREEM 1999	IGNITION
J25JREEN 1999	IGNITION
J25JREUR 1997	IGNITION
J25JRSIE jet drive, rope start, tiller, 15 in shaft 2001	IGNITION
J25JRSSB Jet Drive,Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J25RCCA 1988	IGNITION
J25RCDC 1986	IGNITION
J25RCEM 1989	IGNITION
J25RCIM 1981	MAGNETO
J25RCNB 1982	MAGNETO
J25RCOS 1985	IGNITION
J25RCRD 1984	IGNITION
J25RCTE 1983	MAGNETO
J25RCUR 1987	IGNITION
J25RECB 1998	IGNITION
J25REDA 1996	IGNITION
J25REEB 1999	IGNITION
J25REEN 1999	IGNITION
J25REIE 1991	IGNITION
J25RELCNB 1982	MAGNETO

J25REND 1992	IGNITION
J25REOR 1995	IGNITION
J25RERC 1994	IGNITION
J25RETS 1993	IGNITION
J25REUM 1997	IGNITION
J25RLCCA 1988	IGNITION
J25RLCDC 1986	IGNITION
J25RLCEM 1989	IGNITION
J25RLCIM 1981	MAGNETO
J25RLCNB 1982	MAGNETO
J25RLCOS 1985	IGNITION
J25RLCRD 1984	IGNITION
J25RLCTE 1983	MAGNETO
J25RLCUR 1987	IGNITION
J25RLECB 1998	IGNITION
J25RLEDA 1996	IGNITION
J25RLEEB 1999	IGNITION
J25RLEEN 1999	IGNITION
J25RLEIE 1991	IGNITION
J25RLEND 1992	IGNITION
J25RLEOR 1995	IGNITION
J25RLERC 1994	IGNITION
J25RLETS 1993	IGNITION
J25RLEUM 1997	IGNITION
J25RLSID rope start, tiller, 20 in shaft 2001	IGNITION
J25RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J25RLSOA	IGNITION
J25RLSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSRR	IGNITION
J25RLSRR - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSSE Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J25RLSTC	IGNITION
J25RLSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSA 1981	MAGNETO

J25RSID rope start, tiller, 15 in shaft 2001	IGNITION
J25RSLA 1981	MAGNETO
J25RSLS 1983	MAGNETO
J25RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSNF Rope start, White, Tiller,15 in. shaft, A/C Light 2002	IGNITION
J25RSOA	IGNITION
J25RSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSRR	IGNITION
J25RSRR - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSS 1983	MAGNETO
J25RSSE Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J25RSTC	IGNITION
J25RSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RTSOS	IGNITION
J25RTSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J25RVLSID rope start, tiller, 20 in shaft, wht 2001	IGNITION
J25RVSID rope start, tiller, 15 in shaft, wht 2001	IGNITION
J25RWCDC 1986	MAGNETO
J25RWCIM 1981	MAGNETO
J25RWCOS 1985	MAGNETO
J25RWCRD 1984	MAGNETO
J25RWCTE 1983	MAGNETO
J25RWCUR 1987	MAGNETO
J25RWEDC 1996	IGNITION - H25FP
J25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWEIM 1991	IGNITION
J25RWENB 1992	IGNITION
J25RWEOS 1995	IGNITION - H25FP
J25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWERD 1994	IGNITION - 25RW
J25RWESA 1990	IGNITION
J25RWETE 1993	IGNITION - 25RW
J25RWEUR 1997	IGNITION - H25FP
J25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25RWLCDC 1986	MAGNETO

J25RWLCIM 1981	MAGNETO
J25RWLCOS 1985	MAGNETO
J25RWLCRD 1984	MAGNETO
J25RWLCTE 1983	MAGNETO
J25RWLCUR 1987	MAGNETO
J25RWLEDC 1996	IGNITION - H25FP
J25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWLEIM 1991	IGNITION
J25RWLENB 1992	IGNITION
J25RWLEOS 1995	IGNITION - H25FP
J25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWLERD 1994	IGNITION - 25RW
J25RWLESA 1990	IGNITION
J25RWLETE 1993	IGNITION - 25RW
J25RWLEUR 1997	IGNITION - H25FP
J25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25TECCA 1988	IGNITION
J25TECDC 1986	IGNITION
J25TECEM 1989	IGNITION
J25TECIM 1981	MAGNETO
J25TECNB 1982	MAGNETO
J25TECOS 1985	IGNITION
J25TECRD 1984	IGNITION
J25TECTE 1983	MAGNETO
J25TECUR 1987	IGNITION
J25TEECB 1998	IGNITION
J25TEEDA 1996	IGNITION
J25TEEIE 1991	IGNITION
J25TEEND 1992	IGNITION
J25TEEOR 1995	IGNITION
J25TEERC 1994	IGNITION
J25TEESB 1990	IGNITION
J25TEETS 1993	IGNITION
J25TEEUM 1997	IGNITION
J25TELCCA 1988	IGNITION

J25TELCDC 1986	IGNITION
J25TELCEM 1989	IGNITION
J25TELCIM 1981	MAGNETO
J25TELCOS 1985	IGNITION
J25TELCRD 1984	IGNITION
J25TELCTE 1983	MAGNETO
J25TELCUR 1987	IGNITION
J25TELECB 1998	IGNITION
J25TELEDA 1996	IGNITION
J25TELEIE 1991	IGNITION
J25TELEND 1992	IGNITION
J25TELEOR 1995	IGNITION
J25TELERC	IGNITION
J25TELESB 1990	IGNITION
J25TELETS 1993	IGNITION
J25TELEUM 1997	IGNITION
J25WREEN 1999	IGNITION
J25WREES 1999	IGNITION
J25WRLEEN 1999	IGNITION
J25WRLEES 1999	IGNITION
J25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J25WRLSOB	IGNITION
J25WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSRM	IGNITION
J25WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
J25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J25WRSOB	IGNITION
J25WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSRM	IGNITION
J25WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
J28ELCDS 1986	MAGNETO
J28ESLCCR 1988	IGNITION
J28ESLCEA 1989	IGNITION

J28ESLCUC 1987	MAGNETO
J28ESLEDR 1996	IGNITION
J28ESLEIB 1991	IGNITION
J28ESLENE 1992	IGNITION
J28ESLEOC 1995	IGNITION
J28ESLERS 1994	IGNITION
J28ESLESM 1990	IGNITION
J28ESLETD 1993	IGNITION
J30ECCE 1988	IGNITION
J30ECDM 1986	IGNITION
J30ECED 1989	IGNITION
J30EOCA 1985	IGNITION
J30ECRR 1984	IGNITION
J30ECUB 1987	IGNITION
J30EECS 1998	IGNITION
J30EEDE 1996	IGNITION
J30EEEC 1999	IGNITION
J30EEEN 1999	IGNITION
J30EEIC 1991	IGNITION
J30EENR 1992	IGNITION
J30EEOB 1995	IGNITION
J30EERM 1994	IGNITION
J30EESS 1990	IGNITION
J30EETA 1993	IGNITION
J30EEUD 1997	IGNITION
J30ELCCE 1988	IGNITION
J30ELCDM 1986	IGNITION
J30ELCED 1989	IGNITION
J30ELCOA 1985	IGNITION
J30ELCRR 1984	IGNITION
J30ELCUB 1987	IGNITION
J30ELECS 1998	IGNITION
J30ELEDE 1996	IGNITION
J30ELEEC 1999	IGNITION
J30ELEEN 1999	IGNITION

J30ELEIC 1991	IGNITION
J30ELENR 1992	IGNITION
J30ELEOB 1995	IGNITION
J30ELERM 1994	IGNITION
J30ELESS 1990	IGNITION
J30ELETA 1993	IGNITION
J30ELEUD 1997	IGNITION
J30ELSIA elec start, remote, 20 in shaft 2001	IGNITION
J30ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002	IGNITION
J30ELSOD	IGNITION
J30ELSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSRE	IGNITION
J30ELSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSSR Elec. Start, 20 IN. shaft 2000	IGNITION
J30ELSTB	IGNITION
J30ELSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30ESIA elec start, remote, 15 in shaft 2001	IGNITION
J30ESSR Elec. Start, 15 IN. shaft 2000	IGNITION
J30EVLSIA elec start, remote, 20 in shaft, wht 2001	IGNITION
J30MLSRC	IGNITION
J30MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J30MLSTS	IGNITION
J30MLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J30RCCE 1988	IGNITION
J30RCDM 1986	IGNITION
J30RCED 1989	IGNITION
J30RCOA 1985	IGNITION
J30RCUB 1987	IGNITION
J30REDE 1996	IGNITION
J30REEC 1999	IGNITION
J30REEN 1999	IGNITION
J30REIC 1991	IGNITION
J30RENr 1992	IGNITION
J30REOB 1995	IGNITION

J30RERM 1994	IGNITION
J30RETA 1993	IGNITION
J30REUD 1997	IGNITION
J30RLCCE 1988	IGNITION
J30RLCDM 1986	IGNITION
J30RLCED 1989	IGNITION
J30RLCOA 1985	IGNITION
J30RLCUB 1987	IGNITION
J30RLEDE 1996	IGNITION
J30RLEEC 1999	IGNITION
J30RLEEN 1999	IGNITION
J30RLEIC 1991	IGNITION
J30RLENR 1992	IGNITION
J30RLEOB 1995	IGNITION
J30RLERM 1994	IGNITION
J30RLETA 1993	IGNITION
J30RLEUD 1997	IGNITION
J30RLSIA rope start, tiller, 20 in shaft 2001	IGNITION
J30RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J30RLSOD	IGNITION
J30RLSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSRE	IGNITION
J30RLSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSSR Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J30RLSTB	IGNITION
J30RLSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSIA rope start, tiller, 15 in shaft 2001	IGNITION
J30RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSNF Rope start, White, Tiller, 15 in. shaft, A/C Light 2002	IGNITION
J30RSOD	IGNITION
J30RSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSRE	IGNITION
J30RSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSSR Rope Start, Tiller, 15 IN. shaft 2000	IGNITION

J30RSTB	IGNITION
J30RSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30RVLSIA rope start, tiller, 20 in shaft, wht 2001	IGNITION
J30RVSIA rope start, tiller, 15 in shaft, wht 2001	IGNITION
J30TECCE 1988	IGNITION
J30TECDM 1986	IGNITION
J30TECED 1989	IGNITION
J30TECOA 1985	IGNITION
J30TECUB 1987	IGNITION
J30TEECS 1998	IGNITION
J30TEEDE 1996	IGNITION
J30TEEIC 1991	IGNITION
J30TEENR 1992	IGNITION
J30TEEOB 1995	IGNITION
J30TEERM 1994	IGNITION
J30TEESS 1990	IGNITION
J30TEETA 1993	IGNITION
J30TEEUD 1997	IGNITION
J30TELCCE 1988	IGNITION
J30TELCDM 1986	IGNITION
J30TELCED 1989	IGNITION
J30TELCOA 1985	IGNITION
J30TELCUB 1987	IGNITION
J30TELECS 1998	IGNITION
J30TELEDE 1996	IGNITION
J30TELEIC 1991	IGNITION
J30TELENR 1992	IGNITION
J30TELEOB 1995	IGNITION
J30TELERM 1994	IGNITION
J30TELESS 1990	IGNITION
J30TELETA 1993	IGNITION
J30TELEUD 1997	IGNITION
J35ECIG 1981	MAGNETO
J35ECND 1982	MAGNETO
J35ECRR 1984	IGNITION

J35ECTS 1983	MAGNETO
J35ELCIG 1981	MAGNETO
J35ELCND 1982	MAGNETO
J35ELCRR 1984	IGNITION
J35ELCTS 1983	MAGNETO
J35RCCE 1988	IGNITION
J35RCDM 1986	IGNITION
J35RCED 1989	IGNITION
J35RCIG 1981	MAGNETO
J35RCND 1982	MAGNETO
J35RCRR 1984	IGNITION
J35RCTS 1983	MAGNETO
J35RCUB 1987	IGNITION
J35REIC 1991	IGNITION
J35RENR 1992	IGNITION
J35RERM 1994	IGNITION
J35RETA 1993	IGNITION
J35RLCCE 1988	IGNITION
J35RLCDM 1986	IGNITION
J35RLCED 1989	IGNITION
J35RLCIG 1981	MAGNETO
J35RLCND 1982	MAGNETO
J35RLCRR 1984	IGNITION
J35RLCTS 1983	MAGNETO
J35RLCUB 1987	IGNITION
J35RLEIC 1991	IGNITION
J35RLENR 1992	IGNITION
J35RLERM 1994	IGNITION
J35RLETA 1993	IGNITION
J35TELCNB 1982	MAGNETO
J35TELCRR 1984	IGNITION
J35TELCTS 1983	MAGNETO
SE25RDECA 1998	IGNITION
SE25RDEDC 1996	IGNITION
SE25RDEEM 1999	IGNITION

SE25RDEEN 1999	IGNITION
SE25RDEUR 1997	IGNITION
SE25RDSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SE25RDSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SE25RPLV 1997	IGNITION - H25FP
SE25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SE25RPV 1997	IGNITION - H25FP
SE25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SE35REDE 1996	IGNITION
SE35RLEDE 1996	IGNITION
SJ25RDECA 1998	IGNITION
SJ25RDEDC 1996	IGNITION
SJ25RDEEM 1999	IGNITION
SJ25RDEEMN 1999	IGNITION
SJ25RDEUR 1997	IGNITION
SJ25REDA 1996	IGNITION
SJ25RLEDA 1996	IGNITION
SJ25RPLV 1997	IGNITION - H25FP
SJ25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RPV 1997	IGNITION - H25FP
SJ25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RTEEM 1999	IGNITION
SJ25RTSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SJ25RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SJ25TEEDA 1996	IGNITION
SJ25TEEUM 1997	IGNITION
SJ30EEDE 1996	IGNITION
SJ30REDE 1996	IGNITION
SJ30RLEDE 1996	IGNITION
SJ30TEEUD 1997	IGNITION
SJ35REDE 1996	IGNITION
SJ35RLEDE 1996	IGNITION
TE20CRCEM 1989	IGNITION
TE20CREND 1992	IGNITION
TE20CRETS 1993	IGNITION

TE20CRLCEM 1989	IGNITION
TE20CRLEIE 1991	IGNITION
TE20CRLEND 1992	IGNITION
TE20CRLESF 1989	IGNITION
TE20CRLETS 1993	IGNITION
TE25ELCEB 1989	IGNITION
TE25ELEID 1991	IGNITION
TE25ELENS 1992	IGNITION
TE25ELESE 1990	IGNITION
TE25ELESF 1989	IGNITION
TE25ELETC 1993	IGNITION
TE30ELCED 1989	IGNITION
TE30ELESF 1989	IGNITION
TE30ELESS 1990	IGNITION
TJ20CRCEM 1989	IGNITION
TJ20CREND 1992	IGNITION
TJ20CRETS 1993	IGNITION
TJ20CRLCEM 1989	IGNITION
TJ20CRLEIE 1991	IGNITION
TJ20CRLEND 1992	IGNITION
TJ20CRLESF 1989	IGNITION
TJ20CRLETS 1993	IGNITION
TJ25ELCEB 1989	IGNITION
TJ25ELEID 1991	IGNITION
TJ25ELENS 1992	IGNITION
TJ25ELESE 1990	IGNITION
TJ25ELESF 1989	IGNITION
TJ25ELETC 1993	IGNITION
TJ30ELCED 1989	IGNITION
TJ30ELESF 1989	IGNITION
TJ30ELESS 1990	IGNITION
VE25ELEID 1991	IGNITION
VE25ELENS 1992	IGNITION
VE25ELESE 1990	IGNITION
VE25ELETC 1993	IGNITION

VE25REIE 1991	IGNITION
VE28ESLCCR 1988	IGNITION
VE28ESLCEA 1989	IGNITION
VE28ESLESM 1990	IGNITION
VE30EEIC 1991	IGNITION
VE30EENR 1992	IGNITION
VE30EESS 1990	IGNITION
VE30EETA 1993	IGNITION
VE30ELEIC 1991	IGNITION
VE30ELENR 1992	IGNITION
VE30ELESS 1990	IGNITION
VE30ELETA 1993	IGNITION
VJ25ELEID 1991	IGNITION
VJ25ELENS 1992	IGNITION
VJ25ELESE 1990	IGNITION
VJ25ELETC 1993	IGNITION
VJ25REIE 1991	IGNITION
VJ28ESLCCR 1988	IGNITION
VJ28ESLCEA 1989	IGNITION
VJ28ESLESM 1990	IGNITION
VJ30EEIC 1991	IGNITION
VJ30EENR 1992	IGNITION
VJ30EESS 1990	IGNITION
VJ30EETA 1993	IGNITION
VJ30ELEIC 1991	IGNITION
VJ30ELENR 1992	IGNITION
VJ30ELESS 1990	IGNITION
VJ30ELETA 1993	IGNITION