

Where Used: Part Number 0327729

Model Name	Diagram
D25RWA 1988	FUEL PUMP
D25RWLA 1988	FUEL PUMP
E10ECCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10ECES 1989	FUEL PUMP - ELECTRIC START MODELS
E10ECUE 1987	FUEL PUMP - LATE PRODUCTION
E10EESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10ELCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10ELCUE 1987	FUEL PUMP - LATE PRODUCTION
E10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10RCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10RCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10RCUE 1987	FUEL PUMP - LATE PRODUCTION
E10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10RESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10RLCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10RLCUE 1987	FUEL PUMP - LATE PRODUCTION
E10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS
E10SELCCD 1988	FUEL PUMP - ELECTRIC START MODELS
E10SELCES 1989	FUEL PUMP - ELECTRIC START MODELS
E10SELCUE 1987	FUEL PUMP - LATE PRODUCTION
E10SELESC 1990	FUEL PUMP - ELECTRIC START MODELS
E15ECCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15ECEC 1989	FUEL PUMP - ELECTRIC START MODELS
E15ECUD 1987	FUEL PUMP - LATE PRODUCTION
E15EESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15ELCCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15ELCEC 1989	FUEL PUMP - ELECTRIC START MODELS
E15ELCUD 1987	FUEL PUMP - LATE PRODUCTION
E15ELESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15RCCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15RCEC 1989	FUEL PUMP - ELECTRIC START MODELS

E15RCUD 1987	FUEL PUMP - LATE PRODUCTION
E15RELESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15RESR 1990	FUEL PUMP - ELECTRIC START MODELS
E15RLCCS 1988	FUEL PUMP - ELECTRIC START MODELS
E15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
E15RLCUD 1987	FUEL PUMP - LATE PRODUCTION
E15RLESR 1990	FUEL PUMP - ELECTRIC START MODELS
E185ESXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E185ESXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CXETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CZETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200CZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200STLETC 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200STLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TXETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TZETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E200TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E20CRCCA 1988	FUEL PUMP
E20CRCDC 1986	FUEL PUMP
E20CRCEM 1989	FUEL PUMP
E20CRCOS 1985	FUEL PUMP
E20CRCUR 1987	FUEL PUMP
E20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
E20CRLCCA 1988	FUEL PUMP
E20CRLCDC 1986	FUEL PUMP

E20CRLCEM 1989	FUEL PUMP
E20CRLCOS 1985	FUEL PUMP
E20CRLCUR 1987	FUEL PUMP
E20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
E20ECCA 1988	FUEL PUMP
E20ECDC 1986	FUEL PUMP
E20ECEM 1989	FUEL PUMP
E20ECOS 1985	FUEL PUMP
E20ECUR 1987	FUEL PUMP
E20EESB 1990	FUEL PUMP - EARLY PRODUCTION
E20ELCCA 1988	FUEL PUMP
E20ELCDC 1986	FUEL PUMP
E20ELCEM 1989	FUEL PUMP
E20ELCOS 1985	FUEL PUMP
E20ELCUR 1987	FUEL PUMP
E20ELESB 1990	FUEL PUMP - EARLY PRODUCTION
E20TECDC 1986	FUEL PUMP
E225CXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225CXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225CXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225CXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225CZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225CZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225CZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225CZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225PZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS

E225STLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E225TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
E25CNE 1982	FUEL PUMP
E25ECCM 1988	FUEL PUMP
E25ECDR 1986	FUEL PUMP
E25ECEB 1989	FUEL PUMP
E25ECOC 1985	FUEL PUMP
E25ECRS 1984	FUEL PUMP
E25ECTD 1983	FUEL PUMP
E25ECUA 1987	FUEL PUMP
E25EESE 1990	FUEL PUMP - EARLY PRODUCTION
E25ELCCM 1988	FUEL PUMP
E25ELCDR 1986	FUEL PUMP
E25ELCEB 1989	FUEL PUMP
E25ELCNE 1982	FUEL PUMP
E25ELCOC 1985	FUEL PUMP
E25ELCRS 1984	FUEL PUMP
E25ELCTD 1983	FUEL PUMP
E25ELCUA 1987	FUEL PUMP
E25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
E25RCCA 1988	FUEL PUMP
E25RCDC 1986	FUEL PUMP
E25RCEM 1989	FUEL PUMP
E25RCNB 1982	FUEL PUMP
E25RCOS 1985	FUEL PUMP
E25RCRD 1984	FUEL PUMP

E25RCTE 1983	FUEL PUMP
E25RCUR 1987	FUEL PUMP
E25RESB 1990	FUEL PUMP - EARLY PRODUCTION
E25RLCCA 1988	FUEL PUMP
E25RLCDC 1986	FUEL PUMP
E25RLCEM 1989	FUEL PUMP
E25RLCNB 1982	FUEL PUMP
E25RLCOS 1985	FUEL PUMP
E25RLCRD 1984	FUEL PUMP
E25RLCTE 1983	FUEL PUMP
E25RLCUR 1987	FUEL PUMP
E25RLESB 1990	FUEL PUMP - EARLY PRODUCTION
E25RSLS 1983	FUEL PUMP
E25RSS 1983	FUEL PUMP
E25RWCDC 1986	FUEL PUMP
E25RWCOS 1985	FUEL PUMP
E25RWCRD 1984	FUEL PUMP
E25RWCTE 1983	FUEL PUMP
E25RWCUR 1987	FUEL PUMP
E25RWESA 1990	FUEL PUMP - EARLY PRODUCTION
E25RWK 1989	FUEL PUMP
E25RWLCDC 1986	FUEL PUMP
E25RWLCOS 1985	FUEL PUMP
E25RWLCRD 1984	FUEL PUMP
E25RWLCTE 1983	FUEL PUMP
E25RWLCUR 1987	FUEL PUMP
E25RWLESA 1990	FUEL PUMP - EARLY PRODUCTION
E25RWLK 1989	FUEL PUMP
E25TECCA 1988	FUEL PUMP
E25TECDC 1986	FUEL PUMP
E25TECEM 1989	FUEL PUMP
E25TECNB 1982	FUEL PUMP
E25TECOS 1985	FUEL PUMP
E25TECRD 1984	FUEL PUMP
E25TECTE 1983	FUEL PUMP

E25TECUR 1987	FUEL PUMP
E25TEESB 1990	FUEL PUMP - EARLY PRODUCTION
E25TELCCA 1988	FUEL PUMP
E25TELCDC 1986	FUEL PUMP
E25TELCEM 1989	FUEL PUMP
E25TELCNB 1982	FUEL PUMP
E25TEL COS 1985	FUEL PUMP
E25TEL RD 1984	FUEL PUMP
E25TEL CT E 1983	FUEL PUMP
E25TEL CUR 1987	FUEL PUMP
E25TELESB 1990	FUEL PUMP - EARLY PRODUCTION
E28ELCDS 1986	FUEL PUMP
E28ESLCCR 1988	FUEL PUMP
E28ESLCEA 1989	FUEL PUMP
E28ESLCUC 1987	FUEL PUMP
E28ESLESM 1990	FUEL PUMP - EARLY PRODUCTION
E30ECCE 1988	FUEL PUMP
E30ECDM 1986	FUEL PUMP
E30ECED 1989	FUEL PUMP
E30ECOA 1985	FUEL PUMP
E30ECRR 1984	FUEL PUMP
E30ECUB 1987	FUEL PUMP
E30EESS 1990	FUEL PUMP - EARLY PRODUCTION
E30ELCCE 1988	FUEL PUMP
E30ELCDM 1986	FUEL PUMP
E30ELCED 1989	FUEL PUMP
E30ELCOA 1985	FUEL PUMP
E30ELCRR 1984	FUEL PUMP
E30ELCUB 1987	FUEL PUMP
E30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
E30RCCE 1988	FUEL PUMP
E30RCDM 1986	FUEL PUMP
E30RCED 1989	FUEL PUMP
E30RCOA 1985	FUEL PUMP
E30RCUB 1987	FUEL PUMP

E30RESS 1990	FUEL PUMP - EARLY PRODUCTION
E30RLCCE 1988	FUEL PUMP
E30RLCDM 1986	FUEL PUMP
E30RLCED 1989	FUEL PUMP
E30RLCOA 1985	FUEL PUMP
E30RLCUB 1987	FUEL PUMP
E30RLESS 1990	FUEL PUMP - EARLY PRODUCTION
E30TECCE 1988	FUEL PUMP
E30TECDM 1986	FUEL PUMP
E30TECED 1989	FUEL PUMP
E30TECOA 1985	FUEL PUMP
E30TECUB 1987	FUEL PUMP
E30TEESS 1990	FUEL PUMP - EARLY PRODUCTION
E30TELCEE 1988	FUEL PUMP
E30TELCDM 1986	FUEL PUMP
E30TELCED 1989	FUEL PUMP
E30TELCOA 1985	FUEL PUMP
E30TELCTC 1987	FUEL PUMP
E30TELESS 1990	FUEL PUMP - EARLY PRODUCTION
E35ECND 1982	FUEL PUMP
E35ECRR 1984	FUEL PUMP
E35ECTS 1983	FUEL PUMP
E35ELCND 1982	FUEL PUMP
E35ELCRR 1984	FUEL PUMP
E35ELCTS 1983	FUEL PUMP
E35RCCE 1988	FUEL PUMP
E35RCDM 1986	FUEL PUMP
E35RCED 1989	FUEL PUMP
E35RCND 1982	FUEL PUMP
E35RCRR 1984	FUEL PUMP
E35RCTS 1983	FUEL PUMP
E35RCUB 1987	FUEL PUMP
E35RESS 1990	FUEL PUMP - EARLY PRODUCTION
E35RLCCE 1988	FUEL PUMP
E35RLCDM 1986	FUEL PUMP

E35RLCED 1989	FUEL PUMP
E35RLCND 1982	FUEL PUMP
E35RLCRR 1984	FUEL PUMP
E35RLCTS 1983	FUEL PUMP
E35RLCUB 1987	FUEL PUMP
E35RLESS 1990	FUEL PUMP - EARLY PRODUCTION
E35TELCNB 1982	FUEL PUMP
E35TELCCR 1984	FUEL PUMP
E35TELCTS 1983	FUEL PUMP
E60ELCCR 1988	VRO2 PUMP
E60ELCDS 1986	VRO PUMP
E60ELCEA 1989	VRO2 PUMP
E60ELCUC 1987	VRO PUMP
E60ELES M 1990	VRO2 PUMP
E60TLCCR 1988	VRO2 PUMP
E60TLCDS 1986	VRO PUMP
E60TLCEA 1989	VRO2 PUMP
E60TLCUC 1987	VRO PUMP
E60TLES M 1990	VRO2 PUMP
E60TTLCCR 1988	VRO2 PUMP
E60TTLCEA 1989	VRO2 PUMP
E60TTLES M 1990	VRO2 PUMP
E65WMLCDR 1986	VRO PUMP - WMLC MODELS ONLY
E65WMLCUA 1987	VRO PUMP - WMLC MODELS ONLY
E65WMLES M 1990	VRO2 PUMP
E65WMLZ 1989	VRO2 PUMP
E6RCUD 1987	FUEL PUMP - LATE PRODUCTION
E6RLCUD 1987	FUEL PUMP - LATE PRODUCTION
E6SLCUD 1987	FUEL PUMP - LATE PRODUCTION
E70ELCCA 1988	VRO2 PUMP
E70ELCDC 1986	VRO PUMP
E70ELCEM 1989	VRO2 PUMP
E70ELCUR 1987	VRO PUMP
E70ELES B 1990	VRO2 PUMP
E70TLCCA 1988	VRO2 PUMP

E70TLCDC 1986	VRO PUMP
E70TLCM 1989	VRO2 PUMP
E70TLCUR 1987	VRO PUMP
E70TLESB 1990	VRO2 PUMP
E75ECCA 1988	VRO2 PUMP
E75ECDC 1986	VRO PUMP
E75ECUR 1987	VRO PUMP
E8RCUD 1987	FUEL PUMP - LATE PRODUCTION
E8RLCUD 1987	FUEL PUMP - LATE PRODUCTION
E8SRLCUD 1987	FUEL PUMP - LATE PRODUCTION
FUEL SYSTEMS 1988	ACCUMIX FUEL PUMP KIT - 5, 6, 6.5 & 8
FUEL SYSTEMS 1988	ACCUMIX FUEL PUMP KIT 9.9,15 R AC LIGHT,TE,REM. ELEC. & SAIL
FUEL SYSTEMS 1988	ACCUMIX FUEL PUMP KIT 9.9 15 ROPE START (W/O AC LIGHT)
FUEL SYSTEMS 1989	ACCUMIX FUEL PUMP KIT - 5, 6, 6.5 & 8
FUEL SYSTEMS 1989	ACCUMIX FUEL PUMP KIT 9.9,15 R AC LIGHT,TE,REM. ELEC. & SAIL
FUEL SYSTEMS 1989	ACCUMIX FUEL PUMP KIT 9.9 15 ROPE START (W/O AC LIGHT)
FUEL SYSTEMS 1990	ACCUMIX FUEL PUMP KIT - 5, 6, 6.5 & 8
FUEL SYSTEMS 1990	ACCUMIX FUEL PUMP KIT - 9.9, 15 ROPE START MODELS
J10ECCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10ECES 1989	FUEL PUMP - ELECTRIC START MODELS
J10ECUE 1987	FUEL PUMP - LATE PRODUCTION
J10EEESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10ELCCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10ELCUE 1987	FUEL PUMP - LATE PRODUCTION
J10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10RCCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10RCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10RCUE 1987	FUEL PUMP - LATE PRODUCTION
J10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10RESC 1990	FUEL PUMP - ELECTRIC START MODELS
J10RLCCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10RLCUE 1987	FUEL PUMP - LATE PRODUCTION
J10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS

J10SELCCD 1988	FUEL PUMP - ELECTRIC START MODELS
J10SELCES 1989	FUEL PUMP - ELECTRIC START MODELS
J10SELCUE 1987	FUEL PUMP - LATE PRODUCTION
J10SELESC 1990	FUEL PUMP - ELECTRIC START MODELS
J15ECCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15ECEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15ECUD 1987	FUEL PUMP - LATE PRODUCTION
J15EEESR 1990	FUEL PUMP - ELECTRIC START MODELS
J15ELCCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15ELCEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15ELCUD 1987	FUEL PUMP - LATE PRODUCTION
J15ELESR 1990	FUEL PUMP - ELECTRIC START MODELS
J15RCCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15RCEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15RCUD 1987	FUEL PUMP - LATE PRODUCTION
J15RELESR 1990	FUEL PUMP - ELECTRIC START MODELS
J15RESR 1990	FUEL PUMP - ELECTRIC START MODELS
J15RLCCS 1988	FUEL PUMP - ELECTRIC START MODELS
J15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
J15RLCUD 1987	FUEL PUMP - LATE PRODUCTION
J15RLESR 1990	FUEL PUMP - ELECTRIC START MODELS
J185ESXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J185ESXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CXETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CZETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200CZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200STLETC 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200STLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200TXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200TXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS

J200TXETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200TZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200TZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200TZETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J200TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J20CRCCA 1988	FUEL PUMP
J20CRCDC 1986	FUEL PUMP
J20CRCEM 1989	FUEL PUMP
J20CRCOS 1985	FUEL PUMP
J20CRCUR 1987	FUEL PUMP
J20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
J20CRLCCA 1988	FUEL PUMP
J20CRLCDC 1986	FUEL PUMP
J20CRLCEM 1989	FUEL PUMP
J20CRLCOS 1985	FUEL PUMP
J20CRLCUR 1987	FUEL PUMP
J20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
J20ECCA 1988	FUEL PUMP
J20ECDC 1986	FUEL PUMP
J20ECEM 1989	FUEL PUMP
J20ECOS 1985	FUEL PUMP
J20ECUR 1987	FUEL PUMP
J20EESB 1990	FUEL PUMP - EARLY PRODUCTION
J20ELCCA 1988	FUEL PUMP
J20ELCDC 1986	FUEL PUMP
J20ELCEM 1989	FUEL PUMP
J20ELCOS 1985	FUEL PUMP
J20ELCUR 1987	FUEL PUMP
J20ELESB 1990	FUEL PUMP - EARLY PRODUCTION
J20TECDC 1986	FUEL PUMP
J225CXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225CXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225CXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225CXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS

J225CZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225CZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225CZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225CZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225PZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225STLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TXATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TXATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TZATF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TZATS 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J225TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
J25ECCM 1988	FUEL PUMP
J25ECDR 1986	FUEL PUMP
J25ECEB 1989	FUEL PUMP
J25ECNE 1982	FUEL PUMP
J25ECOC 1985	FUEL PUMP
J25ECRS 1984	FUEL PUMP
J25ECTD 1983	FUEL PUMP
J25ECUA 1987	FUEL PUMP
J25EESE 1990	FUEL PUMP - EARLY PRODUCTION
J25ELCCM 1988	FUEL PUMP

J25ELCDR 1986	FUEL PUMP
J25ELCEB 1989	FUEL PUMP
J25ELCNE 1982	FUEL PUMP
J25ELCOC 1985	FUEL PUMP
J25ELCRS 1984	FUEL PUMP
J25ELCTD 1983	FUEL PUMP
J25ELCUA 1987	FUEL PUMP
J25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
J25RCCA 1988	FUEL PUMP
J25RCDC 1986	FUEL PUMP
J25RCEM 1989	FUEL PUMP
J25RCNB 1982	FUEL PUMP
J25RCOS 1985	FUEL PUMP
J25RCRD 1984	FUEL PUMP
J25RCTE 1983	FUEL PUMP
J25RCUR 1987	FUEL PUMP
J25RELCNB 1982	FUEL PUMP
J25RESB 1990	FUEL PUMP - EARLY PRODUCTION
J25RLCCA 1988	FUEL PUMP
J25RLCDC 1986	FUEL PUMP
J25RLCEM 1989	FUEL PUMP
J25RLCNB 1982	FUEL PUMP
J25RLCOS 1985	FUEL PUMP
J25RLCRD 1984	FUEL PUMP
J25RLCTE 1983	FUEL PUMP
J25RLCUR 1987	FUEL PUMP
J25RLESB 1990	FUEL PUMP - EARLY PRODUCTION
J25RSLS 1983	FUEL PUMP
J25RSS 1983	FUEL PUMP
J25RWCDC 1986	FUEL PUMP
J25RWCOS 1985	FUEL PUMP
J25RWCRD 1984	FUEL PUMP
J25RWCTE 1983	FUEL PUMP
J25RWCUR 1987	FUEL PUMP
J25RWESA 1990	FUEL PUMP - EARLY PRODUCTION

J25RWK 1989	FUEL PUMP
J25RWLCDC 1986	FUEL PUMP
J25RWLCOS 1985	FUEL PUMP
J25RWLCRD 1984	FUEL PUMP
J25RWLCTE 1983	FUEL PUMP
J25RWLCUR 1987	FUEL PUMP
J25RWLESA 1990	FUEL PUMP - EARLY PRODUCTION
J25RWLK 1989	FUEL PUMP
J25TECCA 1988	FUEL PUMP
J25TECDC 1986	FUEL PUMP
J25TECEM 1989	FUEL PUMP
J25TECNB 1982	FUEL PUMP
J25TECOS 1985	FUEL PUMP
J25TECRD 1984	FUEL PUMP
J25TECTE 1983	FUEL PUMP
J25TECUR 1987	FUEL PUMP
J25TEESB 1990	FUEL PUMP - EARLY PRODUCTION
J25TELCCA 1988	FUEL PUMP
J25TELCDC 1986	FUEL PUMP
J25TELCEM 1989	FUEL PUMP
J25TELCOS 1985	FUEL PUMP
J25TELCRD 1984	FUEL PUMP
J25TELCTE 1983	FUEL PUMP
J25TELCUR 1987	FUEL PUMP
J25TELESB 1990	FUEL PUMP - EARLY PRODUCTION
J28ELCDS 1986	FUEL PUMP
J28ESLCCR 1988	FUEL PUMP
J28ESLCEA 1989	FUEL PUMP
J28ESLCUC 1987	FUEL PUMP
J28ESLESM 1990	FUEL PUMP - EARLY PRODUCTION
J30ECCE 1988	FUEL PUMP
J30ECDM 1986	FUEL PUMP
J30ECED 1989	FUEL PUMP
J30ECOA 1985	FUEL PUMP
J30ECRR 1984	FUEL PUMP

J30ECUB 1987	FUEL PUMP
J30EESS 1990	FUEL PUMP - EARLY PRODUCTION
J30ELCCE 1988	FUEL PUMP
J30ELCDM 1986	FUEL PUMP
J30ELCED 1989	FUEL PUMP
J30ELCOA 1985	FUEL PUMP
J30ELCRR 1984	FUEL PUMP
J30ELCUB 1987	FUEL PUMP
J30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
J30RCCE 1988	FUEL PUMP
J30RCDM 1986	FUEL PUMP
J30RCED 1989	FUEL PUMP
J30RCOA 1985	FUEL PUMP
J30RCUB 1987	FUEL PUMP
J30RESS 1990	FUEL PUMP - EARLY PRODUCTION
J30RLCCE 1988	FUEL PUMP
J30RLCDM 1986	FUEL PUMP
J30RLCED 1989	FUEL PUMP
J30RLCOA 1985	FUEL PUMP
J30RLCUB 1987	FUEL PUMP
J30RLESS 1990	FUEL PUMP - EARLY PRODUCTION
J30TECCE 1988	FUEL PUMP
J30TECDM 1986	FUEL PUMP
J30TECED 1989	FUEL PUMP
J30TECOA 1985	FUEL PUMP
J30TECUB 1987	FUEL PUMP
J30TEESS 1990	FUEL PUMP - EARLY PRODUCTION
J30TELCCCE 1988	FUEL PUMP
J30TELCDM 1986	FUEL PUMP
J30TELCED 1989	FUEL PUMP
J30TELCOA 1985	FUEL PUMP
J30TELCCUB 1987	FUEL PUMP
J30TELESS 1990	FUEL PUMP - EARLY PRODUCTION
J35ECND 1982	FUEL PUMP
J35ECRR 1984	FUEL PUMP

J35ECTS 1983	FUEL PUMP
J35ELCND 1982	FUEL PUMP
J35ELCRR 1984	FUEL PUMP
J35ELCTS 1983	FUEL PUMP
J35RCCE 1988	FUEL PUMP
J35RCDM 1986	FUEL PUMP
J35RCED 1989	FUEL PUMP
J35RCND 1982	FUEL PUMP
J35RCRR 1984	FUEL PUMP
J35RCTS 1983	FUEL PUMP
J35RCUB 1987	FUEL PUMP
J35RESS 1990	FUEL PUMP - EARLY PRODUCTION
J35RLCCE 1988	FUEL PUMP
J35RLCDM 1986	FUEL PUMP
J35RLCED 1989	FUEL PUMP
J35RLCND 1982	FUEL PUMP
J35RLCRR 1984	FUEL PUMP
J35RLCTS 1983	FUEL PUMP
J35RLCUB 1987	FUEL PUMP
J35RLESS 1990	FUEL PUMP - EARLY PRODUCTION
J35TELCNB 1982	FUEL PUMP
J35TELCRR 1984	FUEL PUMP
J35TELCTS 1983	FUEL PUMP
J60ELCCR 1988	VRO2 PUMP
J60ELCDS 1986	VRO PUMP
J60ELCEA 1989	VRO2 PUMP
J60ELCUC 1987	VRO PUMP
J60ELESM 1990	VRO2 PUMP
J60TLCCR 1988	VRO2 PUMP
J60TLCDS 1986	VRO PUMP
J60TLCEA 1989	VRO2 PUMP
J60TLCUC 1987	VRO PUMP
J60TLESM 1990	VRO2 PUMP
J60TTLCCR 1988	VRO2 PUMP
J60TTLCEA 1989	VRO2 PUMP

J60TTLESM 1990	VRO2 PUMP
J65WMLCDR 1986	VRO PUMP - WMLC MODELS ONLY
J65WMLCUA 1987	VRO PUMP - WMLC MODELS ONLY
J65WMLES M 1990	VRO2 PUMP
J65WMLZ 1989	VRO2 PUMP
J6RCUD 1987	FUEL PUMP - LATE PRODUCTION
J6RLCUD 1987	FUEL PUMP - LATE PRODUCTION
J6SLCUD 1987	FUEL PUMP - LATE PRODUCTION
J70ELCCA 1988	VRO2 PUMP
J70ELCDC 1986	VRO PUMP
J70ELCEM 1989	VRO2 PUMP
J70ELCUR 1987	VRO PUMP
J70ELESB 1990	VRO2 PUMP
J70TLCCA 1988	VRO2 PUMP
J70TLCDC 1986	VRO PUMP
J70TLCEM 1989	VRO2 PUMP
J70TLCUR 1987	VRO PUMP
J70TLESB 1990	VRO2 PUMP
J75ECCA 1988	VRO2 PUMP
J75ECDC 1986	VRO PUMP
J75ECUR 1987	VRO PUMP
J8RCUD 1987	FUEL PUMP - LATE PRODUCTION
J8RLCUD 1987	FUEL PUMP - LATE PRODUCTION
J8SRLCUD 1987	FUEL PUMP - LATE PRODUCTION
N65WMLM 1988	VRO2 PUMP - WMLM MODELS ONLY
T65WMLM 1988	VRO2 PUMP - WMLM MODELS ONLY
TE10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
TE10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TE10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TE10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
TE10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS
TE15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
TE20CRCM 1989	FUEL PUMP
TE20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
TE20CRLCEM 1989	FUEL PUMP

TE20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
TE20CRLESF 1989	FUEL PUMP
TE25ELCEB 1989	FUEL PUMP
TE25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
TE25ELESF 1989	FUEL PUMP
TE30ELCED 1989	FUEL PUMP
TE30ELESF 1989	FUEL PUMP
TE30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
TE60TLCEA 1989	VRO2 PUMP
TE60TLESF 1989	VRO2 PUMP
TE60TLESF 1990	VRO2 PUMP
TE60TLESM 1990	VRO2 PUMP
TE70TLCEM 1989	VRO2 PUMP
TE70TLESB 1990	VRO2 PUMP
TE70TLESF 1989	VRO2 PUMP
TE70TLESF 1990	VRO2 PUMP
TJ10ELCES 1989	FUEL PUMP - ELECTRIC START MODELS
TJ10ELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TJ10RELESC 1990	FUEL PUMP - ELECTRIC START MODELS
TJ10RLCES 1989	FUEL PUMP - ELECTRIC START MODELS
TJ10RLESC 1990	FUEL PUMP - ELECTRIC START MODELS
TJ15RLCEC 1989	FUEL PUMP - ELECTRIC START MODELS
TJ20CRCM 1989	FUEL PUMP
TJ20CRESB 1990	FUEL PUMP - EARLY PRODUCTION
TJ20CRLCEM 1989	FUEL PUMP
TJ20CRLESB 1990	FUEL PUMP - EARLY PRODUCTION
TJ20CRLESF 1989	FUEL PUMP
TJ25ELCEB 1989	FUEL PUMP
TJ25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
TJ25ELESF 1989	FUEL PUMP
TJ30ELCED 1989	FUEL PUMP
TJ30ELESF 1989	FUEL PUMP
TJ30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
TJ60TLCEA 1989	VRO2 PUMP
TJ60TLESF 1989	VRO2 PUMP

TJ60TLESF 1990	VRO2 PUMP
TJ60TLESM 1990	VRO2 PUMP
TJ70TLCM 1989	VRO2 PUMP
TJ70TLESB 1990	VRO2 PUMP
TJ70TLESF 1989	VRO2 PUMP
TJ70TLESF 1990	VRO2 PUMP
U25RWA 1988	FUEL PUMP
U25RWLA 1988	FUEL PUMP
VE200SLET C 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE200SLET F 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE200TXETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE200TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE200TZETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE200TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225PLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225PLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225PXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225PXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225PZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225PZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225STLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225TLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225TLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225TXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225TZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE225TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VE25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
VE25RESB 1990	FUEL PUMP - EARLY PRODUCTION
VE28ESLCCR 1988	FUEL PUMP
VE28ESLCEA 1989	FUEL PUMP
VE28ESLES M 1990	FUEL PUMP - EARLY PRODUCTION
VE30EESS 1990	FUEL PUMP - EARLY PRODUCTION
VE30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
VE60ELES M 1990	VRO2 PUMP

VE60TLESM 1990	VRO2 PUMP
VE70ELESB 1990	VRO2 PUMP
VE70TLESB 1990	VRO2 PUMP
VJ200SLETCA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ200SLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ200TXETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ200TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ200TZETD 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ200TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225PLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225PLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225PXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225PXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225PZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225PZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225STLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225TLETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225TLETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225TXETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225TXETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225TZETA 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ225TZETF 1993	INTAKE MANIFOLD - SUFFIX "A, C, D, S" MODELS
VJ25ELESE 1990	FUEL PUMP - EARLY PRODUCTION
VJ25RESB 1990	FUEL PUMP - EARLY PRODUCTION
VJ28ESLCCR 1988	FUEL PUMP
VJ28ESLCEA 1989	FUEL PUMP
VJ28ESLESM 1990	FUEL PUMP - EARLY PRODUCTION
VJ30EESS 1990	FUEL PUMP - EARLY PRODUCTION
VJ30ELESS 1990	FUEL PUMP - EARLY PRODUCTION
VJ60ELEM 1990	VRO2 PUMP
VJ60TLESM 1990	VRO2 PUMP
VJ70ELESB 1990	VRO2 PUMP
VJ70TLESB 1990	VRO2 PUMP