

Where Used: Part Number 0328993

Model Name	Diagram
BE5DREDS 1996	INTAKE MANIFOLD
BE5DREUC 1997	INTAKE MANIFOLD
BE5DRLEDS 1996	INTAKE MANIFOLD
BE5DRLEUC 1997	INTAKE MANIFOLD
BE6DRECR 1998	INTAKE MANIFOLD
BE6DREDS 1996	INTAKE MANIFOLD
BE6DREUC 1997	INTAKE MANIFOLD
BE6DRLECR 1998	INTAKE MANIFOLD
BE6DRLEDS 1996	INTAKE MANIFOLD
BE6DRLEUC 1997	INTAKE MANIFOLD
BE6REDS 1996	INTAKE MANIFOLD
BE6RLEDS 1996	INTAKE MANIFOLD
BE8RCB 1997	INTAKE MANIFOLD
BE8RCH 1996	INTAKE MANIFOLD
BE8RCLB 1997	INTAKE MANIFOLD
BE8RCLH 1996	INTAKE MANIFOLD
BE8RCLT 1998	INTAKE MANIFOLD
BE8RCT 1998	INTAKE MANIFOLD
BE8REDS 1996	INTAKE MANIFOLD
BE8RLEDS 1996	INTAKE MANIFOLD
BE8SRLEDS 1996	INTAKE MANIFOLD
BJ5DREDS 1996	INTAKE MANIFOLD
BJ5DREUC 1997	INTAKE MANIFOLD
BJ5DRLEDS 1996	INTAKE MANIFOLD
BJ5DRLEUC 1997	INTAKE MANIFOLD
BJ6DRECR 1998	INTAKE MANIFOLD
BJ6DREDS 1996	INTAKE MANIFOLD
BJ6DREUC 1997	INTAKE MANIFOLD
BJ6DRLECR 1998	INTAKE MANIFOLD
BJ6DRLEDS 1996	INTAKE MANIFOLD
BJ6DRLEUC 1997	INTAKE MANIFOLD
BJ6REDS 1996	INTAKE MANIFOLD
BJ6RLEDS 1996	INTAKE MANIFOLD

BJ8RCB 1997	INTAKE MANIFOLD
BJ8RCH 1996	INTAKE MANIFOLD
BJ8RCLB 1997	INTAKE MANIFOLD
BJ8RCLH 1996	INTAKE MANIFOLD
BJ8RCLT 1998	INTAKE MANIFOLD
BJ8RCT 1998	INTAKE MANIFOLD
BJ8REDS 1996	INTAKE MANIFOLD
BJ8RLEDS 1996	INTAKE MANIFOLD
BJ8SRLEDS 1996	INTAKE MANIFOLD
E5DRECR 1998	INTAKE MANIFOLD
E5DRLECR 1998	INTAKE MANIFOLD
E6RCCS 1988	INTAKE MANIFOLD - 8
E6RCDE 1986	INTAKE MANIFOLD - 8
E6RCEC 1989	INTAKE MANIFOLD - 8
E6RCOB 1985	INTAKE MANIFOLD - 8
E6RCRM 1984	INTAKE MANIFOLD - 8
E6RCUD 1987	INTAKE MANIFOLD - 8
E6RECR 1998	INTAKE MANIFOLD
E6REDS 1996	INTAKE MANIFOLD
E6REIA 1991	INTAKE MANIFOLD
E6RENM 1992	INTAKE MANIFOLD
E6REOD 1995	INTAKE MANIFOLD
E6RERE 1994	INTAKE MANIFOLD
E6RESR 1990	INTAKE MANIFOLD - 8
E6RETB 1993	INTAKE MANIFOLD
E6REUC 1997	INTAKE MANIFOLD
E6RLCCS 1988	INTAKE MANIFOLD - 8
E6RLCDE 1986	INTAKE MANIFOLD - 8
E6RLCEC 1989	INTAKE MANIFOLD - 8
E6RLCOB 1985	INTAKE MANIFOLD - 8
E6RLCRM 1984	INTAKE MANIFOLD - 8
E6RLCUD 1987	INTAKE MANIFOLD - 8
E6RLECR 1998	INTAKE MANIFOLD
E6RLEDS 1996	INTAKE MANIFOLD
E6RLEIA 1991	INTAKE MANIFOLD

E6RLENM 1992	INTAKE MANIFOLD
E6RLEOD 1995	INTAKE MANIFOLD
E6RLERE 1994	INTAKE MANIFOLD
E6RLESR 1990	INTAKE MANIFOLD - 8
E6RLETB 1993	INTAKE MANIFOLD
E6RLEUC 1997	INTAKE MANIFOLD
E6SLCCS 1988	INTAKE MANIFOLD - 8
E6SLCDE 1986	INTAKE MANIFOLD - 8
E6SLCEC 1989	INTAKE MANIFOLD - 8
E6SLCOB 1985	INTAKE MANIFOLD - 8
E6SLCRM 1984	INTAKE MANIFOLD - 8
E6SLCUD 1987	INTAKE MANIFOLD - 8
E6SLEDs 1996	INTAKE MANIFOLD
E6SLEIA 1991	INTAKE MANIFOLD
E6SLENM 1992	INTAKE MANIFOLD
E6SLEOD 1995	INTAKE MANIFOLD
E6SLERE 1994	INTAKE MANIFOLD
E6SLESR 1990	INTAKE MANIFOLD - 8
E6SLETB 1993	INTAKE MANIFOLD
E8DREEA 1999	INTAKE MANIFOLD
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	INTAKE MANIFOLD
E8RCCS 1988	INTAKE MANIFOLD - 8
E8RCDE 1986	INTAKE MANIFOLD - 8
E8RCEC 1989	INTAKE MANIFOLD - 8
E8RCOB 1985	INTAKE MANIFOLD - 8
E8RCRM 1984	INTAKE MANIFOLD - 8
E8RCUD 1987	INTAKE MANIFOLD - 8
E8RECR 1998	INTAKE MANIFOLD
E8REDS 1996	INTAKE MANIFOLD
E8REIA 1991	INTAKE MANIFOLD
E8RENM 1992	INTAKE MANIFOLD
E8REOD 1995	INTAKE MANIFOLD
E8RERE 1994	INTAKE MANIFOLD
E8RESR 1990	INTAKE MANIFOLD - 8
E8RETB 1993	INTAKE MANIFOLD

E8REUC 1997	INTAKE MANIFOLD
E8RLCCS 1988	INTAKE MANIFOLD - 8
E8RLCDE 1986	INTAKE MANIFOLD - 8
E8RLCEC 1989	INTAKE MANIFOLD - 8
E8RLCOB 1985	INTAKE MANIFOLD - 8
E8RLCRM 1984	INTAKE MANIFOLD - 8
E8RLCUD 1987	INTAKE MANIFOLD - 8
E8RLECR 1998	INTAKE MANIFOLD
E8RLEDS 1996	INTAKE MANIFOLD
E8RLEIA 1991	INTAKE MANIFOLD
E8RLENM 1992	INTAKE MANIFOLD
E8RLEOD 1995	INTAKE MANIFOLD
E8RLERE 1994	INTAKE MANIFOLD
E8RLESR 1990	INTAKE MANIFOLD - 8
E8RLETB 1993	INTAKE MANIFOLD
E8RLEUC 1997	INTAKE MANIFOLD
E8SRLCCS 1988	INTAKE MANIFOLD - 8
E8SRLCDE 1986	INTAKE MANIFOLD - 8
E8SRLCEC 1989	INTAKE MANIFOLD - 8
E8SRLCOB 1985	INTAKE MANIFOLD - 8
E8SRLCRM 1984	INTAKE MANIFOLD - 8
E8SRLCUD 1987	INTAKE MANIFOLD - 8
E8SRLECA 1998	INTAKE MANIFOLD
E8SRLEDS 1996	INTAKE MANIFOLD
E8SRLEIA 1991	INTAKE MANIFOLD
E8SRLENM 1992	INTAKE MANIFOLD
E8SRLEOD 1995	INTAKE MANIFOLD
E8SRLERE 1994	INTAKE MANIFOLD
E8SRLESR 1990	INTAKE MANIFOLD - 8
E8SRLETB 1993	INTAKE MANIFOLD
E8SRLEUC 1997	INTAKE MANIFOLD
E8WREES 1999	INTAKE MANIFOLD
E8WRLEES 1999	INTAKE MANIFOLD
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	INTAKE MANIFOLD
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	INTAKE MANIFOLD

E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	INTAKE MANIFOLD
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	INTAKE MANIFOLD
J5DRECR 1998	INTAKE MANIFOLD
J5DRLECR 1998	INTAKE MANIFOLD
J6RCCS 1988	INTAKE MANIFOLD - 8
J6RCDE 1986	INTAKE MANIFOLD - 8
J6RCEC 1989	INTAKE MANIFOLD - 8
J6RCOB 1985	INTAKE MANIFOLD - 8
J6RCRM 1984	INTAKE MANIFOLD - 8
J6RCUD 1987	INTAKE MANIFOLD - 8
J6RECR 1998	INTAKE MANIFOLD
J6REDS 1996	INTAKE MANIFOLD
J6REEA 1999	INTAKE MANIFOLD
J6REIA 1991	INTAKE MANIFOLD
J6RENM 1992	INTAKE MANIFOLD
J6REOD 1995	INTAKE MANIFOLD
J6RERE 1994	INTAKE MANIFOLD
J6RESR 1990	INTAKE MANIFOLD - 8
J6RETB 1993	INTAKE MANIFOLD
J6REUC 1997	INTAKE MANIFOLD
J6RLCCS 1988	INTAKE MANIFOLD - 8
J6RLCDE 1986	INTAKE MANIFOLD - 8
J6RLCEC 1989	INTAKE MANIFOLD - 8
J6RLCOB 1985	INTAKE MANIFOLD - 8
J6RLCRM 1984	INTAKE MANIFOLD - 8
J6RLCUD 1987	INTAKE MANIFOLD - 8
J6RLECR 1998	INTAKE MANIFOLD
J6RLEDs 1996	INTAKE MANIFOLD
J6RLEEa 1999	INTAKE MANIFOLD
J6RLEIA 1991	INTAKE MANIFOLD
J6RLENM 1992	INTAKE MANIFOLD
J6RLEOD 1995	INTAKE MANIFOLD
J6RLERE 1994	INTAKE MANIFOLD
J6RLESR 1990	INTAKE MANIFOLD - 8
J6RLETB 1993	INTAKE MANIFOLD

J6RLEUC 1997	INTAKE MANIFOLD
J6RLSIB rope start, tiller, 20 in shaft 2001	INTAKE MANIFOLD
J6RLSOC	INTAKE MANIFOLD
J6RLSOC - FR	25-1_COLLECTEUR D'ADMISSION
J6RLSRS	INTAKE MANIFOLD
J6RLSRS - FR	25-1_COLLECTEUR D'ADMISSION
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	INTAKE MANIFOLD
J6RLSTD	INTAKE MANIFOLD
J6RLSTD - FR	25-1_COLLECTEUR D'ADMISSION
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	INTAKE MANIFOLD
J6RSIB rope start, tiller, 15 in shaft 2001	INTAKE MANIFOLD
J6RSOC	INTAKE MANIFOLD
J6RSOC - FR	25-1_COLLECTEUR D'ADMISSION
J6RSRS	INTAKE MANIFOLD
J6RSRS - FR	25-1_COLLECTEUR D'ADMISSION
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	INTAKE MANIFOLD
J6RSTD	INTAKE MANIFOLD
J6RSTD - FR	25-1_COLLECTEUR D'ADMISSION
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	INTAKE MANIFOLD
J6SLCCS 1988	INTAKE MANIFOLD - 8
J6SLCDE 1986	INTAKE MANIFOLD - 8
J6SLCEC 1989	INTAKE MANIFOLD - 8
J6SLCOB 1985	INTAKE MANIFOLD - 8
J6SLCRM 1984	INTAKE MANIFOLD - 8
J6SLCUD 1987	INTAKE MANIFOLD - 8
J6SLEDS 1996	INTAKE MANIFOLD
J6SLEIA 1991	INTAKE MANIFOLD
J6SLENM 1992	INTAKE MANIFOLD
J6SLEOD 1995	INTAKE MANIFOLD
J6SLERE 1994	INTAKE MANIFOLD
J6SLESR 1990	INTAKE MANIFOLD - 8
J6SLETB 1993	INTAKE MANIFOLD
J8DREEA 1999	INTAKE MANIFOLD
J8RCCS 1988	INTAKE MANIFOLD - 8
J8RCDE 1986	INTAKE MANIFOLD - 8

J8RCEC 1989	INTAKE MANIFOLD - 8
J8RCOB 1985	INTAKE MANIFOLD - 8
J8RCRM 1984	INTAKE MANIFOLD - 8
J8RCUD 1987	INTAKE MANIFOLD - 8
J8RECR 1998	INTAKE MANIFOLD
J8REDS 1996	INTAKE MANIFOLD
J8REEM 1999	INTAKE MANIFOLD
J8REIA 1991	INTAKE MANIFOLD
J8RENM 1992	INTAKE MANIFOLD
J8REOD 1995	INTAKE MANIFOLD
J8RERE 1994	INTAKE MANIFOLD
J8RESR 1990	INTAKE MANIFOLD - 8
J8RETB 1993	INTAKE MANIFOLD
J8REUC 1997	INTAKE MANIFOLD
J8RLCCS 1988	INTAKE MANIFOLD - 8
J8RLCDE 1986	INTAKE MANIFOLD - 8
J8RLCEC 1989	INTAKE MANIFOLD - 8
J8RLCOB 1985	INTAKE MANIFOLD - 8
J8RLCRM 1984	INTAKE MANIFOLD - 8
J8RLCUD 1987	INTAKE MANIFOLD - 8
J8RLECR 1998	INTAKE MANIFOLD
J8RLEDS 1996	INTAKE MANIFOLD
J8RLEEM 1999	INTAKE MANIFOLD
J8RLEIA 1991	INTAKE MANIFOLD
J8RLENM 1992	INTAKE MANIFOLD
J8RLEOD 1995	INTAKE MANIFOLD
J8RLERE 1994	INTAKE MANIFOLD
J8RLESR 1990	INTAKE MANIFOLD - 8
J8RLETB 1993	INTAKE MANIFOLD
J8RLEUC 1997	INTAKE MANIFOLD
J8RLSIE rope start, tiller, 20 in shaft 2001	INTAKE MANIFOLD
J8RLSOR	INTAKE MANIFOLD
J8RLSOR - FR	25-1_COLLECTEUR D'ADMISSION
J8RLSRC	INTAKE MANIFOLD
J8RLSRC - FR	25-1_COLLECTEUR D'ADMISSION

J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	INTAKE MANIFOLD
J8RLSTS	INTAKE MANIFOLD
J8RLSTS - FR	25-1_COLLECTEUR D'ADMISSION
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	INTAKE MANIFOLD
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	INTAKE MANIFOLD
J8RSIE rope start, tiller, 15 in shaft 2001	INTAKE MANIFOLD
J8RSOR	INTAKE MANIFOLD
J8RSOR - FR	25-1_COLLECTEUR D'ADMISSION
J8RSRC	INTAKE MANIFOLD
J8RSRC - FR	25-1_COLLECTEUR D'ADMISSION
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	INTAKE MANIFOLD
J8RSTD	INTAKE MANIFOLD
J8RSTD - FR	25-1_COLLECTEUR D'ADMISSION
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	INTAKE MANIFOLD
J8RXEEM 1999	INTAKE MANIFOLD
J8RXSIE rope start, tiller, 25 in shaft 2001	INTAKE MANIFOLD
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	INTAKE MANIFOLD
J8SRLCCS 1988	INTAKE MANIFOLD - 8
J8SRLCDE 1986	INTAKE MANIFOLD - 8
J8SRLCEC 1989	INTAKE MANIFOLD - 8
J8SRLCOB 1985	INTAKE MANIFOLD - 8
J8SRLCRM 1984	INTAKE MANIFOLD - 8
J8SRLCUD 1987	INTAKE MANIFOLD - 8
J8SRLECA 1998	INTAKE MANIFOLD
J8SRLEDS 1996	INTAKE MANIFOLD
J8SRLEIA 1991	INTAKE MANIFOLD
J8SRLENM 1992	INTAKE MANIFOLD
J8SRLEOD 1995	INTAKE MANIFOLD
J8SRLERE 1994	INTAKE MANIFOLD
J8SRLESR 1990	INTAKE MANIFOLD - 8
J8SRLETB 1993	INTAKE MANIFOLD
J8SRLEUC 1997	INTAKE MANIFOLD
J8WREES 1999	INTAKE MANIFOLD
J8WRLEES 1999	INTAKE MANIFOLD
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	INTAKE MANIFOLD

J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	INTAKE MANIFOLD
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	INTAKE MANIFOLD
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	INTAKE MANIFOLD
SJ6REDS 1996	INTAKE MANIFOLD
SJ6RLEDS 1996	INTAKE MANIFOLD
SJ8REDS 1996	INTAKE MANIFOLD
SJ8RLEDS 1996	INTAKE MANIFOLD
TE8RCEC 1989	INTAKE MANIFOLD - 8
TE8RLCEC 1989	INTAKE MANIFOLD - 8
TE8RLESCF 1990	INTAKE MANIFOLD - 8
TJ8RCEC 1989	INTAKE MANIFOLD - 8
TJ8RLCEC 1989	INTAKE MANIFOLD - 8