

Where Used: Part Number 0330562

Model Name	Diagram
BE250CXECB 1998	CYLINDER & CRANKCASE
BE250CXEDA 1996	CYLINDER & CRANKCASE
BE250CXEUM 1997	CYLINDER & CRANKCASE
BE250TXECB 1998	CYLINDER & CRANKCASE
BE250TXEDA 1996	CYLINDER & CRANKCASE
BE250TXEUM 1997	CYLINDER & CRANKCASE
BJ250CXECB 1998	CYLINDER & CRANKCASE
BJ250CXEDA 1996	CYLINDER & CRANKCASE
BJ250CXEUM 1997	CYLINDER & CRANKCASE
BJ250TXECB 1998	CYLINDER & CRANKCASE
BJ250TXEDA 1996	CYLINDER & CRANKCASE
BJ250TXEUM 1997	CYLINDER & CRANKCASE
D25RWA 1988	GEARCASE
D25RWLA 1988	GEARCASE
E20CRCOS 1985	MIDSECTION - ELECTRIC START ONLY
E20CRLCOS 1985	MIDSECTION - ELECTRIC START ONLY
E20ECOS 1985	MIDSECTION - ELECTRIC START ONLY
E20ELCOS 1985	MIDSECTION - ELECTRIC START ONLY
E250CXARC 1994	CYLINDER & CRANKCASE
E250CXEOR 1995	CYLINDER & CRANKCASE
E250CXERC 1994	CYLINDER & CRANKCASE
E250CZEOR 1995	CYLINDER & CRANKCASE
E250CZERC 1994	CYLINDER & CRANKCASE
E250TXARC 1994	CYLINDER & CRANKCASE
E250TXEOR 1995	CYLINDER & CRANKCASE
E250TXERC 1994	CYLINDER & CRANKCASE
E250TZEOR 1995	CYLINDER & CRANKCASE
E250TZERC 1994	CYLINDER & CRANKCASE
E25ECOC 1985	MIDSECTION - ELECTRIC START ONLY
E25ELCOC 1985	MIDSECTION - ELECTRIC START ONLY
E25RCOS 1985	MIDSECTION - ELECTRIC START ONLY
E25RLCOS 1985	MIDSECTION - ELECTRIC START ONLY
E25RWDC 1986	GEARCASE

E25RWCOS 1985	GEARCASE
E25RWCUR 1987	GEARCASE
E25RWEDC 1996	GEARCASE - 25RS - 25RW - H25FP
E25RWEIM 1991	GEARCASE
E25RWENB 1992	GEARCASE
E25RWEOS 1995	GEARCASE - 25RS - 25RW - H25FP
E25RWERD 1994	GEARCASE - 25RW
E25RWESA 1990	GEARCASE
E25RWETE 1993	GEARCASE - 25RW
E25RWEUR 1997	GEARCASE - 25RS, 25RW, H25FP
E25RWK 1989	GEARCASE
E25RWLDC 1986	GEARCASE
E25RWLCOS 1985	GEARCASE
E25RWLCUR 1987	GEARCASE
E25RWLEDC 1996	GEARCASE - 25RS - 25RW - H25FP
E25RWLEIM 1991	GEARCASE
E25RWLENB 1992	GEARCASE
E25RWLEOS 1995	GEARCASE - 25RS - 25RW - H25FP
E25RWLERD 1994	GEARCASE - 25RW
E25RWLESA 1990	GEARCASE
E25RWLETE 1993	GEARCASE - 25RW
E25RWLEUR 1997	GEARCASE - 25RS, 25RW, H25FP
E25RWLK 1989	GEARCASE
E25TECOS 1985	MIDSECTION - ELECTRIC START ONLY
E25TELCOS 1985	MIDSECTION - ELECTRIC START ONLY
E28ELCDS 1986	GEARCASE
E28ESLCCR 1988	GEARCASE
E28ESLCEA 1989	GEARCASE
E28ESLCUC 1987	GEARCASE
E28ESLEDR 1996	GEARCASE
E28ESLEIB 1991	GEARCASE
E28ESLENE 1992	GEARCASE
E28ESLEOC 1995	GEARCASE
E28ESLERS 1994	GEARCASE
E28ESLESM 1990	GEARCASE

E28ESLETD 1993	GEARCASE
E300CXEOR 1995	CYLINDER & CRANKCASE
E300CXERC 1994	CYLINDER & CRANKCASE
E300PLEOR 1995	CYLINDER & CRANKCASE
E300PLERC 1994	CYLINDER & CRANKCASE
E300PXEOR 1995	CYLINDER & CRANKCASE
E300PXERC 1994	CYLINDER & CRANKCASE
HE25FPO 1996	GEARCASE - 25RS - 25RW - H25FP
HE25FPV 1997	GEARCASE - 25RS, 25RW, H25FP
HE25RSLO 1996	GEARCASE - 25RS - 25RW - H25FP
HE25RSLV 1997	GEARCASE - 25RS, 25RW, H25FP
HJ25FPO 1996	GEARCASE - 25RS - 25RW - H25FP
HJ25FPV 1997	GEARCASE - 25RS, 25RW, H25FP
HJ25RSLV 1997	GEARCASE - 25RS, 25RW, H25FP
HJ25RSLO 1996	GEARCASE - 25RS - 25RW - H25FP
J20CRCOS 1985	MIDSECTION - ELECTRIC START ONLY
J20CRLCOS 1985	MIDSECTION - ELECTRIC START ONLY
J20ECOS 1985	MIDSECTION - ELECTRIC START ONLY
J20ELCOS 1985	MIDSECTION - ELECTRIC START ONLY
J250CXARC 1994	CYLINDER & CRANKCASE
J250CXEOR 1995	CYLINDER & CRANKCASE
J250CXERC 1994	CYLINDER & CRANKCASE
J250CZEOR 1995	CYLINDER & CRANKCASE
J250CZERC 1994	CYLINDER & CRANKCASE
J250TXARC 1994	CYLINDER & CRANKCASE
J250TXEOR 1995	CYLINDER & CRANKCASE
J250TXERC 1994	CYLINDER & CRANKCASE
J250TZEOR 1995	CYLINDER & CRANKCASE
J250TZERC 1994	CYLINDER & CRANKCASE
J25ECDR 1986	MIDSECTION - ELECTRIC START ONLY
J25ECOC 1985	MIDSECTION - ELECTRIC START ONLY
J25ELCDR 1986	MIDSECTION - ELECTRIC START ONLY
J25ELCOC 1985	MIDSECTION - ELECTRIC START ONLY
J25RCDC 1986	MIDSECTION - ELECTRIC START ONLY
J25RCOS 1985	MIDSECTION - ELECTRIC START ONLY

J25RLCDC 1986	MIDSECTION - ELECTRIC START ONLY
J25RLCOS 1985	MIDSECTION - ELECTRIC START ONLY
J25RWDCDC 1986	GEARCASE
J25RWCOS 1985	GEARCASE
J25RWCUR 1987	GEARCASE
J25RWEDC 1996	GEARCASE - 25RS - 25RW - H25FP
J25RWEIM 1991	GEARCASE
J25RWENB 1992	GEARCASE
J25RWEOS 1995	GEARCASE - 25RS - 25RW - H25FP
J25RWERD 1994	GEARCASE - 25RW
J25RWESA 1990	GEARCASE
J25RWETE 1993	GEARCASE - 25RW
J25RWEUR 1997	GEARCASE - 25RS, 25RW, H25FP
J25RWK 1989	GEARCASE
J25RWLCDC 1986	GEARCASE
J25RWLCOS 1985	GEARCASE
J25RWLCUR 1987	GEARCASE
J25RWLEDC 1996	GEARCASE - 25RS - 25RW - H25FP
J25RWLEIM 1991	GEARCASE
J25RWLENB 1992	GEARCASE
J25RWLEOS 1995	GEARCASE - 25RS - 25RW - H25FP
J25RWLERD 1994	GEARCASE - 25RW
J25RWLESA 1990	GEARCASE
J25RWLETE 1993	GEARCASE - 25RW
J25RWLEUR 1997	GEARCASE - 25RS, 25RW, H25FP
J25RWLK 1989	GEARCASE
J25TECDC 1986	MIDSECTION - ELECTRIC START ONLY
J25TECOS 1985	MIDSECTION - ELECTRIC START ONLY
J25TELCDC 1986	MIDSECTION - ELECTRIC START ONLY
J25TELCOS 1985	MIDSECTION - ELECTRIC START ONLY
J28ELCDS 1986	GEARCASE
J28ESLCCR 1988	GEARCASE
J28ESLCEA 1989	GEARCASE
J28ESLCUC 1987	GEARCASE
J28ESLEDR 1996	GEARCASE

J28ESLEIB 1991	GEARCASE
J28ESLENE 1992	GEARCASE
J28ESLEOC 1995	GEARCASE
J28ESLERS 1994	GEARCASE
J28ESLESM 1990	GEARCASE
J28ESLETD 1993	GEARCASE
J300CXEOR 1995	CYLINDER & CRANKCASE
J300CXERC 1994	CYLINDER & CRANKCASE
J300PLEOR 1995	CYLINDER & CRANKCASE
J300PLERC 1994	CYLINDER & CRANKCASE
J300PXEOR 1995	CYLINDER & CRANKCASE
J300PXERC 1994	CYLINDER & CRANKCASE
SE25RPLV 1997	GEARCASE - 25RS, 25RW, H25FP
SE25RPV 1997	GEARCASE - 25RS, 25RW, H25FP
SJ25RPLV 1997	GEARCASE - 25RS, 25RW, H25FP
SJ25RPV 1997	GEARCASE - 25RS, 25RW, H25FP
U25RWA 1988	GEARCASE
U25RWLA 1988	GEARCASE
VE14RCCS 1988	GEARCASE
VE14RCEC 1989	GEARCASE
VE28ESLCCR 1988	GEARCASE
VE28ESLCEA 1989	GEARCASE
VE28ESLESM 1990	GEARCASE
VJ14RCCS 1988	GEARCASE
VJ14RCEC 1989	GEARCASE
VJ28ESLCCR 1988	GEARCASE
VJ28ESLCEA 1989	GEARCASE
VJ28ESLESM 1990	GEARCASE