

Where Used: Part Number 0331130

Model Name	Diagram
BE5DREDS 1996	GEARCASE
BE5DREUC 1997	GEARCASE
BE5DRLEDS 1996	GEARCASE
BE5DRLEUC 1997	GEARCASE
BE5FRBECC 1998	GEARCASE
BE5FRBEUS 1997	GEARCASE
BE5FRBLECC 1998	GEARCASE
BE5FRBLEUS 1997	GEARCASE
BE6DRECR 1998	GEARCASE
BE6DREDS 1996	GEARCASE
BE6DREUC 1997	GEARCASE
BE6DRLECR 1998	GEARCASE
BE6DRLEDS 1996	GEARCASE
BE6DRLEUC 1997	GEARCASE
BE6REDS 1996	GEARCASE
BE6RLEDS 1996	GEARCASE
BE8RCB 1997	GEARCASE
BE8RCH 1996	GEARCASE
BE8RCLB 1997	GEARCASE
BE8RCLH 1996	GEARCASE
BE8RCLT 1998	GEARCASE
BE8RCT 1998	GEARCASE
BE8REDS 1996	GEARCASE
BE8RLEDS 1996	GEARCASE
BE8SRLEDS 1996	GEARCASE
BJ5DREDS 1996	GEARCASE
BJ5DREUC 1997	GEARCASE
BJ5DRLEDS 1996	GEARCASE
BJ5DRLEUC 1997	GEARCASE
BJ5FRBECC 1998	GEARCASE
BJ5FRBEUS 1997	GEARCASE
BJ5FRBLECC 1998	GEARCASE
BJ5FRBLEUS 1997	GEARCASE

BJ6DRECR 1998	GEARCASE
BJ6DREDS 1996	GEARCASE
BJ6DREUC 1997	GEARCASE
BJ6DRLECR 1998	GEARCASE
BJ6DRLEDS 1996	GEARCASE
BJ6DRLEUC 1997	GEARCASE
BJ6REDS 1996	GEARCASE
BJ6RLEDS 1996	GEARCASE
BJ8RCB 1997	GEARCASE
BJ8RCH 1996	GEARCASE
BJ8RCLB 1997	GEARCASE
BJ8RCLH 1996	GEARCASE
BJ8RCLT 1998	GEARCASE
BJ8RCT 1998	GEARCASE
BJ8REDS 1996	GEARCASE
BJ8RLEDS 1996	GEARCASE
BJ8SRLEDS 1996	GEARCASE
E3BRCEC 1989	GEARCASE
E3BRESR 1990	GEARCASE
E3RCCM 1988	GEARCASE - 3RC MODELS
E3RCCM 1988	GEARCASE - 4RC & 4RLC MODELS
E3RCUA 1987	GEARCASE - 3RC MODELS
E3RCUA 1987	GEARCASE - 4RC & 4RLC MODELS
E4BRHCCS 1988	GEARCASE
E4BRHCUD 1987	GEARCASE
E4BRHLCCS 1988	GEARCASE
E4BRHLCUD 1987	GEARCASE
E4RCCS 1988	GEARCASE - 3RC MODELS
E4RCCS 1988	GEARCASE - 4RC & 4RLC MODELS
E4RCEC 1989	GEARCASE
E4RCUD 1987	GEARCASE - 3RC MODELS
E4RCUD 1987	GEARCASE - 4RC & 4RLC MODELS
E4RDHCCS 1988	GEARCASE
E4RDHCDE 1986	GEARCASE
E4RDHCEC 1989	GEARCASE

E4RDHCUD 1987	GEARCASE
E4RDHESR 1990	GEARCASE
E4RDHLCCS 1988	GEARCASE
E4RDHLCEC 1989	GEARCASE
E4RDHLCUD 1987	GEARCASE
E4RDHLESR 1990	GEARCASE
E4RESR 1990	GEARCASE
E4RLCCS 1988	GEARCASE - 3RC MODELS
E4RLCCS 1988	GEARCASE - 4RC & 4RLC MODELS
E4RLCEC 1989	GEARCASE
E4RLCUD 1987	GEARCASE - 3RC MODELS
E4RLCUD 1987	GEARCASE - 4RC & 4RLC MODELS
E4RLESR 1990	GEARCASE
E5DRECR 1998	GEARCASE
E5DRLECR 1998	GEARCASE
E5R4EEM 1999	GEARCASE
E5R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	GEARCASE
E5R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	GEARCASE
E5RB4EER 1999	GEARCASE
E5RBL4EER 1999	GEARCASE
E5RL4EEM 1999	GEARCASE
E5RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	GEARCASE
E5RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	GEARCASE
E6R4EEM 1999	GEARCASE
E6R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	GEARCASE
E6R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	GEARCASE
E6RCCS 1988	GEARCASE
E6RCDE 1986	GEARCASE
E6RCEC 1989	GEARCASE
E6RCUD 1987	GEARCASE
E6RECR 1998	GEARCASE
E6REDS 1996	GEARCASE
E6REOD 1995	GEARCASE
E6RERE 1994	GEARCASE
E6RESR 1990	GEARCASE

E6RETB 1993	GEARCASE
E6REUC 1997	GEARCASE
E6RL4EEM 1999	GEARCASE
E6RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	GEARCASE
E6RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	GEARCASE
E6RLCCS 1988	GEARCASE
E6RLCDE 1986	GEARCASE
E6RLCEC 1989	GEARCASE
E6RLCUD 1987	GEARCASE
E6RLECR 1998	GEARCASE
E6RLEDS 1996	GEARCASE
E6RLEOD 1995	GEARCASE
E6RLERE 1994	GEARCASE
E6RLESR 1990	GEARCASE
E6RLETB 1993	GEARCASE
E6RLEUC 1997	GEARCASE
E6SLCCS 1988	GEARCASE
E6SLCDE 1986	GEARCASE
E6SLCEC 1989	GEARCASE
E6SLCUD 1987	GEARCASE
E6SLEDS 1996	GEARCASE
E6SLEOD 1995	GEARCASE
E6SLERE 1994	GEARCASE
E6SLESR 1990	GEARCASE
E6SLETB 1993	GEARCASE
E8DREEA 1999	GEARCASE
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	GEARCASE
E8RCCTS 1988	GEARCASE
E8RCDE 1986	GEARCASE
E8RCEC 1989	GEARCASE
E8RCUD 1987	GEARCASE
E8RECR 1998	GEARCASE
E8REDS 1996	GEARCASE
E8REOD 1995	GEARCASE
E8RERE 1994	GEARCASE

E8RESR 1990	GEARCASE
E8RETB 1993	GEARCASE
E8REUC 1997	GEARCASE
E8RLCCS 1988	GEARCASE
E8RLCDE 1986	GEARCASE
E8RLCEC 1989	GEARCASE
E8RLCUD 1987	GEARCASE
E8RLECR 1998	GEARCASE
E8RLEDS 1996	GEARCASE
E8RLEOD 1995	GEARCASE
E8RLERE 1994	GEARCASE
E8RLESR 1990	GEARCASE
E8RLETB 1993	GEARCASE
E8RLEUC 1997	GEARCASE
E8SRLCCS 1988	GEARCASE
E8SRLCDE 1986	GEARCASE
E8SRLCEC 1989	GEARCASE
E8SRLCUD 1987	GEARCASE
E8SRLECA 1998	GEARCASE
E8SRLEDS 1996	GEARCASE
E8SRLEOD 1995	GEARCASE
E8SRLERE 1994	GEARCASE
E8SRLESR 1990	GEARCASE
E8SRLETB 1993	GEARCASE
E8SRLEUC 1997	GEARCASE
E8WREES 1999	GEARCASE
E8WRLEES 1999	GEARCASE
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	GEARCASE
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	GEARCASE
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
HE5FRECA 1998	GEARCASE
HE5FREUR 1997	GEARCASE
HE5FRLECA 1998	GEARCASE
HE5FRLEUR 1997	GEARCASE

HE6FRECA 1998	GEARCASE
HE6FREUR 1997	GEARCASE
HE6FRLECA 1998	GEARCASE
HE6FRLEUR 1997	GEARCASE
HJ5FRECA 1998	GEARCASE
HJ5FREUR 1997	GEARCASE
HJ5FRLECA 1998	GEARCASE
HJ5FRLEUR 1997	GEARCASE
HJ6FRECA 1998	GEARCASE
HJ6FREUR 1997	GEARCASE
HJ6FRLECA 1998	GEARCASE
HJ6FRLEUR 1997	GEARCASE
J3BRCEC 1989	GEARCASE
J3BRESR 1990	GEARCASE
J3RCCM 1988	GEARCASE - 3RC MODELS
J3RCCM 1988	GEARCASE - 4RC & 4RLC MODELS
J3RCUA 1987	GEARCASE - 3RC MODELS
J3RCUA 1987	GEARCASE - 4RC & 4RLC MODELS
J4BRHCCS 1988	GEARCASE
J4BRHCUD 1987	GEARCASE
J4BRHLCCS 1988	GEARCASE
J4BRHLCUD 1987	GEARCASE
J4RCCS 1988	GEARCASE - 3RC MODELS
J4RCCS 1988	GEARCASE - 4RC & 4RLC MODELS
J4RCEC 1989	GEARCASE
J4RCUD 1987	GEARCASE - 3RC MODELS
J4RCUD 1987	GEARCASE - 4RC & 4RLC MODELS
J4RDHCCS 1988	GEARCASE
J4RDHCDE 1986	GEARCASE
J4RDHCEC 1989	GEARCASE
J4RDHCUD 1987	GEARCASE
J4RDHESR 1990	GEARCASE
J4RDHLCCS 1988	GEARCASE
J4RDHLCEC 1989	GEARCASE
J4RDHLCUD 1987	GEARCASE

J4RDHLESR 1990	GEARCASE
J4RESR 1990	GEARCASE
J4RLCCS 1988	GEARCASE - 3RC MODELS
J4RLCCS 1988	GEARCASE - 4RC & 4RLC MODELS
J4RLCEC 1989	GEARCASE
J4RLCUD 1987	GEARCASE - 3RC MODELS
J4RLCUD 1987	GEARCASE - 4RC & 4RLC MODELS
J4RLESR 1990	GEARCASE
J5DRECR 1998	GEARCASE
J5DRLECR 1998	GEARCASE
J6R4SRC	GEARCASE
J6R4SRC - FR	17-1_BOÎTIER D'ENGRENAGES
J6R4STS	GEARCASE
J6R4STS - FR	17-1_BOÎTIER D'ENGRENAGES
J6RCCS 1988	GEARCASE
J6RCDE 1986	GEARCASE
J6RCEC 1989	GEARCASE
J6RCUD 1987	GEARCASE
J6RECR 1998	GEARCASE
J6REDS 1996	GEARCASE
J6REEA 1999	GEARCASE
J6REOD 1995	GEARCASE
J6RERE 1994	GEARCASE
J6RESR 1990	GEARCASE
J6RETB 1993	GEARCASE
J6REUC 1997	GEARCASE
J6RL4SRC	GEARCASE
J6RL4SRC - FR	17-1_BOÎTIER D'ENGRENAGES
J6RL4STS	GEARCASE
J6RL4STS - FR	17-1_BOÎTIER D'ENGRENAGES
J6RLCCS 1988	GEARCASE
J6RLCDE 1986	GEARCASE
J6RLCEC 1989	GEARCASE
J6RLCUD 1987	GEARCASE
J6RLECR 1998	GEARCASE

J6RLEDS 1996	GEARCASE
J6RLEEA 1999	GEARCASE
J6RLEOD 1995	GEARCASE
J6RLERE 1994	GEARCASE
J6RLESR 1990	GEARCASE
J6RLETB 1993	GEARCASE
J6RLEUC 1997	GEARCASE
J6RLSIB rope start, tiller, 20 in shaft 2001	GEARCASE
J6RLSOC	GEARCASE
J6RLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J6RLSRS	GEARCASE
J6RLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J6RLSTD	GEARCASE
J6RLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	GEARCASE
J6RSIB rope start, tiller, 15 in shaft 2001	GEARCASE
J6RSOC	GEARCASE
J6RSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J6RSRS	GEARCASE
J6RSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J6RSTD	GEARCASE
J6RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	GEARCASE
J6SLCCS 1988	GEARCASE
J6SLCDE 1986	GEARCASE
J6SLCEC 1989	GEARCASE
J6SLCUD 1987	GEARCASE
J6SLEDS 1996	GEARCASE
J6SLEOD 1995	GEARCASE
J6SLERE 1994	GEARCASE
J6SLESR 1990	GEARCASE
J6SLETB 1993	GEARCASE
J8DREEA 1999	GEARCASE

J8RCCS 1988	GEARCASE
J8RCDE 1986	GEARCASE
J8RCEC 1989	GEARCASE
J8RCUD 1987	GEARCASE
J8RECR 1998	GEARCASE
J8REDS 1996	GEARCASE
J8REEM 1999	GEARCASE
J8REOD 1995	GEARCASE
J8RERE 1994	GEARCASE
J8RESR 1990	GEARCASE
J8RETB 1993	GEARCASE
J8REUC 1997	GEARCASE
J8RLCCS 1988	GEARCASE
J8RLCDE 1986	GEARCASE
J8RLCEC 1989	GEARCASE
J8RLCUD 1987	GEARCASE
J8RLECR 1998	GEARCASE
J8RLEDS 1996	GEARCASE
J8RLEEM 1999	GEARCASE
J8RLEOD 1995	GEARCASE
J8RLERE 1994	GEARCASE
J8RLESR 1990	GEARCASE
J8RLETB 1993	GEARCASE
J8RLEUC 1997	GEARCASE
J8RLSIE rope start, tiller, 20 in shaft 2001	GEARCASE
J8RLSOR	GEARCASE
J8RLSOR - FR	27-1_BOÎTIER D'ENGRENAGES
J8RLSRC	GEARCASE
J8RLSRC - FR	27-1_BOÎTIER D'ENGRENAGES
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J8RLSTS	GEARCASE
J8RLSTS - FR	27-1_BOÎTIER D'ENGRENAGES
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	GEARCASE
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	GEARCASE
J8RSIE rope start, tiller, 15 in shaft 2001	GEARCASE

J8RSOR	GEARCASE
J8RSOR - FR	27-1_BOÎTIER D'ENGRENAGES
J8RSRC	GEARCASE
J8RSRC - FR	27-1_BOÎTIER D'ENGRENAGES
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J8RSTD	GEARCASE
J8RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	GEARCASE
J8RXEEM 1999	GEARCASE
J8RXSIE rope start, tiller, 25 in shaft 2001	GEARCASE
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	GEARCASE
J8SRLCCS 1988	GEARCASE
J8SRLCDE 1986	GEARCASE
J8SRLCEC 1989	GEARCASE
J8SRLCUD 1987	GEARCASE
J8SRLECA 1998	GEARCASE
J8SRLEDS 1996	GEARCASE
J8SRLEOD 1995	GEARCASE
J8SRLERE 1994	GEARCASE
J8SRLESR 1990	GEARCASE
J8SRLETB 1993	GEARCASE
J8SRLEUC 1997	GEARCASE
J8WREES 1999	GEARCASE
J8WRLEES 1999	GEARCASE
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	GEARCASE
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	GEARCASE
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
SJ6REDS 1996	GEARCASE
SJ6RLEDs 1996	GEARCASE
SJ8REDS 1996	GEARCASE
SJ8RLEDs 1996	GEARCASE
TE8RCEC 1989	GEARCASE
TE8RLCEC 1989	GEARCASE
TE8RLESFC 1990	GEARCASE

TJ8RCEC 1989

GEARCASE

TJ8RLCEC 1989

GEARCASE