

Where Used: Part Number 0331430

Model Name	Diagram
C155WTLM 1988	REMOTE CONTROL
C155WTXM 1988	REMOTE CONTROL
CE275TLCDC 1986	REMOTE CONTROL
CE275TLCOS 1985	REMOTE CONTROL
CE275TXCDC 1986	REMOTE CONTROL
CE275TXCOS 1985	REMOTE CONTROL
CE300TLCDC 1986	REMOTE CONTROL
CE300TLCOS 1985	REMOTE CONTROL
CE300TXCDC 1986	REMOTE CONTROL
CE300TXCOS 1985	REMOTE CONTROL
CJ275TLCDC 1986	REMOTE CONTROL
CJ275TLCOS 1985	REMOTE CONTROL
CJ275TXCDC 1986	REMOTE CONTROL
CJ275TXCOS 1985	REMOTE CONTROL
CJ300TLCDC 1986	REMOTE CONTROL
CJ300TLCOS 1985	REMOTE CONTROL
CJ300TXCDC 1986	REMOTE CONTROL
CJ300TXCOS 1985	REMOTE CONTROL
D100WTLM 1988	REMOTE CONTROL
D100WTXM 1988	REMOTE CONTROL
E100STLCCA 1988	REMOTE CONTROL
E100STLCEM 1989	REMOTE CONTROL
E100STLESB 1990	REMOTE CONTROL
E100WMLCDR 1986	REMOTE CONTROL
E100WMLCOC 1985	REMOTE CONTROL
E100WTLCDR 1986	REMOTE CONTROL
E100WTLCOC 1985	REMOTE CONTROL
E100WTLCUA 1987	REMOTE CONTROL
E100WTLESM 1990	REMOTE CONTROL
E100WTLZ 1989	REMOTE CONTROL
E100WTXCDR 1986	REMOTE CONTROL
E100WTXCUA 1987	REMOTE CONTROL
E100WTXESM 1990	REMOTE CONTROL

E100WTXZ 1989	REMOTE CONTROL
E10EESC 1990	REMOTE CONTROL
E10ELESC 1990	REMOTE CONTROL
E10RELESC 1990	REMOTE CONTROL
E10RESC 1990	REMOTE CONTROL
E10RLESC 1990	REMOTE CONTROL
E10SELESC 1990	REMOTE CONTROL
E110MLCCA 1988	REMOTE CONTROL
E110MLCDC 1986	REMOTE CONTROL
E110MLCEM 1989	REMOTE CONTROL
E110MLCUR 1987	REMOTE CONTROL
E110TLCCA 1988	REMOTE CONTROL
E110TLCDC 1986	REMOTE CONTROL
E110TLCDF 1986	REMOTE CONTROL
E110TLCEM 1989	REMOTE CONTROL
E110TLCUR 1987	REMOTE CONTROL
E110TXCCA 1988	REMOTE CONTROL
E110TXCEM 1989	REMOTE CONTROL
E110TXCUR 1987	REMOTE CONTROL
E115MLCOS 1985	REMOTE CONTROL
E115MLESB 1990	REMOTE CONTROL
E115TLCOS 1985	REMOTE CONTROL
E115TLESB 1990	REMOTE CONTROL
E115TXESB 1990	REMOTE CONTROL
E120TLCCA 1988	REMOTE CONTROL
E120TLCDC 1986	REMOTE CONTROL
E120TLCEM 1989	REMOTE CONTROL
E120TLCOS 1985	REMOTE CONTROL
E120TLCUR 1987	REMOTE CONTROL
E120TLESB 1990	REMOTE CONTROL
E120TXCCA 1988	REMOTE CONTROL
E120TXCDC 1986	REMOTE CONTROL
E120TXCEM 1989	REMOTE CONTROL
E120TXCOS 1985	REMOTE CONTROL
E120TXCUR 1987	REMOTE CONTROL

E120TXESB 1990	REMOTE CONTROL
E125ESXESS 1990	REMOTE CONTROL
E125ESXW 1989	REMOTE CONTROL
E125WTPLE 1995	REMOTE CONTROL
E140CXCCS 1988	REMOTE CONTROL
E140CXCEC 1989	REMOTE CONTROL
E140CXESR 1990	REMOTE CONTROL
E140TLCCM 1988	REMOTE CONTROL
E140TLCDC 1986	REMOTE CONTROL
E140TLCEB 1989	REMOTE CONTROL
E140TLCOS 1985	REMOTE CONTROL
E140TLCUA 1987	REMOTE CONTROL
E140TLESE 1990	REMOTE CONTROL
E140TXCCM 1988	REMOTE CONTROL
E140TXCDC 1986	REMOTE CONTROL
E140TXCEB 1989	REMOTE CONTROL
E140TXCOS 1985	REMOTE CONTROL
E140TXCUA 1987	REMOTE CONTROL
E140TXESE 1990	REMOTE CONTROL
E150CXCCA 1988	REMOTE CONTROL
E150CXCEM 1989	REMOTE CONTROL
E150CXESB 1990	REMOTE CONTROL
E150STLCCA 1988	REMOTE CONTROL
E150STLCDC 1986	REMOTE CONTROL
E150STLCEM 1989	REMOTE CONTROL
E150STLCOH 1985	REMOTE CONTROL
E150STLCOS 1985	REMOTE CONTROL
E150STLCUR 1987	REMOTE CONTROL
E150STLESB 1990	REMOTE CONTROL
E150TLCCA 1988	REMOTE CONTROL
E150TLCDC 1986	REMOTE CONTROL
E150TLCEM 1989	REMOTE CONTROL
E150TLCOS 1985	REMOTE CONTROL
E150TLCUR 1987	REMOTE CONTROL
E150TLESB 1990	REMOTE CONTROL

E150TXCCA 1988	REMOTE CONTROL
E150TXCDC 1986	REMOTE CONTROL
E150TXCEM 1989	REMOTE CONTROL
E150TXCOS 1985	REMOTE CONTROL
E150TXCUR 1987	REMOTE CONTROL
E150TXESB 1990	REMOTE CONTROL
E150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	REMOTE CONTROL
E150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	REMOTE CONTROL
E150WTLEOR 1995	REMOTE CONTROL
E150WTLERC 1994	REMOTE CONTROL
E150WTLERV 1994	REMOTE CONTROL
E150WTLETG 1993	REMOTE CONTROL
E150WTLETS 1993	REMOTE CONTROL
E150WTXEOR 1995	REMOTE CONTROL
E150WTXERC 1994	REMOTE CONTROL
E150WTXERV 1994	REMOTE CONTROL
E150WTXETG 1993	REMOTE CONTROL
E150WTXETS 1993	REMOTE CONTROL
E155WTLCDR 1986	REMOTE CONTROL
E155WTLCOG 1985	REMOTE CONTROL
E155WTLCUA 1987	REMOTE CONTROL
E155WTLISM 1990	REMOTE CONTROL
E155WTLZ 1989	REMOTE CONTROL
E155WTXCDR 1986	REMOTE CONTROL
E155WTXCOC 1985	REMOTE CONTROL
E155WTXCUA 1987	REMOTE CONTROL
E155WTXISM 1990	REMOTE CONTROL
E155WTXZ 1989	REMOTE CONTROL
E15EESR 1990	REMOTE CONTROL
E15ELESR 1990	REMOTE CONTROL
E15RELESR 1990	REMOTE CONTROL
E15RESR 1990	REMOTE CONTROL
E15RLESR 1990	REMOTE CONTROL
E175STLCCM 1988	REMOTE CONTROL

E175STLCEB 1989	REMOTE CONTROL
E175STLESE 1990	REMOTE CONTROL
E175TLCCM 1988	REMOTE CONTROL
E175TLCDR 1986	REMOTE CONTROL
E175TLCOC 1985	REMOTE CONTROL
E175TLCUA 1987	REMOTE CONTROL
E175TXCCM 1988	REMOTE CONTROL
E175TXCDR 1986	REMOTE CONTROL
E175TXCEB 1989	REMOTE CONTROL
E175TXCOC 1985	REMOTE CONTROL
E175TXCUA 1987	REMOTE CONTROL
E175TXESE 1990	REMOTE CONTROL
E185ESXESS 1990	REMOTE CONTROL
E185ESXW 1989	REMOTE CONTROL
E185TLCOC 1985	REMOTE CONTROL
E185TXCOC 1985	REMOTE CONTROL
E200CXCCR 1988	REMOTE CONTROL
E200CXCEA 1989	REMOTE CONTROL
E200CXESM 1990	REMOTE CONTROL
E200STLCCM 1988	REMOTE CONTROL
E200STLCEB 1989	REMOTE CONTROL
E200STLCUA 1987	REMOTE CONTROL
E200STLESE 1990	REMOTE CONTROL
E200TXCCR 1988	REMOTE CONTROL
E200TXCEA 1989	REMOTE CONTROL
E200TXCUC 1987	REMOTE CONTROL
E200TXESM 1990	REMOTE CONTROL
E200WPXEEN 1999	REMOTE CONTROL
E200WPXEES 1999	REMOTE CONTROL
E200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	REMOTE CONTROL
E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	REMOTE CONTROL
E20CRCCA 1988	REMOTE CONTROL
E20CRCDC 1986	REMOTE CONTROL
E20CRCOS 1985	REMOTE CONTROL

E20CRCUR 1987	REMOTE CONTROL
E20CRLCCA 1988	REMOTE CONTROL
E20CRLCDC 1986	REMOTE CONTROL
E20CRLCOS 1985	REMOTE CONTROL
E20CRLCUR 1987	REMOTE CONTROL
E20ECCA 1988	REMOTE CONTROL
E20ECDC 1986	REMOTE CONTROL
E20ECEM 1989	REMOTE CONTROL
E20ECOS 1985	REMOTE CONTROL
E20ECUR 1987	REMOTE CONTROL
E20EESB 1990	REMOTE CONTROL
E20ELCCA 1988	REMOTE CONTROL
E20ELCDC 1986	REMOTE CONTROL
E20ELCEM 1989	REMOTE CONTROL
E20ELCOS 1985	REMOTE CONTROL
E20ELCUR 1987	REMOTE CONTROL
E20ELESB 1990	REMOTE CONTROL
E20TECDC 1986	REMOTE CONTROL
E225CLCUB 1987	REMOTE CONTROL
E225XCCE 1988	REMOTE CONTROL
E225XCED 1989	REMOTE CONTROL
E225XCUB 1987	REMOTE CONTROL
E225XCESS 1990	REMOTE CONTROL
E225PLCCE 1988	REMOTE CONTROL
E225PLCED 1989	REMOTE CONTROL
E225PLCUB 1987	REMOTE CONTROL
E225PLESS 1990	REMOTE CONTROL
E225PXCE 1988	REMOTE CONTROL
E225PXCED 1989	REMOTE CONTROL
E225PXCUB 1987	REMOTE CONTROL
E225PXESS 1990	REMOTE CONTROL
E225TLCCE 1988	REMOTE CONTROL
E225TLCED 1989	REMOTE CONTROL
E225TLCUB 1987	REMOTE CONTROL
E225TLESS 1990	REMOTE CONTROL

E225TXCCE 1988	REMOTE CONTROL
E225TXCED 1989	REMOTE CONTROL
E225TXCUB 1987	REMOTE CONTROL
E225TXESS 1990	REMOTE CONTROL
E235STLCOR 1985	REMOTE CONTROL
E235TLCOR 1985	REMOTE CONTROL
E235TXCOR 1985	REMOTE CONTROL
E25ECCM 1988	REMOTE CONTROL
E25ECDR 1986	REMOTE CONTROL
E25ECEB 1989	REMOTE CONTROL
E25ECOC 1985	REMOTE CONTROL
E25ECUA 1987	REMOTE CONTROL
E25EESE 1990	REMOTE CONTROL
E25ELCCM 1988	REMOTE CONTROL
E25ELCDR 1986	REMOTE CONTROL
E25ELCEB 1989	REMOTE CONTROL
E25ELCOC 1985	REMOTE CONTROL
E25ELCUA 1987	REMOTE CONTROL
E25ELESE 1990	REMOTE CONTROL
E25RCCA 1988	REMOTE CONTROL
E25RCDC 1986	REMOTE CONTROL
E25RCOS 1985	REMOTE CONTROL
E25RCUR 1987	REMOTE CONTROL
E25RLCCA 1988	REMOTE CONTROL
E25RLCDC 1986	REMOTE CONTROL
E25RLCOS 1985	REMOTE CONTROL
E25RLCUR 1987	REMOTE CONTROL
E25TECCA 1988	REMOTE CONTROL
E25TECDC 1986	REMOTE CONTROL
E25TECOS 1985	REMOTE CONTROL
E25TECUR 1987	REMOTE CONTROL
E25TELCCA 1988	REMOTE CONTROL
E25TELCDC 1986	REMOTE CONTROL
E25TELCOS 1985	REMOTE CONTROL
E25TELCUR 1987	REMOTE CONTROL

E275CLCUR 1987	REMOTE CONTROL
E275CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275CXCUR 1987	REMOTE CONTROL
E275PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275PLCUR 1987	REMOTE CONTROL
E275PTLCDC 1986	REMOTE CONTROL
E275PTXCDC 1986	REMOTE CONTROL
E275PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E275PXCUR 1987	REMOTE CONTROL
E275TLCOS 1985	REMOTE CONTROL
E275TXCOS 1985	REMOTE CONTROL
E28ESLCEA 1989	REMOTE CONTROL
E28ESLESM 1990	REMOTE CONTROL
E300CLCUR 1987	REMOTE CONTROL
E300CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300CXCEM 1989	REMOTE CONTROL
E300CXCUR 1987	REMOTE CONTROL
E300CXESB 1990	REMOTE CONTROL
E300PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300PLCEM 1989	REMOTE CONTROL
E300PLCUR 1987	REMOTE CONTROL
E300PLESB 1990	REMOTE CONTROL
E300PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
E300PXCEM 1989	REMOTE CONTROL
E300PXCUR 1987	REMOTE CONTROL
E300PXESB 1990	REMOTE CONTROL
E300TLCDC 1986	REMOTE CONTROL
E300TLCOS 1985	REMOTE CONTROL
E300TXCDC 1986	REMOTE CONTROL
E300TXCOS 1985	REMOTE CONTROL
E30ECCE 1988	REMOTE CONTROL
E30ECDM 1986	REMOTE CONTROL
E30ECED 1989	REMOTE CONTROL
E30EOA 1985	REMOTE CONTROL
E30ECUB 1987	REMOTE CONTROL

E30EESS 1990	REMOTE CONTROL
E30ELCCE 1988	REMOTE CONTROL
E30ELCDM 1986	REMOTE CONTROL
E30ELCED 1989	REMOTE CONTROL
E30ELCOA 1985	REMOTE CONTROL
E30ELCUB 1987	REMOTE CONTROL
E30ELESS 1990	REMOTE CONTROL
E30RCCE 1988	REMOTE CONTROL
E30RCDM 1986	REMOTE CONTROL
E30RCOA 1985	REMOTE CONTROL
E30RCUB 1987	REMOTE CONTROL
E30RLCCE 1988	REMOTE CONTROL
E30RLCDM 1986	REMOTE CONTROL
E30RLCOA 1985	REMOTE CONTROL
E30RLCUB 1987	REMOTE CONTROL
E30TECCE 1988	REMOTE CONTROL
E30TECDM 1986	REMOTE CONTROL
E30TECOA 1985	REMOTE CONTROL
E30TECUB 1987	REMOTE CONTROL
E30TELCCE 1988	REMOTE CONTROL
E30TELCDM 1986	REMOTE CONTROL
E30TELCOA 1985	REMOTE CONTROL
E30TELCUB 1987	REMOTE CONTROL
E35AELCDE 1986	REMOTE CONTROL
E35AELCUD 1987	REMOTE CONTROL
E35ARLCDE 1986	REMOTE CONTROL
E35ARLCUD 1987	REMOTE CONTROL
E35RCCE 1988	REMOTE CONTROL
E35RCDM 1986	REMOTE CONTROL
E35RCUB 1987	REMOTE CONTROL
E35RLCCE 1988	REMOTE CONTROL
E35RLCDM 1986	REMOTE CONTROL
E35RLCUB 1987	REMOTE CONTROL
E40AELCCS 1988	REMOTE CONTROL
E40ARLCCS 1988	REMOTE CONTROL

E40ATLCCS 1988	REMOTE CONTROL
E40ECCS 1988	REMOTE CONTROL
E40ECDE 1986	REMOTE CONTROL
E40ECEC 1989	REMOTE CONTROL
E40ECOB 1985	REMOTE CONTROL
E40ECUD 1987	REMOTE CONTROL
E40EESR 1990	REMOTE CONTROL
E40ELCCS 1988	REMOTE CONTROL
E40ELCDE 1986	REMOTE CONTROL
E40ELCEC 1989	REMOTE CONTROL
E40ELCOB 1985	REMOTE CONTROL
E40ELCUD 1987	REMOTE CONTROL
E40ELESR 1990	REMOTE CONTROL
E40RCCS 1988	REMOTE CONTROL
E40RCDE 1986	REMOTE CONTROL
E40RCEC 1989	REMOTE CONTROL
E40RCOB 1985	REMOTE CONTROL
E40RCUD 1987	REMOTE CONTROL
E40RESR 1990	REMOTE CONTROL
E40RLCCS 1988	REMOTE CONTROL
E40RLCDE 1986	REMOTE CONTROL
E40RLCEC 1989	REMOTE CONTROL
E40RLCOB 1985	REMOTE CONTROL
E40RLCUD 1987	REMOTE CONTROL
E40RLESR 1990	REMOTE CONTROL
E40TECCS 1988	REMOTE CONTROL
E40TECDE 1986	REMOTE CONTROL
E40TECEC 1989	REMOTE CONTROL
E40TECOB 1985	REMOTE CONTROL
E40TECUD 1987	REMOTE CONTROL
E40TEESR 1990	REMOTE CONTROL
E40TELCCS 1988	REMOTE CONTROL
E40TELCDE 1986	REMOTE CONTROL
E40TELCEC 1989	REMOTE CONTROL
E40TELCOB 1985	REMOTE CONTROL

E40TELESR 1990	REMOTE CONTROL
E40TLCCS 1988	REMOTE CONTROL
E40TLCDE 1986	REMOTE CONTROL
E40TLCEC 1989	REMOTE CONTROL
E40TLCUD 1987	REMOTE CONTROL
E40TLESR 1990	REMOTE CONTROL
E40TTLCCS 1988	REMOTE CONTROL
E40TTLCEC 1989	REMOTE CONTROL
E40TTLESR 1990	REMOTE CONTROL
E45RCE 1989	REMOTE CONTROL - ELECTRIC START
E45RCEIA 1991	REMOTE CONTROL
E45RCENM 1992	REMOTE CONTROL
E45RCESR 1990	REMOTE CONTROL
E45RCLE 1989	REMOTE CONTROL - ELECTRIC START
E45RCLEIA 1991	REMOTE CONTROL
E45RCLENM 1992	REMOTE CONTROL
E45RCLESR 1990	REMOTE CONTROL
E45WMLE 1989	REMOTE CONTROL - ELECTRIC START
E45WMLEIA 1991	REMOTE CONTROL
E45WMLNEM 1992	REMOTE CONTROL
E45WMLSR 1990	REMOTE CONTROL
E48ESLCCC 1988	REMOTE CONTROL
E48ESLCER 1989	REMOTE CONTROL (CONTINUED)
E48ESLESA 1990	REMOTE CONTROL
E50BECCS 1988	REMOTE CONTROL
E50BECDE 1986	REMOTE CONTROL
E50BECEC 1989	REMOTE CONTROL
E50BECOB 1985	REMOTE CONTROL
E50BECUD 1987	REMOTE CONTROL
E50BEESR 1990	REMOTE CONTROL
E50BELCCS 1988	REMOTE CONTROL
E50BELCDE 1986	REMOTE CONTROL
E50BELCEC 1989	REMOTE CONTROL
E50BELCOB 1985	REMOTE CONTROL
E50BELCUD 1987	REMOTE CONTROL

E50BELESR 1990	REMOTE CONTROL
E50RNLIA 1990	REMOTE CONTROL
E50TELCCS 1988	REMOTE CONTROL
E50TELCDE 1986	REMOTE CONTROL
E50TELCEC 1989	REMOTE CONTROL
E50TELCOB 1985	REMOTE CONTROL
E50TELCUD 1987	REMOTE CONTROL
E50TELESR 1990	REMOTE CONTROL
E50TLCCS 1988	REMOTE CONTROL
E50TLCDE 1986	REMOTE CONTROL
E50TLCEC 1989	REMOTE CONTROL
E50TLCOB 1985	REMOTE CONTROL
E50TLCUD 1987	REMOTE CONTROL
E50TLESR 1990	REMOTE CONTROL
E55RWLE 1989	REMOTE CONTROL - ELECTRIC START
E55RWLEIA 1991	REMOTE CONTROL
E55RWLENM 1992	REMOTE CONTROL
E55RWLESR 1990	REMOTE CONTROL
E60ELCCR 1988	REMOTE CONTROL
E60ELCDS 1986	REMOTE CONTROL
E60ELCEA 1989	REMOTE CONTROL
E60ELCOD 1985	REMOTE CONTROL
E60ELCUC 1987	REMOTE CONTROL
E60ELES 1990	REMOTE CONTROL
E60TLCCR 1988	REMOTE CONTROL
E60TLCDS 1986	REMOTE CONTROL
E60TLCEA 1989	REMOTE CONTROL
E60TLCOD 1985	REMOTE CONTROL
E60TLCUC 1987	REMOTE CONTROL
E60TLES 1990	REMOTE CONTROL
E60TTLCCR 1988	REMOTE CONTROL
E60TTLCEA 1989	REMOTE CONTROL
E60TTLES 1990	REMOTE CONTROL
E65WELSIR Commercial, elec start, 20 in shaft 2001	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH

E65WMLCDR 1986	REMOTE CONTROL
E65WMLCOC 1985	REMOTE CONTROL
E65WMLCUA 1987	REMOTE CONTROL
E65WMLISM 1990	REMOTE CONTROL
E65WMLZ 1989	REMOTE CONTROL
E65WTLCOC 1985	REMOTE CONTROL
E70ELCCA 1988	REMOTE CONTROL
E70ELCDC 1986	REMOTE CONTROL
E70ELCEM 1989	REMOTE CONTROL
E70ELCOS 1985	REMOTE CONTROL
E70ELCUR 1987	REMOTE CONTROL
E70ELESB 1990	REMOTE CONTROL
E70TLCCA 1988	REMOTE CONTROL
E70TLCDC 1986	REMOTE CONTROL
E70TLCEM 1989	REMOTE CONTROL
E70TLCOS 1985	REMOTE CONTROL
E70TLCUR 1987	REMOTE CONTROL
E70TLESB 1990	REMOTE CONTROL
E75ECCA 1988	REMOTE CONTROL
E75ECDC 1986	REMOTE CONTROL
E75ECOS 1985	REMOTE CONTROL
E75ECUR 1987	REMOTE CONTROL
E88MSLCCC 1988	REMOTE CONTROL
E88MSLCER 1989	REMOTE CONTROL
E88MSLESA 1990	REMOTE CONTROL
E90MLCDC 1986	REMOTE CONTROL
E90MLCOS 1985	REMOTE CONTROL
E90MLCUR 1987	REMOTE CONTROL
E90TLCCA 1988	REMOTE CONTROL
E90TLCDC 1986	REMOTE CONTROL
E90TLCEM 1989	REMOTE CONTROL
E90TLCOS 1985	REMOTE CONTROL
E90TLCUR 1987	REMOTE CONTROL
E90TLESB 1990	REMOTE CONTROL
E90TXCDC 1986	REMOTE CONTROL

E90TXCOS 1985	REMOTE CONTROL
HE55WMLM 1996	REMOTE CONTROL
HE55WMLZ 1997	REMOTE CONTROL
HJ55WMLM 1996	REMOTE CONTROL
HJ55WMLZ 1997	REMOTE CONTROL
J100STLCCA 1988	REMOTE CONTROL
J100STLCEM 1989	REMOTE CONTROL
J100STLESB 1990	REMOTE CONTROL
J100WMLCDR 1986	REMOTE CONTROL
J100WMLCOC 1985	REMOTE CONTROL
J100WTLCDR 1986	REMOTE CONTROL
J100WTLCOC 1985	REMOTE CONTROL
J100WTLCUA 1987	REMOTE CONTROL
J100WTLESM 1990	REMOTE CONTROL
J100WTLZ 1989	REMOTE CONTROL
J100WTXCDR 1986	REMOTE CONTROL
J100WTXCUA 1987	REMOTE CONTROL
J100WTXESM 1990	REMOTE CONTROL
J100WTXZ 1989	REMOTE CONTROL
J10EESC 1990	REMOTE CONTROL
J10ELESC 1990	REMOTE CONTROL
J10RELESC 1990	REMOTE CONTROL
J10RESC 1990	REMOTE CONTROL
J10RLESC 1990	REMOTE CONTROL
J10SELESC 1990	REMOTE CONTROL
J110MLCCA 1988	REMOTE CONTROL
J110MLCDC 1986	REMOTE CONTROL
J110MLCEM 1989	REMOTE CONTROL
J110MLCUR 1987	REMOTE CONTROL
J110TLAEM 1989	REMOTE CONTROL
J110TLCCA 1988	REMOTE CONTROL
J110TLCDC 1986	REMOTE CONTROL
J110TLCDF 1986	REMOTE CONTROL
J110TLCEM 1989	REMOTE CONTROL
J110TLCUR 1987	REMOTE CONTROL

J110TXCCA 1988	REMOTE CONTROL
J110TXCEM 1989	REMOTE CONTROL
J110TXCUR 1987	REMOTE CONTROL
J115MLCOS 1985	REMOTE CONTROL
J115MLESB 1990	REMOTE CONTROL
J115TLASB 1990	REMOTE CONTROL
J115TLCOS 1985	REMOTE CONTROL
J115TLESB 1990	REMOTE CONTROL
J115TXESB 1990	REMOTE CONTROL
J120LAEM 1989	REMOTE CONTROL
J120TLASB 1990	REMOTE CONTROL
J120TLCCA 1988	REMOTE CONTROL
J120TLCDC 1986	REMOTE CONTROL
J120TLCEM 1989	REMOTE CONTROL
J120TLCOS 1985	REMOTE CONTROL
J120TLCUR 1987	REMOTE CONTROL
J120TLESB 1990	REMOTE CONTROL
J120TXCCA 1988	REMOTE CONTROL
J120TXCDC 1986	REMOTE CONTROL
J120TXCEM 1989	REMOTE CONTROL
J120TXCOS 1985	REMOTE CONTROL
J120TXCUR 1987	REMOTE CONTROL
J120TXESB 1990	REMOTE CONTROL
J125ESXESS 1990	REMOTE CONTROL
J125ESXW 1989	REMOTE CONTROL
J125WTPLE 1995	REMOTE CONTROL
J140CXCCS 1988	REMOTE CONTROL
J140CXCEC 1989	REMOTE CONTROL
J140CXESR 1990	REMOTE CONTROL
J140TLAEB 1989	REMOTE CONTROL
J140TLASE 1990	REMOTE CONTROL
J140TLCCM 1988	REMOTE CONTROL
J140TLCDC 1986	REMOTE CONTROL
J140TLCEB 1989	REMOTE CONTROL
J140TLCOS 1985	REMOTE CONTROL

J140TLCUA 1987	REMOTE CONTROL
J140TLESE 1990	REMOTE CONTROL
J140TXCCM 1988	REMOTE CONTROL
J140TXCDC 1986	REMOTE CONTROL
J140TXCEB 1989	REMOTE CONTROL
J140XCCOS 1985	REMOTE CONTROL
J140TXCUA 1987	REMOTE CONTROL
J140TXESE 1990	REMOTE CONTROL
J150CXCCA 1988	REMOTE CONTROL
J150CXCEM 1989	REMOTE CONTROL
J150CXESB 1990	REMOTE CONTROL
J150GTLCUR 1987	REMOTE CONTROL
J150STLACA 1988	REMOTE CONTROL
J150STLCCA 1988	REMOTE CONTROL
J150STLCDC 1986	REMOTE CONTROL
J150STLCEM 1989	REMOTE CONTROL
J150STLCOH 1985	REMOTE CONTROL
J150STLCOS 1985	REMOTE CONTROL
J150STLCUR 1987	REMOTE CONTROL
J150STLESB 1990	REMOTE CONTROL
J150TLAEM 1989	REMOTE CONTROL
J150TLASB 1990	REMOTE CONTROL
J150TLCCA 1988	REMOTE CONTROL
J150TLCDC 1986	REMOTE CONTROL
J150TLCEM 1989	REMOTE CONTROL
J150TLCOS 1985	REMOTE CONTROL
J150TLCUR 1987	REMOTE CONTROL
J150TLESB 1990	REMOTE CONTROL
J150TXCCA 1988	REMOTE CONTROL
J150TXCDC 1986	REMOTE CONTROL
J150TXCEM 1989	REMOTE CONTROL
J150TXCOS 1985	REMOTE CONTROL
J150TXCUR 1987	REMOTE CONTROL
J150TXESB 1990	REMOTE CONTROL
J150WPLEES 1999	REMOTE CONTROL

J150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	REMOTE CONTROL
J150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	REMOTE CONTROL
J150WTLEOR 1995	REMOTE CONTROL
J150WTLERC 1994	REMOTE CONTROL
J150WTLERV 1994	REMOTE CONTROL
J150WTLETG 1993	REMOTE CONTROL
J150WTLETS 1993	REMOTE CONTROL
J150WTXEOR 1995	REMOTE CONTROL
J150WTXERC 1994	REMOTE CONTROL
J150WTXERV 1994	REMOTE CONTROL
J150WTXETG 1993	REMOTE CONTROL
J150WTXETS 1993	REMOTE CONTROL
J155WTLCDR 1986	REMOTE CONTROL
J155WTLCOG 1985	REMOTE CONTROL
J155WTLCUA 1987	REMOTE CONTROL
J155WTLISM 1990	REMOTE CONTROL
J155WTLZ 1989	REMOTE CONTROL
J155WTXCDR 1986	REMOTE CONTROL
J155WTXCOC 1985	REMOTE CONTROL
J155WTXCUA 1987	REMOTE CONTROL
J155WTXISM 1990	REMOTE CONTROL
J155WTXZ 1989	REMOTE CONTROL
J15EESR 1990	REMOTE CONTROL
J15ELESR 1990	REMOTE CONTROL
J15RELESR 1990	REMOTE CONTROL
J15RESR 1990	REMOTE CONTROL
J15RLESR 1990	REMOTE CONTROL
J175STLACM 1988	REMOTE CONTROL
J175STLCCM 1988	REMOTE CONTROL
J175STLCEB 1989	REMOTE CONTROL
J175STLESE 1990	REMOTE CONTROL
J175TLCCM 1988	REMOTE CONTROL
J175TLCDR 1986	REMOTE CONTROL
J175TLCOG 1985	REMOTE CONTROL

J175TLCUA 1987	REMOTE CONTROL
J175TXCCM 1988	REMOTE CONTROL
J175TXCDR 1986	REMOTE CONTROL
J175TXCEB 1989	REMOTE CONTROL
J175TXCOC 1985	REMOTE CONTROL
J175TXCUA 1987	REMOTE CONTROL
J175TXESE 1990	REMOTE CONTROL
J185ESXESS 1990	REMOTE CONTROL
J185ESXW 1989	REMOTE CONTROL
J185TLCOC 1985	REMOTE CONTROL
J185TXCOC 1985	REMOTE CONTROL
J200CXCCR 1988	REMOTE CONTROL
J200CXCEA 1989	REMOTE CONTROL
J200CXESM 1990	REMOTE CONTROL
J200STLACM 1988	REMOTE CONTROL
J200STLCCM 1988	REMOTE CONTROL
J200STLCEB 1989	REMOTE CONTROL
J200STLCUA 1987	REMOTE CONTROL
J200STLESE 1990	REMOTE CONTROL
J200TXCCR 1988	REMOTE CONTROL
J200TXCEA 1989	REMOTE CONTROL
J200TXCUC 1987	REMOTE CONTROL
J200TXESM 1990	REMOTE CONTROL
J200WPXEEN 1999	REMOTE CONTROL
J200WPXEES 1999	REMOTE CONTROL
J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	REMOTE CONTROL
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	REMOTE CONTROL
J20CRCCA 1988	REMOTE CONTROL
J20CRCDC 1986	REMOTE CONTROL
J20CRCOS 1985	REMOTE CONTROL
J20CRCUR 1987	REMOTE CONTROL
J20CRLCCA 1988	REMOTE CONTROL
J20CRLCDC 1986	REMOTE CONTROL
J20CRLCOS 1985	REMOTE CONTROL
J20CRLCUR 1987	REMOTE CONTROL

J20ECCA 1988	REMOTE CONTROL
J20ECDC 1986	REMOTE CONTROL
J20ECEM 1989	REMOTE CONTROL
J20ECOS 1985	REMOTE CONTROL
J20ECUR 1987	REMOTE CONTROL
J20EESB 1990	REMOTE CONTROL
J20ELCCA 1988	REMOTE CONTROL
J20ELCDC 1986	REMOTE CONTROL
J20ELCEM 1989	REMOTE CONTROL
J20ELCOS 1985	REMOTE CONTROL
J20ELCUR 1987	REMOTE CONTROL
J20ELESB 1990	REMOTE CONTROL
J20TECDC 1986	REMOTE CONTROL
J225CLCUB 1987	REMOTE CONTROL
J225CXCE 1988	REMOTE CONTROL
J225CXCED 1989	REMOTE CONTROL
J225CXUB 1987	REMOTE CONTROL
J225CXESS 1990	REMOTE CONTROL
J225PLAED 1989	REMOTE CONTROL
J225PLASS 1990	REMOTE CONTROL
J225PLCCE 1988	REMOTE CONTROL
J225PLCED 1989	REMOTE CONTROL
J225PLCUB 1987	REMOTE CONTROL
J225PLESS 1990	REMOTE CONTROL
J225PXCCE 1988	REMOTE CONTROL
J225PXCED 1989	REMOTE CONTROL
J225PXCUB 1987	REMOTE CONTROL
J225PXESS 1990	REMOTE CONTROL
J225TLAED 1989	REMOTE CONTROL
J225TLASS 1990	REMOTE CONTROL
J225TLCCE 1988	REMOTE CONTROL
J225TLCED 1989	REMOTE CONTROL
J225TLCUB 1987	REMOTE CONTROL
J225TLESS 1990	REMOTE CONTROL
J225TXCCE 1988	REMOTE CONTROL

J225TXCED 1989	REMOTE CONTROL
J225TXCUB 1987	REMOTE CONTROL
J225TXESS 1990	REMOTE CONTROL
J235STLCOR 1985	REMOTE CONTROL
J235TLCOR 1985	REMOTE CONTROL
J235TXCOR 1985	REMOTE CONTROL
J25ECCM 1988	REMOTE CONTROL
J25ECDR 1986	REMOTE CONTROL
J25ECEB 1989	REMOTE CONTROL
J25ECOC 1985	REMOTE CONTROL
J25ECUA 1987	REMOTE CONTROL
J25EESE 1990	REMOTE CONTROL
J25ELCCM 1988	REMOTE CONTROL
J25ELCDR 1986	REMOTE CONTROL
J25ELCEB 1989	REMOTE CONTROL
J25ELCOC 1985	REMOTE CONTROL
J25ELCUA 1987	REMOTE CONTROL
J25ELESE 1990	REMOTE CONTROL
J25RCCA 1988	REMOTE CONTROL
J25RCDC 1986	REMOTE CONTROL
J25RCOS 1985	REMOTE CONTROL
J25RCUR 1987	REMOTE CONTROL
J25RLCCA 1988	REMOTE CONTROL
J25RLCDC 1986	REMOTE CONTROL
J25RLCOS 1985	REMOTE CONTROL
J25RLCUR 1987	REMOTE CONTROL
J25TECCA 1988	REMOTE CONTROL
J25TECDC 1986	REMOTE CONTROL
J25TECOS 1985	REMOTE CONTROL
J25TECUR 1987	REMOTE CONTROL
J25TELCCA 1988	REMOTE CONTROL
J25TELCDC 1986	REMOTE CONTROL
J25TELCOS 1985	REMOTE CONTROL
J25TELCUR 1987	REMOTE CONTROL
J275CLCUR 1987	REMOTE CONTROL

J275CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275CXCUR 1987	REMOTE CONTROL
J275PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275PLCUR 1987	REMOTE CONTROL
J275PTLCDC 1986	REMOTE CONTROL
J275PTXCDC 1986	REMOTE CONTROL
J275PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J275PXCUR 1987	REMOTE CONTROL
J275TLCOS 1985	REMOTE CONTROL
J275TXCOS 1985	REMOTE CONTROL
J28ESLCEA 1989	REMOTE CONTROL
J28ESLESM 1990	REMOTE CONTROL
J300CLCUR 1987	REMOTE CONTROL
J300CXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300CXCEM 1989	REMOTE CONTROL
J300CXCUR 1987	REMOTE CONTROL
J300CXESB 1990	REMOTE CONTROL
J300PLCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300PLCEM 1989	REMOTE CONTROL
J300PLCUR 1987	REMOTE CONTROL
J300PLESB 1990	REMOTE CONTROL
J300PXCCA 1988	REMOTE CONTROL - STANDARD ROTATION
J300PXCEM 1989	REMOTE CONTROL
J300PXCUR 1987	REMOTE CONTROL
J300PXESB 1990	REMOTE CONTROL
J300TLCDC 1986	REMOTE CONTROL
J300TLCOS 1985	REMOTE CONTROL
J300TXCDC 1986	REMOTE CONTROL
J300TXCOS 1985	REMOTE CONTROL
J30ECCE 1988	REMOTE CONTROL
J30ECDM 1986	REMOTE CONTROL
J30ECED 1989	REMOTE CONTROL
J30EOA 1985	REMOTE CONTROL
J30ECUB 1987	REMOTE CONTROL
J30EES 1990	REMOTE CONTROL

J30ELCCE 1988	REMOTE CONTROL
J30ELCDM 1986	REMOTE CONTROL
J30ELCED 1989	REMOTE CONTROL
J30ELCOA 1985	REMOTE CONTROL
J30ELCUB 1987	REMOTE CONTROL
J30ELESS 1990	REMOTE CONTROL
J30RCCE 1988	REMOTE CONTROL
J30RCDM 1986	REMOTE CONTROL
J30RCOA 1985	REMOTE CONTROL
J30RCUB 1987	REMOTE CONTROL
J30RLCCE 1988	REMOTE CONTROL
J30RLCDM 1986	REMOTE CONTROL
J30RLCOA 1985	REMOTE CONTROL
J30RLCUB 1987	REMOTE CONTROL
J30TECCE 1988	REMOTE CONTROL
J30TECDM 1986	REMOTE CONTROL
J30TECOA 1985	REMOTE CONTROL
J30TECUB 1987	REMOTE CONTROL
J30TELCCE 1988	REMOTE CONTROL
J30TELCDM 1986	REMOTE CONTROL
J30TELCOA 1985	REMOTE CONTROL
J30TELCUB 1987	REMOTE CONTROL
J35AELCDE 1986	REMOTE CONTROL
J35AELCUD 1987	REMOTE CONTROL
J35ARLCDE 1986	REMOTE CONTROL
J35ARLCUD 1987	REMOTE CONTROL
J35RCCE 1988	REMOTE CONTROL
J35RCDM 1986	REMOTE CONTROL
J35RCUB 1987	REMOTE CONTROL
J35RLCCE 1988	REMOTE CONTROL
J35RLCDM 1986	REMOTE CONTROL
J35RLCUB 1987	REMOTE CONTROL
J40AELCCS 1988	REMOTE CONTROL
J40ARLCCS 1988	REMOTE CONTROL
J40ATLCCS 1988	REMOTE CONTROL

J40ECCS 1988	REMOTE CONTROL
J40ECDE 1986	REMOTE CONTROL
J40ECEC 1989	REMOTE CONTROL
J40ECOB 1985	REMOTE CONTROL
J40ECUD 1987	REMOTE CONTROL
J40EESR 1990	REMOTE CONTROL
J40ELCCS 1988	REMOTE CONTROL
J40ELCDE 1986	REMOTE CONTROL
J40ELCEC 1989	REMOTE CONTROL
J40ELCOB 1985	REMOTE CONTROL
J40ELCUD 1987	REMOTE CONTROL
J40ELESR 1990	REMOTE CONTROL
J40RCCS 1988	REMOTE CONTROL
J40RCDE 1986	REMOTE CONTROL
J40RCEC 1989	REMOTE CONTROL
J40RCOB 1985	REMOTE CONTROL
J40RCUD 1987	REMOTE CONTROL
J40RESR 1990	REMOTE CONTROL
J40RLCCS 1988	REMOTE CONTROL
J40RLCDE 1986	REMOTE CONTROL
J40RLCEC 1989	REMOTE CONTROL
J40RLCOB 1985	REMOTE CONTROL
J40RLCUD 1987	REMOTE CONTROL
J40RLESR 1990	REMOTE CONTROL
J40TECCS 1988	REMOTE CONTROL
J40TECDE 1986	REMOTE CONTROL
J40TECEC 1989	REMOTE CONTROL
J40TECOB 1985	REMOTE CONTROL
J40TECUD 1987	REMOTE CONTROL
J40TEESR 1990	REMOTE CONTROL
J40TELCCS 1988	REMOTE CONTROL
J40TELCDE 1986	REMOTE CONTROL
J40TELCEC 1989	REMOTE CONTROL
J40TELCOB 1985	REMOTE CONTROL
J40TELESR 1990	REMOTE CONTROL

J40TLCCS 1988	REMOTE CONTROL
J40TLCDE 1986	REMOTE CONTROL
J40TLCEC 1989	REMOTE CONTROL
J40TLCUD 1987	REMOTE CONTROL
J40TLESR 1990	REMOTE CONTROL
J40TTLCCS 1988	REMOTE CONTROL
J40TTLCEC 1989	REMOTE CONTROL
J40TTLESR 1990	REMOTE CONTROL
J45RCE 1989	REMOTE CONTROL - ELECTRIC START
J45RCEIA 1991	REMOTE CONTROL
J45RCENM 1992	REMOTE CONTROL
J45RCESR 1990	REMOTE CONTROL
J45RCLE 1989	REMOTE CONTROL - ELECTRIC START
J45RCLEIA 1991	REMOTE CONTROL
J45RCLENM 1992	REMOTE CONTROL
J45RCLESR 1990	REMOTE CONTROL
J45WMLE 1989	REMOTE CONTROL - ELECTRIC START
J45WMLEIA 1991	REMOTE CONTROL
J45WMLNEM 1992	REMOTE CONTROL
J45WMLNEM 1992	REMOTE CONTROL
J45WMLNEM 1992	REMOTE CONTROL
J45WMLNEM 1992	REMOTE CONTROL
J48ESLCCC 1988	REMOTE CONTROL
J48ESLCER 1989	REMOTE CONTROL (CONTINUED)
J48ESLESA 1990	REMOTE CONTROL
J50BECCS 1988	REMOTE CONTROL
J50BECDE 1986	REMOTE CONTROL
J50BECEC 1989	REMOTE CONTROL
J50BECOB 1985	REMOTE CONTROL
J50BECUD 1987	REMOTE CONTROL
J50BEESR 1990	REMOTE CONTROL
J50BELCCS 1988	REMOTE CONTROL
J50BELCDE 1986	REMOTE CONTROL
J50BELCEC 1989	REMOTE CONTROL
J50BELCOB 1985	REMOTE CONTROL
J50BELCUD 1987	REMOTE CONTROL
J50BELESR 1990	REMOTE CONTROL

J50TELCCS 1988	REMOTE CONTROL
J50TELCDE 1986	REMOTE CONTROL
J50TELCEC 1989	REMOTE CONTROL
J50TELCOB 1985	REMOTE CONTROL
J50TELCUD 1987	REMOTE CONTROL
J50TELESR 1990	REMOTE CONTROL
J50TLCCS 1988	REMOTE CONTROL
J50TLCDE 1986	REMOTE CONTROL
J50TLCEC 1989	REMOTE CONTROL
J50TLCOB 1985	REMOTE CONTROL
J50TLCUD 1987	REMOTE CONTROL
J50TLESR 1990	REMOTE CONTROL
J55RWLE 1989	REMOTE CONTROL - ELECTRIC START
J55RWLEIA 1991	REMOTE CONTROL
J55RWLENM 1992	REMOTE CONTROL
J55RWLESR 1990	REMOTE CONTROL
J60ELCCR 1988	REMOTE CONTROL
J60ELCDS 1986	REMOTE CONTROL
J60ELCEA 1989	REMOTE CONTROL
J60ELCOD 1985	REMOTE CONTROL
J60ELCUC 1987	REMOTE CONTROL
J60ELES 1990	REMOTE CONTROL
J60TLCCR 1988	REMOTE CONTROL
J60TLCDS 1986	REMOTE CONTROL
J60TLCEA 1989	REMOTE CONTROL
J60TLCOD 1985	REMOTE CONTROL
J60TLCUC 1987	REMOTE CONTROL
J60TLES 1990	REMOTE CONTROL
J60TTLCCR 1988	REMOTE CONTROL
J60TTLCEA 1989	REMOTE CONTROL
J60TTLES 1990	REMOTE CONTROL
J65WELSIR Commercial, elec start, 20 in shaft 2001	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
J65WMLCDR 1986	REMOTE CONTROL
J65WMLCOC 1985	REMOTE CONTROL

J65WMLCUA 1987	REMOTE CONTROL
J65WMLESM 1990	REMOTE CONTROL
J65WMLZ 1989	REMOTE CONTROL
J65WTLCOC 1985	REMOTE CONTROL
J70ELCCA 1988	REMOTE CONTROL
J70ELCDC 1986	REMOTE CONTROL
J70ELCEM 1989	REMOTE CONTROL
J70ELCOS 1985	REMOTE CONTROL
J70ELCUR 1987	REMOTE CONTROL
J70ELESB 1990	REMOTE CONTROL
J70TLCCA 1988	REMOTE CONTROL
J70TLCDC 1986	REMOTE CONTROL
J70TLCEM 1989	REMOTE CONTROL
J70TLCOS 1985	REMOTE CONTROL
J70TLCUR 1987	REMOTE CONTROL
J70TLESB 1990	REMOTE CONTROL
J75ECCA 1988	REMOTE CONTROL
J75ECDC 1986	REMOTE CONTROL
J75ECOS 1985	REMOTE CONTROL
J75ECUR 1987	REMOTE CONTROL
J88MSLCCC 1988	REMOTE CONTROL
J88MSLCER 1989	REMOTE CONTROL
J88MSLESA 1990	REMOTE CONTROL
J90MLCDC 1986	REMOTE CONTROL
J90MLCOS 1985	REMOTE CONTROL
J90MLCUR 1987	REMOTE CONTROL
J90TLAEM 1989	REMOTE CONTROL
J90TLASB 1990	REMOTE CONTROL
J90TLCCA 1988	REMOTE CONTROL
J90TLCDC 1986	REMOTE CONTROL
J90TLCEM 1989	REMOTE CONTROL
J90TLCOS 1985	REMOTE CONTROL
J90TLCUR 1987	REMOTE CONTROL
J90TLESB 1990	REMOTE CONTROL
J90TXCDC 1986	REMOTE CONTROL

J90TXCOS 1985	REMOTE CONTROL
N65WMLM 1988	REMOTE CONTROL
REMOTE CONTROL 1995	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROL 1996	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
REMOTE CONTROLS	REMOTE CONTROL - SURFACE MOUNT WITH KEY SWITCH
REMOTE CONTROLS 1991	REMOTE CONTROL
REMOTE CONTROLS 1992	REMOTE CONTROL
REMOTE CONTROLS 1993	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROLS 1994	REMOTE CONTROL - SIDE MOUNT - PREWIRED
REMOTE CONTROLS 1997	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
REMOTE CONTROLS 1998	REMOTE CONTROL -- SIDE MOUNT -- KEY SWITCH
REMOTE CONTROLS 1999	REMOTE CONTROL -- SIDE MOUNT -- KEY SWITCH
REMOTE CONTROLS 2000	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH (SYSTEM CHECK)
REMOTE CONTROLS and CABLES	REMOTE CONTROL - SIDE MOUNT - KEY SWITCH
SE125WTPLJ 1997	REMOTE CONTROL
SE125WTPLN 1998	REMOTE CONTROL
SE125WTPLV 1996	REMOTE CONTROL
SE125WTPXJ 1997	REMOTE CONTROL
SE125WTPXN 1998	REMOTE CONTROL
SE125WTPXV 1996	REMOTE CONTROL
SE150WTPLB 1996	REMOTE CONTROL
SE150WTPLT 1997	REMOTE CONTROL
SE150WTPLT4 1997	REMOTE CONTROL
SE150WTPLY 1998	REMOTE CONTROL
SE150WTPXB 1996	REMOTE CONTROL
SE150WTPXT 1997	REMOTE CONTROL
SE150WTPXT4 1997	REMOTE CONTROL
SE150WTPXY 1998	REMOTE CONTROL
SE200WTPLA 1996	REMOTE CONTROL
SE200WTPLG 1998	REMOTE CONTROL
SE200WTPLS 1997	REMOTE CONTROL
SE200WTPXA 1996	REMOTE CONTROL
SE200WTPXG 1998	REMOTE CONTROL
SE200WTPXS 1997	REMOTE CONTROL

SJ125WTPLJ 1997	REMOTE CONTROL
SJ125WTPLN 1998	REMOTE CONTROL
SJ125WTPLV 1996	REMOTE CONTROL
SJ125WTPXJ 1997	REMOTE CONTROL
SJ125WTPXN 1998	REMOTE CONTROL
SJ125WTPXV 1996	REMOTE CONTROL
SJ150WTPLB 1996	REMOTE CONTROL
SJ150WTPLT 1997	REMOTE CONTROL
SJ150WTPLT4 1997	REMOTE CONTROL
SJ150WTPLY 1998	REMOTE CONTROL
SJ150WTPXB 1996	REMOTE CONTROL
SJ150WTPXT 1997	REMOTE CONTROL
SJ150WTPXT4 1997	REMOTE CONTROL
SJ150WTPXY 1998	REMOTE CONTROL
SJ200WTPLA 1996	REMOTE CONTROL
SJ200WTPLG 1998	REMOTE CONTROL
SJ200WTPLS 1997	REMOTE CONTROL
SJ200WTPXA 1996	REMOTE CONTROL
SJ200WTPXG 1998	REMOTE CONTROL
SJ200WTPXS 1997	REMOTE CONTROL
T65WMLM 1988	REMOTE CONTROL
TE10ELESC 1990	REMOTE CONTROL
TE10RELESC 1990	REMOTE CONTROL
TE10RLESC 1990	REMOTE CONTROL
TE110TLCEM 1989	REMOTE CONTROL
TE110TLESF 1989	REMOTE CONTROL
TE110TXCEM 1989	REMOTE CONTROL
TE115TLESB 1990	REMOTE CONTROL
TE120TXCEM 1989	REMOTE CONTROL
TE150SLCEM 1989	REMOTE CONTROL
TE150SLESB 1990	REMOTE CONTROL
TE150TXCEM 1989	REMOTE CONTROL
TE200TXCEA 1989	REMOTE CONTROL
TE25ELCEB 1989	REMOTE CONTROL
TE25ELESE 1990	REMOTE CONTROL

TE25ELESF 1989	REMOTE CONTROL
TE30ELCED 1989	REMOTE CONTROL
TE30ELESF 1989	REMOTE CONTROL
TE30ELESS 1990	REMOTE CONTROL
TE40ELCEC 1989	REMOTE CONTROL
TE40ELESR 1990	REMOTE CONTROL
TE40TELESF 1990	REMOTE CONTROL
TE40TELESR 1990	REMOTE CONTROL
TE50TLCEC 1989	REMOTE CONTROL
TE50TLESF 1989	REMOTE CONTROL
TE50TLESF 1990	REMOTE CONTROL
TE50TLESR 1990	REMOTE CONTROL
TE60TLCEA 1989	REMOTE CONTROL
TE60TLESF 1989	REMOTE CONTROL
TE60TLESF 1990	REMOTE CONTROL
TE60TLESM 1990	REMOTE CONTROL
TE70TLCEM 1989	REMOTE CONTROL
TE70TLESB 1990	REMOTE CONTROL
TE70TLESF 1989	REMOTE CONTROL
TE70TLESF 1990	REMOTE CONTROL
TE90TLCEM 1989	REMOTE CONTROL
TE90TLESB 1990	REMOTE CONTROL
TE90TLESF 1989	REMOTE CONTROL
TE90TLESF 1990	REMOTE CONTROL
TJ10ELESC 1990	REMOTE CONTROL
TJ10RELESC 1990	REMOTE CONTROL
TJ10RLESC 1990	REMOTE CONTROL
TJ110TLCEM 1989	REMOTE CONTROL
TJ110TXCEM 1989	REMOTE CONTROL
TJ115TLESB 1990	REMOTE CONTROL
TJ120TXCEM 1989	REMOTE CONTROL
TJ150SLCEM 1989	REMOTE CONTROL
TJ150SLESB 1990	REMOTE CONTROL
TJ150TXCEM 1989	REMOTE CONTROL
TJ200TXCEA 1989	REMOTE CONTROL

TJ25ELCEB 1989	REMOTE CONTROL
TJ25ELESE 1990	REMOTE CONTROL
TJ25ELESF 1989	REMOTE CONTROL
TJ30ELCED 1989	REMOTE CONTROL
TJ30ELESF 1989	REMOTE CONTROL
TJ30ELESS 1990	REMOTE CONTROL
TJ40ELCEC 1989	REMOTE CONTROL
TJ40ELESF 1990	REMOTE CONTROL
TJ40ELESR 1990	REMOTE CONTROL
TJ40TELESF 1990	REMOTE CONTROL
TJ40TELESR 1990	REMOTE CONTROL
TJ50TLCEC 1989	REMOTE CONTROL
TJ50TLESF 1989	REMOTE CONTROL
TJ50TLESF 1990	REMOTE CONTROL
TJ50TLESR 1990	REMOTE CONTROL
TJ60TLCEA 1989	REMOTE CONTROL
TJ60TLESF 1989	REMOTE CONTROL
TJ60TLESF 1990	REMOTE CONTROL
TJ60TLESM 1990	REMOTE CONTROL
TJ70TLCEM 1989	REMOTE CONTROL
TJ70TLESB 1990	REMOTE CONTROL
TJ70TLESF 1989	REMOTE CONTROL
TJ70TLESF 1990	REMOTE CONTROL
TJ90TLCEM 1989	REMOTE CONTROL
TJ90TLESB 1990	REMOTE CONTROL
VE100SLESB 1990	REMOTE CONTROL
VE115TLESB 1990	REMOTE CONTROL
VE115TXESB 1990	REMOTE CONTROL
VE120TLESB 1990	REMOTE CONTROL
VE120TXESB 1990	REMOTE CONTROL
VE140LESE 1990	REMOTE CONTROL
VE140TXESE 1990	REMOTE CONTROL
VE150SLESB 1990	REMOTE CONTROL
VE150TLESB 1990	REMOTE CONTROL
VE150TXESB 1990	REMOTE CONTROL

VE175SLESE 1990	REMOTE CONTROL
VE175TXESE 1990	REMOTE CONTROL
VE200SLESE 1990	REMOTE CONTROL
VE200TXESM 1990	REMOTE CONTROL
VE225PLESS 1990	REMOTE CONTROL
VE225PXESS 1990	REMOTE CONTROL
VE225TLESS 1990	REMOTE CONTROL
VE225TXESS 1990	REMOTE CONTROL
VE25ELESE 1990	REMOTE CONTROL
VE28ESLCEA 1989	REMOTE CONTROL
VE28ESLESM 1990	REMOTE CONTROL
VE30EESS 1990	REMOTE CONTROL
VE30ELESS 1990	REMOTE CONTROL
VE40EESR 1990	REMOTE CONTROL
VE40ELESR 1990	REMOTE CONTROL
VE40TELESR 1990	REMOTE CONTROL
VE40TLESR 1990	REMOTE CONTROL
VE48ESLCCC 1988	REMOTE CONTROL
VE48ESLCER 1989	REMOTE CONTROL (CONTINUED)
VE48ESLESA 1990	REMOTE CONTROL
VE50BEESR 1990	REMOTE CONTROL
VE50BELESR 1990	REMOTE CONTROL
VE50TLESR 1990	REMOTE CONTROL
VE60ELESM 1990	REMOTE CONTROL
VE60TLESM 1990	REMOTE CONTROL
VE70ELESB 1990	REMOTE CONTROL
VE70TLESB 1990	REMOTE CONTROL
VE88MSLCCC 1988	REMOTE CONTROL
VE88MSLCER 1989	REMOTE CONTROL
VE88MSLESA 1990	REMOTE CONTROL
VE90MLESB 1990	REMOTE CONTROL
VE90TLESB 1990	REMOTE CONTROL
VJ100SLESB 1990	REMOTE CONTROL
VJ115TLASB 1990	REMOTE CONTROL
VJ115TLESB 1990	REMOTE CONTROL

VJ115TXESB 1990	REMOTE CONTROL
VJ120TLASB 1990	REMOTE CONTROL
VJ120TLESB 1990	REMOTE CONTROL
VJ120TXESB 1990	REMOTE CONTROL
VJ140TLASE 1990	REMOTE CONTROL
VJ140TLESE 1990	REMOTE CONTROL
VJ140TXESE 1990	REMOTE CONTROL
VJ150SLESB 1990	REMOTE CONTROL
VJ150TLESB 1990	REMOTE CONTROL
VJ150TXESB 1990	REMOTE CONTROL
VJ175SLESE 1990	REMOTE CONTROL
VJ175TXESE 1990	REMOTE CONTROL
VJ200SLESE 1990	REMOTE CONTROL
VJ200TXESM 1990	REMOTE CONTROL
VJ225PLESS 1990	REMOTE CONTROL
VJ225PXESS 1990	REMOTE CONTROL
VJ225TLASS 1990	REMOTE CONTROL
VJ225TLESS 1990	REMOTE CONTROL
VJ225TXESS 1990	REMOTE CONTROL
VJ25ELESE 1990	REMOTE CONTROL
VJ28ESLCEA 1989	REMOTE CONTROL
VJ28ESLESM 1990	REMOTE CONTROL
VJ30EESS 1990	REMOTE CONTROL
VJ30ELESS 1990	REMOTE CONTROL
VJ40EESR 1990	REMOTE CONTROL
VJ40ELESR 1990	REMOTE CONTROL
VJ40TELESR 1990	REMOTE CONTROL
VJ40TLESR 1990	REMOTE CONTROL
VJ48ESLCCC 1988	REMOTE CONTROL
VJ48ESLCER 1989	REMOTE CONTROL (CONTINUED)
VJ48ESLESA 1990	REMOTE CONTROL
VJ50BEESR 1990	REMOTE CONTROL
VJ50BELESR 1990	REMOTE CONTROL
VJ50TLESR 1990	REMOTE CONTROL
VJ60ELESM 1990	REMOTE CONTROL

VJ60TLESM 1990	REMOTE CONTROL
VJ70ELESB 1990	REMOTE CONTROL
VJ70TLESB 1990	REMOTE CONTROL
VJ88MSLCCC 1988	REMOTE CONTROL
VJ88MSLCER 1989	REMOTE CONTROL
VJ88MSLESA 1990	REMOTE CONTROL
VJ90MLESB 1990	REMOTE CONTROL
VJ90TLASB 1990	REMOTE CONTROL
VJ90TLESB 1990	REMOTE CONTROL
W100WTLM 1988	REMOTE CONTROL
W100WTXM 1988	REMOTE CONTROL
X155WTLM 1988	REMOTE CONTROL
X155WTXM 1988	REMOTE CONTROL