

Where Used: Part Number 0331626

Model Name	Diagram
BE20SEECB 1998	IGNITION
BE20SEEDA 1996	IGNITION
BE20SEEUM 1997	IGNITION
BE20SELECB 1998	IGNITION
BE20SELEDA 1996	IGNITION
BE20SELEUM 1997	IGNITION
BE25EECE 1998	IGNITION
BE25EEDM 1996	IGNITION
BE25EEUB 1997	IGNITION
BE25ELECE 1998	IGNITION
BE25ELEDM 1996	IGNITION
BE25ELEUB 1997	IGNITION
BE25EREDEC 1996	IGNITION
BE25ERLEDC 1996	IGNITION
BE30EECS 1998	IGNITION
BE30EEDE 1996	IGNITION
BE30EEUD 1997	IGNITION
BE30ELECS 1998	IGNITION
BE30ELEDE 1996	IGNITION
BE30ELEUD 1997	IGNITION
BJ20SEECB 1998	IGNITION
BJ20SEEDA 1996	IGNITION
BJ20SEEUM 1997	IGNITION
BJ20SELECB 1998	IGNITION
BJ20SELEDA 1996	IGNITION
BJ20SELEUM 1997	IGNITION
BJ25EECE 1998	IGNITION
BJ25EEDM 1996	IGNITION
BJ25EEED 1999	IGNITION
BJ25EEEN 1999	IGNITION
BJ25EEUB 1997	IGNITION
BJ25ELECE 1998	IGNITION
BJ25ELEDM 1996	IGNITION

BJ25ELEED 1999	IGNITION
BJ25ELEEN 1999	IGNITION
BJ25ELEUB 1997	IGNITION
BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ25EREDC 1996	IGNITION
BJ25ERLED C 1996	IGNITION
BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ25EVLSIC elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ30EECS 1998	IGNITION
BJ30EEDE 1996	IGNITION
BJ30EEEC 1999	IGNITION
BJ30EEEN 1999	IGNITION
BJ30EEUD 1997	IGNITION
BJ30ELECS 1998	IGNITION
BJ30ELEDE 1996	IGNITION
BJ30ELEEC 1999	IGNITION
BJ30ELEEN 1999	IGNITION
BJ30ELEUD 1997	IGNITION
BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ30EVLSIA elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
D25RWA 1988	MAGNETO
D25RWLA 1988	MAGNETO
E10ECCD 1988	IGNITION
E10ECDB 1986	IGNITION
E10ECES 1989	IGNITION
E10ECUE 1987	IGNITION
E10EEIR 1991	IGNITION
E10EEENA 1992	IGNITION

E10EESC 1990	IGNITION
E10ELCCD 1988	IGNITION
E10ELCDB 1986	IGNITION
E10ELCES 1989	IGNITION
E10ELCUE 1987	IGNITION
E10ELEIR 1991	IGNITION
E10ELENA 1992	IGNITION
E10ELESC 1990	IGNITION
E10RCCD 1988	IGNITION
E10RCDB 1986	IGNITION
E10RCES 1989	IGNITION
E10RCUE 1987	IGNITION
E10REIR 1991	IGNITION
E10RELEIR 1991	IGNITION
E10RELENA 1992	IGNITION
E10RELESC 1990	IGNITION
E10RENA 1992	IGNITION
E10RESC 1990	IGNITION
E10RLCCD 1988	IGNITION
E10RLCDB 1986	IGNITION
E10RLCES 1989	IGNITION
E10RLCUE 1987	IGNITION
E10RLEIR 1991	IGNITION
E10RLENA 1992	IGNITION
E10RLESC 1990	IGNITION
E10SELCCD 1988	IGNITION
E10SELcdb 1986	IGNITION
E10SELCES 1989	IGNITION
E10SELCUE 1987	IGNITION
E10SELEIR 1991	IGNITION
E10SELENA 1992	IGNITION
E10SELESC 1990	IGNITION
E15ECCS 1988	IGNITION
E15ECDE 1986	IGNITION
E15ECEC 1989	IGNITION

E15ECUD 1987	IGNITION
E15EEIA 1991	IGNITION
E15EENM 1992	IGNITION
E15EESR 1990	IGNITION
E15ELCCS 1988	IGNITION
E15ELCDE 1986	IGNITION
E15ELCEC 1989	IGNITION
E15ELCUD 1987	IGNITION
E15ELEIA 1991	IGNITION
E15ELENM 1992	IGNITION
E15ELESR 1990	IGNITION
E15RCCS 1988	IGNITION
E15RCDE 1986	IGNITION
E15RCEC 1989	IGNITION
E15RCUD 1987	IGNITION
E15REIA 1991	IGNITION
E15RELEIA 1991	IGNITION
E15RELENM 1992	IGNITION
E15RELESR 1990	IGNITION
E15RENM 1992	IGNITION
E15RESR 1990	IGNITION
E15RLCCS 1988	IGNITION
E15RLCDE 1986	IGNITION
E15RLCEC 1989	IGNITION
E15RLCUD 1987	IGNITION
E15RLEIA 1991	IGNITION
E15RLENM 1992	IGNITION
E15RLESR 1990	IGNITION
E20CRCCA 1988	IGNITION
E20CRLCCA 1988	IGNITION
E20ECCA 1988	IGNITION
E20EEOR 1995	IGNITION
E20EERC 1994	IGNITION
E20EEETS 1993	IGNITION
E20ELCCA 1988	IGNITION

E20ELEOR 1995	IGNITION
E20ELERC 1994	IGNITION
E20ELETS 1993	IGNITION
E25ECCM 1988	IGNITION
E25EECE 1998	IGNITION
E25EEDM 1996	IGNITION
E25EEOA 1995	IGNITION
E25EERR 1994	IGNITION
E25EETC 1993	IGNITION
E25EEUB 1997	IGNITION
E25ELCCM 1988	IGNITION
E25ELECE 1998	IGNITION
E25ELEDM 1996	IGNITION
E25ELEOA 1995	IGNITION
E25ELERR 1994	IGNITION
E25ELETC 1993	IGNITION
E25ELEUB 1997	IGNITION
E25RCCA 1988	IGNITION
E25RLCCA 1988	IGNITION
E25TECCA 1988	IGNITION
E25TEECB 1998	IGNITION
E25TEEDA 1996	IGNITION
E25TEEOR 1995	IGNITION
E25TEERC 1994	IGNITION
E25TEETS 1993	IGNITION
E25TEEUM 1997	IGNITION
E25TELCCA 1988	IGNITION
E25TELECB 1998	IGNITION
E25TELEDA 1996	IGNITION
E25TELEOR 1995	IGNITION
E25TELETS 1993	IGNITION
E25TELEUM 1997	IGNITION
E28ESLCCR 1988	IGNITION
E28ESLEDR 1996	IGNITION
E28ESLEOC 1995	IGNITION

E28ESLERS	1994	IGNITION
E28ESLETD	1993	IGNITION
E30ECCE	1988	IGNITION
E30EECS	1998	IGNITION
E30EEDE	1996	IGNITION
E30EEOB	1995	IGNITION
E30EERM	1994	IGNITION
E30EETA	1993	IGNITION
E30EEUD	1997	IGNITION
E30ELCCE	1988	IGNITION
E30ELECS	1998	IGNITION
E30ELEDE	1996	IGNITION
E30ELEOB	1995	IGNITION
E30ELERM	1994	IGNITION
E30ELETA	1993	IGNITION
E30ELEUD	1997	IGNITION
E30RCCE	1988	IGNITION
E30RLCCE	1988	IGNITION
E30TECCE	1988	IGNITION
E30TEECS	1998	IGNITION
E30TEEDE	1996	IGNITION
E30TEEOB	1995	IGNITION
E30TEERM	1994	IGNITION
E30TEETA	1993	IGNITION
E30TEEUD	1997	IGNITION
E30TELCCCE	1988	IGNITION
E30TELECB	1998	IGNITION
E30TELEDE	1996	IGNITION
E30TELEOB	1995	IGNITION
E30TELERM	1994	IGNITION
E30TELETA	1993	IGNITION
E30TELEUD	1997	IGNITION
E35AELCUD	1987	IGNITION SYSTEM
E35ARLCUD	1987	IGNITION SYSTEM
E35RCCE	1988	IGNITION

E35RLCCE 1988	IGNITION
E40AELCCS 1988	IGNITION SYSTEM
E40ARLCCS 1988	IGNITION SYSTEM
E40ATLCCS 1988	IGNITION SYSTEM
E40ECCS 1988	IGNITION SYSTEM
E40ECUD 1987	IGNITION SYSTEM
E40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELCCS 1988	IGNITION SYSTEM
E40ELCUD 1987	IGNITION SYSTEM
E40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RCCS 1988	IGNITION SYSTEM
E40RCUD 1987	IGNITION SYSTEM
E40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLCCS 1988	IGNITION SYSTEM
E40RLCUD 1987	IGNITION SYSTEM
E40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TECCS 1988	IGNITION SYSTEM
E40TECUD 1987	IGNITION SYSTEM
E40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELCCS 1988	IGNITION SYSTEM
E40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLCCS 1988	IGNITION SYSTEM
E40TLCUD 1987	IGNITION SYSTEM

E40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLLCCS 1988	IGNITION SYSTEM
E40TTEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E48ESLEDC 1996	IGNITION SYSTEM
E48ESLEOS 1995	IGNITION SYSTEM
E48ESLERD 1994	IGNITION SYSTEM
E4RDHCCS 1988	MAGNETO
E4RDHCUD 1987	MAGNETO
E4RDHLCCS 1988	MAGNETO
E4RDHLCUD 1987	MAGNETO
E50BECCS 1988	IGNITION SYSTEM
E50BECUD 1987	IGNITION SYSTEM
E50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELCCS 1988	IGNITION SYSTEM
E50BELCUD 1987	IGNITION SYSTEM
E50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TELCCS 1988	IGNITION SYSTEM
E50TELCUD 1987	IGNITION SYSTEM
E50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLCCS 1988	IGNITION SYSTEM
E50TLCUD 1987	IGNITION SYSTEM
E50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY

E50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E6RCEC 1989	IGNITION
E6RLCEC 1989	IGNITION
E6SLCEC 1989	IGNITION
E8RCEC 1989	IGNITION
E8RLCEC 1989	IGNITION
E8SRLCEC 1989	IGNITION
HE25TELEDA 1996	IGNITION
HE55WMLM 1996	IGNITION SYSTEM
HE55WMLZ 1997	IGNITION SYSTEM
HJ25TELEDA 1996	IGNITION
HJ55WMLM 1996	IGNITION SYSTEM
HJ55WMLZ 1997	IGNITION SYSTEM
J10ECCD 1988	IGNITION
J10ECDB 1986	IGNITION
J10ECES 1989	IGNITION
J10ECUE 1987	IGNITION
J10EEIR 1991	IGNITION
J10EENA 1992	IGNITION
J10EESC 1990	IGNITION
J10ELCCD 1988	IGNITION
J10ELCDB 1986	IGNITION
J10ELCES 1989	IGNITION
J10ELCUE 1987	IGNITION
J10ELEIR 1991	IGNITION
J10ELENA 1992	IGNITION
J10ELESC 1990	IGNITION
J10RCCD 1988	IGNITION
J10RCDB 1986	IGNITION
J10RCES 1989	IGNITION
J10RCUE 1987	IGNITION
J10REIR 1991	IGNITION
J10RELEIR 1991	IGNITION
J10RELENA 1992	IGNITION

J10RELESC 1990	IGNITION
J10RENA 1992	IGNITION
J10RESC 1990	IGNITION
J10RLCCD 1988	IGNITION
J10RLCDB 1986	IGNITION
J10RLCES 1989	IGNITION
J10RLCUE 1987	IGNITION
J10RLEIR 1991	IGNITION
J10RLENA 1992	IGNITION
J10RLESC 1990	IGNITION
J10SELCCD 1988	IGNITION
J10SELCDB 1986	IGNITION
J10SELCES 1989	IGNITION
J10SELCUE 1987	IGNITION
J10SELEIR 1991	IGNITION
J10SELENA 1992	IGNITION
J10SELESC 1990	IGNITION
J15ECCS 1988	IGNITION
J15ECDE 1986	IGNITION
J15ECEC 1989	IGNITION
J15ECUD 1987	IGNITION
J15EEIA 1991	IGNITION
J15EENM 1992	IGNITION
J15EESR 1990	IGNITION
J15ELCCS 1988	IGNITION
J15ELCDE 1986	IGNITION
J15ELCEC 1989	IGNITION
J15ELCUD 1987	IGNITION
J15ELEIA 1991	IGNITION
J15ELENM 1992	IGNITION
J15ELESR 1990	IGNITION
J15RCCS 1988	IGNITION
J15RCDE 1986	IGNITION
J15RCEC 1989	IGNITION
J15RCUD 1987	IGNITION

J15REIA 1991	IGNITION
J15RELEIA 1991	IGNITION
J15RELENM 1992	IGNITION
J15RELESR 1990	IGNITION
J15RENM 1992	IGNITION
J15RESR 1990	IGNITION
J15RLCCS 1988	IGNITION
J15RLCDE 1986	IGNITION
J15RLCEC 1989	IGNITION
J15RLCUD 1987	IGNITION
J15RLEIA 1991	IGNITION
J15RLENM 1992	IGNITION
J15RLESR 1990	IGNITION
J20CRCCA 1988	IGNITION
J20CRLCCA 1988	IGNITION
J20ECCA 1988	IGNITION
J20EEOR 1995	IGNITION
J20EERC 1994	IGNITION
J20EETS 1993	IGNITION
J20ELCCA 1988	IGNITION
J20ELEOR 1995	IGNITION
J20ELERC 1994	IGNITION
J20ELETS 1993	IGNITION
J25ECCM 1988	IGNITION
J25EECE 1998	IGNITION
J25EEDM 1996	IGNITION
J25EEED 1999	IGNITION
J25EEEN 1999	IGNITION
J25EEOA 1995	IGNITION
J25EERR 1994	IGNITION
J25EETC 1993	IGNITION
J25EEUB 1997	IGNITION
J25ELCCM 1988	IGNITION
J25ELECE 1998	IGNITION
J25ELEDM 1996	IGNITION

J25ELEED 1999	IGNITION
J25ELEEN 1999	IGNITION
J25ELEOA 1995	IGNITION
J25ELERR 1994	IGNITION
J25ELETC 1993	IGNITION
J25ELEUB 1997	IGNITION
J25ELSIC elec start, remote, 20 in shaft 2001	IGNITION
J25ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002	IGNITION
J25ELSOB	IGNITION
J25ELSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSRM	IGNITION
J25ELSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSSS Elec. Start, 20 IN. shaft 2000	IGNITION
J25ELSTA	IGNITION
J25ELSTA - FR	22-5_SYSTÈME D'ALLUMAGE
J25ESIC elec start, remote, 15 in shaft 2001	IGNITION
J25ESSS Elec. Start, 15 IN. shaft 2000	IGNITION
J25EVLSIC elec start, remote, 120 in shaft, wht 2001	IGNITION
J25EVSIC elec start, remote, 15 in shaft, wht 2001	IGNITION
J25GTESOC	IGNITION
J25GTESOC - FR	22-5_SYSTÈME D'ALLUMAGE
J25GTESRS	IGNITION
J25GTESRS - FR	22-5_SYSTÈME D'ALLUMAGE
J25RCCA 1988	IGNITION
J25RLCCA 1988	IGNITION
J25TECCA 1988	IGNITION
J25TEECB 1998	IGNITION
J25TEEDA 1996	IGNITION
J25TEEEE 1999	IGNITION
J25TEEEEN 1999	IGNITION
J25TEEOR 1995	IGNITION
J25TEERC 1994	IGNITION
J25TEETS 1993	IGNITION

J25TEEUM 1997	IGNITION
J25TELCCA 1988	IGNITION
J25TELECB 1998	IGNITION
J25TELEDA 1996	IGNITION
J25TELEEE 1999	IGNITION
J25TELEEN 1999	IGNITION
J25TELEOR 1995	IGNITION
J25TELERC	IGNITION
J25TELETS 1993	IGNITION
J25TELEM 1997	IGNITION
J25TELSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSNF Electric strart, White, Tiller, 20 in., 4 Amp Alt 2002	IGNITION
J25TELSOM	IGNITION
J25TELSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSRA	IGNITION
J25TELSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSSD Elec. Start, Tiller, 20 IN. shaft 2000	IGNITION
J25TELSTR	IGNITION
J25TELSTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESIS elec start, tiller, 15 in shaft 2001	IGNITION
J25TESNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESNF Electric strart, White, Tiller,15 in. shaft, 4 Amp Alt 2002	IGNITION
J25TESOM	IGNITION
J25TESOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESRA	IGNITION
J25TESRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESSD Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION
J25TESTR	IGNITION
J25TESTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TVLSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TVSIS elec start, tiller, 15 in shaft 2001	IGNITION
J28ESLCCR 1988	IGNITION
J28ESLEDR 1996	IGNITION

J28ESLEOC 1995	IGNITION
J28ESLERS 1994	IGNITION
J28ESLETD 1993	IGNITION
J30ECCE 1988	IGNITION
J30EECS 1998	IGNITION
J30EEDE 1996	IGNITION
J30EEEC 1999	IGNITION
J30EEEN 1999	IGNITION
J30EEOB 1995	IGNITION
J30EERM 1994	IGNITION
J30EETA 1993	IGNITION
J30EEUD 1997	IGNITION
J30ELCCE 1988	IGNITION
J30ELECS 1998	IGNITION
J30ELEDE 1996	IGNITION
J30ELEEC 1999	IGNITION
J30ELEEN 1999	IGNITION
J30ELEOB 1995	IGNITION
J30ELERM 1994	IGNITION
J30ELETA 1993	IGNITION
J30ELEUD 1997	IGNITION
J30ELSSA elec start, remote, 20 in shaft 2001	IGNITION
J30ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002	IGNITION
J30ELSOD	IGNITION
J30ELSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSRE	IGNITION
J30ELSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSSR Elec. Start, 20 IN. shaft 2000	IGNITION
J30ELSTB	IGNITION
J30ELSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30ESIA elec start, remote, 15 in shaft 2001	IGNITION
J30ESSR Elec. Start, 15 IN. shaft 2000	IGNITION
J30EVLSIA elec start, remote, 20 in shaft, wht 2001	IGNITION

J30RCCE 1988	IGNITION
J30RLCCE 1988	IGNITION
J30TECCE 1988	IGNITION
J30TEECS 1998	IGNITION
J30TEEDE 1996	IGNITION
J30TEEOB 1995	IGNITION
J30TEERM 1994	IGNITION
J30TEETA 1993	IGNITION
J30TEEUD 1997	IGNITION
J30TELCCCE 1988	IGNITION
J30TELECS 1998	IGNITION
J30TELEDE 1996	IGNITION
J30TELEOB 1995	IGNITION
J30TELERM 1994	IGNITION
J30TELETA 1993	IGNITION
J30TELEUD 1997	IGNITION
J35AELCUD 1987	IGNITION SYSTEM
J35ARLCUD 1987	IGNITION SYSTEM
J35RCCE 1988	IGNITION
J35RLCCE 1988	IGNITION
J40AELCCS 1988	IGNITION SYSTEM
J40ARLCCS 1988	IGNITION SYSTEM
J40ATLCCS 1988	IGNITION SYSTEM
J40ECCS 1988	IGNITION SYSTEM
J40ECUD 1987	IGNITION SYSTEM
J40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELCCS 1988	IGNITION SYSTEM
J40ELCUD 1987	IGNITION SYSTEM
J40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RCCS 1988	IGNITION SYSTEM
J40RCUD 1987	IGNITION SYSTEM

J40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLCCS 1988	IGNITION SYSTEM
J40RLCUD 1987	IGNITION SYSTEM
J40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TECCS 1988	IGNITION SYSTEM
J40TECUD 1987	IGNITION SYSTEM
J40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELCCS 1988	IGNITION SYSTEM
J40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLCCS 1988	IGNITION SYSTEM
J40TLCUD 1987	IGNITION SYSTEM
J40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLCCS 1988	IGNITION SYSTEM
J40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J48ESLEDC 1996	IGNITION SYSTEM
J48ESLEOS 1995	IGNITION SYSTEM
J48ESLERD 1994	IGNITION SYSTEM
J4RDHCCS 1988	MAGNETO
J4RDHCUD 1987	MAGNETO
J4RDHLCCS 1988	MAGNETO
J4RDHLCUD 1987	MAGNETO
J50BECCS 1988	IGNITION SYSTEM
J50BECUD 1987	IGNITION SYSTEM

J50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELCCS 1988	IGNITION SYSTEM
J50BELCUD 1987	IGNITION SYSTEM
J50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELCCS 1988	IGNITION SYSTEM
J50TELCUD 1987	IGNITION SYSTEM
J50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLCCS 1988	IGNITION SYSTEM
J50TLCUD 1987	IGNITION SYSTEM
J50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J6RCEC 1989	IGNITION
J6RLCEC 1989	IGNITION
J6SLCEC 1989	IGNITION
J8RCEC 1989	IGNITION
J8RLCEC 1989	IGNITION
J8SRLCEC 1989	IGNITION
SJ25TEEDA 1996	IGNITION
SJ25TEEUM 1997	IGNITION
SJ30EEDE 1996	IGNITION
SJ30TEEUD 1997	IGNITION
TE10ELCES 1989	IGNITION
TE10ELESC 1990	IGNITION
TE10RELEIR 1991	IGNITION
TE10RELENA 1992	IGNITION

TE10RELESC 1990	IGNITION
TE10RLCES 1989	IGNITION
TE10RLESC 1990	IGNITION
TE15RLCEC 1989	IGNITION
TE25ELETC 1993	IGNITION
TE8RCEC 1989	IGNITION
TE8RLCEC 1989	IGNITION
TJ10ELCES 1989	IGNITION
TJ10ELESC 1990	IGNITION
TJ10RELEIR 1991	IGNITION
TJ10RELENA 1992	IGNITION
TJ10RELESC 1990	IGNITION
TJ10RLCES 1989	IGNITION
TJ10RLESC 1990	IGNITION
TJ15RLCEC 1989	IGNITION
TJ25ELETC 1993	IGNITION
TJ8RCEC 1989	IGNITION
TJ8RLCEC 1989	IGNITION
U25RWA 1988	MAGNETO
U25RWLA 1988	MAGNETO
VE14RCCS 1988	MAGNETO
VE14RCEC 1989	IGNITION
VE25ELETC 1993	IGNITION
VE28ESLCCR 1988	IGNITION
VE30EETA 1993	IGNITION
VE30ELETA 1993	IGNITION
VJ14RCCS 1988	MAGNETO
VJ14RCEC 1989	IGNITION
VJ25ELETC 1993	IGNITION
VJ28ESLCCR 1988	IGNITION
VJ30EETA 1993	IGNITION
VJ30ELETA 1993	IGNITION