

Where Used: Part Number 0332057

Model Name	Diagram
BE3REDS 1996	INTAKE MANIFOLD
BE4BREDS 1996	INTAKE MANIFOLD
BE4BREUC 1997	INTAKE MANIFOLD
BE4BRLEDS 1996	INTAKE MANIFOLD
BE4BRLEUC 1997	INTAKE MANIFOLD
BE4RDHEDS 1996	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
BE4RDHLEDS 1996	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
BE4REDS 1996	INTAKE MANIFOLD
BE4RLEDS 1996	INTAKE MANIFOLD
BJ3REDS 1996	INTAKE MANIFOLD
BJ4BREDS 1996	INTAKE MANIFOLD
BJ4BREUC 1997	INTAKE MANIFOLD
BJ4BRLEDS 1996	INTAKE MANIFOLD
BJ4BRLEUC 1997	INTAKE MANIFOLD
BJ4RDHEDS 1996	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
BJ4RDHLEDS 1996	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
BJ4REDS 1996	INTAKE MANIFOLD
BJ4RLEDS 1996	INTAKE MANIFOLD
E3BRCEC 1989	INTAKE MANIFOLD
E3BRESR 1990	INTAKE MANIFOLD
E3RCCM 1988	INTAKE MANIFOLD
E3RCUA 1987	INTAKE MANIFOLD
E3REIA 1991	INTAKE MANIFOLD
E3RENM 1992	INTAKE MANIFOLD
E3REOD 1995	INTAKE MANIFOLD
E3RERE 1994	INTAKE MANIFOLD
E3RETB 1993	INTAKE MANIFOLD
E3REUC 1997	INTAKE MANIFOLD
E4BRECRJ 1998	INTAKE MANIFOLD
E4BRHCCS 1988	INTAKE MANIFOLD
E4BRHLCCS 1988	INTAKE MANIFOLD
E4BRLECRJ 1998	INTAKE MANIFOLD
E4RCCS 1988	INTAKE MANIFOLD

E4RCEC 1989	INTAKE MANIFOLD
E4RCUD 1987	INTAKE MANIFOLD
E4RDHCCS 1988	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHCEC 1989	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHEIA 1991	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHENM 1992	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHEOD 1995	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHERE 1994	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHESR 1990	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHETB 1993	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLCCS 1988	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLCEC 1989	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLEIA 1991	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLENM 1992	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLEOD 1995	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLERE 1994	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLESR 1990	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4RDHLETB 1993	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
E4REDS 1996	INTAKE MANIFOLD
E4REIA 1991	INTAKE MANIFOLD
E4RENM 1992	INTAKE MANIFOLD
E4REOD 1995	INTAKE MANIFOLD
E4RERE 1994	INTAKE MANIFOLD
E4RESR 1990	INTAKE MANIFOLD
E4RETB 1993	INTAKE MANIFOLD
E4REUC 1997	INTAKE MANIFOLD
E4RLCCS 1988	INTAKE MANIFOLD
E4RLCEC 1989	INTAKE MANIFOLD
E4RLCUD 1987	INTAKE MANIFOLD
E4RLEDs 1996	INTAKE MANIFOLD
E4RLEIA 1991	INTAKE MANIFOLD
E4RLENM 1992	INTAKE MANIFOLD
E4RLEOD 1995	INTAKE MANIFOLD
E4RLERE 1994	INTAKE MANIFOLD
E4RLESR 1990	INTAKE MANIFOLD

E4RLETB 1993	INTAKE MANIFOLD
E4RLEUC 1997	INTAKE MANIFOLD
J3BRCEC 1989	INTAKE MANIFOLD
J3BRESR 1990	INTAKE MANIFOLD
J3RCCM 1988	INTAKE MANIFOLD
J3RCUA 1987	INTAKE MANIFOLD
J3REIA 1991	INTAKE MANIFOLD
J3RENM 1992	INTAKE MANIFOLD
J3REOD 1995	INTAKE MANIFOLD
J3RERE 1994	INTAKE MANIFOLD
J3RETB 1993	INTAKE MANIFOLD
J3REUC 1997	INTAKE MANIFOLD
J4BRECRJ 1998	INTAKE MANIFOLD
J4BRHCCS 1988	INTAKE MANIFOLD
J4BRHLCCS 1988	INTAKE MANIFOLD
J4BRLECRJ 1998	INTAKE MANIFOLD
J4RCCS 1988	INTAKE MANIFOLD
J4RCEC 1989	INTAKE MANIFOLD
J4RCUD 1987	INTAKE MANIFOLD
J4RDHCCS 1988	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHCEC 1989	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHEIA 1991	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHENM 1992	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHEOD 1995	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHERE 1994	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHESR 1990	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHETB 1993	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLCCS 1988	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLCEC 1989	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLEIA 1991	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLENM 1992	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLEOD 1995	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLERE 1994	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLESR 1990	CYLINDER, CRANKCASE, & INTAKE MANIFOLD
J4RDHLETB 1993	CYLINDER, CRANKCASE, & INTAKE MANIFOLD

J4REDS 1996	INTAKE MANIFOLD
J4REEA 1999	INTAKE MANIFOLD
J4REIA 1991	INTAKE MANIFOLD
J4RENM 1992	INTAKE MANIFOLD
J4REOD 1995	INTAKE MANIFOLD
J4RERE 1994	INTAKE MANIFOLD
J4RESR 1990	INTAKE MANIFOLD
J4RETB 1993	INTAKE MANIFOLD
J4REUC 1997	INTAKE MANIFOLD
J4RLCCS 1988	INTAKE MANIFOLD
J4RLCEC 1989	INTAKE MANIFOLD
J4RLCUD 1987	INTAKE MANIFOLD
J4RLEDS 1996	INTAKE MANIFOLD
J4RLEEA 1999	INTAKE MANIFOLD
J4RLEIA 1991	INTAKE MANIFOLD
J4RLENM 1992	INTAKE MANIFOLD
J4RLEOD 1995	INTAKE MANIFOLD
J4RLERE 1994	INTAKE MANIFOLD
J4RLESR 1990	INTAKE MANIFOLD
J4RLETB 1993	INTAKE MANIFOLD
J4RLEUC 1997	INTAKE MANIFOLD
J4RLSIB Rope Start, Tiller, 20 IN. shaft 2001	INTAKE MANIFOLD
J4RLSSM Rope Start, Tiller, 20 IN. shaft 2000	INTAKE MANIFOLD
J4RSIB Rope Start, Tiller, 15 IN. shaft 2001	INTAKE MANIFOLD
J4RSSM Rope Start, Tiller, 15 IN. shaft 2000	INTAKE MANIFOLD
SJ3REDS 1996	INTAKE MANIFOLD
SJ4REDS 1996	INTAKE MANIFOLD
SJ4RLEDS 1996	INTAKE MANIFOLD