

Where Used: Part Number 0332494

Model Name	Diagram
BE40EECR 1998	GEARCASE
BE40EEDS 1996	GEARCASE
BE40EEUC 1997	GEARCASE
BE40ELECR 1998	GEARCASE
BE40ELEDS 1996	GEARCASE
BE40ELEUC 1997	GEARCASE
BE40TLECR 1998	GEARCASE
BE40TLEDS 1996	GEARCASE
BE40TLEUC 1997	GEARCASE
BE50BEEDS 1996	GEARCASE
BE50BELEDS 1996	GEARCASE
BE50ESECC 1998	GEARCASE
BE50RLECR 1998	GEARCASE
BE50RLEUC 1997	GEARCASE
BE50TLECR 1998	GEARCASE
BE50TLEDS 1996	GEARCASE
BE50TLEUC 1997	GEARCASE
BE50TSLECC 1998	GEARCASE
BE50TSLEUS 1997	GEARCASE
BJ40EECR 1998	GEARCASE
BJ40EEDS 1996	GEARCASE
BJ40EEEAA 1999	GEARCASE
BJ40EEUC 1997	GEARCASE
BJ40ELECR 1998	GEARCASE
BJ40ELEDS 1996	GEARCASE
BJ40ELEEA 1999	GEARCASE
BJ40ELEUC 1997	GEARCASE
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40PLEEA 1999	GEARCASE
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE

BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40TLECR 1998	GEARCASE
BJ40TLEDS 1996	GEARCASE
BJ40TLEUC 1997	GEARCASE
BJ50BEEDS 1996	GEARCASE
BJ50BELEDS 1996	GEARCASE
BJ50EEER 1999	GEARCASE
BJ50ELEER 1999	GEARCASE
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50ESECC 1998	GEARCASE
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ50PLEEA 1999	GEARCASE
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50RLECR 1998	GEARCASE
BJ50RLEEA 1999	GEARCASE
BJ50RLEUC 1997	GEARCASE
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50TLECR 1998	GEARCASE
BJ50TLEDS 1996	GEARCASE
BJ50TLEUC 1997	GEARCASE
BJ50TSLECC 1998	GEARCASE
BJ50TSLEUS 1997	GEARCASE
E40ECEC 1989	GEARCASE
E40EEIA 1991	GEARCASE
E40EENJ 1992	GEARCASE
E40EENM 1992	GEARCASE
E40EEOD 1995	GEARCASE
E40EERE 1994	GEARCASE
E40EESR 1990	GEARCASE
E40EETB 1993	GEARCASE
E40ELCEC 1989	GEARCASE

E40ELECR 1998	GEARCASE
E40ELEDS 1996	GEARCASE
E40ELEIA 1991	GEARCASE
E40ELENJ 1992	GEARCASE
E40ELENM 1992	GEARCASE
E40ELEOD 1995	GEARCASE
E40ELERE 1994	GEARCASE
E40ELESR 1990	GEARCASE
E40ELETB 1993	GEARCASE
E40ELEUC 1997	GEARCASE
E40RCEC 1989	GEARCASE
E40RECR 1998	GEARCASE
E40REDS 1996	GEARCASE
E40REIA 1991	GEARCASE
E40RENM 1992	GEARCASE
E40REOD 1995	GEARCASE
E40RERE 1994	GEARCASE
E40RESR 1990	GEARCASE
E40RETB 1993	GEARCASE
E40REUC 1997	GEARCASE
E40RLCEC 1989	GEARCASE
E40RLECR 1998	GEARCASE
E40RLEDS 1996	GEARCASE
E40RLEIA 1991	GEARCASE
E40RLENM 1992	GEARCASE
E40RLEOD 1995	GEARCASE
E40RLERE 1994	GEARCASE
E40RLESR 1990	GEARCASE
E40RLETB 1993	GEARCASE
E40RLEUC 1997	GEARCASE
E40TECEC 1989	GEARCASE
E40TEECR 1998	GEARCASE
E40TEEDS 1996	GEARCASE
E40TEEIA 1991	GEARCASE
E40TEENJ 1992	GEARCASE

E40TEENM 1992	GEARCASE
E40TEEOD 1995	GEARCASE
E40TEERE 1994	GEARCASE
E40TEESR 1990	GEARCASE
E40TEETB 1993	GEARCASE
E40TEEUC 1997	GEARCASE
E40TELCEC 1989	GEARCASE
E40TELECR 1998	GEARCASE
E40TELEDS 1996	GEARCASE
E40TELEIA 1991	GEARCASE
E40TELENJ 1992	GEARCASE
E40TELENM 1992	GEARCASE
E40TELEOD 1995	GEARCASE
E40TELERE 1994	GEARCASE
E40TELESR 1990	GEARCASE
E40TELETB 1993	GEARCASE
E40TELEUC 1997	GEARCASE
E40TLCEC 1989	GEARCASE
E40TLECR 1998	GEARCASE
E40TLEDS 1996	GEARCASE
E40TLEIA 1991	GEARCASE
E40TLENJ 1992	GEARCASE
E40TLENM 1992	GEARCASE
E40TLEOD 1995	GEARCASE
E40TLERE 1994	GEARCASE
E40TLESR 1990	GEARCASE
E40TLETB 1993	GEARCASE
E40TLETF 1993	GEARCASE
E40TLEUC 1997	GEARCASE
E40TTLCEC 1989	GEARCASE
E40TTLECR 1998	GEARCASE
E40TTLEDS 1996	GEARCASE
E40TTLEIA 1991	GEARCASE
E40TTLENM 1992	GEARCASE
E40TTLEOD 1995	GEARCASE

E40TTLERE 1994	GEARCASE
E40TTLESR 1990	GEARCASE
E40TTLETB 1993	GEARCASE
E40TTLETF 1993	GEARCASE
E40TTLEUC 1997	GEARCASE
E48ESLCER 1989	GEARCASE (CONTINUED)
E48ESLEDC 1996	GEARCASE
E48ESLEIM 1991	GEARCASE
E48ESLENB 1992	GEARCASE
E48ESLEOS 1995	GEARCASE
E48ESLERD 1994	GEARCASE
E48ESLESA 1990	GEARCASE
E48ESLETE 1993	GEARCASE
E50BECEC 1989	GEARCASE
E50BEEIA 1991	GEARCASE
E50BEENJ 1992	GEARCASE
E50BEENM 1992	GEARCASE
E50BEEOD 1995	GEARCASE
E50BEERE 1994	GEARCASE
E50BEESR 1990	GEARCASE
E50BEETB 1993	GEARCASE
E50BELCEC 1989	GEARCASE
E50BELEIA 1991	GEARCASE
E50BELENJ 1992	GEARCASE
E50BELENM 1992	GEARCASE
E50BELEOD 1995	GEARCASE
E50BELERE 1994	GEARCASE
E50BELESR 1990	GEARCASE
E50BELETB 1993	GEARCASE
E50ESLECC 1998	GEARCASE
E50ESLEUR 1997	GEARCASE
E50JEDS 1996	GEARCASE
E50JEIA 1991	GEARCASE
E50JENJ 1992	GEARCASE
E50JENM 1992	GEARCASE

E50JEOD 1995	GEARCASE
E50JERE 1994	GEARCASE
E50JETB 1993	GEARCASE
E50JEUC 1997	GEARCASE
E50RNLIA 1990	GEARCASE
E50RNLIB 1992	GEARCASE
E50TELCEC 1989	GEARCASE
E50TELEIA 1991	GEARCASE
E50TELENM 1992	GEARCASE
E50TELEOD 1995	GEARCASE
E50TELERE 1994	GEARCASE
E50TELESR 1990	GEARCASE
E50TELETB 1993	GEARCASE
E50TLCEC 1989	GEARCASE
E50TLECR 1998	GEARCASE
E50TLEDS 1996	GEARCASE
E50TLEIA 1991	GEARCASE
E50TLENJ 1992	GEARCASE
E50TLENM 1992	GEARCASE
E50TLEOD 1995	GEARCASE
E50TLERE 1994	GEARCASE
E50TLESR 1990	GEARCASE
E50TLETB 1993	GEARCASE
E50TLETF 1993	GEARCASE
E50TLEUC 1997	GEARCASE
E50TSLECC 1998	GEARCASE
E50TSLEUS 1997	GEARCASE
HE40REDS 1996	GEARCASE
HE40REUC 1997	GEARCASE
HE40RLEDS 1996	GEARCASE
HE40RLEUC 1997	GEARCASE
HJ40REDS 1996	GEARCASE
HJ40REUC 1997	GEARCASE
HJ40RLEDS 1996	GEARCASE
HJ40RLEUC 1997	GEARCASE

J40ECEC 1989	GEARCASE
J40EEIA 1991	GEARCASE
J40EENJ 1992	GEARCASE
J40EENM 1992	GEARCASE
J40EEOD 1995	GEARCASE
J40EERE 1994	GEARCASE
J40EESR 1990	GEARCASE
J40EETB 1993	GEARCASE
J40ELCEC 1989	GEARCASE
J40ELECR 1998	GEARCASE
J40ELEDS 1996	GEARCASE
J40ELEIA 1991	GEARCASE
J40ELENJ 1992	GEARCASE
J40ELENM 1992	GEARCASE
J40ELEOD 1995	GEARCASE
J40ELERE 1994	GEARCASE
J40ELESR 1990	GEARCASE
J40ELETB 1993	GEARCASE
J40ELEUC 1997	GEARCASE
J40PLEEA 1999	GEARCASE
J40PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J40PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J40PLSOC	GEARCASE
J40PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSRS	GEARCASE
J40PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J40PLSTD	GEARCASE
J40PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RCEC 1989	GEARCASE
J40RECR 1998	GEARCASE
J40REDS 1996	GEARCASE
J40REEA 1999	GEARCASE
J40REIA 1991	GEARCASE

J40RENM 1992	GEARCASE
J40REOD 1995	GEARCASE
J40RERE 1994	GEARCASE
J40RESR 1990	GEARCASE
J40RETB 1993	GEARCASE
J40REUC 1997	GEARCASE
J40RLCEC 1989	GEARCASE
J40RLECR 1998	GEARCASE
J40RLEDS 1996	GEARCASE
J40RLEEA 1999	GEARCASE
J40RLEIA 1991	GEARCASE
J40RLENM 1992	GEARCASE
J40RLEOD 1995	GEARCASE
J40RLERE 1994	GEARCASE
J40RLESR 1990	GEARCASE
J40LETB 1993	GEARCASE
J40RLEUC 1997	GEARCASE
J40RLSIF rope start, 20 in shaft 2001	GEARCASE
J40RLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RLSOC	GEARCASE
J40RLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSRS	GEARCASE
J40RLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40RLSTD	GEARCASE
J40RLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSIF rope start, 15 in shaft 2001	GEARCASE
J40RSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RSOC	GEARCASE
J40RSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSRS	GEARCASE
J40RSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE

J40RSTD	GEARCASE
J40RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40TECEC 1989	GEARCASE
J40TEECR 1998	GEARCASE
J40TEEDS 1996	GEARCASE
J40TEEIA 1991	GEARCASE
J40TEENJ 1992	GEARCASE
J40TEENM 1992	GEARCASE
J40TEEOD 1995	GEARCASE
J40TEERE 1994	GEARCASE
J40TEESR 1990	GEARCASE
J40TEETB 1993	GEARCASE
J40TEEUC 1997	GEARCASE
J40TELCEC 1989	GEARCASE
J40TELECR 1998	GEARCASE
J40TELEDS 1996	GEARCASE
J40TELEIA 1991	GEARCASE
J40TELENJ 1992	GEARCASE
J40TELENM 1992	GEARCASE
J40TELEOD 1995	GEARCASE
J40TELERE 1994	GEARCASE
J40TELESR 1990	GEARCASE
J40TELETB 1993	GEARCASE
J40TELEUC 1997	GEARCASE
J40TLCEC 1989	GEARCASE
J40TLECR 1998	GEARCASE
J40TLEDS 1996	GEARCASE
J40TLEIA 1991	GEARCASE
J40TLENJ 1992	GEARCASE
J40TLENM 1992	GEARCASE
J40TLEOD 1995	GEARCASE
J40TLERE 1994	GEARCASE
J40TLESR 1990	GEARCASE
J40TLETB 1993	GEARCASE
J40TLETF 1993	GEARCASE

J40TLEUC 1997	GEARCASE
J40TPLEEA 1999	GEARCASE
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	GEARCASE
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J40TTLCEC 1989	GEARCASE
J40TTLECR 1998	GEARCASE
J40TTLEDS 1996	GEARCASE
J40TTLEIA 1991	GEARCASE
J40TTLENM 1992	GEARCASE
J40TTLEOD 1995	GEARCASE
J40TTLERE 1994	GEARCASE
J40TTLESR 1990	GEARCASE
J40TTLETB 1993	GEARCASE
J40TTLETF 1993	GEARCASE
J40TTLERUC 1997	GEARCASE
J48ESLCER 1989	GEARCASE (CONTINUED)
J48ESLEDC 1996	GEARCASE
J48ESLEIM 1991	GEARCASE
J48ESLENB 1992	GEARCASE
J48ESLEOS 1995	GEARCASE
J48ESLERD 1994	GEARCASE
J48ESLESA 1990	GEARCASE
J48ESLETE 1993	GEARCASE
J50BECEC 1989	GEARCASE
J50BEEIA 1991	GEARCASE
J50BEENJ 1992	GEARCASE
J50BEENM 1992	GEARCASE
J50BEEOD 1995	GEARCASE
J50BEERE 1994	GEARCASE
J50BEESR 1990	GEARCASE
J50BEETB 1993	GEARCASE
J50BELCEC 1989	GEARCASE
J50BELEIA 1991	GEARCASE
J50BELENJ 1992	GEARCASE
J50BELENM 1992	GEARCASE

J50BELEOD 1995	GEARCASE
J50BELERE 1994	GEARCASE
J50BELESR 1990	GEARCASE
J50BELETB 1993	GEARCASE
J50ELEER 1999	GEARCASE
J50ELSIF elec start, 20 in shaft 2001	GEARCASE
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	GEARCASE
J50ESLECC 1998	GEARCASE
J50ESLEUR 1997	GEARCASE
J50JEDS 1996	GEARCASE
J50JEIA 1991	GEARCASE
J50JENJ 1992	GEARCASE
J50JENM 1992	GEARCASE
J50JEOD 1995	GEARCASE
J50JERE 1994	GEARCASE
J50JETB 1993	GEARCASE
J50JEUC 1997	GEARCASE
J50PLEEA 1999	GEARCASE
J50PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J50PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J50PLSOC	GEARCASE
J50PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSRS	GEARCASE
J50PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J50PLSTD	GEARCASE
J50PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J50TELCEC 1989	GEARCASE
J50TELEIA 1991	GEARCASE
J50TELENM 1992	GEARCASE
J50TELEOD 1995	GEARCASE
J50TELERE 1994	GEARCASE
J50TELESR 1990	GEARCASE
J50TELETB 1993	GEARCASE

J50TLCEC 1989	GEARCASE
J50TLECR 1998	GEARCASE
J50TLEDS 1996	GEARCASE
J50TLEIA 1991	GEARCASE
J50TLENJ 1992	GEARCASE
J50TLENM 1992	GEARCASE
J50TLEOD 1995	GEARCASE
J50TLERE 1994	GEARCASE
J50TLESR 1990	GEARCASE
J50TLETB 1993	GEARCASE
J50TLETF 1993	GEARCASE
J50TLEUC 1997	GEARCASE
J50TSLECC 1998	GEARCASE
J50TSLEUS 1997	GEARCASE
RJ50ELSIF elec start, TNT, 20 in shaft 2001	GEARCASE
SE40RSLD 1997	GEARCASE
SE40RSLR 1998	GEARCASE
SE40RSLZ 1996	GEARCASE
SE50TLEDS 1996	GEARCASE
SJ40EEDS 1996	GEARCASE
SJ40REDS 1996	GEARCASE
SJ40RLEDS 1996	GEARCASE
SJ40RSLD 1997	GEARCASE
SJ40RSLR 1998	GEARCASE
SJ40RSLZ 1996	GEARCASE
TE40ELCEC 1989	GEARCASE
TE40ELEIA 1991	GEARCASE
TE40ELENJ 1992	GEARCASE
TE40ELENM 1992	GEARCASE
TE40ELESR 1990	GEARCASE
TE40ELETB 1993	GEARCASE
TE40TELESF 1990	GEARCASE
TE40TELESR 1990	GEARCASE
TE48ESLETE 1993	GEARCASE
TE50TLCEC 1989	GEARCASE

TE50TLESF 1989	GEARCASE
TE50TLESF 1990	GEARCASE
TE50TLESR 1990	GEARCASE
TJ40ELCEC 1989	GEARCASE
TJ40ELEIA 1991	GEARCASE
TJ40ELENJ 1992	GEARCASE
TJ40ELENM 1992	GEARCASE
TJ40ELESF 1990	GEARCASE
TJ40ELESR 1990	GEARCASE
TJ40ELETB 1993	GEARCASE
TJ40TELESF 1990	GEARCASE
TJ40TELESR 1990	GEARCASE
TJ48ESLETE 1993	GEARCASE
TJ50TLCEC 1989	GEARCASE
TJ50TLESF 1989	GEARCASE
TJ50TLESF 1990	GEARCASE
TJ50TLESR 1990	GEARCASE
VE40EEIA 1991	GEARCASE
VE40EENJ 1992	GEARCASE
VE40EENM 1992	GEARCASE
VE40EESR 1990	GEARCASE
VE40EETB 1993	GEARCASE
VE40ELEIA 1991	GEARCASE
VE40ELENJ 1992	GEARCASE
VE40ELENM 1992	GEARCASE
VE40ELESR 1990	GEARCASE
VE40ELETB 1993	GEARCASE
VE40TELEIA 1991	GEARCASE
VE40TELENJ 1992	GEARCASE
VE40TELENM 1992	GEARCASE
VE40TELESR 1990	GEARCASE
VE40TELETB 1993	GEARCASE
VE40TLEIA 1991	GEARCASE
VE40TLENJ 1992	GEARCASE
VE40TLEMN 1992	GEARCASE

VE40TLESR 1990	GEARCASE
VE40TLETB 1993	GEARCASE
VE40TLETF 1993	GEARCASE
VE48ESLCER 1989	GEARCASE (CONTINUED)
VE48ESLENB 1992	GEARCASE
VE48ESLESA 1990	GEARCASE
VE48ESLETE 1993	GEARCASE
VE50BEEIA 1991	GEARCASE
VE50BEENJ 1992	GEARCASE
VE50BEENM 1992	GEARCASE
VE50BEESR 1990	GEARCASE
VE50BEETB 1993	GEARCASE
VE50BELEIA 1991	GEARCASE
VE50BELENJ 1992	GEARCASE
VE50BELENM 1992	GEARCASE
VE50BELESR 1990	GEARCASE
VE50BELETB 1993	GEARCASE
VE50TELENM 1992	GEARCASE
VE50TLEIA 1991	GEARCASE
VE50TLENJ 1992	GEARCASE
VE50TLENM 1992	GEARCASE
VE50TLESR 1990	GEARCASE
VE50TLETB 1993	GEARCASE
VE50TLETF 1993	GEARCASE
VJ40EEIA 1991	GEARCASE
VJ40EENJ 1992	GEARCASE
VJ40EENM 1992	GEARCASE
VJ40EESR 1990	GEARCASE
VJ40EETB 1993	GEARCASE
VJ40ELEIA 1991	GEARCASE
VJ40ELENJ 1992	GEARCASE
VJ40ELENM 1992	GEARCASE
VJ40ELESR 1990	GEARCASE
VJ40ELETB 1993	GEARCASE
VJ40TELEIA 1991	GEARCASE

VJ40TELENJ 1992	GEARCASE
VJ40TELENM 1992	GEARCASE
VJ40TELESR 1990	GEARCASE
VJ40TELETB 1993	GEARCASE
VJ40TLEIA 1991	GEARCASE
VJ40TLENJ 1992	GEARCASE
VJ40TLENM 1992	GEARCASE
VJ40TLESR 1990	GEARCASE
VJ40TLETB 1993	GEARCASE
VJ40TLETF 1993	GEARCASE
VJ48ESLCER 1989	GEARCASE (CONTINUED)
VJ48ESLENB 1992	GEARCASE
VJ48ESLESA 1990	GEARCASE
VJ48ESLETE 1993	GEARCASE
VJ50BEEIA 1991	GEARCASE
VJ50BEENJ 1992	GEARCASE
VJ50BEENM 1992	GEARCASE
VJ50BEESR 1990	GEARCASE
VJ50BEETB 1993	GEARCASE
VJ50BELEIA 1991	GEARCASE
VJ50BELENJ 1992	GEARCASE
VJ50BELEMN 1992	GEARCASE
VJ50BELESR 1990	GEARCASE
VJ50BELETB 1993	GEARCASE
VJ50TELENM 1992	GEARCASE
VJ50TLEIA 1991	GEARCASE
VJ50TLENJ 1992	GEARCASE
VJ50TLENM 1992	GEARCASE
VJ50TLESR 1990	GEARCASE
VJ50TLETB 1993	GEARCASE
VJ50TLETF 1993	GEARCASE
X50ESLECC 1998	GEARCASE