

Where Used: Part Number 0334698

Model Name	Diagram
40/50HP (2 Stroke)	ELECTRIC START KIT (1993-Current models w/CD II Ignition)
40HP Rope 45-55HP Comm (2 Stroke) 1992-2001	TILLER ELECTRIC START KIT - 40, 55
E25TEECB 1998	START SWITCH & CABLES
E25TEEDA 1996	START SWITCH & CABLES
E25TEEND 1992	START SWITCH & CABLES
E25TEEOR 1995	START SWITCH & CABLES
E25TEERC 1994	START SWITCH & CABLES
E25TEETS 1993	START SWITCH & CABLES
E25TEEUM 1997	START SWITCH & CABLES
E25TELECB 1998	START SWITCH & CABLES
E25TELEDA 1996	START SWITCH & CABLES
E25TELEND 1992	START SWITCH & CABLES
E25TELEOR 1995	START SWITCH & CABLES
E25TELETS 1993	START SWITCH & CABLES
E25TELEUM 1997	START SWITCH & CABLES
E30TEECS 1998	START SWITCH & CABLES
E30TEEDE 1996	START SWITCH & CABLES
E30TEENR 1992	START SWITCH & CABLES
E30TEEOB 1995	START SWITCH & CABLES
E30TEERM 1994	START SWITCH & CABLES
E30TEETA 1993	START SWITCH & CABLES
E30TEEUD 1997	START SWITCH & CABLES
E30TELECB 1998	START SWITCH & CABLES
E30TELEDE 1996	START SWITCH & CABLES
E30TELENR 1992	START SWITCH & CABLES
E30TELEOB 1995	START SWITCH & CABLES
E30TELERM 1994	START SWITCH & CABLES
E30TELETA 1993	START SWITCH & CABLES
E30TELEUD 1997	START SWITCH & CABLES
ELECTRICAL	ELECTRIC START KIT - 25,30 HP (2-Stroke)
ELECTRICAL	ELECTRIC START KIT - 40,50 HP (Johnson 2-Stroke)
ELECTRICAL 1989	ELECTRIC STARTING KIT 40
ELECTRICAL 1990	ELECTRIC STARTING KIT 40

ELECTRICAL 1991	ELECTRIC STARTING KIT 40
ELECTRICAL 1992	ELECTRIC STARTING KIT 40,45,55
ELECTRICAL 1993	ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1994	ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1995	TILLER ELECTRIC STARTING KIT - 45/55
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 45, 55
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 45, 55
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 55
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 55
HE25TELEDA 1996	START SWITCH & CABLES
HJ25TELEDA 1996	START SWITCH & CABLES
J25GTESOC	START SWITCH & CABLES
J25GTESOC - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25GTESRS	START SWITCH & CABLES
J25GTESRS - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TEECB 1998	START SWITCH & CABLES
J25TEEDA 1996	START SWITCH & CABLES
J25TEEEE 1999	START SWITCH & CABLES
J25TEEEN 1999	START SWITCH & CABLES
J25TEEND 1992	START SWITCH & CABLES
J25TEEOR 1995	START SWITCH & CABLES
J25TEERC 1994	START SWITCH & CABLES
J25TEETS 1993	START SWITCH & CABLES
J25TEEUM 1997	START SWITCH & CABLES
J25TELECB 1998	START SWITCH & CABLES
J25TELEDA 1996	START SWITCH & CABLES
J25TELEEE 1999	START SWITCH & CABLES
J25TELEEN 1999	START SWITCH & CABLES
J25TELEND 1992	START SWITCH & CABLES

J25TELEOR 1995	START SWITCH & CABLES
J25TELERC	START SWITCH & CABLES
J25TELETS 1993	START SWITCH & CABLES
J25TELEUM 1997	START SWITCH & CABLES
J25TELSIS elec start, tiller, 20 in shaft 2001	START SWITCH & CABLES
J25TELSNF - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TELSNF Electric strart, White, Tiller, 20 in., 4 Amp Alt 2002	START SWITCH & CABLES
J25TELSOM	START SWITCH & CABLES
J25TELSOM - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TELSRA	START SWITCH & CABLES
J25TELSRA - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TELSSD Elec. Start, Tiller, 20 IN. shaft 2000	START SWITCH & CABLES
J25TELSTR	START SWITCH & CABLES
J25TELSTR - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TESIS elec start, tiller, 15 in shaft 2001	START SWITCH & CABLES
J25TESNF - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TESNF Electric strart, White, Tiller,15 in. shaft, 4 Amp Alt 2002	START SWITCH & CABLES
J25TESOM	START SWITCH & CABLES
J25TESOM - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TESRA	START SWITCH & CABLES
J25TESRA - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TESSD Elec. Start, Tiller, 15 IN. shaft 2000	START SWITCH & CABLES
J25TESTR	START SWITCH & CABLES
J25TESTR - FR	22-9_INTERRUPTEUR & CÂBLES DE DÉMARRAGE
J25TVLSIS elec start, tiller, 20 in shaft 2001	START SWITCH & CABLES
J25TVSIS elec start, tiller, 15 in shaft 2001	START SWITCH & CABLES
J30TEECS 1998	START SWITCH & CABLES
J30TEEDE 1996	START SWITCH & CABLES
J30TEENR 1992	START SWITCH & CABLES
J30TEEOB 1995	START SWITCH & CABLES
J30TEERM 1994	START SWITCH & CABLES
J30TEETA 1993	START SWITCH & CABLES
J30TEEUD 1997	START SWITCH & CABLES
J30TELECS 1998	START SWITCH & CABLES

J30TELEDE 1996	START SWITCH & CABLES
J30TELENR 1992	START SWITCH & CABLES
J30TELEOB 1995	START SWITCH & CABLES
J30TELERM 1994	START SWITCH & CABLES
J30TELETA 1993	START SWITCH & CABLES
J30TELEUD 1997	START SWITCH & CABLES
SJ25TEEDA 1996	START SWITCH & CABLES
SJ25TEEUM 1997	START SWITCH & CABLES
SJ30TEEUD 1997	START SWITCH & CABLES