

Where Used: Part Number 0335144

Model Name	Diagram
40/50HP (2 Stroke)	POWER TRIM/TILT KIT (Early Style)
BE25ARECA 1998	POWER TRIM/TILT
BE25AREDC 1996	POWER TRIM/TILT
BE25AREUR 1997	POWER TRIM/TILT
BE25ARLECA 1998	POWER TRIM/TILT
BE25ARLEDC 1996	POWER TRIM/TILT
BE25ARLEUR 1997	POWER TRIM/TILT
BE25KECA 1998	POWER TRIM/TILT
BE25KEDC 1996	POWER TRIM/TILT
BE25KEUR 1997	POWER TRIM/TILT
BE25KLECA 1998	POWER TRIM/TILT
BE25KLEDC 1996	POWER TRIM/TILT
BE25KLEUR 1997	POWER TRIM/TILT
BE25QLECA 1998	POWER TRIM/TILT
BE25QLEDC 1996	POWER TRIM/TILT
BE25QLEUR 1997	POWER TRIM/TILT
BE35ARECR 1998	POWER TRIM/TILT
BE35AREDS 1996	POWER TRIM/TILT
BE35AREEA 1999	POWER TRIM/TILT
BE35AREUC 1997	POWER TRIM/TILT
BE35ARLECR 1998	POWER TRIM/TILT
BE35ARLEDS 1996	POWER TRIM/TILT
BE35ARLEUC 1997	POWER TRIM/TILT
BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	POWER TRIM AND TILT
BE35KECA 1998	POWER TRIM/TILT
BE35KEDC 1996	POWER TRIM/TILT
BE35KEEM 1999	POWER TRIM/TILT
BE35KEUR 1997	POWER TRIM/TILT
BE35KLECA 1998	POWER TRIM/TILT
BE35KLEDC 1996	POWER TRIM/TILT
BE35KLEUR 1997	POWER TRIM/TILT

BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	POWER TRIM AND TILT
BE35QLECA 1998	POWER TRIM/TILT
BE35QLEDC 1996	POWER TRIM/TILT
BE35QLEUR 1997	POWER TRIM/TILT
BE40EECR 1998	POWER TRIM/TILT
BE40EEDS 1996	POWER TRIM/TILT
BE40EEUC 1997	POWER TRIM/TILT
BE40ELECR 1998	POWER TRIM/TILT
BE40ELEDs 1996	POWER TRIM/TILT
BE40ELEUC 1997	POWER TRIM/TILT
BE40TLECR 1998	POWER TRIM/TILT
BE40TLEDs 1996	POWER TRIM/TILT
BE40TLEUC 1997	POWER TRIM/TILT
BE50BEEDS 1996	POWER TRIM/TILT
BE50BELEDs 1996	POWER TRIM/TILT
BE50ESECC 1998	POWER TRIM/TILT
BE50RLECR 1998	POWER TRIM/TILT
BE50RLEUC 1997	POWER TRIM/TILT
BE50TLECR 1998	POWER TRIM/TILT
BE50TLEDs 1996	POWER TRIM/TILT
BE50TLEUC 1997	POWER TRIM/TILT
BE50TSLECC 1998	POWER TRIM/TILT
BE50TSLEUS 1997	POWER TRIM/TILT
BJ25ARECA 1998	POWER TRIM/TILT
BJ25AREDC 1996	POWER TRIM/TILT
BJ25AREUR 1997	POWER TRIM/TILT
BJ25ARLECA 1998	POWER TRIM/TILT
BJ25ARLEDC 1996	POWER TRIM/TILT
BJ25ARLEUR 1997	POWER TRIM/TILT
BJ25KECA 1998	POWER TRIM/TILT
BJ25KEDC 1996	POWER TRIM/TILT
BJ25KEUR 1997	POWER TRIM/TILT
BJ25KLECA 1998	POWER TRIM/TILT

BJ25KLEDC 1996	POWER TRIM/TILT
BJ25KLEUR 1997	POWER TRIM/TILT
BJ25PL3EEM 1999	POWER TRIM/TILT
BJ25PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT
BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	POWER TRIM AND TILT
BJ25QLECA 1998	POWER TRIM/TILT
BJ25QLEDC 1996	POWER TRIM/TILT
BJ25QLEUR 1997	POWER TRIM/TILT
BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
BJ35ARECR 1998	POWER TRIM/TILT
BJ35AREDS 1996	POWER TRIM/TILT
BJ35AREEA 1999	POWER TRIM/TILT
BJ35AREUC 1997	POWER TRIM/TILT
BJ35ARLECR 1998	POWER TRIM/TILT
BJ35ARLEDS 1996	POWER TRIM/TILT
BJ35ARLEUC 1997	POWER TRIM/TILT
BJ35E3EEM 1999	POWER TRIM/TILT
BJ35E3SIE elec start, 15 in shaft, n/a usa 2001	POWER TRIM/TILT
BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000	POWER TRIM AND TILT
BJ35EL3EEM 1999	POWER TRIM/TILT
BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000	POWER TRIM AND TILT
BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
BJ35KECA 1998	POWER TRIM/TILT
BJ35KEDC 1996	POWER TRIM/TILT
BJ35KEEM 1999	POWER TRIM/TILT
BJ35KEUR 1997	POWER TRIM/TILT
BJ35KLECA 1998	POWER TRIM/TILT
BJ35KLEDC 1996	POWER TRIM/TILT
BJ35KLEUR 1997	POWER TRIM/TILT
BJ35PL3EEM 1999	POWER TRIM/TILT
BJ35PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT

BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	POWER TRIM AND TILT
BJ35QLECA 1998	POWER TRIM/TILT
BJ35QLEDC 1996	POWER TRIM/TILT
BJ35QLEUR 1997	POWER TRIM/TILT
BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
BJ40EECR 1998	POWER TRIM/TILT
BJ40EEDS 1996	POWER TRIM/TILT
BJ40EEEE 1999	POWER TRIM/TILT
BJ40EEUC 1997	POWER TRIM/TILT
BJ40ELECR 1998	POWER TRIM/TILT
BJ40ELEDS 1996	POWER TRIM/TILT
BJ40ELEEA 1999	POWER TRIM/TILT
BJ40ELEUC 1997	POWER TRIM/TILT
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	POWER TRIM & TILT
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	POWER TRIM & TILT
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	POWER TRIM & TILT
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	POWER TRIM & TILT
BJ40PLEEA 1999	POWER TRIM/TILT
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	POWER TRIM & TILT
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	POWER TRIM & TILT
BJ40TLECR 1998	POWER TRIM/TILT
BJ40TLEDS 1996	POWER TRIM/TILT
BJ40TLEUC 1997	POWER TRIM/TILT
BJ50BEEDS 1996	POWER TRIM/TILT
BJ50BELEDS 1996	POWER TRIM/TILT
BJ50EEER 1999	POWER TRIM/TILT
BJ50ELEER 1999	POWER TRIM/TILT
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	POWER TRIM & TILT
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	POWER TRIM & TILT
BJ50ESECC 1998	POWER TRIM/TILT
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	POWER TRIM & TILT
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	POWER TRIM & TILT
BJ50PLEEA 1999	POWER TRIM/TILT
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	POWER TRIM & TILT

BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	POWER TRIM & TILT
BJ50RLECR 1998	POWER TRIM/TILT
BJ50RLEEA 1999	POWER TRIM/TILT
BJ50RLEUC 1997	POWER TRIM/TILT
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	POWER TRIM & TILT
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	POWER TRIM & TILT
BJ50TLECR 1998	POWER TRIM/TILT
BJ50TLEDS 1996	POWER TRIM/TILT
BJ50TLEUC 1997	POWER TRIM/TILT
BJ50TSLECC 1998	POWER TRIM/TILT
BJ50TSLEUS 1997	POWER TRIM/TILT
E25KLECA 1998	POWER TRIM/TILT
E25KLEDC 1996	POWER TRIM/TILT
E25KLEUR 1997	POWER TRIM/TILT
E25QLECA 1998	POWER TRIM/TILT
E25QLEDC 1996	POWER TRIM/TILT
E25QLEUR 1997	POWER TRIM/TILT
E25RMECA 1998	POWER TRIM/TILT
E25RMEDC 1996	POWER TRIM/TILT
E25RMEUR 1997	POWER TRIM/TILT
E25RMLECA 1998	POWER TRIM/TILT
E25RMLEDC 1996	POWER TRIM/TILT
E25RMLEUR 1997	POWER TRIM/TILT
E25TKECA 1998	POWER TRIM/TILT
E25TKEDC 1996	POWER TRIM/TILT
E25TKEUR 1997	POWER TRIM/TILT
E25TKLECA 1998	POWER TRIM/TILT
E25TKLEDC 1996	POWER TRIM/TILT
E25TKLEUR 1997	POWER TRIM/TILT
E35KLECA 1998	POWER TRIM/TILT
E35KLEDC 1996	POWER TRIM/TILT
E35KLEUR 1997	POWER TRIM/TILT
E35QLECA 1998	POWER TRIM/TILT
E35QLEDC 1996	POWER TRIM/TILT

E35QLEUR 1997	POWER TRIM/TILT
E35RMLEDC 1996	POWER TRIM/TILT
E35RMLEUR 1997	POWER TRIM/TILT
E35TKLECA 1998	POWER TRIM/TILT
E35TKLEDC 1996	POWER TRIM/TILT
E35TKLEUR 1997	POWER TRIM/TILT
E40ELECR 1998	POWER TRIM/TILT
E40ELEDs 1996	POWER TRIM/TILT
E40ELEUC 1997	POWER TRIM/TILT
E40RECR 1998	POWER TRIM/TILT
E40REDS 1996	POWER TRIM/TILT
E40REUC 1997	POWER TRIM/TILT
E40RLECR 1998	POWER TRIM/TILT
E40RLEDs 1996	POWER TRIM/TILT
E40RLEUC 1997	POWER TRIM/TILT
E40TEECR 1998	POWER TRIM/TILT
E40TEEDs 1996	POWER TRIM/TILT
E40TEEUC 1997	POWER TRIM/TILT
E40TELECR 1998	POWER TRIM/TILT
E40TELEDs 1996	POWER TRIM/TILT
E40TELEUC 1997	POWER TRIM/TILT
E40TLECR 1998	POWER TRIM/TILT
E40TLEDs 1996	POWER TRIM/TILT
E40TLEUC 1997	POWER TRIM/TILT
E40TTLECR 1998	POWER TRIM/TILT
E40TTLEDs 1996	POWER TRIM/TILT
E40TTLEUC 1997	POWER TRIM/TILT
E50ESLECC 1998	POWER TRIM/TILT
E50ESLEUR 1997	POWER TRIM/TILT
E50JEDs 1996	POWER TRIM/TILT
E50JEUC 1997	POWER TRIM/TILT
E50TLECR 1998	POWER TRIM/TILT
E50TLEDs 1996	POWER TRIM/TILT
E50TLEUC 1997	POWER TRIM/TILT
E50TSLECC 1998	POWER TRIM/TILT

E50TSLEUS 1997	POWER TRIM/TILT
HE35RMLEDC 1996	POWER TRIM/TILT
HE35RMLEUR 1997	POWER TRIM/TILT
HE40REDS 1996	POWER TRIM/TILT
HE40REUC 1997	POWER TRIM/TILT
HE40RLEDS 1996	POWER TRIM/TILT
HE40RLEUC 1997	POWER TRIM/TILT
HJ35RMLEDC 1996	POWER TRIM/TILT
HJ35RMLEUR 1997	POWER TRIM/TILT
HJ40REDS 1996	POWER TRIM/TILT
HJ40REUC 1997	POWER TRIM/TILT
HJ40RLEDS 1996	POWER TRIM/TILT
HJ40RLEUC 1997	POWER TRIM/TILT
J25KLECA 1998	POWER TRIM/TILT
J25KLEDC 1996	POWER TRIM/TILT
J25KLEUR 1997	POWER TRIM/TILT
J25PL3EEM 1999	POWER TRIM/TILT
J25PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT
J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	POWER TRIM AND TILT
J25QLECA 1998	POWER TRIM/TILT
J25QLEDC 1996	POWER TRIM/TILT
J25QLEUR 1997	POWER TRIM/TILT
J25R3EEM 1999	POWER TRIM/TILT
J25R3SIE rope start, tiller, 15 in shaft 2001	POWER TRIM/TILT
J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	POWER TRIM AND TILT
J25RL3EEM 1999	POWER TRIM/TILT
J25RL3SIE rope start, tiller, 20 in shaft 2001	POWER TRIM/TILT
J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT
J25RMECA 1998	POWER TRIM/TILT
J25RMEDC 1996	POWER TRIM/TILT
J25RMEUR 1997	POWER TRIM/TILT
J25RMLECA 1998	POWER TRIM/TILT
J25RMLEDC 1996	POWER TRIM/TILT
J25RMLEUR 1997	POWER TRIM/TILT
J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001	POWER TRIM/TILT

J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001	POWER TRIM/TILT
J25TEL3EEM 1999	POWER TRIM/TILT
J25TEL3SIE elec start, tiller, 20 in shaft 2001	POWER TRIM/TILT
J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT
J25TKECA 1998	POWER TRIM/TILT
J25TKEDC 1996	POWER TRIM/TILT
J25TKEUR 1997	POWER TRIM/TILT
J25TKLECA 1998	POWER TRIM/TILT
J25TKLEDC 1996	POWER TRIM/TILT
J25TKLEUR 1997	POWER TRIM/TILT
J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001	POWER TRIM/TILT
J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	POWER TRIM/TILT
J35E3EEM 1999	POWER TRIM/TILT
J35EL3EEM 1999	POWER TRIM/TILT
J35KLECA 1998	POWER TRIM/TILT
J35KLEDC 1996	POWER TRIM/TILT
J35KLEUR 1997	POWER TRIM/TILT
J35PL3EEM 1999	POWER TRIM/TILT
J35PL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT
J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	POWER TRIM AND TILT
J35QLECA 1998	POWER TRIM/TILT
J35QLEDC 1996	POWER TRIM/TILT
J35QLEUR 1997	POWER TRIM/TILT
J35R3EEM 1999	POWER TRIM/TILT
J35R3SIE rope start, tiller, 15 in shaft 2001	POWER TRIM/TILT
J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	POWER TRIM AND TILT
J35RL3EEM 1999	POWER TRIM/TILT
J35RL3SIE rope start, tiller, 20 in shaft 2001	POWER TRIM/TILT
J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT
J35RMLEDC 1996	POWER TRIM/TILT
J35RMLEUR 1997	POWER TRIM/TILT
J35RV3SIE rope start, 15 in shaft, wht 2001	POWER TRIM/TILT
J35RVL3SIE rope start, 20 in shaft, wht 2001	POWER TRIM/TILT
J35TEL3EEM 1999	POWER TRIM/TILT

J35TEL3SIE elec start, TNT, 20 in shaft 2001	POWER TRIM/TILT
J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000	POWER TRIM AND TILT
J35TKLECA 1998	POWER TRIM/TILT
J35TKLEDC 1996	POWER TRIM/TILT
J35TKLEUR 1997	POWER TRIM/TILT
J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001	POWER TRIM/TILT
J35VL3SIE elec start, TNT, 20 in shaft, wht 2001	POWER TRIM/TILT
J40ELECR 1998	POWER TRIM/TILT
J40ELEDs 1996	POWER TRIM/TILT
J40ELEUC 1997	POWER TRIM/TILT
J40PLEEA 1999	POWER TRIM/TILT
J40PLSIF elec start, TNT, 20 in shaft 2001	POWER TRIM & TILT
J40PLSNF - FR	28-1_ENSEMBLE HYDRAULIQUE DE CORRECTION DASSIETTE ET DE RELEVAGE
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	POWER TRIM/TILT
J40PLSRS	POWER TRIM/TILT
J40PLSRS - FR	28-1_ENSEMBLE HYDRAULIQUE DE CORRECTION DASSIETTE ET DE RELEVAGE
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	POWER TRIM & TILT
J40PLSTD	POWER TRIM/TILT
J40PLSTD - FR	28-1_ENSEMBLE HYDRAULIQUE DE CORRECTION DASSIETTE ET DE RELEVAGE
J40RECR 1998	POWER TRIM/TILT
J40REDS 1996	POWER TRIM/TILT
J40REEA 1999	POWER TRIM/TILT
J40REUC 1997	POWER TRIM/TILT
J40RLECR 1998	POWER TRIM/TILT
J40RLEDS 1996	POWER TRIM/TILT
J40RLEEA 1999	POWER TRIM/TILT
J40RLEUC 1997	POWER TRIM/TILT
J40RLSIF rope start, 20 in shaft 2001	POWER TRIM & TILT
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	POWER TRIM & TILT
J40RSIF rope start, 15 in shaft 2001	POWER TRIM & TILT
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	POWER TRIM & TILT
J40TEECR 1998	POWER TRIM/TILT
J40TEEDS 1996	POWER TRIM/TILT

J40TEEUC 1997	POWER TRIM/TILT
J40TELECR 1998	POWER TRIM/TILT
J40TELEDS 1996	POWER TRIM/TILT
J40TELEUC 1997	POWER TRIM/TILT
J40TLECR 1998	POWER TRIM/TILT
J40TLEDS 1996	POWER TRIM/TILT
J40TLEUC 1997	POWER TRIM/TILT
J40TPLEEA 1999	POWER TRIM/TILT
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	POWER TRIM & TILT
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	POWER TRIM & TILT
J40TTLECR 1998	POWER TRIM/TILT
J40TTLEDS 1996	POWER TRIM/TILT
J40TTLEUC 1997	POWER TRIM/TILT
J50ELEER 1999	POWER TRIM/TILT
J50ELSIF elec start, 20 in shaft 2001	POWER TRIM & TILT
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	POWER TRIM & TILT
J50ESLECC 1998	POWER TRIM/TILT
J50ESLEUR 1997	POWER TRIM/TILT
J50JEDS 1996	POWER TRIM/TILT
J50JEUC 1997	POWER TRIM/TILT
J50PLEEA 1999	POWER TRIM/TILT
J50PLSIF elec start, TNT, 20 in shaft 2001	POWER TRIM & TILT
J50PLSNF - FR	28-1_ENSEMBLE HYDRAULIQUE DE CORRECTION DASSIETTE ET DE RELEVAGE
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	POWER TRIM/TILT
J50PLSRS	POWER TRIM/TILT
J50PLSRS - FR	28-1_ENSEMBLE HYDRAULIQUE DE CORRECTION DASSIETTE ET DE RELEVAGE
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	POWER TRIM & TILT
J50PLSTD	POWER TRIM/TILT
J50PLSTD - FR	28-1_ENSEMBLE HYDRAULIQUE DE CORRECTION DASSIETTE ET DE RELEVAGE
J50TLECR 1998	POWER TRIM/TILT
J50TLEDS 1996	POWER TRIM/TILT
J50TLEUC 1997	POWER TRIM/TILT
J50TSLECC 1998	POWER TRIM/TILT

J50TSLEUS 1997	POWER TRIM/TILT
POWER TRIM/TILT 1996	POWER TRIM/TILT KIT - 40, 48, & 50 MODELS
POWER TRIM/TILT 1997	POWER TRIM/TILT KIT - 40 & 50 MODELS
POWER TRIM/TILT 1998	POWER TRIM/TILT KIT -- 40 & 50 MODELS
POWER TRIM/TILT 1999	POWER TRIM/TILT KIT -- 40 & 50 MODELS
POWER TRIM_TILT 2000	POWER TRIM/TILT KIT - 40 & 50 MODELS
RJ50ELSIF elec start, TNT, 20 in shaft 2001	POWER TRIM & TILT
SE50TLEDS 1996	POWER TRIM/TILT
SJ40EEDS 1996	POWER TRIM/TILT
SJ40REDS 1996	POWER TRIM/TILT
SJ40RLEDS 1996	POWER TRIM/TILT
X50ESLECC 1998	POWER TRIM/TILT