

Where Used: Part Number 0337522

Model Name	Diagram
20/35HP	AC LIGHTING KIT
40/50HP (2 Stroke)	ELECTRIC START KIT (1993-Current models w/CD II Ignition)
6/8HP (2 Stroke)	BATTERY CHARGING KIT
6/8HP (2 Stroke)	AC LIGHTING KIT
9.9/15HP (2 Stroke) 1993-Current	ELECTRIC START KIT
9.9/15HP (2 Stroke) 1993-Current	AC LIGHTING KIT
AM55RSLD 1999	IGNITION SYSTEM
B25JREUR 1997	IGNITION
BE10EEDD 1996	IGNITION - ELECTRIC
BE10EEDD 1996	IGNITION - ROPE
BE10ELEDD 1996	IGNITION - ELECTRIC
BE10ELEDD 1996	IGNITION - ROPE
BE10REDD 1996	IGNITION - ELECTRIC
BE10REDD 1996	IGNITION - ROPE
BE10RELEDD 1996	IGNITION - ELECTRIC
BE10RELEDD 1996	IGNITION - ROPE
BE10RELEUS 1997	IGNITION - ELECTRIC
BE10RELEUS 1997	IGNITION - ROPE
BE10RLEDD 1996	IGNITION - ELECTRIC
BE10RLEDD 1996	IGNITION - ROPE
BE10SELEDD 1996	IGNITION - ELECTRIC
BE10SELEDD 1996	IGNITION - ROPE
BE15EEDS 1996	IGNITION - ELECTRIC
BE15EEDS 1996	IGNITION - ROPE
BE15ELEDS 1996	IGNITION - ELECTRIC
BE15ELEDS 1996	IGNITION - ROPE
BE15REDS 1996	IGNITION - ELECTRIC
BE15REDS 1996	IGNITION - ROPE
BE15RELEUC 1997	IGNITION - ELECTRIC
BE15RELEUC 1997	IGNITION - ROPE
BE15RLEDS 1996	IGNITION - ELECTRIC
BE15RLEDS 1996	IGNITION - ROPE
BE20SEECB 1998	IGNITION

BE20SEEDA 1996	IGNITION
BE20SEEUM 1997	IGNITION
BE20SELECB 1998	IGNITION
BE20SELEDA 1996	IGNITION
BE20SELEUM 1997	IGNITION
BE20SRECB 1998	IGNITION
BE20SREDA 1996	IGNITION
BE20SREUM 1997	IGNITION
BE20SRLECB 1998	IGNITION
BE20SRLEDA 1996	IGNITION
BE20SRLEUM 1997	IGNITION
BE25BAECM 1998	IGNITION
BE25BAEDR 1996	IGNITION
BE25BAEUA 1997	IGNITION
BE25BALECM 1998	IGNITION
BE25BALEDR 1996	IGNITION
BE25BALEUA 1997	IGNITION
BE25BREDC 1996	IGNITION
BE25BRLEDC 1996	IGNITION
BE25EECE 1998	IGNITION
BE25EEDM 1996	IGNITION
BE25EEUB 1997	IGNITION
BE25ELECE 1998	IGNITION
BE25ELEDM 1996	IGNITION
BE25ELEUB 1997	IGNITION
BE25EREDEC 1996	IGNITION
BE25ERLEDC 1996	IGNITION
BE30BAECS 1998	IGNITION
BE30BAEDE 1996	IGNITION
BE30BAEEC 1999	IGNITION
BE30BAEEN 1999	IGNITION
BE30BAEUD 1997	IGNITION
BE30BALECS 1998	IGNITION
BE30BALEDE 1996	IGNITION
BE30BALEUD 1997	IGNITION

BE30BASIA rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
BE30BASSR Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
BE30EECS 1998	IGNITION
BE30EEDE 1996	IGNITION
BE30EEUD 1997	IGNITION
BE30ELECS 1998	IGNITION
BE30ELEDE 1996	IGNITION
BE30ELEUD 1997	IGNITION
BE40EECR 1998	IGNITION SYSTEM -- ROPE START
BE40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40EEUC 1997	IGNITION SYSTEM - ROPE START
BE40ELECR 1998	IGNITION SYSTEM -- ROPE START
BE40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40ELEUC 1997	IGNITION SYSTEM - ROPE START
BE40TLECR 1998	IGNITION SYSTEM -- ROPE START
BE40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE40TLEUC 1997	IGNITION SYSTEM - ROPE START
BE4RDHEDS 1996	MAGNETO
BE4RDHLEDS 1996	MAGNETO
BE50BEEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE50BELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE50ESECC 1998	IGNITION SYSTEM -- ROPE START
BE50RLECR 1998	IGNITION SYSTEM -- ROPE START
BE50RLEUC 1997	IGNITION SYSTEM - ROPE START
BE50TLECR 1998	IGNITION SYSTEM -- ROPE START
BE50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BE50TLEUC 1997	IGNITION SYSTEM - ROPE START
BE50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BE50TSLEUS 1997	IGNITION SYSTEM - ROPE START
BE5DREDS 1996	IGNITION
BE5DREUC 1997	IGNITION
BE5DRLEDS 1996	IGNITION
BE5DRLEUC 1997	IGNITION
BE6DRECR 1998	IGNITION
BE6DREDS 1996	IGNITION

BE6DREUC 1997	IGNITION
BE6DRLECR 1998	IGNITION
BE6DRLEDS 1996	IGNITION
BE6DRLEUC 1997	IGNITION
BE6REDS 1996	IGNITION
BE6RLEDS 1996	IGNITION
BE8RCB 1997	IGNITION
BE8RCH 1996	IGNITION
BE8RCLB 1997	IGNITION
BE8RCLH 1996	IGNITION
BE8RCLT 1998	IGNITION
BE8RCT 1998	IGNITION
BE8REDS 1996	IGNITION
BE8RLEDS 1996	IGNITION
BE8SRLEDS 1996	IGNITION
BJ10EEDD 1996	IGNITION - ELECTRIC
BJ10EEDD 1996	IGNITION - ROPE
BJ10ELEDD 1996	IGNITION - ELECTRIC
BJ10ELEDD 1996	IGNITION - ROPE
BJ10REDD 1996	IGNITION - ELECTRIC
BJ10REDD 1996	IGNITION - ROPE
BJ10RELEDD 1996	IGNITION - ELECTRIC
BJ10RELEDD 1996	IGNITION - ROPE
BJ10RELEUS 1997	IGNITION - ELECTRIC
BJ10RELEUS 1997	IGNITION - ROPE
BJ10RHLSDA	IGNITION
BJ10RHLSDA - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSOR	IGNITION
BJ10RHLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSC	IGNITION
BJ10RHLSC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHLSTS	IGNITION
BJ10RHLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSDA	IGNITION
BJ10RHSDA - FR	22-5_SYSTÈME D'ALLUMAGE

BJ10RHSOR	IGNITION
BJ10RHSOR - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSRC	IGNITION
BJ10RHSRC - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RHSTS	IGNITION
BJ10RHSTS - FR	22-5_SYSTÈME D'ALLUMAGE
BJ10RLEDD 1996	IGNITION - ELECTRIC
BJ10RLEDD 1996	IGNITION - ROPE
BJ10SELEDD 1996	IGNITION - ELECTRIC
BJ10SELEDD 1996	IGNITION - ROPE
BJ15EEDS 1996	IGNITION - ELECTRIC
BJ15EEDS 1996	IGNITION - ROPE
BJ15ELEDS 1996	IGNITION - ELECTRIC
BJ15ELEDS 1996	IGNITION - ROPE
BJ15REDS 1996	IGNITION - ELECTRIC
BJ15REDS 1996	IGNITION - ROPE
BJ15RELEUC 1997	IGNITION - ELECTRIC
BJ15RELEUC 1997	IGNITION - ROPE
BJ15RLEDS 1996	IGNITION - ELECTRIC
BJ15RLEDS 1996	IGNITION - ROPE
BJ20SEECB 1998	IGNITION
BJ20SEEDA 1996	IGNITION
BJ20SEEUM 1997	IGNITION
BJ20SELECB 1998	IGNITION
BJ20SELEDA 1996	IGNITION
BJ20SELEUM 1997	IGNITION
BJ20SRECB 1998	IGNITION
BJ20SREDA 1996	IGNITION
BJ20SREUM 1997	IGNITION
BJ20SRLECB 1998	IGNITION
BJ20SRLEDA 1996	IGNITION
BJ20SRLEUM 1997	IGNITION
BJ25BAECM 1998	IGNITION
BJ25BAEDR 1996	IGNITION
BJ25BAEUA 1997	IGNITION

BJ25BALECM 1998	IGNITION
BJ25BALEDR 1996	IGNITION
BJ25BALEUA 1997	IGNITION
BJ25BREDC 1996	IGNITION
BJ25BRLED C 1996	IGNITION
BJ25EECE 1998	IGNITION
BJ25EEDM 1996	IGNITION
BJ25EEED 1999	IGNITION
BJ25EEEN 1999	IGNITION
BJ25EEUB 1997	IGNITION
BJ25ELECE 1998	IGNITION
BJ25ELED M 1996	IGNITION
BJ25ELEED 1999	IGNITION
BJ25ELEEN 1999	IGNITION
BJ25ELEUB 1997	IGNITION
BJ25ELSIC elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ25ELSSS Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ25EREDEC 1996	IGNITION
BJ25ERLED C 1996	IGNITION
BJ25ESIC elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ25ESSS Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ25EVLSIC elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ25EVSIC elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ30BAECS 1998	IGNITION
BJ30BAEDE 1996	IGNITION
BJ30BAEEC 1999	IGNITION
BJ30BAEEN 1999	IGNITION
BJ30BAEUD 1997	IGNITION
BJ30BALECS 1998	IGNITION
BJ30BALEDE 1996	IGNITION
BJ30BALEUD 1997	IGNITION
BJ30EECS 1998	IGNITION
BJ30EEDE 1996	IGNITION
BJ30EEE C 1999	IGNITION
BJ30EEEN 1999	IGNITION

BJ30EEUD 1997	IGNITION
BJ30ELECS 1998	IGNITION
BJ30ELEDE 1996	IGNITION
BJ30ELEEC 1999	IGNITION
BJ30ELEEN 1999	IGNITION
BJ30ELEUD 1997	IGNITION
BJ30ELSIA elec start, remote, 20 in shaft, n/a usa 2001	IGNITION
BJ30ELSSR Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION
BJ30ESIA elec start, remote, 15 in shaft, n/a usa 2001	IGNITION
BJ30ESSR Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION
BJ30EVLSIA elec start, remote, 20 in shaft, wht, n/a usa 2001	IGNITION
BJ30EVSIA elec start, remote, 15 in shaft, wht, n/a usa 2001	IGNITION
BJ40EECR 1998	IGNITION SYSTEM -- ROPE START
BJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40EEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40EEUC 1997	IGNITION SYSTEM - ROPE START
BJ40ELECR 1998	IGNITION SYSTEM -- ROPE START
BJ40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40ELEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40ELEUC 1997	IGNITION SYSTEM - ROPE START
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ40TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ40TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ4RDHEDS 1996	MAGNETO
BJ4RDHLEDS 1996	MAGNETO
BJ50BEEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50BELEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50EEER 1999	IGNITION SYSTEM -- ROPE START

BJ50ELEER 1999	IGNITION SYSTEM -- ROPE START
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50ESECC 1998	IGNITION SYSTEM -- ROPE START
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50PLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50RLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50RLEEA 1999	IGNITION SYSTEM -- ROPE START
BJ50RLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	IGNITION SYSTEM - ROPE START
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	IGNITION SYSTEM - ROPE START
BJ50TLECR 1998	IGNITION SYSTEM -- ROPE START
BJ50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
BJ50TLEUC 1997	IGNITION SYSTEM - ROPE START
BJ50TSLECC 1998	IGNITION SYSTEM -- ROPE START
BJ50TSLEUS 1997	IGNITION SYSTEM - ROPE START
BJ5DREDS 1996	IGNITION
BJ5DREUC 1997	IGNITION
BJ5DRLEDS 1996	IGNITION
BJ5DRLEUC 1997	IGNITION
BJ6DRECR 1998	IGNITION
BJ6DREDS 1996	IGNITION
BJ6DREUC 1997	IGNITION
BJ6DRLECR 1998	IGNITION
BJ6DRLEDS 1996	IGNITION
BJ6DRLEUC 1997	IGNITION
BJ6REDS 1996	IGNITION
BJ6RLEDS 1996	IGNITION
BJ8RCB 1997	IGNITION
BJ8RCH 1996	IGNITION
BJ8RCLB 1997	IGNITION
BJ8RCLH 1996	IGNITION

BJ8RCLT 1998	IGNITION
BJ8RCT 1998	IGNITION
BJ8REDS 1996	IGNITION
BJ8RLEDS 1996	IGNITION
BJ8SRLEDS 1996	IGNITION
E10EECC 1998	IGNITION -- ELECTRIC
E10EECC 1998	IGNITION -- ROPE
E10EEDD 1996	IGNITION - ELECTRIC
E10EEDD 1996	IGNITION - ROPE
E10EEOE 1995	IGNITION - ELECTRIC
E10EEOE 1995	IGNITION - ROPE
E10EERB 1994	IGNITION - ELECTRIC
E10EERB 1994	IGNITION - ROPE
E10EETM 1993	IGNITION - ELECTRIC
E10EETM 1993	IGNITION - ROPE
E10EEUS 1997	IGNITION - ELECTRIC
E10EEUS 1997	IGNITION - ROPE
E10ELECC 1998	IGNITION -- ELECTRIC
E10ELECC 1998	IGNITION -- ROPE
E10ELEDD 1996	IGNITION - ELECTRIC
E10ELEDD 1996	IGNITION - ROPE
E10ELEOE 1995	IGNITION - ELECTRIC
E10ELEOE 1995	IGNITION - ROPE
E10ELERB 1994	IGNITION - ELECTRIC
E10ELERB 1994	IGNITION - ROPE
E10ELETM 1993	IGNITION - ELECTRIC
E10ELETM 1993	IGNITION - ROPE
E10ELEUS 1997	IGNITION - ELECTRIC
E10ELEUS 1997	IGNITION - ROPE
E10RECC 1998	IGNITION -- ELECTRIC
E10RECC 1998	IGNITION -- ROPE
E10REDD 1996	IGNITION - ELECTRIC
E10REDD 1996	IGNITION - ROPE
E10RELECC 1998	IGNITION -- ELECTRIC
E10RELECC 1998	IGNITION -- ROPE

E10RELEDD 1996	IGNITION - ELECTRIC
E10RELEDD 1996	IGNITION - ROPE
E10RELEOE 1995	IGNITION - ELECTRIC
E10RELEOE 1995	IGNITION - ROPE
E10RELEROB 1994	IGNITION - ELECTRIC
E10RELEROB 1994	IGNITION - ROPE
E10RELETM 1993	IGNITION - ELECTRIC
E10RELETM 1993	IGNITION - ROPE
E10RELEUS 1997	IGNITION - ELECTRIC
E10RELEUS 1997	IGNITION - ROPE
E10REOE 1995	IGNITION - ELECTRIC
E10REOE 1995	IGNITION - ROPE
E10RERB 1994	IGNITION - ELECTRIC
E10RERB 1994	IGNITION - ROPE
E10RETM 1993	IGNITION - ELECTRIC
E10RETM 1993	IGNITION - ROPE
E10REUS 1997	IGNITION - ELECTRIC
E10REUS 1997	IGNITION - ROPE
E10RLECC 1998	IGNITION -- ELECTRIC
E10RLECC 1998	IGNITION -- ROPE
E10RLEDD 1996	IGNITION - ELECTRIC
E10RLEDD 1996	IGNITION - ROPE
E10RLEOE 1995	IGNITION - ELECTRIC
E10RLEOE 1995	IGNITION - ROPE
E10RLEROB 1994	IGNITION - ELECTRIC
E10RLEROB 1994	IGNITION - ROPE
E10RELETM 1993	IGNITION - ELECTRIC
E10RELETM 1993	IGNITION - ROPE
E10RLEUS 1997	IGNITION - ELECTRIC
E10RLEUS 1997	IGNITION - ROPE
E10SELECC 1998	IGNITION -- ELECTRIC
E10SELECC 1998	IGNITION -- ROPE
E10SELEDD 1996	IGNITION - ELECTRIC
E10SELEDD 1996	IGNITION - ROPE
E10SELEOE 1995	IGNITION - ELECTRIC

E10SELEOE 1995	IGNITION - ROPE
E10SELERB 1994	IGNITION - ELECTRIC
E10SELERB 1994	IGNITION - ROPE
E10SELETM 1993	IGNITION - ELECTRIC
E10SELETM 1993	IGNITION - ROPE
E10SELEUS 1997	IGNITION - ELECTRIC
E10SELEUS 1997	IGNITION - ROPE
E15EECR 1998	IGNITION -- ELECTRIC
E15EECR 1998	IGNITION -- ROPE
E15EEDS 1996	IGNITION - ELECTRIC
E15EEDS 1996	IGNITION - ROPE
E15EEOD 1995	IGNITION - ELECTRIC
E15EEOD 1995	IGNITION - ROPE
E15EEERE 1994	IGNITION - ELECTRIC
E15EEERE 1994	IGNITION - ROPE
E15EETB 1993	IGNITION - ELECTRIC
E15EETB 1993	IGNITION - ROPE
E15EEUC 1997	IGNITION - ELECTRIC
E15EEUC 1997	IGNITION - ROPE
E15ELECR 1998	IGNITION -- ELECTRIC
E15ELECR 1998	IGNITION -- ROPE
E15ELEDS 1996	IGNITION - ELECTRIC
E15ELEDS 1996	IGNITION - ROPE
E15ELEOD 1995	IGNITION - ELECTRIC
E15ELEOD 1995	IGNITION - ROPE
E15ELERE 1994	IGNITION - ELECTRIC
E15ELERE 1994	IGNITION - ROPE
E15ELETB 1993	IGNITION - ELECTRIC
E15ELETB 1993	IGNITION - ROPE
E15ELEUC 1997	IGNITION - ELECTRIC
E15ELEUC 1997	IGNITION - ROPE
E15RECR 1998	IGNITION -- ELECTRIC
E15RECR 1998	IGNITION -- ROPE
E15REDS 1996	IGNITION - ELECTRIC
E15REDS 1996	IGNITION - ROPE

E15RELECR 1998	IGNITION -- ELECTRIC
E15RELECR 1998	IGNITION -- ROPE
E15RELEDS 1996	IGNITION - ELECTRIC
E15RELEDS 1996	IGNITION - ROPE
E15RELEOD 1995	IGNITION - ELECTRIC
E15RELEOD 1995	IGNITION - ROPE
E15RELERE 1994	IGNITION - ELECTRIC
E15RELERE 1994	IGNITION - ROPE
E15RELETB 1993	IGNITION - ELECTRIC
E15RELETB 1993	IGNITION - ROPE
E15RELEUC 1997	IGNITION - ELECTRIC
E15RELEUC 1997	IGNITION - ROPE
E15REOD 1995	IGNITION - ELECTRIC
E15REOD 1995	IGNITION - ROPE
E15RERE 1994	IGNITION - ELECTRIC
E15RERE 1994	IGNITION - ROPE
E15RETB 1993	IGNITION - ELECTRIC
E15RETB 1993	IGNITION - ROPE
E15REUC 1997	IGNITION - ELECTRIC
E15REUC 1997	IGNITION - ROPE
E15RLECR 1998	IGNITION -- ELECTRIC
E15RLECR 1998	IGNITION -- ROPE
E15RLEDS 1996	IGNITION - ELECTRIC
E15RLEDS 1996	IGNITION - ROPE
E15RLEOD 1995	IGNITION - ELECTRIC
E15RLEOD 1995	IGNITION - ROPE
E15RLERE 1994	IGNITION - ELECTRIC
E15RLERE 1994	IGNITION - ROPE
E15RLETB 1993	IGNITION - ELECTRIC
E15RLETB 1993	IGNITION - ROPE
E15RLEUC 1997	IGNITION - ELECTRIC
E15RLEUC 1997	IGNITION - ROPE
E15WREES 1999	IGNITION
E15WRLEES 1999	IGNITION
E15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION

E15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
E15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION
E20CREDA 1996	IGNITION
E20CREIE 1991	IGNITION
E20CREND 1992	IGNITION
E20CREOR 1995	IGNITION
E20CRERC 1994	IGNITION
E20CRETS 1993	IGNITION
E20CREUM 1997	IGNITION
E20CRLEDA 1996	IGNITION
E20CRLEIE 1991	IGNITION
E20CRLEND 1992	IGNITION
E20CRLEOR 1995	IGNITION
E20CRLERC 1994	IGNITION
E20CRLETS 1993	IGNITION
E20CRLEUM 1997	IGNITION
E20EEIE 1991	IGNITION
E20EEND 1992	IGNITION
E20EEOR 1995	IGNITION
E20EERC 1994	IGNITION
E20EEETS 1993	IGNITION
E20ELEIE 1991	IGNITION
E20ELEND 1992	IGNITION
E20ELEOR 1995	IGNITION
E20ELERC 1994	IGNITION
E20ELETS 1993	IGNITION
E25EECE 1998	IGNITION
E25EEDM 1996	IGNITION
E25EEID 1991	IGNITION
E25EEENS 1992	IGNITION
E25EEOA 1995	IGNITION
E25EERR 1994	IGNITION
E25EETC 1993	IGNITION
E25EEUB 1997	IGNITION

E25ELECE 1998	IGNITION
E25ELEDM 1996	IGNITION
E25ELEID 1991	IGNITION
E25ELENS 1992	IGNITION
E25ELEOA 1995	IGNITION
E25ELERR 1994	IGNITION
E25ELET C 1993	IGNITION
E25ELEUB 1997	IGNITION
E25JRECA 1998	IGNITION
E25JREDC 1996	IGNITION
E25JREOS 1995	IGNITION
E25RECB 1998	IGNITION
E25REDA 1996	IGNITION
E25REIE 1991	IGNITION
E25REND 1992	IGNITION
E25REOR 1995	IGNITION
E25RERC 1994	IGNITION
E25RETS 1993	IGNITION
E25REUM 1997	IGNITION
E25RLECB 1998	IGNITION
E25RLEDA 1996	IGNITION
E25RLEIE 1991	IGNITION
E25RLEND 1992	IGNITION
E25RLEOR 1995	IGNITION
E25RLERC 1994	IGNITION
E25RLETS 1993	IGNITION
E25RLEUM 1997	IGNITION
E25RWEDC 1996	IGNITION - H25FP
E25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWEIM 1991	IGNITION
E25RWENB 1992	IGNITION
E25RWEOS 1995	IGNITION - H25FP
E25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP
E25RWERD 1994	IGNITION - 25RW
E25RWETE 1993	IGNITION - 25RW

E25RWEUR 1997	IGNITION - H25FP
E25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25RWLEDC 1996	IGNITION - H25FP
E25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
E25RWLEIM 1991	IGNITION
E25RWLENB 1992	IGNITION
E25RWLEOS 1995	IGNITION - H25FP
E25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
E25RWLERD 1994	IGNITION - 25RW
E25RWLETE 1993	IGNITION - 25RW
E25RWLEUR 1997	IGNITION - H25FP
E25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
E25TEECB 1998	IGNITION
E25TEEDA 1996	IGNITION
E25TEEIE 1991	IGNITION
E25TEEND 1992	IGNITION
E25TEEOR 1995	IGNITION
E25TEERC 1994	IGNITION
E25TEETS 1993	IGNITION
E25TEEUM 1997	IGNITION
E25TELECB 1998	IGNITION
E25TELEDA 1996	IGNITION
E25TELEIE 1991	IGNITION
E25TELEND 1992	IGNITION
E25TELEOR 1995	IGNITION
E25TELETS 1993	IGNITION
E25TELEM 1997	IGNITION
E25WREEN 1999	IGNITION
E25WREES 1999	IGNITION
E25WRLEEN 1999	IGNITION
E25WRLEES 1999	IGNITION
E25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
E25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION

E28ESLEDR 1996	IGNITION
E28ESLEIB 1991	IGNITION
E28ESLENE 1992	IGNITION
E28ESLEOC 1995	IGNITION
E28ESLERS 1994	IGNITION
E28ESLETD 1993	IGNITION
E30EECS 1998	IGNITION
E30EEDE 1996	IGNITION
E30EEIC 1991	IGNITION
E30EEENR 1992	IGNITION
E30EEOB 1995	IGNITION
E30EERM 1994	IGNITION
E30EETA 1993	IGNITION
E30EEUD 1997	IGNITION
E30ELECS 1998	IGNITION
E30ELEDE 1996	IGNITION
E30ELEIC 1991	IGNITION
E30ELENR 1992	IGNITION
E30ELEOB 1995	IGNITION
E30ELERM 1994	IGNITION
E30ELETA 1993	IGNITION
E30ELEUD 1997	IGNITION
E30REDE 1996	IGNITION
E30REIC 1991	IGNITION
E30RENR 1992	IGNITION
E30REOB 1995	IGNITION
E30RERM 1994	IGNITION
E30RETA 1993	IGNITION
E30REUD 1997	IGNITION
E30RLEDE 1996	IGNITION
E30RLEIC 1991	IGNITION
E30RLENR 1992	IGNITION
E30RLEOB 1995	IGNITION
E30RLERM 1994	IGNITION
E30RLETA 1993	IGNITION

E30RLEUD 1997	IGNITION
E30TEECS 1998	IGNITION
E30TEEDE 1996	IGNITION
E30TEEIC 1991	IGNITION
E30TEENR 1992	IGNITION
E30TEEOB 1995	IGNITION
E30TEERM 1994	IGNITION
E30TEETA 1993	IGNITION
E30TEEUD 1997	IGNITION
E30TELECB 1998	IGNITION
E30TELEDE 1996	IGNITION
E30TELEIC 1991	IGNITION
E30TELENR 1992	IGNITION
E30TELEOB 1995	IGNITION
E30TELTERM 1994	IGNITION
E30TELETA 1993	IGNITION
E30TELEUD 1997	IGNITION
E35REIC 1991	IGNITION
E35RENRR 1992	IGNITION
E35RERM 1994	IGNITION
E35RETA 1993	IGNITION
E35RLEIC 1991	IGNITION
E35RLENR 1992	IGNITION
E35RLTERM 1994	IGNITION
E35RLETA 1993	IGNITION
E40EEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40EEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40EERE 1994	IGNITION SYSTEM - 40 ROPE START
E40EERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40EETB 1993	IGNITION SYSTEM - 40 ROPE START
E40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELECR 1998	IGNITION SYSTEM -- ROPE START
E40ELEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START

E40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40ELEUC 1997	IGNITION SYSTEM - ROPE START
E40JRECA 1998	IGNITION SYSTEM
E40JREDC 1996	IGNITION SYSTEM
E40JREOS 1995	IGNITION SYSTEM
E40JREUR 1997	IGNITION SYSTEM
E40RECR 1998	IGNITION SYSTEM -- ROPE START
E40REDS 1996	IGNITION SYSTEM - 40 ROPE START
E40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RETB 1993	IGNITION SYSTEM - 40 ROPE START
E40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40REUC 1997	IGNITION SYSTEM - ROPE START
E40RLECR 1998	IGNITION SYSTEM -- ROPE START
E40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40RLEUC 1997	IGNITION SYSTEM - ROPE START
E40TEECR 1998	IGNITION SYSTEM -- ROPE START
E40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START

E40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TEEUC 1997	IGNITION SYSTEM - ROPE START
E40TELECR 1998	IGNITION SYSTEM -- ROPE START
E40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TELEUC 1997	IGNITION SYSTEM - ROPE START
E40TLECR 1998	IGNITION SYSTEM -- ROPE START
E40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TLEUC 1997	IGNITION SYSTEM - ROPE START
E40TTLECR 1998	IGNITION SYSTEM -- ROPE START
E40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY

E40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
E40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLETB 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
E40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E40TTLEUC 1997	IGNITION SYSTEM - ROPE START
E40WREES 1999	IGNITION SYSTEM
E40WRLEES 1999	IGNITION SYSTEM
E40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E40WRYEES 1999	IGNITION SYSTEM
E40WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E45RCENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCENM 1992	IGNITION SYSTEM - ROPE START
E45RCEOD 1995	IGNITION SYSTEM
E45RCERE 1994	IGNITION SYSTEM
E45RCETB 1993	IGNITION SYSTEM
E45RCLEDS 1996	IGNITION SYSTEM
E45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
E45RCLENM 1992	IGNITION SYSTEM - ROPE START
E45RCLEOD 1995	IGNITION SYSTEM
E45RCLERE 1994	IGNITION SYSTEM
E45RCLETB 1993	IGNITION SYSTEM
E45RCLEUC 1997	IGNITION SYSTEM
E45WMLENM 1992	IGNITION SYSTEM - ELECTRIC
E45WMLENM 1992	IGNITION SYSTEM - ROPE START
E48ESLEDC 1996	IGNITION SYSTEM
E48ESLEOS 1995	IGNITION SYSTEM
E48ESLERD 1994	IGNITION SYSTEM
E48ESLETE 1993	IGNITION SYSTEM

E4RDHEOD 1995	MAGNETO
E4RDHERE 1994	MAGNETO
E4RDHETB 1993	IGNITION
E4RDHLEOD 1995	MAGNETO
E4RDHLERE 1994	MAGNETO
E4RDHLETB 1993	IGNITION
E50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
E50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50ESLECC 1998	IGNITION SYSTEM -- ROPE START
E50ESLEUR 1997	IGNITION SYSTEM - ROPE START
E50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50JERE 1994	IGNITION SYSTEM - 40 ROPE START
E50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JETB 1993	IGNITION SYSTEM - 40 ROPE START
E50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50JEUC 1997	IGNITION SYSTEM - ROPE START
E50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY

E50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLECR 1998	IGNITION SYSTEM -- ROPE START
E50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
E50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
E50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
E50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
E50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
E50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
E50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
E50TLEUC 1997	IGNITION SYSTEM - ROPE START
E50TSLECC 1998	IGNITION SYSTEM -- ROPE START
E50TSLEUS 1997	IGNITION SYSTEM - ROPE START
E55RSCL 1997	IGNITION SYSTEM
E55RSLG 1995	IGNITION SYSTEM
E55RSLW 1996	IGNITION SYSTEM
E55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
E55RWLENM 1992	IGNITION SYSTEM - ROPE START
E55RWLERE 1994	IGNITION SYSTEM
E55RWLETB 1993	IGNITION SYSTEM
E55WREES 1999	IGNITION SYSTEM
E55WRLEES 1999	IGNITION SYSTEM
E55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
E55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
E55WRYEES 1999	IGNITION SYSTEM
E55WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM

E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
E5DRECR 1998	IGNITION
E5DRLECR 1998	IGNITION
E6RECR 1998	IGNITION
E6REDS 1996	IGNITION
E6RENM 1992	IGNITION
E6REOD 1995	IGNITION
E6RERE 1994	IGNITION
E6RETB 1993	IGNITION
E6REUC 1997	IGNITION
E6RLECR 1998	IGNITION
E6RLEDS 1996	IGNITION
E6RLENM 1992	IGNITION
E6RLEOD 1995	IGNITION
E6RLERE 1994	IGNITION
E6RLETB 1993	IGNITION
E6RLEUC 1997	IGNITION
E6SLEDS 1996	IGNITION
E6SLENM 1992	IGNITION
E6SLEOD 1995	IGNITION
E6SLERE 1994	IGNITION
E6SLETB 1993	IGNITION
E8DREEA 1999	IGNITION
E8DRSSM Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
E8RECR 1998	IGNITION
E8REDS 1996	IGNITION
E8RENM 1992	IGNITION
E8REOD 1995	IGNITION
E8RERE 1994	IGNITION
E8RETB 1993	IGNITION
E8REUC 1997	IGNITION
E8RLECR 1998	IGNITION
E8RLEDS 1996	IGNITION
E8RLENM 1992	IGNITION
E8RLEOD 1995	IGNITION

E8RLERE 1994	IGNITION
E8RLETB 1993	IGNITION
E8RLEUC 1997	IGNITION
E8SRLECA 1998	IGNITION
E8SRLEDS 1996	IGNITION
E8SRLENM 1992	IGNITION
E8SRLEOD 1995	IGNITION
E8SRLERE 1994	IGNITION
E8SRLETB 1993	IGNITION
E8SRLEUC 1997	IGNITION
E8WREES 1999	IGNITION
E8WRLEES 1999	IGNITION
E8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
E8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
E8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
E8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
ELECTRICAL	AC LIGHTING KIT, 2.4 AMP - 6 THRU 40 HP (Johnson 2-Stroke)
ELECTRICAL	AC LIGHTING KIT, 5.4 AMP - 9.9,15 HP (2-Stroke)
ELECTRICAL	BATTERY CHARGING KIT - 6.8 HP (2-Stroke)
ELECTRICAL	ELECTRIC START KIT - 9.9,15 HP (2-Stroke)
ELECTRICAL	ELECTRIC START KIT - 40,50 HP (Johnson 2-Stroke)
ELECTRICAL	AC LIGHTING KIT, 5.4 AMP - 9.9,15 HP (2-Stroke)
ELECTRICAL	ELECTRIC START KIT - 9.9,15 HP (2-Stroke)
ELECTRICAL 1993	AC LIGHTING KIT - 9.9, 15
ELECTRICAL 1993	BATTERY CHARGE KIT - 9.9, 15
ELECTRICAL 1993	TILLER ELECTRIC STARTING KIT - 9.9, 15
ELECTRICAL 1994	AC LIGHTING KIT - 9.9, 15
ELECTRICAL 1994	BATTERY CHARGE KIT - 9.9, 15
ELECTRICAL 1994	TILLER ELECTRIC STARTING KIT - 9.9, 15
ELECTRICAL 1995	AC LIGHTING KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1995	BATTERY CHARGE KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1995	TILLER ELECTRIC STARTING KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1996	AC LIGHTING KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1996	BATTERY CHARGE KIT - 9.9, 15 (2-STROKE)

ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1996	TILLER ELECTRIC STARTING KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1997	AC LIGHTING KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1997	BATTERY CHARGE KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 1997	TILLER ELECTRIC STARTING KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 1998	AC LIGHTING KIT -- 5 THRU 55
ELECTRICAL 1998	AC LIGHTING KIT -- 9.9, 15 (2-STROKE)
ELECTRICAL 1998	BATTERY CHARGE KIT -- 9.9, 15 (2-STROKE)
ELECTRICAL 1998	BATTERY CHARGING KIT -- 5, 6, 8 (2-CYCLE)
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1998	TILLER ELECTRIC STARTING KIT -- 9.9, 15 (2-STROKE)
ELECTRICAL 1999	BATTERY CHARGING KIT -- 6, 8 (2-CYCLE)
ELECTRICAL 1999	BATTERY CHARGE KIT -- 9.9, 15 (2-STROKE)
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 40, 50
ELECTRICAL 1999	TILLER ELECTRIC STARTING KIT -- 9.9, 15 (2-STROKE)
ELECTRICAL 1999	AC LIGHTING KIT -- 6 THRU 55
ELECTRICAL 1999	AC LIGHTING KIT -- 9.9, 15 (2-STROKE)
ELECTRICAL 2000	BATTERY CHARGING KIT - 6, 8 (2-CYCLE)
ELECTRICAL 2000	BATTERY CHARGE KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 40, 50
ELECTRICAL 2000	TILLER ELECTRIC STARTING KIT - 9.9, 15 (2-STROKE)
ELECTRICAL 2000	AC LIGHTING KIT - 6 THRU 55
ELECTRICAL 2000	AC LIGHTING KIT - 9.9, 15 (2-STROKE)
HE15KCF 1997	IGNITION
HE15KCLF 1997	IGNITION
HE15KCLN 1996	IGNITION
HE15KCLO 1998	IGNITION
HE15KCN 1996	IGNITION
HE15KCO 1998	IGNITION
HE15RPLW 1997	IGNITION
HE15RPW 1997	IGNITION
HE20CREDA 1996	IGNITION
HE20CRLEDA 1996	IGNITION
HE25FPO 1996	IGNITION - H25FP

HE25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HE25FPV 1997	IGNITION - H25FP
HE25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HE25RAEDA 1996	IGNITION
HE25RAEUM 1997	IGNITION
HE25REDA 1996	IGNITION
HE25RLEDA 1996	IGNITION
HE25RSLO 1996	IGNITION - H25FP
HE25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HE25RSLV 1997	IGNITION - H25FP
HE25RSLV 1997	IGNITION - 25RS, 25RW, S25RP
HE25TELEDA 1996	IGNITION
HE30REDE 1996	IGNITION
HE30RLEDE 1996	IGNITION
HE40REDS 1996	IGNITION SYSTEM - 40 ROPE START
HE40REUC 1997	IGNITION SYSTEM - ROPE START
HE40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
HE40RLEUC 1997	IGNITION SYSTEM - ROPE START
HE45RCLEDS 1996	IGNITION SYSTEM
HE45RCLEUC 1997	IGNITION SYSTEM
HE55RSLC 1997	IGNITION SYSTEM
HE55RSLW 1996	IGNITION SYSTEM
HE55WMLM 1996	IGNITION SYSTEM
HE55WMLZ 1997	IGNITION SYSTEM
HJ15KCF 1997	IGNITION
HJ15KCLF 1997	IGNITION
HJ15KCLN 1996	IGNITION
HJ15KCLO 1998	IGNITION
HJ15KCN 1996	IGNITION
HJ15KCO 1998	IGNITION
HJ15RPLW 1997	IGNITION
HJ15RPW 1997	IGNITION
HJ20CREDA 1996	IGNITION
HJ20CRLEDA 1996	IGNITION
HJ25FPO 1996	IGNITION - H25FP

HJ25FPO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25FPV 1997	IGNITION - H25FP
HJ25FPV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RAEDA 1996	IGNITION
HJ25RAEUM 1997	IGNITION
HJ25RLEDA 1996	IGNITION
HJ25RLSV 1997	IGNITION - H25FP
HJ25RLSV 1997	IGNITION - 25RS, 25RW, S25RP
HJ25RSLO 1996	IGNITION - H25FP
HJ25RSLO 1996	IGNITION - 25RS - 25RW - S25RP
HJ25TELEDA 1996	IGNITION
HJ30REDE 1996	IGNITION
HJ30RLEDE 1996	IGNITION
HJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START
HJ40REUC 1997	IGNITION SYSTEM - ROPE START
HJ40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
HJ40RLEUC 1997	IGNITION SYSTEM - ROPE START
HJ45RCLEDS 1996	IGNITION SYSTEM
HJ45RCLEUC 1997	IGNITION SYSTEM
HJ55RSLC 1997	IGNITION SYSTEM
HJ55RSLW 1996	IGNITION SYSTEM
HJ55WMLM 1996	IGNITION SYSTEM
HJ55WMLZ 1997	IGNITION SYSTEM
J10EECC 1998	IGNITION -- ELECTRIC
J10EECC 1998	IGNITION -- ROPE
J10EEDD 1996	IGNITION - ELECTRIC
J10EEDD 1996	IGNITION - ROPE
J10EEOE 1995	IGNITION - ELECTRIC
J10EEOE 1995	IGNITION - ROPE
J10EERB 1994	IGNITION - ELECTRIC
J10EERB 1994	IGNITION - ROPE
J10EETM 1993	IGNITION - ELECTRIC
J10EETM 1993	IGNITION - ROPE
J10EEUS 1997	IGNITION - ELECTRIC
J10EEUS 1997	IGNITION - ROPE

J10ELECC 1998	IGNITION -- ELECTRIC
J10ELECC 1998	IGNITION -- ROPE
J10ELEDD 1996	IGNITION - ELECTRIC
J10ELEDD 1996	IGNITION - ROPE
J10ELEER 1999	IGNITION -- ROPE
J10ELEER 1999	IGNITION -- ELECTRIC
J10ELEOE 1995	IGNITION - ELECTRIC
J10ELEOE 1995	IGNITION - ROPE
J10ELERB 1994	IGNITION - ELECTRIC
J10ELERB 1994	IGNITION - ROPE
J10ELETM 1993	IGNITION - ELECTRIC
J10ELETM 1993	IGNITION - ROPE
J10ELEUS 1997	IGNITION - ELECTRIC
J10ELEUS 1997	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J10ELSIM elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION - ROPE
J10ELSSA Electric Start, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10EVLSIC elec start, 20 in shaft, wht 2001	IGNITION - ROPE
J10EVLSIC elec start, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10RECC 1998	IGNITION -- ELECTRIC
J10RECC 1998	IGNITION -- ROPE
J10REDD 1996	IGNITION - ELECTRIC
J10REDD 1996	IGNITION - ROPE
J10REER 1999	IGNITION -- ROPE
J10REER 1999	IGNITION -- ELECTRIC
J10RELECC 1998	IGNITION -- ELECTRIC
J10RELECC 1998	IGNITION -- ROPE
J10RELEDD 1996	IGNITION - ELECTRIC
J10RELEDD 1996	IGNITION - ROPE
J10RELEOE 1995	IGNITION - ELECTRIC
J10RELEOE 1995	IGNITION - ROPE
J10RELERB 1994	IGNITION - ELECTRIC

J10RELERB 1994	IGNITION - ROPE
J10RELETM 1993	IGNITION - ELECTRIC
J10RELETM 1993	IGNITION - ROPE
J10RELEUS 1997	IGNITION - ELECTRIC
J10RELEUS 1997	IGNITION - ROPE
J10REOE 1995	IGNITION - ELECTRIC
J10REOE 1995	IGNITION - ROPE
J10RERB 1994	IGNITION - ELECTRIC
J10RERB 1994	IGNITION - ROPE
J10RETM 1993	IGNITION - ELECTRIC
J10RETM 1993	IGNITION - ROPE
J10REUS 1997	IGNITION - ELECTRIC
J10REUS 1997	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ROPE
J10RGTSIC elec start,15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RGTSSS Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10RLECC 1998	IGNITION -- ELECTRIC
J10RLECC 1998	IGNITION -- ROPE
J10RLEDD 1996	IGNITION - ELECTRIC
J10RLEDD 1996	IGNITION - ROPE
J10RLEER 1999	IGNITION -- ROPE
J10RLEER 1999	IGNITION -- ELECTRIC
J10RLEOE 1995	IGNITION - ELECTRIC
J10RLEOE 1995	IGNITION - ROPE
J10RLERB 1994	IGNITION - ELECTRIC
J10RLERB 1994	IGNITION - ROPE
J10RELETM 1993	IGNITION - ELECTRIC
J10RELETM 1993	IGNITION - ROPE
J10RELEUS 1997	IGNITION - ELECTRIC
J10RELEUS 1997	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ROPE
J10RLGTSIC elec start,20 in shaft, wht 2001	IGNITION - ELECTRIC
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10RLGTSSS Rope Start, Tiller, 20 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC

J10RLSDC	IGNITION
J10RLSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10RLSIM rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10RLSOS	IGNITION
J10RLSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSRD	IGNITION
J10RLSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10RLSSA Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10RLSTE	IGNITION
J10RLSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RLSUR	IGNITION
J10RLSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RSDC	IGNITION
J10RSDC - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10RSIM rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10RSOS	IGNITION
J10RSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSRD	IGNITION
J10RSRD - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10RSSA Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10RSTE	IGNITION
J10RSTE - FR	22-5_SYSTÈME D'ALLUMAGE
J10RSUR	IGNITION
J10RSUR - FR	02-5_SYSTÈME D'ALLUMAGE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE
J10RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J10RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE

J10RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J10SELECC 1998	IGNITION -- ELECTRIC
J10SELECC 1998	IGNITION -- ROPE
J10SELEDD 1996	IGNITION - ELECTRIC
J10SELEDD 1996	IGNITION - ROPE
J10SELEOE 1995	IGNITION - ELECTRIC
J10SELEOE 1995	IGNITION - ROPE
J10SELERB 1994	IGNITION - ELECTRIC
J10SELERB 1994	IGNITION - ROPE
J10SELETM 1993	IGNITION - ELECTRIC
J10SELETM 1993	IGNITION - ROPE
J10SELEUS 1997	IGNITION - ELECTRIC
J10SELEUS 1997	IGNITION - ROPE
J10TEEER 1999	IGNITION -- ROPE
J10TEEER 1999	IGNITION -- ELECTRIC
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
J10TEGSSS Electric Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TEGTSIC elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J10TELEER 1999	IGNITION -- ROPE
J10TELEER 1999	IGNITION -- ELECTRIC
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J10TELSIM elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J10TELSSA Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J10TESIM elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J10TESSA Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J10TVESIM elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15EECR 1998	IGNITION -- ELECTRIC
J15EECR 1998	IGNITION -- ROPE
J15EEDS 1996	IGNITION - ELECTRIC
J15EEDS 1996	IGNITION - ROPE

J15EEOD 1995	IGNITION - ELECTRIC
J15EEOD 1995	IGNITION - ROPE
J15EERE 1994	IGNITION - ELECTRIC
J15EERE 1994	IGNITION - ROPE
J15EETB 1993	IGNITION - ELECTRIC
J15EETB 1993	IGNITION - ROPE
J15EEUC 1997	IGNITION - ELECTRIC
J15EEUC 1997	IGNITION - ROPE
J15ELECR 1998	IGNITION -- ELECTRIC
J15ELECR 1998	IGNITION -- ROPE
J15ELEDS 1996	IGNITION - ELECTRIC
J15ELEDS 1996	IGNITION - ROPE
J15ELEEA 1999	IGNITION -- ROPE
J15ELEEA 1999	IGNITION -- ELECTRIC
J15ELEOD 1995	IGNITION - ELECTRIC
J15ELEOD 1995	IGNITION - ROPE
J15ELERE 1994	IGNITION - ELECTRIC
J15ELERE 1994	IGNITION - ROPE
J15ELETB 1993	IGNITION - ELECTRIC
J15ELETB 1993	IGNITION - ROPE
J15EEUC 1997	IGNITION - ELECTRIC
J15EEUC 1997	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ROPE
J15ELSIB elec start, remote, 20 in shaft 2001	IGNITION - ELECTRIC
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION - ROPE
J15ELSSM Electric Start, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15EVLSIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ROPE
J15EVLSIC elec start, remote, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15EVLSSS Electric Start, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15RECR 1998	IGNITION -- ELECTRIC
J15RECR 1998	IGNITION -- ROPE
J15REDS 1996	IGNITION - ELECTRIC
J15REDS 1996	IGNITION - ROPE
J15REEA 1999	IGNITION -- ROPE

J15REEA 1999	IGNITION -- ELECTRIC
J15RELECR 1998	IGNITION -- ELECTRIC
J15RELECR 1998	IGNITION -- ROPE
J15RELEDS 1996	IGNITION - ELECTRIC
J15RELEDS 1996	IGNITION - ROPE
J15RELEOD 1995	IGNITION - ELECTRIC
J15RELEOD 1995	IGNITION - ROPE
J15RELERE 1994	IGNITION - ELECTRIC
J15RELERE 1994	IGNITION - ROPE
J15RELETB 1993	IGNITION - ELECTRIC
J15RELETB 1993	IGNITION - ROPE
J15RELEUC 1997	IGNITION - ELECTRIC
J15RELEUC 1997	IGNITION - ROPE
J15REOD 1995	IGNITION - ELECTRIC
J15REOD 1995	IGNITION - ROPE
J15RERE 1994	IGNITION - ELECTRIC
J15RERE 1994	IGNITION - ROPE
J15RETB 1993	IGNITION - ELECTRIC
J15RETB 1993	IGNITION - ROPE
J15REUC 1997	IGNITION - ELECTRIC
J15REUC 1997	IGNITION - ROPE
J15RLECR 1998	IGNITION -- ELECTRIC
J15RLECR 1998	IGNITION -- ROPE
J15RLEDS 1996	IGNITION - ELECTRIC
J15RLEDS 1996	IGNITION - ROPE
J15RLEEA 1999	IGNITION -- ROPE
J15RLEEA 1999	IGNITION -- ELECTRIC
J15RLEOD 1995	IGNITION - ELECTRIC
J15RLEOD 1995	IGNITION - ROPE
J15RLERE 1994	IGNITION - ELECTRIC
J15RLERE 1994	IGNITION - ROPE
J15RLETB 1993	IGNITION - ELECTRIC
J15RLETB 1993	IGNITION - ROPE
J15RLEUC 1997	IGNITION - ELECTRIC
J15RLEUC 1997	IGNITION - ROPE

J15RLSDR	IGNITION
J15RLSDR - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15RLSIB rope start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15RLSOC	IGNITION
J15RLSOC - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSRS	IGNITION
J15RLSRS - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15RLSTD	IGNITION
J15RLSTD - FR	22-5_SYSTEME D'ALLUMAGE
J15RLSUA	IGNITION
J15RLSUA - FR	02-5_SYSTEME D'ALLUMAGE
J15RSDR	IGNITION
J15RSDR - FR	22-5_SYSTEME D'ALLUMAGE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15RSIB rope start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15RSOC	IGNITION
J15RSOC - FR	22-5_SYSTEME D'ALLUMAGE
J15RSRS	IGNITION
J15RSRS - FR	22-5_SYSTEME D'ALLUMAGE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15RSTD	IGNITION
J15RSTD - FR	22-5_SYSTEME D'ALLUMAGE
J15RSUA	IGNITION
J15RSUA - FR	02-5_SYSTEME D'ALLUMAGE
J15RTSDC	IGNITION
J15RTSDC - FR	22-5_SYSTEME D'ALLUMAGE
J15RTSOS	IGNITION
J15RTSOS - FR	22-5_SYSTEME D'ALLUMAGE
J15RTSUR	IGNITION
J15RTSUR - FR	02-5_SYSTEME D'ALLUMAGE
J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ROPE

J15RVLSIC rope start, tiller, 20 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION - ROPE
J15RVLSSS Rope Start, Tiller, 20 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15RVSIC rope start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION - ROPE
J15RVSSS Rope Start, Tiller, 15 IN. shaft, wht 2000	IGNITION-ELECTRIC
J15TEEEA 1999	IGNITION -- ROPE
J15TEEEA 1999	IGNITION -- ELECTRIC
J15TELEEA 1999	IGNITION -- ROPE
J15TELEEA 1999	IGNITION -- ELECTRIC
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ROPE
J15TELSIB elec start, tiller, 20 in shaft 2001	IGNITION - ELECTRIC
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION - ROPE
J15TELSSM Electric Start, Tiller, 20 IN. shaft 2000	IGNITION-ELECTRIC
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ROPE
J15TESIB elec start, tiller, 15 in shaft 2001	IGNITION - ELECTRIC
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION - ROPE
J15TESSM Electric Start, Tiller, 15 IN. shaft 2000	IGNITION-ELECTRIC
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ROPE
J15TVESIB elec start, tiller, 15 in shaft, wht 2001	IGNITION - ELECTRIC
J15WREES 1999	IGNITION
J15WRLEES 1999	IGNITION
J15WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J15WRLSOB	IGNITION
J15WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSRM	IGNITION
J15WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRLSSC Commercial, Rope Start, Tiller, 20 IN shaft 2000	IGNITION
J15WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J15WRSOB	IGNITION
J15WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSRM	IGNITION
J15WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J15WRSSC Commercial, Rope Start, Tiller, 15 IN shaft 2000	IGNITION

J20CREDA 1996	IGNITION
J20CREIE 1991	IGNITION
J20CREND 1992	IGNITION
J20CREOR 1995	IGNITION
J20CRERC 1994	IGNITION
J20CRETS 1993	IGNITION
J20CREUM 1997	IGNITION
J20CRLEDA 1996	IGNITION
J20CRLEIE 1991	IGNITION
J20CRLEND 1992	IGNITION
J20CRLEOR 1995	IGNITION
J20CRLERC 1994	IGNITION
J20CRLETS 1993	IGNITION
J20CRLEUM 1997	IGNITION
J20EEIE 1991	IGNITION
J20EEND 1992	IGNITION
J20EEOR 1995	IGNITION
J20EERC 1994	IGNITION
J20EETS 1993	IGNITION
J20ELEIE 1991	IGNITION
J20ELEND 1992	IGNITION
J20ELEOR 1995	IGNITION
J20ELERC 1994	IGNITION
J20ELETS 1993	IGNITION
J25EECE 1998	IGNITION
J25EEDM 1996	IGNITION
J25EEED 1999	IGNITION
J25EEEN 1999	IGNITION
J25EEID 1991	IGNITION
J25EEENS 1992	IGNITION
J25EEOA 1995	IGNITION
J25EERR 1994	IGNITION
J25EETC 1993	IGNITION
J25EEUB 1997	IGNITION
J25ELECE 1998	IGNITION

J25ELED M 1996	IGNITION
J25ELEED 1999	IGNITION
J25ELEEN 1999	IGNITION
J25ELEID 1991	IGNITION
J25ELENS 1992	IGNITION
J25ELEOA 1995	IGNITION
J25ELERR 1994	IGNITION
J25ELETC 1993	IGNITION
J25ELEUB 1997	IGNITION
J25ELSIC elec start, remote, 20 in shaft 2001	IGNITION
J25ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt 2002	IGNITION
J25ELSOB	IGNITION
J25ELSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSRM	IGNITION
J25ELSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25ELSSS Elec. Start, 20 IN. shaft 2000	IGNITION
J25ELSTA	IGNITION
J25ELSTA - FR	22-5_SYSTÈME D'ALLUMAGE
J25ESIC elec start, remote, 15 in shaft 2001	IGNITION
J25ESSS Elec. Start, 15 IN. shaft 2000	IGNITION
J25EVLSIC elec start, remote, 120 in shaft, wht 2001	IGNITION
J25EVSIC elec start, remote, 15 in shaft, wht 2001	IGNITION
J25GTESOC	IGNITION
J25GTESOC - FR	22-5_SYSTÈME D'ALLUMAGE
J25GTESRS	IGNITION
J25GTESRS - FR	22-5_SYSTÈME D'ALLUMAGE
J25JRECA 1998	IGNITION
J25JREDC 1996	IGNITION
J25JREEM 1999	IGNITION
J25JREEN 1999	IGNITION
J25JREOS 1995	IGNITION
J25JREUR 1997	IGNITION
J25JRSIE jet drive, rope start, tiller, 15 in shaft 2001	IGNITION

J25JRSSB Jet Drive,Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J25JRTSSS Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J25RECB 1998	IGNITION
J25REDA 1996	IGNITION
J25REEB 1999	IGNITION
J25REEN 1999	IGNITION
J25REIE 1991	IGNITION
J25REND 1992	IGNITION
J25REOR 1995	IGNITION
J25RERC 1994	IGNITION
J25RETS 1993	IGNITION
J25REUM 1997	IGNITION
J25RLECB 1998	IGNITION
J25RLEDA 1996	IGNITION
J25RLEEB 1999	IGNITION
J25RLEEN 1999	IGNITION
J25RLEIE 1991	IGNITION
J25RLEND 1992	IGNITION
J25RLEOR 1995	IGNITION
J25RLERC 1994	IGNITION
J25RLETS 1993	IGNITION
J25RLEUM 1997	IGNITION
J25RLSID rope start, tiller, 20 in shaft 2001	IGNITION
J25RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J25RLSOA	IGNITION
J25RLSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSRR	IGNITION
J25RLSRR - FR	22-5_SYSTÈME D'ALLUMAGE
J25RLSSE Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J25RLSTC	IGNITION
J25RLSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSID rope start, tiller, 15 in shaft 2001	IGNITION
J25RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSNF Rope start, White, Tiller,15 in. shaft, A/C Light 2002	IGNITION

J25RSOA	IGNITION
J25RSOA - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSRR	IGNITION
J25RSRR - FR	22-5_SYSTÈME D'ALLUMAGE
J25RSSE Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J25RSTC	IGNITION
J25RSTC - FR	22-5_SYSTÈME D'ALLUMAGE
J25RTSOS	IGNITION
J25RTSOS - FR	22-5_SYSTÈME D'ALLUMAGE
J25RVLSID rope start, tiller, 20 in shaft, wht 2001	IGNITION
J25RVSID rope start, tiller, 15 in shaft, wht 2001	IGNITION
J25RWEDC 1996	IGNITION - H25FP
J25RWEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWEIM 1991	IGNITION
J25RWENB 1992	IGNITION
J25RWEOS 1995	IGNITION - H25FP
J25RWEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWERD 1994	IGNITION - 25RW
J25RWETE 1993	IGNITION - 25RW
J25RWEUR 1997	IGNITION - H25FP
J25RWEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25RWLEDC 1996	IGNITION - H25FP
J25RWLEDC 1996	IGNITION - 25RS - 25RW - S25RP
J25RWLEIM 1991	IGNITION
J25RWLENB 1992	IGNITION
J25RWLEOS 1995	IGNITION - H25FP
J25RWLEOS 1995	IGNITION - 25RS - 25RW - S25RP
J25RWLERD 1994	IGNITION - 25RW
J25RWLETE 1993	IGNITION - 25RW
J25RWLEUR 1997	IGNITION - H25FP
J25RWLEUR 1997	IGNITION - 25RS, 25RW, S25RP
J25TEECB 1998	IGNITION
J25TEEDA 1996	IGNITION
J25TEEEE 1999	IGNITION
J25TEEEN 1999	IGNITION

J25TEEIE 1991	IGNITION
J25TEEND 1992	IGNITION
J25TEEOR 1995	IGNITION
J25TEERC 1994	IGNITION
J25TEETS 1993	IGNITION
J25TEEUM 1997	IGNITION
J25TELECB 1998	IGNITION
J25TELEDA 1996	IGNITION
J25TELEEE 1999	IGNITION
J25TELEEN 1999	IGNITION
J25TELEIE 1991	IGNITION
J25TELEND 1992	IGNITION
J25TELEOR 1995	IGNITION
J25TELERC	IGNITION
J25TELETS 1993	IGNITION
J25TELEM 1997	IGNITION
J25TELSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSNF Electric strart, White, Tiller, 20 in., 4 Amp Alt 2002	IGNITION
J25TELSOM	IGNITION
J25TELSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSRA	IGNITION
J25TELSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TELSSD Elec. Start, Tiller, 20 IN. shaft 2000	IGNITION
J25TELSTR	IGNITION
J25TELSTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESIS elec start, tiller, 15 in shaft 2001	IGNITION
J25TESNF - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESNF Electric strart, White, Tiller,15 in. shaft, 4 Amp Alt 2002	IGNITION
J25TESOM	IGNITION
J25TESOM - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESRA	IGNITION
J25TESRA - FR	22-5_SYSTÈME D'ALLUMAGE
J25TESSD Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION

J25TESTR	IGNITION
J25TESTR - FR	22-5_SYSTÈME D'ALLUMAGE
J25TVLSIS elec start, tiller, 20 in shaft 2001	IGNITION
J25TVSIS elec start, tiller, 15 in shaft 2001	IGNITION
J25WREEN 1999	IGNITION
J25WREES 1999	IGNITION
J25WRLEEN 1999	IGNITION
J25WRLEES 1999	IGNITION
J25WRLSIR commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J25WRLSOB	IGNITION
J25WRLSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSRM	IGNITION
J25WRLSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	IGNITION
J25WRSIR commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J25WRSOB	IGNITION
J25WRSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSRM	IGNITION
J25WRSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J25WRSSC Commercial, Rope Start, 15 IN. shaft 2000	IGNITION
J28ESLEDR 1996	IGNITION
J28ESLEIB 1991	IGNITION
J28ESLENE 1992	IGNITION
J28ESLEOC 1995	IGNITION
J28ESLERS 1994	IGNITION
J28ESLETD 1993	IGNITION
J30EECS 1998	IGNITION
J30EEDE 1996	IGNITION
J30EEECC 1999	IGNITION
J30EEEN 1999	IGNITION
J30EEIC 1991	IGNITION
J30EENR 1992	IGNITION
J30EEOB 1995	IGNITION
J30EERM 1994	IGNITION
J30EETA 1993	IGNITION

J30EEUD 1997	IGNITION
J30ELECS 1998	IGNITION
J30ELEDE 1996	IGNITION
J30ELEEC 1999	IGNITION
J30ELEEN 1999	IGNITION
J30ELEIC 1991	IGNITION
J30ELENR 1992	IGNITION
J30ELEOB 1995	IGNITION
J30ELERM 1994	IGNITION
J30ELETA 1993	IGNITION
J30ELEUD 1997	IGNITION
J30ELSLA elec start, remote, 20 in shaft 2001	IGNITION
J30ELSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSNF Electric start, Carb, White, Remote, 20 in., 4 Amp Alt, 2002	IGNITION
J30ELSOD	IGNITION
J30ELSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSRE	IGNITION
J30ELSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30ELSSR Elec. Start, 20 IN. shaft 2000	IGNITION
J30ELSTB	IGNITION
J30ELSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30ESIA elec start, remote, 15 in shaft 2001	IGNITION
J30ESSR Elec. Start, 15 IN. shaft 2000	IGNITION
J30EVLSIA elec start, remote, 20 in shaft, wht 2001	IGNITION
J30JREEM 1999	IGNITION SYSTEM
J30JRSIE jet drive, rope start, 15 in shaft 2001	IGNITION SYSTEM
J30JRSSB Jet Drive, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J30MLSRC	IGNITION
J30MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J30MLSTS	IGNITION
J30MLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J30REDE 1996	IGNITION
J30REEC 1999	IGNITION
J30REEN 1999	IGNITION

J30REIC 1991	IGNITION
J30RENR 1992	IGNITION
J30REOB 1995	IGNITION
J30RERM 1994	IGNITION
J30RETA 1993	IGNITION
J30REUD 1997	IGNITION
J30RLEDE 1996	IGNITION
J30RLEEC 1999	IGNITION
J30RLEEN 1999	IGNITION
J30RLEIC 1991	IGNITION
J30RLENR 1992	IGNITION
J30RLEOB 1995	IGNITION
J30RLERM 1994	IGNITION
J30RLETA 1993	IGNITION
J30RLEUD 1997	IGNITION
J30RLSIA rope start, tiller, 20 in shaft 2001	IGNITION
J30RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSNF Rope start, White, Tiller, 20 in. shaft, A/C Light 2002	IGNITION
J30RLSOD	IGNITION
J30RLSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSRE	IGNITION
J30RLSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RLSSR Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J30RLSTB	IGNITION
J30RLSTB - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSIA rope start, tiller, 15 in shaft 2001	IGNITION
J30RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSNF Rope start, White, Tiller,15 in. shaft, A/C Light 2002	IGNITION
J30RSOD	IGNITION
J30RSOD - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSRE	IGNITION
J30RSRE - FR	22-5_SYSTÈME D'ALLUMAGE
J30RSSR Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J30RSTB	IGNITION
J30RSTB - FR	22-5_SYSTÈME D'ALLUMAGE

J30RVLSIA	rope start, tiller, 20 in shaft, wht 2001	IGNITION
J30RVSIA	rope start, tiller, 15 in shaft, wht 2001	IGNITION
J30TEECS	1998	IGNITION
J30TEEDE	1996	IGNITION
J30TEEIC	1991	IGNITION
J30TEENR	1992	IGNITION
J30TEEOB	1995	IGNITION
J30TEERM	1994	IGNITION
J30TEETA	1993	IGNITION
J30TEEUD	1997	IGNITION
J30TELECS	1998	IGNITION
J30TELEDE	1996	IGNITION
J30TELEIC	1991	IGNITION
J30TELENR	1992	IGNITION
J30TELEOB	1995	IGNITION
J30TELTERM	1994	IGNITION
J30TELETA	1993	IGNITION
J30TELEUD	1997	IGNITION
J35REIC	1991	IGNITION
J35RENR	1992	IGNITION
J35RERM	1994	IGNITION
J35RETA	1993	IGNITION
J35RLEIC	1991	IGNITION
J35RLENR	1992	IGNITION
J35RLTERM	1994	IGNITION
J35RLETA	1993	IGNITION
J40EEOD	1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40EEOD	1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40EERE	1994	IGNITION SYSTEM - 40 ROPE START
J40EERE	1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40EETB	1993	IGNITION SYSTEM - 40 ROPE START
J40EETB	1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELECR	1998	IGNITION SYSTEM -- ROPE START
J40ELEDS	1996	IGNITION SYSTEM - 40 ROPE START

J40ELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40ELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40ELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40ELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
J40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40ELEUC 1997	IGNITION SYSTEM - ROPE START
J40JRECA 1998	IGNITION SYSTEM
J40JREDC 1996	IGNITION SYSTEM
J40JREOS 1995	IGNITION SYSTEM
J40JREUR 1997	IGNITION SYSTEM
J40PLEEA 1999	IGNITION SYSTEM -- ROPE START
J40PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RECR 1998	IGNITION SYSTEM -- ROPE START
J40REDS 1996	IGNITION SYSTEM - 40 ROPE START
J40REEA 1999	IGNITION SYSTEM -- ROPE START
J40REOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40REOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RETB 1993	IGNITION SYSTEM - 40 ROPE START
J40RETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40REUC 1997	IGNITION SYSTEM - ROPE START
J40RLECR 1998	IGNITION SYSTEM -- ROPE START
J40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40RLEEA 1999	IGNITION SYSTEM -- ROPE START
J40RLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40RLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40RLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40RLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40RLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40RLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40RLEUC 1997	IGNITION SYSTEM - ROPE START
J40RLSIF rope start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40RLSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RLSOC	IGNITION SYSTEM
J40RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSRS	IGNITION SYSTEM
J40RLSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RLSTD	IGNITION SYSTEM
J40RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSIF rope start, 15 in shaft 2001	IGNITION SYSTEM - ROPE START
J40RSNF - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	IGNITION SYSTEM
J40RSOC	IGNITION SYSTEM
J40RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSRS	IGNITION SYSTEM
J40RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40RSTD	IGNITION SYSTEM
J40RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J40TEECR 1998	IGNITION SYSTEM -- ROPE START
J40TEEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TEERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TEETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TEEUC 1997	IGNITION SYSTEM - ROPE START
J40TELECR 1998	IGNITION SYSTEM -- ROPE START

J40TELEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TELEUC 1997	IGNITION SYSTEM - ROPE START
J40TLECR 1998	IGNITION SYSTEM -- ROPE START
J40TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLEUC 1997	IGNITION SYSTEM - ROPE START
J40TPLEEA 1999	IGNITION SYSTEM -- ROPE START
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J40TTLECR 1998	IGNITION SYSTEM -- ROPE START
J40TTLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J40TTLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J40TTLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J40TTLERE 1994	IGNITION SYSTEM - 40 ROPE START
J40TTLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

J40TTLETF 1993	IGNITION SYSTEM - 40 ROPE START
J40TTLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J40TTLIEUC 1997	IGNITION SYSTEM - ROPE START
J40WREES 1999	IGNITION SYSTEM
J40WRLEES 1999	IGNITION SYSTEM
J40WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J40WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J40WRYEES 1999	IGNITION SYSTEM
J40WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J45RCENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCENM 1992	IGNITION SYSTEM - ROPE START
J45RCEOD 1995	IGNITION SYSTEM
J45RCERE 1994	IGNITION SYSTEM
J45RCETB 1993	IGNITION SYSTEM
J45RCLEDS 1996	IGNITION SYSTEM
J45RCLENM 1992	IGNITION SYSTEM - ELECTRIC
J45RCLENM 1992	IGNITION SYSTEM - ROPE START
J45RCLEOD 1995	IGNITION SYSTEM
J45RCLERE 1994	IGNITION SYSTEM
J45RCLETB 1993	IGNITION SYSTEM
J45RCLEUC 1997	IGNITION SYSTEM
J45WMLENM 1992	IGNITION SYSTEM - ELECTRIC
J45WMLENM 1992	IGNITION SYSTEM - ROPE START
J48ESLEDC 1996	IGNITION SYSTEM
J48ESLEOS 1995	IGNITION SYSTEM
J48ESLERD 1994	IGNITION SYSTEM
J48ESLETE 1993	IGNITION SYSTEM
J4RDHEOD 1995	MAGNETO
J4RDHERE 1994	MAGNETO
J4RDHETB 1993	IGNITION
J4RDHLEOD 1995	MAGNETO

J4RDHLERE 1994	MAGNETO
J4RDHLETB 1993	IGNITION
J50BEEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BEEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BEERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BEERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
J50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50BELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50BELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50BELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
J50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50ELEER 1999	IGNITION SYSTEM -- ROPE START
J50ELSIF elec start, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50ESLECC 1998	IGNITION SYSTEM -- ROPE START
J50ESLEUR 1997	IGNITION SYSTEM - ROPE START
J50JEDS 1996	IGNITION SYSTEM - 40 ROPE START
J50JEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50JEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50JERE 1994	IGNITION SYSTEM - 40 ROPE START
J50JERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JETB 1993	IGNITION SYSTEM - 40 ROPE START
J50JETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50JEUC 1997	IGNITION SYSTEM - ROPE START
J50PLEEA 1999	IGNITION SYSTEM -- ROPE START
J50PLSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM - ROPE START
J50TELEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START

J50TELEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TELERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TELERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TELETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLECR 1998	IGNITION SYSTEM -- ROPE START
J50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
J50TLEOD 1995	IGNITION SYSTEM - 25 & 40 ROPE START
J50TLEOD 1995	IGNITION SYSTEM - 25 ELECTRIC START AND TL MODELS ONLY
J50TLERE 1994	IGNITION SYSTEM - 40 ROPE START
J50TLERE 1994	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
J50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
J50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
J50TLEUC 1997	IGNITION SYSTEM - ROPE START
J50TSLECC 1998	IGNITION SYSTEM -- ROPE START
J50TSLEUS 1997	IGNITION SYSTEM - ROPE START
J55APRL	IGNITION & ELECTRICAL
J55APRL - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSOM	IGNITION & ELECTRICAL
J55APRLSOM - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRA	IGNITION & ELECTRICAL
J55APRLSRA - FR	22-5_SYSTÈME D'ALLUMAGE
J55APRLSRG	IGNITION & ELECTRICAL
J55APRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSOR	IGNITION & ELECTRICAL
J55MLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRC	IGNITION & ELECTRICAL
J55MLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J55MLSRG	IGNITION & ELECTRICAL
J55MLSRG - FR	22-5_SYSTÈME D'ALLUMAGE

J55MRL	IGNITION & ELECTRICAL
J55MRL - FR	22-5_SYSTÈME D'ALLUMAGE
J55RSLC 1997	IGNITION SYSTEM
J55RSLG 1995	IGNITION SYSTEM
J55RSLW 1996	IGNITION SYSTEM
J55RWLENM 1992	IGNITION SYSTEM - ELECTRIC
J55RWLENM 1992	IGNITION SYSTEM - ROPE START
J55RWLERE 1994	IGNITION SYSTEM
J55RWLETB 1993	IGNITION SYSTEM
J55WREES 1999	IGNITION SYSTEM
J55WRLEES 1999	IGNITION SYSTEM
J55WRLSIR commercial, rope start, 20 in shaft 2001	IGNITION SYSTEM
J55WRLSOE	IGNITION SYSTEM
J55WRLSOE - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRB	IGNITION SYSTEM
J55WRLSRB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSRG	IGNITION SYSTEM
J55WRLSRG - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION SYSTEM
J55WRLSTM	IGNITION SYSTEM
J55WRLSTM - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRSIR commercial, rope start, 15 in shaft 2001	IGNITION SYSTEM
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION SYSTEM
J55WRYEES 1999	IGNITION SYSTEM
J55WRYSIR commercial, rope start, 25 in shaft 2001	IGNITION SYSTEM
J55WRYSOB	IGNITION SYSTEM
J55WRYSOB - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSRM	IGNITION SYSTEM
J55WRYSRM - FR	22-5_SYSTÈME D'ALLUMAGE
J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	IGNITION SYSTEM
J5DRECR 1998	IGNITION
J5DRLECR 1998	IGNITION
J6RECR 1998	IGNITION
J6REDS 1996	IGNITION
J6REEA 1999	IGNITION

J6RENM 1992	IGNITION
J6REOD 1995	IGNITION
J6RERE 1994	IGNITION
J6RETB 1993	IGNITION
J6REUC 1997	IGNITION
J6RLECR 1998	IGNITION
J6RLEDS 1996	IGNITION
J6RLEEA 1999	IGNITION
J6RLENM 1992	IGNITION
J6RLEOD 1995	IGNITION
J6RLERE 1994	IGNITION
J6RLETB 1993	IGNITION
J6RLEUC 1997	IGNITION
J6RLSIB rope start, tiller, 20 in shaft 2001	IGNITION
J6RLSOC	IGNITION
J6RLSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLRS	IGNITION
J6RLRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLSSM Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J6RLSTD	IGNITION
J6RLSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RLVSIB rope start, tiller, 20 in shaft, wht 2001	IGNITION
J6RSIB rope start, tiller, 15 in shaft 2001	IGNITION
J6RSOC	IGNITION
J6RSOC - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSRS	IGNITION
J6RSRS - FR	22-5_SYSTÈME D'ALLUMAGE
J6RSSM Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J6RSTD	IGNITION
J6RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J6RVSIB rope start, tiller, 15 in shaft, wht 2001	IGNITION
J6SLEDS 1996	IGNITION
J6SLENM 1992	IGNITION
J6SLEOD 1995	IGNITION
J6SLERE 1994	IGNITION

J6SLETB 1993	IGNITION
J8DREEA 1999	IGNITION
J8RECR 1998	IGNITION
J8REDS 1996	IGNITION
J8REEM 1999	IGNITION
J8RENM 1992	IGNITION
J8REOD 1995	IGNITION
J8RERE 1994	IGNITION
J8RETB 1993	IGNITION
J8REUC 1997	IGNITION
J8RLECR 1998	IGNITION
J8RLEDS 1996	IGNITION
J8RLEEM 1999	IGNITION
J8RLENM 1992	IGNITION
J8RLEOD 1995	IGNITION
J8RLERE 1994	IGNITION
J8RLETB 1993	IGNITION
J8RLEUC 1997	IGNITION
J8RLSIE rope start, tiller, 20 in shaft 2001	IGNITION
J8RLSOR	IGNITION
J8RLSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSRC	IGNITION
J8RLSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLSSB Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8RLSTS	IGNITION
J8RLSTS - FR	22-5_SYSTÈME D'ALLUMAGE
J8RLVSIE rope start, tiller, 20 in shaft, wht 2001	IGNITION
J8RLXSIE rope start, tiller, 25 in shaft, wht 2001	IGNITION
J8RSIE rope start, tiller, 15 in shaft 2001	IGNITION
J8RSOR	IGNITION
J8RSOR - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSRC	IGNITION
J8RSRC - FR	22-5_SYSTÈME D'ALLUMAGE
J8RSSB Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
J8RSTD	IGNITION

J8RSTD - FR	22-5_SYSTÈME D'ALLUMAGE
J8RVSIE rope start, tiller, 15 in shaft, wht 2001	IGNITION
J8RXEEM 1999	IGNITION
J8RXSIE rope start, tiller, 25 in shaft 2001	IGNITION
J8RXSSB Rope Start, Tiller, 25 IN. shaft 2000	IGNITION
J8SRLECA 1998	IGNITION
J8SRLEDS 1996	IGNITION
J8SRLENM 1992	IGNITION
J8SRLEOD 1995	IGNITION
J8SRLERE 1994	IGNITION
J8SRLETB 1993	IGNITION
J8SRLEUC 1997	IGNITION
J8WREES 1999	IGNITION
J8WRLEES 1999	IGNITION
J8WRLSIR Commercial, rope start, tiller, 20 in shaft 2001	IGNITION
J8WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	IGNITION
J8WRSIR Commercial, rope start, tiller, 15 in shaft 2001	IGNITION
J8WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	IGNITION
RJ50ELSIF elec start, TNT, 20 in shaft 2001	IGNITION SYSTEM - ROPE START
SE10RPB 1996	IGNITION
SE10RPLB 1996	IGNITION
SE10RPLT 1997	IGNITION
SE10RPLY 1998	IGNITION
SE10RPT 1997	IGNITION
SE10RPY 1998	IGNITION
SE15BAECA 1998	IGNITION -- ELECTRIC
SE15BAECA 1998	IGNITION -- ROPE
SE15BAEDC 1996	IGNITION - ELECTRIC
SE15BAEDC 1996	IGNITION - ROPE
SE15BAEEM 1999	IGNITION -- ROPE
SE15BAEEM 1999	IGNITION -- ELECTRIC
SE15BAEUR 1997	IGNITION - ELECTRIC
SE15BAEUR 1997	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SE15BASIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC

SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SE15BASSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
SE15RPC 1998	IGNITION
SE15RPG 1996	IGNITION
SE15RPLC 1998	IGNITION
SE15RPLG 1996	IGNITION
SE15RPLW 1997	IGNITION
SE15RPW 1997	IGNITION
SE25RDECA 1998	IGNITION
SE25RDED C 1996	IGNITION
SE25RDEEM 1999	IGNITION
SE25RDEEN 1999	IGNITION
SE25RDEUR 1997	IGNITION
SE25RDSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SE25RDSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SE25RPLP 1998	IGNITION
SE25RPLV 1997	IGNITION - H25FP
SE25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SE25RPP 1998	IGNITION
SE25RPV 1997	IGNITION - H25FP
SE25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SE35REDE 1996	IGNITION
SE35RLEDE 1996	IGNITION
SE40RPB 1997	IGNITION SYSTEM
SE40RPH 1996	IGNITION SYSTEM
SE40RPLB 1997	IGNITION SYSTEM
SE40RPLH 1996	IGNITION SYSTEM
SE40RPLT2 1998	IGNITION SYSTEM
SE40RPT2 1998	IGNITION SYSTEM
SE40R PYB 1997	IGNITION SYSTEM
SE40R PYH 1996	IGNITION SYSTEM
SE40R PYT2 1998	IGNITION SYSTEM
SE40RSLD 1997	IGNITION SYSTEM
SE40RSLR 1998	IGNITION SYSTEM
SE40RSLZ 1996	IGNITION SYSTEM

SE45RSLB 1997	IGNITION SYSTEM
SE45RSLH 1996	IGNITION SYSTEM
SE50TLEDS 1996	IGNITION SYSTEM - 40 ROPE START
SE55RSC 1997	IGNITION SYSTEM
SE55RSLC 1997	IGNITION SYSTEM
SE55RSLM2 1998	IGNITION SYSTEM
SE55RSLW 1996	IGNITION SYSTEM
SE55RSM2 1998	IGNITION SYSTEM
SE55RSW 1996	IGNITION SYSTEM
SE55RSYC 1997	IGNITION SYSTEM
SE55RSYM2 1998	IGNITION SYSTEM
SE55RSYW 1996	IGNITION SYSTEM
SJ10REDD 1996	IGNITION - ELECTRIC
SJ10REDD 1996	IGNITION - ROPE
SJ10RLEDD 1996	IGNITION - ELECTRIC
SJ10RLEDD 1996	IGNITION - ROPE
SJ10RPB 1996	IGNITION
SJ10RPLB 1996	IGNITION
SJ10RPLT 1997	IGNITION
SJ10RPLY 1998	IGNITION
SJ10RPT 1997	IGNITION
SJ10RPY 1998	IGNITION
SJ10SELEDD 1996	IGNITION - ELECTRIC
SJ10SELEDD 1996	IGNITION - ROPE
SJ15BAECA 1998	IGNITION -- ELECTRIC
SJ15BAECA 1998	IGNITION -- ROPE
SJ15BAEDC 1996	IGNITION - ELECTRIC
SJ15BAEDC 1996	IGNITION - ROPE
SJ15BAEEM 1999	IGNITION -- ROPE
SJ15BAEEM 1999	IGNITION -- ELECTRIC
SJ15BAEUR 1997	IGNITION - ELECTRIC
SJ15BAEUR 1997	IGNITION - ROPE
SJ15REDS 1996	IGNITION - ELECTRIC
SJ15REDS 1996	IGNITION - ROPE
SJ15RLEDS 1996	IGNITION - ELECTRIC

SJ15RLEDS 1996	IGNITION - ROPE
SJ15RPC 1998	IGNITION
SJ15RPG 1996	IGNITION
SJ15RPLC 1998	IGNITION
SJ15RPLG 1996	IGNITION
SJ15RPLW 1997	IGNITION
SJ15RPW 1997	IGNITION
SJ15RTEEM 1999	IGNITION -- ROPE
SJ15RTEEM 1999	IGNITION -- ELECTRIC
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ROPE
SJ15RTSIR rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION - ELECTRIC
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION - ROPE
SJ15RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION-ELECTRIC
SJ25RDECA 1998	IGNITION
SJ25RDED C 1996	IGNITION
SJ25RDEEM 1999	IGNITION
SJ25RDEEMN 1999	IGNITION
SJ25RDEUR 1997	IGNITION
SJ25REDA 1996	IGNITION
SJ25RLEDA 1996	IGNITION
SJ25RPLP 1998	IGNITION
SJ25RPLV 1997	IGNITION - H25FP
SJ25RPLV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RPP 1998	IGNITION
SJ25RPV 1997	IGNITION - H25FP
SJ25RPV 1997	IGNITION - 25RS, 25RW, S25RP
SJ25RTEEM 1999	IGNITION
SJ25RTSIE rope start, tiller, 15 in shaft, n/a usa 2001	IGNITION
SJ25RTSSB Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	IGNITION
SJ25TEEDA 1996	IGNITION
SJ25TEEUM 1997	IGNITION
SJ30EEDE 1996	IGNITION
SJ30REDE 1996	IGNITION
SJ30RLEDE 1996	IGNITION
SJ30TEEUD 1997	IGNITION

SJ35REDE 1996	IGNITION
SJ35RLEDE 1996	IGNITION
SJ40EEDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40REDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40RLEDS 1996	IGNITION SYSTEM - 40 ROPE START
SJ40RPB 1997	IGNITION SYSTEM
SJ40RPH 1996	IGNITION SYSTEM
SJ40RPLB 1997	IGNITION SYSTEM
SJ40RPLH 1996	IGNITION SYSTEM
SJ40RPLT2 1998	IGNITION SYSTEM
SJ40RPT2 1998	IGNITION SYSTEM
SJ40R PYB 1997	IGNITION SYSTEM
SJ40R PYH 1996	IGNITION SYSTEM
SJ40R PYT2 1998	IGNITION SYSTEM
SJ40RS LD 1997	IGNITION SYSTEM
SJ40RS LR 1998	IGNITION SYSTEM
SJ40RSLZ 1996	IGNITION SYSTEM
SJ45RSLB 1997	IGNITION SYSTEM
SJ45RSLH 1996	IGNITION SYSTEM
SJ55RSC 1997	IGNITION SYSTEM
SJ55RSLC 1997	IGNITION SYSTEM
SJ55RSLM2 1998	IGNITION SYSTEM
SJ55RSLW 1996	IGNITION SYSTEM
SJ55RSM2 1998	IGNITION SYSTEM
SJ55RSW 1996	IGNITION SYSTEM
SJ55RSYC 1997	IGNITION SYSTEM
SJ55RSYM2 1998	IGNITION SYSTEM
SJ55RSYW 1996	IGNITION SYSTEM
SJ6REDS 1996	IGNITION
SJ6RLEDS 1996	IGNITION
SJ8REDS 1996	IGNITION
SJ8RLEDS 1996	IGNITION
TE10RELETM 1993	IGNITION - ELECTRIC
TE10RELETM 1993	IGNITION - ROPE
TE20CREND 1992	IGNITION

TE20CRETS 1993	IGNITION
TE20CRLEIE 1991	IGNITION
TE20CRLEND 1992	IGNITION
TE20CRLETS 1993	IGNITION
TE25ELEID 1991	IGNITION
TE25ELENS 1992	IGNITION
TE25ELET C 1993	IGNITION
TE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TE48ESLETE 1993	IGNITION SYSTEM
TJ10RELETM 1993	IGNITION - ELECTRIC
TJ10RELETM 1993	IGNITION - ROPE
TJ20CREND 1992	IGNITION
TJ20CRETS 1993	IGNITION
TJ20CRLEIE 1991	IGNITION
TJ20CRLEND 1992	IGNITION
TJ20CRLETS 1993	IGNITION
TJ25ELEID 1991	IGNITION
TJ25ELENS 1992	IGNITION
TJ25ELET C 1993	IGNITION
TJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
TJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
TJ48ESLETE 1993	IGNITION SYSTEM
VE25ELEID 1991	IGNITION
VE25ELENS 1992	IGNITION
VE25ELET C 1993	IGNITION
VE25REIE 1991	IGNITION
VE30EEIC 1991	IGNITION
VE30EENR 1992	IGNITION
VE30EETA 1993	IGNITION
VE30ELEIC 1991	IGNITION
VE30ELENR 1992	IGNITION
VE30ELETA 1993	IGNITION
VE40EETB 1993	IGNITION SYSTEM - 40 ROPE START

VE40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE48ESLETE 1993	IGNITION SYSTEM
VE50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VE50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VE50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ25ELEID 1991	IGNITION
VJ25ELENS 1992	IGNITION
VJ25ELETC 1993	IGNITION
VJ25REIE 1991	IGNITION
VJ30EEIC 1991	IGNITION
VJ30EENR 1992	IGNITION
VJ30EETA 1993	IGNITION
VJ30ELEIC 1991	IGNITION
VJ30ELENR 1992	IGNITION
VJ30ELETA 1993	IGNITION
VJ40EETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40EETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY

VJ40ELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40ELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ40TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VJ40TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ48ESLETE 1993	IGNITION SYSTEM
VJ50BEETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BEETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50BELETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50BELETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TLETB 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLETB 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
VJ50TLETF 1993	IGNITION SYSTEM - 40 ROPE START
VJ50TLETF 1993	IGNITION SYSTEM - ELECTRIC START AND TL MODELS ONLY
X50ESLECC 1998	IGNITION SYSTEM -- ROPE START