

Where Used: Part Number 0337778

Model Name	Diagram
150SHLERC 1994	GEARCASE - COUNTER ROTATION
150SHLERC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
150SLERC 1994	GEARCASE - COUNTER ROTATION
150SLERC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
A115DCXAFG	07-1_GEARCASE, O-Type, Counter Rotation
A115DGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115DGXAFG	07-1_GEARCASE, O-Type
A115DPXAFG	07-1_GEARCASE, O-Type
A115DSLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHLAFH	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHLAFI	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHLAFK	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GHXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GHXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GHXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
A115GNLAFG	07-1_GEARCASE, O-Type
A115SHLAFH	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHLAFI	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHLAFK	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SHXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SHXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SHXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
A115SNLAFG	07-1_GEARCASE, O-Type
BE115ELED 1996	GEARCASE - 20 IN. MODELS
BE115ELED 1996	GEARCASE - 25 IN. MODELS
BE115ELEUA 1997	GEARCASE - 20 IN. MODELS
BE115ELEUA 1997	GEARCASE - 25 IN. MODELS
BE115ELEUC 1997	GEARCASE - 20 IN. MODELS

BE115ELEUC 1997	GEARCASE - 25 IN. MODELS
BE115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE115GLEDR 1996	GEARCASE - 20 IN. MODELS
BE115GLEDR 1996	GEARCASE - 25 IN. MODELS
BE115GLEUA 1997	GEARCASE - 20 IN. MODELS
BE115GLEUA 1997	GEARCASE - 25 IN. MODELS
BE115GLEUC 1997	GEARCASE - 20 IN. MODELS
BE115GLEUC 1997	GEARCASE - 25 IN. MODELS
BE115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE115SXEDR 1996	GEARCASE - 20 IN. MODELS
BE115SXEDR 1996	GEARCASE - 25 IN. MODELS
BE115SXEUUA 1997	GEARCASE - 20 IN. MODELS
BE115SXEUUA 1997	GEARCASE - 25 IN. MODELS
BE115SXEUUC 1997	GEARCASE - 20 IN. MODELS
BE115SXEUUC 1997	GEARCASE - 25 IN. MODELS
BE130TLECE 1998	GEARCASE
BE130TLEDM 1996	GEARCASE - 130CX COUNTER ROTATION
BE130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
BE130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
BE130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
BE150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150ELECD 1998	GEARCASE -- COUNTER-ROTATION
BE150ELEDDB 1996	GEARCASE - COUNTER-ROTATION
BE150ELEDDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUC 1997	GEARCASE - COUNTER-ROTATION
BE150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUE 1997	GEARCASE - COUNTER-ROTATION
BE150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150EXECD 1998	GEARCASE -- COUNTER-ROTATION
BE150EXEDDB 1996	GEARCASE - COUNTER-ROTATION

BE150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150EXEUC 1997	GEARCASE - COUNTER-ROTATION
BE150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150EXEUE 1997	GEARCASE - COUNTER-ROTATION
BE150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150GLECD 1998	GEARCASE -- COUNTER-ROTATION
BE150GLEDB 1996	GEARCASE - COUNTER-ROTATION
BE150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUC 1997	GEARCASE - COUNTER-ROTATION
BE150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUE 1997	GEARCASE - COUNTER-ROTATION
BE150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150NXECD 1998	GEARCASE -- COUNTER-ROTATION
BE150NXEDB 1996	GEARCASE - COUNTER-ROTATION
BE150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUC 1997	GEARCASE - COUNTER-ROTATION
BE150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUE 1997	GEARCASE - COUNTER-ROTATION
BE175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175EXECD 1998	GEARCASE -- COUNTER-ROTATION
BE175EXEDB 1996	GEARCASE - COUNTER-ROTATION
BE175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175EXEUC 1997	GEARCASE - COUNTER-ROTATION
BE175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

BE175EXEUE 1997	GEARCASE - COUNTER-ROTATION
BE175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175GLECD 1998	GEARCASE -- COUNTER-ROTATION
BE175GLEDB 1996	GEARCASE - COUNTER-ROTATION
BE175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUC 1997	GEARCASE - COUNTER-ROTATION
BE175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUE 1997	GEARCASE - COUNTER-ROTATION
BE175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175NXECD 1998	GEARCASE -- COUNTER-ROTATION
BE175NXEDB 1996	GEARCASE - COUNTER-ROTATION
BE175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUC 1997	GEARCASE - COUNTER-ROTATION
BE175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUE 1997	GEARCASE - COUNTER-ROTATION
BE200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE200CXEDR 1996	GEARCASE - COUNTER-ROTATION
BE200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200CXEUA 1997	GEARCASE - COUNTER-ROTATION
BE200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE200TXEDR 1996	GEARCASE - COUNTER-ROTATION
BE200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200TXEUA 1997	GEARCASE - COUNTER-ROTATION
BE200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

BE225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE225CXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225CXEUD 1997	GEARCASE - COUNTER-ROTATION
BE225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225PXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225SLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225SLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE225SLEDE 1996	GEARCASE - COUNTER-ROTATION
BE225SLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225SLEUD 1997	GEARCASE - COUNTER-ROTATION
BE225SLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE225TXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225TXEUD 1997	GEARCASE - COUNTER-ROTATION
BE225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE90ELEDR 1996	GEARCASE - 20 IN. MODELS
BE90ELEDR 1996	GEARCASE - 25 IN. MODELS
BE90ELEUA 1997	GEARCASE - 20 IN. MODELS
BE90ELEUA 1997	GEARCASE - 25 IN. MODELS
BE90ELEUC 1997	GEARCASE - 20 IN. MODELS
BE90ELEUC 1997	GEARCASE - 25 IN. MODELS
BE90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE90SLEDR 1996	GEARCASE - 20 IN. MODELS
BE90SLEDR 1996	GEARCASE - 25 IN. MODELS

BE90SLEUA 1997	GEARCASE - 20 IN. MODELS
BE90SLEUA 1997	GEARCASE - 25 IN. MODELS
BE90SLEUC 1997	GEARCASE - 20 IN. MODELS
BE90SLEUC 1997	GEARCASE - 25 IN. MODELS
BE90SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE90SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE90SXEUA 1997	GEARCASE - 20 IN. MODELS
BE90SXEUA 1997	GEARCASE - 25 IN. MODELS
BE90SXEUC 1997	GEARCASE - 20 IN. MODELS
BE90SXEUC 1997	GEARCASE - 25 IN. MODELS
BJ115LEDR 1996	GEARCASE - 20 IN. MODELS
BJ115LEDR 1996	GEARCASE - 25 IN. MODELS
BJ115LEUA 1997	GEARCASE - 20 IN. MODELS
BJ115LEUA 1997	GEARCASE - 25 IN. MODELS
BJ115LEUC 1997	GEARCASE - 20 IN. MODELS
BJ115LEUC 1997	GEARCASE - 25 IN. MODELS
BJ115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ115GLEDR 1996	GEARCASE - 20 IN. MODELS
BJ115GLEDR 1996	GEARCASE - 25 IN. MODELS
BJ115GLEUA 1997	GEARCASE - 20 IN. MODELS
BJ115GLEUA 1997	GEARCASE - 25 IN. MODELS
BJ115GLEUC 1997	GEARCASE - 20 IN. MODELS
BJ115GLEUC 1997	GEARCASE - 25 IN. MODELS
BJ115PLEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ115PLEEM 1999	GEARCASE -- 90 & 115 PX MODELS
BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ115PXEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ115PXEEM 1999	GEARCASE -- 90 & 115 PX MODELS
BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS

BJ115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ115SXEDR 1996	GEARCASE - 20 IN. MODELS
BJ115SXEDR 1996	GEARCASE - 25 IN. MODELS
BJ115SX EUA 1997	GEARCASE - 20 IN. MODELS
BJ115SX EUA 1997	GEARCASE - 25 IN. MODELS
BJ115SX EUC 1997	GEARCASE - 20 IN. MODELS
BJ115SX EUC 1997	GEARCASE - 25 IN. MODELS
BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ130PLEED 1999	GEARCASE
BJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
BJ130PX EED 1999	GEARCASE
BJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
BJ130TLECE 1998	GEARCASE
BJ130TLED M 1996	GEARCASE - 130CX COUNTER ROTATION
BJ130TLED M 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
BJ130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
BJ130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
BJ135PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ135VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE
BJ150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150ELECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150ELEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS

BJ150EXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150EXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150XEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150XEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150XEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150XEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150GLECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150GLEDDB 1996	GEARCASE - COUNTER-ROTATION
BJ150GLEDDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150NXCED 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150NXCED 1998	GEARCASE -- COUNTER-ROTATION
BJ150NXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175EXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175EXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175XEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

BJ175EXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175EXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175GLECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175GLEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175NXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175NXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
BJ175PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
BJ175PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS

BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ200CXEDR 1996	GEARCASE - COUNTER-ROTATION
BJ200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BJ200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200CXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200CXSSC Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200CXSSC Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PLEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200TXEDR 1996	GEARCASE - COUNTER-ROTATION
BJ200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS

BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200VCSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200VCSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225CXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225CXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PLEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS

BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ90ELED R 1996	GEARCASE - 20 IN. MODELS
BJ90ELED R 1996	GEARCASE - 25 IN. MODELS
BJ90ELEUA 1997	GEARCASE - 20 IN. MODELS
BJ90ELEUA 1997	GEARCASE - 25 IN. MODELS
BJ90ELEUC 1997	GEARCASE - 20 IN. MODELS
BJ90ELEUC 1997	GEARCASE - 25 IN. MODELS
BJ90PLEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ90PLEEB 1999	GEARCASE -- 90 & 115 PX MODELS
BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ90PXEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ90PXEEB 1999	GEARCASE -- 90 & 115 PX MODELS
BJ90PXSSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ90PXSSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ90SLED R 1996	GEARCASE - 20 IN. MODELS
BJ90SLED R 1996	GEARCASE - 25 IN. MODELS
BJ90SLEUA 1997	GEARCASE - 20 IN. MODELS
BJ90SLEUA 1997	GEARCASE - 25 IN. MODELS
BJ90SLEUC 1997	GEARCASE - 20 IN. MODELS
BJ90SLEUC 1997	GEARCASE - 25 IN. MODELS
BJ90SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ90SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ90SXEU A 1997	GEARCASE - 20 IN. MODELS
BJ90SXEU A 1997	GEARCASE - 25 IN. MODELS

BJ90SXEU 1997	GEARCASE - 20 IN. MODELS
BJ90SXEU 1997	GEARCASE - 25 IN. MODELS
BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
E100WPLEEC 1999	GEARCASE
E100WPLSIF commercial, elec start, 20 in shaft 2001	GEARCASE
E100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
E100WPXEEC 1999	GEARCASE
E100WPXSIF commercial, elec start, 25 in shaft 2001	GEARCASE
E100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
E100WQLECS 1998	GEARCASE -- 100WQL MODELS
E100WQLECS 1998	GEARCASE -- 100WQX MODELS
E100WQXECS 1998	GEARCASE -- 100WQL MODELS
E100WQXECS 1998	GEARCASE -- 100WQX MODELS
E100WTLEDR 1996	GEARCASE
E100WTLEOC 1995	GEARCASE
E100WTLERS 1994	GEARCASE
E100WTLETD 1993	GEARCASE
E100WTLEUA 1997	GEARCASE
E100WTXEDR 1996	GEARCASE
E100WTXEOC 1995	GEARCASE
E100WTXERS 1994	GEARCASE
E100WTXETD 1993	GEARCASE
E100WTXEUA 1997	GEARCASE
E105WELEEN 1999	GEARCASE
E105WELEES 1999	GEARCASE
E105WELSIF commercial, elec start, 20 in shaft 2001	GEARCASE
E105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
E105WPLEES 1999	GEARCASE
E105WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
E105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE

E105WPXEES 1999	GEARCASE
E105WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
E105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
E105WRLEES 1999	GEARCASE
E105WRLSIF commercial, rope start, 20 in shaft 2001	GEARCASE
E105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
E105WRYEES 1999	GEARCASE
E105WRYSIF commercial, rope start, 22.5 in shaft 2001	GEARCASE
E105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
E115DBXAAA	07-1_GEARCASE, O-Type
E115DBXAAB	07-1_GEARCASE, O-Type
E115DBXABA	07-1_GEARCASE, O-Type
E115DBXAFA	07-1_GEARCASE, O-Type
E115DBXAFB	07-1_GEARCASE, O-Type
E115DBXIIB	GEARCASE, O-Type
E115DBXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXINE	GEARCASE, O-Type
E115DBXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXISF	GEARCASE
E115DBXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXISM	GEARCASE
E115DBXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSCR	GEARCASE
E115DBXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSEF	GEARCASE
E115DBXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSUC	GEARCASE
E115DBXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DCXAAA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAAB	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXABA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFB	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFF	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFG	07-1_GEARCASE, O-Type, Counter Rotation

E115DCXAFH	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFL	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFL	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXIIA	GEARCASE, O-Type, Counter Rotation
E115DCXIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXINM	GEARCASE, O-Type, Counter Rotation
E115DCXINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXISF	GEARCASE
E115DCXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXISR	GEARCASE
E115DCXISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXSCS	GEARCASE
E115DCXSEF	GEARCASE
E115DCXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFH	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFI	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFK	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGXAFB	07-1_GEARCASE, O-Type
E115DGXAFF	07-1_GEARCASE, O-Type
E115DGXAFG	07-1_GEARCASE, O-Type
E115DGXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DHLAAA	07-1_GEARCASE, S2-Type
E115DHLAAB	07-1_GEARCASE, S2-Type
E115DHLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DHLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DHLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DHLIIR	GEARCASE, S2-Type

E115DHLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLINA	GEARCASE, S2-Type
E115DHLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLISC	GEARCASE
E115DHLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLISF	GEARCASE
E115DHLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLSSES	GEARCASE
E115DHLSSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHXAAA	07-1_GEARCASE, O-Type
E115DHXAAB	07-1_GEARCASE, O-Type
E115DHXABA	07-1_GEARCASE, O-Type
E115DHXAFA	07-1_GEARCASE, O-Type
E115DHXAFB	07-1_GEARCASE, O-Type
E115DHXAFF	07-1_GEARCASE, O-Type
E115DHXIIR	GEARCASE, O-Type
E115DHXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXINA	GEARCASE, O-Type
E115DHXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXISC	GEARCASE
E115DHXISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXISF	GEARCASE
E115DHXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXSES	GEARCASE
E115DHXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPLAAA	07-1_GEARCASE, S2-Type
E115DPLAAB	07-1_GEARCASE, S2-Type
E115DPLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DPLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DPLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DPLIIB	GEARCASE, S2-Type
E115DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLINE	GEARCASE, S2-Type
E115DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLISF	GEARCASE

E115DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLISM	GEARCASE
E115DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSCR	GEARCASE
E115DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSEF	GEARCASE
E115DPLSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSUC	GEARCASE
E115DPLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E115DPXAAA	07-1_GEARCASE, O-Type
E115DPXAAB	07-1_GEARCASE, O-Type
E115DPXABA	07-1_GEARCASE, O-Type
E115DPXAFA	07-1_GEARCASE, O-Type
E115DPXAFB	07-1_GEARCASE, O-Type
E115DPXAFF	07-1_GEARCASE, O-Type
E115DPXAFG	07-1_GEARCASE, O-Type
E115DPXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXIIB	GEARCASE, O-Type
E115DPXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXINE	GEARCASE, O-Type
E115DPXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXISF	GEARCASE
E115DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXISM	GEARCASE
E115DPXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSCR	GEARCASE
E115DPXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSEF	GEARCASE
E115DPXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSUC	GEARCASE
E115DPXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DSLAAA	07-1_GEARCASE, S2-Type

E115DSLAAAB	07-1_GEARCASE, S2-Type
E115DSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DSLAF A	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF F	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF G	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF H	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF I	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF K	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLAF L	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSL IIB	GEARCASE, S2-Type
E115DSL IIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL IINE	GEARCASE, S2-Type
E115DSL IINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL IISF	GEARCASE
E115DSL IISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL IISM	GEARCASE
E115DSL IISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL ISCR	GEARCASE
E115DSL ISCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL SEF	GEARCASE
E115DSL SEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSL SUC	GEARCASE
E115DSL SUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E115ELECTM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115ELECTM 1998	GEARCASE -- 90 & 115 SX MODELS
E115ELED R 1996	GEARCASE - 20 IN. MODELS
E115ELED R 1996	GEARCASE - 25 IN. MODELS
E115ELEC OC 1995	GEARCASE - 20 IN. MODELS
E115ELEC OC 1995	GEARCASE - 25 IN. MODELS
E115ELEC UA 1997	GEARCASE - 20 IN. MODELS
E115ELEC UA 1997	GEARCASE - 25 IN. MODELS
E115ELEC UC 1997	GEARCASE - 20 IN. MODELS
E115ELEC UC 1997	GEARCASE - 25 IN. MODELS
E115FPLEEC 1999	GEARCASE -- FPX MODELS

E115FPLEEN 1999	GEARCASE -- FPX MODELS
E115FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E115FPXEEC 1999	GEARCASE -- FPX MODELS
E115FPXEEN 1999	GEARCASE -- FPX MODELS
E115FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E115FPXSSH FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FPXSSR FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FSLECS 1998	GEARCASE -- FSL, FTL MODELS
E115FSLECS 1998	GEARCASE -- FSX MODELS
E115FSLEEC 1999	GEARCASE -- FPX MODELS
E115FSLEEN 1999	GEARCASE -- FPX MODELS
E115FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E115FSLSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FSLSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FSXECS 1998	GEARCASE -- FSL, FTL MODELS
E115FSXECS 1998	GEARCASE -- FSX MODELS
E115FTLECS 1998	GEARCASE -- FSL, FTL MODELS
E115FTLECS 1998	GEARCASE -- FSX MODELS
E115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115GLEDR 1996	GEARCASE - 20 IN. MODELS
E115GLEDR 1996	GEARCASE - 25 IN. MODELS
E115GLEOC 1995	GEARCASE - 20 IN. MODELS
E115GLEOC 1995	GEARCASE - 25 IN. MODELS
E115GLEUA 1997	GEARCASE - 20 IN. MODELS
E115GLEUA 1997	GEARCASE - 25 IN. MODELS
E115GLEUC 1997	GEARCASE - 20 IN. MODELS
E115GLEUC 1997	GEARCASE - 25 IN. MODELS
E115GNLAFB	07-1_GEARCASE, O-Type
E115GNLAFF	07-1_GEARCASE, O-Type
E115GNLAFG	07-1_GEARCASE, O-Type
E115GNLAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115GNLAFI	07-1_GEARCASE, (0.44 Ratio) O-Type

E115GNLAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115GNLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAAA	07-1_GEARCASE, S2-Type
E115HSLAAB	07-1_GEARCASE, S2-Type
E115HSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HSLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLIIR	GEARCASE, S2-Type
E115HSLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLINA	GEARCASE, S2-Type
E115HSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLISC	GEARCASE
E115HSLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLISF	GEARCASE
E115HSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLSES	GEARCASE
E115HSLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115JTLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115JTLECS 1998	GEARCASE -- 90 & 115 SX MODELS
E115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115SLEDR 1996	GEARCASE - 20 IN. MODELS
E115SLEDR 1996	GEARCASE - 25 IN. MODELS
E115SLEOC 1995	GEARCASE - 20 IN. MODELS
E115SLEOC 1995	GEARCASE - 25 IN. MODELS
E115SLEUA 1997	GEARCASE - 20 IN. MODELS
E115SLEUA 1997	GEARCASE - 25 IN. MODELS
E115SLEUC 1997	GEARCASE - 20 IN. MODELS
E115SLEUC 1997	GEARCASE - 25 IN. MODELS
E115SNLAFA	07-1_GEARCASE, O-Type
E115SNLAFB	07-1_GEARCASE, O-Type
E115SNLAFF	07-1_GEARCASE, O-Type

E115SNLAFG	07-1_GEARCASE, O-Type
E115SNLAFH	07-1_GEARCASE, O-Type
E115SNLAFI	07-1_GEARCASE, O-Type
E115SNLAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115SNLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115SXEDR 1996	GEARCASE - 20 IN. MODELS
E115SXEDR 1996	GEARCASE - 25 IN. MODELS
E115SXEOC 1995	GEARCASE - 20 IN. MODELS
E115SXEOC 1995	GEARCASE - 25 IN. MODELS
E115SX EUA 1997	GEARCASE - 20 IN. MODELS
E115SX EUA 1997	GEARCASE - 25 IN. MODELS
E115SX EUC 1997	GEARCASE - 20 IN. MODELS
E115SX EUC 1997	GEARCASE - 25 IN. MODELS
E120TLERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TLERC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXERC 1994	GEARCASE - 140CX COUNTER ROTATION

E120TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125ESXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E125ESXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E125ESXETA 1993	GEARCASE - 140CX COUNTER ROTATION
E125ESXETA 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125ESXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E125ESXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125WTPLE 1995	GEARCASE
E130CXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
E130CXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130DCXAAA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAAB	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXABA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFB	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFF	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFH	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFL	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFI	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFL	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXIIR	GEARCASE, O-Type, Counter Rotation
E130DCXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXINA	GEARCASE, O-Type, Counter Rotation
E130DCXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXISC	GEARCASE
E130DCXISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXISF	GEARCASE
E130DCXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation

E130DCXSES	GEARCASE
E130DCXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DGLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAAA	07-1_GEARCASE, S2-Type
E130DPLAAB	07-1_GEARCASE, S2-Type
E130DPLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLIIR	GEARCASE, S2-Type
E130DPLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLINA	GEARCASE, S2-Type
E130DPLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLISC	GEARCASE
E130DPLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLISF	GEARCASE
E130DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLSES	GEARCASE
E130DPLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPXAAA	07-1_GEARCASE, O-Type
E130DPXAAB	07-1_GEARCASE, O-Type
E130DPXABA	07-1_GEARCASE, O-Type
E130DPXAFA	07-1_GEARCASE, O-Type
E130DPXAFB	07-1_GEARCASE, O-Type
E130DPXAFF	07-1_GEARCASE, O-Type
E130DPXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXIIR	GEARCASE, O-Type

E130DPXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXINA	GEARCASE, O-Type
E130DPXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXISC	GEARCASE
E130DPXISF	GEARCASE
E130DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXSES	GEARCASE
E130DPXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DSLAAA	07-1_GEARCASE, S2-Type
E130DSLAAAB	07-1_GEARCASE, S2-Type
E130DSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAF A	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAF F	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAF L	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLII R	GEARCASE, S2-Type
E130DSLII R - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLINA	GEARCASE, S2-Type
E130DSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLISC	GEARCASE
E130DSLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLISF	GEARCASE
E130DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLSES	GEARCASE
E130DSLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130TLECE 1998	GEARCASE
E130TLED M 1996	GEARCASE - 130CX COUNTER ROTATION
E130TLED M 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TLEOA 1995	GEARCASE - 130CX COUNTER ROTATION
E130TLEOA 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
E130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION

E130TXACB 1998	GEARCASE
E130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
E130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
E130TXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
E130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FPLSDE	GEARCASE - PL - SL MODELS
E135FPLSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FPLSOB	GEARCASE - PL - SL MODELS
E135FPLSOB - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSLSDE	GEARCASE - PL - SL MODELS
E135FSLSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSLSOB	GEARCASE - PL - SL MODELS
E135FSLSOB - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS

E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E140CXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXERE 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXERE 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXETB 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXETB 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLATC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLATC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TLERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TLERR 1994	GEARCASE - 140CX COUNTER ROTATION
E140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXARC 1994	GEARCASE - 140CX COUNTER ROTATION

E140TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXERR 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E150DGLABB	07-1_GEARCASE, O-Type
E150DGLABF	07-1_GEARCASE, O-Type
E150DGLABG	07-1_GEARCASE, O-Type
E150DGLABH	07-1_GEARCASE, O-Type
E150DGLABJ	07-1_GEARCASE, O-Type
E150DPLAAA	07-1_GEARCASE, O-Type
E150DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLAAB	07-1_GEARCASE, O-Type
E150DPLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLABA	07-1_GEARCASE, O-Type
E150DPLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLABB	07-1_GEARCASE, O-Type
E150DPLIIB	GEARCASE, O-Type
E150DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLINE	GEARCASE, O-Type
E150DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLISF	GEARCASE - PL, SL MODELS
E150DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLISM	GEARCASE - PL, SL MODELS

E150DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSCR	GEARCASE - PL, SL MODELS
E150DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSEA	GEARCASE - PL, SL MODELS
E150DPLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSUC	GEARCASE - PL, SL MODELS
E150DPLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSUF	GEARCASE - PL, SL MODELS
E150DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLAAA	07-1_GEARCASE, O-Type
E150DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLAAAB	07-1_GEARCASE, O-Type
E150DSLAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLABA	07-1_GEARCASE, O-Type
E150DSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLABB	07-1_GEARCASE, O-Type
E150DSLABF	07-1_GEARCASE, O-Type
E150DSLABG	07-1_GEARCASE, O-Type
E150DSLABH	07-1_GEARCASE, O-Type
E150DSLABJ	07-1_GEARCASE, O-Type
E150DSLIIIB	GEARCASE, O-Type
E150DSLIIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLIIINE	GEARCASE, O-Type
E150DSLIIINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLISF	GEARCASE - PL, SL MODELS
E150DSLISM	GEARCASE - PL, SL MODELS
E150DSLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLSCR	GEARCASE - PL, SL MODELS
E150DSLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLSEA	GEARCASE - PL, SL MODELS
E150DSLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DLSUC	GEARCASE - PL, SL MODELS
E150DLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DLSUF	GEARCASE - PL, SL MODELS
E150DLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150ELECD 1998	GEARCASE -- COUNTER-ROTATION
E150ELEDDB 1996	GEARCASE - COUNTER-ROTATION
E150ELEDDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEOM 1995	GEARCASE - COUNTER ROTATION
E150ELEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150ELERA 1994	GEARCASE - COUNTER ROTATION
E150ELERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150ELERV 1994	GEARCASE - COUNTER ROTATION
E150ELERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150ELETG 1993	GEARCASE - COUNTER ROTATION
E150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150ELETR 1993	GEARCASE - COUNTER ROTATION
E150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEUC 1997	GEARCASE - COUNTER-ROTATION
E150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEUE 1997	GEARCASE - COUNTER-ROTATION
E150EXARC 1994	GEARCASE - COUNTER ROTATION
E150EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXARV 1994	GEARCASE - COUNTER ROTATION
E150EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXATG 1993	GEARCASE - COUNTER ROTATION
E150EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXATS 1993	GEARCASE - COUNTER ROTATION
E150EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150EXECD 1998	GEARCASE -- COUNTER-ROTATION
E150EXEDB 1996	GEARCASE - COUNTER-ROTATION
E150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"

E150EXEOM 1995	GEARCASE - COUNTER ROTATION
E150EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150EXERA 1994	GEARCASE - COUNTER ROTATION
E150EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXERV 1994	GEARCASE - COUNTER ROTATION
E150EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXETG 1993	GEARCASE - COUNTER ROTATION
E150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXETR 1993	GEARCASE - COUNTER ROTATION
E150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEUC 1997	GEARCASE - COUNTER-ROTATION
E150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEUE 1997	GEARCASE - COUNTER-ROTATION
E150FCXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FCXEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSMM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSMM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPLEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS

E150FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPLSDR	GEARCASE - PL - SL MODELS
E150FPLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLSOC	GEARCASE - PL - SL MODELS
E150FPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSIV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSIV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FSLEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FSLEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FSLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLSDR	GEARCASE - PL - SL MODELS
E150FSLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL

E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSOC	GEARCASE - PL - SL MODELS
E150FSLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150GLECD 1998	GEARCASE -- COUNTER-ROTATION
E150GLEDB 1996	GEARCASE - COUNTER-ROTATION
E150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEOM 1995	GEARCASE - COUNTER ROTATION
E150GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150GLERA 1994	GEARCASE - COUNTER ROTATION
E150GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150GLERV 1994	GEARCASE - COUNTER ROTATION
E150GLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150GLETG 1993	GEARCASE - COUNTER ROTATION
E150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150GLETR 1993	GEARCASE - COUNTER ROTATION
E150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEUC 1997	GEARCASE - COUNTER-ROTATION
E150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEUE 1997	GEARCASE - COUNTER-ROTATION
E150GNLABB	07-1_GEARCASE, O-Type
E150GNLABF	07-1_GEARCASE, O-Type

E150GNLABG	07-1_GEARCASE, O-Type
E150GNLABH	07-1_GEARCASE, O-Type
E150GNLABJ	07-1_GEARCASE, O-Type
E150ICXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150ILECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150ILECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150ILEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150IXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150JLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150JLECD 1998	GEARCASE -- COUNTER-ROTATION
E150JLEDB 1996	GEARCASE - COUNTER-ROTATION
E150JLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEOM 1995	GEARCASE - COUNTER ROTATION
E150JLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150JLERA 1994	GEARCASE - COUNTER ROTATION
E150JLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150JLERV 1994	GEARCASE - COUNTER ROTATION
E150JLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150JLETG 1993	GEARCASE - COUNTER ROTATION
E150JLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150JLETR 1993	GEARCASE - COUNTER ROTATION
E150JLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150JLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEUC 1997	GEARCASE - COUNTER-ROTATION
E150JLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEUE 1997	GEARCASE - COUNTER-ROTATION
E150NXARC 1994	GEARCASE - COUNTER ROTATION
E150NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

E150NXARV 1994	GEARCASE - COUNTER ROTATION
E150NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXATG 1993	GEARCASE - COUNTER ROTATION
E150NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXATS 1993	GEARCASE - COUNTER ROTATION
E150NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150NXECD 1998	GEARCASE -- COUNTER-ROTATION
E150NXEDB 1996	GEARCASE - COUNTER-ROTATION
E150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEOM 1995	GEARCASE - COUNTER ROTATION
E150NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150NXERA 1994	GEARCASE - COUNTER ROTATION
E150NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXERV 1994	GEARCASE - COUNTER ROTATION
E150NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXETG 1993	GEARCASE - COUNTER ROTATION
E150NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXETR 1993	GEARCASE - COUNTER ROTATION
E150NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEUC 1997	GEARCASE - COUNTER-ROTATION
E150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEUE 1997	GEARCASE - COUNTER-ROTATION
E150PLEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150SLECD 1998	GEARCASE -- COUNTER-ROTATION
E150SLEDB 1996	GEARCASE - COUNTER-ROTATION
E150SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"

E150SLEOM 1995	GEARCASE - COUNTER ROTATION
E150SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEUC 1997	GEARCASE - COUNTER-ROTATION
E150SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEUE 1997	GEARCASE - COUNTER-ROTATION
E150SNLABA	07-1_GEARCASE, O-Type
E150SNLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150SNLABB	07-1_GEARCASE, O-Type
E150SNLABF	07-1_GEARCASE, O-Type
E150SNLABG	07-1_GEARCASE, O-Type
E150SNLABH	07-1_GEARCASE, O-Type
E150SNLABJ	07-1_GEARCASE, O-Type
E150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
E150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
E150WTLEOR 1995	GEARCASE
E150WTLERC 1994	GEARCASE
E150WTLERV 1994	GEARCASE
E150WTLETG 1993	GEARCASE - 20" MODELS
E150WTLETG 1993	GEARCASE - 25" MODELS
E150WTLETS 1993	GEARCASE - 20" MODELS
E150WTLETS 1993	GEARCASE - 25" MODELS
E150WTXEOR 1995	GEARCASE
E150WTXERC 1994	GEARCASE
E150WTXERV 1994	GEARCASE
E150WTXETG 1993	GEARCASE - 20" MODELS
E150WTXETG 1993	GEARCASE - 25" MODELS
E150WTXETS 1993	GEARCASE - 20" MODELS
E150WTXETS 1993	GEARCASE - 25" MODELS
E175DGLABB	07-1_GEARCASE, O-Type
E175DGLABF	07-1_GEARCASE, O-Type
E175DGLABG	07-1_GEARCASE, O-Type
E175DGLABH	07-1_GEARCASE, O-Type
E175DPLAAA	07-1_GEARCASE, O-Type

E175DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLAAB	07-1_GEARCASE, O-Type
E175DPLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLABA	07-1_GEARCASE, O-Type
E175DPLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLABB	07-1_GEARCASE, O-Type
E175DPLIIB	GEARCASE, O-Type
E175DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLINE	GEARCASE, O-Type
E175DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLISF	GEARCASE - PL, SL MODELS
E175DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLISM	GEARCASE - PL, SL MODELS
E175DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSCR	GEARCASE - PL, SL MODELS
E175DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSEA	GEARCASE - PL, SL MODELS
E175DPLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSUF	GEARCASE - PL, SL MODELS
E175DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLAAA	07-1_GEARCASE, O-Type
E175DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLAAAB	07-1_GEARCASE, O-Type
E175DSLAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLABA	07-1_GEARCASE, O-Type
E175DSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLABB	07-1_GEARCASE, O-Type
E175DSLABF	07-1_GEARCASE, O-Type
E175DSLABG	07-1_GEARCASE, O-Type
E175DSLABH	07-1_GEARCASE, O-Type
E175DSLABJ	07-1_GEARCASE, O-Type
E175DSLIIB	GEARCASE, O-Type
E175DSLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIME	GEARCASE, O-Type
E175DSLIME - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E175DSLISF	GEARCASE - PL, SL MODELS
E175DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLISM	GEARCASE - PL, SL MODELS
E175DSLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLSCR	GEARCASE - PL, SL MODELS
E175DSLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLSEA	GEARCASE - PL, SL MODELS
E175DSLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLSTUF	GEARCASE - PL, SL MODELS
E175DSLSTUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175EXARC 1994	GEARCASE - COUNTER ROTATION
E175EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXARV 1994	GEARCASE - COUNTER ROTATION
E175EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXATG 1993	GEARCASE - COUNTER ROTATION
E175EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXATS 1993	GEARCASE - COUNTER ROTATION
E175EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175EXECD 1998	GEARCASE -- COUNTER-ROTATION
E175EXEDB 1996	GEARCASE - COUNTER-ROTATION
E175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEOM 1995	GEARCASE - COUNTER ROTATION
E175EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175EXERA 1994	GEARCASE - COUNTER ROTATION
E175EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXERV 1994	GEARCASE - COUNTER ROTATION
E175EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXETG 1993	GEARCASE - COUNTER ROTATION
E175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXETR 1993	GEARCASE - COUNTER ROTATION
E175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

E175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEUC 1997	GEARCASE - COUNTER-ROTATION
E175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEUE 1997	GEARCASE - COUNTER-ROTATION
E175FCXECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FCXEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPLEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPLEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPLSDS	GEARCASE - PL - SL MODELS
E175FPLSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPLSOD	GEARCASE - PL - SL MODELS
E175FPLSOD - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS

E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FSLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FSLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLSD	GEARCASE - PL - SL MODELS
E175FSLSD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSOE	GEARCASE - PL - SL MODELS
E175FSLSOE - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSXECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS

E175FTLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175GLECD 1998	GEARCASE -- COUNTER-ROTATION
E175GLEDB 1996	GEARCASE - COUNTER-ROTATION
E175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEOM 1995	GEARCASE - COUNTER ROTATION
E175GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175GLERA 1994	GEARCASE - COUNTER ROTATION
E175GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175GLETG 1993	GEARCASE - COUNTER ROTATION
E175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175GLETR 1993	GEARCASE - COUNTER ROTATION
E175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEUC 1997	GEARCASE - COUNTER-ROTATION
E175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEUE 1997	GEARCASE - COUNTER-ROTATION
E175NXARC 1994	GEARCASE - COUNTER ROTATION
E175NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXARV 1994	GEARCASE - COUNTER ROTATION
E175NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXATG 1993	GEARCASE - COUNTER ROTATION
E175NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXATS 1993	GEARCASE - COUNTER ROTATION
E175NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175NXECD 1998	GEARCASE -- COUNTER-ROTATION
E175NXEDB 1996	GEARCASE - COUNTER-ROTATION
E175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"

E175NXEOM 1995	GEARCASE - COUNTER ROTATION
E175NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175NXERA 1994	GEARCASE - COUNTER ROTATION
E175NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXERV 1994	GEARCASE - COUNTER ROTATION
E175NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXETG 1993	GEARCASE - COUNTER ROTATION
E175NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXETR 1993	GEARCASE - COUNTER ROTATION
E175NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175NXEUC 1997	GEARCASE - COUNTER-ROTATION
E175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175NXEUE 1997	GEARCASE - COUNTER-ROTATION
E175SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175SLECD 1998	GEARCASE -- COUNTER-ROTATION
E175SLEDB 1996	GEARCASE - COUNTER-ROTATION
E175SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEOM 1995	GEARCASE - COUNTER ROTATION
E175SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175SLERA 1994	GEARCASE - COUNTER ROTATION
E175SLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEUC 1997	GEARCASE - COUNTER-ROTATION
E175SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEUE 1997	GEARCASE - COUNTER-ROTATION
E185ESERK 1994	GEARCASE - COUNTER ROTATION
E185ESERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXETA 1993	GEARCASE - COUNTER ROTATION

E185ESXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXETF 1993	GEARCASE - COUNTER ROTATION
E185ESXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXARC 1994	GEARCASE - COUNTER ROTATION
E200CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXARK 1994	GEARCASE - COUNTER ROTATION
E200CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXATF 1993	GEARCASE - COUNTER ROTATION
E200CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXATS 1993	GEARCASE - COUNTER ROTATION
E200CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200CXEDR 1996	GEARCASE - COUNTER-ROTATION
E200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXEOC 1995	GEARCASE - COUNTER ROTATION
E200CXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXERK 1994	GEARCASE - COUNTER ROTATION
E200CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXERS 1994	GEARCASE - COUNTER ROTATION
E200CXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXETD 1993	GEARCASE - COUNTER ROTATION
E200CXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXETF 1993	GEARCASE - COUNTER ROTATION
E200CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXEUA 1997	GEARCASE - COUNTER-ROTATION
E200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZARK 1994	GEARCASE - COUNTER ROTATION

E200CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZATF 1993	GEARCASE - COUNTER ROTATION
E200CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZATS 1993	GEARCASE - COUNTER ROTATION
E200CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZEOC 1995	GEARCASE - COUNTER ROTATION
E200CZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZERK 1994	GEARCASE - COUNTER ROTATION
E200CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZERS 1994	GEARCASE - COUNTER ROTATION
E200CZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZETD 1993	GEARCASE - COUNTER ROTATION
E200CZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZETF 1993	GEARCASE - COUNTER ROTATION
E200CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200DGLABB	07-1_GEARCASE, O-Type
E200DGLABF	07-1_GEARCASE, O-Type
E200DGLABG	07-1_GEARCASE, O-Type
E200DPLAAA - (60 degree V6)	07-1_GEARCASE, O-Type
E200DPLAAA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLAAB - (60 degree V6)	07-1_GEARCASE, O-Type
E200DPLAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLABA	07-1_GEARCASE, O-Type
E200DPLABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLABB	07-1_GEARCASE, O-Type
E200DPLIIE - (60 degree V6)	GEARCASE, O-Type
E200DPLIIE - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLIND - (60 degree V6)	GEARCASE, O-Type
E200DPLIND - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLISB	GEARCASE - PL, SL MODELS
E200DPLISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E200DPLISF	GEARCASE - PL, SL MODELS
E200DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSCA	GEARCASE - PL, SL MODELS
E200DPLSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSEM	GEARCASE - PL, SL MODELS
E200DPLSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSUF	GEARCASE - PL, SL MODELS
E200DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSUR	GEARCASE - PL, SL MODELS
E200DPLSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLAAA - (60 degree V6)	07-1_GEARCASE, O-Type
E200DSLAAA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLAAAB - (60 degree V6)	07-1_GEARCASE, O-Type
E200DSLAAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLABA	07-1_GEARCASE, O-Type
E200DSLABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLABB	07-1_GEARCASE, O-Type
E200DSLABF	07-1_GEARCASE, O-Type
E200DSLABG	07-1_GEARCASE, O-Type
E200DSLABJ	07-1_GEARCASE, O-Type
E200DSLIIIE - (60 degree V6)	GEARCASE, O-Type
E200DSLIIIE - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLIND - (60 degree V6)	GEARCASE, O-Type
E200DSLIND - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLISB	GEARCASE - PL, SL MODELS
E200DSLISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLISF	GEARCASE - PL, SL MODELS
E200DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLSCA	GEARCASE - PL, SL MODELS
E200DSLSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLSEM	GEARCASE - PL, SL MODELS
E200DSLSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DLSUF	GEARCASE - PL, SL MODELS
E200DLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DLSUR	GEARCASE - PL, SL MODELS

E200DSLUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FCXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E200FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
E200FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
E200FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FSLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FSLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FSLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS

E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - Counter Rotation
E200STLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200STLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200STLEDM 1996	GEARCASE - COUNTER-ROTATION
E200STLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLEOA 1995	GEARCASE - COUNTER ROTATION
E200STLEOA 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLERK 1994	GEARCASE - COUNTER ROTATION
E200STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLERR 1994	GEARCASE - COUNTER ROTATION
E200STLERR 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLETC 1993	GEARCASE - COUNTER ROTATION
E200STLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLETF 1993	GEARCASE - COUNTER ROTATION
E200STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLEUB 1997	GEARCASE - COUNTER-ROTATION
E200STLEUB 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TLECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200TLECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200TXARC 1994	GEARCASE - COUNTER ROTATION
E200TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXARK 1994	GEARCASE - COUNTER ROTATION
E200TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXATF 1993	GEARCASE - COUNTER ROTATION
E200TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXATS 1993	GEARCASE - COUNTER ROTATION
E200TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

E200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200TXEDR 1996	GEARCASE - COUNTER-ROTATION
E200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXEOC 1995	GEARCASE - COUNTER ROTATION
E200TXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXERK 1994	GEARCASE - COUNTER ROTATION
E200TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXERS 1994	GEARCASE - COUNTER ROTATION
E200TXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXETD 1993	GEARCASE - COUNTER ROTATION
E200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXETF 1993	GEARCASE - COUNTER ROTATION
E200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXEUA 1997	GEARCASE - COUNTER-ROTATION
E200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZARK 1994	GEARCASE - COUNTER ROTATION
E200TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZATF 1993	GEARCASE - COUNTER ROTATION
E200TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZATS 1993	GEARCASE - COUNTER ROTATION
E200TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZEOC 1995	GEARCASE - COUNTER ROTATION
E200TZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZERK 1994	GEARCASE - COUNTER ROTATION
E200TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZERS 1994	GEARCASE - COUNTER ROTATION
E200TZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZETD 1993	GEARCASE - COUNTER ROTATION
E200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E200TZETF 1993	GEARCASE - COUNTER ROTATION
E200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200WPXEEN 1999	GEARCASE
E200WPXEES 1999	GEARCASE
E200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	GEARCASE
E225CXARC 1994	GEARCASE - COUNTER ROTATION
E225CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXARK 1994	GEARCASE - COUNTER ROTATION
E225CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXATF 1993	GEARCASE - COUNTER ROTATION
E225CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXATS 1993	GEARCASE - COUNTER ROTATION
E225CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225CXEDE 1996	GEARCASE - COUNTER-ROTATION
E225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXEOB 1995	GEARCASE - COUNTER ROTATION
E225CXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXERK 1994	GEARCASE - COUNTER ROTATION
E225CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXERM 1994	GEARCASE - COUNTER ROTATION
E225CXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXETA 1993	GEARCASE - COUNTER ROTATION
E225CXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXETF 1993	GEARCASE - COUNTER ROTATION
E225CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXEUD 1997	GEARCASE - COUNTER-ROTATION

E225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZARK 1994	GEARCASE - COUNTER ROTATION
E225CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZATF 1993	GEARCASE - COUNTER ROTATION
E225CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZATS 1993	GEARCASE - COUNTER ROTATION
E225CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225CZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225CZEDE 1996	GEARCASE - COUNTER-ROTATION
E225CZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZEOB 1995	GEARCASE - COUNTER ROTATION
E225CZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZERK 1994	GEARCASE - COUNTER ROTATION
E225CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZERM 1994	GEARCASE - COUNTER ROTATION
E225CZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZETA 1993	GEARCASE - COUNTER ROTATION
E225CZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZETF 1993	GEARCASE - COUNTER ROTATION
E225CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZEUD 1997	GEARCASE - COUNTER-ROTATION
E225CZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS

E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E225FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E225FCZSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCZSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
E225FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - Counter Rotation

E225FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZEE0 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEE0 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - Counter Rotation
E225FPZSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225PLERK 1994	GEARCASE - COUNTER ROTATION
E225PLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLERM 1994	GEARCASE - COUNTER ROTATION
E225PLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLETA 1993	GEARCASE - COUNTER ROTATION
E225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLETF 1993	GEARCASE - COUNTER ROTATION
E225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXARC 1994	GEARCASE - COUNTER ROTATION
E225PXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXARK 1994	GEARCASE - COUNTER ROTATION
E225PXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXATF 1993	GEARCASE - COUNTER ROTATION
E225PXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXATS 1993	GEARCASE - COUNTER ROTATION
E225PXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225PXEDE 1996	GEARCASE - COUNTER-ROTATION
E225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXEOB 1995	GEARCASE - COUNTER ROTATION
E225PXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXERK 1994	GEARCASE - COUNTER ROTATION
E225PXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXERM 1994	GEARCASE - COUNTER ROTATION
E225PXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXETA 1993	GEARCASE - COUNTER ROTATION
E225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXETF 1993	GEARCASE - COUNTER ROTATION
E225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZARK 1994	GEARCASE - COUNTER ROTATION
E225PZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZATF 1993	GEARCASE - COUNTER ROTATION
E225PZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZATS 1993	GEARCASE - COUNTER ROTATION
E225PZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZEOB 1995	GEARCASE - COUNTER ROTATION
E225PZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZERK 1994	GEARCASE - COUNTER ROTATION
E225PZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZERM 1994	GEARCASE - COUNTER ROTATION
E225PZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZETA 1993	GEARCASE - COUNTER ROTATION
E225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZETF 1993	GEARCASE - COUNTER ROTATION
E225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225STLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225STLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225STLEDE 1996	GEARCASE - COUNTER-ROTATION
E225STLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLEOB 1995	GEARCASE - COUNTER ROTATION
E225STLEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLERC 1994	GEARCASE - COUNTER ROTATION
E225STLERC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLERK 1994	GEARCASE - COUNTER ROTATION
E225STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLETF 1993	GEARCASE - COUNTER ROTATION
E225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLEUD 1997	GEARCASE - COUNTER-ROTATION
E225STLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLERK 1994	GEARCASE - COUNTER ROTATION
E225TLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLERM 1994	GEARCASE - COUNTER ROTATION
E225TLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLETA 1993	GEARCASE - COUNTER ROTATION
E225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLETF 1993	GEARCASE - COUNTER ROTATION
E225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXARC 1994	GEARCASE - COUNTER ROTATION
E225TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXARK 1994	GEARCASE - COUNTER ROTATION
E225TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXATF 1993	GEARCASE - COUNTER ROTATION
E225TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225TXATS 1993	GEARCASE - COUNTER ROTATION
E225TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225TXEDE 1996	GEARCASE - COUNTER-ROTATION
E225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXEOB 1995	GEARCASE - COUNTER ROTATION
E225TXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXERK 1994	GEARCASE - COUNTER ROTATION
E225TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXERM 1994	GEARCASE - COUNTER ROTATION
E225TXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXETA 1993	GEARCASE - COUNTER ROTATION
E225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXETF 1993	GEARCASE - COUNTER ROTATION
E225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXEUD 1997	GEARCASE - COUNTER-ROTATION
E225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZARK 1994	GEARCASE - COUNTER ROTATION
E225TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZATF 1993	GEARCASE - COUNTER ROTATION
E225TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZATS 1993	GEARCASE - COUNTER ROTATION
E225TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225TZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225TZEDE 1996	GEARCASE - COUNTER-ROTATION
E225TZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225TZE0B 1995	GEARCASE - COUNTER ROTATION
E225TZE0B 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZERK 1994	GEARCASE - COUNTER ROTATION
E225TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZERM 1994	GEARCASE - COUNTER ROTATION
E225TZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZETA 1993	GEARCASE - COUNTER ROTATION
E225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZETF 1993	GEARCASE - COUNTER ROTATION
E225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZEUD 1997	GEARCASE - COUNTER-ROTATION
E225TZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E250CXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250CXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250CZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250CZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E250FCXSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E250FCZSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
E250FPXSSS FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS

E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - Counter Rotation
E250FPZSSS FFI, Elec Start, TNT, 30 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250PXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250PXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250PZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250PZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E60HGLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HSLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HSLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HSLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E75DPGLAFA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFC	07-1_GEARCASE, (0.50 Ratio) S-Type

E75DPGLAFD	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFF	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFG	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLIIS	GEARCASE, S-Type
E75DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLINC	GEARCASE, S-Type
E75DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLISD	GEARCASE - PL, SL MODELS
E75DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLISF	GEARCASE - PL, SL MODELS
E75DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSCB	GEARCASE - PL, SL MODELS
E75DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSEE	GEARCASE - PL, SL MODELS
E75DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSUM	GEARCASE - PL, SL MODELS
E75DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLafa	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFc	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFD	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFf	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAFG	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLIIA	GEARCASE, S-Type
E75DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLINM	GEARCASE, S-Type
E75DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S

E75DSLISF	GEARCASE - PL, SL MODELS
E75DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLISR	GEARCASE - PL, SL MODELS
E75DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLSCS	GEARCASE - PL, SL MODELS
E75DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLSEC	GEARCASE - PL, SL MODELS
E75DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E75FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E90DGXAFA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DHLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90DHLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90DMXSES	GEARCASE - DMX
E90DPGLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLIIS	GEARCASE, S-Type
E90DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLINC	GEARCASE, S-Type
E90DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLISD	GEARCASE - PL, SL MODELS

E90DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLISF	GEARCASE - PL, SL MODELS
E90DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSCB	GEARCASE - PL, SL MODELS
E90DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSEE	GEARCASE - PL, SL MODELS
E90DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSUM	GEARCASE - PL, SL MODELS
E90DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPXAAA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXABA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXABB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXIIS	GEARCASE, O-Type
E90DPXIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXINC	GEARCASE, O-Type
E90DPXINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXISD	GEARCASE - PX MODELS
E90DPXISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXISF	GEARCASE - PX MODELS
E90DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSCB	GEARCASE - PX MODELS
E90DPXSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSDA	GEARCASE - PX MODELS
E90DPXSDA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E90DPXSEE	GEARCASE - PX MODELS
E90DPXSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSOR	GEARCASE PX , W MODELS
E90DPXSOR - FR	07-1_BOÎTIER D'ENGRENAGES PX , W MODELES

E90DPXSRC	GEARCASE PX MODELS
E90DPXSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E90DPXSUM	GEARCASE - PX MODELS
E90DPXSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DSLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLafa	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLAFc	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLAFf	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLAFg	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLIIID	GEARCASE, S-Type
E90DSLIIID - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLINS	GEARCASE, S-Type
E90DSLINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLISE	GEARCASE - PL, SL MODELS
E90DSLISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLISF	GEARCASE - PL, SL MODELS
E90DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLSCM	GEARCASE - PL, SL MODELS
E90DSLSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLSEB	GEARCASE - PL, SL MODELS
E90DSLSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL SUA	GEARCASE - PL, SL MODELS
E90DSL SUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90ELECTM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E90ELECTM 1998	GEARCASE -- 90 & 115 SX MODELS
E90ELED R 1996	GEARCASE - 20 IN. MODELS
E90ELED R 1996	GEARCASE - 25 IN. MODELS
E90ELEOC 1995	GEARCASE - 20 IN. MODELS
E90ELEOC 1995	GEARCASE - 25 IN. MODELS
E90ELEUA 1997	GEARCASE - 20 IN. MODELS

E90ELEUA 1997	GEARCASE - 25 IN. MODELS
E90ELEUC 1997	GEARCASE - 20 IN. MODELS
E90ELEUC 1997	GEARCASE - 25 IN. MODELS
E90EXEOC 1995	GEARCASE - 20 IN. MODELS
E90EXEOC 1995	GEARCASE - 25 IN. MODELS
E90FPLEEC 1999	GEARCASE -- FPX MODELS
E90FPLEEN 1999	GEARCASE -- FPX MODELS
E90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E90FSLECS 1998	GEARCASE -- FSL, FTL MODELS
E90FSLECS 1998	GEARCASE -- FSX MODELS
E90FTLECS 1998	GEARCASE -- FSL, FTL MODELS
E90FTLECS 1998	GEARCASE -- FSX MODELS
E90FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E90GLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90HGLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGXAFA	07-1_GEARCASE, O-Type
E90HGXAFF	07-1_GEARCASE, O-Type
E90HGXAFAH	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFAI	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFAK	07-1_GEARCASE, (0.44 Ratio) O-Type

E90HGXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSXAFA	07-1_GEARCASE, O-Type
E90HSXAFB	07-1_GEARCASE, O-Type
E90HSXAFF	07-1_GEARCASE, O-Type
E90HSXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E90SLABA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E90SLEDR 1996	GEARCASE - 20 IN. MODELS
E90SLEDR 1996	GEARCASE - 25 IN. MODELS
E90SLEOC 1995	GEARCASE - 20 IN. MODELS
E90SLEOC 1995	GEARCASE - 25 IN. MODELS
E90SLEUA 1997	GEARCASE - 20 IN. MODELS
E90SLEUA 1997	GEARCASE - 25 IN. MODELS
E90SLEUC 1997	GEARCASE - 20 IN. MODELS
E90SLEUC 1997	GEARCASE - 25 IN. MODELS
E90SNLABA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type

E90SNLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90WDELIIA	GEARCASE, S-Type
E90WDELIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELINM	GEARCASE, S-Type
E90WDELINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELISF	GEARCASE - PL, SL MODELS
E90WDELISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELISR	GEARCASE - PL, SL MODELS
E90WDELISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELSCS	GEARCASE - PL, SL MODELS
E90WDELSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELSEC	GEARCASE - PL, SL MODELS
E90WDELSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDEXIIA	GEARCASE, O-Type
E90WDEXIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXINM	GEARCASE, O-Type
E90WDEXINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXISF	GEARCASE - PX MODELS
E90WDEXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXISR	GEARCASE - PX MODELS
E90WDEXISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXSCS	GEARCASE - PX MODELS
E90WDEXSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXSEC	GEARCASE - PX MODELS
E90WDEXSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDPLSOS	GEARCASE PX , W MODELS
E90WDPLSOS - FR	07-1_BOÎTIER D'ENGRENAGES PX , W MODELES
HE115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
HE115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
HE115SLEDR 1996	GEARCASE - 20 IN. MODELS
HE115SLEDR 1996	GEARCASE - 25 IN. MODELS
HE115SLEUA 1997	GEARCASE - 20 IN. MODELS
HE115SLEUA 1997	GEARCASE - 25 IN. MODELS

HE115SLEUC 1997	GEARCASE - 20 IN. MODELS
HE115SLEUC 1997	GEARCASE - 25 IN. MODELS
HE130CXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HE130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130CXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HE130CXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130TXACB 1998	GEARCASE
HE130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HE130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130TXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HE130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
HJ115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
HJ115SLEDR 1996	GEARCASE - 20 IN. MODELS
HJ115SLEDR 1996	GEARCASE - 25 IN. MODELS
HJ115SLEUA 1997	GEARCASE - 20 IN. MODELS
HJ115SLEUA 1997	GEARCASE - 25 IN. MODELS
HJ115SLEUC 1997	GEARCASE - 20 IN. MODELS
HJ115SLEUC 1997	GEARCASE - 25 IN. MODELS
HJ130CXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HJ130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130CXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HJ130CXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130TXACB 1998	GEARCASE
HJ130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HJ130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130TXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HJ130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J100WPLEEC 1999	GEARCASE
J100WPLSIF commercial, elec start, 20 in shaft 2001	GEARCASE
J100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J100WPXEEC 1999	GEARCASE
J100WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J100WQLECS 1998	GEARCASE -- 100WQL MODELS

J100WQLECS 1998	GEARCASE -- 100WQX MODELS
J100WQXECS 1998	GEARCASE -- 100WQL MODELS
J100WQXECS 1998	GEARCASE -- 100WQX MODELS
J100WTLEDR 1996	GEARCASE
J100WTLEOC 1995	GEARCASE
J100WTLERS 1994	GEARCASE
J100WTLETD 1993	GEARCASE
J100WTLEUA 1997	GEARCASE
J100WTXEDR 1996	GEARCASE
J100WTXEOC 1995	GEARCASE
J100WTXERS 1994	GEARCASE
J100WTXETD 1993	GEARCASE
J100WTXEUA 1997	GEARCASE
J105WELEEN 1999	GEARCASE
J105WELEES 1999	GEARCASE
J105WELSIF commercial, elec start, 20 in shaft 2001	GEARCASE
J105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
J105WPLEEN 1999	GEARCASE
J105WPLEES 1999	GEARCASE
J105WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
J105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J105WPXEEN 1999	GEARCASE
J105WPXEES 1999	GEARCASE
J105WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J105WRLEES 1999	GEARCASE
J105WRLSIF commercial, rope start, 20 in shaft 2001	GEARCASE
J105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
J105WRYEES 1999	GEARCASE
J105WRYSIF commercial, rope start, 22.5 in shaft 2001	GEARCASE
J105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
J115ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115ELEDR 1996	GEARCASE - 20 IN. MODELS
J115ELEDR 1996	GEARCASE - 25 IN. MODELS

J115ELEOC 1995	GEARCASE - 20 IN. MODELS
J115ELEOC 1995	GEARCASE - 25 IN. MODELS
J115ELEUA 1997	GEARCASE - 20 IN. MODELS
J115ELEUA 1997	GEARCASE - 25 IN. MODELS
J115ELEUC 1997	GEARCASE - 20 IN. MODELS
J115ELEUC 1997	GEARCASE - 25 IN. MODELS
J115FSLECS 1998	GEARCASE -- FSL, FTL MODELS
J115FSLECS 1998	GEARCASE -- FSX MODELS
J115FSXECS 1998	GEARCASE -- FSL, FTL MODELS
J115FSXECS 1998	GEARCASE -- FSX MODELS
J115FTLECS 1998	GEARCASE -- FSL, FTL MODELS
J115FTLECS 1998	GEARCASE -- FSX MODELS
J115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115GLEDR 1996	GEARCASE - 20 IN. MODELS
J115GLEDR 1996	GEARCASE - 25 IN. MODELS
J115GLEOC 1995	GEARCASE - 20 IN. MODELS
J115GLEOC 1995	GEARCASE - 25 IN. MODELS
J115GLEUA 1997	GEARCASE - 20 IN. MODELS
J115GLEUA 1997	GEARCASE - 25 IN. MODELS
J115GLEUC 1997	GEARCASE - 20 IN. MODELS
J115GLEUC 1997	GEARCASE - 25 IN. MODELS
J115JPLEEC 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115JPLEEC 1999	GEARCASE -- 90 & 115 PX MODELS
J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115JTLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115JTLECS 1998	GEARCASE -- 90 & 115 SX MODELS
J115PLEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115PLEEM 1999	GEARCASE -- 90 & 115 PX MODELS
J115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS

J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115PXEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115PXEEM 1999	GEARCASE -- 90 & 115 PX MODELS
J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115SLEDR 1996	GEARCASE - 20 IN. MODELS
J115SLEDR 1996	GEARCASE - 25 IN. MODELS
J115SLEOC 1995	GEARCASE - 20 IN. MODELS
J115SLEOC 1995	GEARCASE - 25 IN. MODELS
J115SLEUA 1997	GEARCASE - 20 IN. MODELS
J115SLEUA 1997	GEARCASE - 25 IN. MODELS
J115SLEUC 1997	GEARCASE - 20 IN. MODELS
J115SLEUC 1997	GEARCASE - 25 IN. MODELS
J115SPLEES 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115SPLEES 1999	GEARCASE -- 90 & 115 PX MODELS
J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115SXEDR 1996	GEARCASE - 20 IN. MODELS
J115SXEDR 1996	GEARCASE - 25 IN. MODELS
J115SXEOC 1995	GEARCASE - 20 IN. MODELS
J115SXEOC 1995	GEARCASE - 25 IN. MODELS
J115SX EUA 1997	GEARCASE - 20 IN. MODELS
J115SX EUA 1997	GEARCASE - 25 IN. MODELS
J115SX EUC 1997	GEARCASE - 20 IN. MODELS
J115SX EUC 1997	GEARCASE - 25 IN. MODELS
J115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J115VLSSS Elec. Start, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115VLSSS Elec. Start, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS

J115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J120TLARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLARC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLARK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLATS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLERC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLETf 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLETf 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXERC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION

J120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125ESXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J125ESXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J125ESXETA 1993	GEARCASE - 140CX COUNTER ROTATION
J125ESXETA 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125ESXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J125ESXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125WTPLE 1995	GEARCASE
J130CXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
J130CXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130PLEED 1999	GEARCASE
J130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J130PXED 1999	GEARCASE
J130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J130TLECE 1998	GEARCASE
J130TLEDM 1996	GEARCASE - 130CX COUNTER ROTATION
J130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TLEOA 1995	GEARCASE - 130CX COUNTER ROTATION
J130TLEOA 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
J130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXACB 1998	GEARCASE
J130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
J130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
J130TXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
J130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE
J135PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J135VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE

J135VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE
J140CXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXERE 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXERE 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXETB 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXETB 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLARR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLARR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLATC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLATC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLERR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX

J140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXERR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J150CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150ELARA 1994	GEARCASE - COUNTER ROTATION
J150ELARA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELARV 1994	GEARCASE - COUNTER ROTATION
J150ELARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELATG 1993	GEARCASE - COUNTER ROTATION
J150ELATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELATR 1993	GEARCASE - COUNTER ROTATION
J150ELATR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS

J150ELECD 1998	GEARCASE -- COUNTER-ROTATION
J150ELEDDB 1996	GEARCASE - COUNTER-ROTATION
J150ELEDDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEOM 1995	GEARCASE - COUNTER ROTATION
J150ELEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150ELERA 1994	GEARCASE - COUNTER ROTATION
J150ELERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELERV 1994	GEARCASE - COUNTER ROTATION
J150ELERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELETG 1993	GEARCASE - COUNTER ROTATION
J150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELETR 1993	GEARCASE - COUNTER ROTATION
J150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEUC 1997	GEARCASE - COUNTER-ROTATION
J150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEUE 1997	GEARCASE - COUNTER-ROTATION
J150EXARC 1994	GEARCASE - COUNTER ROTATION
J150EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXARV 1994	GEARCASE - COUNTER ROTATION
J150EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXATG 1993	GEARCASE - COUNTER ROTATION
J150EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXATS 1993	GEARCASE - COUNTER ROTATION
J150EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150EXECD 1998	GEARCASE -- COUNTER-ROTATION
J150EXEDDB 1996	GEARCASE - COUNTER-ROTATION
J150EXEDDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEOM 1995	GEARCASE - COUNTER ROTATION

J150EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150EXERA 1994	GEARCASE - COUNTER ROTATION
J150EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXERV 1994	GEARCASE - COUNTER ROTATION
J150EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXETG 1993	GEARCASE - COUNTER ROTATION
J150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXETR 1993	GEARCASE - COUNTER ROTATION
J150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEUC 1997	GEARCASE - COUNTER-ROTATION
J150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEUE 1997	GEARCASE - COUNTER-ROTATION
J150FCXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FSLECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FSXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150GLECD 1998	GEARCASE -- COUNTER-ROTATION
J150GLEDB 1996	GEARCASE - COUNTER-ROTATION
J150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEOM 1995	GEARCASE - COUNTER ROTATION
J150GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150GLERA 1994	GEARCASE - COUNTER ROTATION
J150GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150GLERV 1994	GEARCASE - COUNTER ROTATION
J150GLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150GLETG 1993	GEARCASE - COUNTER ROTATION

J150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150GLETR 1993	GEARCASE - COUNTER ROTATION
J150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEUC 1997	GEARCASE - COUNTER-ROTATION
J150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEUE 1997	GEARCASE - COUNTER-ROTATION
J150GLSDE	GEARCASE - PL - GL MODELS
J150GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J150GLSOB	GEARCASE - PL - SL MODELS
J150GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J150ICXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150ILECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150ILECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150ILEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150IXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150JLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150JLECD 1998	GEARCASE -- COUNTER-ROTATION
J150JLEDB 1996	GEARCASE - COUNTER-ROTATION
J150JLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEOM 1995	GEARCASE - COUNTER ROTATION
J150JLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150JLERA 1994	GEARCASE - COUNTER ROTATION
J150JLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150JLERV 1994	GEARCASE - COUNTER ROTATION
J150JLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150JLETG 1993	GEARCASE - COUNTER ROTATION
J150JLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150JLETR 1993	GEARCASE - COUNTER ROTATION

J150JLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150JLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEUC 1997	GEARCASE - COUNTER-ROTATION
J150JLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEUE 1997	GEARCASE - COUNTER-ROTATION
J150JPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150JPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150NXARC 1994	GEARCASE - COUNTER ROTATION
J150NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXARV 1994	GEARCASE - COUNTER ROTATION
J150NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXATG 1993	GEARCASE - COUNTER ROTATION
J150NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXATS 1993	GEARCASE - COUNTER ROTATION
J150NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150NXECD 1998	GEARCASE -- COUNTER-ROTATION
J150NXEDB 1996	GEARCASE - COUNTER-ROTATION
J150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEOM 1995	GEARCASE - COUNTER ROTATION
J150NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150NXERA 1994	GEARCASE - COUNTER ROTATION
J150NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

J150NXERV 1994	GEARCASE - COUNTER ROTATION
J150NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXETG 1993	GEARCASE - COUNTER ROTATION
J150NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXETR 1993	GEARCASE - COUNTER ROTATION
J150NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEUC 1997	GEARCASE - COUNTER-ROTATION
J150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEUE 1997	GEARCASE - COUNTER-ROTATION
J150PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150PLEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150PLSDD	GEARCASE - PL - GL MODELS
J150PLSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150PLSOE	GEARCASE - PL - SL MODELS
J150PLSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150SLECD 1998	GEARCASE -- COUNTER-ROTATION
J150SLEDB 1996	GEARCASE - COUNTER-ROTATION
J150SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J150SLEOM 1995	GEARCASE - COUNTER ROTATION
J150SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150SLEUC 1997	GEARCASE - COUNTER-ROTATION
J150SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150SLEUE 1997	GEARCASE - COUNTER-ROTATION
J150SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150SPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150WPLEES 1999	GEARCASE
J150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
J150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J150WTLEOR 1995	GEARCASE
J150WTLERC 1994	GEARCASE
J150WTLERV 1994	GEARCASE

J150WTLETG 1993	GEARCASE - 20" MODELS
J150WTLETG 1993	GEARCASE - 25" MODELS
J150WTLETS 1993	GEARCASE - 20" MODELS
J150WTLETS 1993	GEARCASE - 25" MODELS
J150WTXEOR 1995	GEARCASE
J150WTXERC 1994	GEARCASE
J150WTXERV 1994	GEARCASE
J150WTXETG 1993	GEARCASE - 20" MODELS
J150WTXETG 1993	GEARCASE - 25" MODELS
J150WTXETS 1993	GEARCASE - 20" MODELS
J150WTXETS 1993	GEARCASE - 25" MODELS
J175CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175EXARC 1994	GEARCASE - COUNTER ROTATION
J175EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXARV 1994	GEARCASE - COUNTER ROTATION
J175EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXATG 1993	GEARCASE - COUNTER ROTATION
J175EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXATS 1993	GEARCASE - COUNTER ROTATION
J175EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175EXECD 1998	GEARCASE -- COUNTER-ROTATION
J175EXEDB 1996	GEARCASE - COUNTER-ROTATION
J175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEOM 1995	GEARCASE - COUNTER ROTATION
J175EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175EXERA 1994	GEARCASE - COUNTER ROTATION
J175EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

J175EXERV 1994	GEARCASE - COUNTER ROTATION
J175EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXETG 1993	GEARCASE - COUNTER ROTATION
J175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXETR 1993	GEARCASE - COUNTER ROTATION
J175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEUC 1997	GEARCASE - COUNTER-ROTATION
J175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEUE 1997	GEARCASE - COUNTER-ROTATION
J175FCX ECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FCX ECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FSLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FSX ECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FSX ECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FTLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175GLECD 1998	GEARCASE -- COUNTER-ROTATION
J175GLEDB 1996	GEARCASE - COUNTER-ROTATION
J175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEOM 1995	GEARCASE - COUNTER ROTATION
J175GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175GLERA 1994	GEARCASE - COUNTER ROTATION
J175GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175GLETG 1993	GEARCASE - COUNTER ROTATION
J175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175GLETR 1993	GEARCASE - COUNTER ROTATION
J175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J175GLEUC 1997	GEARCASE - COUNTER-ROTATION
J175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEUE 1997	GEARCASE - COUNTER-ROTATION
J175GLSDE	GEARCASE - PL - GL MODELS
J175GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J175GLSOB	GEARCASE - PL - SL MODELS
J175GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J175NXARC 1994	GEARCASE - COUNTER ROTATION
J175NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXARV 1994	GEARCASE - COUNTER ROTATION
J175NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXATG 1993	GEARCASE - COUNTER ROTATION
J175NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXATS 1993	GEARCASE - COUNTER ROTATION
J175NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175NXECD 1998	GEARCASE -- COUNTER-ROTATION
J175NXEDB 1996	GEARCASE - COUNTER-ROTATION
J175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175NXEOM 1995	GEARCASE - COUNTER ROTATION
J175NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175NXERA 1994	GEARCASE - COUNTER ROTATION
J175NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXERV 1994	GEARCASE - COUNTER ROTATION
J175NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXETG 1993	GEARCASE - COUNTER ROTATION
J175NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXETR 1993	GEARCASE - COUNTER ROTATION
J175NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J175NxEUC 1997	GEARCASE - COUNTER-ROTATION
J175NxEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175NxEUE 1997	GEARCASE - COUNTER-ROTATION
J175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175PLSDD	GEARCASE - PL - GL MODELS
J175PLSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175PLSOE	GEARCASE - PL - SL MODELS
J175PLSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175SLECD 1998	GEARCASE -- COUNTER-ROTATION
J175SLEDB 1996	GEARCASE - COUNTER-ROTATION
J175SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEOM 1995	GEARCASE - COUNTER ROTATION
J175SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175SLERA 1994	GEARCASE - COUNTER ROTATION
J175SLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEUC 1997	GEARCASE - COUNTER-ROTATION
J175SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEUE 1997	GEARCASE - COUNTER-ROTATION

J175SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175SPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J185ESERK 1994	GEARCASE - COUNTER ROTATION
J185ESERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXETA 1993	GEARCASE - COUNTER ROTATION
J185ESXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXETF 1993	GEARCASE - COUNTER ROTATION
J185ESXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXARC 1994	GEARCASE - COUNTER ROTATION
J200CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXARK 1994	GEARCASE - COUNTER ROTATION
J200CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXATF 1993	GEARCASE - COUNTER ROTATION
J200CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200CXATS 1993	GEARCASE - COUNTER ROTATION
J200CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200CXEDR 1996	GEARCASE - COUNTER-ROTATION
J200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200CXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200CXEOC 1995	GEARCASE - COUNTER ROTATION
J200CXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXERK 1994	GEARCASE - COUNTER ROTATION
J200CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXERS 1994	GEARCASE - COUNTER ROTATION
J200CXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXETD 1993	GEARCASE - COUNTER ROTATION
J200CXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXETF 1993	GEARCASE - COUNTER ROTATION
J200CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXEUA 1997	GEARCASE - COUNTER-ROTATION
J200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200XSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200XSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200CZARK 1994	GEARCASE - COUNTER ROTATION
J200CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZATF 1993	GEARCASE - COUNTER ROTATION
J200CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZATS 1993	GEARCASE - COUNTER ROTATION
J200CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200CZEOC 1995	GEARCASE - COUNTER ROTATION
J200CZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZERK 1994	GEARCASE - COUNTER ROTATION
J200CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZERS 1994	GEARCASE - COUNTER ROTATION
J200CZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZETD 1993	GEARCASE - COUNTER ROTATION
J200CZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZETF 1993	GEARCASE - COUNTER ROTATION
J200CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PLEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200STLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200STLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200STLEDM 1996	GEARCASE - COUNTER-ROTATION
J200STLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLEOA 1995	GEARCASE - COUNTER ROTATION
J200STLEOA 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200STLERK 1994	GEARCASE - COUNTER ROTATION
J200STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLERR 1994	GEARCASE - COUNTER ROTATION
J200STLERR 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLETC 1993	GEARCASE - COUNTER ROTATION
J200STLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLETF 1993	GEARCASE - COUNTER ROTATION
J200STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLEUB 1997	GEARCASE - COUNTER-ROTATION
J200STLEUB 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TLECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200TLECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200TXARC 1994	GEARCASE - COUNTER ROTATION
J200TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXARK 1994	GEARCASE - COUNTER ROTATION
J200TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXATF 1993	GEARCASE - COUNTER ROTATION
J200TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXATS 1993	GEARCASE - COUNTER ROTATION
J200TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200TXEDR 1996	GEARCASE - COUNTER-ROTATION
J200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXEOC 1995	GEARCASE - COUNTER ROTATION
J200TXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXERK 1994	GEARCASE - COUNTER ROTATION
J200TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200TXERS 1994	GEARCASE - COUNTER ROTATION
J200TXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXETD 1993	GEARCASE - COUNTER ROTATION
J200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXETF 1993	GEARCASE - COUNTER ROTATION
J200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXEUA 1997	GEARCASE - COUNTER-ROTATION
J200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZARK 1994	GEARCASE - COUNTER ROTATION
J200TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZATF 1993	GEARCASE - COUNTER ROTATION
J200TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZATS 1993	GEARCASE - COUNTER ROTATION
J200TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZEOC 1995	GEARCASE - COUNTER ROTATION
J200TZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZERK 1994	GEARCASE - COUNTER ROTATION
J200TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZERS 1994	GEARCASE - COUNTER ROTATION
J200TZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZETD 1993	GEARCASE - COUNTER ROTATION
J200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZETF 1993	GEARCASE - COUNTER ROTATION
J200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS

J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200WPXEEN 1999	GEARCASE
J200WPXEES 1999	GEARCASE
J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	GEARCASE
J225CXARC 1994	GEARCASE - COUNTER ROTATION
J225CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXARK 1994	GEARCASE - COUNTER ROTATION
J225CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXATF 1993	GEARCASE - COUNTER ROTATION
J225CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXATS 1993	GEARCASE - COUNTER ROTATION
J225CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225CXEDE 1996	GEARCASE - COUNTER-ROTATION
J225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225CXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225CXEOB 1995	GEARCASE - COUNTER ROTATION
J225CXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXERK 1994	GEARCASE - COUNTER ROTATION
J225CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225CXERM 1994	GEARCASE - COUNTER ROTATION
J225CXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXETA 1993	GEARCASE - COUNTER ROTATION
J225CXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXETF 1993	GEARCASE - COUNTER ROTATION
J225CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXEUD 1997	GEARCASE - COUNTER-ROTATION
J225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225CZARK 1994	GEARCASE - COUNTER ROTATION
J225CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZATF 1993	GEARCASE - COUNTER ROTATION
J225CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZATS 1993	GEARCASE - COUNTER ROTATION
J225CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225CZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225CZEDE 1996	GEARCASE - COUNTER-ROTATION
J225CZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZEOB 1995	GEARCASE - COUNTER ROTATION
J225CZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZERK 1994	GEARCASE - COUNTER ROTATION
J225CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZERM 1994	GEARCASE - COUNTER ROTATION
J225CZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZETA 1993	GEARCASE - COUNTER ROTATION
J225CZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225CZETF 1993	GEARCASE - COUNTER ROTATION
J225CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZEUD 1997	GEARCASE - COUNTER-ROTATION
J225CZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225HPLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225HPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225HPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225HPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PLEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PLERK 1994	GEARCASE - COUNTER ROTATION
J225PLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLERM 1994	GEARCASE - COUNTER ROTATION
J225PLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLETA 1993	GEARCASE - COUNTER ROTATION
J225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLETF 1993	GEARCASE - COUNTER ROTATION
J225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS

J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PXARC 1994	GEARCASE - COUNTER ROTATION
J225PXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXARK 1994	GEARCASE - COUNTER ROTATION
J225PXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXATF 1993	GEARCASE - COUNTER ROTATION
J225PXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXATS 1993	GEARCASE - COUNTER ROTATION
J225PXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXEDE 1996	GEARCASE - COUNTER-ROTATION
J225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PXEEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PXEOB 1995	GEARCASE - COUNTER ROTATION
J225PXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXERK 1994	GEARCASE - COUNTER ROTATION
J225PXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXERM 1994	GEARCASE - COUNTER ROTATION
J225PXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXETA 1993	GEARCASE - COUNTER ROTATION
J225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXETF 1993	GEARCASE - COUNTER ROTATION
J225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PZARK 1994	GEARCASE - COUNTER ROTATION
J225PZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225PZATF 1993	GEARCASE - COUNTER ROTATION
J225PZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZATS 1993	GEARCASE - COUNTER ROTATION
J225PZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZEOB 1995	GEARCASE - COUNTER ROTATION
J225PZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZERK 1994	GEARCASE - COUNTER ROTATION
J225PZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZERM 1994	GEARCASE - COUNTER ROTATION
J225PZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZETA 1993	GEARCASE - COUNTER ROTATION
J225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZETF 1993	GEARCASE - COUNTER ROTATION
J225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225STLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225STLEDE 1996	GEARCASE - COUNTER-ROTATION
J225STLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLEOB 1995	GEARCASE - COUNTER ROTATION
J225STLEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLERC 1994	GEARCASE - COUNTER ROTATION
J225STLERC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLERK 1994	GEARCASE - COUNTER ROTATION
J225STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLETF 1993	GEARCASE - COUNTER ROTATION
J225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLEUD 1997	GEARCASE - COUNTER-ROTATION
J225STLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225TLERK 1994	GEARCASE - COUNTER ROTATION
J225TLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLERM 1994	GEARCASE - COUNTER ROTATION
J225TLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLETA 1993	GEARCASE - COUNTER ROTATION
J225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLETF 1993	GEARCASE - COUNTER ROTATION
J225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXARC 1994	GEARCASE - COUNTER ROTATION
J225TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXARK 1994	GEARCASE - COUNTER ROTATION
J225TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXATF 1993	GEARCASE - COUNTER ROTATION
J225TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXATS 1993	GEARCASE - COUNTER ROTATION
J225TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225TXEDE 1996	GEARCASE - COUNTER-ROTATION
J225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXEOB 1995	GEARCASE - COUNTER ROTATION
J225TXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXERK 1994	GEARCASE - COUNTER ROTATION
J225TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXERM 1994	GEARCASE - COUNTER ROTATION
J225TXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXETA 1993	GEARCASE - COUNTER ROTATION
J225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225TXETF 1993	GEARCASE - COUNTER ROTATION
J225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXEUD 1997	GEARCASE - COUNTER-ROTATION
J225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZARK 1994	GEARCASE - COUNTER ROTATION
J225TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZATF 1993	GEARCASE - COUNTER ROTATION
J225TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZATS 1993	GEARCASE - COUNTER ROTATION
J225TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225TZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225TZEDE 1996	GEARCASE - COUNTER-ROTATION
J225TZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZEOD 1995	GEARCASE - COUNTER ROTATION
J225TZEOD 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZERK 1994	GEARCASE - COUNTER ROTATION
J225TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZERM 1994	GEARCASE - COUNTER ROTATION
J225TZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZETA 1993	GEARCASE - COUNTER ROTATION
J225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZETF 1993	GEARCASE - COUNTER ROTATION
J225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZEUD 1997	GEARCASE - COUNTER-ROTATION
J225TZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS

J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250CXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250CXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250CZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250CZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250CZEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CZEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CZEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CZEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250PXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250PXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250PXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PXEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS

J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250PZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250PZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250PZEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PZEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PZEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PZEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J90ELECTM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J90ELECTM 1998	GEARCASE -- 90 & 115 SX MODELS
J90ELED R 1996	GEARCASE - 20 IN. MODELS
J90ELED R 1996	GEARCASE - 25 IN. MODELS
J90ELEOC 1995	GEARCASE - 20 IN. MODELS
J90ELEOC 1995	GEARCASE - 25 IN. MODELS
J90ELEUA 1997	GEARCASE - 20 IN. MODELS

J90ELEUA 1997	GEARCASE - 25 IN. MODELS
J90ELEUC 1997	GEARCASE - 20 IN. MODELS
J90ELEUC 1997	GEARCASE - 25 IN. MODELS
J90EXEOC 1995	GEARCASE - 20 IN. MODELS
J90EXEOC 1995	GEARCASE - 25 IN. MODELS
J90FSLECS 1998	GEARCASE -- FSL, FTL MODELS
J90FSLECS 1998	GEARCASE -- FSX MODELS
J90FTLECS 1998	GEARCASE -- FSL, FTL MODELS
J90FTLECS 1998	GEARCASE -- FSX MODELS
J90PLEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J90PLEEB 1999	GEARCASE -- 90 & 115 PX MODELS
J90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J90SLEDR 1996	GEARCASE - 20 IN. MODELS
J90SLEDR 1996	GEARCASE - 25 IN. MODELS
J90SLEOC 1995	GEARCASE - 20 IN. MODELS
J90SLEOC 1995	GEARCASE - 25 IN. MODELS
J90SLEUA 1997	GEARCASE - 20 IN. MODELS
J90SLEUA 1997	GEARCASE - 25 IN. MODELS
J90SLEUC 1997	GEARCASE - 20 IN. MODELS
J90SLEUC 1997	GEARCASE - 25 IN. MODELS
J90SPLEES 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J90SPLEES 1999	GEARCASE -- 90 & 115 PX MODELS
J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
L115GLECA 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
L115GLECA 1998	GEARCASE -- 90 & 115 SX MODELS

L115GLEDC 1996	GEARCASE - 20 IN. MODELS
L115GLEDC 1996	GEARCASE - 25 IN. MODELS
L115GLEOS 1995	GEARCASE - 20 IN. MODELS
L115GLEOS 1995	GEARCASE - 25 IN. MODELS
L115GLEUC 1997	GEARCASE - 20 IN. MODELS
L115GLEUC 1997	GEARCASE - 25 IN. MODELS
L115GLEUR 1997	GEARCASE - 20 IN. MODELS
L115GLEUR 1997	GEARCASE - 25 IN. MODELS
L150GLECA 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
L150GLECA 1998	GEARCASE -- COUNTER-ROTATION
L150GLEDC 1996	GEARCASE - COUNTER-ROTATION
L150GLEDC 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEOS 1995	GEARCASE - COUNTER ROTATION
L150GLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
L150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEUC 1997	GEARCASE - COUNTER-ROTATION
L150GLEUR 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEUR 1997	GEARCASE - COUNTER-ROTATION
L90GLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
L90GLECS 1998	GEARCASE -- 90 & 115 SX MODELS
LE200SLEDR 1996	GEARCASE - COUNTER-ROTATION
LE200SLEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LE200SLEOC 1995	GEARCASE - COUNTER ROTATION
LE200SLEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LJ200SLEDR 1996	GEARCASE - COUNTER-ROTATION
LJ200SLEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LJ200SLEOC 1995	GEARCASE - COUNTER ROTATION
LJ200SLEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
RE115FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE115FLSSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FLSSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS

RE115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
RE115FSSSH FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FSSSR FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
RE115FXSSH FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FXSSR FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS

RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS

RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - Counter Rotation
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
RE200FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
RE225FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
RE225FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation

RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - Counter Rotation
RE225FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - Counter Rotation
RE225FZSSH FFI, Elec Start, TNT, 30 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RJ115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
RJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
RJ130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE

RJ135PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
RJ135VXSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS

RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS

RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ90VLSSS Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ90VLSSS Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
SE105RWLH 1998	GEARCASE
SE105RWLP 1997	GEARCASE
SE105RWYH 1998	GEARCASE
SE105RWYP 1997	GEARCASE
SE105WELV 1998	GEARCASE
SE105WEXV 1998	GEARCASE
SE105WRPLV 1998	GEARCASE
SE105WRPXV 1998	GEARCASE
SE125RWYJ 1997	GEARCASE

SE125RWYN 1998	GEARCASE
SE125RWYV 1996	GEARCASE
SE125WTP LJ 1997	GEARCASE
SE125WTP LN 1998	GEARCASE
SE125WTP LV 1996	GEARCASE
SE125WTP XJ 1997	GEARCASE
SE125WTP XN 1998	GEARCASE
SE125WTP XV 1996	GEARCASE
SE150WTP LB 1996	GEARCASE
SE150WTP LT 1997	GEARCASE
SE150WTP LT4 1997	GEARCASE
SE150WTP LY 1998	GEARCASE
SE150WTP XB 1996	GEARCASE
SE150WTP XT 1997	GEARCASE
SE150WTP XT4 1997	GEARCASE
SE150WTP XY 1998	GEARCASE
SE200WTP LA 1996	GEARCASE
SE200WTP LG 1998	GEARCASE
SE200WTP LS 1997	GEARCASE
SE200WTP XA 1996	GEARCASE
SE200WTP XG 1998	GEARCASE
SE200WTP XS 1997	GEARCASE
SE225GLECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225GLECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225NXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225NXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225NZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225NZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225QXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225QXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225QZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225QZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ105RWLH 1998	GEARCASE

SJ105RWLP 1997	GEARCASE
SJ105RWYH 1998	GEARCASE
SJ105RWYP 1997	GEARCASE
SJ105WELV 1998	GEARCASE
SJ105WEXV 1998	GEARCASE
SJ105WRPLV 1998	GEARCASE
SJ105WRPXV 1998	GEARCASE
SJ115ELEDV 1996	GEARCASE - 20 IN. MODELS
SJ115ELEDV 1996	GEARCASE - 25 IN. MODELS
SJ125RWYJ 1997	GEARCASE
SJ125RWYN 1998	GEARCASE
SJ125RWYV 1996	GEARCASE
SJ125WTPLJ 1997	GEARCASE
SJ125WTPLN 1998	GEARCASE
SJ125WTPLV 1996	GEARCASE
SJ125WTPXJ 1997	GEARCASE
SJ125WTPXN 1998	GEARCASE
SJ125WTPXV 1996	GEARCASE
SJ130CXADA 1996	GEARCASE - 130CX COUNTER ROTATION
SJ130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ130TLEDV 1996	GEARCASE - 130CX COUNTER ROTATION
SJ130TLEDV 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
SJ130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ150ELEDV 1996	GEARCASE - COUNTER-ROTATION
SJ150ELEDV 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
SJ150WTPLB 1996	GEARCASE
SJ150WTPLT 1997	GEARCASE
SJ150WTPLT4 1997	GEARCASE
SJ150WTPLY 1998	GEARCASE
SJ150WTPXB 1996	GEARCASE
SJ150WTPXT 1997	GEARCASE
SJ150WTPXT4 1997	GEARCASE
SJ150WTPXY 1998	GEARCASE

SJ200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200CXEUA 1997	GEARCASE - COUNTER-ROTATION
SJ200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200SLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200SLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200SLEDM 1996	GEARCASE - COUNTER-ROTATION
SJ200SLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200SLEUB 1997	GEARCASE - COUNTER-ROTATION
SJ200SLEUB 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200TXEUA 1997	GEARCASE - COUNTER-ROTATION
SJ200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200WTPLA 1996	GEARCASE
SJ200WTPLG 1998	GEARCASE
SJ200WTPLS 1997	GEARCASE
SJ200WTPXA 1996	GEARCASE
SJ200WTPXG 1998	GEARCASE
SJ200WTPXS 1997	GEARCASE
SJ225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225CXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225CXEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225GLECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225GLECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225NXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

SJ225NXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225NZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225NZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225PXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225QXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225QXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225QZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225QZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225SLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225SLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225SLEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225SLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225SLEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225SLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225TXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225TXEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ90ELEDR 1996	GEARCASE - 20 IN. MODELS
SJ90ELEDR 1996	GEARCASE - 25 IN. MODELS
TE150GLETG 1993	GEARCASE - COUNTER ROTATION
TE150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TE150GLETR 1993	GEARCASE - COUNTER ROTATION
TE150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TJ150GLETG 1993	GEARCASE - COUNTER ROTATION
TJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TJ150GLETR 1993	GEARCASE - COUNTER ROTATION

TJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
V150SLETG 1993	GEARCASE - COUNTER ROTATION
V150SLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
V150SLETS 1993	GEARCASE - COUNTER ROTATION
V150SLETS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE150ELETG 1993	GEARCASE - COUNTER ROTATION
VE150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150ELETR 1993	GEARCASE - COUNTER ROTATION
VE150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150EXETG 1993	GEARCASE - COUNTER ROTATION
VE150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150EXETR 1993	GEARCASE - COUNTER ROTATION
VE150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150GLETG 1993	GEARCASE - COUNTER ROTATION
VE150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

VE150GLETR 1993	GEARCASE - COUNTER ROTATION
VE150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150HLEOS 1995	GEARCASE - COUNTER ROTATION
VE150HLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
VE175EXETG 1993	GEARCASE - COUNTER ROTATION
VE175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175EXETR 1993	GEARCASE - COUNTER ROTATION
VE175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175GLETG 1993	GEARCASE - COUNTER ROTATION
VE175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175GLETR 1993	GEARCASE - COUNTER ROTATION
VE175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE200SLETC 1993	GEARCASE - COUNTER ROTATION
VE200SLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200SLETF 1993	GEARCASE - COUNTER ROTATION
VE200SLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TXETD 1993	GEARCASE - COUNTER ROTATION
VE200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TXETF 1993	GEARCASE - COUNTER ROTATION
VE200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TZETD 1993	GEARCASE - COUNTER ROTATION
VE200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TZETF 1993	GEARCASE - COUNTER ROTATION
VE200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PLETA 1993	GEARCASE - COUNTER ROTATION
VE225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PLETF 1993	GEARCASE - COUNTER ROTATION
VE225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PXETA 1993	GEARCASE - COUNTER ROTATION
VE225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

VE225PXETF 1993	GEARCASE - COUNTER ROTATION
VE225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PZETA 1993	GEARCASE - COUNTER ROTATION
VE225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PZETF 1993	GEARCASE - COUNTER ROTATION
VE225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225STLETF 1993	GEARCASE - COUNTER ROTATION
VE225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TLETA 1993	GEARCASE - COUNTER ROTATION
VE225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TLETF 1993	GEARCASE - COUNTER ROTATION
VE225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TXETA 1993	GEARCASE - COUNTER ROTATION
VE225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TXETF 1993	GEARCASE - COUNTER ROTATION
VE225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TZETA 1993	GEARCASE - COUNTER ROTATION
VE225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TZETF 1993	GEARCASE - COUNTER ROTATION
VE225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ120TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLATS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX

VJ120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ150ELATG 1993	GEARCASE - COUNTER ROTATION
VJ150ELATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELATR 1993	GEARCASE - COUNTER ROTATION
VJ150ELATR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELETG 1993	GEARCASE - COUNTER ROTATION
VJ150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELETR 1993	GEARCASE - COUNTER ROTATION
VJ150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150EXETG 1993	GEARCASE - COUNTER ROTATION
VJ150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150EXETR 1993	GEARCASE - COUNTER ROTATION
VJ150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150GLETG 1993	GEARCASE - COUNTER ROTATION
VJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150GLETR 1993	GEARCASE - COUNTER ROTATION
VJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150HLEOS 1995	GEARCASE - COUNTER ROTATION
VJ150HLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
VJ175EXETG 1993	GEARCASE - COUNTER ROTATION
VJ175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

VJ175EXETR 1993	GEARCASE - COUNTER ROTATION
VJ175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175GLETG 1993	GEARCASE - COUNTER ROTATION
VJ175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175GLETR 1993	GEARCASE - COUNTER ROTATION
VJ175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ200SLETC 1993	GEARCASE - COUNTER ROTATION
VJ200SLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200SLETF 1993	GEARCASE - COUNTER ROTATION
VJ200SLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TXETD 1993	GEARCASE - COUNTER ROTATION
VJ200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TXETF 1993	GEARCASE - COUNTER ROTATION
VJ200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TZETD 1993	GEARCASE - COUNTER ROTATION
VJ200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TZETF 1993	GEARCASE - COUNTER ROTATION
VJ200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PLETA 1993	GEARCASE - COUNTER ROTATION
VJ225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PLETF 1993	GEARCASE - COUNTER ROTATION
VJ225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PXETA 1993	GEARCASE - COUNTER ROTATION
VJ225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PXETF 1993	GEARCASE - COUNTER ROTATION
VJ225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PZETA 1993	GEARCASE - COUNTER ROTATION
VJ225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PZETF 1993	GEARCASE - COUNTER ROTATION
VJ225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

VJ225STLETF 1993	GEARCASE - COUNTER ROTATION
VJ225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TLETA 1993	GEARCASE - COUNTER ROTATION
VJ225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TLETF 1993	GEARCASE - COUNTER ROTATION
VJ225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TXETA 1993	GEARCASE - COUNTER ROTATION
VJ225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TXETF 1993	GEARCASE - COUNTER ROTATION
VJ225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TZETA 1993	GEARCASE - COUNTER ROTATION
VJ225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TZETF 1993	GEARCASE - COUNTER ROTATION
VJ225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS