

## Where Used: Part Number 0338486

| Model Name     | Diagram                                                      |
|----------------|--------------------------------------------------------------|
| 150SHLERC 1994 | GEARCASE - COUNTER ROTATION                                  |
| 150SHLERC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| 150SHLERC 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| 150SHLERC 1994 | JET DRIVE UNIT                                               |
| 150SLERC 1994  | GEARCASE - COUNTER ROTATION                                  |
| 150SLERC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| 150SLERC 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| 150SLERC 1994  | JET DRIVE UNIT                                               |
| A115DCXAFG     | 07-1_GEARCASE, O-Type, Counter Rotation                      |
| A115DGLAFG     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115DGXAFG     | 07-1_GEARCASE, O-Type                                        |
| A115DPXAFG     | 07-1_GEARCASE, O-Type                                        |
| A115DSLAFG     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115GHLAFH     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115GHLAFI     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115GHLAFK     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115GHLAFL     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115GHXAFH     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115GHXAFI     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115GHXAFK     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115GHXAFI     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115GNLAFG     | 07-1_GEARCASE, O-Type                                        |
| A115SHLAFH     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115SHLAFI     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115SHLAFK     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115SHLAFI     | 07-1_GEARCASE, (0.42 Ratio) S2-Type                          |
| A115SHXAFH     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115SHXAFI     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115SHXAFK     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115SHXAFI     | 07-1_GEARCASE, (0.44 Ratio) O-Type                           |
| A115SNLAFG     | 07-1_GEARCASE, O-Type                                        |
| BE115ELED 1996 | GEARCASE - 20 IN. MODELS                                     |

|                  |                                                             |
|------------------|-------------------------------------------------------------|
| BE115ELED R 1996 | GEARCASE - 25 IN. MODELS                                    |
| BE115ELEUA 1997  | GEARCASE - 20 IN. MODELS                                    |
| BE115ELEUA 1997  | GEARCASE - 25 IN. MODELS                                    |
| BE115ELEUC 1997  | GEARCASE - 20 IN. MODELS                                    |
| BE115ELEUC 1997  | GEARCASE - 25 IN. MODELS                                    |
| BE115GLECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS                      |
| BE115GLECM 1998  | GEARCASE -- 90 & 115 SX MODELS                              |
| BE115GLECM 1998  | JET DRIVE UNIT                                              |
| BE115GLEDR 1996  | GEARCASE - 20 IN. MODELS                                    |
| BE115GLEDR 1996  | GEARCASE - 25 IN. MODELS                                    |
| BE115GLEUA 1997  | GEARCASE - 20 IN. MODELS                                    |
| BE115GLEUA 1997  | GEARCASE - 25 IN. MODELS                                    |
| BE115GLEUC 1997  | GEARCASE - 20 IN. MODELS                                    |
| BE115GLEUC 1997  | GEARCASE - 25 IN. MODELS                                    |
| BE115SXECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS                      |
| BE115SXECM 1998  | GEARCASE -- 90 & 115 SX MODELS                              |
| BE115SXECM 1998  | JET DRIVE UNIT                                              |
| BE115SXEDR 1996  | GEARCASE - 20 IN. MODELS                                    |
| BE115SXEDR 1996  | GEARCASE - 25 IN. MODELS                                    |
| BE115SXEU A 1997 | GEARCASE - 20 IN. MODELS                                    |
| BE115SXEU A 1997 | GEARCASE - 25 IN. MODELS                                    |
| BE115SXEU C 1997 | GEARCASE - 20 IN. MODELS                                    |
| BE115SXEU C 1997 | GEARCASE - 25 IN. MODELS                                    |
| BE130TLECE 1998  | GEARCASE                                                    |
| BE130TLED M 1996 | GEARCASE - 130CX COUNTER ROTATION                           |
| BE130TLED M 1996 | GEARCASE - 130TL & 130TX STANDARD ROTATION                  |
| BE130TLEUB 1997  | GEARCASE - 130CX COUNTER-ROTATION                           |
| BE130TLEUB 1997  | GEARCASE - 130TL & 130TX STANDARD ROTATION                  |
| BE150ELECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BE150ELECD 1998  | GEARCASE -- COUNTER-ROTATION                                |
| BE150ELECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BE150ELECD 1998  | JET DRIVE UNIT                                              |
| BE150ELEDB 1996  | GEARCASE - COUNTER-ROTATION                                 |
| BE150ELEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                    |

|                  |                                                             |
|------------------|-------------------------------------------------------------|
| BE150ELEDDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BE150ELEDDB 1996 | JET DRIVE UNIT                                              |
| BE150ELEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150ELEUC 1997  | GEARCASE - COUNTER-ROTATION                                 |
| BE150ELEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150ELEUC 1997  | JET DRIVE UNIT                                              |
| BE150ELEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150ELEUE 1997  | GEARCASE - COUNTER-ROTATION                                 |
| BE150ELEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150ELEUE 1997  | JET DRIVE UNIT                                              |
| BE150EXECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BE150EXECD 1998  | GEARCASE -- COUNTER-ROTATION                                |
| BE150EXECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BE150EXECD 1998  | JET DRIVE UNIT                                              |
| BE150EXEDB 1996  | GEARCASE - COUNTER-ROTATION                                 |
| BE150EXEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150EXEDB 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BE150EXEDB 1996  | JET DRIVE UNIT                                              |
| BE150EXEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150EXEUC 1997  | GEARCASE - COUNTER-ROTATION                                 |
| BE150EXEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150EXEUC 1997  | JET DRIVE UNIT                                              |
| BE150EXEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150EXEUE 1997  | GEARCASE - COUNTER-ROTATION                                 |
| BE150EXEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150EXEUE 1997  | JET DRIVE UNIT                                              |
| BE150GLECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BE150GLECD 1998  | GEARCASE -- COUNTER-ROTATION                                |
| BE150GLECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BE150GLECD 1998  | JET DRIVE UNIT                                              |
| BE150GLEDB 1996  | GEARCASE - COUNTER-ROTATION                                 |
| BE150GLEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                    |

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| BE150GLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BE150GLEDB 1996 | JET DRIVE UNIT                                              |
| BE150GLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150GLEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE150GLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150GLEUC 1997 | JET DRIVE UNIT                                              |
| BE150GLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150GLEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE150GLEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150GLEUE 1997 | JET DRIVE UNIT                                              |
| BE150NXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BE150NXECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BE150NXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BE150NXECD 1998 | JET DRIVE UNIT                                              |
| BE150NXEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BE150NXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150NXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BE150NXEDB 1996 | JET DRIVE UNIT                                              |
| BE150NXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150NXEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE150NXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150NXEUC 1997 | JET DRIVE UNIT                                              |
| BE150NXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE150NXEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE150NXEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE150NXEUE 1997 | JET DRIVE UNIT                                              |
| BE175EXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BE175EXECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BE175EXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BE175EXECD 1998 | JET DRIVE UNIT                                              |
| BE175EXEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BE175EXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| BE175EXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BE175EXEDB 1996 | JET DRIVE UNIT                                              |
| BE175EXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE175EXEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE175EXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE175EXEUC 1997 | JET DRIVE UNIT                                              |
| BE175EXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE175EXEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE175EXEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE175EXEUE 1997 | JET DRIVE UNIT                                              |
| BE175GLECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BE175GLECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BE175GLECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BE175GLECD 1998 | JET DRIVE UNIT                                              |
| BE175GLEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BE175GLEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE175GLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BE175GLEDB 1996 | JET DRIVE UNIT                                              |
| BE175GLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE175GLEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE175GLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE175GLEUC 1997 | JET DRIVE UNIT                                              |
| BE175GLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BE175GLEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BE175GLEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BE175GLEUE 1997 | JET DRIVE UNIT                                              |
| BE175NXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BE175NXECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BE175NXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BE175NXECD 1998 | JET DRIVE UNIT                                              |
| BE175NXEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BE175NXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| BE175NXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| BE175NXEDB 1996 | JET DRIVE UNIT                                               |
| BE175NXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| BE175NXEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE175NXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| BE175NXEUC 1997 | JET DRIVE UNIT                                               |
| BE175NXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| BE175NXEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE175NXEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| BE175NXEUE 1997 | JET DRIVE UNIT                                               |
| BE200CXECM 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| BE200CXECM 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| BE200CXECM 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| BE200CXEDR 1996 | GEARCASE - COUNTER-ROTATION                                  |
| BE200CXEDR 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE200CXEDR 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE200CXEUA 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE200CXEUA 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE200CXEUA 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE200TXECM 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| BE200TXECM 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| BE200TXECM 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| BE200TXEDR 1996 | GEARCASE - COUNTER-ROTATION                                  |
| BE200TXEDR 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE200TXEDR 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE200TXEUA 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE225CXECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| BE225CXECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| BE225CXECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| BE225CXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| BE225CXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| BE225CXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE225CXEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE225CXEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE225CXEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE225PXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| BE225PXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE225PXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE225SLECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| BE225SLECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| BE225SLECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| BE225SLEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| BE225SLEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE225SLEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE225SLEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE225SLEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE225SLEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE225TXECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| BE225TXECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| BE225TXECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| BE225TXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| BE225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE225TXEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| BE225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| BE250CXECB 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| BE250CXECB 1998 | GEARCASE -- STANDARD ROTATION                                |
| BE250CXEDA 1996 | GEARCASE - COUNTER ROTATION                                  |
| BE250CXEDA 1996 | GEARCASE - STANDARD ROTATION                                 |
| BE250CXEUM 1997 | GEARCASE - COUNTER-ROTATION                                  |
| BE250CXEUM 1997 | GEARCASE - STANDARD ROTATION                                 |
| BE250TXECB 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| BE250TXECB 1998 | GEARCASE -- STANDARD ROTATION                                |
| BE250TXEDA 1996 | GEARCASE - COUNTER ROTATION                                  |

|                 |                                        |
|-----------------|----------------------------------------|
| BE250TXEDA 1996 | GEARCASE - STANDARD ROTATION           |
| BE250TXEUM 1997 | GEARCASE - COUNTER-ROTATION            |
| BE250TXEUM 1997 | GEARCASE - STANDARD ROTATION           |
| BE90ELEDR 1996  | GEARCASE - 20 IN. MODELS               |
| BE90ELEDR 1996  | GEARCASE - 25 IN. MODELS               |
| BE90ELEUA 1997  | GEARCASE - 20 IN. MODELS               |
| BE90ELEUA 1997  | GEARCASE - 25 IN. MODELS               |
| BE90ELEUC 1997  | GEARCASE - 20 IN. MODELS               |
| BE90ELEUC 1997  | GEARCASE - 25 IN. MODELS               |
| BE90SLECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| BE90SLECM 1998  | GEARCASE -- 90 & 115 SX MODELS         |
| BE90SLECM 1998  | JET DRIVE UNIT                         |
| BE90SLEDR 1996  | GEARCASE - 20 IN. MODELS               |
| BE90SLEDR 1996  | GEARCASE - 25 IN. MODELS               |
| BE90SLEUA 1997  | GEARCASE - 20 IN. MODELS               |
| BE90SLEUA 1997  | GEARCASE - 25 IN. MODELS               |
| BE90SLEUC 1997  | GEARCASE - 20 IN. MODELS               |
| BE90SLEUC 1997  | GEARCASE - 25 IN. MODELS               |
| BE90SXECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| BE90SXECM 1998  | GEARCASE -- 90 & 115 SX MODELS         |
| BE90SXECM 1998  | JET DRIVE UNIT                         |
| BE90SXEUUA 1997 | GEARCASE - 20 IN. MODELS               |
| BE90SXEUUA 1997 | GEARCASE - 25 IN. MODELS               |
| BE90SXEUUC 1997 | GEARCASE - 20 IN. MODELS               |
| BE90SXEUUC 1997 | GEARCASE - 25 IN. MODELS               |
| BJ115ELEDR 1996 | GEARCASE - 20 IN. MODELS               |
| BJ115ELEDR 1996 | GEARCASE - 25 IN. MODELS               |
| BJ115ELEUA 1997 | GEARCASE - 20 IN. MODELS               |
| BJ115ELEUA 1997 | GEARCASE - 25 IN. MODELS               |
| BJ115ELEUC 1997 | GEARCASE - 20 IN. MODELS               |
| BJ115ELEUC 1997 | GEARCASE - 25 IN. MODELS               |
| BJ115GLECM 1998 | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| BJ115GLECM 1998 | GEARCASE -- 90 & 115 SX MODELS         |
| BJ115GLECM 1998 | JET DRIVE UNIT                         |
| BJ115GLEDR 1996 | GEARCASE - 20 IN. MODELS               |

|                                                            |                                                 |
|------------------------------------------------------------|-------------------------------------------------|
| BJ115GLEDR 1996                                            | GEARCASE - 25 IN. MODELS                        |
| BJ115GLEUA 1997                                            | GEARCASE - 20 IN. MODELS                        |
| BJ115GLEUA 1997                                            | GEARCASE - 25 IN. MODELS                        |
| BJ115GLEUC 1997                                            | GEARCASE - 20 IN. MODELS                        |
| BJ115GLEUC 1997                                            | GEARCASE - 25 IN. MODELS                        |
| BJ115PLEEM 1999                                            | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| BJ115PLEEM 1999                                            | GEARCASE -- 90 & 115 PX MODELS                  |
| BJ115PLEEM 1999                                            | JET DRIVE UNIT                                  |
| BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001      | GEARCASE - 90 - 115 PL - VL MODELS              |
| BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001      | GEARCASE - 90 - 115 VX MODELS                   |
| BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001      | JET DRIVE UNIT                                  |
| BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000    | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000    | GEARCASE - 90 AND 115 PX, VX MODELS             |
| BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000    | JET DRIVE UNIT                                  |
| BJ115PXEEM 1999                                            | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| BJ115PXEEM 1999                                            | GEARCASE -- 90 & 115 PX MODELS                  |
| BJ115PXEEM 1999                                            | JET DRIVE UNIT                                  |
| BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000    | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000    | GEARCASE - 90 AND 115 PX, VX MODELS             |
| BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000    | JET DRIVE UNIT                                  |
| BJ115SXECM 1998                                            | GEARCASE -- 90 & 115 EL, GL, SL MODELS          |
| BJ115SXECM 1998                                            | GEARCASE -- 90 & 115 SX MODELS                  |
| BJ115SXECM 1998                                            | JET DRIVE UNIT                                  |
| BJ115SXEDR 1996                                            | GEARCASE - 20 IN. MODELS                        |
| BJ115SXEDR 1996                                            | GEARCASE - 25 IN. MODELS                        |
| BJ115SXEUUA 1997                                           | GEARCASE - 20 IN. MODELS                        |
| BJ115SXEUUA 1997                                           | GEARCASE - 25 IN. MODELS                        |
| BJ115SXEUUC 1997                                           | GEARCASE - 20 IN. MODELS                        |
| BJ115SXEUUC 1997                                           | GEARCASE - 25 IN. MODELS                        |
| BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001 | GEARCASE - 90 - 115 PL - VL MODELS              |
| BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001 | GEARCASE - 90 - 115 VX MODELS                   |

|                                                              |                                                             |
|--------------------------------------------------------------|-------------------------------------------------------------|
| BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001   | JET DRIVE UNIT                                              |
| BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS                |
| BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS                         |
| BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | JET DRIVE UNIT                                              |
| BJ130PLEED 1999                                              | GEARCASE                                                    |
| BJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000               | GEARCASE                                                    |
| BJ130PXED 1999                                               | GEARCASE                                                    |
| BJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000               | GEARCASE                                                    |
| BJ130TLECE 1998                                              | GEARCASE                                                    |
| BJ130TLEDM 1996                                              | GEARCASE - 130CX COUNTER ROTATION                           |
| BJ130TLEDM 1996                                              | GEARCASE - 130TL & 130TX STANDARD ROTATION                  |
| BJ130TLEUB 1997                                              | GEARCASE - 130CX COUNTER-ROTATION                           |
| BJ130TLEUB 1997                                              | GEARCASE - 130TL & 130TX STANDARD ROTATION                  |
| BJ135PLSIF elec start, TNT, 20 in shaft, n/a usa 2001        | GEARCASE                                                    |
| BJ135VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001   | GEARCASE                                                    |
| BJ150ELECD 1998                                              | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BJ150ELECD 1998                                              | GEARCASE -- COUNTER-ROTATION                                |
| BJ150ELECD 1998                                              | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BJ150ELECD 1998                                              | JET DRIVE UNIT                                              |
| BJ150ELEDDB 1996                                             | GEARCASE - COUNTER-ROTATION                                 |
| BJ150ELEDDB 1996                                             | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150ELEDDB 1996                                             | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BJ150ELEDDB 1996                                             | JET DRIVE UNIT                                              |
| BJ150ELEUC 1997                                              | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150ELEUC 1997                                              | GEARCASE - COUNTER-ROTATION                                 |
| BJ150ELEUC 1997                                              | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150ELEUC 1997                                              | JET DRIVE UNIT                                              |
| BJ150ELEUE 1997                                              | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150ELEUE 1997                                              | GEARCASE - COUNTER-ROTATION                                 |
| BJ150ELEUE 1997                                              | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150ELEUE 1997                                              | JET DRIVE UNIT                                              |

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| BJ150EXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BJ150EXECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BJ150EXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BJ150EXECD 1998 | JET DRIVE UNIT                                              |
| BJ150EXEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150EXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150EXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BJ150EXEDB 1996 | JET DRIVE UNIT                                              |
| BJ150EXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150EXEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150EXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150EXEUC 1997 | JET DRIVE UNIT                                              |
| BJ150EXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150EXEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150EXEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150EXEUE 1997 | JET DRIVE UNIT                                              |
| BJ150GLECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BJ150GLECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BJ150GLECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BJ150GLECD 1998 | JET DRIVE UNIT                                              |
| BJ150GLEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150GLEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150GLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BJ150GLEDB 1996 | JET DRIVE UNIT                                              |
| BJ150GLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150GLEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150GLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150GLEUC 1997 | JET DRIVE UNIT                                              |
| BJ150GLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150GLEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150GLEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150GLEUE 1997 | JET DRIVE UNIT                                              |

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| BJ150NXCED 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BJ150NXCED 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BJ150NXCED 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BJ150NXCED 1998 | JET DRIVE UNIT                                              |
| BJ150NXEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150NXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150NXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BJ150NXEDB 1996 | JET DRIVE UNIT                                              |
| BJ150NXCUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150NXCUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150NXCUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150NXCUC 1997 | JET DRIVE UNIT                                              |
| BJ150NXCUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ150NXCUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ150NXCUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ150NXCUE 1997 | JET DRIVE UNIT                                              |
| BJ175EXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BJ175EXECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BJ175EXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BJ175EXECD 1998 | JET DRIVE UNIT                                              |
| BJ175EXEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175EXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175EXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BJ175EXEDB 1996 | JET DRIVE UNIT                                              |
| BJ175EXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ175EXEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175EXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175EXEUC 1997 | JET DRIVE UNIT                                              |
| BJ175EXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ175EXEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175EXEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175EXEUE 1997 | JET DRIVE UNIT                                              |

|                 |                                                             |
|-----------------|-------------------------------------------------------------|
| BJ175GLECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BJ175GLECD 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BJ175GLECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BJ175GLECD 1998 | JET DRIVE UNIT                                              |
| BJ175GLEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175GLEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175GLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BJ175GLEDB 1996 | JET DRIVE UNIT                                              |
| BJ175GLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ175GLEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175GLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175GLEUC 1997 | JET DRIVE UNIT                                              |
| BJ175GLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ175GLEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175GLEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175GLEUE 1997 | JET DRIVE UNIT                                              |
| BJ175NXCED 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| BJ175NXCED 1998 | GEARCASE -- COUNTER-ROTATION                                |
| BJ175NXCED 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| BJ175NXCED 1998 | JET DRIVE UNIT                                              |
| BJ175NXEDB 1996 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175NXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175NXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"   |
| BJ175NXEDB 1996 | JET DRIVE UNIT                                              |
| BJ175NXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ175NXEUC 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175NXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175NXEUC 1997 | JET DRIVE UNIT                                              |
| BJ175NXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| BJ175NXEUE 1997 | GEARCASE - COUNTER-ROTATION                                 |
| BJ175NXEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| BJ175NXEUE 1997 | JET DRIVE UNIT                                              |

|                                                                |                                                              |
|----------------------------------------------------------------|--------------------------------------------------------------|
| BJ175PLEES 1999                                                | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| BJ175PLEES 1999                                                | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |
| BJ175PLEES 1999                                                | GEARCASE -- COUNTER-ROTATION -- CX MODELS                    |
| BJ175PLEES 1999                                                | JET DRIVE UNIT                                               |
| BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001          | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001          | GEARCASE - STANDARD ROTATION - VL, VX MODELS                 |
| BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001          | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS           |
| BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001          | JET DRIVE UNIT                                               |
| BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                 | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                 | JET DRIVE UNIT                                               |
| BJ175PXEEES 1999                                               | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| BJ175PXEEES 1999                                               | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |
| BJ175PXEEES 1999                                               | GEARCASE -- COUNTER-ROTATION -- CX MODELS                    |
| BJ175PXEEES 1999                                               | JET DRIVE UNIT                                               |
| BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000   | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000   | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000   | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000   | JET DRIVE UNIT                                               |
| BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - VL, VX MODELS                 |
| BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS           |
| BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | JET DRIVE UNIT                                               |
| BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000   | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000   | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000   | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000   | JET DRIVE UNIT                                               |

|                                                                       |                                                          |
|-----------------------------------------------------------------------|----------------------------------------------------------|
| BJ200CXEDR 1996                                                       | GEARCASE - COUNTER-ROTATION                              |
| BJ200CXEDR 1996                                                       | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| BJ200CXEDR 1996                                                       | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| BJ200CXEEB 1999                                                       | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ200CXEEB 1999                                                       | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ200CXEEB 1999                                                       | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ200CXEEN 1999                                                       | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ200CXEEN 1999                                                       | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ200CXEEN 1999                                                       | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ200PLEEB 1999                                                       | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ200PLEEB 1999                                                       | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ200PLEEB 1999                                                       | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ200PLEEN 1999                                                       | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ200PLEEN 1999                                                       | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ200PLEEN 1999                                                       | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001                 | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001                 | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001                 | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001                 | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000               | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000               | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000               | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000               | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ200PXEEB 1999                                                       | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ200PXEEB 1999                                                       | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ200PXEEB 1999                                                       | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ200PXEEB 1999                                                       | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |

|                                                                    |                                                          |
|--------------------------------------------------------------------|----------------------------------------------------------|
| BJ200PXEEN 1999                                                    | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ200PXEEN 1999                                                    | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000            | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000            | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000            | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000            | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ200TXEDR 1996                                                    | GEARCASE - COUNTER-ROTATION                              |
| BJ200TXEDR 1996                                                    | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| BJ200TXEDR 1996                                                    | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001 | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001 | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001 | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001 | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ200VCSSE Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001         | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001         | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001         | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001         | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000       | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |

|                                                                     |                                                          |
|---------------------------------------------------------------------|----------------------------------------------------------|
| BJ225CXEEC 1999                                                     | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ225CXEEC 1999                                                     | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ225CXEEC 1999                                                     | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ225CXEEEN 1999                                                    | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ225CXEEEN 1999                                                    | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ225CXEEEN 1999                                                    | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ225PLEEC 1999                                                     | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ225PLEEC 1999                                                     | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ225PLEEC 1999                                                     | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ225PLEEN 1999                                                     | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ225PLEEN 1999                                                     | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ225PLEEN 1999                                                     | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001               | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001               | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001               | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001               | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000             | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000             | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000             | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000             | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ225PXEEC 1999                                                     | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ225PXEEC 1999                                                     | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ225PXEEC 1999                                                     | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ225PXEEEN 1999                                                    | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| BJ225PXEEEN 1999                                                    | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| BJ225PXEEEN 1999                                                    | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000             | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |

|                                                                  |                                                          |
|------------------------------------------------------------------|----------------------------------------------------------|
| BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000          | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000          | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000          | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ225VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001       | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001       | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001       | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001       | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000     | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000     | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000     | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000     | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| BJ250CXECB 1998                                                  | GEARCASE -- COUNTER-ROTATION                             |
| BJ250CXECB 1998                                                  | GEARCASE -- STANDARD ROTATION                            |
| BJ250CXEDA 1996                                                  | GEARCASE - COUNTER ROTATION                              |
| BJ250CXEDA 1996                                                  | GEARCASE - STANDARD ROTATION                             |
| BJ250CXEUM 1997                                                  | GEARCASE - COUNTER-ROTATION                              |
| BJ250CXEUM 1997                                                  | GEARCASE - STANDARD ROTATION                             |
| BJ250TXECB 1998                                                  | GEARCASE -- COUNTER-ROTATION                             |

|                                                        |                                                 |
|--------------------------------------------------------|-------------------------------------------------|
| BJ250TXECB 1998                                        | GEARCASE -- STANDARD ROTATION                   |
| BJ250TXEDA 1996                                        | GEARCASE - COUNTER ROTATION                     |
| BJ250TXEDA 1996                                        | GEARCASE - STANDARD ROTATION                    |
| BJ250TXEUM 1997                                        | GEARCASE - COUNTER-ROTATION                     |
| BJ250TXEUM 1997                                        | GEARCASE - STANDARD ROTATION                    |
| BJ90ELED R 1996                                        | GEARCASE - 20 IN. MODELS                        |
| BJ90ELED R 1996                                        | GEARCASE - 25 IN. MODELS                        |
| BJ90ELEUA 1997                                         | GEARCASE - 20 IN. MODELS                        |
| BJ90ELEUA 1997                                         | GEARCASE - 25 IN. MODELS                        |
| BJ90ELEUC 1997                                         | GEARCASE - 20 IN. MODELS                        |
| BJ90ELEUC 1997                                         | GEARCASE - 25 IN. MODELS                        |
| BJ90PLEEB 1999                                         | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| BJ90PLEEB 1999                                         | GEARCASE -- 90 & 115 PX MODELS                  |
| BJ90PLEEB 1999                                         | JET DRIVE UNIT                                  |
| BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001   | GEARCASE - 90 - 115 PL - VL MODELS              |
| BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001   | GEARCASE - 90 - 115 VX MODELS                   |
| BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001   | JET DRIVE UNIT                                  |
| BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS             |
| BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | JET DRIVE UNIT                                  |
| BJ90PXEEB 1999                                         | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| BJ90PXEEB 1999                                         | GEARCASE -- 90 & 115 PX MODELS                  |
| BJ90PXEEB 1999                                         | JET DRIVE UNIT                                  |
| BJ90PXSSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| BJ90PXSSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS             |
| BJ90PXSSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000 | JET DRIVE UNIT                                  |
| BJ90SLECM 1998                                         | GEARCASE -- 90 & 115 EL, GL, SL MODELS          |
| BJ90SLECM 1998                                         | GEARCASE -- 90 & 115 SX MODELS                  |
| BJ90SLECM 1998                                         | JET DRIVE UNIT                                  |
| BJ90SLED R 1996                                        | GEARCASE - 20 IN. MODELS                        |
| BJ90SLED R 1996                                        | GEARCASE - 25 IN. MODELS                        |
| BJ90SLEUA 1997                                         | GEARCASE - 20 IN. MODELS                        |
| BJ90SLEUA 1997                                         | GEARCASE - 25 IN. MODELS                        |
| BJ90SLEUC 1997                                         | GEARCASE - 20 IN. MODELS                        |
| BJ90SLEUC 1997                                         | GEARCASE - 25 IN. MODELS                        |

|                                                             |                                                        |
|-------------------------------------------------------------|--------------------------------------------------------|
| BJ90SXECC 1998                                              | GEARCASE -- 90 & 115 EL, GL, SL MODELS                 |
| BJ90SXECC 1998                                              | GEARCASE -- 90 & 115 SX MODELS                         |
| BJ90SXECC 1998                                              | JET DRIVE UNIT                                         |
| BJ90SXEUA 1997                                              | GEARCASE - 20 IN. MODELS                               |
| BJ90SXEUA 1997                                              | GEARCASE - 25 IN. MODELS                               |
| BJ90SXEUC 1997                                              | GEARCASE - 20 IN. MODELS                               |
| BJ90SXEUC 1997                                              | GEARCASE - 25 IN. MODELS                               |
| BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001   | GEARCASE - 90 - 115 PL - VL MODELS                     |
| BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001   | GEARCASE - 90 - 115 VX MODELS                          |
| BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001   | JET DRIVE UNIT                                         |
| BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001   | GEARCASE - 90 - 115 PL - VL MODELS                     |
| BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001   | GEARCASE - 90 - 115 VX MODELS                          |
| BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001   | JET DRIVE UNIT                                         |
| BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS           |
| BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS                    |
| BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | JET DRIVE UNIT                                         |
| DE150CXAAA                                                  | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXAAA - FR                                             | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE150CXAAAB                                                 | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXAAAB - FR                                            | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE150CXAAC                                                  | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXAAC - FR                                             | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE150CXABA                                                  | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXABA - FR                                             | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE150CXABB                                                  | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXABF                                                  | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXABG                                                  | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXABH                                                  | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE150CXINS                                                  | GEARCASE, M2-Type, Counter Rotation                    |
| DE150CXINS - FR                                             | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE150PXAAA                                                  | 07-1_GEARCASE, M2-Type                                 |

|                                          |                                                        |
|------------------------------------------|--------------------------------------------------------|
| DE150PXAAB - FR                          | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE150PXAAB                               | 07-1_GEARCASE, M2-Type                                 |
| DE150PXAAB - FR                          | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE150PXAAC                               | 07-1_GEARCASE, M2-Type                                 |
| DE150PXAAC - FR                          | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE150PXABA                               | 07-1_GEARCASE, M2-Type                                 |
| DE150PXABA - FR                          | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE150PXABB                               | 07-1_GEARCASE, M2-Type                                 |
| DE150PXABF                               | 07-1_GEARCASE, M2-Type                                 |
| DE150PXABG                               | 07-1_GEARCASE, M2-Type                                 |
| DE150PXABH                               | 07-1_GEARCASE, M2-Type                                 |
| DE150PXINS                               | GEARCASE, M2-Type                                      |
| DE150PXINS - FR                          | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200CXAAA - (60 degree V6)              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXAAA - (60 degree V6) - FR         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200CXAAA - (90 degree V6, 3.3 L)       | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXAAA - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200CXAAAB - (60 degree V6)             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXAAAB - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200CXAAAC - (60 degree V6)             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXAAAC - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200CXABA                               | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXABA - (60 degree V6) - FR         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200CXABB                               | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXABF                               | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXABG                               | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXABH                               | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200CXINS - (60 degree V6)              | GEARCASE, M2-Type, Counter Rotation                    |
| DE200CXINS - (60 degree V6) - FR         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200HXAAA - (90 degree V6, 3.3 L)       | 07-1_GEARCASE, M2-Type                                 |
| DE200HXAAA - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200HXAAAB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXAAAB - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200HXAAAC - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXAAAC - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |

|                                         |                                                        |
|-----------------------------------------|--------------------------------------------------------|
| DE200HXAAD - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXAAD - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200HXABA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXABA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200HXABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE200HXINS - (90 degree V6, 3.3 L)      | GEARCASE, M2-Type                                      |
| DE200HXINS - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200PXAAB - (60 degree V6)             | 07-1_GEARCASE, M2-Type                                 |
| DE200PXAAB - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200PXAAB - (60 degree V6)             | 07-1_GEARCASE, M2-Type                                 |
| DE200PXAAB - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200PXAAC - (60 degree V6)             | 07-1_GEARCASE, M2-Type                                 |
| DE200PXAAC - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200PXABA                              | 07-1_GEARCASE, M2-Type                                 |
| DE200PXABA - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200PXABB                              | 07-1_GEARCASE, M2-Type                                 |
| DE200PXABF                              | 07-1_GEARCASE, M2-Type                                 |
| DE200PXABG                              | 07-1_GEARCASE, M2-Type                                 |
| DE200PXABH                              | 07-1_GEARCASE, M2-Type                                 |
| DE200PXINS - (60 degree V6)             | GEARCASE, M2-Type                                      |
| DE200PXINS - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE200XCAAB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200XCAAB - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200XCAAC - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200XCAAC - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200XCAAD - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200XCAAD - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200XCABA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200XCABA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE200XCABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200XCABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200XCABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |

|                                         |                                                        |
|-----------------------------------------|--------------------------------------------------------|
| DE200XCABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE200XCINS - (90 degree V6, 3.3 L)      | GEARCASE, M2-Type, Counter Rotation                    |
| DE200XCINS - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225CXAAA                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXAAA - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225CXaab                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXaab - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225CXaAC                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXaAC - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225CXaAD                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXaAD - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225CXABA                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXABA - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225CXABB                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225CXINS                              | GEARCASE, M2-Type, Counter Rotation                    |
| DE225CXINS - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225PXAAA                              | 07-1_GEARCASE, M2-Type                                 |
| DE225PXAAA - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE225PXaab                              | 07-1_GEARCASE, M2-Type                                 |
| DE225PXaab - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE225PXaAC                              | 07-1_GEARCASE, M2-Type                                 |
| DE225PXaAC - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE225PXaAD                              | 07-1_GEARCASE, M2-Type                                 |
| DE225PXaAD - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE225PXABA                              | 07-1_GEARCASE, M2-Type                                 |
| DE225PXABA - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE225PXABB                              | 07-1_GEARCASE, M2-Type                                 |
| DE225PXABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE225PXABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE225PXABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| DE225PXABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE225PXINS                              | GEARCASE, M2-Type                                      |
| DE225PXINS - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| DE250CXAAA - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXAAA - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CXaab - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXaab - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CXaAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXaAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CXaAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXaAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CXABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXABB - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CXIIC - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CXIIC - (90 degree V6, 3.3 L)     | GEARCASE, M2-Type, Counter Rotation                    |
| DE250CXINR - (90 degree V6, 3.3L)      | GEARCASE, M2-Type, Counter Rotation                    |
| DE250CXINR - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CXISF                             | GEARCASE                                               |
| DE250CXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CXISS                             | GEARCASE                                               |
| DE250CXISS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CZAAA - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZAAA - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CZaAB - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZaAB - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CZaAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZaAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CZaAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZaAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CZABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZABB - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE250CZIIC - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| DE250CZIIC - (90 degree V6, 3.3 L)     | GEARCASE, M2-Type, Counter Rotation                    |
| DE250CZINR - (90 degree V6, 3.3L)      | GEARCASE, M2-Type, Counter Rotation                    |
| DE250CZINR - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CZISF                             | GEARCASE                                               |
| DE250CZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250CZIIS                             | GEARCASE                                               |
| DE250CZIIS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE250PXAAX - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |
| DE250PXAAX - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PXAAB - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |
| DE250PXAAB - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PXAAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |
| DE250PXAAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PXAAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |
| DE250PXAAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PXABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PXABB - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PXABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PXABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PXABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PXIIC - (90 degree 6, 3.3 L)      | GEARCASE, M2-Type                                      |
| DE250PXIIC - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PXINR - (90 degree V6, 3.3L)      | GEARCASE, M2-Type                                      |
| DE250PXINR - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PXISF                             | GEARCASE                                               |
| DE250PXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PXIIS                             | GEARCASE                                               |
| DE250PXIIS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZAAA - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |
| DE250PZAAA - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZAAB - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |
| DE250PZAAB - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZAAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |
| DE250PZAAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZAAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                 |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| DE250PZAAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PZABB - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PZABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PZABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PZABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                 |
| DE250PZIIC - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZIIC - (90 degree V6, 3.3 L)     | GEARCASE, M2-Type                                      |
| DE250PZINR - (90 degree V6, 3.3L)      | GEARCASE, M2-Type                                      |
| DE250PZINR - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZISF                             | GEARCASE                                               |
| DE250PZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE250PZIIS                             | GEARCASE                                               |
| DE250PZIIS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE300CXAAA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CXAAB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CXAAC                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CXAAD                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CXABA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXABB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CXIIC                             | GEARCASE, M2-Type, Counter Rotation                    |
| DE300CXIIC - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CXINR                             | GEARCASE, M2-Type, Counter Rotation                    |
| DE300CXINR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CXISF                             | GEARCASE                                               |
| DE300CXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CXISG                             | GEARCASE                                               |
| DE300CXISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| DE300CXISS                             | GEARCASE                                               |
| DE300CXISS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZAAA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZAAB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZAAC                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZAAD                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZABA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZABB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| DE300CZIIC                             | GEARCASE, M2-Type, Counter Rotation                    |
| DE300CZIIC - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZINR                             | GEARCASE, M2-Type, Counter Rotation                    |
| DE300CZINR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZISF                             | GEARCASE                                               |
| DE300CZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZISG                             | GEARCASE                                               |
| DE300CZISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300CZISS                             | GEARCASE                                               |
| DE300CZISS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| DE300PXAAA                             | 07-1_GEARCASE, M2-Type                                 |
| DE300PXAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE300PXAAB                             | 07-1_GEARCASE, M2-Type                                 |
| DE300PXAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE300PXAAC                             | 07-1_GEARCASE, M2-Type                                 |
| DE300PXAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE300PXAAD                             | 07-1_GEARCASE, M2-Type                                 |
| DE300PXAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| DE300PXABA                             | 07-1_GEARCASE, M2-Type                                 |
| DE300PXABB                             | 07-1_GEARCASE, M2-Type                                 |

|                                        |                                       |
|----------------------------------------|---------------------------------------|
| DE300PXABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| DE300PXABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| DE300PXABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| DE300PXIIC                             | GEARCASE, M2-Type                     |
| DE300PXIIC - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PXINR                             | GEARCASE, M2-Type                     |
| DE300PXINR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PXISF                             | GEARCASE                              |
| DE300PXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PXISG                             | GEARCASE                              |
| DE300PXISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PXISS                             | GEARCASE                              |
| DE300PXISS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZAAA                             | 07-1_GEARCASE, M2-Type                |
| DE300PZAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZAAB                             | 07-1_GEARCASE, M2-Type                |
| DE300PZAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZAAC                             | 07-1_GEARCASE, M2-Type                |
| DE300PZAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZAAD                             | 07-1_GEARCASE, M2-Type                |
| DE300PZAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZABA                             | 07-1_GEARCASE, M2-Type                |
| DE300PZABB                             | 07-1_GEARCASE, M2-Type                |
| DE300PZABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| DE300PZABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| DE300PZABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| DE300PZIIC                             | GEARCASE, M2-Type                     |
| DE300PZIIC - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZINR                             | GEARCASE, M2-Type                     |
| DE300PZINR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZISF                             | GEARCASE                              |
| DE300PZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZISG                             | GEARCASE                              |
| DE300PZISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| DE300PZISS                             | GEARCASE                              |

|                                                            |                                                |
|------------------------------------------------------------|------------------------------------------------|
| DE300PZISS - FR                                            | 07-1_BOÎTIER D'ENGRENAGES, de type M2          |
| E100FPLSOC                                                 | GEARCASE - FPL, FSL MODELS                     |
| E100FPLSOC - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES   |
| E100FPLSRS                                                 | GEARCASE - FPL, FSL MODELS                     |
| E100FPLSRS - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL |
| E100FSLSOC                                                 | GEARCASE - FPL, FSL MODELS                     |
| E100FSLSOC - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES   |
| E100FSLSRS                                                 | GEARCASE - FPL, FSL MODELS                     |
| E100FSLSRS - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL |
| E100WPLEEC 1999                                            | GEARCASE                                       |
| E100WPLSIF commercial, elec start, 20 in shaft 2001        | GEARCASE                                       |
| E100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE                                       |
| E100WPXEEC 1999                                            | GEARCASE                                       |
| E100WPXSIF commercial, elec start, 25 in shaft 2001        | GEARCASE                                       |
| E100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE                                       |
| E100WQLECS 1998                                            | GEARCASE -- 100WQL MODELS                      |
| E100WQLECS 1998                                            | GEARCASE -- 100WQX MODELS                      |
| E100WQXECS 1998                                            | GEARCASE -- 100WQL MODELS                      |
| E100WQXECS 1998                                            | GEARCASE -- 100WQX MODELS                      |
| E105WELEEN 1999                                            | GEARCASE                                       |
| E105WELEES 1999                                            | GEARCASE                                       |
| E105WELSIF commercial, elec start, 20 in shaft 2001        | GEARCASE                                       |
| E105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000      | GEARCASE                                       |
| E105WPLEES 1999                                            | GEARCASE                                       |
| E105WPLSIF commercial, elec start, TNT, 20 in shaft 2001   | GEARCASE                                       |
| E105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE                                       |
| E105WPXEES 1999                                            | GEARCASE                                       |
| E105WPXSIF commercial, elec start, TNT, 25 in shaft 2001   | GEARCASE                                       |
| E105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE                                       |
| E105WRLEES 1999                                            | GEARCASE                                       |
| E105WRLSIF commercial, rope start, 20 in shaft 2001        | GEARCASE                                       |
| E105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000       | GEARCASE                                       |

|                                                        |                                         |
|--------------------------------------------------------|-----------------------------------------|
| E105WRYEES 1999                                        | GEARCASE                                |
| E105WRYISF commercial, rope start, 22.5 in shaft 2001  | GEARCASE                                |
| E105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000 | GEARCASE                                |
| E115DBXAAA                                             | 07-1_GEARCASE, O-Type                   |
| E115DBXAAB                                             | 07-1_GEARCASE, O-Type                   |
| E115DBXABA                                             | 07-1_GEARCASE, O-Type                   |
| E115DBXAFA                                             | 07-1_GEARCASE, O-Type                   |
| E115DBXAFB                                             | 07-1_GEARCASE, O-Type                   |
| E115DBXIIB                                             | GEARCASE, O-Type                        |
| E115DBXIIB - FR                                        | 07-1_BOÎTIER D'ENGRENAGES, de type O    |
| E115DBXINE                                             | GEARCASE, O-Type                        |
| E115DBXINE - FR                                        | 07-1_BOÎTIER D'ENGRENAGES, de type O    |
| E115DBXISF                                             | GEARCASE                                |
| E115DBXISF - FR                                        | 07-1_BOÎTIER D'ENGRENAGES, de type O    |
| E115DBXISM                                             | GEARCASE                                |
| E115DBXISM - FR                                        | 07-1_BOÎTIER D'ENGRENAGES, de type O    |
| E115DBXSCR                                             | GEARCASE                                |
| E115DBXSCR - FR                                        | 07-1_BOÎTIER D'ENGRENAGES, de type O    |
| E115DBXSEF                                             | GEARCASE                                |
| E115DBXSEF - FR                                        | 07-1_BOÎTIER D'ENGRENAGES, de type O    |
| E115DBXSUC                                             | GEARCASE                                |
| E115DBXSUC - FR                                        | 07-1_BOÎTIER D'ENGRENAGES, de type O    |
| E115DCXAAA                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAAB                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXABA                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFA                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFB                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFF                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFG                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFH                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFI                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFK                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXAFL                                             | 07-1_GEARCASE, O-Type, Counter Rotation |
| E115DCXIIA                                             | GEARCASE, O-Type, Counter Rotation      |

|                 |                                                       |
|-----------------|-------------------------------------------------------|
| E115DCXIIA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation |
| E115DCXINM      | GEARCASE, O-Type, Counter Rotation                    |
| E115DCXINM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation |
| E115DCXISF      | GEARCASE                                              |
| E115DCXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation |
| E115DCXISR      | GEARCASE                                              |
| E115DCXISR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation |
| E115DCXSCS      | GEARCASE                                              |
| E115DCXSCS - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation |
| E115DCXSEF      | GEARCASE                                              |
| E115DCXSEF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation |
| E115DGLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DGLAFF      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DGLAFG      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DGLAFH      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DGLAFI      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DGLAFK      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DGLAFL      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DGXAFB      | 07-1_GEARCASE, O-Type                                 |
| E115DGXAFF      | 07-1_GEARCASE, O-Type                                 |
| E115DGXAFG      | 07-1_GEARCASE, O-Type                                 |
| E115DGXAFH      | 07-1_GEARCASE, (0.44 Ratio) O-Type                    |
| E115DGXAFI      | 07-1_GEARCASE, (0.44 Ratio) O-Type                    |
| E115DGXAFK      | 07-1_GEARCASE, (0.44 Ratio) O-Type                    |
| E115DGXAFL      | 07-1_GEARCASE, (0.44 Ratio) O-Type                    |
| E115DHLAAA      | 07-1_GEARCASE, S2-Type                                |
| E115DHLAAB      | 07-1_GEARCASE, S2-Type                                |
| E115DHLABA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type                   |
| E115DHLAFA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type                   |
| E115DHLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type                   |
| E115DHLIIR      | GEARCASE, S2-Type                                     |
| E115DHLIIR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2                 |
| E115DHLINA      | GEARCASE, S2-Type                                     |
| E115DHLINA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2                 |
| E115DHLISC      | GEARCASE                                              |

|                  |                                       |
|------------------|---------------------------------------|
| E115DHLISC - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DHLISF       | GEARCASE                              |
| E115DHLISF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DHLSSES      | GEARCASE                              |
| E115DHLSSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DHXAAA       | 07-1_GEARCASE, O-Type                 |
| E115DHXAAB       | 07-1_GEARCASE, O-Type                 |
| E115DHXABA       | 07-1_GEARCASE, O-Type                 |
| E115DHXAFA       | 07-1_GEARCASE, O-Type                 |
| E115DHXAFB       | 07-1_GEARCASE, O-Type                 |
| E115DHXAFF       | 07-1_GEARCASE, O-Type                 |
| E115DHXIIR       | GEARCASE, O-Type                      |
| E115DHXIIR - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DHXINA       | GEARCASE, O-Type                      |
| E115DHXINA - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DHXISC       | GEARCASE                              |
| E115DHXISC - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DHXISF       | GEARCASE                              |
| E115DHXISF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DHXSES       | GEARCASE                              |
| E115DHXSES - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DPLAAA       | 07-1_GEARCASE, S2-Type                |
| E115DPLAAB       | 07-1_GEARCASE, S2-Type                |
| E115DPLABA       | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E115DPLAFA       | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E115DPLAFB       | 07-1_GEARCASE, (0.42 Ratio) S2-Type   |
| E115DPLIIB       | GEARCASE, S2-Type                     |
| E115DPLIIB - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DPLINE       | GEARCASE, S2-Type                     |
| E115DPLINE - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DPLISF       | GEARCASE                              |
| E115DPLISF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DPLISM       | GEARCASE                              |
| E115DPLISM - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DPLSCR       | GEARCASE                              |

|                 |                                       |
|-----------------|---------------------------------------|
| E115DPLSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E115DPLSEF      | GEARCASE                              |
| E115DPLSEF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S  |
| E115DPLSUC      | GEARCASE                              |
| E115DPLSUC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S  |
| E115DPXAAA      | 07-1_GEARCASE, O-Type                 |
| E115DPXAAB      | 07-1_GEARCASE, O-Type                 |
| E115DPXABA      | 07-1_GEARCASE, O-Type                 |
| E115DPXAFA      | 07-1_GEARCASE, O-Type                 |
| E115DPXAFB      | 07-1_GEARCASE, O-Type                 |
| E115DPXAFF      | 07-1_GEARCASE, O-Type                 |
| E115DPXAFG      | 07-1_GEARCASE, O-Type                 |
| E115DPXAFH      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E115DPXAFI      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E115DPXAFK      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E115DPXAFL      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E115DPXIIB      | GEARCASE, O-Type                      |
| E115DPXIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DPXINE      | GEARCASE, O-Type                      |
| E115DPXINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DPXISF      | GEARCASE                              |
| E115DPXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DPXISM      | GEARCASE                              |
| E115DPXISM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DPXSCR      | GEARCASE                              |
| E115DPXSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DPXSEF      | GEARCASE                              |
| E115DPXSEF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DPXSUC      | GEARCASE                              |
| E115DPXSUC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E115DSLAAA      | 07-1_GEARCASE, S2-Type                |
| E115DSLAAAB     | 07-1_GEARCASE, S2-Type                |
| E115DSLABA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E115DSLafa      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E115DSLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type   |



|                                                                        |                                                |
|------------------------------------------------------------------------|------------------------------------------------|
| E115FPLSDS                                                             | GEARCASE - PL, SL MODELS                       |
| E115FPLSDS - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL     |
| E115FPLSIF FFI, elec start, TNT, 20 in shaft 2001                      | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS   |
| E115FPLSIF FFI, elec start, TNT, 20 in shaft 2001                      | GEARCASE - FPX - FX MODELS                     |
| E115FPLSNF - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL        |
| E115FPLSNF - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX        |
| E115FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002  | GEARCASE - FPL, MODELS                         |
| E115FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002  | GEARCASE - FPX MODELS                          |
| E115FPLSOD                                                             | GEARCASE - FPL, FSL MODELS                     |
| E115FPLSOD - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES   |
| E115FPLSRE                                                             | GEARCASE - FPL, FSL MODELS                     |
| E115FPLSRE - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL |
| E115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000                     | GEARCASE - FPL, FSL, FL, FS MODELS             |
| E115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000                     | GEARCASE - FPX, FX MODELS                      |
| E115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                     | GEARCASE - FPL, FSL, FL, FS MODELS             |
| E115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                     | GEARCASE - FPX, FX MODELS                      |
| E115FPLSTB                                                             | GEARCASE - FPL, FSL MODELS                     |
| E115FPLSTB                                                             | GEARCASE - FPX MODELS                          |
| E115FPLSTB - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL   |
| E115FPLSTB - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX        |
| E115FPXEEC 1999                                                        | GEARCASE -- FPL, FSL MODELS                    |
| E115FPXEEC 1999                                                        | GEARCASE -- FPX MODELS                         |
| E115FPXEEN 1999                                                        | GEARCASE -- FPL, FSL MODELS                    |
| E115FPXEEN 1999                                                        | GEARCASE -- FPX MODELS                         |
| E115FPXSDS                                                             | GEARCASE - PX MODELS                           |
| E115FPXSDS - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX         |
| E115FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS   |
| E115FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - FPX - FX MODELS                     |
| E115FPXSNF - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL        |
| E115FPXSNF - FR                                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX        |
| E115FPXSNF Ficht Fuel Injection, 25 in., White, Remote, Elec, TNT 2002 | GEARCASE - FPL, MODELS                         |
| E115FPXSNF Ficht Fuel Injection, 25 in., White, Remote, Elec, TNT 2002 | GEARCASE - FPX MODELS                          |
| E115FPXSOD                                                             | GEARCASE - FPX MODELS                          |

|                                                        |                                                |
|--------------------------------------------------------|------------------------------------------------|
| E115FPXSOD - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - FPX MODELES        |
| E115FPXSRE                                             | GEARCASE - FPX MODELS                          |
| E115FPXSRE - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX        |
| E115FPXSSH FFI, Elec Start, TNT, 25 IN.shaft, wht 2000 | GEARCASE - FPL, FSL, FL, FS MODELS             |
| E115FPXSSH FFI, Elec Start, TNT, 25 IN.shaft, wht 2000 | GEARCASE - FPX, FX MODELS                      |
| E115FPXSSR FFI, Elec Start, TNT, 25 IN.shaft, wht 2000 | GEARCASE - FPL, FSL, FL, FS MODELS             |
| E115FPXSSR FFI, Elec Start, TNT, 25 IN.shaft, wht 2000 | GEARCASE - FPX, FX MODELS                      |
| E115FPXSTB                                             | GEARCASE - FPL, FSL MODELS                     |
| E115FPXSTB                                             | GEARCASE - FPX MODELS                          |
| E115FPXSTB - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL   |
| E115FPXSTB - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX        |
| E115FSLECS 1998                                        | GEARCASE -- FSL, FTL MODELS                    |
| E115FSLECS 1998                                        | GEARCASE -- FSX MODELS                         |
| E115FSLEEC 1999                                        | GEARCASE -- FPL, FSL MODELS                    |
| E115FSLEEC 1999                                        | GEARCASE -- FPX MODELS                         |
| E115FSLEEN 1999                                        | GEARCASE -- FPL, FSL MODELS                    |
| E115FSLEEN 1999                                        | GEARCASE -- FPX MODELS                         |
| E115FSLSDS                                             | GEARCASE - PL, SL MODELS                       |
| E115FSLSDS - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL     |
| E115FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001 | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS   |
| E115FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001 | GEARCASE - FPX - FX MODELS                     |
| E115FSLSOD                                             | GEARCASE - FPL, FSL MODELS                     |
| E115FSLSOD - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES   |
| E115FSLSRE                                             | GEARCASE - FPL, FSL MODELS                     |
| E115FSLSRE - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL |
| E115FSLSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000 | GEARCASE - FPL, FSL, FL, FS MODELS             |
| E115FSLSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000 | GEARCASE - FPX, FX MODELS                      |
| E115FSLSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000 | GEARCASE - FPL, FSL, FL, FS MODELS             |
| E115FSLSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000 | GEARCASE - FPX, FX MODELS                      |
| E115FSLSTB                                             | GEARCASE - FPL, FSL MODELS                     |
| E115FSLSTB                                             | GEARCASE - FPX MODELS                          |
| E115FSLSTB - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL   |
| E115FSLSTB - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX        |
| E115FSXECS 1998                                        | GEARCASE -- FSL, FTL MODELS                    |
| E115FSXECS 1998                                        | GEARCASE -- FSX MODELS                         |

|                 |                                        |
|-----------------|----------------------------------------|
| E115FTLECS 1998 | GEARCASE -- FSL, FTL MODELS            |
| E115FTLECS 1998 | GEARCASE -- FSX MODELS                 |
| E115GLECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| E115GLECM 1998  | GEARCASE -- 90 & 115 SX MODELS         |
| E115GLECM 1998  | JET DRIVE UNIT                         |
| E115GLEDR 1996  | GEARCASE - 20 IN. MODELS               |
| E115GLEDR 1996  | GEARCASE - 25 IN. MODELS               |
| E115GLEOC 1995  | GEARCASE - 20 IN. MODELS               |
| E115GLEOC 1995  | GEARCASE - 25 IN. MODELS               |
| E115GLEUA 1997  | GEARCASE - 20 IN. MODELS               |
| E115GLEUA 1997  | GEARCASE - 25 IN. MODELS               |
| E115GLEUC 1997  | GEARCASE - 20 IN. MODELS               |
| E115GLEUC 1997  | GEARCASE - 25 IN. MODELS               |
| E115GNLAFB      | 07-1_GEARCASE, O-Type                  |
| E115GNLAFF      | 07-1_GEARCASE, O-Type                  |
| E115GNLAFG      | 07-1_GEARCASE, O-Type                  |
| E115GNLAFH      | 07-1_GEARCASE, (0.44 Ratio) O-Type     |
| E115GNLAFI      | 07-1_GEARCASE, (0.44 Ratio) O-Type     |
| E115GNLAFK      | 07-1_GEARCASE, (0.44 Ratio) O-Type     |
| E115GNLAFL      | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E115HGLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E115HGLAFF      | 07-1_GEARCASE, (0.50 Ratio) S2-Type    |
| E115HSLAAA      | 07-1_GEARCASE, S2-Type                 |
| E115HSLAAB      | 07-1_GEARCASE, S2-Type                 |
| E115HSLABA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type    |
| E115HSLAFA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type    |
| E115HSLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E115HSLAFF      | 07-1_GEARCASE, (0.50 Ratio) S2-Type    |
| E115HSLIIR      | GEARCASE, S2-Type                      |
| E115HSLIIR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2  |
| E115HSLINA      | GEARCASE, S2-Type                      |
| E115HSLINA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2  |
| E115HSLISC      | GEARCASE                               |
| E115HSLISC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2  |
| E115HSLISF      | GEARCASE                               |

|                 |                                        |
|-----------------|----------------------------------------|
| E115HSLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2  |
| E115HSLSES      | GEARCASE                               |
| E115HSLSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2  |
| E115JTLECS 1998 | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| E115JTLECS 1998 | GEARCASE -- 90 & 115 SX MODELS         |
| E115JTLECS 1998 | JET DRIVE UNIT                         |
| E115SLECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| E115SLECM 1998  | GEARCASE -- 90 & 115 SX MODELS         |
| E115SLECM 1998  | JET DRIVE UNIT                         |
| E115SLEDR 1996  | GEARCASE - 20 IN. MODELS               |
| E115SLEDR 1996  | GEARCASE - 25 IN. MODELS               |
| E115SLEOC 1995  | GEARCASE - 20 IN. MODELS               |
| E115SLEOC 1995  | GEARCASE - 25 IN. MODELS               |
| E115SLEUA 1997  | GEARCASE - 20 IN. MODELS               |
| E115SLEUA 1997  | GEARCASE - 25 IN. MODELS               |
| E115SLEUC 1997  | GEARCASE - 20 IN. MODELS               |
| E115SLEUC 1997  | GEARCASE - 25 IN. MODELS               |
| E115SNLAFA      | 07-1_GEARCASE, O-Type                  |
| E115SNLAFB      | 07-1_GEARCASE, O-Type                  |
| E115SNLAFF      | 07-1_GEARCASE, O-Type                  |
| E115SNLAFG      | 07-1_GEARCASE, O-Type                  |
| E115SNLAFH      | 07-1_GEARCASE, O-Type                  |
| E115SNLAFI      | 07-1_GEARCASE, O-Type                  |
| E115SNLAFK      | 07-1_GEARCASE, (0.44 Ratio) O-Type     |
| E115SNLAFL      | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E115SXECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| E115SXECM 1998  | GEARCASE -- 90 & 115 SX MODELS         |
| E115SXECM 1998  | JET DRIVE UNIT                         |
| E115SXEDR 1996  | GEARCASE - 20 IN. MODELS               |
| E115SXEDR 1996  | GEARCASE - 25 IN. MODELS               |
| E115SXEOC 1995  | GEARCASE - 20 IN. MODELS               |
| E115SXEOC 1995  | GEARCASE - 25 IN. MODELS               |
| E115SXEUA 1997  | GEARCASE - 20 IN. MODELS               |
| E115SXEUA 1997  | GEARCASE - 25 IN. MODELS               |
| E115SXEUC 1997  | GEARCASE - 20 IN. MODELS               |

|                 |                                                         |
|-----------------|---------------------------------------------------------|
| E115SXEUC 1997  | GEARCASE - 25 IN. MODELS                                |
| E115TSLECM 1998 | GEARCASE                                                |
| E115TSXECM 1998 | GEARCASE                                                |
| E120TLERC 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E120TLERC 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E120TLERC 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TLERK 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E120TLERK 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E120TLERK 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TLETF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E120TLETF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TLETF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E120TLETS 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E120TLETS 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TLETS 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E120TXARC 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E120TXARC 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E120TXARC 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TXARK 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E120TXARK 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E120TXARK 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TXATF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E120TXATF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TXATF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E120TXATS 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E120TXATS 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TXATS 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E120TXERC 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E120TXERC 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E120TXERC 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TXERK 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E120TXERK 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E120TXERK 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TXETF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E120TXETF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |

|                 |                                                         |
|-----------------|---------------------------------------------------------|
| E120TXETF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E120TXETS 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E120TXETS 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E120TXETS 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E125ESXERK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E125ESXERK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E125ESXERK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| E125ESXETA 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E125ESXETA 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E125ESXETA 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E125ESXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E125ESXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E125ESXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E130CXAOR 1995  | GEARCASE - 130CX COUNTER ROTATION                       |
| E130CXAOR 1995  | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| E130DCXAAA      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAAB      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXABA      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFA      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFB      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFF      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFH      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFL      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFI      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFK      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXAFL      | 07-1_GEARCASE, O-Type, Counter Rotation                 |
| E130DCXIIR      | GEARCASE, O-Type, Counter Rotation                      |
| E130DCXIIR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation   |
| E130DCXINA      | GEARCASE, O-Type, Counter Rotation                      |
| E130DCXINA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation   |
| E130DCXISC      | GEARCASE                                                |
| E130DCXISC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation   |
| E130DCXISF      | GEARCASE                                                |
| E130DCXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation   |
| E130DCXSES      | GEARCASE                                                |
| E130DCXSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation   |

|                 |                                       |
|-----------------|---------------------------------------|
| E130DGLAFB      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DGLAFF      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DGLAFH      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DGLAFI      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DGLAFK      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DGLAFL      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DPLAAA      | 07-1_GEARCASE, S2-Type                |
| E130DPLAAB      | 07-1_GEARCASE, S2-Type                |
| E130DPLABA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DPLAFA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DPLAFB      | 07-1_GEARCASE, (0.50 Ratio) S2-Type   |
| E130DPLIIR      | GEARCASE, S2-Type                     |
| E130DPLIIR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E130DPLINA      | GEARCASE, S2-Type                     |
| E130DPLINA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E130DPLISC      | GEARCASE                              |
| E130DPLISC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E130DPLISF      | GEARCASE                              |
| E130DPLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E130DPLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E130DPLSES      | GEARCASE                              |
| E130DPLSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2 |
| E130DPXAAA      | 07-1_GEARCASE, O-Type                 |
| E130DPXAAB      | 07-1_GEARCASE, O-Type                 |
| E130DPXABA      | 07-1_GEARCASE, O-Type                 |
| E130DPXAFA      | 07-1_GEARCASE, O-Type                 |
| E130DPXAFB      | 07-1_GEARCASE, O-Type                 |
| E130DPXAFF      | 07-1_GEARCASE, O-Type                 |
| E130DPXAFH      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E130DPXAFI      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E130DPXAFK      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E130DPXAFL      | 07-1_GEARCASE, (0.44 Ratio) O-Type    |
| E130DPXIIR      | GEARCASE, O-Type                      |
| E130DPXIIR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E130DPXINA      | GEARCASE, O-Type                      |

|                 |                                            |
|-----------------|--------------------------------------------|
| E130DPXINA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E130DPXISC      | GEARCASE                                   |
| E130DPXISF      | GEARCASE                                   |
| E130DPXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E130DPXSES      | GEARCASE                                   |
| E130DPXSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E130DSLAAA      | 07-1_GEARCASE, S2-Type                     |
| E130DSLAAAB     | 07-1_GEARCASE, S2-Type                     |
| E130DSLABA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLafa      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLAFB      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLaff      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLAFH      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLAFI      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLAFK      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLAFL      | 07-1_GEARCASE, (0.50 Ratio) S2-Type        |
| E130DSLIIR      | GEARCASE, S2-Type                          |
| E130DSLIIR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2      |
| E130DSLINA      | GEARCASE, S2-Type                          |
| E130DSLINA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2      |
| E130DSLISC      | GEARCASE                                   |
| E130DSLISC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2      |
| E130DSLISF      | GEARCASE                                   |
| E130DSLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2      |
| E130DSLSES      | GEARCASE                                   |
| E130DSLSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S2      |
| E130TLECE 1998  | GEARCASE                                   |
| E130TLEDM 1996  | GEARCASE - 130CX COUNTER ROTATION          |
| E130TLEDM 1996  | GEARCASE - 130TL & 130TX STANDARD ROTATION |
| E130TLEOA 1995  | GEARCASE - 130CX COUNTER ROTATION          |
| E130TLEOA 1995  | GEARCASE - 130TL & 130TX STANDARD ROTATION |
| E130TLEUB 1997  | GEARCASE - 130CX COUNTER-ROTATION          |
| E130TLEUB 1997  | GEARCASE - 130TL & 130TX STANDARD ROTATION |
| E130TXACB 1998  | GEARCASE                                   |
| E130TXADA 1996  | GEARCASE - 130CX COUNTER ROTATION          |

|                                                                       |                                                        |
|-----------------------------------------------------------------------|--------------------------------------------------------|
| E130TXADA 1996                                                        | GEARCASE - 130TL & 130TX STANDARD ROTATION             |
| E130TXAOR 1995                                                        | GEARCASE - 130CX COUNTER ROTATION                      |
| E130TXAOR 1995                                                        | GEARCASE - 130TL & 130TX STANDARD ROTATION             |
| E130TXAUM 1997                                                        | GEARCASE - 130CX COUNTER-ROTATION                      |
| E130TXAUM 1997                                                        | GEARCASE - 130TL & 130TX STANDARD ROTATION             |
| E135DHLAAB                                                            | 07-1_GEARCASE, L2-Type                                 |
| E135DHLAAB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E135DHLABA                                                            | 07-1_GEARCASE, L2-Type                                 |
| E135DHLABA - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E135DHLABB                                                            | 07-1_GEARCASE, L2-Type                                 |
| E135DHXAAC                                                            | 07-1_GEARCASE, M2-Type                                 |
| E135DHXAAC - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E135DHXABA                                                            | 07-1_GEARCASE, M2-Type                                 |
| E135DHXABA - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E135DHXABB                                                            | 07-1_GEARCASE, M2-Type                                 |
| E135DHXABF                                                            | 07-1_GEARCASE, M2-Type                                 |
| E135DHXABG                                                            | 07-1_GEARCASE, M2-Type                                 |
| E135DHXABH                                                            | 07-1_GEARCASE, M2-Type                                 |
| E135DHXABJ                                                            | 07-1_GEARCASE, M2-Type                                 |
| E135FCXSDE                                                            | GEARCASE - CX, MODELS                                  |
| E135FCXSDE - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles CX                 |
| E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| E135FCXSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                |
| E135FCXSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX         |
| E135FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FPL - FPX MODELS                            |
| E135FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FCX, MODELS                                 |
| E135FCXSOB                                                            | GEARCASE - CX MODELS                                   |
| E135FCXSOB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - CX MODELES                 |
| E135FCXSRM                                                            | GEARCASE - CX MODELS                                   |
| E135FCXSRM - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles CX                 |
| E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |

|                                                                      |                                                         |
|----------------------------------------------------------------------|---------------------------------------------------------|
| E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E135FCXSTA                                                           | GEARCASE - FCX, MODELS                                  |
| E135FCXSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E135FCXSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E135FCXSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E135FPLSDE                                                           | GEARCASE - PL - SL MODELS                               |
| E135FPLSDE - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL              |
| E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E135FPLSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E135FPLSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX          |
| E135FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002             | GEARCASE - FPL - FPX MODELS                             |
| E135FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002             | GEARCASE - FCX, MODELS                                  |
| E135FPLSOB                                                           | GEARCASE - PL - SL MODELS                               |
| E135FPLSOB - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES             |
| E135FPLSRM                                                           | GEARCASE - PL - SL MODELS                               |
| E135FPLSRM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL            |
| E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E135FPLSTA                                                           | GEARCASE - FCX, MODELS                                  |
| E135FPLSTA                                                           | GEARCASE - FPL - FSL - FPX MODELS                       |
| E135FPLSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E135FPLSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E135FPLSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E135FPLSTF                                                           | GEARCASE - STANDARD ROTATION - "F" Suffix Models        |
| E135FPLSTF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E135FPLSTF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E135FPLSTF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E135FPXSDE                                                           | GEARCASE - PX MODELS                                    |
| E135FPXSDE - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX                  |
| E135FPXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |

|                                                           |                                                         |
|-----------------------------------------------------------|---------------------------------------------------------|
| E135FPXSNF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX          |
| E135FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002 | GEARCASE - FPL - FPX MODELS                             |
| E135FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002 | GEARCASE - FCX, MODELS                                  |
| E135FPXSOB                                                | GEARCASE - PX MODELS                                    |
| E135FPXSOB - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - PX MODELES                  |
| E135FPXSRM                                                | GEARCASE - PX MODELS                                    |
| E135FPXSRM - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX                  |
| E135FPXSTA                                                | GEARCASE - FCX, MODELS                                  |
| E135FPXSTA                                                | GEARCASE - FPL - FSL - FPX MODELS                       |
| E135FPXSTA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E135FPXSTA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E135FPXSTA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E135FSLSDE                                                | GEARCASE - PL - SL MODELS                               |
| E135FSLSDE - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL              |
| E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001    | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E135FSLSOB                                                | GEARCASE - PL - SL MODELS                               |
| E135FSLSOB - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES             |
| E135FSLSRM                                                | GEARCASE - PL - SL MODELS                               |
| E135FSLSRM - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL            |
| E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E135FSLSTA                                                | GEARCASE - FCX, MODELS                                  |
| E135FSLSTA                                                | GEARCASE - FPL - FSL - FPX MODELS                       |
| E135FSLSTA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E135FSLSTA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E135FSLSTF                                                | GEARCASE - STANDARD ROTATION - "F" Suffix Models        |
| E135FSLSTF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E135FSLSTF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E135FSLSTF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001    | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |

|                                                         |                                                        |
|---------------------------------------------------------|--------------------------------------------------------|
| E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| E135HCXAAC                                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E135HCXAAC - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E135HCXABA                                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E135HCXABA - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E135HCXABB                                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E135HCXABF                                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E135HCXABG                                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E135HCXABH                                              | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E135HGLABB                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HGLABF                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HGLABG                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HGLABH                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HGLABJ                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HGXABB                                              | 07-1_GEARCASE, M2-Type                                 |
| E135HGXABF                                              | 07-1_GEARCASE, M2-Type                                 |
| E135HGXABG                                              | 07-1_GEARCASE, M2-Type                                 |
| E135HGXABH                                              | 07-1_GEARCASE, M2-Type                                 |
| E135HGXABJ                                              | 07-1_GEARCASE, M2-Type                                 |
| E135HSLAAB                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HSLAAB - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E135HSLABA                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HSLABA - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E135HSLABB                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HSLABF                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HSLABG                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HSLABH                                              | 07-1_GEARCASE, L2-Type                                 |
| E135HSLABJ                                              | 07-1_GEARCASE, L2-Type                                 |
| E140CXARC 1994                                          | GEARCASE - 120TX & 140TX STANDARD ROTATION             |
| E140CXARC 1994                                          | GEARCASE - 120TL, 125ESX, & 140TL                      |
| E140CXARC 1994                                          | GEARCASE - 140CX COUNTER ROTATION                      |

|                |                                                         |
|----------------|---------------------------------------------------------|
| E140CXARK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140CXARK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140CXARK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140CXATF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140CXATF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140CXATF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140CXATS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140CXATS 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140CXATS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140CXERE 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140CXERE 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140CXERE 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140CXERK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140CXERK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140CXERK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140CXETB 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140CXETB 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140CXETB 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140CXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140CXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140CXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TLATC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TLATC 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TLATC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TLATF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TLATF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TLATF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TLERK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140TLERK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140TLERK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TLERR 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140TLERR 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140TLERR 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TLETC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TLETC 1993 | GEARCASE - 140CX COUNTER ROTATION                       |

|                 |                                                         |
|-----------------|---------------------------------------------------------|
| E140TLETC 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TLETF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TLETF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TLETF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TXARC 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140TXARC 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140TXARC 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXARK 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140TXARK 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140TXARK 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXATF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TXATF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXATF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TXATS 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TXATS 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXATS 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TXERK 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140TXERK 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140TXERK 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXERR 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| E140TXERR 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| E140TXERR 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXETC 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TXETC 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXETC 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E140TXETF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| E140TXETF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| E140TXETF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| E150DBXAAA      | 07-1_GEARCASE, M2-Type                                  |
| E150DBXAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E150DBXAAB      | 07-1_GEARCASE, M2-Type                                  |
| E150DBXAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E150DBXAAC      | 07-1_GEARCASE, M2-Type                                  |
| E150DBXAAC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E150DBXABA      | 07-1_GEARCASE, M2-Type                                  |

|                 |                                                        |
|-----------------|--------------------------------------------------------|
| E150DBXABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E150DBXABB      | 07-1_GEARCASE, M2-Type                                 |
| E150DBXIIB      | GEARCASE, M2-Type                                      |
| E150DBXIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E150DBXINE      | GEARCASE, M2-Type                                      |
| E150DBXINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E150DBXISF      | GEARCASE                                               |
| E150DBXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E150DBXISM      | GEARCASE                                               |
| E150DBXISM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E150DBXSCF      | GEARCASE                                               |
| E150DBXSCF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E150DBXSCR      | GEARCASE                                               |
| E150DBXSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M                   |
| E150DBXSEA      | GEARCASE                                               |
| E150DBXSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E150DBXSUF      | GEARCASE                                               |
| E150DBXSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M                   |
| E150DCXAAA      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXAAB      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXAAC      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXAAC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXABA      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXABB      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXABF      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXABG      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXABH      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXABJ      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E150DCXIIB      | GEARCASE, M2-Type, Counter Rotation                    |
| E150DCXIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXINE      | GEARCASE, M2-Type, Counter Rotation                    |
| E150DCXINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |

|                 |                                                        |
|-----------------|--------------------------------------------------------|
| E150DCXISF      | GEARCASE                                               |
| E150DCXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXISM      | GEARCASE                                               |
| E150DCXISM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXSCF      | GEARCASE                                               |
| E150DCXSCF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXSCR      | GEARCASE                                               |
| E150DCXSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E150DCXSEA      | GEARCASE                                               |
| E150DCXSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E150DCXSUC      | GEARCASE                                               |
| E150DCXSUC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E150DCXSUF      | GEARCASE                                               |
| E150DCXSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E150DGLABB      | 07-1_GEARCASE, O-Type                                  |
| E150DGLABF      | 07-1_GEARCASE, O-Type                                  |
| E150DGLABG      | 07-1_GEARCASE, O-Type                                  |
| E150DGLABH      | 07-1_GEARCASE, O-Type                                  |
| E150DGLABJ      | 07-1_GEARCASE, O-Type                                  |
| E150DGXABB      | 07-1_GEARCASE, M2-Type                                 |
| E150DGXABF      | 07-1_GEARCASE, M2-Type                                 |
| E150DGXABG      | 07-1_GEARCASE, M2-Type                                 |
| E150DGXABH      | 07-1_GEARCASE, M2-Type                                 |
| E150DGXABJ      | 07-1_GEARCASE, M2-Type                                 |
| E150DHLAAA      | 07-1_GEARCASE, L2-Type                                 |
| E150DHLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E150DHLAAB      | 07-1_GEARCASE, L2-Type                                 |
| E150DHLAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E150DHLABA      | 07-1_GEARCASE, L2-Type                                 |
| E150DHLABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E150DHLABB      | 07-1_GEARCASE, L2-Type                                 |
| E150DHLIIB      | GEARCASE, L2-Type                                      |
| E150DHLIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E150DHLINE      | GEARCASE, L2-Type                                      |
| E150DHLINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |

|                 |                                       |
|-----------------|---------------------------------------|
| E150DHLISF      | GEARCASE                              |
| E150DHLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150DHLISM      | GEARCASE                              |
| E150DHLISM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150DHLSCF      | GEARCASE                              |
| E150DHLSCF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150DHLSCR      | GEARCASE - HL MODEL                   |
| E150DHLSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E150DHLSEA      | GEARCASE                              |
| E150DHLSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150DHLSUC      | GEARCASE - HL MODEL                   |
| E150DHLSUC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E150DHLSUF      | GEARCASE - HL MODEL                   |
| E150DHLSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E150DPLAAA      | 07-1_GEARCASE, O-Type                 |
| E150DPLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLAAB      | 07-1_GEARCASE, O-Type                 |
| E150DPLAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLABA      | 07-1_GEARCASE, O-Type                 |
| E150DPLABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLABB      | 07-1_GEARCASE, O-Type                 |
| E150DPLIIB      | GEARCASE, O-Type                      |
| E150DPLIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLINE      | GEARCASE, O-Type                      |
| E150DPLINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLISF      | GEARCASE - PL, SL MODELS              |
| E150DPLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLISM      | GEARCASE - PL, SL MODELS              |
| E150DPLISM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLSCR      | GEARCASE - PL, SL MODELS              |
| E150DPLSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLSEA      | GEARCASE - PL, SL MODELS              |
| E150DPLSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPLSUC      | GEARCASE - PL, SL MODELS              |
| E150DPLSUC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |

|                 |                                       |
|-----------------|---------------------------------------|
| E150DPLSUF      | GEARCASE - PL, SL MODELS              |
| E150DPLSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DPXAAA      | 07-1_GEARCASE, M2-Type                |
| E150DPXAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXAAB      | 07-1_GEARCASE, M2-Type                |
| E150DPXAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXAAC      | 07-1_GEARCASE, M2-Type                |
| E150DPXAAC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXABA      | 07-1_GEARCASE, M2-Type                |
| E150DPXABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXABB      | 07-1_GEARCASE, M2-Type                |
| E150DPXABF      | 07-1_GEARCASE, M2-Type                |
| E150DPXABG      | 07-1_GEARCASE, M2-Type                |
| E150DPXABH      | 07-1_GEARCASE, M2-Type                |
| E150DPXABJ      | 07-1_GEARCASE, M2-Type                |
| E150DPXIIB      | GEARCASE, M2-Type                     |
| E150DPXIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXINE      | GEARCASE, M2-Type                     |
| E150DPXINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXISF      | GEARCASE                              |
| E150DPXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXISM      | GEARCASE                              |
| E150DPXSCF      | GEARCASE                              |
| E150DPXSCF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXSCR      | GEARCASE                              |
| E150DPXSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E150DPXSEA      | GEARCASE                              |
| E150DPXSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150DPXSUC      | GEARCASE                              |
| E150DPXSUC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E150DPXSUF      | GEARCASE                              |
| E150DPXSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E150DSLAAA      | 07-1_GEARCASE, O-Type                 |
| E150DSLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E150DSLAAAB     | 07-1_GEARCASE, O-Type                 |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E150DSLAA - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DSLABA      | 07-1_GEARCASE, O-Type                                        |
| E150DSLABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DSLABB      | 07-1_GEARCASE, O-Type                                        |
| E150DSLABF      | 07-1_GEARCASE, O-Type                                        |
| E150DSLABG      | 07-1_GEARCASE, O-Type                                        |
| E150DSLABH      | 07-1_GEARCASE, O-Type                                        |
| E150DSLABJ      | 07-1_GEARCASE, O-Type                                        |
| E150DSLIIB      | GEARCASE, O-Type                                             |
| E150DSLIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DSLIE       | GEARCASE, O-Type                                             |
| E150DSLIE - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DSLIF       | GEARCASE - PL, SL MODELS                                     |
| E150DSLIM       | GEARCASE - PL, SL MODELS                                     |
| E150DSLIM - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DSLISC      | GEARCASE - PL, SL MODELS                                     |
| E150DSLISC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DSLSEA      | GEARCASE - PL, SL MODELS                                     |
| E150DSLSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DLSUC       | GEARCASE - PL, SL MODELS                                     |
| E150DLSUC - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150DLSUF       | GEARCASE - PL, SL MODELS                                     |
| E150DLSUF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E150ELECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E150ELECD 1998  | GEARCASE -- COUNTER-ROTATION                                 |
| E150ELECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E150ELECD 1998  | JET DRIVE UNIT                                               |
| E150ELEDB 1996  | GEARCASE - COUNTER-ROTATION                                  |
| E150ELEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150ELEDB 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E150ELEDB 1996  | JET DRIVE UNIT                                               |
| E150ELEOM 1995  | GEARCASE - COUNTER ROTATION                                  |
| E150ELEOM 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150ELEOM 1995  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E150ELEOM 1995 | JET DRIVE UNIT                                               |
| E150ELERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150ELERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150ELERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150ELERA 1994 | JET DRIVE UNIT                                               |
| E150ELERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150ELERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150ELERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150ELERV 1994 | JET DRIVE UNIT                                               |
| E150ELETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150ELETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150ELETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150ELETG 1993 | JET DRIVE UNIT                                               |
| E150ELETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150ELETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150ELETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150ELETR 1993 | JET DRIVE UNIT                                               |
| E150ELEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150ELEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150ELEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150ELEUC 1997 | JET DRIVE UNIT                                               |
| E150ELEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150ELEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150ELEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150ELEUE 1997 | JET DRIVE UNIT                                               |
| E150EXARC 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150EXARC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXARC 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150EXARC 1994 | JET DRIVE UNIT                                               |
| E150EXARV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150EXARV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXARV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E150EXARV 1994 | JET DRIVE UNIT                                               |
| E150EXATG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150EXATG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXATG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150EXATG 1993 | JET DRIVE UNIT                                               |
| E150EXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150EXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXATS 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150EXATS 1993 | JET DRIVE UNIT                                               |
| E150EXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E150EXECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| E150EXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E150EXECD 1998 | JET DRIVE UNIT                                               |
| E150EXEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E150EXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150EXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E150EXEDB 1996 | JET DRIVE UNIT                                               |
| E150EXEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| E150EXEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E150EXEOM 1995 | JET DRIVE UNIT                                               |
| E150EXERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150EXERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150EXERA 1994 | JET DRIVE UNIT                                               |
| E150EXERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150EXERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150EXERV 1994 | JET DRIVE UNIT                                               |
| E150EXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150EXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150EXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150EXETG 1993 | JET DRIVE UNIT                                               |

|                                                                       |                                                             |
|-----------------------------------------------------------------------|-------------------------------------------------------------|
| E150EXETR 1993                                                        | GEARCASE - COUNTER ROTATION                                 |
| E150EXETR 1993                                                        | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                |
| E150EXETR 1993                                                        | GEARCASE - STANDARD ROTATION - 25" MODELS                   |
| E150EXETR 1993                                                        | JET DRIVE UNIT                                              |
| E150EXEUC 1997                                                        | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| E150EXEUC 1997                                                        | GEARCASE - COUNTER-ROTATION                                 |
| E150EXEUC 1997                                                        | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| E150EXEUC 1997                                                        | JET DRIVE UNIT                                              |
| E150EXEUE 1997                                                        | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25" |
| E150EXEUE 1997                                                        | GEARCASE - COUNTER-ROTATION                                 |
| E150EXEUE 1997                                                        | GEARCASE - STANDARD ROTATION - GL MODELS                    |
| E150EXEUE 1997                                                        | JET DRIVE UNIT                                              |
| E150FCXECR 1998                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                  |
| E150FCXECR 1998                                                       | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS           |
| E150FCXECR 1998                                                       | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS            |
| E150FCXEEA 1999                                                       | GEARCASE -- STANDARD ROTATION -- FPL MODELS                 |
| E150FCXEEA 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS            |
| E150FCXEEA 1999                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                  |
| E150FCXEEN 1999                                                       | GEARCASE -- STANDARD ROTATION -- FPL MODELS                 |
| E150FCXEEN 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS            |
| E150FCXEEN 1999                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                  |
| E150FCXEEO 1999                                                       | GEARCASE -- STANDARD ROTATION -- FPL MODELS                 |
| E150FCXEEO 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS            |
| E150FCXEEO 1999                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                  |
| E150FCXSDR                                                            | GEARCASE - CX, MODELS                                       |
| E150FCXSDR - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles CX                      |
| E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - FPL - FL MODELS              |
| E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS      |
| E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS                |
| E150FCXSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                     |
| E150FCXSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX              |
| E150FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FPL - FPX MODELS                                 |

|                                                                       |                                                         |
|-----------------------------------------------------------------------|---------------------------------------------------------|
| E150FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FCX, MODELS                                  |
| E150FCXSOC                                                            | GEARCASE - CX MODELS                                    |
| E150FCXSOC - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - CX MODELES                  |
| E150FCXSRS                                                            | GEARCASE - CX MODELS                                    |
| E150FCXSRS - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles CX                  |
| E150FCXSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E150FCXSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FCXSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E150FCXSTD                                                            | GEARCASE - FCX, MODELS                                  |
| E150FCXSTD - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E150FCXSTD - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E150FCXSTD - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E150FHLSDR                                                            | GEARCASE - FHL MODEL                                    |
| E150FHLSDR - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                 |
| E150FHLSOC                                                            | GEARCASE - FHL MODEL                                    |
| E150FHLSOC - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - FHL MODELES                 |
| E150FHLSRS                                                            | GEARCASE - FHL MODEL                                    |
| E150FHLSRS - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                 |
| E150FPLEEA 1999                                                       | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E150FPLEEA 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E150FPLEEA 1999                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FPLEEO 1999                                                       | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E150FPLEEO 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E150FPLEEO 1999                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FPLSDR                                                            | GEARCASE - PL - SL MODELS                               |
| E150FPLSDR - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL              |
| E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001                     | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001                     | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001                     | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |

|                                                          |                                                         |
|----------------------------------------------------------|---------------------------------------------------------|
| E150FPLSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E150FPLSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX          |
| E150FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002 | GEARCASE - FPL - FPX MODELS                             |
| E150FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002 | GEARCASE - FCX, MODELS                                  |
| E150FPLSOC                                               | GEARCASE - PL - SL MODELS                               |
| E150FPLSOC - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES             |
| E150FPLSRS                                               | GEARCASE - PL - SL MODELS                               |
| E150FPLSRS - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL            |
| E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000       | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000       | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000       | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000       | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000       | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000       | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E150FPLSTD                                               | GEARCASE - FCX, MODELS                                  |
| E150FPLSTD                                               | GEARCASE - FPL - FSL - FPX MODELS                       |
| E150FPLSTD - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E150FPLSTD - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E150FPLSTD - FR                                          | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E150FPLSTF                                               | GEARCASE - STANDARD ROTATION - "F" Suffix Models        |
| E150FPLSTF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E150FPLSTF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E150FPLSTF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E150FPXEEA 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E150FPXEEA 1999                                          | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E150FPXEEA 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FPXEEN 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E150FPXEEN 1999                                          | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E150FPXEEN 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FPXEEO 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E150FPXEEO 1999                                          | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E150FPXEEO 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FPXSDR                                               | GEARCASE - PX MODELS                                    |
| E150FPXSDR - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX                  |
| E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |

|                                                           |                                                         |
|-----------------------------------------------------------|---------------------------------------------------------|
| E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E150FPXSNF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E150FPXSNF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX          |
| E150FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002 | GEARCASE - FPL - FPX MODELS                             |
| E150FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002 | GEARCASE - FCX, MODELS                                  |
| E150FPXSOC                                                | GEARCASE - PX MODELS                                    |
| E150FPXSOC - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - PX MODELES                  |
| E150FPXSRS                                                | GEARCASE - PX MODELS                                    |
| E150FPXSRS - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX                  |
| E150FPXSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E150FPXSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FPXSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E150FPXSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E150FPXSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E150FPXSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E150FPXSTD                                                | GEARCASE - FCX, MODELS                                  |
| E150FPXSTD                                                | GEARCASE - FPL - FSL - FPX MODELS                       |
| E150FPXSTD - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E150FPXSTD - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E150FPXSTD - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E150FSLECR 1998                                           | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FSLECR 1998                                           | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS       |
| E150FSLECR 1998                                           | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS        |
| E150FSLEEA 1999                                           | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E150FSLEEA 1999                                           | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E150FSLEEA 1999                                           | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FSLEEO 1999                                           | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E150FSLEEO 1999                                           | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E150FSLEEO 1999                                           | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E150FSLSDR                                                | GEARCASE - PL - SL MODELS                               |

|                                                         |                                                             |
|---------------------------------------------------------|-------------------------------------------------------------|
| E150FSLSDR - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL                  |
| E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FPL - FL MODELS              |
| E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS      |
| E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS                |
| E150FSLSOC                                              | GEARCASE - PL - SL MODELS                                   |
| E150FSLSOC - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES                 |
| E150FSLSRS                                              | GEARCASE - PL - SL MODELS                                   |
| E150FSLSRS - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL                |
| E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS               |
| E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS      |
| E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS                |
| E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS               |
| E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS      |
| E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS                |
| E150FSLSTD                                              | GEARCASE - FCX, MODELS                                      |
| E150FSLSTD                                              | GEARCASE - FPL - FSL - FPX MODELS                           |
| E150FSLSTD - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                     |
| E150FSLSTD - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL           |
| E150FSLSTD - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation     |
| E150FSLSTF                                              | GEARCASE - STANDARD ROTATION - "F" Suffix Models            |
| E150FSLSTF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                     |
| E150FSLSTF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL           |
| E150FSLSTF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation     |
| E150FSXECR 1998                                         | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                  |
| E150FSXECR 1998                                         | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS           |
| E150FSXECR 1998                                         | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS            |
| E150GLECD 1998                                          | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| E150GLECD 1998                                          | GEARCASE -- COUNTER-ROTATION                                |
| E150GLECD 1998                                          | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| E150GLECD 1998                                          | JET DRIVE UNIT                                              |
| E150GLEDB 1996                                          | GEARCASE - COUNTER-ROTATION                                 |
| E150GLEDB 1996                                          | GEARCASE - STANDARD ROTATION - GL MODELS                    |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E150GLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E150GLEDB 1996 | JET DRIVE UNIT                                               |
| E150GLEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| E150GLEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150GLEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E150GLEOM 1995 | JET DRIVE UNIT                                               |
| E150GLERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150GLERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150GLERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150GLERA 1994 | JET DRIVE UNIT                                               |
| E150GLERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150GLERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150GLERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150GLERV 1994 | JET DRIVE UNIT                                               |
| E150GLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150GLETG 1993 | JET DRIVE UNIT                                               |
| E150GLETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150GLETR 1993 | JET DRIVE UNIT                                               |
| E150GLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150GLEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150GLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150GLEUC 1997 | JET DRIVE UNIT                                               |
| E150GLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150GLEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150GLEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150GLEUE 1997 | JET DRIVE UNIT                                               |
| E150GNLABB     | 07-1_GEARCASE, O-Type                                        |
| E150GNLABF     | 07-1_GEARCASE, O-Type                                        |
| E150GNLABG     | 07-1_GEARCASE, O-Type                                        |

|                 |                                       |
|-----------------|---------------------------------------|
| E150GNLABH      | 07-1_GEARCASE, O-Type                 |
| E150GNLABJ      | 07-1_GEARCASE, O-Type                 |
| E150HGLABA      | 07-1_GEARCASE, L2-Type                |
| E150HGLABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150HGLABB      | 07-1_GEARCASE, L2-Type                |
| E150HGLABF      | 07-1_GEARCASE, L2-Type                |
| E150HGLABG      | 07-1_GEARCASE, L2-Type                |
| E150HGLABH      | 07-1_GEARCASE, L2-Type                |
| E150HGLABJ      | 07-1_GEARCASE, L2-Type                |
| E150HGLSES      | GEARCASE                              |
| E150HGLSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150HGXABA      | 07-1_GEARCASE, M2-Type                |
| E150HGXABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150HGXABB      | 07-1_GEARCASE, M2-Type                |
| E150HGXABF      | 07-1_GEARCASE, M2-Type                |
| E150HGXABG      | 07-1_GEARCASE, M2-Type                |
| E150HGXABH      | 07-1_GEARCASE, M2-Type                |
| E150HGXABJ      | 07-1_GEARCASE, M2-Type                |
| E150HGXSES      | GEARCASE                              |
| E150HGXSES - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E150HSLAAA      | 07-1_GEARCASE, L2-Type                |
| E150HSLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150HSLAAB      | 07-1_GEARCASE, L2-Type                |
| E150HSLAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150HSLABA      | 07-1_GEARCASE, L2-Type                |
| E150HSLABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150HSLABB      | 07-1_GEARCASE, L2-Type                |
| E150HSLABF      | 07-1_GEARCASE, L2-Type                |
| E150HSLABG      | 07-1_GEARCASE, L2-Type                |
| E150HSLABH      | 07-1_GEARCASE, L2-Type                |
| E150HSLABJ      | 07-1_GEARCASE, L2-Type                |
| E150HSLIIA      | GEARCASE, L2-Type                     |
| E150HSLIIA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E150HSLINM      | GEARCASE, L2-Type                     |
| E150HSLINM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E150HSLISF      | GEARCASE                                                     |
| E150HSLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E150HSLISR      | GEARCASE                                                     |
| E150HSLISR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E150HSLSCF      | GEARCASE                                                     |
| E150HSLSCF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E150HSLSCS      | GEARCASE - HL MODEL                                          |
| E150HSLSCS - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L                         |
| E150HSLSEC      | GEARCASE                                                     |
| E150HSLSEC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E150ICXEUC 1997 | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                   |
| E150ICXEUC 1997 | GEARCASE -- STANDARD ROTATION -- IL MODELS                   |
| E150ICXEUC 1997 | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS              |
| E150ILECR 1998  | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| E150ILECR 1998  | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| E150ILECR 1998  | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| E150ILEUC 1997  | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                   |
| E150ILEUC 1997  | GEARCASE -- STANDARD ROTATION -- IL MODELS                   |
| E150ILEUC 1997  | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS              |
| E150IXEUC 1997  | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                   |
| E150IXEUC 1997  | GEARCASE -- STANDARD ROTATION -- IL MODELS                   |
| E150IXEUC 1997  | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS              |
| E150JLECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E150JLECD 1998  | GEARCASE -- COUNTER-ROTATION                                 |
| E150JLECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E150JLECD 1998  | JET DRIVE UNIT                                               |
| E150JLEDB 1996  | GEARCASE - COUNTER-ROTATION                                  |
| E150JLEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150JLEDB 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E150JLEDB 1996  | JET DRIVE UNIT                                               |
| E150JLEOM 1995  | GEARCASE - COUNTER ROTATION                                  |
| E150JLEOM 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150JLEOM 1995  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E150JLEOM 1995  | JET DRIVE UNIT                                               |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E150JLERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150JLERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150JLERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150JLERA 1994 | JET DRIVE UNIT                                               |
| E150JLERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150JLERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150JLERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150JLERV 1994 | JET DRIVE UNIT                                               |
| E150JLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150JLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150JLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150JLETG 1993 | JET DRIVE UNIT                                               |
| E150JLETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150JLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150JLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150JLETR 1993 | JET DRIVE UNIT                                               |
| E150JLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150JLEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150JLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150JLEUC 1997 | JET DRIVE UNIT                                               |
| E150JLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150JLEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150JLEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150JLEUE 1997 | JET DRIVE UNIT                                               |
| E150NXARC 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150NXARC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXARC 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150NXARC 1994 | JET DRIVE UNIT                                               |
| E150NXARV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150NXARV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXARV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150NXARV 1994 | JET DRIVE UNIT                                               |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E150NXATG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150NXATG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXATG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150NXATG 1993 | JET DRIVE UNIT                                               |
| E150NXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150NXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXATS 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150NXATS 1993 | JET DRIVE UNIT                                               |
| E150NXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E150NXECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| E150NXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E150NXECD 1998 | JET DRIVE UNIT                                               |
| E150NXEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E150NXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150NXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E150NXEDB 1996 | JET DRIVE UNIT                                               |
| E150NXEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| E150NXEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E150NXEOM 1995 | JET DRIVE UNIT                                               |
| E150NXERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150NXERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150NXERA 1994 | JET DRIVE UNIT                                               |
| E150NXERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E150NXERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E150NXERV 1994 | JET DRIVE UNIT                                               |
| E150NXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E150NXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150NXETG 1993 | JET DRIVE UNIT                                               |
| E150NXETR 1993 | GEARCASE - COUNTER ROTATION                                  |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E150NXETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150NXETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E150NXETR 1993 | JET DRIVE UNIT                                               |
| E150NXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150NXEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150NXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150NXEUC 1997 | JET DRIVE UNIT                                               |
| E150NXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150NXEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150NXEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150NXEUE 1997 | JET DRIVE UNIT                                               |
| E150PLEUC 1997 | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                   |
| E150PLEUC 1997 | GEARCASE -- STANDARD ROTATION -- IL MODELS                   |
| E150PLEUC 1997 | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS              |
| E150SLECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E150SLECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| E150SLECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E150SLECD 1998 | JET DRIVE UNIT                                               |
| E150SLEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E150SLEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150SLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E150SLEDB 1996 | JET DRIVE UNIT                                               |
| E150SLEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| E150SLEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E150SLEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E150SLEOM 1995 | JET DRIVE UNIT                                               |
| E150SLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150SLEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E150SLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E150SLEUC 1997 | JET DRIVE UNIT                                               |
| E150SLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E150SLEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |

|                                                           |                                                        |
|-----------------------------------------------------------|--------------------------------------------------------|
| E150SLEUE 1997                                            | GEARCASE - STANDARD ROTATION - GL MODELS               |
| E150SLEUE 1997                                            | JET DRIVE UNIT                                         |
| E150SNLABA                                                | 07-1_GEARCASE, O-Type                                  |
| E150SNLABA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type O                   |
| E150SNLABB                                                | 07-1_GEARCASE, O-Type                                  |
| E150SNLABF                                                | 07-1_GEARCASE, O-Type                                  |
| E150SNLABG                                                | 07-1_GEARCASE, O-Type                                  |
| E150SNLABH                                                | 07-1_GEARCASE, O-Type                                  |
| E150SNLABJ                                                | 07-1_GEARCASE, O-Type                                  |
| E150WPLSIF commercial, elec start, TNT, 20 in shaft 2001  | GEARCASE                                               |
| E150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000 | GEARCASE                                               |
| E150WTLEOR 1995                                           | GEARCASE                                               |
| E150WTLERC 1994                                           | GEARCASE                                               |
| E150WTLERV 1994                                           | GEARCASE                                               |
| E150WTLETG 1993                                           | GEARCASE - 20" MODELS                                  |
| E150WTLETG 1993                                           | GEARCASE - 25" MODELS                                  |
| E150WTLETS 1993                                           | GEARCASE - 20" MODELS                                  |
| E150WTLETS 1993                                           | GEARCASE - 25" MODELS                                  |
| E150WTXEOE 1995                                           | GEARCASE                                               |
| E150WTXERC 1994                                           | GEARCASE                                               |
| E150WTXERV 1994                                           | GEARCASE                                               |
| E150WTXETG 1993                                           | GEARCASE - 20" MODELS                                  |
| E150WTXETG 1993                                           | GEARCASE - 25" MODELS                                  |
| E150WTXETS 1993                                           | GEARCASE - 20" MODELS                                  |
| E150WTXETS 1993                                           | GEARCASE - 25" MODELS                                  |
| E175DCXAAA                                                | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXAAA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXAAB                                                | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXAAB - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXAAC                                                | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXAAC - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXABA                                                | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXABA - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXABB                                                | 07-1_GEARCASE, M2-Type, Counter Rotation               |

|                 |                                                        |
|-----------------|--------------------------------------------------------|
| E175DCXABF      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXABG      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXABH      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXABJ      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E175DCXIIB      | GEARCASE, M2-Type, Counter Rotation                    |
| E175DCXIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXINE      | GEARCASE, M2-Type, Counter Rotation                    |
| E175DCXINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXISF      | GEARCASE                                               |
| E175DCXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXISM      | GEARCASE                                               |
| E175DCXISM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXSCF      | GEARCASE                                               |
| E175DCXSCF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXSCR      | GEARCASE                                               |
| E175DCXSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E175DCXSEA      | GEARCASE                                               |
| E175DCXSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E175DCXSUF      | GEARCASE                                               |
| E175DCXSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E175DGLABB      | 07-1_GEARCASE, O-Type                                  |
| E175DGLABF      | 07-1_GEARCASE, O-Type                                  |
| E175DGLABG      | 07-1_GEARCASE, O-Type                                  |
| E175DGLABH      | 07-1_GEARCASE, O-Type                                  |
| E175DGXABB      | 07-1_GEARCASE, M2-Type                                 |
| E175DGXABF      | 07-1_GEARCASE, M2-Type                                 |
| E175DGXABG      | 07-1_GEARCASE, M2-Type                                 |
| E175DGXABH      | 07-1_GEARCASE, M2-Type                                 |
| E175DMXAAA      | 07-1_GEARCASE, M2-Type                                 |
| E175DMXAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E175DMXAAB      | 07-1_GEARCASE, M2-Type                                 |
| E175DMXAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E175DMXAAC      | 07-1_GEARCASE, M2-Type                                 |
| E175DMXAAC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E175DPLAAA      | 07-1_GEARCASE, O-Type                                  |

|                 |                                       |
|-----------------|---------------------------------------|
| E175DPLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLAAB      | 07-1_GEARCASE, O-Type                 |
| E175DPLAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLABA      | 07-1_GEARCASE, O-Type                 |
| E175DPLABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLABB      | 07-1_GEARCASE, O-Type                 |
| E175DPLIIB      | GEARCASE, O-Type                      |
| E175DPLIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLINE      | GEARCASE, O-Type                      |
| E175DPLINE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLISF      | GEARCASE - PL, SL MODELS              |
| E175DPLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLISM      | GEARCASE - PL, SL MODELS              |
| E175DPLISM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLSCR      | GEARCASE - PL, SL MODELS              |
| E175DPLSCR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLSEA      | GEARCASE - PL, SL MODELS              |
| E175DPLSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPLSUF      | GEARCASE - PL, SL MODELS              |
| E175DPLSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DPXAAA      | 07-1_GEARCASE, M2-Type                |
| E175DPXAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXAAB      | 07-1_GEARCASE, M2-Type                |
| E175DPXAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXAAC      | 07-1_GEARCASE, M2-Type                |
| E175DPXAAC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXABA      | 07-1_GEARCASE, M2-Type                |
| E175DPXABA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXABB      | 07-1_GEARCASE, M2-Type                |
| E175DPXABF      | 07-1_GEARCASE, M2-Type                |
| E175DPXABG      | 07-1_GEARCASE, M2-Type                |
| E175DPXABH      | 07-1_GEARCASE, M2-Type                |
| E175DPXABJ      | 07-1_GEARCASE, M2-Type                |
| E175DPXIIB      | GEARCASE, M2-Type                     |
| E175DPXIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |

|                  |                                       |
|------------------|---------------------------------------|
| E175DPXINE       | GEARCASE, M2-Type                     |
| E175DPXINE - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXISF       | GEARCASE                              |
| E175DPXISF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXISM       | GEARCASE                              |
| E175DPXISM - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXSCF       | GEARCASE                              |
| E175DPXSCF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXSCR       | GEARCASE                              |
| E175DPXSCR - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E175DPXSEA       | GEARCASE                              |
| E175DPXSEA - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E175DPXSUF       | GEARCASE                              |
| E175DPXSUF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E175DSLAAA       | 07-1_GEARCASE, O-Type                 |
| E175DSLAAA - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DSLAAAB      | 07-1_GEARCASE, O-Type                 |
| E175DSLAAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DSLABA       | 07-1_GEARCASE, O-Type                 |
| E175DSLABA - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DSLABB       | 07-1_GEARCASE, O-Type                 |
| E175DSLABF       | 07-1_GEARCASE, O-Type                 |
| E175DSLABG       | 07-1_GEARCASE, O-Type                 |
| E175DSLABH       | 07-1_GEARCASE, O-Type                 |
| E175DSLABJ       | 07-1_GEARCASE, O-Type                 |
| E175DSLIIIB      | GEARCASE, O-Type                      |
| E175DSLIIIB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DSLIME       | GEARCASE, O-Type                      |
| E175DSLIME - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DSLISF       | GEARCASE - PL, SL MODELS              |
| E175DSLISF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DSLISM       | GEARCASE - PL, SL MODELS              |
| E175DSLISM - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E175DSLSCR       | GEARCASE - PL, SL MODELS              |
| E175DSLSCR - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O  |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E175DSLSEA      | GEARCASE - PL, SL MODELS                                     |
| E175DSLSEA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E175DSLSUF      | GEARCASE - PL, SL MODELS                                     |
| E175DSLSUF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                         |
| E175EXARC 1994  | GEARCASE - COUNTER ROTATION                                  |
| E175EXARC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXARC 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175EXARC 1994  | JET DRIVE UNIT                                               |
| E175EXARV 1994  | GEARCASE - COUNTER ROTATION                                  |
| E175EXARV 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXARV 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175EXARV 1994  | JET DRIVE UNIT                                               |
| E175EXATG 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175EXATG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXATG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175EXATG 1993  | JET DRIVE UNIT                                               |
| E175EXATS 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175EXATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXATS 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175EXATS 1993  | JET DRIVE UNIT                                               |
| E175EXECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E175EXECD 1998  | GEARCASE -- COUNTER-ROTATION                                 |
| E175EXECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E175EXECD 1998  | JET DRIVE UNIT                                               |
| E175EXEDB 1996  | GEARCASE - COUNTER-ROTATION                                  |
| E175EXEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175EXEDB 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E175EXEDB 1996  | JET DRIVE UNIT                                               |
| E175EXEOM 1995  | GEARCASE - COUNTER ROTATION                                  |
| E175EXEOM 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXEOM 1995  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E175EXEOM 1995  | JET DRIVE UNIT                                               |
| E175EXERA 1994  | GEARCASE - COUNTER ROTATION                                  |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E175EXERA 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXERA 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175EXERA 1994  | JET DRIVE UNIT                                               |
| E175EXERV 1994  | GEARCASE - COUNTER ROTATION                                  |
| E175EXERV 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXERV 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175EXERV 1994  | JET DRIVE UNIT                                               |
| E175EXETG 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175EXETG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXETG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175EXETG 1993  | JET DRIVE UNIT                                               |
| E175EXETR 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175EXETR 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175EXETR 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175EXETR 1993  | JET DRIVE UNIT                                               |
| E175EXEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E175EXEUC 1997  | GEARCASE - COUNTER-ROTATION                                  |
| E175EXEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175EXEUC 1997  | JET DRIVE UNIT                                               |
| E175EXEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E175EXEUE 1997  | GEARCASE - COUNTER-ROTATION                                  |
| E175EXEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175EXEUE 1997  | JET DRIVE UNIT                                               |
| E175FCXECS 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| E175FCXECS 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| E175FCXECS 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| E175FCXEEC 1999 | GEARCASE -- STANDARD ROTATION -- FPL MODELS                  |
| E175FCXEEC 1999 | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS             |
| E175FCXEEC 1999 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| E175FCXEEN 1999 | GEARCASE -- STANDARD ROTATION -- FPL MODELS                  |
| E175FCXEEN 1999 | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS             |
| E175FCXEEN 1999 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| E175FCXEEO 1999 | GEARCASE -- STANDARD ROTATION -- FPL MODELS                  |

|                                                                       |                                                         |
|-----------------------------------------------------------------------|---------------------------------------------------------|
| E175FCXEEO 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E175FCXEEO 1999                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FCXSDS                                                            | GEARCASE - CX, MODELS                                   |
| E175FCXSDS - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles CX                  |
| E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FCXSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FCXSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX          |
| E175FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FPL - FPX MODELS                             |
| E175FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FCX, MODELS                                  |
| E175FCXSOD                                                            | GEARCASE - CX MODELS                                    |
| E175FCXSOD - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - CX MODELES                  |
| E175FCXSRE                                                            | GEARCASE - CX MODELS                                    |
| E175FCXSRE - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles CX                  |
| E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FCXSTB                                                            | GEARCASE - FCX, MODELS                                  |
| E175FCXSTB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FCXSTB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E175FCXSTB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E175FPLEEC 1999                                                       | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E175FPLEEC 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E175FPLEEC 1999                                                       | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FPLEEO 1999                                                       | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E175FPLEEO 1999                                                       | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |

|                                                           |                                                         |
|-----------------------------------------------------------|---------------------------------------------------------|
| E175FPLEEO 1999                                           | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FPLSDS                                                | GEARCASE - PL - SL MODELS                               |
| E175FPLSDS - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL              |
| E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001         | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001         | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001         | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FPLSNF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FPLSNF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX          |
| E175FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue, 2002 | GEARCASE - FPL - FPX MODELS                             |
| E175FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue, 2002 | GEARCASE - FCX, MODELS                                  |
| E175FPLSOD                                                | GEARCASE - PL - SL MODELS                               |
| E175FPLSOD - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES             |
| E175FPLSRE                                                | GEARCASE - PL - SL MODELS                               |
| E175FPLSRE - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL            |
| E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000        | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000        | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000        | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000        | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000        | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000        | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FPLSTB                                                | GEARCASE - FCX, MODELS                                  |
| E175FPLSTB                                                | GEARCASE - FPL - FSL - FPX MODELS                       |
| E175FPLSTB - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FPLSTB - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E175FPLSTB - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E175FPLSTF                                                | GEARCASE - STANDARD ROTATION - "F" Suffix Models        |
| E175FPLSTF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FPLSTF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E175FPLSTF - FR                                           | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E175FPXEEC 1999                                           | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E175FPXEEC 1999                                           | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E175FPXEEC 1999                                           | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FPXEEN 1999                                           | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E175FPXEEN 1999                                           | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |

|                                                            |                                                         |
|------------------------------------------------------------|---------------------------------------------------------|
| E175FPXEEN 1999                                            | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FPXEEO 1999                                            | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E175FPXEEO 1999                                            | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E175FPXEEO 1999                                            | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FPXSDS                                                 | GEARCASE - PX MODELS                                    |
| E175FPXSDS - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX                  |
| E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001     | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001     | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001     | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FPXSNF - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FPXSNF - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX          |
| E175FPXSNF Ficht Fuel Injection, 25 in. shaft, White, 2002 | GEARCASE - FPL - FPX MODELS                             |
| E175FPXSNF Ficht Fuel Injection, 25 in. shaft, White, 2002 | GEARCASE - FCX, MODELS                                  |
| E175FPXSOD                                                 | GEARCASE - PX MODELS                                    |
| E175FPXSOD - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - PX MODELES                  |
| E175FPXSRE                                                 | GEARCASE - PX MODELS                                    |
| E175FPXSRE - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX                  |
| E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FPXSTB                                                 | GEARCASE - FCX, MODELS                                  |
| E175FPXSTB                                                 | GEARCASE - FPL - FSL - FPX MODELS                       |
| E175FPXSTB - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FPXSTB - FR                                            | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E175FPXSTB - FR                                            | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E175FSLECS 1998                                            | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FSLECS 1998                                            | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS       |
| E175FSLECS 1998                                            | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS        |

|                                                         |                                                         |
|---------------------------------------------------------|---------------------------------------------------------|
| E175FSLEEO 1999                                         | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E175FSLEEO 1999                                         | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E175FSLEEO 1999                                         | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FSLEES 1999                                         | GEARCASE -- STANDARD ROTATION -- FPL MODELS             |
| E175FSLEES 1999                                         | GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS        |
| E175FSLEES 1999                                         | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FSLSD                                               | GEARCASE - PL - SL MODELS                               |
| E175FSLSD - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL              |
| E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FPL - FL MODELS          |
| E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FSLSOE                                              | GEARCASE - PL - SL MODELS                               |
| E175FSLSOE - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES             |
| E175FSLSRB                                              | GEARCASE - PL - SL MODELS                               |
| E175FSLSRB - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL            |
| E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS           |
| E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS  |
| E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS            |
| E175FSLSTF                                              | GEARCASE - STANDARD ROTATION - "F" Suffix Models        |
| E175FSLSTF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FSLSTF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E175FSLSTF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E175FSLSTM                                              | GEARCASE - FCX, MODELS                                  |
| E175FSLSTM                                              | GEARCASE - FPL - FSL - FPX MODELS                       |
| E175FSLSTM - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX                 |
| E175FSLSTM - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL       |
| E175FSLSTM - FR                                         | 07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation |
| E175FSXECS 1998                                         | GEARCASE -- COUNTER-ROTATION -- FCX MODELS              |
| E175FSXECS 1998                                         | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS       |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E175FSXECS 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| E175FTLECS 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| E175FTLECS 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| E175FTLECS 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| E175GLECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E175GLECD 1998  | GEARCASE -- COUNTER-ROTATION                                 |
| E175GLECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E175GLECD 1998  | JET DRIVE UNIT                                               |
| E175GLEDB 1996  | GEARCASE - COUNTER-ROTATION                                  |
| E175GLEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175GLEDB 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E175GLEDB 1996  | JET DRIVE UNIT                                               |
| E175GLEOM 1995  | GEARCASE - COUNTER ROTATION                                  |
| E175GLEOM 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175GLEOM 1995  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E175GLEOM 1995  | JET DRIVE UNIT                                               |
| E175GLERA 1994  | GEARCASE - COUNTER ROTATION                                  |
| E175GLERA 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175GLERA 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175GLERA 1994  | JET DRIVE UNIT                                               |
| E175GLETG 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175GLETG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175GLETG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175GLETG 1993  | JET DRIVE UNIT                                               |
| E175GLETR 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175GLETR 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175GLETR 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175GLETR 1993  | JET DRIVE UNIT                                               |
| E175GLEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E175GLEUC 1997  | GEARCASE - COUNTER-ROTATION                                  |
| E175GLEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175GLEUC 1997  | JET DRIVE UNIT                                               |
| E175GLEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E175GLEUE 1997  | GEARCASE - COUNTER-ROTATION                                  |
| E175GLEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175GLEUE 1997  | JET DRIVE UNIT                                               |
| E175MFXSOS      | GEARCASE - MFX MODELS                                        |
| E175MFXSOS - FR | 07-1_BOÎTIER D'ENGRENAGES - MFX MODELES                      |
| E175NXARC 1994  | GEARCASE - COUNTER ROTATION                                  |
| E175NXARC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXARC 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175NXARC 1994  | JET DRIVE UNIT                                               |
| E175NXARV 1994  | GEARCASE - COUNTER ROTATION                                  |
| E175NXARV 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXARV 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175NXARV 1994  | JET DRIVE UNIT                                               |
| E175NXATG 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175NXATG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXATG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175NXATG 1993  | JET DRIVE UNIT                                               |
| E175NXATS 1993  | GEARCASE - COUNTER ROTATION                                  |
| E175NXATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXATS 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175NXATS 1993  | JET DRIVE UNIT                                               |
| E175NXECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E175NXECD 1998  | GEARCASE -- COUNTER-ROTATION                                 |
| E175NXECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E175NXECD 1998  | JET DRIVE UNIT                                               |
| E175NXEDB 1996  | GEARCASE - COUNTER-ROTATION                                  |
| E175NXEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175NXEDB 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E175NXEDB 1996  | JET DRIVE UNIT                                               |
| E175NXEOM 1995  | GEARCASE - COUNTER ROTATION                                  |
| E175NXEOM 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXEOM 1995  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E175NXEOM 1995  | JET DRIVE UNIT                                               |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E175NXERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| E175NXERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175NXERA 1994 | JET DRIVE UNIT                                               |
| E175NXERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| E175NXERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175NXERV 1994 | JET DRIVE UNIT                                               |
| E175NXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| E175NXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175NXETG 1993 | JET DRIVE UNIT                                               |
| E175NXETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| E175NXETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175NXETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| E175NXETR 1993 | JET DRIVE UNIT                                               |
| E175NxEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E175NxEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E175NxEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175NxEUC 1997 | JET DRIVE UNIT                                               |
| E175NxEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E175NxEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E175NxEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175NxEUE 1997 | JET DRIVE UNIT                                               |
| E175SLECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| E175SLECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| E175SLECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| E175SLECD 1998 | JET DRIVE UNIT                                               |
| E175SLEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E175SLEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175SLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| E175SLEDB 1996 | JET DRIVE UNIT                                               |
| E175SLEOM 1995 | GEARCASE - COUNTER ROTATION                                  |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E175SLEOM 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175SLEOM 1995  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| E175SLEOM 1995  | JET DRIVE UNIT                                               |
| E175SLERA 1994  | GEARCASE - COUNTER ROTATION                                  |
| E175SLERA 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E175SLERA 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| E175SLERA 1994  | JET DRIVE UNIT                                               |
| E175SLEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E175SLEUC 1997  | GEARCASE - COUNTER-ROTATION                                  |
| E175SLEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175SLEUC 1997  | JET DRIVE UNIT                                               |
| E175SLEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| E175SLEUE 1997  | GEARCASE - COUNTER-ROTATION                                  |
| E175SLEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| E175SLEUE 1997  | JET DRIVE UNIT                                               |
| E185ESERK 1994  | GEARCASE - COUNTER ROTATION                                  |
| E185ESERK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E185ESERK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E185ESXETA 1993 | GEARCASE - COUNTER ROTATION                                  |
| E185ESXETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E185ESXETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E185ESXETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E185ESXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E185ESXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXARC 1994  | GEARCASE - COUNTER ROTATION                                  |
| E200CXARC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXARC 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXARK 1994  | GEARCASE - COUNTER ROTATION                                  |
| E200CXARK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXARK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXATF 1993  | GEARCASE - COUNTER ROTATION                                  |
| E200CXATF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXATF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E200CXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| E200CXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXECM 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E200CXECM 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E200CXECM 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E200CXEDR 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E200CXEDR 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXEDR 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXEOC 1995 | GEARCASE - COUNTER ROTATION                                  |
| E200CXEOC 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXEOC 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E200CXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXERS 1994 | GEARCASE - COUNTER ROTATION                                  |
| E200CXERS 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXERS 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXETD 1993 | GEARCASE - COUNTER ROTATION                                  |
| E200CXETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E200CXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CXEUA 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E200CXEUA 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CXEUA 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CZARK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E200CZARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CZARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CZATF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E200CZATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200CZATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200CZATS 1993 | GEARCASE - COUNTER ROTATION                                  |

|                                  |                                                        |
|----------------------------------|--------------------------------------------------------|
| E200CZATS 1993                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E200CZATS 1993                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E200CZEOC 1995                   | GEARCASE - COUNTER ROTATION                            |
| E200CZEOC 1995                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E200CZEOC 1995                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E200CZERK 1994                   | GEARCASE - COUNTER ROTATION                            |
| E200CZERK 1994                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E200CZERK 1994                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E200CZERS 1994                   | GEARCASE - COUNTER ROTATION                            |
| E200CZERS 1994                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E200CZERS 1994                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E200CZETD 1993                   | GEARCASE - COUNTER ROTATION                            |
| E200CZETD 1993                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E200CZETD 1993                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E200CZETF 1993                   | GEARCASE - COUNTER ROTATION                            |
| E200CZETF 1993                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E200CZETF 1993                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E200DCXAAA - (60 degree V6)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXAAA - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXAAB - (60 degree V6)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXAAB - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXAAC - (60 degree V6)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXAAC - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXABA                       | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXABA - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXABB                       | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXABF                       | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXABG                       | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXABH                       | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXABJ                       | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200DCXIIE - (60 degree V6)      | GEARCASE, M2-Type, Counter Rotation                    |
| E200DCXIIE - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXIND - (60 degree V6)      | GEARCASE, M2-Type, Counter Rotation                    |
| E200DCXIND - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXISB                       | GEARCASE                                               |

|                                         |                                                        |
|-----------------------------------------|--------------------------------------------------------|
| E200DCXISB - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXISF                              | GEARCASE                                               |
| E200DCXISF - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXSACA                             | GEARCASE                                               |
| E200DCXSACA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E200DCXSACF                             | GEARCASE                                               |
| E200DCXSACF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXSEM                              | GEARCASE                                               |
| E200DCXSEM - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200DCXSOC                              | GEARCASE CX, CZ MODELS                                 |
| E200DCXSOC - FR                         | 07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES               |
| E200DCXSUF                              | GEARCASE                                               |
| E200DCXSUF - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E200DCXSUR                              | GEARCASE                                               |
| E200DCXSUR - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E200DGLABB                              | 07-1_GEARCASE, O-Type                                  |
| E200DGLABF                              | 07-1_GEARCASE, O-Type                                  |
| E200DGLABG                              | 07-1_GEARCASE, O-Type                                  |
| E200DGLABH                              | 07-1_GEARCASE, M2-Type                                 |
| E200DGXABB                              | 07-1_GEARCASE, M2-Type                                 |
| E200DGXABF                              | 07-1_GEARCASE, M2-Type                                 |
| E200DGXABG                              | 07-1_GEARCASE, M2-Type                                 |
| E200DGXABH                              | 07-1_GEARCASE, M2-Type                                 |
| E200DHAAAA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| E200DHAAAA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E200DHLAAB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| E200DHLAAB - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E200DHLAAC - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| E200DHLAAC - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E200DHLAAD - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| E200DHLAAD - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E200DHLABA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| E200DHLABA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E200DHLABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                                 |
| E200DHLIID - (90 degree V6 3,3 L)       | GEARCASE, L2-Type                                      |

|                                          |                                       |
|------------------------------------------|---------------------------------------|
| E200DHLIID - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLINF - (90 degree V6, 3.3 L)       | GEARCASE, M2-Type                     |
| E200DHLINF - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLINS - (90 degree V6, 3.3 L)       | GEARCASE, L2-Type                     |
| E200DHLINS - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLISE - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLISE - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLISF - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLISF - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLSCF - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLSCF - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200DHLSCG - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLSCG - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLSCH - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLSCH - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLSCM - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLSCM - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200DHLSDF - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLSDF - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200DHLSEB - (90 degree V6 3,3 L)        | GEARCASE                              |
| E200DHLSEB - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200DHLSOC - (90 degree V6 3,3 L)        | GEARCASE - HL, HX MODELS (L Type)     |
| E200DHLSOC - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200DHLSOG - (90 degree V6 3,3 L)        | GEARCASE HL, HX. MODELS (XP Type)     |
| E200DHLSOG - (90 degree V6 3,3 L) - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200DHL SUA - (90 degree V6, 3.3 L)      | GEARCASE                              |
| E200DHL SUA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200DHL SUG - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHL SUG - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200DHXAAA - (90 degree V6, 3.3 L)       | 07-1_GEARCASE, M2-Type                |
| E200DHXAAA - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXAAB - (90 degree V6, 3.3 L)       | 07-1_GEARCASE, M2-Type                |
| E200DHXAAB - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXAAC - (90 degree V6, 3.3 L)       | 07-1_GEARCASE, M2-Type                |
| E200DHXAAC - (90 degree V6, 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |

|                                         |                                       |
|-----------------------------------------|---------------------------------------|
| E200DHXAAD - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200DHXAAD - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXABA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200DHXABA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200DHXABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200DHXABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200DHXABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200DHXIIB - (90 degree V6 3,3 L)       | GEARCASE, M2-Type                     |
| E200DHXIIB - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXINE - (90 degree V6, 3.3 L)      | GEARCASE, M2-Type                     |
| E200DHXINE - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXISF - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXISF - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXISM - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXISM - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXSCF - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXSCF - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E200DHXSCG - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXSCG - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXSCH - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXSCH - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXSCR - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXSCR - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E200DHXSDS - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXSDS - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E200DHXSEA - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXSEA - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200DHXsuc - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200DHXsuc - (90 degree V6 3.3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E200DPLAAA - (60 degree V6)             | 07-1_GEARCASE, O-Type                 |
| E200DPLAAA - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E200DPLAAB - (60 degree V6)             | 07-1_GEARCASE, O-Type                 |
| E200DPLAAB - (60 degree V6) - FR        | 07-1_BOÎTIER D'ENGRENAGES, de type O  |
| E200DPLABA                              | 07-1_GEARCASE, O-Type                 |

|                                  |                                                         |
|----------------------------------|---------------------------------------------------------|
| E200DPLABA - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLABB                       | 07-1_GEARCASE, O-Type                                   |
| E200DPLIIE - (60 degree V6)      | GEARCASE, O-Type                                        |
| E200DPLIIE - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLIND - (60 degree V6)      | GEARCASE, O-Type                                        |
| E200DPLIND - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLISB                       | GEARCASE - PL, SL MODELS                                |
| E200DPLISB - FR                  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLISF                       | GEARCASE - PL, SL MODELS                                |
| E200DPLISF - FR                  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLSCA                       | GEARCASE - PL, SL MODELS                                |
| E200DPLSCA - FR                  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLSEM                       | GEARCASE - PL, SL MODELS                                |
| E200DPLSEM - FR                  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLSOC                       | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E200DPLSOC - FR                  | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E200DPLSUF                       | GEARCASE - PL, SL MODELS                                |
| E200DPLSUF - FR                  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPLSUR                       | GEARCASE - PL, SL MODELS                                |
| E200DPLSUR - FR                  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DPXAAA - (60 degree V6)      | 07-1_GEARCASE, M2-Type                                  |
| E200DPXAAA - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXAAB - (60 degree V6)      | 07-1_GEARCASE, M2-Type                                  |
| E200DPXAAB - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXAAC - (60 degree V6)      | 07-1_GEARCASE, M2-Type                                  |
| E200DPXAAC - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXABA                       | 07-1_GEARCASE, M2-Type                                  |
| E200DPXABA - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXABB                       | 07-1_GEARCASE, M2-Type                                  |
| E200DPXABF                       | 07-1_GEARCASE, M2-Type                                  |
| E200DPXABG                       | 07-1_GEARCASE, M2-Type                                  |
| E200DPXABH                       | 07-1_GEARCASE, M2-Type                                  |
| E200DPXABJ                       | 07-1_GEARCASE, M2-Type                                  |
| E200DPXIIE - (60 degree V6)      | GEARCASE, M2-Type                                       |
| E200DPXIIE - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |

|                                   |                                                         |
|-----------------------------------|---------------------------------------------------------|
| E200DPXIND - (60 degree V6)       | GEARCASE, M2-Type                                       |
| E200DPXIND - (60 degree V6) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXISB                        | GEARCASE                                                |
| E200DPXISB - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXISF                        | GEARCASE                                                |
| E200DPXISF - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXSCA                        | GEARCASE                                                |
| E200DPXSCA - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E200DPXSCF                        | GEARCASE                                                |
| E200DPXSCF - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXSEM                        | GEARCASE                                                |
| E200DPXSEM - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E200DPXSOC                        | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E200DPXSOC - FR                   | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E200DPXSUF                        | GEARCASE                                                |
| E200DPXSUF - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E200DPXSUR                        | GEARCASE                                                |
| E200DPXSUR - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E200DSLAAA - (60 degree V6)       | 07-1_GEARCASE, O-Type                                   |
| E200DSLAAA - (60 degree V6) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DSLAAAB - (60 degree V6)      | 07-1_GEARCASE, O-Type                                   |
| E200DSLAAAB - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DSLABA                        | 07-1_GEARCASE, O-Type                                   |
| E200DSLABA - (60 degree V6) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DSLABB                        | 07-1_GEARCASE, O-Type                                   |
| E200DSLABF                        | 07-1_GEARCASE, O-Type                                   |
| E200DSLABG                        | 07-1_GEARCASE, O-Type                                   |
| E200DSLABH                        | 07-1_GEARCASE, M2-Type                                  |
| E200DSLABJ                        | 07-1_GEARCASE, O-Type                                   |
| E200DSLIIIE - (60 degree V6)      | GEARCASE, O-Type                                        |
| E200DSLIIIE - (60 degree V6) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DSLIND - (60 degree V6)       | GEARCASE, O-Type                                        |
| E200DSLIND - (60 degree V6) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |
| E200DSLISB                        | GEARCASE - PL, SL MODELS                                |
| E200DSLISB - FR                   | 07-1_BOÎTIER D'ENGRENAGES, de type O                    |

|                                                                      |                                                           |
|----------------------------------------------------------------------|-----------------------------------------------------------|
| E200DSLISF                                                           | GEARCASE - PL, SL MODELS                                  |
| E200DSLISF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type O                      |
| E200DSLSCA                                                           | GEARCASE - PL, SL MODELS                                  |
| E200DSLSCA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type O                      |
| E200DSLSEM                                                           | GEARCASE - PL, SL MODELS                                  |
| E200DSLSEM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type O                      |
| E200DSLSOC                                                           | GEARCASE PL, SL,PX,PZ MODELS (M Type)                     |
| E200DSLSOC - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)   |
| E200DLSUF                                                            | GEARCASE - PL, SL MODELS                                  |
| E200DLSUF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type O                      |
| E200DLSUR                                                            | GEARCASE - PL, SL MODELS                                  |
| E200DLSUR - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES, de type O                      |
| E200FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000   | GEARCASE - Counter Rotation                               |
| E200FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000   | GEARCASE - Counter Rotation                               |
| E200FCXEEN 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FCXEEN 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FCXEEN 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FCXEES 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FCXEES 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FCXEES 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - Counter Rotation                               |
| E200FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E200FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E200FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E200FCXSOE                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E200FCXSOE - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES              |
| E200FCXSRB                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E200FCXSRB - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |

|                                                                     |                                                           |
|---------------------------------------------------------------------|-----------------------------------------------------------|
| E200FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000 | GEARCASE - Counter Rotation                               |
| E200FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000 | GEARCASE - Counter Rotation                               |
| E200FCXSTM                                                          | GEARCASE - FCX & FCZ MODELS                               |
| E200FCXSTM                                                          | GEARCASE - FHL MODEL                                      |
| E200FCXSTM                                                          | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FCXSTM - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E200FCXSTM - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FCXSTM - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E200FHLSOR                                                          | GEARCASE - FHL, FHX MODELS                                |
| E200FHLSOR - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - FHL, FHX MODELES              |
| E200FHLSRC                                                          | GEARCASE - FHL, FHX MODELS                                |
| E200FHLSRC - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX            |
| E200FHLSTS                                                          | GEARCASE - FCX & FCZ MODELS                               |
| E200FHLSTS                                                          | GEARCASE - FHL MODEL                                      |
| E200FHLSTS                                                          | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FHLSTS - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E200FHLSTS - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FHLSTS - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E200FPLEEN 1999                                                     | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FPLEEN 1999                                                     | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FPLEEN 1999                                                     | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FPLEES 1999                                                     | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FPLEES 1999                                                     | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FPLEES 1999                                                     | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - Counter Rotation                               |
| E200FPLSNF - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E200FPLSNF - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FPLSNF - FR                                                     | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002             | GEARCASE - FHL MODEL                                      |
| E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002             | GEARCASE - FPL - FPX - FPZ MODELS                         |

|                                                          |                                                           |
|----------------------------------------------------------|-----------------------------------------------------------|
| E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002  | GEARCASE - FCX & FCZ MODELS                               |
| E200FPLSOE                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FPLSOE - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E200FPLSRB                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FPLSRB - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E200FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000        | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000        | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FPLSTM                                               | GEARCASE - FCX & FCZ MODELS                               |
| E200FPLSTM                                               | GEARCASE - FHL MODEL                                      |
| E200FPLSTM                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FPLSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E200FPLSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FPLSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E200FPXEEN 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FPXEEN 1999                                          | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FPXEEN 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FPXEES 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FPXEES 1999                                          | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FPXEES 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001        | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001        | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001        | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001        | GEARCASE - Counter Rotation                               |
| E200FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E200FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002 | GEARCASE - FHL MODEL                                      |
| E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E200FPXSOE                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FPXSOE - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E200FPXSRB                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |

|                                                        |                                                           |
|--------------------------------------------------------|-----------------------------------------------------------|
| E200FPXSRB - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E200FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E200FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E200FPXSTM                                             | GEARCASE - FCX & FCZ MODELS                               |
| E200FPXSTM                                             | GEARCASE - FHL MODEL                                      |
| E200FPXSTM                                             | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FPXSTM - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E200FPXSTM - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FPXSTM - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E200FSLEEN 1999                                        | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FSLEEN 1999                                        | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FSLEEN 1999                                        | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FSLEES 1999                                        | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E200FSLEES 1999                                        | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E200FSLEES 1999                                        | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001 | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001 | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001 | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001 | GEARCASE - Counter Rotation                               |
| E200FSLSOE                                             | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FSLSOE - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E200FSLSRB                                             | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FSLSRB - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E200FSLSSC FFI, Elec Start, TNT, 20 IN shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FSLSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000 | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E200FSLSTM                                             | GEARCASE - FCX & FCZ MODELS                               |
| E200FSLSTM                                             | GEARCASE - FHL MODEL                                      |
| E200FSLSTM                                             | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E200FSLSTM - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E200FSLSTM - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E200FSLSTM - FR                                        | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E200HCXAAA - (90 degree V6, 3.3 L)                     | 07-1_GEARCASE, M2-Type, Counter Rotation                  |

|                                         |                                                        |
|-----------------------------------------|--------------------------------------------------------|
| E200HCXAAA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXAAB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXAAB - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXAAC - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXAAC - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXAAD - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXAAD - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXABA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXABA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E200HCXIIB - (90 degree V6 3,3 L)       | GEARCASE, M2-Type, Counter Rotation                    |
| E200HCXIIB - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXINE - (90 degree V6, 3.3 L)      | GEARCASE, M2-Type, Counter Rotation                    |
| E200HCXINE - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXISF - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXISF - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXISM - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXISM - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXSFC - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXSFC - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E200HCXSCG - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXSCG - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXSCH - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXSCH - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXSCR - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXSCR - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E200HCXSDS - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXSDS - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E200HCXSEA - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXSEA - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E200HCXSUC - (90 degree V6 3,3 L)       | GEARCASE                                               |
| E200HCXSUC - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |

|                                         |                                       |
|-----------------------------------------|---------------------------------------|
| E200HGLABA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HGLABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HGLABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HGLABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HGLABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLAAA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLAAA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200HSLAAB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLAAB - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200HSLAAC - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLAAC - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200HSLAAD - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLAAD - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200HSLABA - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLABA - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200HSLABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type                |
| E200HSLIIB - (90 degree V6 3,3 L)       | GEARCASE, L2-Type                     |
| E200HSLIIB - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E200HSLINE - (90 degree V6, 3.3 L)      | GEARCASE, L2-Type                     |
| E200HSLINE - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200HSLINF - (90 degree V6, 3.3 L)      | GEARCASE, M2-Type                     |
| E200HSLINF - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200HSLISF - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200HSLISF - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200HSLISM - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200HSLISM - (90 degree V6, 3.3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200HSLSCF - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200HSLSCF - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E200HSLSCG - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200HSLSCG - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E200HLSLCH - (90 degree V6 3,3 L)       | GEARCASE                              |
| E200HLSLCH - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |

|                                         |                                                              |
|-----------------------------------------|--------------------------------------------------------------|
| E200HSLSCR - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HSLSCR - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L                         |
| E200HSLSDS - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HSLSDS - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L                         |
| E200HSLSEA - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HSLSEA - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E200HSLSUC - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HSLSUC - (90 degree V6, 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L                         |
| E200HVLIIA - (90 degree V6 3,3 L)       | GEARCASE, M2-Type                                            |
| E200HVLIIA - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E200HVLINM - (90 degree V6, 3,3 L)      | GEARCASE, M2-Type                                            |
| E200HVLINM - (90 degree V6, 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E200HVLISF - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HVLISF - (90 degree V6, 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E200HVLISR - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HVLISR - (90 degree V6, 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E200HVLSCF - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HVLSCF - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M                         |
| E200HVLSCG - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HVLSCG - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E200HVLSCH - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HVLSCH - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E200HVLSCS - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HVLSCS - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M                         |
| E200HVLSEC - (90 degree V6 3,3 L)       | GEARCASE                                                     |
| E200HVLSEC - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E200STLECE 1998                         | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E200STLECE 1998                         | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E200STLECE 1998                         | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E200STLEDM 1996                         | GEARCASE - COUNTER-ROTATION                                  |
| E200STLEDM 1996                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200STLEDM 1996                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200STLEOA 1995                         | GEARCASE - COUNTER ROTATION                                  |
| E200STLEOA 1995                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E200STLEOA 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200STLERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E200STLERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200STLERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200STLERR 1994 | GEARCASE - COUNTER ROTATION                                  |
| E200STLERR 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200STLERR 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200STLETC 1993 | GEARCASE - COUNTER ROTATION                                  |
| E200STLETC 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200STLETC 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200STLETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E200STLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200STLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200STLEUB 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E200STLEUB 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200STLEUB 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200TLECM 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E200TLECM 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E200TLECM 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E200TXARC 1994  | GEARCASE - COUNTER ROTATION                                  |
| E200TXARC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200TXARC 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200TXARK 1994  | GEARCASE - COUNTER ROTATION                                  |
| E200TXARK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200TXARK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200TXATF 1993  | GEARCASE - COUNTER ROTATION                                  |
| E200TXATF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200TXATF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200TXATS 1993  | GEARCASE - COUNTER ROTATION                                  |
| E200TXATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E200TXATS 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E200TXECM 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E200TXECM 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E200TXECM 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |

|                |                                                       |
|----------------|-------------------------------------------------------|
| E200TXEDR 1996 | GEARCASE - COUNTER-ROTATION                           |
| E200TXEDR 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TXEDR 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TXEOC 1995 | GEARCASE - COUNTER ROTATION                           |
| E200TXEOC 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TXEOC 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TXERK 1994 | GEARCASE - COUNTER ROTATION                           |
| E200TXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TXERS 1994 | GEARCASE - COUNTER ROTATION                           |
| E200TXERS 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TXERS 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TXETD 1993 | GEARCASE - COUNTER ROTATION                           |
| E200TXETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TXETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TXETF 1993 | GEARCASE - COUNTER ROTATION                           |
| E200TXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TXEUA 1997 | GEARCASE - COUNTER-ROTATION                           |
| E200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TZARK 1994 | GEARCASE - COUNTER ROTATION                           |
| E200TZARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TZARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TZATF 1993 | GEARCASE - COUNTER ROTATION                           |
| E200TZATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TZATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TZATS 1993 | GEARCASE - COUNTER ROTATION                           |
| E200TZATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TZATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TZEOC 1995 | GEARCASE - COUNTER ROTATION                           |
| E200TZEOC 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E200TZEOC 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E200TZERK 1994 | GEARCASE - COUNTER ROTATION                           |
| E200TZERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |

|                                                             |                                                                 |
|-------------------------------------------------------------|-----------------------------------------------------------------|
| E200TZERK 1994                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E200TZERS 1994                                              | GEARCASE - COUNTER ROTATION                                     |
| E200TZERS 1994                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E200TZERS 1994                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E200TZETD 1993                                              | GEARCASE - COUNTER ROTATION                                     |
| E200TZETD 1993                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E200TZETD 1993                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E200TZETF 1993                                              | GEARCASE - COUNTER ROTATION                                     |
| E200TZETF 1993                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E200TZETF 1993                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E200WPXEEN 1999                                             | GEARCASE                                                        |
| E200WPXEES 1999                                             | GEARCASE                                                        |
| E200WPXSIF commercial, elec start, TNT, 25 in shaft<br>2001 | GEARCASE                                                        |
| E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft<br>2000 | GEARCASE                                                        |
| E225CXARC 1994                                              | GEARCASE - COUNTER ROTATION                                     |
| E225CXARC 1994                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E225CXARC 1994                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E225CXARK 1994                                              | GEARCASE - COUNTER ROTATION                                     |
| E225CXARK 1994                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E225CXARK 1994                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E225CXATF 1993                                              | GEARCASE - COUNTER ROTATION                                     |
| E225CXATF 1993                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E225CXATF 1993                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E225CXATS 1993                                              | GEARCASE - COUNTER ROTATION                                     |
| E225CXATS 1993                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E225CXATS 1993                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E225CXECS 1998                                              | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX<br>MODELS |
| E225CXECS 1998                                              | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS               |
| E225CXECS 1998                                              | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS           |
| E225CXEDE 1996                                              | GEARCASE - COUNTER-ROTATION                                     |
| E225CXEDE 1996                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| E225CXEDE 1996                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| E225CXEOB 1995                                              | GEARCASE - COUNTER ROTATION                                     |
| E225CXEOB 1995                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E225CXEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CXERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225CXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CXERM 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225CXERM 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CXERM 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CXETA 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225CXETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CXETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CXETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225CXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CXEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E225CXEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CXEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CZARK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225CZARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CZARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CZATF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225CZATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CZATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CZATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225CZATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CZATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CZECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E225CZECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E225CZECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E225CZEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E225CZEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CZEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225CZEOB 1995 | GEARCASE - COUNTER ROTATION                                  |
| E225CZEOB 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225CZEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| E225CZERK 1994                         | GEARCASE - COUNTER ROTATION                            |
| E225CZERK 1994                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E225CZERK 1994                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E225CZERM 1994                         | GEARCASE - COUNTER ROTATION                            |
| E225CZERM 1994                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E225CZERM 1994                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E225CZETA 1993                         | GEARCASE - COUNTER ROTATION                            |
| E225CZETA 1993                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E225CZETA 1993                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E225CZETF 1993                         | GEARCASE - COUNTER ROTATION                            |
| E225CZETF 1993                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E225CZETF 1993                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E225CZEUD 1997                         | GEARCASE - COUNTER-ROTATION                            |
| E225CZEUD 1997                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| E225CZEUD 1997                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| E225DCXAAA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXAAB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXAAC                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXAAD                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXABA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXABA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXABB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E225DCXIID                             | GEARCASE, M2-Type, Counter Rotation                    |
| E225DCXIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXINS                             | GEARCASE, M2-Type, Counter Rotation                    |
| E225DCXINS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXISE                             | GEARCASE                                               |
| E225DCXISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| E225DCXISF                             | GEARCASE                                               |
| E225DCXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXSCF                             | GEARCASE                                               |
| E225DCXSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCXSCG                             | GEARCASE                                               |
| E225DCXSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXSCH                             | GEARCASE                                               |
| E225DCXSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXSCM                             | GEARCASE                                               |
| E225DCXSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCXSDR                             | GEARCASE                                               |
| E225DCXSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCXSEB                             | GEARCASE                                               |
| E225DCXSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCXSOC                             | GEARCASE CX, CZ MODELS                                 |
| E225DCXSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES               |
| E225DCXSUA                             | GEARCASE                                               |
| E225DCXSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCZIID                             | GEARCASE, M2-Type, Counter Rotation                    |
| E225DCZIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCZINS                             | GEARCASE, M2-Type, Counter Rotation                    |
| E225DCZINS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCZISE                             | GEARCASE                                               |
| E225DCZISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCZISF                             | GEARCASE                                               |
| E225DCZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCZSCF                             | GEARCASE                                               |
| E225DCZSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCZSCG                             | GEARCASE                                               |
| E225DCZSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCZSCH                             | GEARCASE                                               |
| E225DCZSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCZSCM                             | GEARCASE                                               |
| E225DCZSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCZSDR                             | GEARCASE                                               |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| E225DCZSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCZSEB                             | GEARCASE                                               |
| E225DCZSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E225DCZSOC                             | GEARCASE CX, CZ MODELS                                 |
| E225DCZSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES               |
| E225DCZSUA                             | GEARCASE                                               |
| E225DCZSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DCZSUG                             | GEARCASE                                               |
| E225DCZSUG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E225DHAAAA                             | 07-1_GEARCASE, M2-Type                                 |
| E225DHAAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E225DHAAAB                             | 07-1_GEARCASE, M2-Type                                 |
| E225DHAAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E225DHAAAC                             | 07-1_GEARCASE, M2-Type                                 |
| E225DHAAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E225DHAAAD                             | 07-1_GEARCASE, M2-Type                                 |
| E225DHAAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E225DHABAA                             | 07-1_GEARCASE, M2-Type                                 |
| E225DHABAB                             | 07-1_GEARCASE, M2-Type                                 |
| E225DHAAID                             | GEARCASE, M2-Type                                      |
| E225DHAAID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E225DHALINS                            | GEARCASE, M2-Type                                      |
| E225DHALINS - FR                       | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E225DHALISE                            | GEARCASE                                               |
| E225DHALISE - FR                       | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E225DHALISF                            | GEARCASE                                               |
| E225DHALISF - FR                       | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E225DHLSCF                             | GEARCASE                                               |
| E225DHLSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L                   |
| E225DHLSG                              | GEARCASE                                               |
| E225DHLSG - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E225DHLSCH                             | GEARCASE                                               |
| E225DHLSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2                  |
| E225DHLSCHM                            | GEARCASE                                               |
| E225DHLSCHM - FR                       | 07-1_BOÎTIER D'ENGRENAGES, de type L                   |

|                                        |                                       |
|----------------------------------------|---------------------------------------|
| E225DHLSDF                             | GEARCASE                              |
| E225DHLSDF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHLSEB                             | GEARCASE                              |
| E225DHLSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E225DHLSOC                             | GEARCASE - HL, HX MODELS (L Type)     |
| E225DHLSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHLSOF                             | GEARCASE PL, SL,PX,PZ MODELS (M Type) |
| E225DHLSOF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHLSOG                             | GEARCASE HL, HX. MODELS (XP Type)     |
| E225DHLSOG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHLSUA                             | GEARCASE                              |
| E225DHLSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHLSUG                             | GEARCASE                              |
| E225DHLSUG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHXAAA                             | 07-1_GEARCASE, M2-Type                |
| E225DHXAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DHXAAB                             | 07-1_GEARCASE, M2-Type                |
| E225DHXAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DHXAAC                             | 07-1_GEARCASE, M2-Type                |
| E225DHXAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DHXAAD                             | 07-1_GEARCASE, M2-Type                |
| E225DHXAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DHXABA                             | 07-1_GEARCASE, M2-Type                |
| E225DHXABB                             | 07-1_GEARCASE, M2-Type                |
| E225DHXIIE                             | GEARCASE, M2-Type                     |
| E225DHXIIE - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DHXIND                             | GEARCASE, M2-Type                     |
| E225DHXIND - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DHXISB                             | GEARCASE                              |
| E225DHXISB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E225DHXISF                             | GEARCASE                              |
| E225DHXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E225DHXSCA                             | GEARCASE                              |
| E225DHXSCA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHXSCF                             | GEARCASE                              |

|                                        |                                       |
|----------------------------------------|---------------------------------------|
| E225DHXSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHXSCG                             | GEARCASE                              |
| E225DHXSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E225DHXSCH                             | GEARCASE                              |
| E225DHXSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E225DHXSDF                             | GEARCASE                              |
| E225DHXSDF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHXSEM                             | GEARCASE                              |
| E225DHXSEM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E225DHXSOC                             | GEARCASE - HL, HX MODELS (L Type)     |
| E225DHXSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHXSOG                             | GEARCASE HL, HX. MODELS (XP Type)     |
| E225DHXSOG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L  |
| E225DHXUG                              | GEARCASE                              |
| E225DHXUG - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E225DHXUR                              | GEARCASE                              |
| E225DHXUR - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E225DPLIID                             | GEARCASE, M2-Type                     |
| E225DPLIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DPLINS                             | GEARCASE, M2-Type                     |
| E225DPLINS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DPLISE                             | GEARCASE                              |
| E225DPLISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DPLISF                             | GEARCASE                              |
| E225DPLISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DPLSCF                             | GEARCASE                              |
| E225DPLSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E225DPLSCG                             | GEARCASE                              |
| E225DPLSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DPLSCH                             | GEARCASE                              |
| E225DPLSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E225DPLSCM                             | GEARCASE                              |
| E225DPLSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M  |
| E225DPLSDR                             | GEARCASE                              |
| E225DPLSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M  |

|                                        |                                                         |
|----------------------------------------|---------------------------------------------------------|
| E225DPLSEB                             | GEARCASE                                                |
| E225DPLSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPLSOC                             | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E225DPLSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E225DPLSUA                             | GEARCASE                                                |
| E225DPLSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPLSUG                             | GEARCASE                                                |
| E225DPLSUG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPXAAA                             | 07-1_GEARCASE, M2-Type                                  |
| E225DPXAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXAAB                             | 07-1_GEARCASE, M2-Type                                  |
| E225DPXAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXAAC                             | 07-1_GEARCASE, M2-Type                                  |
| E225DPXAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXAAD                             | 07-1_GEARCASE, M2-Type                                  |
| E225DPXAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXABA                             | 07-1_GEARCASE, M2-Type                                  |
| E225DPXABB                             | 07-1_GEARCASE, M2-Type                                  |
| E225DPXABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E225DPXABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E225DPXABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E225DPXIID                             | GEARCASE, M2-Type                                       |
| E225DPXIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXINS                             | GEARCASE, M2-Type                                       |
| E225DPXINS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXISE                             | GEARCASE                                                |
| E225DPXISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXISF                             | GEARCASE                                                |
| E225DPXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXSCF                             | GEARCASE                                                |
| E225DPXSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPXSCG                             | GEARCASE                                                |
| E225DPXSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXSCH                             | GEARCASE                                                |
| E225DPXSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |

|                                        |                                                         |
|----------------------------------------|---------------------------------------------------------|
| E225DPXSCM                             | GEARCASE                                                |
| E225DPXSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPXSDR                             | GEARCASE                                                |
| E225DPXSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPXSEB                             | GEARCASE                                                |
| E225DPXSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPXSOC                             | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E225DPXSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E225DPXSUA                             | GEARCASE                                                |
| E225DPXSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPXSUG                             | GEARCASE                                                |
| E225DPXSUG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPZIID                             | GEARCASE, M2-Type                                       |
| E225DPZIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPZINS                             | GEARCASE, M2-Type                                       |
| E225DPZINS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPZISE                             | GEARCASE                                                |
| E225DPZISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPZISF                             | GEARCASE                                                |
| E225DPZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPZSCF                             | GEARCASE                                                |
| E225DPZSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPZSCG                             | GEARCASE                                                |
| E225DPZSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPZSCH                             | GEARCASE                                                |
| E225DPZSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPZSCM                             | GEARCASE                                                |
| E225DPZSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPZSDR                             | GEARCASE                                                |
| E225DPZSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E225DPZSEB                             | GEARCASE                                                |
| E225DPZSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E225DPZSOC                             | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E225DPZSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E225DPZSUA                             | GEARCASE                                                |

|                                                                      |                                                           |
|----------------------------------------------------------------------|-----------------------------------------------------------|
| E225DPZSUA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type M                      |
| E225FCXEEN 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FCXEEN 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FCXEEN 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FCXEEO 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FCXEEO 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FCXEEO 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FCXEES 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FCXEES 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FCXEES 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - Counter Rotation                               |
| E225FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FHL MODEL                                      |
| E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E225FCXSOE                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E225FCXSOE - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES              |
| E225FCXSRB                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E225FCXSRB - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000  | GEARCASE - Counter Rotation                               |
| E225FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000  | GEARCASE - Counter Rotation                               |
| E225FCXSTM                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E225FCXSTM                                                           | GEARCASE - FHL MODEL                                      |
| E225FCXSTM                                                           | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FCXSTM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E225FCXSTM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |

|                                                                      |                                                           |
|----------------------------------------------------------------------|-----------------------------------------------------------|
| E225FCXSTM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E225FCZEEN 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FCZEEN 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FCZEEN 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FCZEEO 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FCZEEO 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FCZEEO 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FCZEES 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FCZEES 1999                                                      | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FCZEES 1999                                                      | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - Counter Rotation                               |
| E225FCZSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FCZSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FCZSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002 | GEARCASE - FHL MODEL                                      |
| E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E225FCZSOE                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E225FCZSOE - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES              |
| E225FCZSRB                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E225FCZSRB - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FCZSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000  | GEARCASE - Counter Rotation                               |
| E225FCZSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000  | GEARCASE - Counter Rotation                               |
| E225FCZSTM                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E225FCZSTM                                                           | GEARCASE - FHL MODEL                                      |
| E225FCZSTM                                                           | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FCZSTM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E225FCZSTM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |

|                                                               |                                                           |
|---------------------------------------------------------------|-----------------------------------------------------------|
| E225FCZSTM - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E225FGLSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000      | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FGLSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000      | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001             | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001             | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001             | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001             | GEARCASE - Counter Rotation                               |
| E225FHLSNF - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FHLSNF - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FHLSNF - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002 | GEARCASE - FHL MODEL                                      |
| E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E225FHLSOB                                                    | GEARCASE - FHL, FHX MODELS                                |
| E225FHLSOB - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - FHL, FHX MODELES              |
| E225FHLSRM                                                    | GEARCASE - FHL, FHX MODELS                                |
| E225FHLSRM - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX            |
| E225FHLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E225FHLSTA                                                    | GEARCASE - FCX & FCZ MODELS                               |
| E225FHLSTA                                                    | GEARCASE - FHL MODEL                                      |
| E225FHLSTA                                                    | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FHLSTA - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E225FHLSTA - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FHLSTA - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E225FHXSOC                                                    | GEARCASE - FHL, FHX MODELS                                |
| E225FHXSOC - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - FHL, FHX MODELES              |
| E225FHXSRS                                                    | GEARCASE - FHL, FHX MODELS                                |
| E225FHXSRS - FR                                               | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX            |
| E225FPLEEN 1999                                               | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPLEEN 1999                                               | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPLEEN 1999                                               | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |

|                                                         |                                                           |
|---------------------------------------------------------|-----------------------------------------------------------|
| E225FPLEEO 1999                                         | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPLEEO 1999                                         | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPLEEO 1999                                         | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FPLEES 1999                                         | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPLEES 1999                                         | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPLEES 1999                                         | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FPLSIF FFI                                          | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FPLSNF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FPLSNF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FPLSNF - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002 | GEARCASE - FHL MODEL                                      |
| E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E225FPLSOE                                              | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPLSOE - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E225FPLSRB                                              | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPLSRB - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E225FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000       | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000       | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FPLSTM                                              | GEARCASE - FCX & FCZ MODELS                               |
| E225FPLSTM                                              | GEARCASE - FHL MODEL                                      |
| E225FPLSTM                                              | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPLSTM - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E225FPLSTM - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FPLSTM - FR                                         | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E225FPXEEN 1999                                         | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPXEEN 1999                                         | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPXEEN 1999                                         | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FPXEEO 1999                                         | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPXEEO 1999                                         | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPXEEO 1999                                         | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FPXEES 1999                                         | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPXEES 1999                                         | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPXEES 1999                                         | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |

|                                                          |                                                           |
|----------------------------------------------------------|-----------------------------------------------------------|
| E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - Counter Rotation                               |
| E225FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002 | GEARCASE - FHL MODEL                                      |
| E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E225FPXSOE                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPXSOE - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E225FPXSRB                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPXSRB - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E225FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FPXSTM                                               | GEARCASE - FCX & FCZ MODELS                               |
| E225FPXSTM                                               | GEARCASE - FHL MODEL                                      |
| E225FPXSTM                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPXSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E225FPXSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FPXSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E225FPZEEN 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPZEEN 1999                                          | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPZEEN 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FPZEEO 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPZEEO 1999                                          | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPZEEO 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FPZEES 1999                                          | GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS          |
| E225FPZEES 1999                                          | GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS          |
| E225FPZEES 1999                                          | GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS           |
| E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |

|                                                          |                                                           |
|----------------------------------------------------------|-----------------------------------------------------------|
| E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001   | GEARCASE - Counter Rotation                               |
| E225FPZSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E225FPZSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FPZSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002 | GEARCASE - FHL MODEL                                      |
| E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E225FPZSOE                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPZSOE - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E225FPZSRB                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPZSRB - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E225FPZSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FPZSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E225FPZSTM                                               | GEARCASE - FCX & FCZ MODELS                               |
| E225FPZSTM                                               | GEARCASE - FHL MODEL                                      |
| E225FPZSTM                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E225FPZSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E225FPZSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E225FPZSTM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E225HGLABA                                               | 07-1_GEARCASE, M2-Type                                    |
| E225HGLABB                                               | 07-1_GEARCASE, M2-Type                                    |
| E225HGLABF - (90 degree V6, 3.3 L)                       | 07-1_GEARCASE, M2-Type                                    |
| E225HGLABG - (90 degree V6, 3.3 L)                       | 07-1_GEARCASE, M2-Type                                    |
| E225HGLABH - (90 degree V6, 3.3 L)                       | 07-1_GEARCASE, M2-Type                                    |
| E225HGXABF - (90 degree V6, 3.3 L)                       | 07-1_GEARCASE, M2-Type                                    |
| E225HGXABG - (90 degree V6, 3.3 L)                       | 07-1_GEARCASE, M2-Type                                    |
| E225HGXABH - (90 degree V6, 3.3 L)                       | 07-1_GEARCASE, M2-Type                                    |
| E225HSLAAA                                               | 07-1_GEARCASE, M2-Type                                    |
| E225HSLAAA - FR                                          | 07-1_BOÎTIER D'ENGRENAGES, de type M2                     |
| E225HSLAAB                                               | 07-1_GEARCASE, M2-Type                                    |

|                                        |                                                       |
|----------------------------------------|-------------------------------------------------------|
| E225HSLAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                 |
| E225HSLAAC                             | 07-1_GEARCASE, M2-Type                                |
| E225HSLAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                 |
| E225HSLAAD                             | 07-1_GEARCASE, M2-Type                                |
| E225HSLAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                 |
| E225HSLABA                             | 07-1_GEARCASE, M2-Type                                |
| E225HSLABB                             | 07-1_GEARCASE, M2-Type                                |
| E225HSLABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                |
| E225HSLABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                |
| E225HSLABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                |
| E225HSLIIA                             | GEARCASE, M2-Type                                     |
| E225HSLIIA - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                 |
| E225HSLINM                             | GEARCASE, M2-Type                                     |
| E225HSLINM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                 |
| E225HSLISF                             | GEARCASE                                              |
| E225HSLISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2                 |
| E225HSLISR                             | GEARCASE                                              |
| E225HSLISR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2                 |
| E225HSLSCF                             | GEARCASE                                              |
| E225HSLSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                  |
| E225HSLSCG                             | GEARCASE                                              |
| E225HSLSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2                 |
| E225HSLSCH                             | GEARCASE                                              |
| E225HSLSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2                 |
| E225HSLSCS                             | GEARCASE                                              |
| E225HSLSCS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2                 |
| E225HSLSEC                             | GEARCASE                                              |
| E225HSLSEC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type L2                 |
| E225PLERK 1994                         | GEARCASE - COUNTER ROTATION                           |
| E225PLERK 1994                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PLERK 1994                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PLERM 1994                         | GEARCASE - COUNTER ROTATION                           |
| E225PLERM 1994                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PLERM 1994                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PLETA 1993                         | GEARCASE - COUNTER ROTATION                           |

|                |                                                       |
|----------------|-------------------------------------------------------|
| E225PLETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PLETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PLETF 1993 | GEARCASE - COUNTER ROTATION                           |
| E225PLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXARC 1994 | GEARCASE - COUNTER ROTATION                           |
| E225PXARC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXARC 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXARK 1994 | GEARCASE - COUNTER ROTATION                           |
| E225PXARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXATF 1993 | GEARCASE - COUNTER ROTATION                           |
| E225PXATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXATS 1993 | GEARCASE - COUNTER ROTATION                           |
| E225PXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXEDE 1996 | GEARCASE - COUNTER-ROTATION                           |
| E225PXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXEOB 1995 | GEARCASE - COUNTER ROTATION                           |
| E225PXEOB 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXERK 1994 | GEARCASE - COUNTER ROTATION                           |
| E225PXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXERM 1994 | GEARCASE - COUNTER ROTATION                           |
| E225PXERM 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXERM 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXETA 1993 | GEARCASE - COUNTER ROTATION                           |
| E225PXETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225PXETF 1993 | GEARCASE - COUNTER ROTATION                           |
| E225PXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225PXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| E225PZARK 1994  | GEARCASE - COUNTER ROTATION                                  |
| E225PZARK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZARK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225PZATF 1993  | GEARCASE - COUNTER ROTATION                                  |
| E225PZATF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZATF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225PZATS 1993  | GEARCASE - COUNTER ROTATION                                  |
| E225PZATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZATS 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225PZEOB 1995  | GEARCASE - COUNTER ROTATION                                  |
| E225PZEOB 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZEOB 1995  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225PZERK 1994  | GEARCASE - COUNTER ROTATION                                  |
| E225PZERK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZERK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225PZERM 1994  | GEARCASE - COUNTER ROTATION                                  |
| E225PZERM 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZERM 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225PZETA 1993  | GEARCASE - COUNTER ROTATION                                  |
| E225PZETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225PZETF 1993  | GEARCASE - COUNTER ROTATION                                  |
| E225PZETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225PZETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225STLECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E225STLECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E225STLECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E225STLEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E225STLEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225STLEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225STLEOB 1995 | GEARCASE - COUNTER ROTATION                                  |
| E225STLEOB 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225STLEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225STLERC 1994 | GEARCASE - COUNTER ROTATION                                  |

|                 |                                                       |
|-----------------|-------------------------------------------------------|
| E225STLERC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225STLERC 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225STLERK 1994 | GEARCASE - COUNTER ROTATION                           |
| E225STLERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225STLERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225STLETF 1993 | GEARCASE - COUNTER ROTATION                           |
| E225STLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225STLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225STLEUD 1997 | GEARCASE - COUNTER-ROTATION                           |
| E225STLEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225STLEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TLERK 1994  | GEARCASE - COUNTER ROTATION                           |
| E225TLERK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TLERK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TLERM 1994  | GEARCASE - COUNTER ROTATION                           |
| E225TLERM 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TLERM 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TLETA 1993  | GEARCASE - COUNTER ROTATION                           |
| E225TLETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TLETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TLETF 1993  | GEARCASE - COUNTER ROTATION                           |
| E225TLETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TLETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TXARC 1994  | GEARCASE - COUNTER ROTATION                           |
| E225TXARC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TXARC 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TXARK 1994  | GEARCASE - COUNTER ROTATION                           |
| E225TXARK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TXARK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TXATF 1993  | GEARCASE - COUNTER ROTATION                           |
| E225TXATF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TXATF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| E225TXATS 1993  | GEARCASE - COUNTER ROTATION                           |
| E225TXATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| E225TXATS 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E225TXECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E225TXECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E225TXECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E225TXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TXEOB 1995 | GEARCASE - COUNTER ROTATION                                  |
| E225TXEOB 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TXEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TXERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225TXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TXERM 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225TXERM 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TXERM 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TXETA 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225TXETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TXETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TXETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225TXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TXEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZARK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225TZARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZATF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225TZATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225TZATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| E225TZECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E225TZECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E225TZEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| E225TZEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZEOb 1995 | GEARCASE - COUNTER ROTATION                                  |
| E225TZEOb 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZEOb 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225TZERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZERM 1994 | GEARCASE - COUNTER ROTATION                                  |
| E225TZERM 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZERM 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZETA 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225TZETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E225TZETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E225TZEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| E225TZEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| E225TZEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| E250CXARC 1994 | GEARCASE - COUNTER ROTATION                                  |
| E250CXARC 1994 | GEARCASE - STANDARD ROTATION                                 |
| E250CXATF 1993 | GEARCASE - COUNTER ROTATION                                  |
| E250CXATF 1993 | GEARCASE - STANDARD ROTATION                                 |
| E250CXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| E250CXATS 1993 | GEARCASE - STANDARD ROTATION                                 |
| E250CXECD 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E250CXECD 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E250CXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E250CXEOR 1995 | GEARCASE - COUNTER ROTATION                                  |
| E250CXEOR 1995 | GEARCASE - STANDARD ROTATION                                 |

|                                        |                                                              |
|----------------------------------------|--------------------------------------------------------------|
| E250CXERC 1994                         | GEARCASE - COUNTER ROTATION                                  |
| E250CXERC 1994                         | GEARCASE - STANDARD ROTATION                                 |
| E250CXETF 1993                         | GEARCASE - COUNTER ROTATION                                  |
| E250CXETF 1993                         | GEARCASE - STANDARD ROTATION                                 |
| E250CXETS 1993                         | GEARCASE - COUNTER ROTATION                                  |
| E250CXETS 1993                         | GEARCASE - STANDARD ROTATION                                 |
| E250CZATF 1993                         | GEARCASE - COUNTER ROTATION                                  |
| E250CZATF 1993                         | GEARCASE - STANDARD ROTATION                                 |
| E250CZATS 1993                         | GEARCASE - COUNTER ROTATION                                  |
| E250CZATS 1993                         | GEARCASE - STANDARD ROTATION                                 |
| E250CZECD 1998                         | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E250CZECD 1998                         | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E250CZECD 1998                         | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E250CZEOR 1995                         | GEARCASE - COUNTER ROTATION                                  |
| E250CZEOR 1995                         | GEARCASE - STANDARD ROTATION                                 |
| E250CZERC 1994                         | GEARCASE - COUNTER ROTATION                                  |
| E250CZERC 1994                         | GEARCASE - STANDARD ROTATION                                 |
| E250CZETF 1993                         | GEARCASE - COUNTER ROTATION                                  |
| E250CZETF 1993                         | GEARCASE - STANDARD ROTATION                                 |
| E250CZETS 1993                         | GEARCASE - COUNTER ROTATION                                  |
| E250CZETS 1993                         | GEARCASE - STANDARD ROTATION                                 |
| E250DCXAAA - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXAAA - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation       |
| E250DCXAAB - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXAAB - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation       |
| E250DCXAAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXAAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation       |
| E250DCXAAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXAAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation       |
| E250DCXABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXABB - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation                     |
| E250DCXABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation                     |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| E250DCXIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCXIID - (90 degree V6, 3.3 L)     | GEARCASE, M2-Type, Counter Rotation                    |
| E250DCXINS - (90 degree V6, 3.3L)      | GEARCASE, M2-Type, Counter Rotation                    |
| E250DCXINS - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCXISE                             | GEARCASE                                               |
| E250DCXISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCXISF                             | GEARCASE                                               |
| E250DCXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCXSCF                             | GEARCASE                                               |
| E250DCXSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCXSCG                             | GEARCASE                                               |
| E250DCXSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCXSCH                             | GEARCASE                                               |
| E250DCXSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCXSCM                             | GEARCASE                                               |
| E250DCXSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCXSDR                             | GEARCASE                                               |
| E250DCXSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCXSEB                             | GEARCASE                                               |
| E250DCXSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCXSOC                             | GEARCASE CX, CZ MODELS                                 |
| E250DCXSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES               |
| E250DCXSUA                             | GEARCASE                                               |
| E250DCXSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCXSUG                             | GEARCASE                                               |
| E250DCXSUG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCZAAA - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZAAA - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZAAB - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZAAB - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZAAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZAAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZAAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZAAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |

|                                         |                                                        |
|-----------------------------------------|--------------------------------------------------------|
| E250DCZABB - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZABF - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZABG - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZABH - (90 degree V6, 3.3 L)      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E250DCZIID - (90 degree V6 3,3 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZIID - (90 degree V6, 3.3 L)      | GEARCASE, M2-Type, Counter Rotation                    |
| E250DCZINS - (90 degree V6, 3.3L)       | GEARCASE, M2-Type, Counter Rotation                    |
| E250DCZINS - (90 degree V6, 3.3L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZISE                              | GEARCASE                                               |
| E250DCZISE - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZISF                              | GEARCASE                                               |
| E250DCZISF - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZSCF                              | GEARCASE                                               |
| E250DCZSCF - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCZSCG                              | GEARCASE                                               |
| E250DCZSCG - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZSCH                              | GEARCASE                                               |
| E250DCZSCH - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZSCM                              | GEARCASE                                               |
| E250DCZSCM - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCZSDR                              | GEARCASE                                               |
| E250DCZSDR - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DCZSEB                              | GEARCASE                                               |
| E250DCZSEB - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E250DCZSOC                              | GEARCASE CX, CZ MODELS                                 |
| E250DCZSOC - FR                         | 07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES               |
| E250DCZSUA                              | GEARCASE                                               |
| E250DCZSUA - FR                         | 07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation  |
| E250DHIAAA - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                 |
| E250DHIAAA - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E250DHIAAB - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                 |
| E250DHIAAB - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E250DHIAAC - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                 |
| E250DHIAAC - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E250DHIAAD - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                 |

|                                         |                                       |
|-----------------------------------------|---------------------------------------|
| E250DHLAAD - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHLABA - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHLABB - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHIIIA - (90 degree V6, 3.4 L)      | GEARCASE, M2-Type                     |
| E250DHIIIA - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHLINM - (90 degree V6, 3.4 L)      | GEARCASE, M2-Type                     |
| E250DHLINM - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHLISF - (90 degree V6 3,4 L)       | GEARCASE                              |
| E250DHLISF - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E250DHLISG - (90 degree V6 3,4 L)       | GEARCASE                              |
| E250DHLISG - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E250DHLISR - (90 degree V6 3,4 L)       | GEARCASE                              |
| E250DHLISR - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E250DHLSCS - (90 degree V6 3,4 L)       | GEARCASE                              |
| E250DHLSCS - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E250DHLSEC - (90 degree V6 3,4 L)       | GEARCASE                              |
| E250DHLSEC - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E250DHXAAA - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHXAAA - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHXAAB - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHXAAB - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHXAAC - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHXAAC - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHXAAD - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHXAAD - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHXABA - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHXABB - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                |
| E250DHXIIA - (90 degree V6 3,4 L)       | GEARCASE, M2-Type                     |
| E250DHXIIA - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHXINM - (90 degree V6, 3.4 L)      | GEARCASE, M2-Type                     |
| E250DHXINM - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E250DHXISF - (90 degree V6 3,4 L)       | GEARCASE                              |
| E250DHXISF - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |
| E250DHXISG - (90 degree V6 3,4 L)       | GEARCASE                              |
| E250DHXISG - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2 |

|                                        |                                                         |
|----------------------------------------|---------------------------------------------------------|
| E250DHXISR - (90 degree V6 3,4 L)      | GEARCASE                                                |
| E250DHXISR - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                   |
| E250DHXSCS - (90 degree V6 3,4 L)      | GEARCASE                                                |
| E250DHXSCS - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                   |
| E250DHXSEC - (90 degree V6 3,4 L)      | GEARCASE                                                |
| E250DHXSEC - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type L2                   |
| E250DPLIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPLIID - (90 degree V6, 3.3 L)     | GEARCASE, M2-Type                                       |
| E250DPLINS - (90 degree V6, 3.3L)      | GEARCASE, M2-Type                                       |
| E250DPLINS - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPLISE                             | GEARCASE                                                |
| E250DPLISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPLISF                             | GEARCASE                                                |
| E250DPLISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPLSCF                             | GEARCASE                                                |
| E250DPLSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPLSCG                             | GEARCASE                                                |
| E250DPLSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPLSCH                             | GEARCASE                                                |
| E250DPLSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPLSCM                             | GEARCASE                                                |
| E250DPLSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPLSDR                             | GEARCASE                                                |
| E250DPLSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPLSEB                             | GEARCASE                                                |
| E250DPLSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPLSOC                             | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E250DPLSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E250DPLSUA                             | GEARCASE                                                |
| E250DPLSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPXAAA - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |
| E250DPXAAA - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXAAB - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |
| E250DPXAAB - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXAAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |

|                                        |                                                         |
|----------------------------------------|---------------------------------------------------------|
| E250DPXAAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXAAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |
| E250DPXAAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPXABB - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPXABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPXABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPXABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPXIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXIID - (90 degree V6, 3.3 L)     | GEARCASE, M2-Type                                       |
| E250DPXINS - (90 degree V6, 3.3L)      | GEARCASE, M2-Type                                       |
| E250DPXINS - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXISE                             | GEARCASE                                                |
| E250DPXISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXISF                             | GEARCASE                                                |
| E250DPXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXSCF                             | GEARCASE                                                |
| E250DPXSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPXSCG                             | GEARCASE                                                |
| E250DPXSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXSCH                             | GEARCASE                                                |
| E250DPXSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXSCM                             | GEARCASE                                                |
| E250DPXSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPXSDR                             | GEARCASE                                                |
| E250DPXSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPXSEB                             | GEARCASE                                                |
| E250DPXSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPXSOC                             | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E250DPXSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E250DPXSUA                             | GEARCASE                                                |
| E250DPXSUA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPXSUG                             | GEARCASE                                                |
| E250DPXSUG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPZAAA - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |

|                                        |                                                         |
|----------------------------------------|---------------------------------------------------------|
| E250DPZAAA - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZAAB - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |
| E250DPZAAB - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZAAC - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |
| E250DPZAAC - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZAAD - (90 degree V6, 3.3L)      | 07-1_GEARCASE, M2-Type                                  |
| E250DPZAAD - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZABA - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPZABB - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPZABF - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPZABG - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPZABH - (90 degree V6, 3.3 L)     | 07-1_GEARCASE, M2-Type                                  |
| E250DPZIID - (90 degree V6 3,3 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZIID - (90 degree V6, 3.3 L)     | GEARCASE, M2-Type                                       |
| E250DPZINS - (90 degree V6, 3.3L)      | GEARCASE, M2-Type                                       |
| E250DPZINS - (90 degree V6, 3.3L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZISE                             | GEARCASE                                                |
| E250DPZISE - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZISF                             | GEARCASE                                                |
| E250DPZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZSCF                             | GEARCASE                                                |
| E250DPZSCF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPZSCG                             | GEARCASE                                                |
| E250DPZSCG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZSCH                             | GEARCASE                                                |
| E250DPZSCH - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZSCM                             | GEARCASE                                                |
| E250DPZSCM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPZSDR                             | GEARCASE                                                |
| E250DPZSDR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M                    |
| E250DPZSEB                             | GEARCASE                                                |
| E250DPZSEB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                   |
| E250DPZSOC                             | GEARCASE PL, SL,PX,PZ MODELS (M Type)                   |
| E250DPZSOC - FR                        | 07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type) |
| E250DPZSUA                             | GEARCASE                                                |

|                                                                      |                                                           |
|----------------------------------------------------------------------|-----------------------------------------------------------|
| E250DPZSUA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type M                      |
| E250DPZSUG                                                           | GEARCASE                                                  |
| E250DPZSUG - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES, de type M                      |
| E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - Counter Rotation                               |
| E250FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E250FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FCXSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FHL MODEL                                      |
| E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E250FCXSOB                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E250FCXSOB - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES              |
| E250FCXSRM                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E250FCXSRM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E250FCXSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000  | GEARCASE - Counter Rotation                               |
| E250FCXSTA                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E250FCXSTA                                                           | GEARCASE - FHL MODEL                                      |
| E250FCXSTA                                                           | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FCXSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E250FCXSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FCXSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001  | GEARCASE - Counter Rotation                               |
| E250FCZSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |

|                                                                      |                                                           |
|----------------------------------------------------------------------|-----------------------------------------------------------|
| E250FCZSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FCZSNF - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002 | GEARCASE - FHL MODEL                                      |
| E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E250FCZSOB                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E250FCZSOB - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES              |
| E250FCZSRM                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E250FCZSRM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E250FCZSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000  | GEARCASE - Counter Rotation                               |
| E250FCZSTA                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E250FCZSTA                                                           | GEARCASE - FHL MODEL                                      |
| E250FCZSTA                                                           | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FCZSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E250FCZSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FCZSTA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E250FGLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000             | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E250FPLSOM                                                           | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPLSOM - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES              |
| E250FPLSRA                                                           | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPLSRA - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E250FPLSSS FFI, Elec Start, TNT, 20 IN shaft 2000                    | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E250FPLSTR                                                           | GEARCASE - FCX & FCZ MODELS                               |
| E250FPLSTR                                                           | GEARCASE - FHL MODEL                                      |
| E250FPLSTR                                                           | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPLSTR - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E250FPLSTR - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FPLSTR - FR                                                      | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |

|                                                          |                                                           |
|----------------------------------------------------------|-----------------------------------------------------------|
| E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001        | GEARCASE - Counter Rotation                               |
| E250FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E250FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FPXSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E250FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E250FPXSOB                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPXSOB - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E250FPXSRM                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPXSRM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E250FPXSSS FFI, Elec Start, TNT, 25 IN shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E250FPXSTA                                               | GEARCASE - FCX & FCZ MODELS                               |
| E250FPXSTA                                               | GEARCASE - FHL MODEL                                      |
| E250FPXSTA                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPXSTA - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ              |
| E250FPXSTA - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FPXSTA - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL   |
| E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001        | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001        | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001        | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001        | GEARCASE - Counter Rotation                               |
| E250FPZSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ            |
| E250FPZSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FHL                   |
| E250FPZSNF - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ       |
| E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002 | GEARCASE - FHL MODEL                                      |
| E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002 | GEARCASE - FPL - FPX - FPZ MODELS                         |
| E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002 | GEARCASE - FCX & FCZ MODELS                               |
| E250FPZSOB                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPZSOB - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES |
| E250FPZSRM                                               | GEARCASE - FPL - FSL - FPX - FPZ MODELS                   |
| E250FPZSRM - FR                                          | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL  |
| E250FPZSSS FFI, Elec Start, TNT, 30 IN shaft, wht 2000   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |

E250FPZSTA  
 E250FPZSTA  
 E250FPZSTA  
 E250FPZSTA - FR  
 E250FPZSTA - FR  
 E250FPZSTA - FR  
 E250HGLAAB - (90 degree V6, 3.4 L)  
 E250HGLAAB - (90 degree V6, 3.4 L) - FR  
 E250HGLAAC - (90 degree V6, 3.4 L)  
 E250HGLAAC - (90 degree V6, 3.4 L) - FR  
 E250HGLAAD - (90 degree V6, 3.4 L)  
 E250HGLAAD - (90 degree V6, 3.4 L) - FR  
 E250HGLABA - (90 degree V6, 3.4 L)  
 E250HGLABB - (90 degree V6, 3.4 L)  
 E250HGLABF - (90 degree V6, 3.4 L)  
 E250HGLABG - (90 degree V6, 3.4 L)  
 E250HGLABH - (90 degree V6, 3.4 L)  
 E250HGLSES - (90 degree V6 3,4 L)  
 E250HGLSES - (90 degree V6 3,4 L) - FR  
 E250HGXAAB - (90 degree V6, 3.4 L)  
 E250HGXAAB - (90 degree V6, 3.4 L) - FR  
 E250HGXAAC - (90 degree V6, 3.4 L)  
 E250HGXAAC - (90 degree V6, 3.4 L) - FR  
 E250HGXAAD - (90 degree V6, 3.4 L)  
 E250HGXAAD - (90 degree V6, 3.4 L) - FR  
 E250HGXABA - (90 degree V6, 3.4 L)  
 E250HGXABB - (90 degree V6, 3.4 L)  
 E250HGXABF - (90 degree V6, 3.4 L)  
 E250HGXABG - (90 degree V6, 3.4 L)  
 E250HGXABH - (90 degree V6, 3.4 L)  
 E250HGXSES - (90 degree V6 3,4 L)  
 E250HGXSES - (90 degree V6 3,4 L) - FR  
 E250HSLAAA - (90 degree V6, 3.4 L)  
 E250HSLAAA - (90 degree V6, 3.4 L) - FR  
 E250HSLAAB - (90 degree V6, 3.4 L)

GEARCASE - FCX & FCZ MODELS  
 GEARCASE - FHL MODEL  
 GEARCASE - FPL - FSL - FPX - FPZ MODELS  
 07-1\_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ  
 07-1\_BOÎTIER D'ENGRENAGES - Modèles FHL  
 07-1\_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL  
 07-1\_GEARCASE, M2-Type  
 07-1\_BOÎTIER D'ENGRENAGES, de type M2  
 07-1\_GEARCASE, M2-Type  
 07-1\_BOÎTIER D'ENGRENAGES, de type M2  
 07-1\_GEARCASE, M2-Type  
 07-1\_BOÎTIER D'ENGRENAGES, de type M2  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 GEARCASE  
 07-1\_BOÎTIER D'ENGRENAGES, de type L2  
 07-1\_GEARCASE, M2-Type  
 07-1\_BOÎTIER D'ENGRENAGES, de type M2  
 07-1\_GEARCASE, M2-Type  
 07-1\_BOÎTIER D'ENGRENAGES, de type M2  
 07-1\_GEARCASE, M2-Type  
 07-1\_BOÎTIER D'ENGRENAGES, de type M2  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 07-1\_GEARCASE, M2-Type  
 GEARCASE  
 07-1\_BOÎTIER D'ENGRENAGES, de type L2  
 07-1\_GEARCASE, M2-Type  
 07-1\_BOÎTIER D'ENGRENAGES, de type M2  
 07-1\_GEARCASE, M2-Type

|                                         |                                                              |
|-----------------------------------------|--------------------------------------------------------------|
| E250HSLAAB - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E250HSLAAC - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                       |
| E250HSLAAC - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E250HSLAAD - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                       |
| E250HSLAAD - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E250HSLABA - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                       |
| E250HSLABB - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                       |
| E250HSLABF - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                       |
| E250HSLABG - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                       |
| E250HSLABH - (90 degree V6, 3.4 L)      | 07-1_GEARCASE, M2-Type                                       |
| E250HSLIIR - (90 degree V6 3,4 L)       | GEARCASE, M2-Type                                            |
| E250HSLIIR - (90 degree V6, 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E250HSLINA - (90 degree V6, 3.4 L)      | GEARCASE, M2-Type                                            |
| E250HSLINA - (90 degree V6, 3.4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                        |
| E250HSLISC - (90 degree V6 3,4 L)       | GEARCASE                                                     |
| E250HSLISC - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E250HSLISF - (90 degree V6 3,4 L)       | GEARCASE                                                     |
| E250HSLISF - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E250HSLISG - (90 degree V6 3,4 L)       | GEARCASE                                                     |
| E250HSLISG - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E250HSLSES - (90 degree V6 3,4 L)       | GEARCASE                                                     |
| E250HSLSES - (90 degree V6 3,4 L) - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type L2                        |
| E250PXECD 1998                          | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E250PXECD 1998                          | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E250PXECD 1998                          | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E250PZECD 1998                          | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| E250PZECD 1998                          | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| E250PZECD 1998                          | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| E250TXARC 1994                          | GEARCASE - COUNTER ROTATION                                  |
| E250TXARC 1994                          | GEARCASE - STANDARD ROTATION                                 |
| E250TXATF 1993                          | GEARCASE - COUNTER ROTATION                                  |
| E250TXATF 1993                          | GEARCASE - STANDARD ROTATION                                 |
| E250TXATS 1993                          | GEARCASE - COUNTER ROTATION                                  |
| E250TXATS 1993                          | GEARCASE - STANDARD ROTATION                                 |

|                 |                                                        |
|-----------------|--------------------------------------------------------|
| E250TXEOR 1995  | GEARCASE - COUNTER ROTATION                            |
| E250TXEOR 1995  | GEARCASE - STANDARD ROTATION                           |
| E250TXERC 1994  | GEARCASE - COUNTER ROTATION                            |
| E250TXERC 1994  | GEARCASE - STANDARD ROTATION                           |
| E250TXETF 1993  | GEARCASE - COUNTER ROTATION                            |
| E250TXETF 1993  | GEARCASE - STANDARD ROTATION                           |
| E250TXETS 1993  | GEARCASE - COUNTER ROTATION                            |
| E250TXETS 1993  | GEARCASE - STANDARD ROTATION                           |
| E250TZATF 1993  | GEARCASE - COUNTER ROTATION                            |
| E250TZATF 1993  | GEARCASE - STANDARD ROTATION                           |
| E250TZATS 1993  | GEARCASE - COUNTER ROTATION                            |
| E250TZATS 1993  | GEARCASE - STANDARD ROTATION                           |
| E250TZEOR 1995  | GEARCASE - COUNTER ROTATION                            |
| E250TZEOR 1995  | GEARCASE - STANDARD ROTATION                           |
| E250TZERC 1994  | GEARCASE - COUNTER ROTATION                            |
| E250TZERC 1994  | GEARCASE - STANDARD ROTATION                           |
| E250TZETF 1993  | GEARCASE - COUNTER ROTATION                            |
| E250TZETF 1993  | GEARCASE - STANDARD ROTATION                           |
| E250TZETS 1993  | GEARCASE - COUNTER ROTATION                            |
| E250TZETS 1993  | GEARCASE - STANDARD ROTATION                           |
| E300CXEOR 1995  | GEARCASE - COUNTER ROTATION                            |
| E300CXEOR 1995  | GEARCASE - STANDARD ROTATION                           |
| E300CXERC 1994  | GEARCASE - COUNTER ROTATION                            |
| E300CXERC 1994  | GEARCASE - STANDARD ROTATION                           |
| E300CXETF 1993  | GEARCASE - COUNTER ROTATION                            |
| E300CXETF 1993  | GEARCASE - STANDARD ROTATION                           |
| E300CXETS 1993  | GEARCASE - COUNTER ROTATION                            |
| E300CXETS 1993  | GEARCASE - STANDARD ROTATION                           |
| E300DCXAAA      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXAAB      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXAAB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXAAC      | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXAAC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXAAD      | 07-1_GEARCASE, M2-Type, Counter Rotation               |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| E300DCXAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXABA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXABB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCXIIA                             | GEARCASE, M2-Type, Counter Rotation                    |
| E300DCXIIA - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXINM                             | GEARCASE, M2-Type, Counter Rotation                    |
| E300DCXINM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXISF                             | GEARCASE                                               |
| E300DCXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXISG                             | GEARCASE                                               |
| E300DCXISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXISR                             | GEARCASE                                               |
| E300DCXISR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXSCS                             | GEARCASE                                               |
| E300DCXSCS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCXSEC                             | GEARCASE                                               |
| E300DCXSEC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZAAA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZAAB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZAAC                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZAAD                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZABA                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZABB                             | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type, Counter Rotation               |
| E300DCZIIA                             | GEARCASE, M2-Type, Counter Rotation                    |
| E300DCZIIA - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |

|                                        |                                                        |
|----------------------------------------|--------------------------------------------------------|
| E300DCZINM                             | GEARCASE, M2-Type, Counter Rotation                    |
| E300DCZINM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZISF                             | GEARCASE                                               |
| E300DCZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZISG                             | GEARCASE                                               |
| E300DCZISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZISR                             | GEARCASE                                               |
| E300DCZISR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZSCS                             | GEARCASE                                               |
| E300DCZSCS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DCZSEC                             | GEARCASE                                               |
| E300DCZSEC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2, contre rotation |
| E300DGXABA                             | 07-1_GEARCASE, M2-Type                                 |
| E300DGXABB                             | 07-1_GEARCASE, M2-Type                                 |
| E300DGXABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                                 |
| E300DGXABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                                 |
| E300DGXABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                                 |
| E300DPXAAA                             | 07-1_GEARCASE, M2-Type                                 |
| E300DPXAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E300DPXAAB                             | 07-1_GEARCASE, M2-Type                                 |
| E300DPXAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E300DPXAAC                             | 07-1_GEARCASE, M2-Type                                 |
| E300DPXAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E300DPXAAD                             | 07-1_GEARCASE, M2-Type                                 |
| E300DPXAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E300DPXABA                             | 07-1_GEARCASE, M2-Type                                 |
| E300DPXABB                             | 07-1_GEARCASE, M2-Type                                 |
| E300DPXABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                                 |
| E300DPXABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                                 |
| E300DPXABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                                 |
| E300DPXIIA                             | GEARCASE, M2-Type                                      |
| E300DPXIIA - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E300DPXINM                             | GEARCASE, M2-Type                                      |
| E300DPXINM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2                  |
| E300DPXISF                             | GEARCASE                                               |

|                                        |                                       |
|----------------------------------------|---------------------------------------|
| E300DPXISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPXISG                             | GEARCASE                              |
| E300DPXISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPXISR                             | GEARCASE                              |
| E300DPXISR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPXSCS                             | GEARCASE                              |
| E300DPXSCS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPXSEC                             | GEARCASE                              |
| E300DPXSEC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZAAA                             | 07-1_GEARCASE, M2-Type                |
| E300DPZAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZAAB                             | 07-1_GEARCASE, M2-Type                |
| E300DPZAAB - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZAAC                             | 07-1_GEARCASE, M2-Type                |
| E300DPZAAC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZAAD                             | 07-1_GEARCASE, M2-Type                |
| E300DPZAAD - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZABA                             | 07-1_GEARCASE, M2-Type                |
| E300DPZABB                             | 07-1_GEARCASE, M2-Type                |
| E300DPZABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| E300DPZABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| E300DPZABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| E300DPZIIA                             | GEARCASE, M2-Type                     |
| E300DPZIIA - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZINM                             | GEARCASE, M2-Type                     |
| E300DPZINM - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZISF                             | GEARCASE                              |
| E300DPZISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZISG                             | GEARCASE                              |
| E300DPZISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZISR                             | GEARCASE                              |
| E300DPZISR - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZSCS                             | GEARCASE                              |
| E300DPZSCS - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DPZSEC                             | GEARCASE                              |

|                                        |                                       |
|----------------------------------------|---------------------------------------|
| E300DPZSEC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLAAA                             | 07-1_GEARCASE, M2-Type                |
| E300DSLAAA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLAAAB                            | 07-1_GEARCASE, M2-Type                |
| E300DSLAAAB - FR                       | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLAAAC                            | 07-1_GEARCASE, M2-Type                |
| E300DSLAAAC - FR                       | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLAAAD                            | 07-1_GEARCASE, M2-Type                |
| E300DSLAAAD - FR                       | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLABA                             | 07-1_GEARCASE, M2-Type                |
| E300DSLABB                             | 07-1_GEARCASE, M2-Type                |
| E300DSLABF - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| E300DSLABG - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| E300DSLABH - (90 degree V6, 3.4 L)     | 07-1_GEARCASE, M2-Type                |
| E300DSLIIR                             | GEARCASE, M2-Type                     |
| E300DSLIIR - (90 degree V6 3,4 L) - FR | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLINA                             | GEARCASE, M2-Type                     |
| E300DSLINA - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLISC                             | GEARCASE                              |
| E300DSLISC - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLISF                             | GEARCASE                              |
| E300DSLISF - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLISG                             | GEARCASE                              |
| E300DSLISG - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300DSLSES                             | GEARCASE                              |
| E300DSLSES - FR                        | 07-1_BOÎTIER D'ENGRENAGES, de type M2 |
| E300PLEOR 1995                         | GEARCASE - COUNTER ROTATION           |
| E300PLEOR 1995                         | GEARCASE - STANDARD ROTATION          |
| E300PLERC 1994                         | GEARCASE - COUNTER ROTATION           |
| E300PLERC 1994                         | GEARCASE - STANDARD ROTATION          |
| E300PLETF 1993                         | GEARCASE - COUNTER ROTATION           |
| E300PLETF 1993                         | GEARCASE - STANDARD ROTATION          |
| E300PLETS 1993                         | GEARCASE - COUNTER ROTATION           |
| E300PLETS 1993                         | GEARCASE - STANDARD ROTATION          |
| E300PXEOE 1995                         | GEARCASE - COUNTER ROTATION           |

|                |                                     |
|----------------|-------------------------------------|
| E300PXEOR 1995 | GEARCASE - STANDARD ROTATION        |
| E300PXERC 1994 | GEARCASE - COUNTER ROTATION         |
| E300PXERC 1994 | GEARCASE - STANDARD ROTATION        |
| E300PXETF 1993 | GEARCASE - COUNTER ROTATION         |
| E300PXETF 1993 | GEARCASE - STANDARD ROTATION        |
| E300PXETS 1993 | GEARCASE - COUNTER ROTATION         |
| E300PXETS 1993 | GEARCASE - STANDARD ROTATION        |
| E60HGLAFC      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E60HGLAFD      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E60HGLAFF      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E60HGLAFG      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E60HGXAFC      | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E60HGXAFD      | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E60HGXAFF      | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E60HGXAFG      | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E60HSLAFD      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E60HSLAFF      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E60HSLAFG      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65GLAFA       | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65GLAFB       | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65GLAFC       | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65GNLAFA      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65GNLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65GNLAFC      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SLABB       | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SLAFA       | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SLAFB       | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SLAFC       | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SNLABB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SNLAFA      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SNLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E65SNLAFC      | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E75DPGLAFA     | 07-1_GEARCASE, (0.50 Ratio) S-Type  |
| E75DPGLAFB     | 07-1_GEARCASE, (0.50 Ratio) S-Type  |
| E75DPGLAFC     | 07-1_GEARCASE, (0.50 Ratio) S-Type  |

|                |                                              |
|----------------|----------------------------------------------|
| E75DPGLAFD     | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DPGLAFF     | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DPGLAFG     | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DPLAAA      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DPLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DPLABA      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DPLABB      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DPLIIS      | GEARCASE, S-Type                             |
| E75DPLIIS - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DPLINC      | GEARCASE, S-Type                             |
| E75DPLINC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DPLISD      | GEARCASE - PL, SL MODELS                     |
| E75DPLISD - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DPLISF      | GEARCASE - PL, SL MODELS                     |
| E75DPLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DPLSCB      | GEARCASE - PL, SL MODELS                     |
| E75DPLSCB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DPLSDA      | GEARCASE - PL, SL MODELS                     |
| E75DPLSDA - FR | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL   |
| E75DPLSEE      | GEARCASE - PL, SL MODELS                     |
| E75DPLSEE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DPLSOR      | GEARCASE PL & SL MODELS                      |
| E75DPLSOR - FR | 07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES    |
| E75DPLSRC      | GEARCASE PL & SL MODELS                      |
| E75DPLSRC - FR | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL |
| E75DPLSUM      | GEARCASE - PL, SL MODELS                     |
| E75DPLSUM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DSLAAA      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DSLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E75DSLABA      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DSLABB      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DSLafa      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DSLAFB      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DSLafc      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E75DSLAFD      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |



|                |                                              |
|----------------|----------------------------------------------|
| E90DHLAFA      | 07-1_GEARCASE, (0.50 Ratio) S2-Type          |
| E90DHLAFB      | 07-1_GEARCASE, (0.50 Ratio) S2-Type          |
| E90DMXSES      | GEARCASE - DMX                               |
| E90DPGLAFA     | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DPGLAFB     | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DPGLAFC     | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DPGLAFD     | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DPGLAFF     | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DPGLAFG     | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DPLAAA      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E90DPLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPLABA      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E90DPLABB      | 07-1_GEARCASE, (0.50 Ratio) S-Type           |
| E90DPLIIS      | GEARCASE, S-Type                             |
| E90DPLIIS - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPLINC      | GEARCASE, S-Type                             |
| E90DPLINC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPLISD      | GEARCASE - PL, SL MODELS                     |
| E90DPLISD - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPLISF      | GEARCASE - PL, SL MODELS                     |
| E90DPLISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPLSCB      | GEARCASE - PL, SL MODELS                     |
| E90DPLSCB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPLSDA      | GEARCASE - PL, SL MODELS                     |
| E90DPLSDA - FR | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL   |
| E90DPLSEE      | GEARCASE - PL, SL MODELS                     |
| E90DPLSEE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPLSOR      | GEARCASE PL & SL MODELS                      |
| E90DPLSOR - FR | 07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES    |
| E90DPLSRC      | GEARCASE PL & SL MODELS                      |
| E90DPLSRC - FR | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL |
| E90DPLSUM      | GEARCASE - PL, SL MODELS                     |
| E90DPLSUM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DPXAAA      | 07-1_GEARCASE, (0.44 Ratio) O-Type           |
| E90DPXAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O         |

|                |                                          |
|----------------|------------------------------------------|
| E90DPXABA      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXABB      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXAFA      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXAFB      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXAFC      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXAFD      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXAFF      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXAFG      | 07-1_GEARCASE, (0.44 Ratio) O-Type       |
| E90DPXIIS      | GEARCASE, O-Type                         |
| E90DPXIIS - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O     |
| E90DPXINC      | GEARCASE, O-Type                         |
| E90DPXINC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O     |
| E90DPXISD      | GEARCASE - PX MODELS                     |
| E90DPXISD - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O     |
| E90DPXISF      | GEARCASE - PX MODELS                     |
| E90DPXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O     |
| E90DPXSCB      | GEARCASE - PX MODELS                     |
| E90DPXSCB - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O     |
| E90DPXSDA      | GEARCASE - PX MODELS                     |
| E90DPXSDA - FR | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX   |
| E90DPXSEE      | GEARCASE - PX MODELS                     |
| E90DPXSEE - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O     |
| E90DPXSOR      | GEARCASE PX , W MODELS                   |
| E90DPXSOR - FR | 07-1_BOÎTIER D'ENGRENAGES PX , W MODELES |
| E90DPXSRC      | GEARCASE PX MODELS                       |
| E90DPXSRC - FR | 07-1_BOÎTIER D'ENGRENAGES - Modèles PX   |
| E90DPXSUM      | GEARCASE - PX MODELS                     |
| E90DPXSUM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O     |
| E90DSLAAA      | 07-1_GEARCASE, (0.50 Ratio) S-Type       |
| E90DSLAAA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S     |
| E90DSLABA      | 07-1_GEARCASE, (0.50 Ratio) S-Type       |
| E90DSLABB      | 07-1_GEARCASE, (0.50 Ratio) S-Type       |
| E90DSLafa      | 07-1_GEARCASE, (0.42 Ratio) S2-Type      |
| E90DSLAFB      | 07-1_GEARCASE, (0.42 Ratio) S2-Type      |
| E90DSL AFC     | 07-1_GEARCASE, (0.42 Ratio) S2-Type      |

|                 |                                              |
|-----------------|----------------------------------------------|
| E90DSLAFD       | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DSLAF        | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DSLAFG       | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90DSLIIID      | GEARCASE, S-Type                             |
| E90DSLIIID - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DSLINS       | GEARCASE, S-Type                             |
| E90DSLINS - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DSLISE       | GEARCASE - PL, SL MODELS                     |
| E90DSLISE - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DSLISF       | GEARCASE - PL, SL MODELS                     |
| E90DSLISF - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DSLSCM       | GEARCASE - PL, SL MODELS                     |
| E90DSLSCM - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DSLSDR       | GEARCASE - PL, SL MODELS                     |
| E90DSLSDR - FR  | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL   |
| E90DSLSEB       | GEARCASE - PL, SL MODELS                     |
| E90DSLSEB - FR  | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90DLSOC        | GEARCASE PL & SL MODELS                      |
| E90DLSOR - FR   | 07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES    |
| E90DLSRC        | GEARCASE PL & SL MODELS                      |
| E90DLSRC - FR   | 07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL |
| E90DLSUA        | GEARCASE - PL, SL MODELS                     |
| E90DLSUM - FR   | 07-1_BOÎTIER D'ENGRENAGES, de type S         |
| E90ELECM 1998   | GEARCASE -- 90 & 115 EL, GL, SL MODELS       |
| E90ELECM 1998   | GEARCASE -- 90 & 115 SX MODELS               |
| E90ELECM 1998   | JET DRIVE UNIT                               |
| E90ELEDR 1996   | GEARCASE - 20 IN. MODELS                     |
| E90ELEDR 1996   | GEARCASE - 25 IN. MODELS                     |
| E90ELEOC 1995   | GEARCASE - 20 IN. MODELS                     |
| E90ELEOC 1995   | GEARCASE - 25 IN. MODELS                     |
| E90ELEUA 1997   | GEARCASE - 20 IN. MODELS                     |
| E90ELEUA 1997   | GEARCASE - 25 IN. MODELS                     |
| E90ELEUC 1997   | GEARCASE - 20 IN. MODELS                     |
| E90ELEUC 1997   | GEARCASE - 25 IN. MODELS                     |
| E90EXEOC 1995   | GEARCASE - 20 IN. MODELS                     |

|                                                                      |                                              |
|----------------------------------------------------------------------|----------------------------------------------|
| E90EXEOC 1995                                                        | GEARCASE - 25 IN. MODELS                     |
| E90FPLEEC 1999                                                       | GEARCASE -- FPL, FSL MODELS                  |
| E90FPLEEC 1999                                                       | GEARCASE -- FPX MODELS                       |
| E90FPLEEN 1999                                                       | GEARCASE -- FPL, FSL MODELS                  |
| E90FPLEEN 1999                                                       | GEARCASE -- FPX MODELS                       |
| E90FPLSIF FFI, elec start, TNT, 20 in shaft 2001                     | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS |
| E90FPLSIF FFI, elec start, TNT, 20 in shaft 2001                     | GEARCASE - FPX - FX MODELS                   |
| E90FPLSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL      |
| E90FPLSNF - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX      |
| E90FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002 | GEARCASE - FPL, MODELS                       |
| E90FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002 | GEARCASE - FPX MODELS                        |
| E90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000                    | GEARCASE - FPL, FSL, FL, FS MODELS           |
| E90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000                    | GEARCASE - FPX, FX MODELS                    |
| E90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                    | GEARCASE - FPL, FSL, FL, FS MODELS           |
| E90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                    | GEARCASE - FPX, FX MODELS                    |
| E90FPLSTB                                                            | GEARCASE - FPL, FSL MODELS                   |
| E90FPLSTB                                                            | GEARCASE - FPX MODELS                        |
| E90FPLSTB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL |
| E90FPLSTB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX      |
| E90FSLECS 1998                                                       | GEARCASE -- FSL, FTL MODELS                  |
| E90FSLECS 1998                                                       | GEARCASE -- FSX MODELS                       |
| E90FSLSTB                                                            | GEARCASE - FPL, FSL MODELS                   |
| E90FSLSTB                                                            | GEARCASE - FPX MODELS                        |
| E90FSLSTB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL |
| E90FSLSTB - FR                                                       | 07-1_BOÎTIER D'ENGRENAGES - Modèles FPX      |
| E90FTLECS 1998                                                       | GEARCASE -- FSL, FTL MODELS                  |
| E90FTLECS 1998                                                       | GEARCASE -- FSX MODELS                       |
| E90FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS |
| E90FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - FPX - FX MODELS                   |
| E90GLAFA                                                             | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90GLAFB                                                             | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90GLAFC                                                             | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90GNLAFA                                                            | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |
| E90GNLAFB                                                            | 07-1_GEARCASE, (0.42 Ratio) S2-Type          |

|            |                                     |
|------------|-------------------------------------|
| E90GNL AFC | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90GNL AFD | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90GNL AFF | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90GNL AFG | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90HGL AFB | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HGL AFF | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HGL AFH | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HGL AFI | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HGL AFK | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HGL AFL | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HGXA FB | 07-1_GEARCASE, O-Type               |
| E90HGXA FF | 07-1_GEARCASE, O-Type               |
| E90HGXA FH | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90HGXA FI | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90HGXA FK | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90HGXA FL | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90HSL AFA | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HSL AFB | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HSL AFF | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HSL AFH | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HSL AFI | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HSL AFK | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HSL AFL | 07-1_GEARCASE, (0.50 Ratio) S2-Type |
| E90HSXA FA | 07-1_GEARCASE, O-Type               |
| E90HSXA FB | 07-1_GEARCASE, O-Type               |
| E90HSXA FF | 07-1_GEARCASE, O-Type               |
| E90HSXA FH | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90HSXA FI | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90HSXA FK | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90HSXA FL | 07-1_GEARCASE, (0.44 Ratio) O-Type  |
| E90SLA BA  | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90SLA BB  | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90SLA FA  | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90SLA FB  | 07-1_GEARCASE, (0.42 Ratio) S2-Type |
| E90SLA FC  | 07-1_GEARCASE, (0.42 Ratio) S2-Type |

|                 |                                        |
|-----------------|----------------------------------------|
| E90SLECM 1998   | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| E90SLECM 1998   | GEARCASE -- 90 & 115 SX MODELS         |
| E90SLECM 1998   | JET DRIVE UNIT                         |
| E90SLEDR 1996   | GEARCASE - 20 IN. MODELS               |
| E90SLEDR 1996   | GEARCASE - 25 IN. MODELS               |
| E90SLEOC 1995   | GEARCASE - 20 IN. MODELS               |
| E90SLEOC 1995   | GEARCASE - 25 IN. MODELS               |
| E90SLEUA 1997   | GEARCASE - 20 IN. MODELS               |
| E90SLEUA 1997   | GEARCASE - 25 IN. MODELS               |
| E90SLEUC 1997   | GEARCASE - 20 IN. MODELS               |
| E90SLEUC 1997   | GEARCASE - 25 IN. MODELS               |
| E90SNLABA       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90SNLABB       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90SNLAFA       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90SNLAFB       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90SNLAFC       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90SNLAFD       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90SNLAFF       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90SNLAFG       | 07-1_GEARCASE, (0.42 Ratio) S2-Type    |
| E90TSLECM 1998  | GEARCASE                               |
| E90WDELIIA      | GEARCASE, S-Type                       |
| E90WDELIIA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S   |
| E90WDELINM      | GEARCASE, S-Type                       |
| E90WDELINM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S   |
| E90WDELISF      | GEARCASE - PL, SL MODELS               |
| E90WDELISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S   |
| E90WDELISR      | GEARCASE - PL, SL MODELS               |
| E90WDELISR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S   |
| E90WDELSCS      | GEARCASE - PL, SL MODELS               |
| E90WDELSCS - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S   |
| E90WDELSEC      | GEARCASE - PL, SL MODELS               |
| E90WDELSEC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type S   |
| E90WDEXIIA      | GEARCASE, O-Type                       |
| E90WDEXIIA - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O   |
| E90WDEXINM      | GEARCASE, O-Type                       |

|                 |                                            |
|-----------------|--------------------------------------------|
| E90WDEXINM - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E90WDEXISF      | GEARCASE - PX MODELS                       |
| E90WDEXISF - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E90WDEXISR      | GEARCASE - PX MODELS                       |
| E90WDEXISR - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E90WDEXSCS      | GEARCASE - PX MODELS                       |
| E90WDEXSCS - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E90WDEXSEC      | GEARCASE - PX MODELS                       |
| E90WDEXSEC - FR | 07-1_BOÎTIER D'ENGRENAGES, de type O       |
| E90WDPLSOS      | GEARCASE PX , W MODELS                     |
| E90WDPLSOS - FR | 07-1_BOÎTIER D'ENGRENAGES PX , W MODELES   |
| HE115SLECM 1998 | GEARCASE -- 90 & 115 EL, GL, SL MODELS     |
| HE115SLECM 1998 | GEARCASE -- 90 & 115 SX MODELS             |
| HE115SLECM 1998 | JET DRIVE UNIT                             |
| HE115SLEDR 1996 | GEARCASE - 20 IN. MODELS                   |
| HE115SLEDR 1996 | GEARCASE - 25 IN. MODELS                   |
| HE115SLEUA 1997 | GEARCASE - 20 IN. MODELS                   |
| HE115SLEUA 1997 | GEARCASE - 25 IN. MODELS                   |
| HE115SLEUC 1997 | GEARCASE - 20 IN. MODELS                   |
| HE115SLEUC 1997 | GEARCASE - 25 IN. MODELS                   |
| HE130CXADA 1996 | GEARCASE - 130CX COUNTER ROTATION          |
| HE130CXADA 1996 | GEARCASE - 130TL & 130TX STANDARD ROTATION |
| HE130CXAUM 1997 | GEARCASE - 130CX COUNTER-ROTATION          |
| HE130CXAUM 1997 | GEARCASE - 130TL & 130TX STANDARD ROTATION |
| HE130TXACB 1998 | GEARCASE                                   |
| HE130TXADA 1996 | GEARCASE - 130CX COUNTER ROTATION          |
| HE130TXADA 1996 | GEARCASE - 130TL & 130TX STANDARD ROTATION |
| HE130TXAUM 1997 | GEARCASE - 130CX COUNTER-ROTATION          |
| HE130TXAUM 1997 | GEARCASE - 130TL & 130TX STANDARD ROTATION |
| HJ115SLECM 1998 | GEARCASE -- 90 & 115 EL, GL, SL MODELS     |
| HJ115SLECM 1998 | GEARCASE -- 90 & 115 SX MODELS             |
| HJ115SLECM 1998 | JET DRIVE UNIT                             |
| HJ115SLEDR 1996 | GEARCASE - 20 IN. MODELS                   |
| HJ115SLEDR 1996 | GEARCASE - 25 IN. MODELS                   |
| HJ115SLEUA 1997 | GEARCASE - 20 IN. MODELS                   |

|                                                            |                                               |
|------------------------------------------------------------|-----------------------------------------------|
| HJ115SLEUA 1997                                            | GEARCASE - 25 IN. MODELS                      |
| HJ115SLEUC 1997                                            | GEARCASE - 20 IN. MODELS                      |
| HJ115SLEUC 1997                                            | GEARCASE - 25 IN. MODELS                      |
| HJ130CXADA 1996                                            | GEARCASE - 130CX COUNTER ROTATION             |
| HJ130CXADA 1996                                            | GEARCASE - 130TL & 130TX STANDARD ROTATION    |
| HJ130CXAUM 1997                                            | GEARCASE - 130CX COUNTER-ROTATION             |
| HJ130CXAUM 1997                                            | GEARCASE - 130TL & 130TX STANDARD ROTATION    |
| HJ130TXACB 1998                                            | GEARCASE                                      |
| HJ130TXADA 1996                                            | GEARCASE - 130CX COUNTER ROTATION             |
| HJ130TXADA 1996                                            | GEARCASE - 130TL & 130TX STANDARD ROTATION    |
| HJ130TXAUM 1997                                            | GEARCASE - 130CX COUNTER-ROTATION             |
| HJ130TXAUM 1997                                            | GEARCASE - 130TL & 130TX STANDARD ROTATION    |
| J100WPLEEC 1999                                            | GEARCASE                                      |
| J100WPLSIF commercial, elec start, 20 in shaft 2001        | GEARCASE                                      |
| J100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE                                      |
| J100WPXEEC 1999                                            | GEARCASE                                      |
| J100WPXSIF commercial, elec start, TNT, 25 in shaft 2001   | GEARCASE                                      |
| J100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE                                      |
| J100WQLECS 1998                                            | GEARCASE -- 100WQL MODELS                     |
| J100WQLECS 1998                                            | GEARCASE -- 100WQX MODELS                     |
| J100WQXECS 1998                                            | GEARCASE -- 100WQL MODELS                     |
| J100WQXECS 1998                                            | GEARCASE -- 100WQX MODELS                     |
| J105WELEEN 1999                                            | GEARCASE                                      |
| J105WELEES 1999                                            | GEARCASE                                      |
| J105WELSIF commercial, elec start, 20 in shaft 2001        | GEARCASE                                      |
| J105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000      | GEARCASE                                      |
| J105WPLEEN 1999                                            | GEARCASE                                      |
| J105WPLEES 1999                                            | GEARCASE                                      |
| J105WPLSIF commercial, elec start, TNT, 20 in shaft 2001   | GEARCASE                                      |
| J105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE                                      |
| J105WPLSTM                                                 | GEARCASE - PX - WPL MODELS                    |
| J105WPLSTM - FR                                            | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL |
| J105WPXEEN 1999                                            | GEARCASE                                      |

|                                                            |                                        |
|------------------------------------------------------------|----------------------------------------|
| J105WPXEES 1999                                            | GEARCASE                               |
| J105WPXSIF commercial, elec start, TNT, 25 in shaft 2001   | GEARCASE                               |
| J105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE                               |
| J105WRLEES 1999                                            | GEARCASE                               |
| J105WRLSIF commercial, rope start, 20 in shaft 2001        | GEARCASE                               |
| J105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000       | GEARCASE                               |
| J105WRYEES 1999                                            | GEARCASE                               |
| J105WRYSIF commercial, rope start, 22.5 in shaft 2001      | GEARCASE                               |
| J105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000     | GEARCASE                               |
| J115ELECM 1998                                             | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| J115ELECM 1998                                             | GEARCASE -- 90 & 115 SX MODELS         |
| J115ELECM 1998                                             | JET DRIVE UNIT                         |
| J115ELEDR 1996                                             | GEARCASE - 20 IN. MODELS               |
| J115ELEDR 1996                                             | GEARCASE - 25 IN. MODELS               |
| J115ELEOC 1995                                             | GEARCASE - 20 IN. MODELS               |
| J115ELEOC 1995                                             | GEARCASE - 25 IN. MODELS               |
| J115ELEUA 1997                                             | GEARCASE - 20 IN. MODELS               |
| J115ELEUA 1997                                             | GEARCASE - 25 IN. MODELS               |
| J115ELEUC 1997                                             | GEARCASE - 20 IN. MODELS               |
| J115ELEUC 1997                                             | GEARCASE - 25 IN. MODELS               |
| J115FSLECS 1998                                            | GEARCASE -- FSL, FTL MODELS            |
| J115FSLECS 1998                                            | GEARCASE -- FSX MODELS                 |
| J115FSXECS 1998                                            | GEARCASE -- FSL, FTL MODELS            |
| J115FSXECS 1998                                            | GEARCASE -- FSX MODELS                 |
| J115FTLECS 1998                                            | GEARCASE -- FSL, FTL MODELS            |
| J115FTLECS 1998                                            | GEARCASE -- FSX MODELS                 |
| J115GLECM 1998                                             | GEARCASE -- 90 & 115 EL, GL, SL MODELS |
| J115GLECM 1998                                             | GEARCASE -- 90 & 115 SX MODELS         |
| J115GLECM 1998                                             | JET DRIVE UNIT                         |
| J115GLEDR 1996                                             | GEARCASE - 20 IN. MODELS               |
| J115GLEDR 1996                                             | GEARCASE - 25 IN. MODELS               |
| J115GLEOC 1995                                             | GEARCASE - 20 IN. MODELS               |
| J115GLEOC 1995                                             | GEARCASE - 25 IN. MODELS               |
| J115GLEUA 1997                                             | GEARCASE - 20 IN. MODELS               |

|                                                          |                                                 |
|----------------------------------------------------------|-------------------------------------------------|
| J115GLEUA 1997                                           | GEARCASE - 25 IN. MODELS                        |
| J115GLEUC 1997                                           | GEARCASE - 20 IN. MODELS                        |
| J115GLEUC 1997                                           | GEARCASE - 25 IN. MODELS                        |
| J115GLSDE                                                | GEARCASE - PL, GL MODELS                        |
| J115GLSDE - FR                                           | 17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES      |
| J115GLSOB                                                | GEARCASE - PL, GL MODELS                        |
| J115GLSOB - FR                                           | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL    |
| J115GLSRC                                                | GEARCASE - PL, GL MODELS                        |
| J115GLSRC - FR                                           | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL    |
| J115GLSTA                                                | GEARCASE - PL, GL MODELS                        |
| J115GLSTA                                                | GEARCASE - PX - WPL MODELS                      |
| J115GLSTA - FR                                           | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL    |
| J115GLSTA - FR                                           | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL   |
| J115JPLEEC 1999                                          | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| J115JPLEEC 1999                                          | GEARCASE -- 90 & 115 PX MODELS                  |
| J115JPLEEC 1999                                          | JET DRIVE UNIT                                  |
| J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001  | GEARCASE - 90 - 115 PL - VL MODELS              |
| J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001  | GEARCASE - 90 - 115 VX MODELS                   |
| J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001  | JET DRIVE UNIT                                  |
| J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000 | GEARCASE - 90 AND 115 PX, VX MODELS             |
| J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000 | JET DRIVE UNIT                                  |
| J115JTLECS 1998                                          | GEARCASE -- 90 & 115 EL, GL, SL MODELS          |
| J115JTLECS 1998                                          | GEARCASE -- 90 & 115 SX MODELS                  |
| J115JTLECS 1998                                          | JET DRIVE UNIT                                  |
| J115PLEEM 1999                                           | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| J115PLEEM 1999                                           | GEARCASE -- 90 & 115 PX MODELS                  |
| J115PLEEM 1999                                           | JET DRIVE UNIT                                  |
| J115PLSDA                                                | GEARCASE - PL, GL MODELS                        |
| J115PLSDA - FR                                           | 17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES      |
| J115PLSIE elec start, TNT, 20 in shaft 2001              | GEARCASE - 90 - 115 PL - VL MODELS              |
| J115PLSIE elec start, TNT, 20 in shaft 2001              | GEARCASE - 90 - 115 VX MODELS                   |
| J115PLSIE elec start, TNT, 20 in shaft 2001              | JET DRIVE UNIT                                  |
| J115PLSNF - FR                                           | 27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS  |
| J115PLSNF - FR                                           | 27-1_BOÎTIER D'ENGRENAGES - Modèles PXS         |

|                                                                    |                                                 |
|--------------------------------------------------------------------|-------------------------------------------------|
| J115PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002  | GEARCASE - PLS, VLS MODELS                      |
| J115PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002  | GEARCASE - PXS MODELS                           |
| J115PLSOR                                                          | GEARCASE - PL, GL MODELS                        |
| J115PLSOR - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL    |
| J115PLSRC                                                          | GEARCASE - PL, GL MODELS                        |
| J115PLSRC - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL    |
| J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000                      | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000                      | GEARCASE - 90 AND 115 PX, VX MODELS             |
| J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000                      | JET DRIVE UNIT                                  |
| J115PLSTS                                                          | GEARCASE - PL, GL MODELS                        |
| J115PLSTS                                                          | GEARCASE - PX - WPL MODELS                      |
| J115PLSTS - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL    |
| J115PLSTS - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL   |
| J115PXEEM 1999                                                     | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| J115PXEEM 1999                                                     | GEARCASE -- 90 & 115 PX MODELS                  |
| J115PXEEM 1999                                                     | JET DRIVE UNIT                                  |
| J115PXSDA                                                          | GEARCASE - PX MODELS                            |
| J115PXSDA - FR                                                     | 17-1_BOÎTIER D'ENGRENAGES - PX MODELES          |
| J115PXSNF - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS  |
| J115PXSNF - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PXS         |
| J115PXSNF Carbureted, 25 in. shaft, White, Remote, Elec, TNT, 2002 | GEARCASE - PLS, VLS MODELS                      |
| J115PXSNF Carbureted, 25 in. shaft, White, Remote, Elec, TNT, 2002 | GEARCASE - PXS MODELS                           |
| J115PXSOR                                                          | GEARCASE - PX - WPL MODELS                      |
| J115PXSOR - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL   |
| J115PXSRM                                                          | GEARCASE - PX - WPL MODELS                      |
| J115PXSRM - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL   |
| J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000                      | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000                      | GEARCASE - 90 AND 115 PX, VX MODELS             |
| J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000                      | JET DRIVE UNIT                                  |
| J115PXSTS                                                          | GEARCASE - PL, GL MODELS                        |
| J115PXSTS                                                          | GEARCASE - PX - WPL MODELS                      |
| J115PXSTS - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL    |
| J115PXSTS - FR                                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL   |

|                                                                 |                                                 |
|-----------------------------------------------------------------|-------------------------------------------------|
| J115SLECM 1998                                                  | GEARCASE -- 90 & 115 EL, GL, SL MODELS          |
| J115SLECM 1998                                                  | GEARCASE -- 90 & 115 SX MODELS                  |
| J115SLECM 1998                                                  | JET DRIVE UNIT                                  |
| J115SLEDR 1996                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SLEDR 1996                                                  | GEARCASE - 25 IN. MODELS                        |
| J115SLEOC 1995                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SLEOC 1995                                                  | GEARCASE - 25 IN. MODELS                        |
| J115SLEUA 1997                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SLEUA 1997                                                  | GEARCASE - 25 IN. MODELS                        |
| J115SLEUC 1997                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SLEUC 1997                                                  | GEARCASE - 25 IN. MODELS                        |
| J115SPLEES 1999                                                 | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| J115SPLEES 1999                                                 | GEARCASE -- 90 & 115 PX MODELS                  |
| J115SPLEES 1999                                                 | JET DRIVE UNIT                                  |
| J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A<br>USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS    |
| J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A<br>USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS             |
| J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A<br>USA 2000 | JET DRIVE UNIT                                  |
| J115SXECM 1998                                                  | GEARCASE -- 90 & 115 EL, GL, SL MODELS          |
| J115SXECM 1998                                                  | GEARCASE -- 90 & 115 SX MODELS                  |
| J115SXECM 1998                                                  | JET DRIVE UNIT                                  |
| J115SXEDR 1996                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SXEDR 1996                                                  | GEARCASE - 25 IN. MODELS                        |
| J115SXEOC 1995                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SXEOC 1995                                                  | GEARCASE - 25 IN. MODELS                        |
| J115SXEUA 1997                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SXEUA 1997                                                  | GEARCASE - 25 IN. MODELS                        |
| J115SXEUC 1997                                                  | GEARCASE - 20 IN. MODELS                        |
| J115SXEUC 1997                                                  | GEARCASE - 25 IN. MODELS                        |
| J115TSLECM 1998                                                 | GEARCASE                                        |
| J115TSXECM 1998                                                 | GEARCASE                                        |
| J115VLSIC elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - 90 - 115 PL - VL MODELS              |
| J115VLSIC elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - 90 - 115 VX MODELS                   |
| J115VLSIC elec start, TNT, 20 in shaft, wht 2001                | JET DRIVE UNIT                                  |
| J115VLSNF - FR                                                  | 27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS  |

|                                                                   |                                                         |
|-------------------------------------------------------------------|---------------------------------------------------------|
| J115VLSNF - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PXS                 |
| J115VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002 | GEARCASE - PLS, VLS MODELS                              |
| J115VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002 | GEARCASE - PXS MODELS                                   |
| J115VLSSS Elec. Start, 20 IN. shaft, wht 2000                     | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS            |
| J115VLSSS Elec. Start, 20 IN. shaft, wht 2000                     | GEARCASE - 90 AND 115 PX, VX MODELS                     |
| J115VLSSS Elec. Start, 20 IN. shaft, wht 2000                     | JET DRIVE UNIT                                          |
| J115VXSIC elec start, TNT, 25 in shaft, wht 2001                  | GEARCASE - 90 - 115 PL - VL MODELS                      |
| J115VXSIC elec start, TNT, 25 in shaft, wht 2001                  | GEARCASE - 90 - 115 VX MODELS                           |
| J115VXSIC elec start, TNT, 25 in shaft, wht 2001                  | JET DRIVE UNIT                                          |
| J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000               | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS            |
| J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000               | GEARCASE - 90 AND 115 PX, VX MODELS                     |
| J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000               | JET DRIVE UNIT                                          |
| J115WPLSOC                                                        | GEARCASE - PX - WPL MODELS                              |
| J115WPLSOC - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL           |
| J115WPLSRS                                                        | GEARCASE - PX - WPL MODELS                              |
| J115WPLSRS - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL           |
| J120TLARC 1994                                                    | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TLARC 1994                                                    | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TLARC 1994                                                    | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TLARK 1994                                                    | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TLARK 1994                                                    | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TLARK 1994                                                    | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TLATF 1993                                                    | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TLATF 1993                                                    | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TLATF 1993                                                    | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J120TLATS 1993                                                    | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TLATS 1993                                                    | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TLATS 1993                                                    | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J120TLERC 1994                                                    | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TLERC 1994                                                    | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TLERC 1994                                                    | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TLERK 1994                                                    | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TLERK 1994                                                    | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TLERK 1994                                                    | GEARCASE - 140CX COUNTER ROTATION                       |

|                 |                                                         |
|-----------------|---------------------------------------------------------|
| J120TLETF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TLETF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TLETF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J120TLETS 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TLETS 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TLETS 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J120TXARC 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TXARC 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TXARC 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXARK 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TXARK 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TXARK 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXATF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TXATF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXATF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J120TXATS 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TXATS 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXATS 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J120TXERC 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TXERC 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TXERC 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXERK 1994  | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J120TXERK 1994  | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J120TXERK 1994  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXETF 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TXETF 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXETF 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J120TXETS 1993  | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J120TXETS 1993  | GEARCASE - 140CX COUNTER ROTATION                       |
| J120TXETS 1993  | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J125ESXERK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J125ESXERK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J125ESXERK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| J125ESXETA 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J125ESXETA 1993 | GEARCASE - 140CX COUNTER ROTATION                       |

|                                                    |                                                         |
|----------------------------------------------------|---------------------------------------------------------|
| J125ESXETA 1993                                    | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J125ESXETF 1993                                    | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J125ESXETF 1993                                    | GEARCASE - 140CX COUNTER ROTATION                       |
| J125ESXETF 1993                                    | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J130CXAOR 1995                                     | GEARCASE - 130CX COUNTER ROTATION                       |
| J130CXAOR 1995                                     | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| J130PLEED 1999                                     | GEARCASE                                                |
| J130PLSSS Elec. Start, TNT, 20 IN. shaft 2000      | GEARCASE                                                |
| J130PXED 1999                                      | GEARCASE                                                |
| J130PXSSS Elec. Start, TNT, 25 IN. shaft 2000      | GEARCASE                                                |
| J130TLECE 1998                                     | GEARCASE                                                |
| J130TLEDM 1996                                     | GEARCASE - 130CX COUNTER ROTATION                       |
| J130TLEDM 1996                                     | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| J130TLEOA 1995                                     | GEARCASE - 130CX COUNTER ROTATION                       |
| J130TLEOA 1995                                     | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| J130TLEUB 1997                                     | GEARCASE - 130CX COUNTER-ROTATION                       |
| J130TLEUB 1997                                     | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| J130TXACB 1998                                     | GEARCASE                                                |
| J130TXADA 1996                                     | GEARCASE - 130CX COUNTER ROTATION                       |
| J130TXADA 1996                                     | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| J130TXAOR 1995                                     | GEARCASE - 130CX COUNTER ROTATION                       |
| J130TXAOR 1995                                     | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| J130TXAUM 1997                                     | GEARCASE - 130CX COUNTER-ROTATION                       |
| J130TXAUM 1997                                     | GEARCASE - 130TL & 130TX STANDARD ROTATION              |
| J130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE                                                |
| J135PLSIF elec start, TNT, 20 in shaft 2001        | GEARCASE                                                |
| J135VLSIF elec start, TNT, 20 in shaft, wht 2001   | GEARCASE                                                |
| J135VXSIF elec start, TNT, 25 in shaft, wht 2001   | GEARCASE                                                |
| J140CXARC 1994                                     | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140CXARC 1994                                     | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140CXARC 1994                                     | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXARK 1994                                     | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140CXARK 1994                                     | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140CXARK 1994                                     | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXATF 1993                                     | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |

|                |                                                         |
|----------------|---------------------------------------------------------|
| J140CXATF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXATF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J140CXATS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J140CXATS 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXATS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J140CXERE 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140CXERE 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140CXERE 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXERK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140CXERK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140CXERK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXETB 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J140CXETB 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXETB 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J140CXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J140CXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140CXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J140TLARK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140TLARK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140TLARK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140TLARR 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140TLARR 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140TLARR 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140TLATC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J140TLATC 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140TLATC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J140TLATF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| J140TLATF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140TLATF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| J140TLERK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140TLERK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140TLERK 1994 | GEARCASE - 140CX COUNTER ROTATION                       |
| J140TLERR 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION              |
| J140TLERR 1994 | GEARCASE - 120TL, 125ESX, & 140TL                       |
| J140TLERR 1994 | GEARCASE - 140CX COUNTER ROTATION                       |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J140TLETC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY      |
| J140TLETC 1993 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TLETC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX      |
| J140TLETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY      |
| J140TLETF 1993 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TLETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX      |
| J140TXARC 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION                   |
| J140TXARC 1994 | GEARCASE - 120TL, 125ESX, & 140TL                            |
| J140TXARC 1994 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXARK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION                   |
| J140TXARK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                            |
| J140TXARK 1994 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXATF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY      |
| J140TXATF 1993 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXATF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX      |
| J140TXATS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY      |
| J140TXATS 1993 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXATS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX      |
| J140TXERK 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION                   |
| J140TXERK 1994 | GEARCASE - 120TL, 125ESX, & 140TL                            |
| J140TXERK 1994 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXERR 1994 | GEARCASE - 120TX & 140TX STANDARD ROTATION                   |
| J140TXERR 1994 | GEARCASE - 120TL, 125ESX, & 140TL                            |
| J140TXERR 1994 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXETC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY      |
| J140TXETC 1993 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXETC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX      |
| J140TXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY      |
| J140TXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                            |
| J140TXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX      |
| J150CXEES 1999 | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| J150CXEES 1999 | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |
| J150CXEES 1999 | GEARCASE -- COUNTER-ROTATION -- CX MODELS                    |
| J150CXEES 1999 | JET DRIVE UNIT                                               |

|                                                                  |                                                              |
|------------------------------------------------------------------|--------------------------------------------------------------|
| J150CXSD                                                         | GEARCASE - CX, MODELS                                        |
| J150CXSD - FR                                                    | 17-1_BOÎTIER D'ENGRENAGES - CX, MODELES                      |
| J150CXSNF - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J150CXSNF - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL             |
| J150CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002 | GEARCASE - PL - VL - PX MODELS                               |
| J150CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002 | GEARCASE - CX, MODELS                                        |
| J150CXSOB                                                        | GEARCASE - CX, MODELS                                        |
| J150CXSOB - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J150CXSRM                                                        | GEARCASE - CX, MODELS                                        |
| J150CXSRM - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000      | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000      | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000      | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000      | JET DRIVE UNIT                                               |
| J150CXSTA                                                        | GEARCASE - CX, MODELS                                        |
| J150CXSTA - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J150ELARA 1994                                                   | GEARCASE - COUNTER ROTATION                                  |
| J150ELARA 1994                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELARA 1994                                                   | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150ELARA 1994                                                   | JET DRIVE UNIT                                               |
| J150ELARV 1994                                                   | GEARCASE - COUNTER ROTATION                                  |
| J150ELARV 1994                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELARV 1994                                                   | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150ELARV 1994                                                   | JET DRIVE UNIT                                               |
| J150ELATG 1993                                                   | GEARCASE - COUNTER ROTATION                                  |
| J150ELATG 1993                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELATG 1993                                                   | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150ELATG 1993                                                   | JET DRIVE UNIT                                               |
| J150ELATR 1993                                                   | GEARCASE - COUNTER ROTATION                                  |
| J150ELATR 1993                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELATR 1993                                                   | GEARCASE - STANDARD ROTATION - 25" MODELS                    |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J150ELATR 1993 | JET DRIVE UNIT                                               |
| J150ELECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| J150ELECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| J150ELECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J150ELECD 1998 | JET DRIVE UNIT                                               |
| J150ELEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J150ELEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150ELEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J150ELEDB 1996 | JET DRIVE UNIT                                               |
| J150ELEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| J150ELEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J150ELEOM 1995 | JET DRIVE UNIT                                               |
| J150ELERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150ELERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150ELERA 1994 | JET DRIVE UNIT                                               |
| J150ELERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150ELERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150ELERV 1994 | JET DRIVE UNIT                                               |
| J150ELETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150ELETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150ELETG 1993 | JET DRIVE UNIT                                               |
| J150ELETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150ELETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150ELETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150ELETR 1993 | JET DRIVE UNIT                                               |
| J150ELEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150ELEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J150ELEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150ELEUC 1997 | JET DRIVE UNIT                                               |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J150ELEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150ELEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J150ELEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150ELEUE 1997 | JET DRIVE UNIT                                               |
| J150EXARC 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150EXARC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXARC 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150EXARC 1994 | JET DRIVE UNIT                                               |
| J150EXARV 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150EXARV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXARV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150EXARV 1994 | JET DRIVE UNIT                                               |
| J150EXATG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150EXATG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXATG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150EXATG 1993 | JET DRIVE UNIT                                               |
| J150EXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150EXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXATS 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150EXATS 1993 | JET DRIVE UNIT                                               |
| J150EXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| J150EXECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| J150EXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J150EXECD 1998 | JET DRIVE UNIT                                               |
| J150EXEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J150EXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150EXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J150EXEDB 1996 | JET DRIVE UNIT                                               |
| J150EXEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| J150EXEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J150EXEOM 1995 | JET DRIVE UNIT                                               |
| J150EXERA 1994 | GEARCASE - COUNTER ROTATION                                  |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| J150EXERA 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXERA 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150EXERA 1994  | JET DRIVE UNIT                                               |
| J150EXERV 1994  | GEARCASE - COUNTER ROTATION                                  |
| J150EXERV 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXERV 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150EXERV 1994  | JET DRIVE UNIT                                               |
| J150EXETG 1993  | GEARCASE - COUNTER ROTATION                                  |
| J150EXETG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXETG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150EXETG 1993  | JET DRIVE UNIT                                               |
| J150EXETR 1993  | GEARCASE - COUNTER ROTATION                                  |
| J150EXETR 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150EXETR 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150EXETR 1993  | JET DRIVE UNIT                                               |
| J150EXEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150EXEUC 1997  | GEARCASE - COUNTER-ROTATION                                  |
| J150EXEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150EXEUC 1997  | JET DRIVE UNIT                                               |
| J150EXEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150EXEUE 1997  | GEARCASE - COUNTER-ROTATION                                  |
| J150EXEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150EXEUE 1997  | JET DRIVE UNIT                                               |
| J150FCXECR 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| J150FCXECR 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| J150FCXECR 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| J150FSLECR 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| J150FSLECR 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| J150FSLECR 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| J150FSXECR 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| J150FSXECR 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| J150FSXECR 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| J150GLECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J150GLECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| J150GLECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J150GLECD 1998 | JET DRIVE UNIT                                               |
| J150GLEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J150GLEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150GLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J150GLEDB 1996 | JET DRIVE UNIT                                               |
| J150GLEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| J150GLEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150GLEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J150GLEOM 1995 | JET DRIVE UNIT                                               |
| J150GLERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150GLERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150GLERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150GLERA 1994 | JET DRIVE UNIT                                               |
| J150GLERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150GLERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150GLERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150GLERV 1994 | JET DRIVE UNIT                                               |
| J150GLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150GLETG 1993 | JET DRIVE UNIT                                               |
| J150GLETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150GLETR 1993 | JET DRIVE UNIT                                               |
| J150GLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150GLEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J150GLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150GLEUC 1997 | JET DRIVE UNIT                                               |
| J150GLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |

|                 |                                                                                     |
|-----------------|-------------------------------------------------------------------------------------|
| J150GLEUE 1997  | GEARCASE - COUNTER-ROTATION                                                         |
| J150GLEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                                            |
| J150GLEUE 1997  | JET DRIVE UNIT                                                                      |
| J150GLSDE       | GEARCASE - PL - GL MODELS                                                           |
| J150GLSDE - FR  | 17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES                                         |
| J150GLSOB       | GEARCASE - PL - SL MODELS                                                           |
| J150GLSOB - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL                                        |
| J150GLSRM       | GEARCASE - PL - GL MODELS                                                           |
| J150GLSRM - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL                                        |
| J150GLSTA       | GEARCASE - CX, MODELS                                                               |
| J150GLSTA       | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J150GLSTA - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J150GLSTA - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J150GLSTF       | GEARCASE - STANDARD ROTATION - "F" Suffix Models                                    |
| J150GLSTF - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard                   |
| J150ICXEUC 1997 | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                                          |
| J150ICXEUC 1997 | GEARCASE -- STANDARD ROTATION -- IL MODELS                                          |
| J150ICXEUC 1997 | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS                                     |
| J150ILECR 1998  | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                                          |
| J150ILECR 1998  | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS                                   |
| J150ILECR 1998  | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS                                    |
| J150ILEUC 1997  | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                                          |
| J150ILEUC 1997  | GEARCASE -- STANDARD ROTATION -- IL MODELS                                          |
| J150ILEUC 1997  | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS                                     |
| J150IXEUC 1997  | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                                          |
| J150IXEUC 1997  | GEARCASE -- STANDARD ROTATION -- IL MODELS                                          |
| J150IXEUC 1997  | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS                                     |
| J150JLECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS                         |
| J150JLECD 1998  | GEARCASE -- COUNTER-ROTATION                                                        |
| J150JLECD 1998  | GEARCASE -- STANDARD ROTATION -- GL MODELS                                          |
| J150JLECD 1998  | JET DRIVE UNIT                                                                      |
| J150JLEDB 1996  | GEARCASE - COUNTER-ROTATION                                                         |
| J150JLEDB 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                                            |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| J150JLEDB 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J150JLEDB 1996  | JET DRIVE UNIT                                               |
| J150JLEOM 1995  | GEARCASE - COUNTER ROTATION                                  |
| J150JLEOM 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150JLEOM 1995  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J150JLEOM 1995  | JET DRIVE UNIT                                               |
| J150JLERA 1994  | GEARCASE - COUNTER ROTATION                                  |
| J150JLERA 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150JLERA 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150JLERA 1994  | JET DRIVE UNIT                                               |
| J150JLERV 1994  | GEARCASE - COUNTER ROTATION                                  |
| J150JLERV 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150JLERV 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150JLERV 1994  | JET DRIVE UNIT                                               |
| J150JLETG 1993  | GEARCASE - COUNTER ROTATION                                  |
| J150JLETG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150JLETG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150JLETG 1993  | JET DRIVE UNIT                                               |
| J150JLETR 1993  | GEARCASE - COUNTER ROTATION                                  |
| J150JLETR 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150JLETR 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150JLETR 1993  | JET DRIVE UNIT                                               |
| J150JLEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150JLEUC 1997  | GEARCASE - COUNTER-ROTATION                                  |
| J150JLEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150JLEUC 1997  | JET DRIVE UNIT                                               |
| J150JLEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150JLEUE 1997  | GEARCASE - COUNTER-ROTATION                                  |
| J150JLEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150JLEUE 1997  | JET DRIVE UNIT                                               |
| J150JPLEES 1999 | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| J150JPLEES 1999 | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |

|                                                           |                                                                                     |
|-----------------------------------------------------------|-------------------------------------------------------------------------------------|
| J150JPLEES 1999                                           | GEARCASE -- COUNTER-ROTATION -- CX MODELS                                           |
| J150JPLEES 1999                                           | JET DRIVE UNIT                                                                      |
| J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - PL MODELS                                            |
| J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - VL, VX MODELS                                        |
| J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001   | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS                                  |
| J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001   | JET DRIVE UNIT                                                                      |
| J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL MODELS                                            |
| J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS                              |
| J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS                                    |
| J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000 | JET DRIVE UNIT                                                                      |
| J150MLSOR                                                 | GEARCASE - ML - MX - PX MODELS                                                      |
| J150MLSRC                                                 | GEARCASE - ML - MX - PX MODELS                                                      |
| J150MLSRC - FR                                            | 27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX                                    |
| J150MLSTS                                                 | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J150MLSTS - FR                                            | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J150MXSOR                                                 | GEARCASE - ML - MX - PX MODELS                                                      |
| J150MXSRC                                                 | GEARCASE - ML - MX - PX MODELS                                                      |
| J150MXSRC - FR                                            | 27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX                                    |
| J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000   | GEARCASE - STANDARD ROTATION - PL MODELS                                            |
| J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000   | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS                              |
| J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000   | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS                                    |
| J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000   | JET DRIVE UNIT                                                                      |
| J150MXSTS                                                 | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J150MXSTS - FR                                            | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J150NXARC 1994                                            | GEARCASE - COUNTER ROTATION                                                         |
| J150NXARC 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                                        |
| J150NXARC 1994                                            | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS                        |
| J150NXARC 1994                                            | JET DRIVE UNIT                                                                      |
| J150NXARV 1994                                            | GEARCASE - COUNTER ROTATION                                                         |
| J150NXARV 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                                        |
| J150NXARV 1994                                            | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS                        |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J150NXARV 1994 | JET DRIVE UNIT                                               |
| J150NXATG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150NXATG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150NXATG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150NXATG 1993 | JET DRIVE UNIT                                               |
| J150NXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150NXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150NXATS 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150NXATS 1993 | JET DRIVE UNIT                                               |
| J150NXCED 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| J150NXCED 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| J150NXCED 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J150NXCED 1998 | JET DRIVE UNIT                                               |
| J150NXEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J150NXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150NXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J150NXEDB 1996 | JET DRIVE UNIT                                               |
| J150NXEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| J150NXEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150NXEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J150NXEOM 1995 | JET DRIVE UNIT                                               |
| J150NXERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150NXERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150NXERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150NXERA 1994 | JET DRIVE UNIT                                               |
| J150NXERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| J150NXERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150NXERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J150NXERV 1994 | JET DRIVE UNIT                                               |
| J150NXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J150NXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150NXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150NXETG 1993 | JET DRIVE UNIT                                               |

|                                                         |                                                              |
|---------------------------------------------------------|--------------------------------------------------------------|
| J150NXETR 1993                                          | GEARCASE - COUNTER ROTATION                                  |
| J150NXETR 1993                                          | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150NXETR 1993                                          | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J150NXETR 1993                                          | JET DRIVE UNIT                                               |
| J150NXEUC 1997                                          | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150NXEUC 1997                                          | GEARCASE - COUNTER-ROTATION                                  |
| J150NXEUC 1997                                          | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150NXEUC 1997                                          | JET DRIVE UNIT                                               |
| J150NXEUE 1997                                          | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150NXEUE 1997                                          | GEARCASE - COUNTER-ROTATION                                  |
| J150NXEUE 1997                                          | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150NXEUE 1997                                          | JET DRIVE UNIT                                               |
| J150PLEES 1999                                          | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| J150PLEES 1999                                          | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |
| J150PLEES 1999                                          | GEARCASE -- COUNTER-ROTATION -- CX MODELS                    |
| J150PLEES 1999                                          | JET DRIVE UNIT                                               |
| J150PLEUC 1997                                          | GEARCASE -- COUNTER-ROTATION -- ICX MODELS                   |
| J150PLEUC 1997                                          | GEARCASE -- STANDARD ROTATION -- IL MODELS                   |
| J150PLEUC 1997                                          | GEARCASE -- STANDARD ROTATION -- PL & IX MODELS              |
| J150PLSDD                                               | GEARCASE - PL - GL MODELS                                    |
| J150PLSDD - FR                                          | 17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES                  |
| J150PLSIF elec start, TNT, 20 in shaft 2001             | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J150PLSIF elec start, TNT, 20 in shaft 2001             | GEARCASE - STANDARD ROTATION - VL, VX MODELS                 |
| J150PLSIF elec start, TNT, 20 in shaft 2001             | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS           |
| J150PLSIF elec start, TNT, 20 in shaft 2001             | JET DRIVE UNIT                                               |
| J150PLSNF - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J150PLSNF - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL             |
| J150PLSNF Carbureted, 20 in. shaft, Smoke 2002          | GEARCASE - PL - VL - PX MODELS                               |
| J150PLSNF Carbureted, 20 in. shaft, Smoke 2002          | GEARCASE - CX, MODELS                                        |
| J150PLSOE                                               | GEARCASE - PL - SL MODELS                                    |
| J150PLSOE - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL                 |
| J150PLSRB                                               | GEARCASE - PL - GL MODELS                                    |
| J150PLSRB - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL                 |
| J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL MODELS                     |

|                                                         |                                                                                     |
|---------------------------------------------------------|-------------------------------------------------------------------------------------|
| J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS                              |
| J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS                                    |
| J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000 | JET DRIVE UNIT                                                                      |
| J150PLSTF                                               | GEARCASE - STANDARD ROTATION - "F" Suffix Models                                    |
| J150PLSTF - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard                   |
| J150PLSTM                                               | GEARCASE - CX, MODELS                                                               |
| J150PLSTM                                               | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J150PLSTM - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J150PLSTM - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J150PXEEES 1999                                         | GEARCASE -- STANDARD ROTATION -- PL MODELS                                          |
| J150PXEEES 1999                                         | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS                        |
| J150PXEEES 1999                                         | GEARCASE -- COUNTER-ROTATION -- CX MODELS                                           |
| J150PXEEES 1999                                         | JET DRIVE UNIT                                                                      |
| J150PXSD                                                | GEARCASE - PX MODELS                                                                |
| J150PXSD - FR                                           | 17-1_BOÎTIER D'ENGRENAGES - PX MODELS                                               |
| J150PXSNF - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J150PXSNF - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL                                    |
| J150PXSNF Carbureted, 25 in. shaft, White 2002          | GEARCASE - PL - VL - PX MODELS                                                      |
| J150PXSNF Carbureted, 25 in. shaft, White 2002          | GEARCASE - CX, MODELS                                                               |
| J150PXSOE                                               | GEARCASE - PX MODELS                                                                |
| J150PXSOE - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX                                              |
| J150PXSRB                                               | GEARCASE - ML - MX - PX MODELS                                                      |
| J150PXSRB - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX                                    |
| J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000           | GEARCASE - STANDARD ROTATION - PL MODELS                                            |
| J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000           | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS                              |
| J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000           | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS                                    |
| J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000           | JET DRIVE UNIT                                                                      |
| J150PXSTM                                               | GEARCASE - CX, MODELS                                                               |
| J150PXSTM                                               | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J150PXSTM - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J150PXSTM - FR                                          | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J150SLECD 1998                                          | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS                         |

|                                                                 |                                                              |
|-----------------------------------------------------------------|--------------------------------------------------------------|
| J150SLECD 1998                                                  | GEARCASE -- COUNTER-ROTATION                                 |
| J150SLECD 1998                                                  | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J150SLECD 1998                                                  | JET DRIVE UNIT                                               |
| J150SLEDB 1996                                                  | GEARCASE - COUNTER-ROTATION                                  |
| J150SLEDB 1996                                                  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150SLEDB 1996                                                  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J150SLEDB 1996                                                  | JET DRIVE UNIT                                               |
| J150SLEOM 1995                                                  | GEARCASE - COUNTER ROTATION                                  |
| J150SLEOM 1995                                                  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J150SLEOM 1995                                                  | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J150SLEOM 1995                                                  | JET DRIVE UNIT                                               |
| J150SLEUC 1997                                                  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150SLEUC 1997                                                  | GEARCASE - COUNTER-ROTATION                                  |
| J150SLEUC 1997                                                  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150SLEUC 1997                                                  | JET DRIVE UNIT                                               |
| J150SLEUE 1997                                                  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J150SLEUE 1997                                                  | GEARCASE - COUNTER-ROTATION                                  |
| J150SLEUE 1997                                                  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J150SLEUE 1997                                                  | JET DRIVE UNIT                                               |
| J150SPLEES 1999                                                 | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| J150SPLEES 1999                                                 | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |
| J150SPLEES 1999                                                 | GEARCASE -- COUNTER-ROTATION -- CX MODELS                    |
| J150SPLEES 1999                                                 | JET DRIVE UNIT                                               |
| J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                  | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                  | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                  | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                  | JET DRIVE UNIT                                               |
| J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                               |

|                                                                 |                                                        |
|-----------------------------------------------------------------|--------------------------------------------------------|
| J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | JET DRIVE UNIT                                         |
| J150VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J150VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| J150VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| J150VLSIF elec start, TNT, 20 in shaft, wht 2001                | JET DRIVE UNIT                                         |
| J150VLSNF - FR                                                  | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                 |
| J150VLSNF - FR                                                  | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL       |
| J150VLSNF Carbureted, 20 in. shaft, White 2002                  | GEARCASE - PL - VL - PX MODELS                         |
| J150VLSNF Carbureted, 20 in. shaft, White 2002                  | GEARCASE - CX, MODELS                                  |
| J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                         |
| J150VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J150VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| J150VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| J150VXSIF elec start, TNT, 25 in shaft, wht 2001                | JET DRIVE UNIT                                         |
| J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                         |
| J150WPLEES 1999                                                 | GEARCASE                                               |
| J150WPLSIF commercial, elec start, TNT, 20 in shaft 2001        | GEARCASE                                               |
| J150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000       | GEARCASE                                               |
| J150WTLEOR 1995                                                 | GEARCASE                                               |

|                                                                  |                                                              |
|------------------------------------------------------------------|--------------------------------------------------------------|
| J150WTLERC 1994                                                  | GEARCASE                                                     |
| J150WTLERV 1994                                                  | GEARCASE                                                     |
| J150WTLETG 1993                                                  | GEARCASE - 20" MODELS                                        |
| J150WTLETG 1993                                                  | GEARCASE - 25" MODELS                                        |
| J150WTLETS 1993                                                  | GEARCASE - 20" MODELS                                        |
| J150WTLETS 1993                                                  | GEARCASE - 25" MODELS                                        |
| J150WTXEOR 1995                                                  | GEARCASE                                                     |
| J150WTXERC 1994                                                  | GEARCASE                                                     |
| J150WTXERV 1994                                                  | GEARCASE                                                     |
| J150WTXETG 1993                                                  | GEARCASE - 20" MODELS                                        |
| J150WTXETG 1993                                                  | GEARCASE - 25" MODELS                                        |
| J150WTXETS 1993                                                  | GEARCASE - 20" MODELS                                        |
| J150WTXETS 1993                                                  | GEARCASE - 25" MODELS                                        |
| J175CXEES 1999                                                   | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| J175CXEES 1999                                                   | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |
| J175CXEES 1999                                                   | GEARCASE -- COUNTER-ROTATION -- CX MODELS                    |
| J175CXEES 1999                                                   | JET DRIVE UNIT                                               |
| J175CXSD                                                         | GEARCASE - CX, MODELS                                        |
| J175CXSD - FR                                                    | 17-1_BOÎTIER D'ENGRENAGES - CX, MODELES                      |
| J175CXSNF - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J175CXSNF - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL             |
| J175CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002 | GEARCASE - PL - VL - PX MODELS                               |
| J175CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002 | GEARCASE - CX, MODELS                                        |
| J175CXSOB                                                        | GEARCASE - CX, MODELS                                        |
| J175CXSOB - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J175CXSRM                                                        | GEARCASE - CX, MODELS                                        |
| J175CXSRM - FR                                                   | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000  | JET DRIVE UNIT                                               |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J175CXSTA      | GEARCASE - CX, MODELS                                        |
| J175CXSTA - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                       |
| J175EXARC 1994 | GEARCASE - COUNTER ROTATION                                  |
| J175EXARC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXARC 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J175EXARC 1994 | JET DRIVE UNIT                                               |
| J175EXARV 1994 | GEARCASE - COUNTER ROTATION                                  |
| J175EXARV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXARV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J175EXARV 1994 | JET DRIVE UNIT                                               |
| J175EXATG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J175EXATG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXATG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175EXATG 1993 | JET DRIVE UNIT                                               |
| J175EXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| J175EXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXATS 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175EXATS 1993 | JET DRIVE UNIT                                               |
| J175EXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |
| J175EXECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| J175EXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J175EXECD 1998 | JET DRIVE UNIT                                               |
| J175EXEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J175EXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175EXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J175EXEDB 1996 | JET DRIVE UNIT                                               |
| J175EXEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| J175EXEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J175EXEOM 1995 | JET DRIVE UNIT                                               |
| J175EXERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| J175EXERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| J175EXERA 1994  | JET DRIVE UNIT                                               |
| J175EXERV 1994  | GEARCASE - COUNTER ROTATION                                  |
| J175EXERV 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXERV 1994  | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J175EXERV 1994  | JET DRIVE UNIT                                               |
| J175EXETG 1993  | GEARCASE - COUNTER ROTATION                                  |
| J175EXETG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXETG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175EXETG 1993  | JET DRIVE UNIT                                               |
| J175EXETR 1993  | GEARCASE - COUNTER ROTATION                                  |
| J175EXETR 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175EXETR 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175EXETR 1993  | JET DRIVE UNIT                                               |
| J175EXEUC 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J175EXEUC 1997  | GEARCASE - COUNTER-ROTATION                                  |
| J175EXEUC 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175EXEUC 1997  | JET DRIVE UNIT                                               |
| J175EXEUE 1997  | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J175EXEUE 1997  | GEARCASE - COUNTER-ROTATION                                  |
| J175EXEUE 1997  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175EXEUE 1997  | JET DRIVE UNIT                                               |
| J175FCXECS 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| J175FCXECS 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| J175FCXECS 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| J175FSLECS 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| J175FSLECS 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| J175FSLECS 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| J175FSXECS 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| J175FSXECS 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| J175FSXECS 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| J175FTLECS 1998 | GEARCASE -- COUNTER-ROTATION -- FCX MODELS                   |
| J175FTLECS 1998 | GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS            |
| J175FTLECS 1998 | GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS             |
| J175GLECD 1998  | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS  |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J175GLECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| J175GLECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J175GLECD 1998 | JET DRIVE UNIT                                               |
| J175GLEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J175GLEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175GLEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J175GLEDB 1996 | JET DRIVE UNIT                                               |
| J175GLEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| J175GLEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175GLEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J175GLEOM 1995 | JET DRIVE UNIT                                               |
| J175GLERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| J175GLERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175GLERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J175GLERA 1994 | JET DRIVE UNIT                                               |
| J175GLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J175GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175GLETG 1993 | JET DRIVE UNIT                                               |
| J175GLETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| J175GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175GLETR 1993 | JET DRIVE UNIT                                               |
| J175GLEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J175GLEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J175GLEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175GLEUC 1997 | JET DRIVE UNIT                                               |
| J175GLEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J175GLEUE 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J175GLEUE 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175GLEUE 1997 | JET DRIVE UNIT                                               |
| J175GLSDE      | GEARCASE - PL - GL MODELS                                    |
| J175GLSDE - FR | 17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES                  |

|                |                                                                                     |
|----------------|-------------------------------------------------------------------------------------|
| J175GLSOB      | GEARCASE - PL - SL MODELS                                                           |
| J175GLSOB - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL                                        |
| J175GLSRM      | GEARCASE - PL - GL MODELS                                                           |
| J175GLSRM - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL                                        |
| J175GLSTA      | GEARCASE - CX, MODELS                                                               |
| J175GLSTA      | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J175GLSTA - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J175GLSTA - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J175GLSTF      | GEARCASE - STANDARD ROTATION - "F" Suffix Models                                    |
| J175GLSTF - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard                   |
| J175MXSOR      | GEARCASE - ML - MX - PX MODELS                                                      |
| J175MXSRC      | GEARCASE - ML - MX - PX MODELS                                                      |
| J175MXSRC - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX                                    |
| J175MXSTS      | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J175MXSTS - FR | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J175NXARC 1994 | GEARCASE - COUNTER ROTATION                                                         |
| J175NXARC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                                        |
| J175NXARC 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS                        |
| J175NXARC 1994 | JET DRIVE UNIT                                                                      |
| J175NXARV 1994 | GEARCASE - COUNTER ROTATION                                                         |
| J175NXARV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                                        |
| J175NXARV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS                        |
| J175NXARV 1994 | JET DRIVE UNIT                                                                      |
| J175NXATG 1993 | GEARCASE - COUNTER ROTATION                                                         |
| J175NXATG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                                        |
| J175NXATG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                                           |
| J175NXATG 1993 | JET DRIVE UNIT                                                                      |
| J175NXATS 1993 | GEARCASE - COUNTER ROTATION                                                         |
| J175NXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                                        |
| J175NXATS 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                                           |
| J175NXATS 1993 | JET DRIVE UNIT                                                                      |
| J175NXECD 1998 | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS                         |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J175NXECD 1998 | GEARCASE -- COUNTER-ROTATION                                 |
| J175NXECD 1998 | GEARCASE -- STANDARD ROTATION -- GL MODELS                   |
| J175NXECD 1998 | JET DRIVE UNIT                                               |
| J175NXEDB 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J175NXEDB 1996 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175NXEDB 1996 | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| J175NXEDB 1996 | JET DRIVE UNIT                                               |
| J175NXEOM 1995 | GEARCASE - COUNTER ROTATION                                  |
| J175NXEOM 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175NXEOM 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| J175NXEOM 1995 | JET DRIVE UNIT                                               |
| J175NXERA 1994 | GEARCASE - COUNTER ROTATION                                  |
| J175NXERA 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175NXERA 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J175NXERA 1994 | JET DRIVE UNIT                                               |
| J175NXERV 1994 | GEARCASE - COUNTER ROTATION                                  |
| J175NXERV 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175NXERV 1994 | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J175NXERV 1994 | JET DRIVE UNIT                                               |
| J175NXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| J175NXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175NXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175NXETG 1993 | JET DRIVE UNIT                                               |
| J175NXETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| J175NXETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175NXETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| J175NXETR 1993 | JET DRIVE UNIT                                               |
| J175NXEUC 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J175NXEUC 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J175NXEUC 1997 | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175NXEUC 1997 | JET DRIVE UNIT                                               |
| J175NXEUE 1997 | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |

|                                                |                                                                                     |
|------------------------------------------------|-------------------------------------------------------------------------------------|
| J175NXEUE 1997                                 | GEARCASE - COUNTER-ROTATION                                                         |
| J175NXEUE 1997                                 | GEARCASE - STANDARD ROTATION - GL MODELS                                            |
| J175NXEUE 1997                                 | JET DRIVE UNIT                                                                      |
| J175PLEES 1999                                 | GEARCASE -- STANDARD ROTATION -- PL MODELS                                          |
| J175PLEES 1999                                 | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS                        |
| J175PLEES 1999                                 | GEARCASE -- COUNTER-ROTATION -- CX MODELS                                           |
| J175PLEES 1999                                 | JET DRIVE UNIT                                                                      |
| J175PLSDD                                      | GEARCASE - PL - GL MODELS                                                           |
| J175PLSDD - FR                                 | 17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES                                         |
| J175PLSIF elec start, TNT, 20 in shaft 2001    | GEARCASE - STANDARD ROTATION - PL MODELS                                            |
| J175PLSIF elec start, TNT, 20 in shaft 2001    | GEARCASE - STANDARD ROTATION - VL, VX MODELS                                        |
| J175PLSIF elec start, TNT, 20 in shaft 2001    | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS                                  |
| J175PLSIF elec start, TNT, 20 in shaft 2001    | JET DRIVE UNIT                                                                      |
| J175PLSNF - FR                                 | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J175PLSNF - FR                                 | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL                                    |
| J175PLSNF Carbureted, 20 in. shaft, Smoke 2002 | GEARCASE - PL - VL - PX MODELS                                                      |
| J175PLSNF Carbureted, 20 in. shaft, Smoke 2002 | GEARCASE - CX, MODELS                                                               |
| J175PLSOE                                      | GEARCASE - PL - SL MODELS                                                           |
| J175PLSOE - FR                                 | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL                                        |
| J175PLSRB                                      | GEARCASE - PL - GL MODELS                                                           |
| J175PLSRB - FR                                 | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL                                        |
| J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000  | GEARCASE - STANDARD ROTATION - PL MODELS                                            |
| J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000  | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS                              |
| J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000  | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS                                    |
| J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000  | JET DRIVE UNIT                                                                      |
| J175PLSTF                                      | GEARCASE - STANDARD ROTATION - "F" Suffix Models                                    |
| J175PLSTF - FR                                 | 27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard                   |
| J175PLSTM                                      | GEARCASE - CX, MODELS                                                               |
| J175PLSTM                                      | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J175PLSTM - FR                                 | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J175PLSTM - FR                                 | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J175PXEEES 1999                                | GEARCASE -- STANDARD ROTATION -- PL MODELS                                          |
| J175PXEEES 1999                                | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS                        |

|                                                    |                                                                                     |
|----------------------------------------------------|-------------------------------------------------------------------------------------|
| J175PXEEES 1999                                    | GEARCASE -- COUNTER-ROTATION -- CX MODELS                                           |
| J175PXEEES 1999                                    | JET DRIVE UNIT                                                                      |
| J175PXSD                                           | GEARCASE - PX MODELS                                                                |
| J175PXSD - FR                                      | 17-1_BOÎTIER D'ENGRENAGES - PX MODELS                                               |
| J175PXSNF - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J175PXSNF - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL                                    |
| J175PXSNF Carbureted, 25 in. shaft, White 2002     | GEARCASE - PL - VL - PX MODELS                                                      |
| J175PXSNF Carbureted, 25 in. shaft, White 2002     | GEARCASE - CX, MODELS                                                               |
| J175PXSOE                                          | GEARCASE - PX MODELS                                                                |
| J175PXSOE - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX                                              |
| J175PXSRB                                          | GEARCASE - ML - MX - PX MODELS                                                      |
| J175PXSRB - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX                                    |
| J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PL MODELS                                            |
| J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS                              |
| J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS                                    |
| J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000 | JET DRIVE UNIT                                                                      |
| J175PXSTM                                          | GEARCASE - CX, MODELS                                                               |
| J175PXSTM                                          | GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix                |
| J175PXSTM - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                                              |
| J175PXSTM - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S" |
| J175SLECD 1998                                     | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS                         |
| J175SLECD 1998                                     | GEARCASE -- COUNTER-ROTATION                                                        |
| J175SLECD 1998                                     | GEARCASE -- STANDARD ROTATION -- GL MODELS                                          |
| J175SLECD 1998                                     | JET DRIVE UNIT                                                                      |
| J175SLEDB 1996                                     | GEARCASE - COUNTER-ROTATION                                                         |
| J175SLEDB 1996                                     | GEARCASE - STANDARD ROTATION - GL MODELS                                            |
| J175SLEDB 1996                                     | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"                           |
| J175SLEDB 1996                                     | JET DRIVE UNIT                                                                      |
| J175SLEOM 1995                                     | GEARCASE - COUNTER ROTATION                                                         |
| J175SLEOM 1995                                     | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                                        |
| J175SLEOM 1995                                     | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS                        |
| J175SLEOM 1995                                     | JET DRIVE UNIT                                                                      |
| J175SLERA 1994                                     | GEARCASE - COUNTER ROTATION                                                         |

|                                                                  |                                                              |
|------------------------------------------------------------------|--------------------------------------------------------------|
| J175SLERA 1994                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J175SLERA 1994                                                   | GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS |
| J175SLERA 1994                                                   | JET DRIVE UNIT                                               |
| J175SLEUC 1997                                                   | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J175SLEUC 1997                                                   | GEARCASE - COUNTER-ROTATION                                  |
| J175SLEUC 1997                                                   | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175SLEUC 1997                                                   | JET DRIVE UNIT                                               |
| J175SLEUE 1997                                                   | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| J175SLEUE 1997                                                   | GEARCASE - COUNTER-ROTATION                                  |
| J175SLEUE 1997                                                   | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| J175SLEUE 1997                                                   | JET DRIVE UNIT                                               |
| J175SPLEES 1999                                                  | GEARCASE -- STANDARD ROTATION -- PL MODELS                   |
| J175SPLEES 1999                                                  | GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS |
| J175SPLEES 1999                                                  | GEARCASE -- COUNTER-ROTATION -- CX MODELS                    |
| J175SPLEES 1999                                                  | JET DRIVE UNIT                                               |
| J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | JET DRIVE UNIT                                               |
| J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VL, VX MODELS                 |
| J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS           |
| J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | JET DRIVE UNIT                                               |
| J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS       |
| J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS             |
| J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                               |
| J175VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - PL MODELS                     |
| J175VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - VL, VX MODELS                 |

|                                                    |                                                        |
|----------------------------------------------------|--------------------------------------------------------|
| J175VLSIF elec start, TNT, 20 in shaft, wht 2001   | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| J175VLSIF elec start, TNT, 20 in shaft, wht 2001   | JET DRIVE UNIT                                         |
| J175VLSNF - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles CX                 |
| J175VLSNF - FR                                     | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL       |
| J175VLSNF Carbureted, 20 in. shaft, White 2002     | GEARCASE - PL - VL - PX MODELS                         |
| J175VLSNF Carbureted, 20 in. shaft, White 2002     | GEARCASE - CX, MODELS                                  |
| J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000 | JET DRIVE UNIT                                         |
| J175VXSIF elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J175VXSIF elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| J175VXSIF elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| J175VXSIF elec start, TNT, 25 in shaft, wht 2001   | JET DRIVE UNIT                                         |
| J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | JET DRIVE UNIT                                         |
| J185ESERK 1994                                     | GEARCASE - COUNTER ROTATION                            |
| J185ESERK 1994                                     | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| J185ESERK 1994                                     | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| J185ESXETA 1993                                    | GEARCASE - COUNTER ROTATION                            |
| J185ESXETA 1993                                    | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| J185ESXETA 1993                                    | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| J185ESXETF 1993                                    | GEARCASE - COUNTER ROTATION                            |
| J185ESXETF 1993                                    | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| J185ESXETF 1993                                    | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| J200CXARC 1994                                     | GEARCASE - COUNTER ROTATION                            |
| J200CXARC 1994                                     | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| J200CXARC 1994                                     | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| J200CXARK 1994                                     | GEARCASE - COUNTER ROTATION                            |
| J200CXARK 1994                                     | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |
| J200CXARK 1994                                     | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS  |
| J200CXATF 1993                                     | GEARCASE - COUNTER ROTATION                            |
| J200CXATF 1993                                     | GEARCASE - STANDARD ROTATION - 20 IN. MODELS           |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J200CXATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| J200CXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXECM 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J200CXECM 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J200CXECM 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J200CXEDR 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J200CXEDR 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXEDR 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXEEB 1999 | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J200CXEEB 1999 | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J200CXEEB 1999 | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J200CXEEN 1999 | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J200CXEEN 1999 | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J200CXEEN 1999 | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J200CXEOC 1995 | GEARCASE - COUNTER ROTATION                                  |
| J200CXEOC 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXEOC 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| J200CXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXERS 1994 | GEARCASE - COUNTER ROTATION                                  |
| J200CXERS 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXERS 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXETD 1993 | GEARCASE - COUNTER ROTATION                                  |
| J200CXETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| J200CXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200CXEUA 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J200CXEUA 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200CXEUA 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |

|                                                           |                                                       |
|-----------------------------------------------------------|-------------------------------------------------------|
| J200XSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS         |
| J200XSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS         |
| J200XSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS          |
| J200XSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS           |
| J200CZARK 1994                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZARK 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZARK 1994                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200CZATF 1993                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZATF 1993                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZATF 1993                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200CZATS 1993                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZATS 1993                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZATS 1993                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200CZEOC 1995                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZEOC 1995                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZEOC 1995                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200CZERK 1994                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZERK 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZERK 1994                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200CZERS 1994                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZERS 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZERS 1994                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200CZETD 1993                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZETD 1993                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZETD 1993                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200CZETF 1993                                            | GEARCASE - COUNTER ROTATION                           |
| J200CZETF 1993                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200CZETF 1993                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200PLEEB 1999                                            | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS       |
| J200PLEEB 1999                                            | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS        |
| J200PLEEB 1999                                            | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS         |
| J200PLEEN 1999                                            | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS       |
| J200PLEEN 1999                                            | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS        |

|                                               |                                                              |
|-----------------------------------------------|--------------------------------------------------------------|
| J200PLEEN 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J200PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - VL - HGL MODELS               |
| J200PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS          |
| J200PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - VX - VZ MODELS                |
| J200PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS     |
| J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |
| J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J200PXEEB 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J200PXEEB 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J200PXEEB 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J200PXEEB 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J200PXEEB 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J200PXEEB 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |
| J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J200STLECE 1998                               | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J200STLECE 1998                               | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J200STLECE 1998                               | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J200STLEDM 1996                               | GEARCASE - COUNTER-ROTATION                                  |
| J200STLEDM 1996                               | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200STLEDM 1996                               | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200STLEOA 1995                               | GEARCASE - COUNTER ROTATION                                  |
| J200STLEOA 1995                               | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200STLEOA 1995                               | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200STLERK 1994                               | GEARCASE - COUNTER ROTATION                                  |
| J200STLERK 1994                               | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200STLERK 1994                               | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200STLERR 1994                               | GEARCASE - COUNTER ROTATION                                  |
| J200STLERR 1994                               | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200STLERR 1994                               | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| J200STLETC 1993 | GEARCASE - COUNTER ROTATION                                  |
| J200STLETC 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200STLETC 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200STLETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| J200STLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200STLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200STLEUB 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J200STLEUB 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200STLEUB 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200TLECM 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J200TLECM 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J200TLECM 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J200TXARC 1994  | GEARCASE - COUNTER ROTATION                                  |
| J200TXARC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200TXARC 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200TXARK 1994  | GEARCASE - COUNTER ROTATION                                  |
| J200TXARK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200TXARK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200TXATF 1993  | GEARCASE - COUNTER ROTATION                                  |
| J200TXATF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200TXATF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200TXATS 1993  | GEARCASE - COUNTER ROTATION                                  |
| J200TXATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200TXATS 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200TXECM 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J200TXECM 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J200TXECM 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J200TXEDR 1996  | GEARCASE - COUNTER-ROTATION                                  |
| J200TXEDR 1996  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200TXEDR 1996  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200TXEOC 1995  | GEARCASE - COUNTER ROTATION                                  |
| J200TXEOC 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J200TXEOC 1995  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J200TXERK 1994  | GEARCASE - COUNTER ROTATION                                  |

|                |                                                       |
|----------------|-------------------------------------------------------|
| J200TXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TXERS 1994 | GEARCASE - COUNTER ROTATION                           |
| J200TXERS 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TXERS 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TXETD 1993 | GEARCASE - COUNTER ROTATION                           |
| J200TXETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TXETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TXETF 1993 | GEARCASE - COUNTER ROTATION                           |
| J200TXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TXEUA 1997 | GEARCASE - COUNTER-ROTATION                           |
| J200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TZARK 1994 | GEARCASE - COUNTER ROTATION                           |
| J200TZARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TZARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TZATF 1993 | GEARCASE - COUNTER ROTATION                           |
| J200TZATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TZATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TZATS 1993 | GEARCASE - COUNTER ROTATION                           |
| J200TZATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TZATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TZEOD 1995 | GEARCASE - COUNTER ROTATION                           |
| J200TZEOD 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TZEOD 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TZERK 1994 | GEARCASE - COUNTER ROTATION                           |
| J200TZERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TZERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TZERS 1994 | GEARCASE - COUNTER ROTATION                           |
| J200TZERS 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TZERS 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J200TZETD 1993 | GEARCASE - COUNTER ROTATION                           |
| J200TZETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J200TZETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |

|                                                                  |                                                          |
|------------------------------------------------------------------|----------------------------------------------------------|
| J200TZETF 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J200TZETF 1993                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J200TZETF 1993                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J200VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J200VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J200VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J200VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J200VXSIF elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J200VXSIF elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J200VXSIF elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J200VXSIF elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000               | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000               | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000               | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000               | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J200WPXEEN 1999                                                  | GEARCASE                                                 |
| J200WPXEES 1999                                                  | GEARCASE                                                 |
| J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001         | GEARCASE                                                 |
| J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000         | GEARCASE                                                 |
| J225CXARC 1994                                                   | GEARCASE - COUNTER ROTATION                              |
| J225CXARC 1994                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J225CXARC 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXARK 1994 | GEARCASE - COUNTER ROTATION                                  |
| J225CXARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXATF 1993 | GEARCASE - COUNTER ROTATION                                  |
| J225CXATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| J225CXATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J225CXECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J225CXECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J225CXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J225CXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXEEC 1999 | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J225CXEEC 1999 | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J225CXEEC 1999 | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J225CXEEN 1999 | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J225CXEEN 1999 | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J225CXEEN 1999 | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J225CXEOB 1995 | GEARCASE - COUNTER ROTATION                                  |
| J225CXEOB 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| J225CXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXERM 1994 | GEARCASE - COUNTER ROTATION                                  |
| J225CXERM 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXERM 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXETA 1993 | GEARCASE - COUNTER ROTATION                                  |
| J225CXETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |

|                                                           |                                                              |
|-----------------------------------------------------------|--------------------------------------------------------------|
| J225CXETF 1993                                            | GEARCASE - COUNTER ROTATION                                  |
| J225CXETF 1993                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXETF 1993                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXEUD 1997                                            | GEARCASE - COUNTER-ROTATION                                  |
| J225CXEUD 1997                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CXEUD 1997                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |
| J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J225CZARK 1994                                            | GEARCASE - COUNTER ROTATION                                  |
| J225CZARK 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CZARK 1994                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CZATF 1993                                            | GEARCASE - COUNTER ROTATION                                  |
| J225CZATF 1993                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CZATF 1993                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CZATS 1993                                            | GEARCASE - COUNTER ROTATION                                  |
| J225CZATS 1993                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CZATS 1993                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CZECS 1998                                            | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J225CZECS 1998                                            | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J225CZECS 1998                                            | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J225CZEDE 1996                                            | GEARCASE - COUNTER-ROTATION                                  |
| J225CZEDE 1996                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CZEDE 1996                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CZEOB 1995                                            | GEARCASE - COUNTER ROTATION                                  |
| J225CZEOB 1995                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CZEOB 1995                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CZERK 1994                                            | GEARCASE - COUNTER ROTATION                                  |
| J225CZERK 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225CZERK 1994                                            | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225CZERM 1994                                            | GEARCASE - COUNTER ROTATION                                  |
| J225CZERM 1994                                            | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |

|                                                             |                                                          |
|-------------------------------------------------------------|----------------------------------------------------------|
| J225CZERM 1994                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225CZETA 1993                                              | GEARCASE - COUNTER ROTATION                              |
| J225CZETA 1993                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225CZETA 1993                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225CZETF 1993                                              | GEARCASE - COUNTER ROTATION                              |
| J225CZETF 1993                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225CZETF 1993                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225CZEUD 1997                                              | GEARCASE - COUNTER-ROTATION                              |
| J225CZEUD 1997                                              | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225CZEUD 1997                                              | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225HGLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J225HGLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J225HGLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J225HGLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J225HPLEEN 1999                                             | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| J225HPLEEN 1999                                             | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| J225HPLEEN 1999                                             | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| J225HPLEES 1999                                             | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| J225HPLEES 1999                                             | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| J225HPLEES 1999                                             | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| J225HPLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J225HPLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J225HPLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J225HPLSIF elec start, TNT, 20 in shaft 2001                | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000        | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000        | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000        | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000        | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |

|                                               |                                                          |
|-----------------------------------------------|----------------------------------------------------------|
| J225PLEEC 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| J225PLEEC 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| J225PLEEC 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| J225PLEEN 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS          |
| J225PLEEN 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS           |
| J225PLEEN 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS            |
| J225PLERK 1994                                | GEARCASE - COUNTER ROTATION                              |
| J225PLERK 1994                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225PLERK 1994                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225PLERM 1994                                | GEARCASE - COUNTER ROTATION                              |
| J225PLERM 1994                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225PLERM 1994                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225PLETA 1993                                | GEARCASE - COUNTER ROTATION                              |
| J225PLETA 1993                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225PLETA 1993                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225PLETF 1993                                | GEARCASE - COUNTER ROTATION                              |
| J225PLETF 1993                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225PLETF 1993                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J225PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J225PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J225PLSIF elec start, TNT, 20 in shaft 2001   | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J225PXARC 1994                                | GEARCASE - COUNTER ROTATION                              |
| J225PXARC 1994                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225PXARC 1994                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225PXARK 1994                                | GEARCASE - COUNTER ROTATION                              |
| J225PXARK 1994                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225PXARK 1994                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225PXATF 1993                                | GEARCASE - COUNTER ROTATION                              |
| J225PXATF 1993                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |

|                                               |                                                       |
|-----------------------------------------------|-------------------------------------------------------|
| J225PXATF 1993                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXATS 1993                                | GEARCASE - COUNTER ROTATION                           |
| J225PXATS 1993                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PXATS 1993                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXEDE 1996                                | GEARCASE - COUNTER-ROTATION                           |
| J225PXEDE 1996                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PXEDE 1996                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXEEC 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS       |
| J225PXEEC 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS        |
| J225PXEEC 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS         |
| J225PXEEEN 1999                               | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS       |
| J225PXEEEN 1999                               | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS        |
| J225PXEEEN 1999                               | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS         |
| J225PXEOB 1995                                | GEARCASE - COUNTER ROTATION                           |
| J225PXEOB 1995                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PXEOB 1995                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXERK 1994                                | GEARCASE - COUNTER ROTATION                           |
| J225PXERK 1994                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PXERK 1994                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXERM 1994                                | GEARCASE - COUNTER ROTATION                           |
| J225PXERM 1994                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PXERM 1994                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXETA 1993                                | GEARCASE - COUNTER ROTATION                           |
| J225PXETA 1993                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PXETA 1993                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXETF 1993                                | GEARCASE - COUNTER ROTATION                           |
| J225PXETF 1993                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PXETF 1993                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS         |
| J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS         |
| J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS          |
| J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS           |
| J225PZARK 1994                                | GEARCASE - COUNTER ROTATION                           |
| J225PZARK 1994                                | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| J225PZARK 1994                                | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| J225PZATF 1993  | GEARCASE - COUNTER ROTATION                                  |
| J225PZATF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225PZATF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225PZATS 1993  | GEARCASE - COUNTER ROTATION                                  |
| J225PZATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225PZATS 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225PZEOB 1995  | GEARCASE - COUNTER ROTATION                                  |
| J225PZEOB 1995  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225PZEOB 1995  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225PZERK 1994  | GEARCASE - COUNTER ROTATION                                  |
| J225PZERK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225PZERK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225PZERM 1994  | GEARCASE - COUNTER ROTATION                                  |
| J225PZERM 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225PZERM 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225PZETA 1993  | GEARCASE - COUNTER ROTATION                                  |
| J225PZETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225PZETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225PZETF 1993  | GEARCASE - COUNTER ROTATION                                  |
| J225PZETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225PZETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225STLECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J225STLECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J225STLECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J225STLEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J225STLEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225STLEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225STLEOB 1995 | GEARCASE - COUNTER ROTATION                                  |
| J225STLEOB 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225STLEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225STLERC 1994 | GEARCASE - COUNTER ROTATION                                  |
| J225STLERC 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225STLERC 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225STLERK 1994 | GEARCASE - COUNTER ROTATION                                  |

|                 |                                                                 |
|-----------------|-----------------------------------------------------------------|
| J225STLERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225STLERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225STLETF 1993 | GEARCASE - COUNTER ROTATION                                     |
| J225STLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225STLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225STLEUD 1997 | GEARCASE - COUNTER-ROTATION                                     |
| J225STLEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225STLEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TLERK 1994  | GEARCASE - COUNTER ROTATION                                     |
| J225TLERK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TLERK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TLERM 1994  | GEARCASE - COUNTER ROTATION                                     |
| J225TLERM 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TLERM 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TLETA 1993  | GEARCASE - COUNTER ROTATION                                     |
| J225TLETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TLETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TLETF 1993  | GEARCASE - COUNTER ROTATION                                     |
| J225TLETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TLETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TXARC 1994  | GEARCASE - COUNTER ROTATION                                     |
| J225TXARC 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TXARC 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TXARK 1994  | GEARCASE - COUNTER ROTATION                                     |
| J225TXARK 1994  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TXARK 1994  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TXATF 1993  | GEARCASE - COUNTER ROTATION                                     |
| J225TXATF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TXATF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TXATS 1993  | GEARCASE - COUNTER ROTATION                                     |
| J225TXATS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                    |
| J225TXATS 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS           |
| J225TXECS 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX<br>MODELS |
| J225TXECS 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS               |

|                |                                                              |
|----------------|--------------------------------------------------------------|
| J225TXECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J225TXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| J225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TXEOB 1995 | GEARCASE - COUNTER ROTATION                                  |
| J225TXEOB 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TXEOB 1995 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TXERK 1994 | GEARCASE - COUNTER ROTATION                                  |
| J225TXERK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TXERK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TXERM 1994 | GEARCASE - COUNTER ROTATION                                  |
| J225TXERM 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TXERM 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TXETA 1993 | GEARCASE - COUNTER ROTATION                                  |
| J225TXETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TXETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TXETF 1993 | GEARCASE - COUNTER ROTATION                                  |
| J225TXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TXEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| J225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TZARK 1994 | GEARCASE - COUNTER ROTATION                                  |
| J225TZARK 1994 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TZARK 1994 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TZATF 1993 | GEARCASE - COUNTER ROTATION                                  |
| J225TZATF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TZATF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TZATS 1993 | GEARCASE - COUNTER ROTATION                                  |
| J225TZATS 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| J225TZATS 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| J225TZECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J225TZECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J225TZECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |

|                                                                  |                                                          |
|------------------------------------------------------------------|----------------------------------------------------------|
| J225TZEDE 1996                                                   | GEARCASE - COUNTER-ROTATION                              |
| J225TZEDE 1996                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225TZEDE 1996                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225TZEOD 1995                                                   | GEARCASE - COUNTER ROTATION                              |
| J225TZEOD 1995                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225TZEOD 1995                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225TZERK 1994                                                   | GEARCASE - COUNTER ROTATION                              |
| J225TZERK 1994                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225TZERK 1994                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225TZERM 1994                                                   | GEARCASE - COUNTER ROTATION                              |
| J225TZERM 1994                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225TZERM 1994                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225TZETA 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J225TZETA 1993                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225TZETA 1993                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225TZETF 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J225TZETF 1993                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225TZETF 1993                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225TZEUD 1997                                                   | GEARCASE - COUNTER-ROTATION                              |
| J225TZEUD 1997                                                   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS             |
| J225TZEUD 1997                                                   | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS    |
| J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J225VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J225VLSIF elec start, TNT, 20 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |

|                                                                 |                                                              |
|-----------------------------------------------------------------|--------------------------------------------------------------|
| J225VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VX - VZ MODELS                |
| J225VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS     |
| J225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL - HGL MODELS               |
| J225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS          |
| J225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VX - VZ MODELS                |
| J225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS     |
| J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |
| J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J250CXARC 1994                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CXARC 1994                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CXATF 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CXATF 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CXATS 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CXATS 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CXECD 1998                                                  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J250CXECD 1998                                                  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J250CXECD 1998                                                  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J250CXEEN 1999                                                  | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250CXEEN 1999                                                  | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250CXEEN 1999                                                  | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250CXEES 1999                                                  | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250CXEES 1999                                                  | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250CXEES 1999                                                  | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250CXEOR 1995                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CXEOR 1995                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CXERC 1994                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CXERC 1994                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CXETF 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CXETF 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CXETS 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CXETS 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |

|                                                                 |                                                              |
|-----------------------------------------------------------------|--------------------------------------------------------------|
| J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J250CZATF 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CZATF 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CZATS 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CZATS 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CZECD 1998                                                  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J250CZECD 1998                                                  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J250CZECD 1998                                                  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J250CZEEN 1999                                                  | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250CZEEN 1999                                                  | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250CZEEN 1999                                                  | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250CZEES 1999                                                  | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250CZEES 1999                                                  | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250CZEES 1999                                                  | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250CZEOR 1995                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CZEOR 1995                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CZERC 1994                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CZERC 1994                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CZETF 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CZETF 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CZETS 1993                                                  | GEARCASE - COUNTER ROTATION                                  |
| J250CZETS 1993                                                  | GEARCASE - STANDARD ROTATION                                 |
| J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |
| J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J250PXECD 1998                                                  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J250PXECD 1998                                                  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J250PXECD 1998                                                  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |

|                                               |                                                              |
|-----------------------------------------------|--------------------------------------------------------------|
| J250PXEEN 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250PXEEN 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250PXEEN 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250PXEEES 1999                               | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250PXEEES 1999                               | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250PXEEES 1999                               | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |
| J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J250PZECD 1998                                | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| J250PZECD 1998                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| J250PZECD 1998                                | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| J250PZEEN 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250PZEEN 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250PZEEN 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250PZEES 1999                                | GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS              |
| J250PZEES 1999                                | GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS               |
| J250PZEES 1999                                | GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS                |
| J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS                |
| J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS                |
| J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS                 |
| J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS                  |
| J250TXARC 1994                                | GEARCASE - COUNTER ROTATION                                  |
| J250TXARC 1994                                | GEARCASE - STANDARD ROTATION                                 |
| J250TXATF 1993                                | GEARCASE - COUNTER ROTATION                                  |
| J250TXATF 1993                                | GEARCASE - STANDARD ROTATION                                 |
| J250TXATS 1993                                | GEARCASE - COUNTER ROTATION                                  |
| J250TXATS 1993                                | GEARCASE - STANDARD ROTATION                                 |
| J250TXEOR 1995                                | GEARCASE - COUNTER ROTATION                                  |
| J250TXEOR 1995                                | GEARCASE - STANDARD ROTATION                                 |
| J250TXERC 1994                                | GEARCASE - COUNTER ROTATION                                  |
| J250TXERC 1994                                | GEARCASE - STANDARD ROTATION                                 |
| J250TXETF 1993                                | GEARCASE - COUNTER ROTATION                                  |

|                                                                  |                                                          |
|------------------------------------------------------------------|----------------------------------------------------------|
| J250TXETF 1993                                                   | GEARCASE - STANDARD ROTATION                             |
| J250TXETS 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J250TXETS 1993                                                   | GEARCASE - STANDARD ROTATION                             |
| J250TZATF 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J250TZATF 1993                                                   | GEARCASE - STANDARD ROTATION                             |
| J250TZATS 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J250TZATS 1993                                                   | GEARCASE - STANDARD ROTATION                             |
| J250TZEOR 1995                                                   | GEARCASE - COUNTER ROTATION                              |
| J250TZEOR 1995                                                   | GEARCASE - STANDARD ROTATION                             |
| J250TZERC 1994                                                   | GEARCASE - COUNTER ROTATION                              |
| J250TZERC 1994                                                   | GEARCASE - STANDARD ROTATION                             |
| J250TZETF 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J250TZETF 1993                                                   | GEARCASE - STANDARD ROTATION                             |
| J250TZETS 1993                                                   | GEARCASE - COUNTER ROTATION                              |
| J250TZETS 1993                                                   | GEARCASE - STANDARD ROTATION                             |
| J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J250VXSIF elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J250VXSIF elec start, TNT, 25 in shaft, wht 2001                 | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |

|                                                    |                                                          |
|----------------------------------------------------|----------------------------------------------------------|
| J250VXSIF elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J250VXSIF elec start, TNT, 25 in shaft, wht 2001   | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J250VZSSIF elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| J250VZSSIF elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| J250VZSSIF elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| J250VZSSIF elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| J300CXEOR 1995                                     | GEARCASE - COUNTER ROTATION                              |
| J300CXEOR 1995                                     | GEARCASE - STANDARD ROTATION                             |
| J300CXERC 1994                                     | GEARCASE - COUNTER ROTATION                              |
| J300CXERC 1994                                     | GEARCASE - STANDARD ROTATION                             |
| J300CXETF 1993                                     | GEARCASE - COUNTER ROTATION                              |
| J300CXETF 1993                                     | GEARCASE - STANDARD ROTATION                             |
| J300CXETS 1993                                     | GEARCASE - COUNTER ROTATION                              |
| J300CXETS 1993                                     | GEARCASE - STANDARD ROTATION                             |
| J300PLEOR 1995                                     | GEARCASE - COUNTER ROTATION                              |
| J300PLEOR 1995                                     | GEARCASE - STANDARD ROTATION                             |
| J300PLERC 1994                                     | GEARCASE - COUNTER ROTATION                              |
| J300PLERC 1994                                     | GEARCASE - STANDARD ROTATION                             |
| J300PLETF 1993                                     | GEARCASE - COUNTER ROTATION                              |
| J300PLETF 1993                                     | GEARCASE - STANDARD ROTATION                             |
| J300PLETS 1993                                     | GEARCASE - COUNTER ROTATION                              |
| J300PLETS 1993                                     | GEARCASE - STANDARD ROTATION                             |
| J300PXEOR 1995                                     | GEARCASE - COUNTER ROTATION                              |
| J300PXEOR 1995                                     | GEARCASE - STANDARD ROTATION                             |
| J300PXERC 1994                                     | GEARCASE - COUNTER ROTATION                              |
| J300PXERC 1994                                     | GEARCASE - STANDARD ROTATION                             |

|                |                                                 |
|----------------|-------------------------------------------------|
| J300PXETF 1993 | GEARCASE - COUNTER ROTATION                     |
| J300PXETF 1993 | GEARCASE - STANDARD ROTATION                    |
| J300PXETS 1993 | GEARCASE - COUNTER ROTATION                     |
| J300PXETS 1993 | GEARCASE - STANDARD ROTATION                    |
| J90ELECM 1998  | GEARCASE -- 90 & 115 EL, GL, SL MODELS          |
| J90ELECM 1998  | GEARCASE -- 90 & 115 SX MODELS                  |
| J90ELECM 1998  | JET DRIVE UNIT                                  |
| J90ELEDR 1996  | GEARCASE - 20 IN. MODELS                        |
| J90ELEDR 1996  | GEARCASE - 25 IN. MODELS                        |
| J90ELEOC 1995  | GEARCASE - 20 IN. MODELS                        |
| J90ELEOC 1995  | GEARCASE - 25 IN. MODELS                        |
| J90ELEUA 1997  | GEARCASE - 20 IN. MODELS                        |
| J90ELEUA 1997  | GEARCASE - 25 IN. MODELS                        |
| J90ELEUC 1997  | GEARCASE - 20 IN. MODELS                        |
| J90ELEUC 1997  | GEARCASE - 25 IN. MODELS                        |
| J90EXEOC 1995  | GEARCASE - 20 IN. MODELS                        |
| J90EXEOC 1995  | GEARCASE - 25 IN. MODELS                        |
| J90FSLECS 1998 | GEARCASE -- FSL, FTL MODELS                     |
| J90FSLECS 1998 | GEARCASE -- FSX MODELS                          |
| J90FTLECS 1998 | GEARCASE -- FSL, FTL MODELS                     |
| J90FTLECS 1998 | GEARCASE -- FSX MODELS                          |
| J90GLSDE       | GEARCASE - PL, GL MODELS                        |
| J90GLSDE - FR  | 17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES      |
| J90GLSOB       | GEARCASE - PL, GL MODELS                        |
| J90GLSOB - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL    |
| J90GLSRM       | GEARCASE - PL, GL MODELS                        |
| J90GLSRM - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL    |
| J90GLSTA       | GEARCASE - PL, GL MODELS                        |
| J90GLSTA       | GEARCASE - PX - WPL MODELS                      |
| J90GLSTA - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL    |
| J90GLSTA - FR  | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL   |
| J90PLEEB 1999  | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS |
| J90PLEEB 1999  | GEARCASE -- 90 & 115 PX MODELS                  |
| J90PLEEB 1999  | JET DRIVE UNIT                                  |
| J90PLSDM       | GEARCASE - PL, GL MODELS                        |

|                                                                  |                                                |
|------------------------------------------------------------------|------------------------------------------------|
| J90PLSDM - FR                                                    | 17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES     |
| J90PLSID elec start, TNT, 20 in shaft 2001                       | GEARCASE - 90 - 115 PL - VL MODELS             |
| J90PLSID elec start, TNT, 20 in shaft 2001                       | GEARCASE - 90 - 115 VX MODELS                  |
| J90PLSID elec start, TNT, 20 in shaft 2001                       | JET DRIVE UNIT                                 |
| J90PLSNF - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS |
| J90PLSNF - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PXS        |
| J90PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002 | GEARCASE - PLS, VLS MODELS                     |
| J90PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002 | GEARCASE - PXS MODELS                          |
| J90PLSOA                                                         | GEARCASE - PL, GL MODELS                       |
| J90PLSOA - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL   |
| J90PLSRR                                                         | GEARCASE - PL, GL MODELS                       |
| J90PLSRR - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL   |
| J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000                     | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS   |
| J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000                     | GEARCASE - 90 AND 115 PX, VX MODELS            |
| J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000                     | JET DRIVE UNIT                                 |
| J90PLSTC                                                         | GEARCASE - PL, GL MODELS                       |
| J90PLSTC                                                         | GEARCASE - PX - WPL MODELS                     |
| J90PLSTC - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL   |
| J90PLSTC - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL  |
| J90PXSDR                                                         | GEARCASE - PX MODELS                           |
| J90PXSDR - FR                                                    | 17-1_BOÎTIER D'ENGRENAGES - PX MODELES         |
| J90PXSOC                                                         | GEARCASE - PX - WPL MODELS                     |
| J90PXSOC - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL  |
| J90PXSRS                                                         | GEARCASE - PX - WPL MODELS                     |
| J90PXSRS - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL  |
| J90SLECM 1998                                                    | GEARCASE -- 90 & 115 EL, GL, SL MODELS         |
| J90SLECM 1998                                                    | GEARCASE -- 90 & 115 SX MODELS                 |
| J90SLECM 1998                                                    | JET DRIVE UNIT                                 |
| J90SLEDR 1996                                                    | GEARCASE - 20 IN. MODELS                       |
| J90SLEDR 1996                                                    | GEARCASE - 25 IN. MODELS                       |
| J90SLEOC 1995                                                    | GEARCASE - 20 IN. MODELS                       |
| J90SLEOC 1995                                                    | GEARCASE - 25 IN. MODELS                       |
| J90SLEUA 1997                                                    | GEARCASE - 20 IN. MODELS                       |
| J90SLEUA 1997                                                    | GEARCASE - 25 IN. MODELS                       |

|                                                                  |                                                             |
|------------------------------------------------------------------|-------------------------------------------------------------|
| J90SLEUC 1997                                                    | GEARCASE - 20 IN. MODELS                                    |
| J90SLEUC 1997                                                    | GEARCASE - 25 IN. MODELS                                    |
| J90SPLEES 1999                                                   | GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS             |
| J90SPLEES 1999                                                   | GEARCASE -- 90 & 115 PX MODELS                              |
| J90SPLEES 1999                                                   | JET DRIVE UNIT                                              |
| J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS                |
| J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - 90 AND 115 PX, VX MODELS                         |
| J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000               | JET DRIVE UNIT                                              |
| J90TSLECM 1998                                                   | GEARCASE                                                    |
| J90VLSIC elec start, TNT, 20 in shaft, wht 2001                  | GEARCASE - 90 - 115 PL - VL MODELS                          |
| J90VLSIC elec start, TNT, 20 in shaft, wht 2001                  | GEARCASE - 90 - 115 VX MODELS                               |
| J90VLSIC elec start, TNT, 20 in shaft, wht 2001                  | JET DRIVE UNIT                                              |
| J90VLSNF - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS              |
| J90VLSNF - FR                                                    | 27-1_BOÎTIER D'ENGRENAGES - Modèles PXS                     |
| J90VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002 | GEARCASE - PLS, VLS MODELS                                  |
| J90VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002 | GEARCASE - PXS MODELS                                       |
| J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000                | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS                |
| J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000                | GEARCASE - 90 AND 115 PX, VX MODELS                         |
| J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000                | JET DRIVE UNIT                                              |
| L115GLECA 1998                                                   | GEARCASE -- 90 & 115 EL, GL, SL MODELS                      |
| L115GLECA 1998                                                   | GEARCASE -- 90 & 115 SX MODELS                              |
| L115GLECA 1998                                                   | JET DRIVE UNIT                                              |
| L115GLEDC 1996                                                   | GEARCASE - 20 IN. MODELS                                    |
| L115GLEDC 1996                                                   | GEARCASE - 25 IN. MODELS                                    |
| L115GLEOS 1995                                                   | GEARCASE - 20 IN. MODELS                                    |
| L115GLEOS 1995                                                   | GEARCASE - 25 IN. MODELS                                    |
| L115GLEUC 1997                                                   | GEARCASE - 20 IN. MODELS                                    |
| L115GLEUC 1997                                                   | GEARCASE - 25 IN. MODELS                                    |
| L115GLEUR 1997                                                   | GEARCASE - 20 IN. MODELS                                    |
| L115GLEUR 1997                                                   | GEARCASE - 25 IN. MODELS                                    |
| L150GLECA 1998                                                   | GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS |
| L150GLECA 1998                                                   | GEARCASE -- COUNTER-ROTATION                                |
| L150GLECA 1998                                                   | GEARCASE -- STANDARD ROTATION -- GL MODELS                  |
| L150GLECA 1998                                                   | JET DRIVE UNIT                                              |

|                                                         |                                                              |
|---------------------------------------------------------|--------------------------------------------------------------|
| L150GLEDC 1996                                          | GEARCASE - COUNTER-ROTATION                                  |
| L150GLEDC 1996                                          | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| L150GLEDC 1996                                          | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| L150GLEDC 1996                                          | JET DRIVE UNIT                                               |
| L150GLEOS 1995                                          | GEARCASE - COUNTER ROTATION                                  |
| L150GLEOS 1995                                          | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| L150GLEOS 1995                                          | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| L150GLEOS 1995                                          | JET DRIVE UNIT                                               |
| L150GLEUC 1997                                          | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| L150GLEUC 1997                                          | GEARCASE - COUNTER-ROTATION                                  |
| L150GLEUC 1997                                          | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| L150GLEUC 1997                                          | JET DRIVE UNIT                                               |
| L150GLEUR 1997                                          | GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"  |
| L150GLEUR 1997                                          | GEARCASE - COUNTER-ROTATION                                  |
| L150GLEUR 1997                                          | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| L150GLEUR 1997                                          | JET DRIVE UNIT                                               |
| L90GLECS 1998                                           | GEARCASE -- 90 & 115 EL, GL, SL MODELS                       |
| L90GLECS 1998                                           | GEARCASE -- 90 & 115 SX MODELS                               |
| L90GLECS 1998                                           | JET DRIVE UNIT                                               |
| LE200SLEDR 1996                                         | GEARCASE - COUNTER-ROTATION                                  |
| LE200SLEDR 1996                                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| LE200SLEDR 1996                                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| LE200SLEOC 1995                                         | GEARCASE - COUNTER ROTATION                                  |
| LE200SLEOC 1995                                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| LE200SLEOC 1995                                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| LJ200SLEDR 1996                                         | GEARCASE - COUNTER-ROTATION                                  |
| LJ200SLEDR 1996                                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| LJ200SLEDR 1996                                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| LJ200SLEOC 1995                                         | GEARCASE - COUNTER ROTATION                                  |
| LJ200SLEOC 1995                                         | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| LJ200SLEOC 1995                                         | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| RE115FLSIF FFI, elec start, TNT, 20 in shaft 2001       | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS                 |
| RE115FLSIF FFI, elec start, TNT, 20 in shaft 2001       | GEARCASE - FPX - FX MODELS                                   |
| RE115FLSSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000 | GEARCASE - FPL, FSL, FL, FS MODELS                           |

|                                                                      |                                                        |
|----------------------------------------------------------------------|--------------------------------------------------------|
| RE115FLSSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000              | GEARCASE - FPX, FX MODELS                              |
| RE115FLSSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000              | GEARCASE - FPL, FSL, FL, FS MODELS                     |
| RE115FLSSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000              | GEARCASE - FPX, FX MODELS                              |
| RE115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000                  | GEARCASE - FPL, FSL, FL, FS MODELS                     |
| RE115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000                  | GEARCASE - FPX, FX MODELS                              |
| RE115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                  | GEARCASE - FPL, FSL, FL, FS MODELS                     |
| RE115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                  | GEARCASE - FPX, FX MODELS                              |
| RE115FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001               | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS           |
| RE115FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001               | GEARCASE - FPX - FX MODELS                             |
| RE115FSSSH FFI, Elec Start, TNT, 20 IN. shaft, wht 2000              | GEARCASE - FPL, FSL, FL, FS MODELS                     |
| RE115FSSSH FFI, Elec Start, TNT, 20 IN. shaft, wht 2000              | GEARCASE - FPX, FX MODELS                              |
| RE115FSSSR FFI, Elec Start, TNT, 20 IN. shaft, wht 2000              | GEARCASE - FPL, FSL, FL, FS MODELS                     |
| RE115FSSSR FFI, Elec Start, TNT, 20 IN. shaft, wht 2000              | GEARCASE - FPX, FX MODELS                              |
| RE115FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS           |
| RE115FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - FPX - FX MODELS                             |
| RE115FXSSH FFI, Elec Start, TNT, 25 IN. shaft 2000                   | GEARCASE - FPL, FSL, FL, FS MODELS                     |
| RE115FXSSH FFI, Elec Start, TNT, 25 IN. shaft 2000                   | GEARCASE - FPX, FX MODELS                              |
| RE115FXSSR FFI, Elec Start, TNT, 25 IN. shaft 2000                   | GEARCASE - FPL, FSL, FL, FS MODELS                     |
| RE115FXSSR FFI, Elec Start, TNT, 25 IN. shaft 2000                   | GEARCASE - FPX, FX MODELS                              |
| RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |

|                                                                      |                                                        |
|----------------------------------------------------------------------|--------------------------------------------------------|
| RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001               | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001               | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001               | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |

|                                                                      |                                                        |
|----------------------------------------------------------------------|--------------------------------------------------------|
| RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000               | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001               | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FPL - FL MODELS         |
| RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001                    | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |
| RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS |
| RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - FCX, FC MODELS           |
| RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - FPL, FL MODELS          |

|                                                                     |                                                           |
|---------------------------------------------------------------------|-----------------------------------------------------------|
| RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                  | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS    |
| RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000                  | GEARCASE - COUNTER ROTATION - FCX, FC MODELS              |
| RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - FPL, FL MODELS             |
| RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS    |
| RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000              | GEARCASE - COUNTER ROTATION - FCX, FC MODELS              |
| RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001              | GEARCASE - STANDARD ROTATION - FPL - FL MODELS            |
| RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001              | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS    |
| RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001              | GEARCASE - COUNTER ROTATION - FCX, FC MODELS              |
| RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001              | GEARCASE - STANDARD ROTATION - FPL - FL MODELS            |
| RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001              | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS    |
| RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001              | GEARCASE - COUNTER ROTATION - FCX, FC MODELS              |
| RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000             | GEARCASE - STANDARD ROTATION - FPL, FL MODELS             |
| RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000             | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS    |
| RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000             | GEARCASE - COUNTER ROTATION - FCX, FC MODELS              |
| RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000             | GEARCASE - STANDARD ROTATION - FPL, FL MODELS             |
| RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000             | GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS    |
| RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000             | GEARCASE - COUNTER ROTATION - FCX, FC MODELS              |
| RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - Counter Rotation                               |
| RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - Counter Rotation                               |
| RE200FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE200FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE200FSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000               | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |

|                                                                     |                                                           |
|---------------------------------------------------------------------|-----------------------------------------------------------|
| RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001              | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001              | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001              | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001              | GEARCASE - Counter Rotation                               |
| RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001                   | GEARCASE - Counter Rotation                               |
| RE200FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000              | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE200FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000              | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - Counter Rotation                               |
| RE225FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000 | GEARCASE - Counter Rotation                               |
| RE225FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000 | GEARCASE - Counter Rotation                               |
| RE225FGSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000            | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE225FGSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000            | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001                   | GEARCASE - Counter Rotation                               |
| RE225FHSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000        | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE225FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE225FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000                   | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |

|                                                         |                                                           |
|---------------------------------------------------------|-----------------------------------------------------------|
| RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001  | GEARCASE - Counter Rotation                               |
| RE225FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE225FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS |
| RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - STANDARD ROTATION - FH - FHL MODELS            |
| RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001  | GEARCASE - Counter Rotation                               |
| RE225FZSSH FFI, Elec Start, TNT, 30 IN shaft, wht 2000  | GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS |
| RE75FPLSIF FFI, elec start, TNT, 20 in shaft 2001       | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS              |
| RE75FPLSIF FFI, elec start, TNT, 20 in shaft 2001       | GEARCASE - FPX - FX MODELS                                |
| RE75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000      | GEARCASE - FPL, FSL, FL, FS MODELS                        |
| RE75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000      | GEARCASE - FPX, FX MODELS                                 |
| RE90FPLSIF FFI, elec start, TNT, 20 in shaft 2001       | GEARCASE - FPL - FSL - FL - FVL - FSS MODELS              |
| RE90FPLSIF FFI, elec start, TNT, 20 in shaft 2001       | GEARCASE - FPX - FX MODELS                                |
| RE90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000      | GEARCASE - FPL, FSL, FL, FS MODELS                        |
| RE90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000      | GEARCASE - FPX, FX MODELS                                 |
| RE90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000      | GEARCASE - FPL, FSL, FL, FS MODELS                        |
| RE90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000      | GEARCASE - FPX, FX MODELS                                 |
| RJ115PLSIE elec start, TNT, 20 in shaft 2001            | GEARCASE - 90 - 115 PL - VL MODELS                        |
| RJ115PLSIE elec start, TNT, 20 in shaft 2001            | GEARCASE - 90 - 115 VX MODELS                             |
| RJ115PLSIE elec start, TNT, 20 in shaft 2001            | JET DRIVE UNIT                                            |
| RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS              |
| RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS                       |
| RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | JET DRIVE UNIT                                            |
| RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS              |
| RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS                       |

|                                                              |                                                        |
|--------------------------------------------------------------|--------------------------------------------------------|
| RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000      | JET DRIVE UNIT                                         |
| RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001            | GEARCASE - 90 - 115 PL - VL MODELS                     |
| RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001            | GEARCASE - 90 - 115 VX MODELS                          |
| RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001            | JET DRIVE UNIT                                         |
| RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000      | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS           |
| RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000      | GEARCASE - 90 AND 115 PX, VX MODELS                    |
| RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000      | JET DRIVE UNIT                                         |
| RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001            | GEARCASE - 90 - 115 PL - VL MODELS                     |
| RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001            | GEARCASE - 90 - 115 VX MODELS                          |
| RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001            | JET DRIVE UNIT                                         |
| RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS           |
| RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS                    |
| RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000 | JET DRIVE UNIT                                         |
| RJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000               | GEARCASE                                               |
| RJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000               | GEARCASE                                               |
| RJ130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000          | GEARCASE                                               |
| RJ135PLSIF elec start, TNT, 20 in shaft 2001                 | GEARCASE                                               |
| RJ135VXSIF elec start, TNT, 20 in shaft, wht 2001            | GEARCASE                                               |
| RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000 | JET DRIVE UNIT                                         |
| RJ150PLSIF elec start, TNT, 20 in shaft 2001                 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150PLSIF elec start, TNT, 20 in shaft 2001                 | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| RJ150PLSIF elec start, TNT, 20 in shaft 2001                 | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| RJ150PLSIF elec start, TNT, 20 in shaft 2001                 | JET DRIVE UNIT                                         |
| RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000               | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000               | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000               | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000               | JET DRIVE UNIT                                         |

|                                                                  |                                                        |
|------------------------------------------------------------------|--------------------------------------------------------|
| RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000                   | JET DRIVE UNIT                                         |
| RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001   | JET DRIVE UNIT                                         |
| RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                         |
| RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001                | JET DRIVE UNIT                                         |
| RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |
| RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                         |
| RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL, VX MODELS           |
| RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS     |
| RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001                | JET DRIVE UNIT                                         |
| RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS               |
| RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS |
| RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS       |

|                                                                  |                                                          |
|------------------------------------------------------------------|----------------------------------------------------------|
| RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                           |
| RJ175CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001    | GEARCASE - STANDARD ROTATION - PL MODELS                 |
| RJ175CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001    | GEARCASE - STANDARD ROTATION - VL, VX MODELS             |
| RJ175CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001    | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS       |
| RJ175CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001    | JET DRIVE UNIT                                           |
| RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL MODELS                 |
| RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS   |
| RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS         |
| RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | JET DRIVE UNIT                                           |
| RJ175PLSF elec start, TNT, 20 in shaft 2001                      | GEARCASE - STANDARD ROTATION - PL MODELS                 |
| RJ175PLSF elec start, TNT, 20 in shaft 2001                      | GEARCASE - STANDARD ROTATION - VL, VX MODELS             |
| RJ175PLSF elec start, TNT, 20 in shaft 2001                      | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS       |
| RJ175PLSF elec start, TNT, 20 in shaft 2001                      | JET DRIVE UNIT                                           |
| RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PL MODELS                 |
| RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS   |
| RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS         |
| RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | JET DRIVE UNIT                                           |
| RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL MODELS                 |
| RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL, VX MODELS             |
| RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS       |
| RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001                | JET DRIVE UNIT                                           |
| RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - PL MODELS                 |
| RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS   |
| RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS         |
| RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | JET DRIVE UNIT                                           |
| RJ200PLSF elec start, TNT, 20 in shaft 2001                      | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ200PLSF elec start, TNT, 20 in shaft 2001                      | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| RJ200PLSF elec start, TNT, 20 in shaft 2001                      | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ200PLSF elec start, TNT, 20 in shaft 2001                      | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |

|                                                               |                                                          |
|---------------------------------------------------------------|----------------------------------------------------------|
| RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000                | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000                | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000                | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000                | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000                | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000                | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000                | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001             | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001             | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001             | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001             | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000           | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000           | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000           | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000           | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001 | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000    | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000    | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000    | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000    | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000   | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000   | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000   | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000   | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ225HLSIF elec start, TNT, 20 in shaft 2001                  | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ225HLSIF elec start, TNT, 20 in shaft 2001                  | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |

|                                                                  |                                                          |
|------------------------------------------------------------------|----------------------------------------------------------|
| RJ225HLSIF elec start, TNT, 20 in shaft 2001                     | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ225HLSIF elec start, TNT, 20 in shaft 2001                     | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000             | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000             | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000             | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000             | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ225PLSIF elec start, TNT, 20 in shaft 2001                     | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ225PLSIF elec start, TNT, 20 in shaft 2001                     | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| RJ225PLSIF elec start, TNT, 20 in shaft 2001                     | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ225PLSIF elec start, TNT, 20 in shaft 2001                     | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000                   | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000                   | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000              | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000 | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001                | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |

|                                                        |                                                          |
|--------------------------------------------------------|----------------------------------------------------------|
| RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001      | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001      | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000    | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001     | GEARCASE - STANDARD ROTATION - VL - HGL MODELS           |
| RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001     | GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS      |
| RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001     | GEARCASE - STANDARD ROTATION - VX - VZ MODELS            |
| RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001     | GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS |
| RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - HG, HGL MODELS            |
| RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - PL, HPL MODELS            |
| RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000    | GEARCASE - STANDARD ROTATION - PX, PZ MODELS             |
| RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000    | GEARCASE - COUNTER ROTATION - CX, CZ MODELS              |
| RJ90PLSID elec start, TNT, 20 in shaft 2001            | GEARCASE - 90 - 115 PL - VL MODELS                       |
| RJ90PLSID elec start, TNT, 20 in shaft 2001            | GEARCASE - 90 - 115 VX MODELS                            |
| RJ90PLSID elec start, TNT, 20 in shaft 2001            | JET DRIVE UNIT                                           |
| RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS             |
| RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS                      |
| RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000 | JET DRIVE UNIT                                           |
| RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001       | GEARCASE - 90 - 115 PL - VL MODELS                       |
| RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001       | GEARCASE - 90 - 115 VX MODELS                            |
| RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001       | JET DRIVE UNIT                                           |
| RJ90VLSSS Elec. Start, 20 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS             |
| RJ90VLSSS Elec. Start, 20 IN. shaft, wht, N/A USA 2000 | GEARCASE - 90 AND 115 PX, VX MODELS                      |
| RJ90VLSSS Elec. Start, 20 IN. shaft, wht, N/A USA 2000 | JET DRIVE UNIT                                           |
| SE105RWLH 1998                                         | GEARCASE                                                 |
| SE105RWLP 1997                                         | GEARCASE                                                 |
| SE105RWYH 1998                                         | GEARCASE                                                 |
| SE105RWYP 1997                                         | GEARCASE                                                 |
| SE105WELV 1998                                         | GEARCASE                                                 |
| SE105WEXV 1998                                         | GEARCASE                                                 |
| SE105WRPLV 1998                                        | GEARCASE                                                 |
| SE105WRPXV 1998                                        | GEARCASE                                                 |

|                  |                                                              |
|------------------|--------------------------------------------------------------|
| SE150WTPLB 1996  | GEARCASE                                                     |
| SE150WTPLT 1997  | GEARCASE                                                     |
| SE150WTPLT4 1997 | GEARCASE                                                     |
| SE150WTPLY 1998  | GEARCASE                                                     |
| SE150WTPXB 1996  | GEARCASE                                                     |
| SE150WTPXT 1997  | GEARCASE                                                     |
| SE150WTPXT4 1997 | GEARCASE                                                     |
| SE150WTPXY 1998  | GEARCASE                                                     |
| SE200WTPLG 1998  | GEARCASE                                                     |
| SE200WTPXG 1998  | GEARCASE                                                     |
| SE225GLECC 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SE225GLECC 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SE225GLECC 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SE225NXECC 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SE225NXECC 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SE225NXECC 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SE225NZECC 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SE225NZECC 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SE225NZECC 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SE225QXECC 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SE225QXECC 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SE225QXECC 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SE225QZECC 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SE225QZECC 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SE225QZECC 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ105RWLH 1998   | GEARCASE                                                     |
| SJ105RWLP 1997   | GEARCASE                                                     |
| SJ105RWYH 1998   | GEARCASE                                                     |
| SJ105RWYP 1997   | GEARCASE                                                     |
| SJ105WELV 1998   | GEARCASE                                                     |
| SJ105WEXV 1998   | GEARCASE                                                     |
| SJ105WRPLV 1998  | GEARCASE                                                     |
| SJ105WRPXV 1998  | GEARCASE                                                     |

|                   |                                                              |
|-------------------|--------------------------------------------------------------|
| SJ115ELED R 1996  | GEARCASE - 20 IN. MODELS                                     |
| SJ115ELED R 1996  | GEARCASE - 25 IN. MODELS                                     |
| SJ130CXADA 1996   | GEARCASE - 130CX COUNTER ROTATION                            |
| SJ130CXADA 1996   | GEARCASE - 130TL & 130TX STANDARD ROTATION                   |
| SJ130TLED M 1996  | GEARCASE - 130CX COUNTER ROTATION                            |
| SJ130TLED M 1996  | GEARCASE - 130TL & 130TX STANDARD ROTATION                   |
| SJ130TXADA 1996   | GEARCASE - 130CX COUNTER ROTATION                            |
| SJ130TXADA 1996   | GEARCASE - 130TL & 130TX STANDARD ROTATION                   |
| SJ150ELED B 1996  | GEARCASE - COUNTER-ROTATION                                  |
| SJ150ELED B 1996  | GEARCASE - STANDARD ROTATION - GL MODELS                     |
| SJ150ELED B 1996  | GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"    |
| SJ150ELED B 1996  | JET DRIVE UNIT                                               |
| SJ150WTPL B 1996  | GEARCASE                                                     |
| SJ150WTPL T 1997  | GEARCASE                                                     |
| SJ150WTPL T4 1997 | GEARCASE                                                     |
| SJ150WTPL Y 1998  | GEARCASE                                                     |
| SJ150WTPX B 1996  | GEARCASE                                                     |
| SJ150WTPX T 1997  | GEARCASE                                                     |
| SJ150WTPX T4 1997 | GEARCASE                                                     |
| SJ150WTPX Y 1998  | GEARCASE                                                     |
| SJ200CXEC M 1998  | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ200CXEC M 1998  | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ200CXEC M 1998  | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ200CXEU A 1997  | GEARCASE - COUNTER-ROTATION                                  |
| SJ200CXEU A 1997  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ200CXEU A 1997  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ200SLECE 1998   | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ200SLECE 1998   | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ200SLECE 1998   | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ200SLED M 1996  | GEARCASE - COUNTER-ROTATION                                  |
| SJ200SLED M 1996  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ200SLED M 1996  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ200SLEUB 1997   | GEARCASE - COUNTER-ROTATION                                  |
| SJ200SLEUB 1997   | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| SJ200SLEUB 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ200TXECM 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ200TXECM 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ200TXECM 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ200TXEUA 1997 | GEARCASE - COUNTER-ROTATION                                  |
| SJ200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ200TXEUA 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ200WTPLG 1998 | GEARCASE                                                     |
| SJ200WTPXG 1998 | GEARCASE                                                     |
| SJ225CXECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225CXECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ225CXECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225CXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| SJ225CXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ225CXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ225CXEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| SJ225CXEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ225CXEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ225GLECC 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225GLECC 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ225GLECC 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225NXECC 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225NXECC 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ225NXECC 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225NZECC 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225NZECC 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ225NZECC 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225PXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| SJ225PXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ225PXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ225QXECC 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225QXECC 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| SJ225QXECC 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225QZECC 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225QZECC 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ225QZECC 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225SLECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225SLECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ225SLECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225SLEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| SJ225SLEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ225SLEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ225SLEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| SJ225SLEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ225SLEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ225TXECS 1998 | GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS |
| SJ225TXECS 1998 | GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS            |
| SJ225TXECS 1998 | GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS        |
| SJ225TXEDE 1996 | GEARCASE - COUNTER-ROTATION                                  |
| SJ225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ225TXEDE 1996 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ225TXEUD 1997 | GEARCASE - COUNTER-ROTATION                                  |
| SJ225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| SJ225TXEUD 1997 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS        |
| SJ90ELEDR 1996  | GEARCASE - 20 IN. MODELS                                     |
| SJ90ELEDR 1996  | GEARCASE - 25 IN. MODELS                                     |
| TE150GLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| TE150GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| TE150GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| TE150GLETG 1993 | JET DRIVE UNIT                                               |
| TE150GLETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| TE150GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| TE150GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| TE150GLETR 1993 | JET DRIVE UNIT                                               |
| TJ150GLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| TJ150GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |

|                 |                                                         |
|-----------------|---------------------------------------------------------|
| TJ150GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS               |
| TJ150GLETG 1993 | JET DRIVE UNIT                                          |
| TJ150GLETR 1993 | GEARCASE - COUNTER ROTATION                             |
| TJ150GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS            |
| TJ150GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS               |
| TJ150GLETR 1993 | JET DRIVE UNIT                                          |
| V150SLETG 1993  | GEARCASE - COUNTER ROTATION                             |
| V150SLETG 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS            |
| V150SLETG 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS               |
| V150SLETG 1993  | JET DRIVE UNIT                                          |
| V150SLETS 1993  | GEARCASE - COUNTER ROTATION                             |
| V150SLETS 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS            |
| V150SLETS 1993  | GEARCASE - STANDARD ROTATION - 25" MODELS               |
| V150SLETS 1993  | JET DRIVE UNIT                                          |
| VE120TLETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VE120TLETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VE120TLETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VE120TLETS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VE120TLETS 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VE120TLETS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VE120TXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VE120TXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VE120TXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VE120TXETS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VE120TXETS 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VE120TXETS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VE140TLETC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VE140TLETC 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VE140TLETC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VE140TLETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VE140TLETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VE140TLETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VE140TXETC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VE140TXETC 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VE140TXETC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| VE140TXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY      |
| VE140TXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                            |
| VE140TXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX      |
| VE150ELETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VE150ELETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE150ELETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VE150ELETG 1993 | JET DRIVE UNIT                                               |
| VE150ELETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| VE150ELETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE150ELETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VE150ELETR 1993 | JET DRIVE UNIT                                               |
| VE150EXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VE150EXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE150EXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VE150EXETG 1993 | JET DRIVE UNIT                                               |
| VE150EXETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| VE150EXETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE150EXETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VE150EXETR 1993 | JET DRIVE UNIT                                               |
| VE150GLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VE150GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE150GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VE150GLETG 1993 | JET DRIVE UNIT                                               |
| VE150GLETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| VE150GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE150GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VE150GLETR 1993 | JET DRIVE UNIT                                               |
| VE150HLEOS 1995 | GEARCASE - COUNTER ROTATION                                  |
| VE150HLEOS 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE150HLEOS 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| VE150HLEOS 1995 | JET DRIVE UNIT                                               |
| VE175EXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VE175EXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VE175EXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |

|                 |                                                       |
|-----------------|-------------------------------------------------------|
| VE175EXETG 1993 | JET DRIVE UNIT                                        |
| VE175EXETR 1993 | GEARCASE - COUNTER ROTATION                           |
| VE175EXETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE175EXETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS             |
| VE175EXETR 1993 | JET DRIVE UNIT                                        |
| VE175GLETG 1993 | GEARCASE - COUNTER ROTATION                           |
| VE175GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE175GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS             |
| VE175GLETG 1993 | JET DRIVE UNIT                                        |
| VE175GLETR 1993 | GEARCASE - COUNTER ROTATION                           |
| VE175GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE175GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS             |
| VE175GLETR 1993 | JET DRIVE UNIT                                        |
| VE200SLETC 1993 | GEARCASE - COUNTER ROTATION                           |
| VE200SLETC 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE200SLETC 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE200SLETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VE200SLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE200SLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE200TXETD 1993 | GEARCASE - COUNTER ROTATION                           |
| VE200TXETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE200TXETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE200TXETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VE200TXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE200TXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE200TZETD 1993 | GEARCASE - COUNTER ROTATION                           |
| VE200TZETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE200TZETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE200TZETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VE200TZETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE200TZETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225PLETA 1993 | GEARCASE - COUNTER ROTATION                           |
| VE225PLETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225PLETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225PLETF 1993 | GEARCASE - COUNTER ROTATION                           |

|                  |                                                       |
|------------------|-------------------------------------------------------|
| VE225PLETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225PLETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225PXETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225PXETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225PXETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225PXETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225PXETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225PXETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225PZETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225PZETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225PZETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225PZETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225PZETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225PZETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225STLETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VE225STLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225STLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225TLETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225TLETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225TLETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225TLETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225TLETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225TLETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225TXETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225TXETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225TXETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225TXETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225TXETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225TXETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225TZETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225TZETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225TZETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VE225TZETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VE225TZETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VE225TZETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |

|                 |                                                         |
|-----------------|---------------------------------------------------------|
| VJ120TLATF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ120TLATF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ120TLATF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ120TLATS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ120TLATS 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ120TLATS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ120TLETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ120TLETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ120TLETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ120TLETS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ120TLETS 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ120TLETS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ120TXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ120TXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ120TXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ120TXETS 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ120TXETS 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ120TXETS 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ140TLETC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ140TLETC 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ140TLETC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ140TLETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ140TLETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ140TLETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ140TXETC 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ140TXETC 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ140TXETC 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ140TXETF 1993 | GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY |
| VJ140TXETF 1993 | GEARCASE - 140CX COUNTER ROTATION                       |
| VJ140TXETF 1993 | GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX |
| VJ150ELATG 1993 | GEARCASE - COUNTER ROTATION                             |
| VJ150ELATG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS            |
| VJ150ELATG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS               |
| VJ150ELATG 1993 | JET DRIVE UNIT                                          |
| VJ150ELATR 1993 | GEARCASE - COUNTER ROTATION                             |

|                 |                                                              |
|-----------------|--------------------------------------------------------------|
| VJ150ELATR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150ELATR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VJ150ELATR 1993 | JET DRIVE UNIT                                               |
| VJ150ELETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VJ150ELETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150ELETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VJ150ELETG 1993 | JET DRIVE UNIT                                               |
| VJ150ELETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| VJ150ELETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150ELETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VJ150ELETR 1993 | JET DRIVE UNIT                                               |
| VJ150EXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VJ150EXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150EXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VJ150EXETG 1993 | JET DRIVE UNIT                                               |
| VJ150EXETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| VJ150EXETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150EXETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VJ150EXETR 1993 | JET DRIVE UNIT                                               |
| VJ150GLETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VJ150GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VJ150GLETG 1993 | JET DRIVE UNIT                                               |
| VJ150GLETR 1993 | GEARCASE - COUNTER ROTATION                                  |
| VJ150GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |
| VJ150GLETR 1993 | JET DRIVE UNIT                                               |
| VJ150HLEOS 1995 | GEARCASE - COUNTER ROTATION                                  |
| VJ150HLEOS 1995 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ150HLEOS 1995 | GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS |
| VJ150HLEOS 1995 | JET DRIVE UNIT                                               |
| VJ175EXETG 1993 | GEARCASE - COUNTER ROTATION                                  |
| VJ175EXETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS                 |
| VJ175EXETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS                    |

|                 |                                                       |
|-----------------|-------------------------------------------------------|
| VJ175EXETG 1993 | JET DRIVE UNIT                                        |
| VJ175EXETR 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ175EXETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ175EXETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS             |
| VJ175EXETR 1993 | JET DRIVE UNIT                                        |
| VJ175GLETG 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ175GLETG 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ175GLETG 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS             |
| VJ175GLETG 1993 | JET DRIVE UNIT                                        |
| VJ175GLETR 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ175GLETR 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ175GLETR 1993 | GEARCASE - STANDARD ROTATION - 25" MODELS             |
| VJ175GLETR 1993 | JET DRIVE UNIT                                        |
| VJ200SLETC 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ200SLETC 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ200SLETC 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ200SLETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ200SLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ200SLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ200TXETD 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ200TXETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ200TXETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ200TXETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ200TXETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ200TXETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ200TZETD 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ200TZETD 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ200TZETD 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ200TZETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ200TZETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ200TZETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225PLETA 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ225PLETA 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225PLETA 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225PLETF 1993 | GEARCASE - COUNTER ROTATION                           |

|                  |                                                       |
|------------------|-------------------------------------------------------|
| VJ225PLETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225PLETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225PXETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225PXETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225PXETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225PXETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225PXETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225PXETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225PZETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225PZETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225PZETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225PZETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225PZETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225PZETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225STLETF 1993 | GEARCASE - COUNTER ROTATION                           |
| VJ225STLETF 1993 | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225STLETF 1993 | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225TLETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225TLETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225TLETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225TLETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225TLETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225TLETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225TXETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225TXETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225TXETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225TXETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225TXETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225TXETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225TZETA 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225TZETA 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225TZETA 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |
| VJ225TZETF 1993  | GEARCASE - COUNTER ROTATION                           |
| VJ225TZETF 1993  | GEARCASE - STANDARD ROTATION - 20 IN. MODELS          |
| VJ225TZETF 1993  | GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS |

|                 |          |
|-----------------|----------|
| XE115HLECM 1998 | GEARCASE |
| XE115HXECM 1998 | GEARCASE |
| XE90TSLECM 1998 | GEARCASE |
| XJ115HLECM 1998 | GEARCASE |
| XJ115HXECM 1998 | GEARCASE |
| XJ90TSLECM 1998 | GEARCASE |