

Where Used: Part Number 0339320

Model Name	Diagram
BE10FDLECM 1998	CYLINDER HEAD & CRANKSHAFT
BE10FDLEDR 1996	CYLINDER HEAD & CRANKSHAFT
BE10FDLEUA 1997	CYLINDER HEAD & CRANKSHAFT
BE10FPXEDC 1996	CYLINDER HEAD & CRANKSHAFT
BE10FPXEUR 1997	CYLINDER HEAD & CRANKSHAFT
BE10FREldr 1996	CYLINDER HEAD & CRANKSHAFT
BE10FRELUa 1997	CYLINDER HEAD & CRANKSHAFT
BE15FAEDR 1996	CYLINDER HEAD & CRANKSHAFT
BE15FAEUA 1997	CYLINDER HEAD & CRANKSHAFT
BE15FDLECM 1998	CYLINDER HEAD & CRANKSHAFT
BE15FDLEDR 1996	CYLINDER HEAD & CRANKSHAFT
BE15FDLEUA 1997	CYLINDER HEAD & CRANKSHAFT
BE15FKEDR 1996	CYLINDER HEAD & CRANKSHAFT
BE15FKEUA 1997	CYLINDER HEAD & CRANKSHAFT
BE15FREDR 1996	CYLINDER HEAD & CRANKSHAFT
BE15FRELEDR 1996	CYLINDER HEAD & CRANKSHAFT
BE15FRELUa 1997	CYLINDER HEAD & CRANKSHAFT
BE15FREUA 1997	CYLINDER HEAD & CRANKSHAFT
BE15FWECA 1998	CYLINDER HEAD & CRANKSHAFT
BE15FWEDC 1996	CYLINDER HEAD & CRANKSHAFT
BE15FWEUR 1997	CYLINDER HEAD & CRANKSHAFT
BE15FWLECA 1998	CYLINDER HEAD & CRANKSHAFT
BE15FWLEDC 1996	CYLINDER HEAD & CRANKSHAFT
BE15FWLEUR 1997	CYLINDER HEAD & CRANKSHAFT
BJ10FDLECM 1998	CYLINDER HEAD & CRANKSHAFT
BJ10FDLEDR 1996	CYLINDER HEAD & CRANKSHAFT
BJ10FDLEUA 1997	CYLINDER HEAD & CRANKSHAFT
BJ10FPXEDC 1996	CYLINDER HEAD & CRANKSHAFT
BJ10FPXEUR 1997	CYLINDER HEAD & CRANKSHAFT
BJ10FREldr 1996	CYLINDER HEAD & CRANKSHAFT
BJ10FRELUa 1997	CYLINDER HEAD & CRANKSHAFT
BJ15FAEDR 1996	CYLINDER HEAD & CRANKSHAFT
BJ15FAEUA 1997	CYLINDER HEAD & CRANKSHAFT

BJ15FDLECM 1998	CYLINDER HEAD & CRANKSHAFT
BJ15FDLEDR 1996	CYLINDER HEAD & CRANKSHAFT
BJ15FDLEUA 1997	CYLINDER HEAD & CRANKSHAFT
BJ15FKEDR 1996	CYLINDER HEAD & CRANKSHAFT
BJ15FKEUA 1997	CYLINDER HEAD & CRANKSHAFT
BJ15FREDR 1996	CYLINDER HEAD & CRANKSHAFT
BJ15FRELEDR 1996	CYLINDER HEAD & CRANKSHAFT
BJ15FRELUA 1997	CYLINDER HEAD & CRANKSHAFT
BJ15FREUA 1997	CYLINDER HEAD & CRANKSHAFT
BJ15FWECA 1998	CYLINDER HEAD & CRANKSHAFT
BJ15FWEDC 1996	CYLINDER HEAD & CRANKSHAFT
BJ15FWEUR 1997	CYLINDER HEAD & CRANKSHAFT
BJ15FWLECA 1998	CYLINDER HEAD & CRANKSHAFT
BJ15FWLEDC 1996	CYLINDER HEAD & CRANKSHAFT
BJ15FWLEUR 1997	CYLINDER HEAD & CRANKSHAFT
E10EBL4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E10EL4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E10EL4SID 4-stroke, elec start, remote, 20 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E10EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	CYLINDER HEAD & CRANKSHAFT
E10EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E10EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	CYLINDER HEAD & CRANKSHAFT
E10FEXECM 1998	CYLINDER HEAD & CRANKSHAFT
E10FEXEDR 1996	CYLINDER HEAD & CRANKSHAFT
E10FEXEO 1995	CYLINDER HEAD & CRANKSHAFT
E10FEXEUA 1997	CYLINDER HEAD & CRANKSHAFT
E10FRECM 1998	CYLINDER HEAD & CRANKSHAFT
E10FREDR 1996	CYLINDER HEAD & CRANKSHAFT
E10FRELECM 1998	CYLINDER HEAD & CRANKSHAFT
E10FRELEDR 1996	CYLINDER HEAD & CRANKSHAFT
E10FRELEOC 1995	CYLINDER HEAD & CRANKSHAFT
E10FRELEUA 1997	CYLINDER HEAD & CRANKSHAFT
E10FREOC 1995	CYLINDER HEAD & CRANKSHAFT
E10FREUA 1997	CYLINDER HEAD & CRANKSHAFT
E10FRLECM 1998	CYLINDER HEAD & CRANKSHAFT
E10FRLEDR 1996	CYLINDER HEAD & CRANKSHAFT

E10FRLEO 1995	CYLINDER HEAD & CRANKSHAFT
E10FRLEUA 1997	CYLINDER HEAD & CRANKSHAFT
E10R4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E10R4SID 4-stroke, rope start, tiller, 15 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E10R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	CYLINDER HEAD & CRANKSHAFT
E10RL4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E10RL4SID 4-stroke, rope start, tiller, 20 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E10RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	CYLINDER HEAD & CRANKSHAFT
E10RV4SIC 4-stroke, rope start, tiller, 15 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E10RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	CYLINDER HEAD & CRANKSHAFT
E10RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E10RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	CYLINDER HEAD & CRANKSHAFT
E10TEX4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E10TEX4SID 4-stroke, elec start, tiller, 25 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E10TEX4SSE 4-Stroke, Elec. Start, Tiller, 25 IN shaft 2000	CYLINDER HEAD & CRANKSHAFT
E10TVX4SIC 4-stroke, elec start, tiller, 25 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E10TVX4SSS 4-Stroke, Elec. Start, Tiller, 25 IN shaft, wht 2000	CYLINDER HEAD & CRANKSHAFT
E15DLEOC 1995	CYLINDER HEAD & CRANKSHAFT
E15EBL4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E15EL4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E15EL4SID 4-stroke, elec start, 20 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E15EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	CYLINDER HEAD & CRANKSHAFT
E15EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E15EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	CYLINDER HEAD & CRANKSHAFT
E15FKEDR 1996	CYLINDER HEAD & CRANKSHAFT
E15FKEUA 1997	CYLINDER HEAD & CRANKSHAFT
E15FRECM 1998	CYLINDER HEAD & CRANKSHAFT
E15FREDR 1996	CYLINDER HEAD & CRANKSHAFT
E15FRELECM 1998	CYLINDER HEAD & CRANKSHAFT
E15FRELEDR 1996	CYLINDER HEAD & CRANKSHAFT
E15FRELEUA 1997	CYLINDER HEAD & CRANKSHAFT
E15FREOC 1995	CYLINDER HEAD & CRANKSHAFT
E15FREUA 1997	CYLINDER HEAD & CRANKSHAFT
E15FRLECM 1998	CYLINDER HEAD & CRANKSHAFT
E15FRLEDR 1996	CYLINDER HEAD & CRANKSHAFT

E15FRLEOC 1995	CYLINDER HEAD & CRANKSHAFT
E15FRLEUA 1997	CYLINDER HEAD & CRANKSHAFT
E15KEOC 1995	CYLINDER HEAD & CRANKSHAFT
E15R4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E15R4SID 4-stroke, rope start, 15 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E15R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	CYLINDER HEAD & CRANKSHAFT
E15RB4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E15RBL4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E15RL4EEB 1999	CYLINDER HEAD & CRANKSHAFT
E15RL4SID 4-stroke, rope start, 20 in shaft 2001	CYLINDER HEAD & CRANKSHAFT
E15RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	CYLINDER HEAD & CRANKSHAFT
E15RV4SIC 4-stroke,rope start, 15 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E15RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	CYLINDER HEAD & CRANKSHAFT
E15RVL4SIC 4-stroke, elec start, 15 in shaft, wht 2001	CYLINDER HEAD & CRANKSHAFT
E15RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	CYLINDER HEAD & CRANKSHAFT
J10FEXECM 1998	CYLINDER HEAD & CRANKSHAFT
J10FEXEDR 1996	CYLINDER HEAD & CRANKSHAFT
J10FEXEO 1995	CYLINDER HEAD & CRANKSHAFT
J10FEXEUA 1997	CYLINDER HEAD & CRANKSHAFT
J10FRECM 1998	CYLINDER HEAD & CRANKSHAFT
J10FREDR 1996	CYLINDER HEAD & CRANKSHAFT
J10FRELECM 1998	CYLINDER HEAD & CRANKSHAFT
J10FRELEDR 1996	CYLINDER HEAD & CRANKSHAFT
J10FRELEOC 1995	CYLINDER HEAD & CRANKSHAFT
J10FRELEUA 1997	CYLINDER HEAD & CRANKSHAFT
J10FREOC 1995	CYLINDER HEAD & CRANKSHAFT
J10FREUA 1997	CYLINDER HEAD & CRANKSHAFT
J10FRLECM 1998	CYLINDER HEAD & CRANKSHAFT
J10FRLEDR 1996	CYLINDER HEAD & CRANKSHAFT
J10FRLEO 1995	CYLINDER HEAD & CRANKSHAFT
J10FRLEUA 1997	CYLINDER HEAD & CRANKSHAFT
J15DLEOC 1995	CYLINDER HEAD & CRANKSHAFT
J15FKEDR 1996	CYLINDER HEAD & CRANKSHAFT
J15FKEUA 1997	CYLINDER HEAD & CRANKSHAFT
J15FRECM 1998	CYLINDER HEAD & CRANKSHAFT

J15FREDR 1996	CYLINDER HEAD & CRANKSHAFT
J15FRELECM 1998	CYLINDER HEAD & CRANKSHAFT
J15FRELEDR 1996	CYLINDER HEAD & CRANKSHAFT
J15FRELEUA 1997	CYLINDER HEAD & CRANKSHAFT
J15FREOC 1995	CYLINDER HEAD & CRANKSHAFT
J15FREUA 1997	CYLINDER HEAD & CRANKSHAFT
J15FRLECM 1998	CYLINDER HEAD & CRANKSHAFT
J15FRLEDR 1996	CYLINDER HEAD & CRANKSHAFT
J15FRLEOC 1995	CYLINDER HEAD & CRANKSHAFT
J15FRLEUA 1997	CYLINDER HEAD & CRANKSHAFT
J15KEOC 1995	CYLINDER HEAD & CRANKSHAFT
L10FRELECM 1998	CYLINDER HEAD & CRANKSHAFT
L10FRELEDR 1996	CYLINDER HEAD & CRANKSHAFT
L10FRELEUA 1997	CYLINDER HEAD & CRANKSHAFT