

Where Used: Part Number 0341501

Model Name	Diagram
BE10FAEDC 1996	CARBURETOR
BE10FAEUR 1997	CARBURETOR
BE10FCLEDC 1996	CARBURETOR
BE10FCLEUR 1997	CARBURETOR
BE10FDLECM 1998	CARBURETOR -- 15 HP
BE10FDLECM 1998	CARBURETOR -- 9.9 HP
BE10FDLEDR 1996	CARBURETOR - 15 H.P.
BE10FDLEDR 1996	CARBURETOR - 9.9 H.P.
BE10FDLEUA 1997	CARBURETOR - 15 H.P.
BE10FDLEUA 1997	CARBURETOR - 9.9 H.P.
BE10FPXEDC 1996	CARBURETOR - 15 H.P.
BE10FPXEDC 1996	CARBURETOR - 9.9 H.P.
BE10FPXEUR 1997	CARBURETOR - 15 H.P.
BE10FPXEUR 1997	CARBURETOR - 9.9 H.P.
BE10FREldr 1996	CARBURETOR - 15 H.P.
BE10FREldr 1996	CARBURETOR - 9.9 H.P.
BE10FRELUa 1997	CARBURETOR - 15 H.P.
BE10FRELUa 1997	CARBURETOR - 9.9 H.P.
BE10FWEDC 1996	CARBURETOR
BE10FWEUR 1997	CARBURETOR
BE10FWLEDC 1996	CARBURETOR
BE10FWLEUR 1997	CARBURETOR
BE15FAEDR 1996	CARBURETOR - 15 H.P.
BE15FAEDR 1996	CARBURETOR - 9.9 H.P.
BE15FAEUA 1997	CARBURETOR - 15 H.P.
BE15FAEUA 1997	CARBURETOR - 9.9 H.P.
BE15FDLECM 1998	CARBURETOR -- 15 HP
BE15FDLECM 1998	CARBURETOR -- 9.9 HP
BE15FDLEDR 1996	CARBURETOR - 15 H.P.
BE15FDLEDR 1996	CARBURETOR - 9.9 H.P.
BE15FDLEUA 1997	CARBURETOR - 15 H.P.
BE15FDLEUA 1997	CARBURETOR - 9.9 H.P.
BE15FKEDR 1996	CARBURETOR - 15 H.P.

BE15FKEDR 1996	CARBURETOR - 9.9 H.P.
BE15FKEUA 1997	CARBURETOR - 15 H.P.
BE15FKEUA 1997	CARBURETOR - 9.9 H.P.
BE15FREDR 1996	CARBURETOR - 15 H.P.
BE15FREDR 1996	CARBURETOR - 9.9 H.P.
BE15FRELEDR 1996	CARBURETOR - 15 H.P.
BE15FRELEDR 1996	CARBURETOR - 9.9 H.P.
BE15FRELUA 1997	CARBURETOR - 15 H.P.
BE15FRELUA 1997	CARBURETOR - 9.9 H.P.
BE15FREUA 1997	CARBURETOR - 15 H.P.
BE15FREUA 1997	CARBURETOR - 9.9 H.P.
BE15FWECA 1998	CARBURETOR -- 15 HP
BE15FWECA 1998	CARBURETOR -- 9.9 HP
BE15FWEDC 1996	CARBURETOR - 15 H.P.
BE15FWEDC 1996	CARBURETOR - 9.9 H.P.
BE15FWEUR 1997	CARBURETOR - 15 H.P.
BE15FWEUR 1997	CARBURETOR - 9.9 H.P.
BE15FWLECA 1998	CARBURETOR -- 15 HP
BE15FWLECA 1998	CARBURETOR -- 9.9 HP
BE15FWLEDC 1996	CARBURETOR - 15 H.P.
BE15FWLEDC 1996	CARBURETOR - 9.9 H.P.
BE15FWLEUR 1997	CARBURETOR - 15 H.P.
BE15FWLEUR 1997	CARBURETOR - 9.9 H.P.
BE25ARECA 1998	CARBURETOR -- 25 HP
BE25ARECA 1998	CARBURETOR -- 35 HP
BE25AREDC 1996	CARBURETOR - 25 H.P.
BE25AREDC 1996	CARBURETOR - 35 H.P.
BE25AREUR 1997	CARBURETOR - 25 H.P.
BE25AREUR 1997	CARBURETOR - 35 H.P.
BE25ARLECA 1998	CARBURETOR -- 25 HP
BE25ARLECA 1998	CARBURETOR -- 35 HP
BE25ARLEDC 1996	CARBURETOR - 25 H.P.
BE25ARLEDC 1996	CARBURETOR - 35 H.P.
BE25ARLEUR 1997	CARBURETOR - 25 H.P.
BE25ARLEUR 1997	CARBURETOR - 35 H.P.

BE25KECA 1998	CARBURETOR -- 25 HP
BE25KECA 1998	CARBURETOR -- 35 HP
BE25KEDC 1996	CARBURETOR - 25 H.P.
BE25KEDC 1996	CARBURETOR - 35 H.P.
BE25KEUR 1997	CARBURETOR - 25 H.P.
BE25KEUR 1997	CARBURETOR - 35 H.P.
BE25KLECA 1998	CARBURETOR -- 25 HP
BE25KLECA 1998	CARBURETOR -- 35 HP
BE25KLEDC 1996	CARBURETOR - 25 H.P.
BE25KLEDC 1996	CARBURETOR - 35 H.P.
BE25KLEUR 1997	CARBURETOR - 25 H.P.
BE25KLEUR 1997	CARBURETOR - 35 H.P.
BE25QLECA 1998	CARBURETOR -- 25 HP
BE25QLECA 1998	CARBURETOR -- 35 HP
BE25QLEDC 1996	CARBURETOR - 25 H.P.
BE25QLEDC 1996	CARBURETOR - 35 H.P.
BE25QLEUR 1997	CARBURETOR - 25 H.P.
BE25QLEUR 1997	CARBURETOR - 35 H.P.
BE35ARECR 1998	CARBURETOR -- 25 HP
BE35ARECR 1998	CARBURETOR -- 35 HP
BE35AREDS 1996	CARBURETOR - 25 H.P.
BE35AREDS 1996	CARBURETOR - 35 H.P.
BE35AREEA 1999	CARBURETOR -- 25 HP
BE35AREEA 1999	CARBURETOR -- 35 HP
BE35AREUC 1997	CARBURETOR - 25 H.P.
BE35AREUC 1997	CARBURETOR - 35 H.P.
BE35ARLECR 1998	CARBURETOR -- 25 HP
BE35ARLECR 1998	CARBURETOR -- 35 HP
BE35ARLEDS 1996	CARBURETOR - 25 H.P.
BE35ARLEDS 1996	CARBURETOR - 35 H.P.
BE35ARLEUC 1997	CARBURETOR - 25 H.P.
BE35ARLEUC 1997	CARBURETOR - 35 H.P.
BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
BE35ARSIB rope start, tiller, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	CARBURETOR - 25 HP

BE35ARSSM 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	CARBURETOR - 35 HP
BE35KECA 1998	CARBURETOR -- 25 HP
BE35KECA 1998	CARBURETOR -- 35 HP
BE35KEDC 1996	CARBURETOR - 25 H.P.
BE35KEDC 1996	CARBURETOR - 35 H.P.
BE35KEEM 1999	CARBURETOR -- 25 HP
BE35KEEM 1999	CARBURETOR -- 35 HP
BE35KEUR 1997	CARBURETOR - 25 H.P.
BE35KEUR 1997	CARBURETOR - 35 H.P.
BE35KLECA 1998	CARBURETOR -- 25 HP
BE35KLECA 1998	CARBURETOR -- 35 HP
BE35KLEDC 1996	CARBURETOR - 25 H.P.
BE35KLEDC 1996	CARBURETOR - 35 H.P.
BE35KLEUR 1997	CARBURETOR - 25 H.P.
BE35KLEUR 1997	CARBURETOR - 35 H.P.
BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
BE35KSIE elec start, tiller, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	CARBURETOR - 25 HP
BE35KSSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	CARBURETOR - 35 HP
BE35QLECA 1998	CARBURETOR -- 25 HP
BE35QLECA 1998	CARBURETOR -- 35 HP
BE35QLEDC 1996	CARBURETOR - 25 H.P.
BE35QLEDC 1996	CARBURETOR - 35 H.P.
BE35QLEUR 1997	CARBURETOR - 25 H.P.
BE35QLEUR 1997	CARBURETOR - 35 H.P.
BE5FRBECC 1998	CARBURETOR
BE5FRBEUS 1997	CARBURETOR
BE5FRBLECC 1998	CARBURETOR
BE5FRBLEUS 1997	CARBURETOR
BE8FRBECA 1998	CARBURETOR
BE8FRBEDC 1996	CARBURETOR
BE8FRBEUR 1997	CARBURETOR
BE8FRBLECA 1998	CARBURETOR
BE8FRBLEDC 1996	CARBURETOR
BE8FRBLEUR 1997	CARBURETOR

BE8FRBXEDC 1996	CARBURETOR
BE8FRBXEUR 1997	CARBURETOR
BJ10FAEDC 1996	CARBURETOR
BJ10FAEUR 1997	CARBURETOR
BJ10FCLEDC 1996	CARBURETOR
BJ10FCLEUR 1997	CARBURETOR
BJ10FDLECM 1998	CARBURETOR -- 15 HP
BJ10FDLECM 1998	CARBURETOR -- 9.9 HP
BJ10FDLEDR 1996	CARBURETOR - 15 H.P.
BJ10FDLEDR 1996	CARBURETOR - 9.9 H.P.
BJ10FDLEUA 1997	CARBURETOR - 15 H.P.
BJ10FDLEUA 1997	CARBURETOR - 9.9 H.P.
BJ10FPXEDC 1996	CARBURETOR - 15 H.P.
BJ10FPXEDC 1996	CARBURETOR - 9.9 H.P.
BJ10FPXEUR 1997	CARBURETOR - 15 H.P.
BJ10FPXEUR 1997	CARBURETOR - 9.9 H.P.
BJ10FREldr 1996	CARBURETOR - 15 H.P.
BJ10FREldr 1996	CARBURETOR - 9.9 H.P.
BJ10FRELUA 1997	CARBURETOR - 15 H.P.
BJ10FRELUA 1997	CARBURETOR - 9.9 H.P.
BJ10FWEDC 1996	CARBURETOR
BJ10FWEUR 1997	CARBURETOR
BJ10FWLEDC 1996	CARBURETOR
BJ10FWLEUR 1997	CARBURETOR
BJ15FAEDR 1996	CARBURETOR - 15 H.P.
BJ15FAEDR 1996	CARBURETOR - 9.9 H.P.
BJ15FAEUA 1997	CARBURETOR - 15 H.P.
BJ15FAEUA 1997	CARBURETOR - 9.9 H.P.
BJ15FDLECM 1998	CARBURETOR -- 15 HP
BJ15FDLECM 1998	CARBURETOR -- 9.9 HP
BJ15FDLEDR 1996	CARBURETOR - 15 H.P.
BJ15FDLEDR 1996	CARBURETOR - 9.9 H.P.
BJ15FDLEUA 1997	CARBURETOR - 15 H.P.
BJ15FDLEUA 1997	CARBURETOR - 9.9 H.P.
BJ15FKEDR 1996	CARBURETOR - 15 H.P.

BJ15FKEDR 1996	CARBURETOR - 9.9 H.P.
BJ15FKEUA 1997	CARBURETOR - 15 H.P.
BJ15FKEUA 1997	CARBURETOR - 9.9 H.P.
BJ15FREDR 1996	CARBURETOR - 15 H.P.
BJ15FREDR 1996	CARBURETOR - 9.9 H.P.
BJ15FRELEDR 1996	CARBURETOR - 15 H.P.
BJ15FRELEDR 1996	CARBURETOR - 9.9 H.P.
BJ15FRELUA 1997	CARBURETOR - 15 H.P.
BJ15FRELUA 1997	CARBURETOR - 9.9 H.P.
BJ15FREUA 1997	CARBURETOR - 15 H.P.
BJ15FREUA 1997	CARBURETOR - 9.9 H.P.
BJ15FWECA 1998	CARBURETOR -- 15 HP
BJ15FWECA 1998	CARBURETOR -- 9.9 HP
BJ15FWEDC 1996	CARBURETOR - 15 H.P.
BJ15FWEDC 1996	CARBURETOR - 9.9 H.P.
BJ15FWEUR 1997	CARBURETOR - 15 H.P.
BJ15FWEUR 1997	CARBURETOR - 9.9 H.P.
BJ15FWLECA 1998	CARBURETOR -- 15 HP
BJ15FWLECA 1998	CARBURETOR -- 9.9 HP
BJ15FWLEDC 1996	CARBURETOR - 15 H.P.
BJ15FWLEDC 1996	CARBURETOR - 9.9 H.P.
BJ15FWLEUR 1997	CARBURETOR - 15 H.P.
BJ15FWLEUR 1997	CARBURETOR - 9.9 H.P.
BJ25ARECA 1998	CARBURETOR -- 25 HP
BJ25ARECA 1998	CARBURETOR -- 35 HP
BJ25AREDC 1996	CARBURETOR - 25 H.P.
BJ25AREDC 1996	CARBURETOR - 35 H.P.
BJ25AREUR 1997	CARBURETOR - 25 H.P.
BJ25AREUR 1997	CARBURETOR - 35 H.P.
BJ25ARLECA 1998	CARBURETOR -- 25 HP
BJ25ARLECA 1998	CARBURETOR -- 35 HP
BJ25ARLEDC 1996	CARBURETOR - 25 H.P.
BJ25ARLEDC 1996	CARBURETOR - 35 H.P.
BJ25ARLEUR 1997	CARBURETOR - 25 H.P.
BJ25ARLEUR 1997	CARBURETOR - 35 H.P.

BJ25KECA 1998	CARBURETOR -- 25 HP
BJ25KECA 1998	CARBURETOR -- 35 HP
BJ25KEDC 1996	CARBURETOR - 25 H.P.
BJ25KEDC 1996	CARBURETOR - 35 H.P.
BJ25KEUR 1997	CARBURETOR - 25 H.P.
BJ25KEUR 1997	CARBURETOR - 35 H.P.
BJ25KLECA 1998	CARBURETOR -- 25 HP
BJ25KLECA 1998	CARBURETOR -- 35 HP
BJ25KLEDC 1996	CARBURETOR - 25 H.P.
BJ25KLEDC 1996	CARBURETOR - 35 H.P.
BJ25KLEUR 1997	CARBURETOR - 25 H.P.
BJ25KLEUR 1997	CARBURETOR - 35 H.P.
BJ25PL3EEM 1999	CARBURETOR -- 25 HP
BJ25PL3EEM 1999	CARBURETOR -- 35 HP
BJ25PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 25 HP
BJ25PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 35 HP
BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	CARBURETOR - 25 HP
BJ25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	CARBURETOR - 35 HP
BJ25QLECA 1998	CARBURETOR -- 25 HP
BJ25QLECA 1998	CARBURETOR -- 35 HP
BJ25QLEDC 1996	CARBURETOR - 25 H.P.
BJ25QLEDC 1996	CARBURETOR - 35 H.P.
BJ25QLEUR 1997	CARBURETOR - 25 H.P.
BJ25QLEUR 1997	CARBURETOR - 35 H.P.
BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
BJ25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
BJ35ARECR 1998	CARBURETOR -- 25 HP
BJ35ARECR 1998	CARBURETOR -- 35 HP
BJ35AREDS 1996	CARBURETOR - 25 H.P.
BJ35AREDS 1996	CARBURETOR - 35 H.P.
BJ35AREEA 1999	CARBURETOR -- 25 HP
BJ35AREEA 1999	CARBURETOR -- 35 HP
BJ35AREUC 1997	CARBURETOR - 25 H.P.
BJ35AREUC 1997	CARBURETOR - 35 H.P.
BJ35ARLECR 1998	CARBURETOR -- 25 HP

BJ35ARLECR 1998	CARBURETOR -- 35 HP
BJ35ARLEDS 1996	CARBURETOR - 25 H.P.
BJ35ARLEDS 1996	CARBURETOR - 35 H.P.
BJ35ARLEUC 1997	CARBURETOR - 25 H.P.
BJ35ARLEUC 1997	CARBURETOR - 35 H.P.
BJ35E3EEM 1999	CARBURETOR -- 25 HP
BJ35E3EEM 1999	CARBURETOR -- 35 HP
BJ35E3SIE elec start, 15 in shaft, n/a usa 2001	CARBURETOR - 25 HP
BJ35E3SIE elec start, 15 in shaft, n/a usa 2001	CARBURETOR - 35 HP
BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000	CARBURETOR - 25 HP
BJ35E3SSB 3 Cyl, Elec. Start, 15 IN. shaft, N/A USA 2000	CARBURETOR - 35 HP
BJ35EL3EEM 1999	CARBURETOR -- 25 HP
BJ35EL3EEM 1999	CARBURETOR -- 35 HP
BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
BJ35EL3SIE elec start, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000	CARBURETOR - 25 HP
BJ35EL3SSB 3 Cyl, Elec. Start, 20 IN. shaft, N/A USA 2000	CARBURETOR - 35 HP
BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
BJ35EV3SIE elec start, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
BJ35EVL3SIE elec start, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
BJ35KECA 1998	CARBURETOR -- 25 HP
BJ35KECA 1998	CARBURETOR -- 35 HP
BJ35KEDC 1996	CARBURETOR - 25 H.P.
BJ35KEDC 1996	CARBURETOR - 35 H.P.
BJ35KEEM 1999	CARBURETOR -- 25 HP
BJ35KEEM 1999	CARBURETOR -- 35 HP
BJ35KEUR 1997	CARBURETOR - 25 H.P.
BJ35KEUR 1997	CARBURETOR - 35 H.P.
BJ35KLECA 1998	CARBURETOR -- 25 HP
BJ35KLECA 1998	CARBURETOR -- 35 HP
BJ35KLEDC 1996	CARBURETOR - 25 H.P.
BJ35KLEDC 1996	CARBURETOR - 35 H.P.
BJ35KLEUR 1997	CARBURETOR - 25 H.P.
BJ35KLEUR 1997	CARBURETOR - 35 H.P.

BJ35PL3EEM 1999	CARBURETOR -- 25 HP
BJ35PL3EEM 1999	CARBURETOR -- 35 HP
BJ35PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 25 HP
BJ35PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 35 HP
BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	CARBURETOR - 25 HP
BJ35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	CARBURETOR - 35 HP
BJ35QLECA 1998	CARBURETOR -- 25 HP
BJ35QLECA 1998	CARBURETOR -- 35 HP
BJ35QLEDC 1996	CARBURETOR - 25 H.P.
BJ35QLEDC 1996	CARBURETOR - 35 H.P.
BJ35QLEUR 1997	CARBURETOR - 25 H.P.
BJ35QLEUR 1997	CARBURETOR - 35 H.P.
BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
BJ35VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
BJ5FRBECC 1998	CARBURETOR
BJ5FRBEUS 1997	CARBURETOR
BJ5FRBLECC 1998	CARBURETOR
BJ5FRBLEUS 1997	CARBURETOR
BJ8FRBECA 1998	CARBURETOR
BJ8FRBEDC 1996	CARBURETOR
BJ8FRBEUR 1997	CARBURETOR
BJ8FRBLECA 1998	CARBURETOR
BJ8FRBLEDC 1996	CARBURETOR
BJ8FRBLEUR 1997	CARBURETOR
BJ8FRBXEDC 1996	CARBURETOR
BJ8FRBXEUR 1997	CARBURETOR
E10EBL4EEB 1999	CARBURETOR -- 9.9 HP
E10EBL4EEB 1999	CARBURETOR -- 15 HP
E10EL4EEB 1999	CARBURETOR -- 9.9 HP
E10EL4EEB 1999	CARBURETOR -- 15 HP
E10EL4SID 4-stroke, elec start, remote, 20 in shaft 2001	CARBURETOR - 9.9 HP
E10EL4SID 4-stroke, elec start, remote, 20 in shaft 2001	CARBURETOR - 15 HP
E10EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	CARBURETOR - 9.9 HP
E10EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	CARBURETOR -15 HP
E10EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	CARBURETOR - 9.9 HP

E10EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	CARBURETOR - 15 HP
E10EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	CARBURETOR - 9.9 HP
E10EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	CARBURETOR -15 HP
E10FEXECM 1998	CARBURETOR -- 15 HP
E10FEXECM 1998	CARBURETOR -- 9.9 HP
E10FEXEDR 1996	CARBURETOR - 15 H.P.
E10FEXEDR 1996	CARBURETOR - 9.9 H.P.
E10FEXEO 1995	CARBURETOR - 15 H.P.
E10FEXEO 1995	CARBURETOR - 9.9 H.P.
E10FEXEUA 1997	CARBURETOR - 15 H.P.
E10FEXEUA 1997	CARBURETOR - 9.9 H.P.
E10FOECA 1998	CARBURETOR
E10FOLECA 1998	CARBURETOR
E10FRECM 1998	CARBURETOR -- 15 HP
E10FRECM 1998	CARBURETOR -- 9.9 HP
E10FREDR 1996	CARBURETOR - 15 H.P.
E10FREDR 1996	CARBURETOR - 9.9 H.P.
E10FRELECM 1998	CARBURETOR -- 15 HP
E10FRELECM 1998	CARBURETOR -- 9.9 HP
E10FRELEDR 1996	CARBURETOR - 15 H.P.
E10FRELEDR 1996	CARBURETOR - 9.9 H.P.
E10FRELEOC 1995	CARBURETOR - 15 H.P.
E10FRELEOC 1995	CARBURETOR - 9.9 H.P.
E10FRELEUA 1997	CARBURETOR - 15 H.P.
E10FRELEUA 1997	CARBURETOR - 9.9 H.P.
E10FREOC 1995	CARBURETOR - 15 H.P.
E10FREOC 1995	CARBURETOR - 9.9 H.P.
E10FREUA 1997	CARBURETOR - 15 H.P.
E10FREUA 1997	CARBURETOR - 9.9 H.P.
E10FRLECM 1998	CARBURETOR -- 15 HP
E10FRLECM 1998	CARBURETOR -- 9.9 HP
E10FRLEDR 1996	CARBURETOR - 15 H.P.
E10FRLEDR 1996	CARBURETOR - 9.9 H.P.
E10FRLEO 1995	CARBURETOR - 15 H.P.
E10FRLEO 1995	CARBURETOR - 9.9 H.P.

E10FRLEUA 1997	CARBURETOR - 15 H.P.
E10FRLEUA 1997	CARBURETOR - 9.9 H.P.
E10R4EEB 1999	CARBURETOR -- 9.9 HP
E10R4EEB 1999	CARBURETOR -- 15 HP
E10R4SID 4-stroke, rope start, tiller, 15 in shaft 2001	CARBURETOR - 9.9 HP
E10R4SID 4-stroke, rope start, tiller, 15 in shaft 2001	CARBURETOR - 15 HP
E10R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	CARBURETOR - 9.9 HP
E10R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	CARBURETOR -15 HP
E10RL4EEB 1999	CARBURETOR -- 9.9 HP
E10RL4EEB 1999	CARBURETOR -- 15 HP
E10RL4SID 4-stroke, rope start, tiller, 20 in shaft 2001	CARBURETOR - 9.9 HP
E10RL4SID 4-stroke, rope start, tiller, 20 in shaft 2001	CARBURETOR - 15 HP
E10RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	CARBURETOR - 9.9 HP
E10RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	CARBURETOR -15 HP
E10RV4SIC 4-stroke, rope start, tiller, 15 in shaft, wht 2001	CARBURETOR - 9.9 HP
E10RV4SIC 4-stroke, rope start, tiller, 15 in shaft, wht 2001	CARBURETOR - 15 HP
E10RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	CARBURETOR - 9.9 HP
E10RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	CARBURETOR -15 HP
E10RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	CARBURETOR - 9.9 HP
E10RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	CARBURETOR - 15 HP
E10RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	CARBURETOR - 9.9 HP
E10RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	CARBURETOR -15 HP
E10TEX4EEB 1999	CARBURETOR -- 9.9 HP
E10TEX4EEB 1999	CARBURETOR -- 15 HP
E10TEX4SID 4-stroke, elec start, tiller, 25 in shaft 2001	CARBURETOR - 9.9 HP
E10TEX4SID 4-stroke, elec start, tiller, 25 in shaft 2001	CARBURETOR - 15 HP
E10TEX4SSE 4-Stroke, Elec. Start, Tiller, 25 IN shaft 2000	CARBURETOR - 9.9 HP
E10TEX4SSE 4-Stroke, Elec. Start, Tiller, 25 IN shaft 2000	CARBURETOR -15 HP
E10TVX4SIC 4-stroke, elec start, tiller, 25 in shaft, wht 2001	CARBURETOR - 9.9 HP
E10TVX4SIC 4-stroke, elec start, tiller, 25 in shaft, wht 2001	CARBURETOR - 15 HP
E10TVX4SSS 4-Stroke, Elec. Start, Tiller, 25 IN shaft, wht 2000	CARBURETOR - 9.9 HP
E10TVX4SSS 4-Stroke, Elec. Start, Tiller, 25 IN shaft, wht 2000	CARBURETOR -15 HP
E15DLEOC 1995	CARBURETOR - 15 H.P.
E15DLEOC 1995	CARBURETOR - 9.9 H.P.
E15EBL4EEB 1999	CARBURETOR -- 9.9 HP

E15EBL4EEB 1999	CARBURETOR -- 15 HP
E15EL4EEB 1999	CARBURETOR -- 9.9 HP
E15EL4EEB 1999	CARBURETOR -- 15 HP
E15EL4SID 4-stroke, elec start, 20 in shaft 2001	CARBURETOR - 9.9 HP
E15EL4SID 4-stroke, elec start, 20 in shaft 2001	CARBURETOR - 15 HP
E15EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	CARBURETOR - 9.9 HP
E15EL4SSE 4-Stroke, Elec. Start, 20 IN shaft 2000	CARBURETOR -15 HP
E15EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	CARBURETOR - 9.9 HP
E15EVL4SIC 4-stroke, elec start, 20 in shaft, wht 2001	CARBURETOR - 15 HP
E15EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	CARBURETOR - 9.9 HP
E15EVL4SSS 4-Stroke, Elec. Start, 20 IN shaft, wht 2000	CARBURETOR -15 HP
E15FKEDR 1996	CARBURETOR - 15 H.P.
E15FKEDR 1996	CARBURETOR - 9.9 H.P.
E15FKEUA 1997	CARBURETOR - 15 H.P.
E15FKEUA 1997	CARBURETOR - 9.9 H.P.
E15FRECM 1998	CARBURETOR -- 15 HP
E15FRECM 1998	CARBURETOR -- 9.9 HP
E15FREDR 1996	CARBURETOR - 15 H.P.
E15FREDR 1996	CARBURETOR - 9.9 H.P.
E15FRELECM 1998	CARBURETOR -- 15 HP
E15FRELECM 1998	CARBURETOR -- 9.9 HP
E15FRELEDR 1996	CARBURETOR - 15 H.P.
E15FRELEDR 1996	CARBURETOR - 9.9 H.P.
E15FRELEUA 1997	CARBURETOR - 15 H.P.
E15FRELEUA 1997	CARBURETOR - 9.9 H.P.
E15FREOC 1995	CARBURETOR - 15 H.P.
E15FREOC 1995	CARBURETOR - 9.9 H.P.
E15FREUA 1997	CARBURETOR - 15 H.P.
E15FREUA 1997	CARBURETOR - 9.9 H.P.
E15FRLECM 1998	CARBURETOR -- 15 HP
E15FRLECM 1998	CARBURETOR -- 9.9 HP
E15FRLEDR 1996	CARBURETOR - 15 H.P.
E15FRLEDR 1996	CARBURETOR - 9.9 H.P.
E15FRLEOC 1995	CARBURETOR - 15 H.P.
E15FRLEOC 1995	CARBURETOR - 9.9 H.P.

E15FRLEUA 1997	CARBURETOR - 15 H.P.
E15FRLEUA 1997	CARBURETOR - 9.9 H.P.
E15KEOC 1995	CARBURETOR - 15 H.P.
E15KEOC 1995	CARBURETOR - 9.9 H.P.
E15R4EEB 1999	CARBURETOR -- 9.9 HP
E15R4EEB 1999	CARBURETOR -- 15 HP
E15R4SID 4-stroke, rope start, 15 in shaft 2001	CARBURETOR - 9.9 HP
E15R4SID 4-stroke, rope start, 15 in shaft 2001	CARBURETOR - 15 HP
E15R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	CARBURETOR - 9.9 HP
E15R4SSE 4-Stroke, Rope Start, Tiller, 15 IN shaft 2000	CARBURETOR -15 HP
E15RB4EEB 1999	CARBURETOR -- 9.9 HP
E15RB4EEB 1999	CARBURETOR -- 15 HP
E15RBL4EEB 1999	CARBURETOR -- 9.9 HP
E15RBL4EEB 1999	CARBURETOR -- 15 HP
E15RL4EEB 1999	CARBURETOR -- 9.9 HP
E15RL4EEB 1999	CARBURETOR -- 15 HP
E15RL4SID 4-stroke, rope start, 20 in shaft 2001	CARBURETOR - 9.9 HP
E15RL4SID 4-stroke, rope start, 20 in shaft 2001	CARBURETOR - 15 HP
E15RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	CARBURETOR - 9.9 HP
E15RL4SSE 4-Stroke, Rope Start, Tiller, 20 IN shaft 2000	CARBURETOR -15 HP
E15RV4SIC 4-stroke,rope start, 15 in shaft, wht 2001	CARBURETOR - 9.9 HP
E15RV4SIC 4-stroke,rope start, 15 in shaft, wht 2001	CARBURETOR - 15 HP
E15RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	CARBURETOR - 9.9 HP
E15RV4SSS 4-Stroke, Rope Start, Tiller, 15 IN shaft, wht 2000	CARBURETOR -15 HP
E15RVL4SIC 4-stroke, elec start, 15 in shaft, wht 2001	CARBURETOR - 9.9 HP
E15RVL4SIC 4-stroke, elec start, 15 in shaft, wht 2001	CARBURETOR - 15 HP
E15RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	CARBURETOR - 9.9 HP
E15RVL4SSS 4-Stroke, Rope Start, Tiller, 20 IN shaft, wht 2000	CARBURETOR -15 HP
E25KLECA 1998	CARBURETOR -- 25 HP
E25KLECA 1998	CARBURETOR -- 35 HP
E25KLEDC 1996	CARBURETOR - 25 H.P.
E25KLEDC 1996	CARBURETOR - 35 H.P.
E25KLEUR 1997	CARBURETOR - 25 H.P.
E25KLEUR 1997	CARBURETOR - 35 H.P.
E25QLECA 1998	CARBURETOR -- 25 HP

E25QLECA 1998	CARBURETOR -- 35 HP
E25QLEDC 1996	CARBURETOR - 25 H.P.
E25QLEDC 1996	CARBURETOR - 35 H.P.
E25QLEUR 1997	CARBURETOR - 25 H.P.
E25QLEUR 1997	CARBURETOR - 35 H.P.
E25RMECA 1998	CARBURETOR -- 25 HP
E25RMECA 1998	CARBURETOR -- 35 HP
E25RMEDC 1996	CARBURETOR - 25 H.P.
E25RMEDC 1996	CARBURETOR - 35 H.P.
E25RMEUR 1997	CARBURETOR - 25 H.P.
E25RMEUR 1997	CARBURETOR - 35 H.P.
E25RMLECA 1998	CARBURETOR -- 25 HP
E25RMLECA 1998	CARBURETOR -- 35 HP
E25RMLEDC 1996	CARBURETOR - 25 H.P.
E25RMLEDC 1996	CARBURETOR - 35 H.P.
E25RMLEUR 1997	CARBURETOR - 25 H.P.
E25RMLEUR 1997	CARBURETOR - 35 H.P.
E25TKECA 1998	CARBURETOR -- 25 HP
E25TKECA 1998	CARBURETOR -- 35 HP
E25TKEDC 1996	CARBURETOR - 25 H.P.
E25TKEDC 1996	CARBURETOR - 35 H.P.
E25TKEUR 1997	CARBURETOR - 25 H.P.
E25TKEUR 1997	CARBURETOR - 35 H.P.
E25TKLECA 1998	CARBURETOR -- 25 HP
E25TKLECA 1998	CARBURETOR -- 35 HP
E25TKLEDC 1996	CARBURETOR - 25 H.P.
E25TKLEDC 1996	CARBURETOR - 35 H.P.
E25TKLEUR 1997	CARBURETOR - 25 H.P.
E25TKLEUR 1997	CARBURETOR - 35 H.P.
E35KLECA 1998	CARBURETOR -- 25 HP
E35KLECA 1998	CARBURETOR -- 35 HP
E35KLEDC 1996	CARBURETOR - 25 H.P.
E35KLEDC 1996	CARBURETOR - 35 H.P.
E35KLEUR 1997	CARBURETOR - 25 H.P.
E35KLEUR 1997	CARBURETOR - 35 H.P.

E35QLECA 1998	CARBURETOR -- 25 HP
E35QLECA 1998	CARBURETOR -- 35 HP
E35QLEDC 1996	CARBURETOR - 25 H.P.
E35QLEDC 1996	CARBURETOR - 35 H.P.
E35QLEUR 1997	CARBURETOR - 25 H.P.
E35QLEUR 1997	CARBURETOR - 35 H.P.
E35RMLEDC 1996	CARBURETOR - 25 H.P.
E35RMLEDC 1996	CARBURETOR - 35 H.P.
E35RMLEUR 1997	CARBURETOR - 25 H.P.
E35RMLEUR 1997	CARBURETOR - 35 H.P.
E35TKLECA 1998	CARBURETOR -- 25 HP
E35TKLECA 1998	CARBURETOR -- 35 HP
E35TKLEDC 1996	CARBURETOR - 25 H.P.
E35TKLEDC 1996	CARBURETOR - 35 H.P.
E35TKLEUR 1997	CARBURETOR - 25 H.P.
E35TKLEUR 1997	CARBURETOR - 35 H.P.
E5R4EEM 1999	CARBURETOR
E5R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	CARBURETOR
E5R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	CARBURETOR
E5RB4EER 1999	CARBURETOR
E5RBL4EER 1999	CARBURETOR
E5RL4EEM 1999	CARBURETOR
E5RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	CARBURETOR
E5RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	CARBURETOR
E6R4EEM 1999	CARBURETOR
E6R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	CARBURETOR
E6R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. Shaft 2000	CARBURETOR
E6RL4EEM 1999	CARBURETOR
E6RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	CARBURETOR
E6RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. Shaft 2000	CARBURETOR
E8FRECA 1998	CARBURETOR
E8FREDC 1996	CARBURETOR
E8FREUR 1997	CARBURETOR
E8FRLECA 1998	CARBURETOR
E8FRXECA 1998	CARBURETOR

E8FRXEDC 1996	CARBURETOR
E8FRXEUR 1997	CARBURETOR
E8R4EEM 1999	CARBURETOR
E8R4SIE 4-stroke, rope start, tiller, 15 in shaft 2001	CARBURETOR
E8R4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft 2000	CARBURETOR
E8RB4EEM 1999	CARBURETOR
E8RBL4EEM 1999	CARBURETOR
E8RL4EEM 1999	CARBURETOR
E8RL4SIE 4-stroke, rope start, tiller, 20 in shaft 2001	CARBURETOR
E8RL4SSB 4-Stroke, Rope Start, Tiller, 20 IN. shaft 2000	CARBURETOR
E8RVL4SIC 4-stroke, rope start, tiller, 20 in shaft, wht 2001	CARBURETOR
E8RVL4SSB 4-Stroke, Rope Start, Tiller, 15 IN. shaft, N/A USA 2000	CARBURETOR
HE10FDEDC 1996	CARBURETOR
HE10FDLEDC 1996	CARBURETOR
HE10FELECA 1998	CARBURETOR
HE10FELEDC 1996	CARBURETOR
HE10FELEUR 1997	CARBURETOR
HE10FOEUR 1997	CARBURETOR
HE10FOLEUR 1997	CARBURETOR
HE10FTEDC 1996	CARBURETOR
HE10FTEUR 1997	CARBURETOR
HE10FTLEDC 1996	CARBURETOR
HE10FTLEUR 1997	CARBURETOR
HE15KCF 1997	CARBURETOR
HE15KCLF 1997	CARBURETOR
HE15KCLN 1996	CARBURETOR
HE15KCLO 1998	CARBURETOR
HE15KCN 1996	CARBURETOR
HE15KCO 1998	CARBURETOR
HE15RPLW 1997	CARBURETOR
HE15RPW 1997	CARBURETOR
HE35RMLEDC 1996	CARBURETOR - 25 H.P.
HE35RMLEDC 1996	CARBURETOR - 35 H.P.
HE35RMLEUR 1997	CARBURETOR - 25 H.P.
HE35RMLEUR 1997	CARBURETOR - 35 H.P.

HE5FRECA 1998	CARBURETOR
HE5FREUR 1997	CARBURETOR
HE5FRLECA 1998	CARBURETOR
HE5FRLEUR 1997	CARBURETOR
HE6FRECA 1998	CARBURETOR
HE6FREUR 1997	CARBURETOR
HE6FRLECA 1998	CARBURETOR
HE6FRLEUR 1997	CARBURETOR
HE8FREDC 1996	CARBURETOR
HE8FREUR 1997	CARBURETOR
HE8FRLEDC 1996	CARBURETOR
HE8FRLEUR 1997	CARBURETOR
HJ10FDEDC 1996	CARBURETOR
HJ10FDLEDC 1996	CARBURETOR
HJ10FELECA 1998	CARBURETOR
HJ10FELEDC 1996	CARBURETOR
HJ10FELEUR 1997	CARBURETOR
HJ10FOEUR 1997	CARBURETOR
HJ10FOLEUR 1997	CARBURETOR
HJ10FTEDC 1996	CARBURETOR
HJ10FTEUR 1997	CARBURETOR
HJ10FTLEDC 1996	CARBURETOR
HJ10FTLEUR 1997	CARBURETOR
HJ15KCF 1997	CARBURETOR
HJ15KCLF 1997	CARBURETOR
HJ15KCLN 1996	CARBURETOR
HJ15KCLO 1998	CARBURETOR
HJ15KCN 1996	CARBURETOR
HJ15KCO 1998	CARBURETOR
HJ15RPLW 1997	CARBURETOR
HJ15RPW 1997	CARBURETOR
HJ35RMLEDC 1996	CARBURETOR - 25 H.P.
HJ35RMLEDC 1996	CARBURETOR - 35 H.P.
HJ35RMLEUR 1997	CARBURETOR - 25 H.P.
HJ35RMLEUR 1997	CARBURETOR - 35 H.P.

HJ5FRECA 1998	CARBURETOR
HJ5FREUR 1997	CARBURETOR
HJ5FRLECA 1998	CARBURETOR
HJ5FRLEUR 1997	CARBURETOR
HJ6FRECA 1998	CARBURETOR
HJ6FREUR 1997	CARBURETOR
HJ6FRLECA 1998	CARBURETOR
HJ6FRLEUR 1997	CARBURETOR
HJ8FREDC 1996	CARBURETOR
HJ8FREUR 1997	CARBURETOR
HJ8FRLEDC 1996	CARBURETOR
HJ8FRLEUR 1997	CARBURETOR
J10FEXECM 1998	CARBURETOR -- 15 HP
J10FEXECM 1998	CARBURETOR -- 9.9 HP
J10FEXEDR 1996	CARBURETOR - 15 H.P.
J10FEXEDR 1996	CARBURETOR - 9.9 H.P.
J10FEXEO 1995	CARBURETOR - 15 H.P.
J10FEXEO 1995	CARBURETOR - 9.9 H.P.
J10FEXEUA 1997	CARBURETOR - 15 H.P.
J10FEXEUA 1997	CARBURETOR - 9.9 H.P.
J10FOECA 1998	CARBURETOR
J10FOLECA 1998	CARBURETOR
J10FRECM 1998	CARBURETOR -- 15 HP
J10FRECM 1998	CARBURETOR -- 9.9 HP
J10FREDR 1996	CARBURETOR - 15 H.P.
J10FREDR 1996	CARBURETOR - 9.9 H.P.
J10FRELECM 1998	CARBURETOR -- 15 HP
J10FRELECM 1998	CARBURETOR -- 9.9 HP
J10FRELEDR 1996	CARBURETOR - 15 H.P.
J10FRELEDR 1996	CARBURETOR - 9.9 H.P.
J10FRELEOC 1995	CARBURETOR - 15 H.P.
J10FRELEOC 1995	CARBURETOR - 9.9 H.P.
J10FRELEUA 1997	CARBURETOR - 15 H.P.
J10FRELEUA 1997	CARBURETOR - 9.9 H.P.
J10FREOC 1995	CARBURETOR - 15 H.P.

J10FREOC 1995	CARBURETOR - 9.9 H.P.
J10FREUA 1997	CARBURETOR - 15 H.P.
J10FREUA 1997	CARBURETOR - 9.9 H.P.
J10FRLECM 1998	CARBURETOR -- 15 HP
J10FRLECM 1998	CARBURETOR -- 9.9 HP
J10FRLEDR 1996	CARBURETOR - 15 H.P.
J10FRLEDR 1996	CARBURETOR - 9.9 H.P.
J10FRLEO 1995	CARBURETOR - 15 H.P.
J10FRLEO 1995	CARBURETOR - 9.9 H.P.
J10FRLEUA 1997	CARBURETOR - 15 H.P.
J10FRLEUA 1997	CARBURETOR - 9.9 H.P.
J15DLEOC 1995	CARBURETOR - 15 H.P.
J15DLEOC 1995	CARBURETOR - 9.9 H.P.
J15FKEDR 1996	CARBURETOR - 15 H.P.
J15FKEDR 1996	CARBURETOR - 9.9 H.P.
J15FKEUA 1997	CARBURETOR - 15 H.P.
J15FKEUA 1997	CARBURETOR - 9.9 H.P.
J15FRECM 1998	CARBURETOR -- 15 HP
J15FRECM 1998	CARBURETOR -- 9.9 HP
J15FREDR 1996	CARBURETOR - 15 H.P.
J15FREDR 1996	CARBURETOR - 9.9 H.P.
J15FRELECM 1998	CARBURETOR -- 15 HP
J15FRELECM 1998	CARBURETOR -- 9.9 HP
J15FRELEDR 1996	CARBURETOR - 15 H.P.
J15FRELEDR 1996	CARBURETOR - 9.9 H.P.
J15FRELEUA 1997	CARBURETOR - 15 H.P.
J15FRELEUA 1997	CARBURETOR - 9.9 H.P.
J15FREOC 1995	CARBURETOR - 15 H.P.
J15FREOC 1995	CARBURETOR - 9.9 H.P.
J15FREUA 1997	CARBURETOR - 15 H.P.
J15FREUA 1997	CARBURETOR - 9.9 H.P.
J15FRLECM 1998	CARBURETOR -- 15 HP
J15FRLECM 1998	CARBURETOR -- 9.9 HP
J15FRLEDR 1996	CARBURETOR - 15 H.P.
J15FRLEDR 1996	CARBURETOR - 9.9 H.P.

J15FRLEOC 1995	CARBURETOR - 15 H.P.
J15FRLEOC 1995	CARBURETOR - 9.9 H.P.
J15FRLEUA 1997	CARBURETOR - 15 H.P.
J15FRLEUA 1997	CARBURETOR - 9.9 H.P.
J15KEOC 1995	CARBURETOR - 15 H.P.
J15KEOC 1995	CARBURETOR - 9.9 H.P.
J25KLECA 1998	CARBURETOR -- 25 HP
J25KLECA 1998	CARBURETOR -- 35 HP
J25KLEDC 1996	CARBURETOR - 25 H.P.
J25KLEDC 1996	CARBURETOR - 35 H.P.
J25KLEUR 1997	CARBURETOR - 25 H.P.
J25KLEUR 1997	CARBURETOR - 35 H.P.
J25PL3EEM 1999	CARBURETOR -- 25 HP
J25PL3EEM 1999	CARBURETOR -- 35 HP
J25PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 25 HP
J25PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 35 HP
J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	CARBURETOR - 25 HP
J25PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	CARBURETOR - 35 HP
J25QLECA 1998	CARBURETOR -- 25 HP
J25QLECA 1998	CARBURETOR -- 35 HP
J25QLEDC 1996	CARBURETOR - 25 H.P.
J25QLEDC 1996	CARBURETOR - 35 H.P.
J25QLEUR 1997	CARBURETOR - 25 H.P.
J25QLEUR 1997	CARBURETOR - 35 H.P.
J25R3EEM 1999	CARBURETOR -- 25 HP
J25R3EEM 1999	CARBURETOR -- 35 HP
J25R3SIE rope start, tiller, 15 in shaft 2001	CARBURETOR - 25 HP
J25R3SIE rope start, tiller, 15 in shaft 2001	CARBURETOR - 35 HP
J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	CARBURETOR - 25 HP
J25R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	CARBURETOR - 35 HP
J25RL3EEM 1999	CARBURETOR -- 25 HP
J25RL3EEM 1999	CARBURETOR -- 35 HP
J25RL3SIE rope start, tiller, 20 in shaft 2001	CARBURETOR - 25 HP
J25RL3SIE rope start, tiller, 20 in shaft 2001	CARBURETOR - 35 HP
J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	CARBURETOR - 25 HP

J25RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	CARBURETOR - 35 HP
J25RMECA 1998	CARBURETOR -- 25 HP
J25RMECA 1998	CARBURETOR -- 35 HP
J25RMEDC 1996	CARBURETOR - 25 H.P.
J25RMEDC 1996	CARBURETOR - 35 H.P.
J25RMEUR 1997	CARBURETOR - 25 H.P.
J25RMEUR 1997	CARBURETOR - 35 H.P.
J25RMLECA 1998	CARBURETOR -- 25 HP
J25RMLECA 1998	CARBURETOR -- 35 HP
J25RMLEDC 1996	CARBURETOR - 25 H.P.
J25RMLEDC 1996	CARBURETOR - 35 H.P.
J25RMLEUR 1997	CARBURETOR - 25 H.P.
J25RMLEUR 1997	CARBURETOR - 35 H.P.
J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
J25RV3SIE rope start, tiller, 15 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001	CARBURETOR - 25 HP
J25RVL3SIE rope start, tiller, 20 in shaft, wht 2001	CARBURETOR - 35 HP
J25TEL3EEM 1999	CARBURETOR -- 25 HP
J25TEL3EEM 1999	CARBURETOR -- 35 HP
J25TEL3SIE elec start, tiller, 20 in shaft 2001	CARBURETOR - 25 HP
J25TEL3SIE elec start, tiller, 20 in shaft 2001	CARBURETOR - 35 HP
J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000	CARBURETOR - 25 HP
J25TEL3SSB 3 Cyl, Elec. Start, Tiller, 20 IN. shaft 2000	CARBURETOR - 35 HP
J25TKECA 1998	CARBURETOR -- 25 HP
J25TKECA 1998	CARBURETOR -- 35 HP
J25TKEDC 1996	CARBURETOR - 25 H.P.
J25TKEDC 1996	CARBURETOR - 35 H.P.
J25TKEUR 1997	CARBURETOR - 25 H.P.
J25TKEUR 1997	CARBURETOR - 35 H.P.
J25TKLECA 1998	CARBURETOR -- 25 HP
J25TKLECA 1998	CARBURETOR -- 35 HP
J25TKLEDC 1996	CARBURETOR - 25 H.P.
J25TKLEDC 1996	CARBURETOR - 35 H.P.
J25TKLEUR 1997	CARBURETOR - 25 H.P.
J25TKLEUR 1997	CARBURETOR - 35 H.P.

J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001	CARBURETOR - 25 HP
J25TVL3SIE elec start, tiller, 20 in shaft, wht 2001	CARBURETOR - 35 HP
J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 25 HP
J25VL3SIE elec start, TNT, 20 in shaft, wht, n/a usa 2001	CARBURETOR - 35 HP
J35E3EEM 1999	CARBURETOR -- 25 HP
J35E3EEM 1999	CARBURETOR -- 35 HP
J35EL3EEM 1999	CARBURETOR -- 25 HP
J35EL3EEM 1999	CARBURETOR -- 35 HP
J35KLECA 1998	CARBURETOR -- 25 HP
J35KLECA 1998	CARBURETOR -- 35 HP
J35KLEDC 1996	CARBURETOR - 25 H.P.
J35KLEDC 1996	CARBURETOR - 35 H.P.
J35KLEUR 1997	CARBURETOR - 25 H.P.
J35KLEUR 1997	CARBURETOR - 35 H.P.
J35PL3EEM 1999	CARBURETOR -- 25 HP
J35PL3EEM 1999	CARBURETOR -- 35 HP
J35PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 25 HP
J35PL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 35 HP
J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	CARBURETOR - 25 HP
J35PL3SSB 3 Cyl, Elec. Start, TNT, 20 IN. shaft 2000	CARBURETOR - 35 HP
J35QLECA 1998	CARBURETOR -- 25 HP
J35QLECA 1998	CARBURETOR -- 35 HP
J35QLEDC 1996	CARBURETOR - 25 H.P.
J35QLEDC 1996	CARBURETOR - 35 H.P.
J35QLEUR 1997	CARBURETOR - 25 H.P.
J35QLEUR 1997	CARBURETOR - 35 H.P.
J35R3EEM 1999	CARBURETOR -- 25 HP
J35R3EEM 1999	CARBURETOR -- 35 HP
J35R3SIE rope start, tiller, 15 in shaft 2001	CARBURETOR - 25 HP
J35R3SIE rope start, tiller, 15 in shaft 2001	CARBURETOR - 35 HP
J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	CARBURETOR - 25 HP
J35R3SSB 3 Cyl, Rope Start, Tiller, 15 IN. shaft 2000	CARBURETOR - 35 HP
J35RL3EEM 1999	CARBURETOR -- 25 HP
J35RL3EEM 1999	CARBURETOR -- 35 HP
J35RL3SIE rope start, tiller, 20 in shaft 2001	CARBURETOR - 25 HP

J35RL3SIE rope start, tiller, 20 in shaft 2001	CARBURETOR - 35 HP
J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	CARBURETOR - 25 HP
J35RL3SSB 3 Cyl, Rope Start, Tiller, 20 IN. shaft 2000	CARBURETOR - 35 HP
J35RMLEDC 1996	CARBURETOR - 25 H.P.
J35RMLEDC 1996	CARBURETOR - 35 H.P.
J35RMLEUR 1997	CARBURETOR - 25 H.P.
J35RMLEUR 1997	CARBURETOR - 35 H.P.
J35RV3SIE rope start, 15 in shaft, wht 2001	CARBURETOR - 25 HP
J35RV3SIE rope start, 15 in shaft, wht 2001	CARBURETOR - 35 HP
J35RVL3SIE rope start, 20 in shaft, wht 2001	CARBURETOR - 25 HP
J35RVL3SIE rope start, 20 in shaft, wht 2001	CARBURETOR - 35 HP
J35TEL3EEM 1999	CARBURETOR -- 25 HP
J35TEL3EEM 1999	CARBURETOR -- 35 HP
J35TEL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 25 HP
J35TEL3SIE elec start, TNT, 20 in shaft 2001	CARBURETOR - 35 HP
J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000	CARBURETOR - 25 HP
J35TEL3SSB 3 Cyl, Elec. Start, TNT, Tiller, 20 IN. shaft 2000	CARBURETOR - 35 HP
J35TKLECA 1998	CARBURETOR -- 25 HP
J35TKLECA 1998	CARBURETOR -- 35 HP
J35TKLEDC 1996	CARBURETOR - 25 H.P.
J35TKLEDC 1996	CARBURETOR - 35 H.P.
J35TKLEUR 1997	CARBURETOR - 25 H.P.
J35TKLEUR 1997	CARBURETOR - 35 H.P.
J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001	CARBURETOR - 25 HP
J35TVL3SIE elec start, tiller, 20 in shaft, wht 2001	CARBURETOR - 35 HP
J35VL3SIE elec start, TNT, 20 in shaft, wht 2001	CARBURETOR - 25 HP
J35VL3SIE elec start, TNT, 20 in shaft, wht 2001	CARBURETOR - 35 HP
J6R4SRC	CARBURETOR
J6R4SRC - FR	13-3_CARBURATEUR
J6R4STS	CARBURETOR
J6R4STS - FR	13-3_CARBURATEUR
J6RL4SRC	CARBURETOR
J6RL4SRC - FR	13-3_CARBURATEUR
J6RL4STS	CARBURETOR
J6RL4STS - FR	13-3_CARBURATEUR

J8FRECA 1998	CARBURETOR
J8FREDC 1996	CARBURETOR
J8FREUR 1997	CARBURETOR
J8FRLECA 1998	CARBURETOR
J8FRXECA 1998	CARBURETOR
J8FRXEDC 1996	CARBURETOR
J8FRXEUR 1997	CARBURETOR
J8R4SRC	CARBURETOR
J8R4SRC - FR	13-3_CARBURATEUR
J8R4STS	CARBURETOR
J8R4STS - FR	13-3_CARBURATEUR
J8RL4SRC	CARBURETOR
J8RL4SRC - FR	13-3_CARBURATEUR
J8RL4STS	CARBURETOR
J8RL4STS - FR	13-3_CARBURATEUR
L10FRELECM 1998	CARBURETOR -- 15 HP
L10FRELECM 1998	CARBURETOR -- 9.9 HP
L10FRELEDR 1996	CARBURETOR - 15 H.P.
L10FRELEDR 1996	CARBURETOR - 9.9 H.P.
L10FRELEUA 1997	CARBURETOR - 15 H.P.
L10FRELEUA 1997	CARBURETOR - 9.9 H.P.
SE10RPB 1996	CARBURETOR
SE10RPLB 1996	CARBURETOR
SE10RPLT 1997	CARBURETOR
SE10RPLY 1998	CARBURETOR
SE10RPT 1997	CARBURETOR
SE10RPY 1998	CARBURETOR
SE15RPC 1998	CARBURETOR
SE15RPG 1996	CARBURETOR
SE15RPLC 1998	CARBURETOR
SE15RPLG 1996	CARBURETOR
SE15RPLW 1997	CARBURETOR
SE15RPW 1997	CARBURETOR
SE35RWECS 1998	CARBURETOR
SE35RWLECS 1998	CARBURETOR

SJ10RPB 1996	CARBURETOR
SJ10RPLB 1996	CARBURETOR
SJ10RPLT 1997	CARBURETOR
SJ10RPLY 1998	CARBURETOR
SJ10RPT 1997	CARBURETOR
SJ10RPY 1998	CARBURETOR
SJ15RPC 1998	CARBURETOR
SJ15RPG 1996	CARBURETOR
SJ15RPLC 1998	CARBURETOR
SJ15RPLG 1996	CARBURETOR
SJ15RPLW 1997	CARBURETOR
SJ15RPW 1997	CARBURETOR
SJ35RWECS 1998	CARBURETOR
SJ35RWLECS 1998	CARBURETOR