

Where Used: Part Number 0382221

Model Name	Diagram
1002R 1970	GEARCASE GROUP
1802S 1968	GEARCASE GROUP
1902C 1969	GEARCASE GROUP
1R69C 1969	GEARCASE GROUP
1R70R 1970	GEARCASE GROUP
2102A 1971	GEARCASE
2202M 1972	GEARCASE
2302B 1973	GEARCASE
2402E 1974	GEARCASE
2502D 1975	GEARCASE
2602S 1976	GEARCASE
2702C 1977	GEARCASE
2802R 1978	GEARCASE
2902A 1979	GEARCASE
2R71A 1971	GEARCASE
2R72M 1972	GEARCASE
2R73B 1973	GEARCASE
2R74E 1974	GEARCASE
2R75D 1975	GEARCASE
2R76S 1976	GEARCASE
2R77C 1977	GEARCASE
2R78R 1978	GEARCASE
2R79A 1979	GEARCASE
4306C 1973	GEARCASE - STANDARD DRIVE
4336C 1973	GEARCASE - STANDARD DRIVE
4406R 1974	GEARCASE - STANDARD DRIVE
4436R 1974	GEARCASE - STANDARD DRIVE
4506A 1975	GEARCASE-STANDARD DRIVE
4536A 1975	GEARCASE-STANDARD DRIVE
4R73C 1973	GEARCASE-STANDARD DRIVE
4R74R 1974	GEARCASE - STANDARD DRIVE
4R75A 1975	GEARCASE-STANDARD DRIVE
4W73C 1973	GEARCASE-STANDARD DRIVE

4W74R 1974	GEARCASE - STANDARD DRIVE
4W75A 1975	GEARCASE-STANDARD DRIVE
E2RCIB 1981	GEARCASE
E2RCNE 1982	GEARCASE
E2RCRS 1984	GEARCASE
E2RCSM 1980	GEARCASE
E2RCTD 1983	GEARCASE
J2RCIB 1981	GEARCASE
J2RCNE 1982	GEARCASE
J2RCRS 1984	GEARCASE
J2RCSM 1980	GEARCASE
J2RCTD 1983	GEARCASE
SC-10S 1968	GEARCASE GROUP