

Where Used: Part Number 0385043

Model Name	Diagram
100193A 1971	GEARCASE
100193C 1971	GEARCASE
100293R 1972	GEARCASE
100990S 1979	GEARCASE
100993S 1979	GEARCASE
100999S 1979	GEARCASE
100ESL71A 1971	GEARCASE
100ESL71C 1971	GEARCASE
100ESL72R 1972	GEARCASE
100ML79S 1979	GEARCASE
100TLR79S 1979	GEARCASE
100TXLR79S 1979	GEARCASE
115393M 1973	GEARCASE
115493B 1974	GEARCASE GROUP
115593 1975	GEARCASE
115693D 1976	GEARCASE
115693G 1976	GEARCASE
115699D 1976	GEARCASE
115699G 1976	GEARCASE
115790S 1977	GEARCASE
115793S 1977	GEARCASE
115799S 1977	GEARCASE
115890C 1978	GEARCASE
115893C 1978	GEARCASE
115899C 1978	GEARCASE
115990R 1979	GEARCASE
115993R 1979	GEARCASE
115999R 1979	GEARCASE
115EL77S 1977	GEARCASE
115ESL73M 1973	GEARCASE
115ESL74B 1974	GEARCASE
115ESL75E 1975	GEARCASE
115ETL74B 1974	GEARCASE

115ETL75E 1975	GEARCASE
115ETL77 1977	GEARCASE
115ETZ78C 1978	GEARCASE
115ML78C 1978	GEARCASE
115ML79R 1979	GEARCASE
115TL79R 1979	GEARCASE
115TXL77S 1977	GEARCASE
115TXL78C 1978	GEARCASE
115TXL79R 1979	GEARCASE
120FTHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
120FTHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
125183C 1971	GEARCASE
125283R 1972	GEARCASE
125ESL71C 1971	GEARCASE
125ESL72R 1972	GEARCASE
135383M 1973	GEARCASE
135443B 1974	GEARCASE
135483B 1974	GEARCASE
135489B 1974	GEARCASE
135543E 1975	GEARCASE
135583E 1975	GEARCASE
135589E 1975	GEARCASE
135643D 1976	GEARCASE
135643G 1976	GEARCASE
135683D 1976	GEARCASE
135683G 1976	GEARCASE
135ESL73M 1973	GEARCASE
135ESL74B 1974	GEARCASE
135ESL75E 1975	GEARCASE
135ETL74B 1974	GEARCASE
135ETL75E 1975	GEARCASE
140740S 1977	GEARCASE
140743S 1977	GEARCASE
140783S 1977	GEARCASE
140840C 1978	GEARCASE

140843C 1978	GEARCASE
140883C 1978	GEARCASE
140940R 1979	GEARCASE
140943R 1979	GEARCASE
140983R 1979	GEARCASE
140FTHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140FTHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140ML77S 1977	GEARCASE
140ML78C 1978	GEARCASE
140ML79R 1979	GEARCASE
140SPHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140SPHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140STHRCIF 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140STHRCIS 1981	LOWER GEARCASE 120,140 MODELS STERN DRIVE
140TL77S 1977	GEARCASE
140TL78C 1978	GEARCASE
140TL79R 1979	GEARCASE
140TX78C 1978	GEARCASE
140TXL77S 1977	GEARCASE
140TXL79R 1979	GEARCASE
150SHLERC 1994	GEARCASE - COUNTER ROTATION
150SLERC 1994	GEARCASE - COUNTER ROTATION
232AMFTC 1987	LOWER GEARCASE
232AMRGDE 1988	LOWER GEARCASE
232AMRGDP 1988	LOWER GEARCASE
232APFTC 1987	LOWER GEARCASE
232APRGDE 1988	LOWER GEARCASE
232APRGDP 1988	LOWER GEARCASE
232APSRC 1987	LOWER GEARCASE
232BMRMED 1989	LOWER GEARCASE
232BMRMEF 1989	LOWER GEARCASE
232BMRPWS 1990	LOWER GEARCASE
232BPRMED 1989	LOWER GEARCASE
232BPRMEF 1989	LOWER GEARCASE
232BPRPWS 1990	LOWER GEARCASE

252AMKWB 1986	LOWER GEARCASE
252APKWB 1986	LOWER GEARCASE
252FTHRCNC 1982	LOWER GEARCASE GROUP
252FTHRCNG 1982	LOWER GEARCASE GROUP
252FTHRCOM 1985	LOWER GEARCASE GROUP
252FTHRCRA 1984	LOWER GEARCASE GROUP
252FTHRCTR 1983	LOWER GEARCASE GROUP
252STHCNC 1982	LOWER GEARCASE GROUP
252STHRCOM 1985	LOWER GEARCASE GROUP
252STHCRA 1984	LOWER GEARCASE GROUP
252STHRCTR 1983	LOWER GEARCASE GROUP
302AMARJ 1987	LOWER GEARCASE
302AMARY 1987	LOWER GEARCASE
302AMFTC 1987	LOWER GEARCASE
302AMKWB 1986	LOWER GEARCASE
302AMRGDP 1988	LOWER GEARCASE
302AMRMED 1989	LOWER GEARCASE
302APARY 1987	LOWER GEARCASE
302APFTC 1987	LOWER GEARCASE
302APKWB 1986	LOWER GEARCASE
302APRGDP 1988	LOWER GEARCASE
302APRMED 1989	LOWER GEARCASE
302APSRC 1987	LOWER GEARCASE
302ARSRY 1987	LOWER GEARCASE
302FPHRCNC 1982	LOWER GEARCASE GROUP
302FPHRCNG 1982	LOWER GEARCASE GROUP
302FPHRCTR 1983	LOWER GEARCASE GROUP
302FTHRCNC 1982	LOWER GEARCASE GROUP
302FTHRCNG 1982	LOWER GEARCASE GROUP
302FTHRCOM 1985	LOWER GEARCASE GROUP
302FTHRCRA 1984	LOWER GEARCASE GROUP
302FTHRCTR 1983	LOWER GEARCASE GROUP
302SPHCNC 1982	LOWER GEARCASE GROUP
302SPHCNG 1982	LOWER GEARCASE GROUP
302SPHRCOM 1985	LOWER GEARCASE GROUP

302SPHCRA 1984	LOWER GEARCASE GROUP
302SPHRCTR 1983	LOWER GEARCASE GROUP
302STHRCNC 1982	LOWER GEARCASE GROUP
302STHRCNG 1982	LOWER GEARCASE GROUP
302STHRCOM 1985	LOWER GEARCASE GROUP
302STHCRA 1984	LOWER GEARCASE GROUP
302STHRCTR 1983	LOWER GEARCASE GROUP
32DAPEAMH 1992	WATER PUMP AND ADAPTOR
32DAPEJVB 1993	WATER PUMP & ADAPTOR
432APLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APLJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APLJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APRJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502BPRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
50FAPLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
50FAPLJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
50FAPRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
50FAPRJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574APEAMH 1992	WATER PUMP ADAPTER
574APEPWS 1990	WATER PUMP AND ADAPTOR
574APERGD 1991	WATER PUMP & ADAPTOR
574BPEPWS 1990	WATER PUMP AND ADAPTOR
574BPERGD 1991	WATER PUMP & ADAPTOR
584APLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584DPEAMH 1992	WATER PUMP & ADAPTOR
584DPEAMK 1992	WATER PUMP & ADAPTOR
584DPEJVB 1993	WATER PUMP & ADAPTOR
584DPPJVB 1993	WATER PUMP & ADAPTOR

58FAPEJVB 1993	WATER PUMP & ADAPTOR
58FAPLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
58FAPLJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
58FAPPJVB 1993	WATER PUMP & ADAPTOR
58FAPRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
58FAPRJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
58FBPEJVB 1993	WATER PUMP & ADAPTOR
65372R 1973	GEARCASE
65373R 1973	GEARCASE
65ES72S 1972	GEARCASE
65ES73R 1973	GEARCASE
65ESL72S 1972	GEARCASE
65ESL73R 1973	GEARCASE
70442M 1974	GEARCASE
70443M 1974	GEARCASE
70472M 1974	GEARCASE
70473M 1974	GEARCASE
70572B 1975	GEARCASE FOR MODELS 70572B,70573B
70572B 1975	GEARCASE FOR MODELS 70572E,70573E
70572E 1975	GEARCASE FOR MODELS 70572B,70573B
70572E 1975	GEARCASE FOR MODELS 70572E,70573E
70573B 1975	GEARCASE FOR MODELS 70572B,70573B
70573B 1975	GEARCASE FOR MODELS 70572E,70573E
70573E 1975	GEARCASE FOR MODELS 70572B,70573B
70573E 1975	GEARCASE FOR MODELS 70572E,70573E
70673D 1976	GEARCASE
70773S 1977	GEARCASE-20"TRANSOM
70873C 1978	GEARCASE - 20" TRANSOM
70973R 1979	GEARCASE-20" TRANSOM
70EL76D 1976	GEARCASE
70EL77S 1977	GEARCASE-20"TRANSOM
70EL78C 1978	GEARCASE-20 INCH TRANSOM
70EL79R 1979	GEARCASE-20" TRANSOM
70ES74M 1974	GEARCASE
70ES75B 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B

70ES75B 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ES75E 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ES75E 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESL74M 1974	GEARCASE
70ESL75B 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ESL75B 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESL75E 1975	GEARCASE FOR MODELS 70ES75B,70ESL75B
70ESL75E 1975	GEARCASE FOR MODELS 70ES75E,70ESL75E
70ESLR74M 1974	GEARCASE
744APEPWS 1990	WATER PUMP AND ADAPTOR
744APERGD 1991	WATER PUMP & ADAPTOR
744APERGF 1991	WATER PUMP & ADAPTOR
744BPERGD 1991	WATER PUMP & ADAPTOR
744CPEAMH 1992	WATER PUMP AND ADAPTOR
744CPEJVB 1993	WATER PUMP & ADAPTOR
744DPEAMH 1992	WATER PUMP AND ADAPTOR
744DPEJVB 1993	WATER PUMP & ADAPTOR
744DPPAMH 1992	WATER PUMP AND ADAPTOR
744DPPJVB 1993	WATER PUMP & ADAPTOR
754APEPWS 1990	WATER PUMP AND ADAPTOR
75542B 1975	GEARCASE - 20" TRANSOM
75543B 1975	GEARCASE - 20" TRANSOM
75642D 1976	GEARCASE-20" TRANSOM
75643D 1976	GEARCASE-20" TRANSOM
75742S 1977	GEARCASE-20"TRANSOM
75743S 1977	GEARCASE-20"TRANSOM
75842C 1978	GEARCASE - 20" TRANSOM
75843C 1978	GEARCASE - 20" TRANSOM
75942R 1979	GEARCASE-20" TRANSOM
75943R 1979	GEARCASE-20" TRANSOM
75ELR76D 1976	GEARCASE-20" TRANSOM
75ELR77S 1977	GEARCASE-20"TRANSOM
75ELR78C 1978	GEARCASE-20 INCH TRANSOM
75ELR79R 1979	GEARCASE-20" TRANSOM
75ER76D 1976	GEARCASE-20" TRANSOM

75ER77S 1977	GEARCASE-20"TRANSOM
75ER78C 1978	GEARCASE-20 INCH TRANSOM
75ER79R 1979	GEARCASE-20" TRANSOM
75ESLR75B 1975	GEARCASE-20" TRANSOM
75ESR75B 1975	GEARCASE-20" TRANSOM
824BPEAMH 1992	WATER PUMP AND ADAPTOR
824BPEJVB 1993	WATER PUMP & ADAPTOR
85193A 1971	GEARCASE
85193H 1971	GEARCASE
85293R 1972	GEARCASE
85393M 1973	GEARCASE
85493B 1974	GEARCASE
85593E 1975	GEARCASE
85693D 1976	GEARCASE
85693G 1976	GEARCASE
85699G 1976	GEARCASE
85790S 1977	GEARCASE
85793S 1977	GEARCASE
85799S 1977	GEARCASE
85890C 1978	GEARCASE
85895C 1978	GEARCASE
85899C 1978	GEARCASE
85990R 1979	GEARCASE
85995R 1979	GEARCASE
85999R 1979	GEARCASE
85EL76D 1976	GEARCASE
85EL76G 1976	GEARCASE
85EL77S 1977	GEARCASE
85ESL71A 1971	GEARCASE
85ESL71H 1971	GEARCASE
85ESL73M 1973	GEARCASE
85ESL74B 1974	GEARCASE
85ESL75E 1975	GEARCASE
85ETLR76D 1976	GEARCASE
85ETLR76G 1976	GEARCASE

85ETLR77S 1977	GEARCASE
85ETLR78C 1978	GEARCASE
85ML78C 1978	GEARCASE
85ML79R 1979	GEARCASE
85TL79R 1979	GEARCASE
85TXL79R 1979	GEARCASE
85TXLR77S 1977	GEARCASE
85TXLR78C 1978	GEARCASE
990242C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990242C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990242D 1978	LOWER GEARCASE
990242H 1978	LOWER GEARCASE
990242H1 1978	LOWER GEARCASE
990242S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990242S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990243C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990243C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990243D 1978	LOWER GEARCASE
990243H 1978	LOWER GEARCASE
990243H1 1978	LOWER GEARCASE
990243S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990243S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990244C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990244C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990244D 1978	LOWER GEARCASE
990244H 1978	LOWER GEARCASE
990244H1 1978	LOWER GEARCASE
990244P 1978	LOWER GEARCASE
990244S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990244S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990245C 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990245C1 1980	LOWER GEARCASE 120,140 MODELS STERN DRIVE
990245D 1978	LOWER GEARCASE
990245H 1978	LOWER GEARCASE
990245H1 1978	LOWER GEARCASE

990245S 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
990245S1 1979	LOWER GEARCASE 120 & 140 MODELS STERN DRIVE
A115DCXAFG	07-1_GEARCASE, O-Type, Counter Rotation
A115DGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115DSLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafh	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafi	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafk	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115GHlafL	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHlafh	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHlafI	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHlafK	07-1_GEARCASE, (0.42 Ratio) S2-Type
A115SHlafL	07-1_GEARCASE, (0.42 Ratio) S2-Type
AM55RSLD 1999	GEARCASE
BE115ELEDR 1996	GEARCASE - 20 IN. MODELS
BE115ELEUA 1997	GEARCASE - 20 IN. MODELS
BE115ELEUC 1997	GEARCASE - 20 IN. MODELS
BE115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE115GLEDR 1996	GEARCASE - 20 IN. MODELS
BE115GLEUA 1997	GEARCASE - 20 IN. MODELS
BE115GLEUC 1997	GEARCASE - 20 IN. MODELS
BE115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE115SXEDR 1996	GEARCASE - 20 IN. MODELS
BE115SXEUA 1997	GEARCASE - 20 IN. MODELS
BE115SXEUC 1997	GEARCASE - 20 IN. MODELS
BE115TLEDA 1996	GEARCASE
BE130TLEDM 1996	GEARCASE - 130CX COUNTER ROTATION
BE130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
BE150ELECD 1998	GEARCASE -- COUNTER-ROTATION
BE150ELEDB 1996	GEARCASE - COUNTER-ROTATION
BE150ELEUC 1997	GEARCASE - COUNTER-ROTATION
BE150ELEUE 1997	GEARCASE - COUNTER-ROTATION
BE150EXECD 1998	GEARCASE -- COUNTER-ROTATION
BE150EXEDB 1996	GEARCASE - COUNTER-ROTATION
BE150EXEUC 1997	GEARCASE - COUNTER-ROTATION

BE150EXEUE 1997	GEARCASE - COUNTER-ROTATION
BE150GLECD 1998	GEARCASE -- COUNTER-ROTATION
BE150GLEDB 1996	GEARCASE - COUNTER-ROTATION
BE150GLEUC 1997	GEARCASE - COUNTER-ROTATION
BE150GLEUE 1997	GEARCASE - COUNTER-ROTATION
BE150NXECD 1998	GEARCASE -- COUNTER-ROTATION
BE150NXEDB 1996	GEARCASE - COUNTER-ROTATION
BE150NXEUC 1997	GEARCASE - COUNTER-ROTATION
BE150NXEUE 1997	GEARCASE - COUNTER-ROTATION
BE175EXECD 1998	GEARCASE -- COUNTER-ROTATION
BE175EXEDB 1996	GEARCASE - COUNTER-ROTATION
BE175EXEUC 1997	GEARCASE - COUNTER-ROTATION
BE175EXEUE 1997	GEARCASE - COUNTER-ROTATION
BE175GLECD 1998	GEARCASE -- COUNTER-ROTATION
BE175GLEDB 1996	GEARCASE - COUNTER-ROTATION
BE175GLEUC 1997	GEARCASE - COUNTER-ROTATION
BE175GLEUE 1997	GEARCASE - COUNTER-ROTATION
BE175NXECD 1998	GEARCASE -- COUNTER-ROTATION
BE175NXEDB 1996	GEARCASE - COUNTER-ROTATION
BE175NXEUC 1997	GEARCASE - COUNTER-ROTATION
BE175NXEUE 1997	GEARCASE - COUNTER-ROTATION
BE200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE200CXEDR 1996	GEARCASE - COUNTER-ROTATION
BE200CXEUA 1997	GEARCASE - COUNTER-ROTATION
BE200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE200TXEDR 1996	GEARCASE - COUNTER-ROTATION
BE200TXEUA 1997	GEARCASE - COUNTER-ROTATION
BE225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE225CXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225CXEUD 1997	GEARCASE - COUNTER-ROTATION
BE225PXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225SLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE225SLEDE 1996	GEARCASE - COUNTER-ROTATION
BE225SLEUD 1997	GEARCASE - COUNTER-ROTATION
BE225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS

BE225TXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225TXEUD 1997	GEARCASE - COUNTER-ROTATION
BE50DTLEDC 1996	GEARCASE
BE50DTLEUR 1997	GEARCASE
BE60ELEDR 1996	GEARCASE
BE60ELEUA 1997	GEARCASE
BE60TLECM 1998	GEARCASE
BE60TLEDR 1996	GEARCASE
BE60TLEUA 1997	GEARCASE
BE70ELECB 1998	GEARCASE
BE70ELEDA 1996	GEARCASE
BE70ELEUM 1997	GEARCASE
BE70TLECB 1998	GEARCASE
BE70TLEDA 1996	GEARCASE
BE70TLEUM 1997	GEARCASE
BE90ELEDR 1996	GEARCASE - 20 IN. MODELS
BE90ELEUA 1997	GEARCASE - 20 IN. MODELS
BE90ELEUC 1997	GEARCASE - 20 IN. MODELS
BE90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE90SLEDR 1996	GEARCASE - 20 IN. MODELS
BE90SLEUA 1997	GEARCASE - 20 IN. MODELS
BE90SLEUC 1997	GEARCASE - 20 IN. MODELS
BE90SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BE90SXEUA 1997	GEARCASE - 20 IN. MODELS
BE90SXEUC 1997	GEARCASE - 20 IN. MODELS
BE90TLEDA 1996	GEARCASE
BJ115ELEDR 1996	GEARCASE - 20 IN. MODELS
BJ115ELEUA 1997	GEARCASE - 20 IN. MODELS
BJ115ELEUC 1997	GEARCASE - 20 IN. MODELS
BJ115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ115GLEDR 1996	GEARCASE - 20 IN. MODELS
BJ115GLEUA 1997	GEARCASE - 20 IN. MODELS
BJ115GLEUC 1997	GEARCASE - 20 IN. MODELS
BJ115PLEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS

BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115PX EEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ115SXEDR 1996	GEARCASE - 20 IN. MODELS
BJ115SX EUA 1997	GEARCASE - 20 IN. MODELS
BJ115SX EUC 1997	GEARCASE - 20 IN. MODELS
BJ115TLEDA 1996	GEARCASE
BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ130TLEDM 1996	GEARCASE - 130CX COUNTER ROTATION
BJ130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
BJ150ELECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150ELEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150ELEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150ELEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150EXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150EXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150EXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150EXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150GLECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150GLEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150GLEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150GLEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150NXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150NXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150NXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150NXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175EXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175EXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175EXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175EXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175GLECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175GLEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175GLEUC 1997	GEARCASE - COUNTER-ROTATION

BJ175GLEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175NXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175NXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175NXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175NXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ175PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ200CXEDR 1996	GEARCASE - COUNTER-ROTATION
BJ200CXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200CXSSC Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200PLEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200TXEDR 1996	GEARCASE - COUNTER-ROTATION
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200VCSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225CXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS

BJ225PLEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225PXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PXEEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ50DTLEDC 1996	GEARCASE
BJ50DTLEUR 1997	GEARCASE
BJ60ELEDR 1996	GEARCASE
BJ60ELEUA 1997	GEARCASE
BJ60TLECM 1998	GEARCASE
BJ60TLEDR 1996	GEARCASE
BJ60TLEUA 1997	GEARCASE
BJ70ELECB 1998	GEARCASE
BJ70ELEDA 1996	GEARCASE
BJ70ELEUM 1997	GEARCASE
BJ70PLEEE 1999	GEARCASE
BJ70PLSIS elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
BJ70TLECB 1998	GEARCASE
BJ70TLEDA 1996	GEARCASE
BJ70TLEUM 1997	GEARCASE
BJ90ELEDR 1996	GEARCASE - 20 IN. MODELS
BJ90ELEUA 1997	GEARCASE - 20 IN. MODELS
BJ90ELEUC 1997	GEARCASE - 20 IN. MODELS
BJ90PLEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS

BJ90PXEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
BJ90PXSE Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
BJ90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ90SLEDR 1996	GEARCASE - 20 IN. MODELS
BJ90SLEUA 1997	GEARCASE - 20 IN. MODELS
BJ90SLEUC 1997	GEARCASE - 20 IN. MODELS
BJ90SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
BJ90SXEUA 1997	GEARCASE - 20 IN. MODELS
BJ90SXEUC 1997	GEARCASE - 20 IN. MODELS
BJ90TLEDA 1996	GEARCASE
BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 PL - VL MODELS
BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
E100FPLSOC	GEARCASE - FPL, FSL MODELS
E100FPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E100FPLSRS	GEARCASE - FPL, FSL MODELS
E100FPLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E100FSLSOC	GEARCASE - FPL, FSL MODELS
E100FSLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E100FSLSRS	GEARCASE - FPL, FSL MODELS
E100FSLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E100MLCSC 1980	GEARCASE
E100STLCCA 1988	GEARCASE
E100STLCEM 1989	GEARCASE
E100STLEIE 1991	GEARCASE
E100STLEND 1992	GEARCASE
E100STLERC 1994	GEARCASE
E100STLESB 1990	GEARCASE
E100STLETS 1993	GEARCASE
E100TLCSC 1980	GEARCASE
E100TXCSC 1980	GEARCASE
E100WQLECS 1998	GEARCASE -- 100WQL MODELS
E100WQXECS 1998	GEARCASE -- 100WQL MODELS
E110MLCCA 1988	GEARCASE
E110MLCDC 1986	GEARCASE

E110MLCEM 1989	GEARCASE
E110MLCUR 1987	GEARCASE
E110TLCCA 1988	GEARCASE
E110TLCDC 1986	GEARCASE
E110TLCDF 1986	GEARCASE
E110TLCEM 1989	GEARCASE
E110TLCUR 1987	GEARCASE
E110TXCCA 1988	GEARCASE
E110TXCEM 1989	GEARCASE
E110TXCUR 1987	GEARCASE
E112TSLEDR 1996	GEARCASE
E112TSLEOC 1995	GEARCASE
E112TSLERS 1994	GEARCASE
E112TSXEDR 1996	GEARCASE
E112TSXEOC 1995	GEARCASE
E112TSXERS 1994	GEARCASE
E115DCXAAA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAAB	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXABA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFB	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFF	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFG	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFH	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFI	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFL	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXIIA	GEARCASE, O-Type, Counter Rotation
E115DCXIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXINM	GEARCASE, O-Type, Counter Rotation
E115DCXINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXISF	GEARCASE
E115DCXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXISR	GEARCASE
E115DCXISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation

E115DCXSCS	GEARCASE
E115DCXSEF	GEARCASE
E115DCXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFH	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFI	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFK	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DGLAFL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DHLAAA	07-1_GEARCASE, S2-Type
E115DHLAAB	07-1_GEARCASE, S2-Type
E115DHLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DHLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DHLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DHLIIR	GEARCASE, S2-Type
E115DHLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLINA	GEARCASE, S2-Type
E115DHLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLISC	GEARCASE
E115DHLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLISF	GEARCASE
E115DHLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DHLSSES	GEARCASE
E115DHLSSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLAAA	07-1_GEARCASE, S2-Type
E115DPLAAB	07-1_GEARCASE, S2-Type
E115DPLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DPLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DPLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DPLIIB	GEARCASE, S2-Type
E115DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLINE	GEARCASE, S2-Type
E115DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLISF	GEARCASE

E115DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLISM	GEARCASE
E115DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSCR	GEARCASE
E115DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSEF	GEARCASE
E115DPLSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DPLSUC	GEARCASE
E115DPLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E115DSLAAA	07-1_GEARCASE, S2-Type
E115DSLAAAB	07-1_GEARCASE, S2-Type
E115DSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DSLafa	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115DSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLaff	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLafg	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLafH	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLafi	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLafK	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLafL	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115DSLIIb	GEARCASE, S2-Type
E115DSLIIb - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSLInE	GEARCASE, S2-Type
E115DSLInE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSLISF	GEARCASE
E115DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSLISM	GEARCASE
E115DSLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSLSCR	GEARCASE
E115DSLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DSLSEF	GEARCASE
E115DSLSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115DLSUC	GEARCASE
E115DLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E115ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS

E115ELED R 1996	GEARCASE - 20 IN. MODELS
E115ELEOC 1995	GEARCASE - 20 IN. MODELS
E115ELEUA 1997	GEARCASE - 20 IN. MODELS
E115ELEUC 1997	GEARCASE - 20 IN. MODELS
E115FPLEEC 1999	GEARCASE -- FPL, FSL MODELS
E115FPLEEN 1999	GEARCASE -- FPL, FSL MODELS
E115FPLSDS	GEARCASE - PL, SL MODELS
E115FPLSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E115FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E115FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL
E115FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E115FPLSOD	GEARCASE - FPL, FSL MODELS
E115FPLSOD - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E115FPLSRE	GEARCASE - FPL, FSL MODELS
E115FPLSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPLSTB	GEARCASE - FPL, FSL MODELS
E115FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E115FPXEEC 1999	GEARCASE -- FPL, FSL MODELS
E115FPXEEN 1999	GEARCASE -- FPL, FSL MODELS
E115FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E115FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL
E115FPXSNF Ficht Fuel Injection, 25 in., White, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E115FPXSSH FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPXSSR FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FPXSTB	GEARCASE - FPL, FSL MODELS
E115FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E115FSLECS 1998	GEARCASE -- FSL, FTL MODELS
E115FSLEEC 1999	GEARCASE -- FPL, FSL MODELS
E115FSLEEN 1999	GEARCASE -- FPL, FSL MODELS
E115FSLSDS	GEARCASE - PL, SL MODELS
E115FSLSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E115FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS

E115FSLSOD	GEARCASE - FPL, FSL MODELS
E115FSLSOD - FR	07-1_BOÎTIER D'ENGRENAGES - FPL, FSL MODELES
E115FSLSRE	GEARCASE - FPL, FSL MODELS
E115FSLSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FSL
E115FSLSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FSLSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E115FSLSTB	GEARCASE - FPL, FSL MODELS
E115FSLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E115FSXECS 1998	GEARCASE -- FSL, FTL MODELS
E115FTLECS 1998	GEARCASE -- FSL, FTL MODELS
E115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115GLEDR 1996	GEARCASE - 20 IN. MODELS
E115GLEOC 1995	GEARCASE - 20 IN. MODELS
E115GLEUA 1997	GEARCASE - 20 IN. MODELS
E115GLEUC 1997	GEARCASE - 20 IN. MODELS
E115GNLAFI	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAAA	07-1_GEARCASE, S2-Type
E115HSLAAB	07-1_GEARCASE, S2-Type
E115HSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115HSLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E115HSLIIR	GEARCASE, S2-Type
E115HSLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLINA	GEARCASE, S2-Type
E115HSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLISC	GEARCASE
E115HSLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLISF	GEARCASE
E115HSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115HSLSES	GEARCASE
E115HSLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E115JKLEOC 1995	GEARCASE

E115JKLERS 1994	GEARCASE
E115JLEDA 1996	GEARCASE
E115JLEIE 1991	GEARCASE
E115JLEND 1992	GEARCASE
E115JLEOR 1995	GEARCASE
E115JLERC 1994	GEARCASE
E115JLETS 1993	GEARCASE
E115JTLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115MLCIH 1981	GEARCASE
E115MLCIM 1981	GEARCASE
E115MLCNB 1982	GEARCASE
E115MLCOS 1985	GEARCASE
E115MLCRD 1984	GEARCASE
E115MLCSA 1980	GEARCASE
E115MLCTE 1983	GEARCASE
E115MLEIE 1991	GEARCASE
E115MLEND 1992	GEARCASE
E115MLEOR 1995	GEARCASE
E115MLERS 1994	GEARCASE
E115MLESB 1990	GEARCASE
E115MLETS 1993	GEARCASE
E115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115SLEDR 1996	GEARCASE - 20 IN. MODELS
E115SLEOC 1995	GEARCASE - 20 IN. MODELS
E115SLEUA 1997	GEARCASE - 20 IN. MODELS
E115SLEUC 1997	GEARCASE - 20 IN. MODELS
E115SNLAF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E115SXEDR 1996	GEARCASE - 20 IN. MODELS
E115SXEOC 1995	GEARCASE - 20 IN. MODELS
E115SXEUA 1997	GEARCASE - 20 IN. MODELS
E115SXEUC 1997	GEARCASE - 20 IN. MODELS
E115TLCIH 1981	GEARCASE
E115TLCIM 1981	GEARCASE
E115TLCNB 1982	GEARCASE

E115TLCOS 1985	GEARCASE
E115TLCRD 1984	GEARCASE
E115TLCSA 1980	GEARCASE
E115TLCTE 1983	GEARCASE
E115TLEDA 1996	GEARCASE
E115TLEIE 1991	GEARCASE
E115TLEND 1992	GEARCASE
E115TLEOR 1995	GEARCASE
E115TLERC 1994	GEARCASE
E115TLESB 1990	GEARCASE
E115TLETS 1993	GEARCASE
E115TSLECM 1998	GEARCASE
E115TSLEUA 1997	GEARCASE
E115TSXECM 1998	GEARCASE
E115TSXEUA 1997	GEARCASE
E115TXADA 1996	GEARCASE
E115TXAOR 1995	GEARCASE
E115TXARS 1994	GEARCASE
E115TXATS 1993	GEARCASE
E115TXCIH 1981	GEARCASE
E115TXCIM 1981	GEARCASE
E115TXCNB 1982	GEARCASE
E115TXCRD 1984	GEARCASE
E115TXCSA 1980	GEARCASE
E115TXCTE 1983	GEARCASE
E115TXEIE 1991	GEARCASE
E115TXEND 1992	GEARCASE
E115TXESB 1990	GEARCASE
E120TLCCA 1988	GEARCASE - 120TL & TX/140 TL
E120TLCDC 1986	GEARCASE
E120TLCEM 1989	GEARCASE - 120TL & TX/140 TL
E120TLCUR 1987	GEARCASE
E120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
E120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E120TLERC 1994	GEARCASE - 120TL, 125ESX, & 140TL

E120TLERC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TLESB 1990	GEARCASE - 120TL & TX/140 TL
E120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXCCA 1988	GEARCASE - 120TL & TX/140 TL
E120TXCDC 1986	GEARCASE
E120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
E120TXCUR 1987	GEARCASE
E120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
E120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E120TXERC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TXERC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E120TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXESB 1990	GEARCASE - 120TL & TX/140 TL
E120XETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120XETF 1993	GEARCASE - 140CX COUNTER ROTATION
E120XETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E120XETS 1993	GEARCASE - 140CX COUNTER ROTATION
E125ESXENR 1992	GEARCASE - 120TL & TX/125ESX/140 TL

E125ESXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E125ESXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E125ESXESS 1990	GEARCASE - ESX MODELS ONLY
E125ESXETA 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E125ESXETA 1993	GEARCASE - 140CX COUNTER ROTATION
E125ESXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E125ESXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E125ESXW 1989	GEARCASE - ESX MODELS ONLY
E130CXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
E130DCXAAA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAAB	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXABA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFB	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFF	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFH	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFI	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFI	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFI	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXIIR	GEARCASE, O-Type, Counter Rotation
E130DCXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXINA	GEARCASE, O-Type, Counter Rotation
E130DCXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXISC	GEARCASE
E130DCXISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXISF	GEARCASE
E130DCXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXSES	GEARCASE
E130DCXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DGLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DGLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type

E130DGLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAAA	07-1_GEARCASE, S2-Type
E130DPLAAB	07-1_GEARCASE, S2-Type
E130DPLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DPLIIR	GEARCASE, S2-Type
E130DPLIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLINA	GEARCASE, S2-Type
E130DPLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLISC	GEARCASE
E130DPLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLISF	GEARCASE
E130DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DPLSES	GEARCASE
E130DPLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLAAA	07-1_GEARCASE, S2-Type
E130DSLAAAB	07-1_GEARCASE, S2-Type
E130DSLABA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLAF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E130DSLIIIR	GEARCASE, S2-Type
E130DSLIIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLINA	GEARCASE, S2-Type
E130DSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLISC	GEARCASE
E130DSLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLISF	GEARCASE
E130DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130DSLSES	GEARCASE

E130DSLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type S2
E130TLEDM 1996	GEARCASE - 130CX COUNTER ROTATION
E130TLEOA 1995	GEARCASE - 130CX COUNTER ROTATION
E130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
E130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
E130TXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
E130TXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
E135FCXSDE	GEARCASE - CX, MODELS
E135FCXSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX, MODELS
E135FCXSDE	GEARCASE - CX MODELS
E135FCXSDE - FR	07-1_BOÎTIER D'ENGRENAGES - CX MODELES
E135FCXSRM	GEARCASE - CX MODELS
E135FCXSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FCXSTA	GEARCASE - FCX, MODELS
E135FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX, MODELS
E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FPLSTA	GEARCASE - FCX, MODELS
E135FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002	GEARCASE - FCX, MODELS
E135FPXSTA	GEARCASE - FCX, MODELS
E135FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSLSTA	GEARCASE - FCX, MODELS
E135FSLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX

E135FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E140CXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXCCS 1988	GEARCASE - 120TL & TX/140 TL
E140CXCEC 1989	GEARCASE - 120TL & TX/140 TL
E140CXEIA 1991	GEARCASE - 120TL & TX/140 TL
E140CXENM 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140CXERE 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXERE 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140CXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXESR 1990	GEARCASE - 120TL & TX/140 TL
E140CXETB 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXETB 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140CXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140MLCIH 1981	GEARCASE
E140MLCIM 1981	GEARCASE
E140MLCNB 1982	GEARCASE
E140MLCSA 1980	GEARCASE
E140MLCTE 1983	GEARCASE
E140TLATC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TLATC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

E140TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLCCM 1988	GEARCASE - 120TL & TX/140 TL
E140TLCDC 1986	GEARCASE
E140TLCEB 1989	GEARCASE - 120TL & TX/140 TL
E140TLCRD 1984	GEARCASE
E140TLCUA 1987	GEARCASE
E140TLEID 1991	GEARCASE - 120TL & TX/140 TL
E140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TLERR 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TLERR 1994	GEARCASE - 140CX COUNTER ROTATION
E140TLESE 1990	GEARCASE - 120TL & TX/140 TL
E140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TRLCIH 1981	GEARCASE
E140TRLCIM 1981	GEARCASE
E140TRLCNB 1982	GEARCASE
E140TRLCSA 1980	GEARCASE
E140TRLCTE 1983	GEARCASE
E140TRXCIH 1981	GEARCASE
E140TRXCIM 1981	GEARCASE
E140TRXCNB 1982	GEARCASE
E140TRXCSA 1980	GEARCASE
E140TRXCTE 1983	GEARCASE
E140TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

E140TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXCCM 1988	GEARCASE - 120TL & TX/140 TL
E140TXCDC 1986	GEARCASE
E140TXCEB 1989	GEARCASE - 120TL & TX/140 TL
E140TXCRD 1984	GEARCASE
E140TXCUA 1987	GEARCASE
E140TXEID 1991	GEARCASE - 120TL & TX/140 TL
E140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
E140TXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXERR 1994	GEARCASE - 120TL, 125ESX, & 140TL
E140TXERR 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXESE 1990	GEARCASE - 120TL & TX/140 TL
E140TXETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
E140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E150DCXSUC	GEARCASE
E150DCXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E150DCXSUF	GEARCASE
E150DCXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E150ELECD 1998	GEARCASE -- COUNTER-ROTATION
E150ELEDB 1996	GEARCASE - COUNTER-ROTATION
E150ELEOM 1995	GEARCASE - COUNTER ROTATION
E150ELERA 1994	GEARCASE - COUNTER ROTATION
E150ELERV 1994	GEARCASE - COUNTER ROTATION
E150ELETG 1993	GEARCASE - COUNTER ROTATION
E150ELETR 1993	GEARCASE - COUNTER ROTATION
E150ELEUC 1997	GEARCASE - COUNTER-ROTATION
E150ELEUE 1997	GEARCASE - COUNTER-ROTATION
E150EXARC 1994	GEARCASE - COUNTER ROTATION
E150EXARV 1994	GEARCASE - COUNTER ROTATION
E150EXATG 1993	GEARCASE - COUNTER ROTATION
E150EXATS 1993	GEARCASE - COUNTER ROTATION

E150EXECD 1998	GEARCASE -- COUNTER-ROTATION
E150EXEDB 1996	GEARCASE - COUNTER-ROTATION
E150EXEOM 1995	GEARCASE - COUNTER ROTATION
E150EXERA 1994	GEARCASE - COUNTER ROTATION
E150EXERV 1994	GEARCASE - COUNTER ROTATION
E150EXETG 1993	GEARCASE - COUNTER ROTATION
E150EXETR 1993	GEARCASE - COUNTER ROTATION
E150EXEUC 1997	GEARCASE - COUNTER-ROTATION
E150EXEUE 1997	GEARCASE - COUNTER-ROTATION
E150FCXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXSDR	GEARCASE - CX, MODELS
E150FCXSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX, MODELS
E150FCXSOC	GEARCASE - CX MODELS
E150FCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES - CX MODELES
E150FCXSRS	GEARCASE - CX MODELS
E150FCXSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E150FCXSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSTD	GEARCASE - FCX, MODELS
E150FCXSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPLEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX, MODELS
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS

E150FPLSTD	GEARCASE - FCX, MODELS
E150FPLSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPXEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002	GEARCASE - FCX, MODELS
E150FPXSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSTD	GEARCASE - FCX, MODELS
E150FPXSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FSLECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSTD	GEARCASE - FCX, MODELS
E150FSLSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FSXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150GLECD 1998	GEARCASE -- COUNTER-ROTATION
E150GLEDB 1996	GEARCASE - COUNTER-ROTATION
E150GLEOM 1995	GEARCASE - COUNTER ROTATION
E150GLERA 1994	GEARCASE - COUNTER ROTATION
E150GLERV 1994	GEARCASE - COUNTER ROTATION
E150GLETG 1993	GEARCASE - COUNTER ROTATION
E150GLETR 1993	GEARCASE - COUNTER ROTATION
E150GLEUC 1997	GEARCASE - COUNTER-ROTATION
E150GLEUE 1997	GEARCASE - COUNTER-ROTATION
E150ICXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150ILECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150ILEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS

E150IXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150JLECD 1998	GEARCASE -- COUNTER-ROTATION
E150JLEDB 1996	GEARCASE - COUNTER-ROTATION
E150JLEOM 1995	GEARCASE - COUNTER ROTATION
E150JLERA 1994	GEARCASE - COUNTER ROTATION
E150JLERV 1994	GEARCASE - COUNTER ROTATION
E150JLETG 1993	GEARCASE - COUNTER ROTATION
E150JLETR 1993	GEARCASE - COUNTER ROTATION
E150JLEUC 1997	GEARCASE - COUNTER-ROTATION
E150JLEUE 1997	GEARCASE - COUNTER-ROTATION
E150NXARC 1994	GEARCASE - COUNTER ROTATION
E150NXARV 1994	GEARCASE - COUNTER ROTATION
E150NXATG 1993	GEARCASE - COUNTER ROTATION
E150NXATS 1993	GEARCASE - COUNTER ROTATION
E150NXECD 1998	GEARCASE -- COUNTER-ROTATION
E150NXEDB 1996	GEARCASE - COUNTER-ROTATION
E150NXEOM 1995	GEARCASE - COUNTER ROTATION
E150NXERA 1994	GEARCASE - COUNTER ROTATION
E150NXERV 1994	GEARCASE - COUNTER ROTATION
E150NXETG 1993	GEARCASE - COUNTER ROTATION
E150NXETR 1993	GEARCASE - COUNTER ROTATION
E150NXEUC 1997	GEARCASE - COUNTER-ROTATION
E150NXEUE 1997	GEARCASE - COUNTER-ROTATION
E150PLEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150SLECD 1998	GEARCASE -- COUNTER-ROTATION
E150SLEDB 1996	GEARCASE - COUNTER-ROTATION
E150SLEOM 1995	GEARCASE - COUNTER ROTATION
E150SLEUC 1997	GEARCASE - COUNTER-ROTATION
E150SLEUE 1997	GEARCASE - COUNTER-ROTATION
E175DCXSUF	GEARCASE
E175DCXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E175EXARC 1994	GEARCASE - COUNTER ROTATION
E175EXARV 1994	GEARCASE - COUNTER ROTATION
E175EXATG 1993	GEARCASE - COUNTER ROTATION
E175EXATS 1993	GEARCASE - COUNTER ROTATION

E175EXECD 1998	GEARCASE -- COUNTER-ROTATION
E175EXEDB 1996	GEARCASE - COUNTER-ROTATION
E175EXEOM 1995	GEARCASE - COUNTER ROTATION
E175EXERA 1994	GEARCASE - COUNTER ROTATION
E175EXERV 1994	GEARCASE - COUNTER ROTATION
E175EXETG 1993	GEARCASE - COUNTER ROTATION
E175EXETR 1993	GEARCASE - COUNTER ROTATION
E175EXEUC 1997	GEARCASE - COUNTER-ROTATION
E175EXEUE 1997	GEARCASE - COUNTER-ROTATION
E175FCX ECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXSDS	GEARCASE - CX, MODELS
E175FCXSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX, MODELS
E175FCXSOD	GEARCASE - CX MODELS
E175FCXSOD - FR	07-1_BOÎTIER D'ENGRENAGES - CX MODELES
E175FCXSRE	GEARCASE - CX MODELS
E175FCXSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FCXSTB	GEARCASE - FCX, MODELS
E175FCXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPLEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue, 2002	GEARCASE - FCX, MODELS
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS

E175FPLSTB	GEARCASE - FCX, MODELS
E175FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPXEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPXSNF Ficht Fuel Injection, 25 in. shaft, White, 2002	GEARCASE - FCX, MODELS
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSTB	GEARCASE - FCX, MODELS
E175FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FSLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FSLSTM	GEARCASE - FCX, MODELS
E175FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FSXECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FTLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175GLECD 1998	GEARCASE -- COUNTER-ROTATION
E175GLEDB 1996	GEARCASE - COUNTER-ROTATION
E175GLEOM 1995	GEARCASE - COUNTER ROTATION
E175GLERA 1994	GEARCASE - COUNTER ROTATION
E175GLETG 1993	GEARCASE - COUNTER ROTATION
E175GLETR 1993	GEARCASE - COUNTER ROTATION
E175GLEUC 1997	GEARCASE - COUNTER-ROTATION
E175GLEUE 1997	GEARCASE - COUNTER-ROTATION
E175NXARC 1994	GEARCASE - COUNTER ROTATION
E175NXARV 1994	GEARCASE - COUNTER ROTATION
E175NXATG 1993	GEARCASE - COUNTER ROTATION

E175NXATS 1993	GEARCASE - COUNTER ROTATION
E175NXECD 1998	GEARCASE -- COUNTER-ROTATION
E175NXEDB 1996	GEARCASE - COUNTER-ROTATION
E175NXEOM 1995	GEARCASE - COUNTER ROTATION
E175NXERA 1994	GEARCASE - COUNTER ROTATION
E175NXERV 1994	GEARCASE - COUNTER ROTATION
E175NXETG 1993	GEARCASE - COUNTER ROTATION
E175NXETR 1993	GEARCASE - COUNTER ROTATION
E175NXEUC 1997	GEARCASE - COUNTER-ROTATION
E175NXEUE 1997	GEARCASE - COUNTER-ROTATION
E175SLECD 1998	GEARCASE -- COUNTER-ROTATION
E175SLEDB 1996	GEARCASE - COUNTER-ROTATION
E175SLEOM 1995	GEARCASE - COUNTER ROTATION
E175SLERA 1994	GEARCASE - COUNTER ROTATION
E175SLEUC 1997	GEARCASE - COUNTER-ROTATION
E175SLEUE 1997	GEARCASE - COUNTER-ROTATION
E185ESERK 1994	GEARCASE - COUNTER ROTATION
E185ESXETA 1993	GEARCASE - COUNTER ROTATION
E185ESXETF 1993	GEARCASE - COUNTER ROTATION
E200CXARC 1994	GEARCASE - COUNTER ROTATION
E200CXARK 1994	GEARCASE - COUNTER ROTATION
E200CXATF 1993	GEARCASE - COUNTER ROTATION
E200CXATS 1993	GEARCASE - COUNTER ROTATION
E200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200CXEDR 1996	GEARCASE - COUNTER-ROTATION
E200CXEOC 1995	GEARCASE - COUNTER ROTATION
E200CXERK 1994	GEARCASE - COUNTER ROTATION
E200CXERS 1994	GEARCASE - COUNTER ROTATION
E200CXETD 1993	GEARCASE - COUNTER ROTATION
E200CXETF 1993	GEARCASE - COUNTER ROTATION
E200CXEUA 1997	GEARCASE - COUNTER-ROTATION
E200CZARK 1994	GEARCASE - COUNTER ROTATION
E200CZATF 1993	GEARCASE - COUNTER ROTATION
E200CZATS 1993	GEARCASE - COUNTER ROTATION
E200CZEOC 1995	GEARCASE - COUNTER ROTATION

E200CZERK 1994	GEARCASE - COUNTER ROTATION
E200CZERS 1994	GEARCASE - COUNTER ROTATION
E200CZETD 1993	GEARCASE - COUNTER ROTATION
E200CZETF 1993	GEARCASE - COUNTER ROTATION
E200DCXSOC	GEARCASE CX, CZ MODELS
E200DCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E200DCXSUF	GEARCASE
E200DCXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200DCXSUR	GEARCASE
E200DCXSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCSSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FCXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E200FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E200FCXSOE	GEARCASE - FCX & FCZ MODELS
E200FCXSOE - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E200FCXSRB	GEARCASE - FCX & FCZ MODELS
E200FCXSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXSTM	GEARCASE - FCX & FCZ MODELS
E200FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FHLSTS	GEARCASE - FCX & FCZ MODELS
E200FHLSTS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
E200FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX & FCZ MODELS

E200FPLSTM	GEARCASE - FCX & FCZ MODELS
E200FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
E200FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E200FPXSTM	GEARCASE - FCX & FCZ MODELS
E200FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FSLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FSLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - Counter Rotation
E200FSLSTM	GEARCASE - FCX & FCZ MODELS
E200FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200HCXSDS - (90 degree V6 3,3 L)	GEARCASE
E200HCXSDS - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200HCXSUC - (90 degree V6 3,3 L)	GEARCASE
E200HCXSUC - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200STLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200STLEDM 1996	GEARCASE - COUNTER-ROTATION
E200STLEOA 1995	GEARCASE - COUNTER ROTATION
E200STLERK 1994	GEARCASE - COUNTER ROTATION
E200STLERR 1994	GEARCASE - COUNTER ROTATION
E200STLETC 1993	GEARCASE - COUNTER ROTATION
E200STLETF 1993	GEARCASE - COUNTER ROTATION
E200STLEUB 1997	GEARCASE - COUNTER-ROTATION
E200TLECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200TXARC 1994	GEARCASE - COUNTER ROTATION
E200TXARK 1994	GEARCASE - COUNTER ROTATION
E200TXATF 1993	GEARCASE - COUNTER ROTATION
E200TXATS 1993	GEARCASE - COUNTER ROTATION
E200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200TXEDR 1996	GEARCASE - COUNTER-ROTATION
E200TXEOC 1995	GEARCASE - COUNTER ROTATION
E200TXERK 1994	GEARCASE - COUNTER ROTATION

E200TXERS 1994	GEARCASE - COUNTER ROTATION
E200TXETD 1993	GEARCASE - COUNTER ROTATION
E200TXETF 1993	GEARCASE - COUNTER ROTATION
E200TXEUA 1997	GEARCASE - COUNTER-ROTATION
E200TZARK 1994	GEARCASE - COUNTER ROTATION
E200TZATF 1993	GEARCASE - COUNTER ROTATION
E200TZATS 1993	GEARCASE - COUNTER ROTATION
E200ZEOC 1995	GEARCASE - COUNTER ROTATION
E200TZERK 1994	GEARCASE - COUNTER ROTATION
E200TZERS 1994	GEARCASE - COUNTER ROTATION
E200TZETD 1993	GEARCASE - COUNTER ROTATION
E200TZETF 1993	GEARCASE - COUNTER ROTATION
E225CXARC 1994	GEARCASE - COUNTER ROTATION
E225CXARK 1994	GEARCASE - COUNTER ROTATION
E225CXATF 1993	GEARCASE - COUNTER ROTATION
E225CXATS 1993	GEARCASE - COUNTER ROTATION
E225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225CXEDE 1996	GEARCASE - COUNTER-ROTATION
E225CXEOB 1995	GEARCASE - COUNTER ROTATION
E225CXERK 1994	GEARCASE - COUNTER ROTATION
E225CXERM 1994	GEARCASE - COUNTER ROTATION
E225CXETA 1993	GEARCASE - COUNTER ROTATION
E225CXETF 1993	GEARCASE - COUNTER ROTATION
E225CXEUD 1997	GEARCASE - COUNTER-ROTATION
E225CZARK 1994	GEARCASE - COUNTER ROTATION
E225CZATF 1993	GEARCASE - COUNTER ROTATION
E225CZATS 1993	GEARCASE - COUNTER ROTATION
E225CZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225CZEDE 1996	GEARCASE - COUNTER-ROTATION
E225CZEOB 1995	GEARCASE - COUNTER ROTATION
E225CZERK 1994	GEARCASE - COUNTER ROTATION
E225CZERM 1994	GEARCASE - COUNTER ROTATION
E225CZETA 1993	GEARCASE - COUNTER ROTATION
E225CZETF 1993	GEARCASE - COUNTER ROTATION
E225CZEUD 1997	GEARCASE - COUNTER-ROTATION

E225DCXSDR	GEARCASE
E225DCXSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCXSOC	GEARCASE CX, CZ MODELS
E225DCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E225DCXSUA	GEARCASE
E225DCXSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSDR	GEARCASE
E225DCZSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSOC	GEARCASE CX, CZ MODELS
E225DCZSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E225DCZSUA	GEARCASE
E225DCZSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSUG	GEARCASE
E225DCZSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E225FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E225FCXSOE	GEARCASE - FCX & FCZ MODELS
E225FCXSOE - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E225FCXSRB	GEARCASE - FCX & FCZ MODELS
E225FCXSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCXSTM	GEARCASE - FCX & FCZ MODELS
E225FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FCZEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation

E225FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E225FCZSOE	GEARCASE - FCX & FCZ MODELS
E225FCZSOE - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E225FCZSRB	GEARCASE - FCX & FCZ MODELS
E225FCZSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCZSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCZSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCZSTM	GEARCASE - FCX & FCZ MODELS
E225FCZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
E225FHLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002	GEARCASE - FCX & FCZ MODELS
E225FHLSTA	GEARCASE - FCX & FCZ MODELS
E225FHLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX & FCZ MODELS
E225FPLSTM	GEARCASE - FCX & FCZ MODELS
E225FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - Counter Rotation
E225FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E225FPXSTM	GEARCASE - FCX & FCZ MODELS
E225FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FPZEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - Counter Rotation

E225FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E225FPZSTM	GEARCASE - FCX & FCZ MODELS
E225FPZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225PLERK 1994	GEARCASE - COUNTER ROTATION
E225PLERM 1994	GEARCASE - COUNTER ROTATION
E225PLETA 1993	GEARCASE - COUNTER ROTATION
E225PLETF 1993	GEARCASE - COUNTER ROTATION
E225PXARC 1994	GEARCASE - COUNTER ROTATION
E225PXARK 1994	GEARCASE - COUNTER ROTATION
E225PXATF 1993	GEARCASE - COUNTER ROTATION
E225PXATS 1993	GEARCASE - COUNTER ROTATION
E225PXEDE 1996	GEARCASE - COUNTER-ROTATION
E225PXEOB 1995	GEARCASE - COUNTER ROTATION
E225PXERK 1994	GEARCASE - COUNTER ROTATION
E225PXERM 1994	GEARCASE - COUNTER ROTATION
E225PXETA 1993	GEARCASE - COUNTER ROTATION
E225PXETF 1993	GEARCASE - COUNTER ROTATION
E225PZARK 1994	GEARCASE - COUNTER ROTATION
E225PZATF 1993	GEARCASE - COUNTER ROTATION
E225PZATS 1993	GEARCASE - COUNTER ROTATION
E225PZEOB 1995	GEARCASE - COUNTER ROTATION
E225PZERK 1994	GEARCASE - COUNTER ROTATION
E225PZERM 1994	GEARCASE - COUNTER ROTATION
E225PZETA 1993	GEARCASE - COUNTER ROTATION
E225PZETF 1993	GEARCASE - COUNTER ROTATION
E225STLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225STLEDE 1996	GEARCASE - COUNTER-ROTATION
E225STLEOB 1995	GEARCASE - COUNTER ROTATION
E225STLERC 1994	GEARCASE - COUNTER ROTATION
E225STLERK 1994	GEARCASE - COUNTER ROTATION
E225STLETF 1993	GEARCASE - COUNTER ROTATION
E225STLEUD 1997	GEARCASE - COUNTER-ROTATION
E225TLERK 1994	GEARCASE - COUNTER ROTATION
E225TLERM 1994	GEARCASE - COUNTER ROTATION

E225TLETA 1993	GEARCASE - COUNTER ROTATION
E225TLETF 1993	GEARCASE - COUNTER ROTATION
E225TXARC 1994	GEARCASE - COUNTER ROTATION
E225TXARK 1994	GEARCASE - COUNTER ROTATION
E225TXATF 1993	GEARCASE - COUNTER ROTATION
E225TXATS 1993	GEARCASE - COUNTER ROTATION
E225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225TXEDE 1996	GEARCASE - COUNTER-ROTATION
E225TXEOB 1995	GEARCASE - COUNTER ROTATION
E225TXERK 1994	GEARCASE - COUNTER ROTATION
E225TXERM 1994	GEARCASE - COUNTER ROTATION
E225TXETA 1993	GEARCASE - COUNTER ROTATION
E225TXETF 1993	GEARCASE - COUNTER ROTATION
E225TXEUD 1997	GEARCASE - COUNTER-ROTATION
E225TZARK 1994	GEARCASE - COUNTER ROTATION
E225TZATF 1993	GEARCASE - COUNTER ROTATION
E225TZATS 1993	GEARCASE - COUNTER ROTATION
E225TZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225TZEDE 1996	GEARCASE - COUNTER-ROTATION
E225TZEOB 1995	GEARCASE - COUNTER ROTATION
E225TZERK 1994	GEARCASE - COUNTER ROTATION
E225TZERM 1994	GEARCASE - COUNTER ROTATION
E225TZETA 1993	GEARCASE - COUNTER ROTATION
E225TZETF 1993	GEARCASE - COUNTER ROTATION
E225TZEUD 1997	GEARCASE - COUNTER-ROTATION
E250CXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250CZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250DCXSDR	GEARCASE
E250DCXSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCXSOC	GEARCASE CX, CZ MODELS
E250DCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E250DCXSUA	GEARCASE
E250DCXSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCXSUG	GEARCASE
E250DCXSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation

E250DCZSDR	GEARCASE
E250DCZSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCZSOC	GEARCASE CX, CZ MODELS
E250DCZSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E250DCZSUA	GEARCASE
E250DCZSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E250FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E250FCXSOB	GEARCASE - FCX & FCZ MODELS
E250FCXSOB - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E250FCXSRM	GEARCASE - FCX & FCZ MODELS
E250FCXSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCXSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E250FCXSTA	GEARCASE - FCX & FCZ MODELS
E250FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E250FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E250FCZSOB	GEARCASE - FCX & FCZ MODELS
E250FCZSOB - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E250FCZSRM	GEARCASE - FCX & FCZ MODELS
E250FCZSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCZSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E250FCZSTA	GEARCASE - FCX & FCZ MODELS
E250FCZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FPLSOM - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E250FPLSTR	GEARCASE - FCX & FCZ MODELS
E250FPLSTR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
E250FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FPXSTA	GEARCASE - FCX & FCZ MODELS

E250FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - Counter Rotation
E250FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E250FPZSTA	GEARCASE - FCX & FCZ MODELS
E250FPZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250PXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250PZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40DELSDA	GEARCASE
E40DELSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DELSOR	GEARCASE
E40DELSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DELSRC	GEARCASE
E40DELSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DGTLAGA	07-1_GEARCASE, F-Type
E40DGTLAGB	07-1_GEARCASE, F-Type
E40DGTLAGC	07-1_GEARCASE, F-Type
E40DGTLAGD	07-1_GEARCASE, F-Type
E40DGTLAGF	07-1_GEARCASE, F-Type
E40DGTLAGG	07-1_GEARCASE, F-Type
E40DHGLAGA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGC - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGD - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGF - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHGLAGG - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAAA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLABA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAFA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAFB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAGA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLAGB - ITALY ONLY	07-1_GEARCASE, F-Type

E40DHLAGC - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DHLINS - ITALY ONLY	GEARCASE, F-Type
E40DHSLAAA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLABA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAFA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAFB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGA - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGB - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGC - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGD - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGF - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHSLAGG - ITALY ONLY	07-1_GEARCASE, F-Type
E40DHLINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DHLINS - ITALY ONLY	GEARCASE, F-Type
E40DPGLAGA	07-1_GEARCASE, F-Type
E40DPGLAGB	07-1_GEARCASE, F-Type
E40DPGLAGC	07-1_GEARCASE, F-Type
E40DPGLAGD	07-1_GEARCASE, F-Type
E40DPGLAGF	07-1_GEARCASE, F-Type
E40DPGLAGG	07-1_GEARCASE, F-Type
E40DPLAAA	07-1_GEARCASE, F-Type
E40DPLABA	07-1_GEARCASE, F-Type
E40DPLAFA	07-1_GEARCASE, F-Type
E40DPLAFB	07-1_GEARCASE, F-Type
E40DPLAGA	07-1_GEARCASE, F-Type
E40DPLIIS	GEARCASE, F-Type
E40DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLINC	GEARCASE, F-Type
E40DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLISD	GEARCASE
E40DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLISF	GEARCASE
E40DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSCB	GEARCASE

E40DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSDA	GEARCASE
E40DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSEE	GEARCASE
E40DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DPLSOR	GEARCASE
E40DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DPLSRC	GEARCASE
E40DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DPLSUM	GEARCASE
E40DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRGLAGA	07-1_GEARCASE, F-Type
E40DRGLAGB	07-1_GEARCASE, F-Type
E40DRGLAGC	07-1_GEARCASE, F-Type
E40DRGLAGD	07-1_GEARCASE, F-Type
E40DRGLAGF	07-1_GEARCASE, F-Type
E40DRGLAGG	07-1_GEARCASE, F-Type
E40DRLAAA	07-1_GEARCASE, F-Type
E40DRLABA	07-1_GEARCASE, F-Type
E40DRLAFA	07-1_GEARCASE, F-Type
E40DRLAFB	07-1_GEARCASE, F-Type
E40DRLAGA	07-1_GEARCASE, F-Type
E40DRLIIS	GEARCASE, F-Type
E40DRLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLINC	GEARCASE, F-Type
E40DRLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLISD	GEARCASE
E40DRLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLISF	GEARCASE
E40DRLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSCB	GEARCASE
E40DRLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSDA	GEARCASE
E40DRLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSEE	GEARCASE

E40DRLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRLSOR	GEARCASE
E40DRLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E40DRLSRC	GEARCASE
E40DRLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E40DRLSUM	GEARCASE
E40DRLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DRMLABA	07-1_GEARCASE, F-Type
E40DRMLAGA	07-1_GEARCASE, F-Type
E40DRMLAGB	07-1_GEARCASE, F-Type
E40DRMLAGC	07-1_GEARCASE, F-Type
E40DRMLAGD	07-1_GEARCASE, F-Type
E40DRMLAGF	07-1_GEARCASE, F-Type
E40DRMLAGG	07-1_GEARCASE, F-Type
E40DSLAAA	07-1_GEARCASE, F-Type
E40DSLABA	07-1_GEARCASE, F-Type
E40DSLafa	07-1_GEARCASE, F-Type
E40DSLafb	07-1_GEARCASE, F-Type
E40DSLAGA	07-1_GEARCASE, F-Type
E40DSLAGB	07-1_GEARCASE, F-Type
E40DSLAGC	07-1_GEARCASE, F-Type
E40DSLAGD	07-1_GEARCASE, F-Type
E40DSLAGF	07-1_GEARCASE, F-Type
E40DSLAGG	07-1_GEARCASE, F-Type
E40DSLIIA	GEARCASE, F-Type
E40DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLINM	GEARCASE, F-Type
E40DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLISF	GEARCASE
E40DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLISR	GEARCASE
E40DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLSCS	GEARCASE
E40DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DSLSEC	GEARCASE

E40DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLAAA	07-1_GEARCASE, F-Type
E40DTLABA	07-1_GEARCASE, F-Type
E40DTLAFA	07-1_GEARCASE, F-Type
E40DTLAFB	07-1_GEARCASE, F-Type
E40DTLAGA	07-1_GEARCASE, F-Type
E40DTLIIA	GEARCASE, F-Type
E40DTLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLINM	GEARCASE, F-Type
E40DTLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLISF	GEARCASE
E40DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLISR	GEARCASE
E40DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLSCS	GEARCASE
E40DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40DTLSEC	GEARCASE
E40DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E40WREES 1999	GEARCASE
E40WRLEES 1999	GEARCASE
E40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E40WRLSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
E40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E40WRYEES 1999	GEARCASE
E40WRY SIR commercial, rope start, 25 in shaft 2001	GEARCASE
E40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE

E45RCCDS 1986	GEARCASE
E45RCCUC 1987	GEARCASE
E45RCE 1989	GEARCASE
E45RCEIA 1991	GEARCASE
E45RCENM 1992	GEARCASE
E45RCEOD 1995	GEARCASE
E45RCERE 1994	GEARCASE
E45RCESR 1990	GEARCASE
E45RCETB 1993	GEARCASE
E45RCLCDS 1986	GEARCASE
E45RCLCUC 1987	GEARCASE
E45RCLE 1989	GEARCASE
E45RCLEDS 1996	GEARCASE
E45RCLEIA 1991	GEARCASE
E45RCLENM 1992	GEARCASE
E45RCLEOD 1995	GEARCASE
E45RCLERE 1994	GEARCASE
E45RCLESR 1990	GEARCASE
E45RCLETB 1993	GEARCASE
E45RCLEUC 1997	GEARCASE
E45WMLE 1989	GEARCASE
E45WMLEIA 1991	GEARCASE
E45WMLNEM 1992	GEARCASE
E45WMLESR 1990	GEARCASE
E50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50DGTLAGA	07-1_GEARCASE, F-Type
E50DGTLAGB	07-1_GEARCASE, F-Type
E50DGTLAGC	07-1_GEARCASE, F-Type
E50DGTLAGD	07-1_GEARCASE, F-Type
E50DGTLAGF	07-1_GEARCASE, F-Type
E50DGTLAGG	07-1_GEARCASE, F-Type
E50DPGLAGA	07-1_GEARCASE, F-Type
E50DPGLAGB	07-1_GEARCASE, F-Type
E50DPGLAGC	07-1_GEARCASE, F-Type

E50DPGLAGD	07-1_GEARCASE, F-Type
E50DPGLAGF	07-1_GEARCASE, F-Type
E50DPGLAGG	07-1_GEARCASE, F-Type
E50DPLAAA	07-1_GEARCASE, F-Type
E50DPLABA	07-1_GEARCASE, F-Type
E50DPLAFA	07-1_GEARCASE, F-Type
E50DPLAFB	07-1_GEARCASE, F-Type
E50DPLAGA	07-1_GEARCASE, F-Type
E50DPLIIS	GEARCASE, F-Type
E50DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLINC	GEARCASE, F-Type
E50DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLISD	GEARCASE
E50DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLISF	GEARCASE
E50DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSCB	GEARCASE
E50DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSDA	GEARCASE
E50DPLSEE	GEARCASE
E50DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DPLSOR	GEARCASE
E50DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES
E50DPLSRC	GEARCASE
E50DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES
E50DPLSUM	GEARCASE
E50DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DRMLAFA	07-1_GEARCASE, F-Type
E50DRMLAFB	07-1_GEARCASE, F-Type
E50DSLAAA	07-1_GEARCASE, F-Type
E50DSLABA	07-1_GEARCASE, F-Type
E50DSLAFB	07-1_GEARCASE, F-Type
E50DSLAFB	07-1_GEARCASE, F-Type
E50DSLAGA	07-1_GEARCASE, F-Type
E50DSLAGB	07-1_GEARCASE, F-Type

E50DSLACG	07-1_GEARCASE, F-Type
E50DSLACD	07-1_GEARCASE, F-Type
E50DSLACF	07-1_GEARCASE, F-Type
E50DSLACG	07-1_GEARCASE, F-Type
E50DSLIIA	GEARCASE, F-Type
E50DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLINM	GEARCASE, F-Type
E50DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLISF	GEARCASE
E50DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLISR	GEARCASE
E50DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLSCS	GEARCASE
E50DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DSLSEC	GEARCASE
E50DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLAAA	07-1_GEARCASE, F-Type
E50DTLABA	07-1_GEARCASE, F-Type
E50DTLAFA	07-1_GEARCASE, F-Type
E50DTLAFB	07-1_GEARCASE, F-Type
E50DTLAGA	07-1_GEARCASE, F-Type
E50DTLECA 1998	GEARCASE
E50DTLEDC 1996	GEARCASE
E50DTLEOS 1995	GEARCASE
E50DTLEUR 1997	GEARCASE
E50DTLIIA	GEARCASE, F-Type
E50DTLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLINM	GEARCASE, F-Type
E50DTLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLISF	GEARCASE
E50DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLISR	GEARCASE
E50DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50DTLSCS	GEARCASE
E50DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F

E50DTLSEC	GEARCASE
E50DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E50ELED 1996	GEARCASE
E50ELEOS 1995	GEARCASE
E50ELEUR 1997	GEARCASE
E50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
E50TTLECA 1998	GEARCASE
E50TTLEDC 1996	GEARCASE
E50TTLEOS 1995	GEARCASE
E50TTLEUR 1997	GEARCASE
E55MJRLAAA	07-1_GEARCASE, F-Type (MJRL)
E55MJRLABA	07-1_GEARCASE, F-Type (MJRL)
E55MJRLABB	07-1_GEARCASE, F-Type (MJRL)
E55MJRLABF	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFA	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFB	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFC	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFD	07-1_GEARCASE, F-Type (MJRL)
E55MJRLAFF	07-1_GEARCASE, F-Type (MJRL)
E55MJRLIIM	GEARCASE, F-Type (MJRL)
E55MJRLIIM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLINB	GEARCASE, F-Type (MJRL)
E55MJRLINB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLISA	GEARCASE
E55MJRLISA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLSCC	GEARCASE
E55MJRLSCC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLSEF	GEARCASE
E55MJRLSEF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MJRLSER	GEARCASE
E55MJRLSER - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MJRL
E55MRLAAA	07-1_GEARCASE, F-Type (MRL)
E55MRLABA	07-1_GEARCASE, F-Type (MRL)
E55MRLABB	07-1_GEARCASE, F-Type (MRL)

E55MRLABF	07-1_GEARCASE, F-Type (MRL)
E55MRLAFA	07-1_GEARCASE, F-Type (MRL)
E55MRLAFB	07-1_GEARCASE, F-Type (MRL)
E55MRLAFC	07-1_GEARCASE, F-Type (MRL)
E55MRLAFD	07-1_GEARCASE, F-Type (MRL)
E55MRLAFF	07-1_GEARCASE, F-Type (MRL)
E55MRLIIM	GEARCASE, F-Type (MRL)
E55MRLINB	GEARCASE, F-Type (MRL)
E55MRLINB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLISA	GEARCASE
E55MRLISA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSCC	GEARCASE
E55MRLSCC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSEF	GEARCASE
E55MRLSEF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55MRLSER	GEARCASE
E55MRLSER - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles MRL
E55RSLC 1997	GEARCASE
E55RSLG 1995	GEARCASE
E55RSLN 1983	GEARCASE
E55RSLN-2 1983	GEARCASE
E55RSLW 1996	GEARCASE
E55RSN 1983	GEARCASE
E55RSN-2 1983	GEARCASE
E55RSYN 1983	GEARCASE
E55RSYN-2 1983	GEARCASE
E55RWLCDC 1986	GEARCASE
E55RWLCOS 1985	GEARCASE
E55RWLCRD 1984	GEARCASE
E55RWLCUC 1987	GEARCASE
E55RWLE 1989	GEARCASE
E55RWLEIA 1991	GEARCASE
E55RWLENM 1992	GEARCASE
E55RWLERE 1994	GEARCASE
E55RWLESR 1990	GEARCASE

E55RWLETB 1993	GEARCASE
E55WREES 1999	GEARCASE
E55WRLEES 1999	GEARCASE
E55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
E55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
E55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
E55WRYEES 1999	GEARCASE
E55WRY SIR commercial, rope start, 25 in shaft 2001	GEARCASE
E55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
E60DGTLAGA	07-1_GEARCASE, F-Type
E60DGTLAGB	07-1_GEARCASE, F-Type
E60DGTLAGC	07-1_GEARCASE, F-Type
E60DGTLAGD	07-1_GEARCASE, F-Type
E60DGTLAGF	07-1_GEARCASE, F-Type
E60DGTLAGG	07-1_GEARCASE, F-Type
E60DPGLAGA	07-1_GEARCASE, F-Type
E60DPGLAGB	07-1_GEARCASE, F-Type
E60DPGLAGC	07-1_GEARCASE, F-Type
E60DPGLAGD	07-1_GEARCASE, F-Type
E60DPGLAGF	07-1_GEARCASE, F-Type
E60DPGLAGG	07-1_GEARCASE, F-Type
E60DPLAAA	07-1_GEARCASE, F-Type
E60DPLABA	07-1_GEARCASE, F-Type
E60DPLAFA	07-1_GEARCASE, F-Type
E60DPLAFB	07-1_GEARCASE, F-Type
E60DPLAGA	07-1_GEARCASE, F-Type
E60DPLIIS	GEARCASE, F-Type
E60DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLINC	GEARCASE, F-Type
E60DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLISD	GEARCASE
E60DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLISF	GEARCASE

E60DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSCB	GEARCASE
E60DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSDA	GEARCASE
E60DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSEE	GEARCASE
E60DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DPLSUM	GEARCASE
E60DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLAAA	07-1_GEARCASE, F-Type
E60DSLABA	07-1_GEARCASE, F-Type
E60DSLafa	07-1_GEARCASE, F-Type
E60DSLafb	07-1_GEARCASE, F-Type
E60DSLAGA	07-1_GEARCASE, F-Type
E60DSLAGB	07-1_GEARCASE, F-Type
E60DSLAGC	07-1_GEARCASE, F-Type
E60DSLAGD	07-1_GEARCASE, F-Type
E60DSLAGF	07-1_GEARCASE, F-Type
E60DSLAGG	07-1_GEARCASE, F-Type
E60DSLIIA	GEARCASE, F-Type
E60DSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLINM	GEARCASE, F-Type
E60DSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLISF	GEARCASE
E60DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLISR	GEARCASE
E60DSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLSCS	GEARCASE
E60DSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DSLSEC	GEARCASE
E60DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLAAA	07-1_GEARCASE, F-Type
E60DTLABA	07-1_GEARCASE, F-Type
E60DTLafa	07-1_GEARCASE, F-Type
E60DTLafb	07-1_GEARCASE, F-Type

E60DTLAGA	07-1_GEARCASE, F-Type
E60DTLIIA	GEARCASE, F-Type
E60DTLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLINM	GEARCASE, F-Type
E60DTLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLISF	GEARCASE
E60DTLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLISR	GEARCASE
E60DTLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLSCS	GEARCASE
E60DTLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60DTLSEC	GEARCASE
E60DTLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E60ELCCR 1988	GEARCASE
E60ELCDS 1986	GEARCASE - 20" MODELS
E60ELCEA 1989	GEARCASE
E60ELCUC 1987	GEARCASE - 20" MODELS
E60ELEDR 1996	GEARCASE
E60ELEIB 1991	GEARCASE
E60ELENE 1992	GEARCASE
E60ELEOC 1995	GEARCASE
E60ELERS 1994	GEARCASE
E60ELERV 1994	GEARCASE
E60ELES 1990	GEARCASE
E60ELET 1993	GEARCASE
E60ELEUA 1997	GEARCASE
E60HGLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HSLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HSLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60HSLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E60TLCCR 1988	GEARCASE
E60TLCDS 1986	GEARCASE - 20" MODELS

E60TLCEA 1989	GEARCASE
E60TLCUC 1987	GEARCASE - 20" MODELS
E60TLECM 1998	GEARCASE
E60TLEDR 1996	GEARCASE
E60TLEIB 1991	GEARCASE
E60TLENE 1992	GEARCASE
E60TLEOC 1995	GEARCASE
E60TLERS 1994	GEARCASE
E60TLERV 1994	GEARCASE
E60TLESM 1990	GEARCASE
E60TLETD 1993	GEARCASE
E60TLEUA 1997	GEARCASE
E60TTLCCR 1988	GEARCASE
E60TTLCEA 1989	GEARCASE
E60TTLECM 1998	GEARCASE
E60TTLEDR 1996	GEARCASE
E60TTLEIB 1991	GEARCASE
E60TTLENE 1992	GEARCASE
E60TTLEOC 1995	GEARCASE
E60TTLERS 1994	GEARCASE
E60TTLERV 1994	GEARCASE
E60TTLESM 1990	GEARCASE
E60TTLETD 1993	GEARCASE
E60TTLEUA 1997	GEARCASE
E60WDRLSOS	GEARCASE
E60WDRLSOS - FR	07-1_BOÎTIER D'ENGRENAGES
E60WDRYOS	GEARCASE
E60WDRYOS - FR	07-1_BOÎTIER D'ENGRENAGES
E65GLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65GNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65RSLC 1995	GEARCASE

E65RSLM 1996	GEARCASE
E65RSLZ2 1997	GEARCASE
E65RWLCDR 1986	GEARCASE
E65RWLCOC 1985	GEARCASE
E65RWLCRS 1984	GEARCASE
E65SLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65SNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E65TELCDR 1986	GEARCASE
E65TELCOC 1985	GEARCASE
E65TELCRS 1984	GEARCASE
E65WDRLIIA	GEARCASE, F-Type
E65WDRLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLINM	GEARCASE, F-Type
E65WDRLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLISF	GEARCASE
E65WDRLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLISR	GEARCASE
E65WDRLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLSCS	GEARCASE
E65WDRLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRLSEC	GEARCASE
E65WDRLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYIIA	GEARCASE, F-Type
E65WDRYIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYINM	GEARCASE, F-Type
E65WDRYINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYISF	GEARCASE
E65WDRYISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYISR	GEARCASE

E65WDRYISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYSCS	GEARCASE
E65WDRYSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WDRYSEC	GEARCASE
E65WDRYSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type F
E65WELEES 1999	GEARCASE
E65WELSIR Commercial, elec start, 20 in shaft 2001	GEARCASE
E65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
E65WMLCDR 1986	GEARCASE
E65WMLCOC 1985	GEARCASE
E65WMLCUA 1987	GEARCASE
E65WMLEIB 1991	GEARCASE
E65WMLENE 1992	GEARCASE
E65WMLEOC 1995	GEARCASE
E65WMLERS 1994	GEARCASE
E65WMLESM 1990	GEARCASE
E65WMLETD 1993	GEARCASE
E65WMLZ 1989	GEARCASE
E65WRLEEO 1999	GEARCASE
E65WRLEES 1999	GEARCASE
E65WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
E65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
E65WRYEEO 1999	GEARCASE
E65WRYEES 1999	GEARCASE
E65WRYSIR commercial, rope start, 22.5 in shaft 2001	GEARCASE
E65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
E65WTLCOC 1985	GEARCASE
E65WTLCRS 1984	GEARCASE
E70ELCCA 1988	GEARCASE
E70ELCDC 1986	GEARCASE
E70ELCEM 1989	GEARCASE
E70ELCIH 1981	GEARCASE - 20" TRANSOM
E70ELCIM 1981	GEARCASE - 20" TRANSOM
E70ELCNB 1982	GEARCASE - 20" TRANSOM
E70ELCOS 1985	GEARCASE - 20" MODELS

E70ELCRD 1984	GEARCASE - 20" MODELS
E70ELCSA 1980	GEARCASE-20" TRANSOM
E70ELCTE 1983	GEARCASE - 20" TRANSOM
E70ELCUR 1987	GEARCASE
E70ELEIE 1991	GEARCASE
E70ELEND 1992	GEARCASE
E70ELEOR 1995	GEARCASE
E70ELERC 1994	GEARCASE
E70ELERV 1994	GEARCASE
E70ELESB 1990	GEARCASE
E70ELETs 1993	GEARCASE
E70TLCCA 1988	GEARCASE
E70TLCDC 1986	GEARCASE
E70TLCEM 1989	GEARCASE
E70TLCIM 1981	GEARCASE - 20" TRANSOM
E70TLCNB 1982	GEARCASE - 20" TRANSOM
E70TLCOS 1985	GEARCASE - 20" MODELS
E70TLCRD 1984	GEARCASE - 20" MODELS
E70TLCTE 1983	GEARCASE - 20" TRANSOM
E70TLCUR 1987	GEARCASE
E70TLECB 1998	GEARCASE
E70TLEDA 1996	GEARCASE
E70TLEIE 1991	GEARCASE
E70TLEND 1992	GEARCASE
E70TLEOR 1995	GEARCASE
E70TLERC 1994	GEARCASE
E70TLERV 1994	GEARCASE
E70TLESB 1990	GEARCASE
E70TLETs 1993	GEARCASE
E70TLEUM 1997	GEARCASE
E70TTLEIE 1991	GEARCASE
E70TTLEND 1992	GEARCASE
E70TTLEOR 1995	GEARCASE
E70TTLERC 1994	GEARCASE
E70TTLERV 1994	GEARCASE

E70TTLETS 1993	GEARCASE
E75DPGLAFA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFC	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFD	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFF	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPGLAFG	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DPLIIS	GEARCASE, S-Type
E75DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLINC	GEARCASE, S-Type
E75DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLISD	GEARCASE - PL, SL MODELS
E75DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLISF	GEARCASE - PL, SL MODELS
E75DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSCB	GEARCASE - PL, SL MODELS
E75DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSDA	GEARCASE - PL, SL MODELS
E75DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E75DPLSEE	GEARCASE - PL, SL MODELS
E75DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DPLSOR	GEARCASE PL & SL MODELS
E75DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES
E75DPLSRC	GEARCASE PL & SL MODELS
E75DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E75DPLSUM	GEARCASE - PL, SL MODELS
E75DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLABB	07-1_GEARCASE, (0.50 Ratio) S-Type

E75DSLAF A	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAF B	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAF C	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAF D	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAF F	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLAF G	07-1_GEARCASE, (0.50 Ratio) S-Type
E75DSLII A	GEARCASE, S-Type
E75DSLII A - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLIN M	GEARCASE, S-Type
E75DSLIN M - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLIS F	GEARCASE - PL, SL MODELS
E75DSLIS F - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLIS R	GEARCASE - PL, SL MODELS
E75DSLIS R - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLSC S	GEARCASE - PL, SL MODELS
E75DSLSC S - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75DSLSEC	GEARCASE - PL, SL MODELS
E75DSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E75ECDC 1986	GEARCASE - 20" MODELS
E75ECOS 1985	GEARCASE - 20" MODELS
E75ECDR 1984	GEARCASE - 20" MODELS
E75ECUR 1987	GEARCASE - 20" MODELS
E75ELCRD 1984	GEARCASE - 20" MODELS
E75ERICI H 1981	GEARCASE - 20" TRANSOM
E75ERICI M 1981	GEARCASE - 20" TRANSOM
E75ERCNB 1982	GEARCASE - 20" TRANSOM
E75ERCSA 1980	GEARCASE-20" TRANSOM
E75ERCTE 1983	GEARCASE - 20" TRANSOM
E75ERLCI H 1981	GEARCASE - 20" TRANSOM
E75ERLCI M 1981	GEARCASE - 20" TRANSOM
E75ERLCNB 1982	GEARCASE - 20" TRANSOM
E75ERLCSA 1980	GEARCASE-20" TRANSOM
E75ERLCTE 1983	GEARCASE - 20" TRANSOM
E75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E75FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL

E75FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E75FPLSTA	GEARCASE - FPL, FSL MODELS
E75FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E75FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E75TLCRD 1984	GEARCASE - 20" MODELS
E75TRLCIH 1981	GEARCASE - 20" TRANSOM
E75TRLCIM 1981	GEARCASE - 20" TRANSOM
E75TRLCNB 1982	GEARCASE - 20" TRANSOM
E75TRLCSA 1980	GEARCASE-20" TRANSOM
E75TRLCTE 1983	GEARCASE - 20" TRANSOM
E85MLCSA 1980	GEARCASE
E85STLCSA 1980	GEARCASE
E85STXCSEA 1980	GEARCASE
E85TTLEIE 1991	GEARCASE
E85TTLEND 1992	GEARCASE
E85TTLEOR 1995	GEARCASE
E85TTLERC 1994	GEARCASE
E85TTLETS 1993	GEARCASE
E88MSLCCC 1988	GEARCASE
E88MSLCER 1989	GEARCASE
E88MSLCUS 1987	GEARCASE
E88MSLEDC 1996	GEARCASE
E88MSLEIM 1991	GEARCASE
E88MSLENB 1992	GEARCASE
E88MSLEOS 1995	GEARCASE
E88MSLERD 1994	GEARCASE
E88MSLESA 1990	GEARCASE
E88MSLETE 1993	GEARCASE
E88TSLEDR 1996	GEARCASE
E88TSLEOC 1995	GEARCASE
E88TSLERS 1994	GEARCASE
E90DHLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90DHLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type

E90DPGLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPGLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DPLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DPLIIS	GEARCASE, S-Type
E90DPLIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLINC	GEARCASE, S-Type
E90DPLINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLISD	GEARCASE - PL, SL MODELS
E90DPLISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLISF	GEARCASE - PL, SL MODELS
E90DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSCB	GEARCASE - PL, SL MODELS
E90DPLSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSDA	GEARCASE - PL, SL MODELS
E90DPLSDA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E90DPLSEE	GEARCASE - PL, SL MODELS
E90DPLSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DPLSOR	GEARCASE PL & SL MODELS
E90DPLSOR - FR	07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES
E90DPLSRC	GEARCASE PL & SL MODELS
E90DPLSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E90DPLSUM	GEARCASE - PL, SL MODELS
E90DPLSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLAAA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSLABA	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLABB	07-1_GEARCASE, (0.50 Ratio) S-Type
E90DSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type

E90DSLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL AFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL AFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL AFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90DSL IID	GEARCASE, S-Type
E90DSL IID - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL IINS	GEARCASE, S-Type
E90DSL IINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL ISE	GEARCASE - PL, SL MODELS
E90DSL ISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL ISF	GEARCASE - PL, SL MODELS
E90DSL ISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL S CM	GEARCASE - PL, SL MODELS
E90DSL S CM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL S DR	GEARCASE - PL, SL MODELS
E90DSL S DR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E90DSL SEB	GEARCASE - PL, SL MODELS
E90DSL SEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90DSL SOC	GEARCASE PL & SL MODELS
E90DSL SOR - FR	07-1_BOÎTIER D'ENGRENAGES PL & SL MODELES
E90DSL SRC	GEARCASE PL & SL MODELS
E90DSL SRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E90DSL S UA	GEARCASE - PL, SL MODELS
E90DSL S UM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90ELE CM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E90ELE DR 1996	GEARCASE - 20 IN. MODELS
E90ELE OC 1995	GEARCASE - 20 IN. MODELS
E90ELE UA 1997	GEARCASE - 20 IN. MODELS
E90ELE UC 1997	GEARCASE - 20 IN. MODELS
E90EXE OC 1995	GEARCASE - 20 IN. MODELS
E90FPLE EC 1999	GEARCASE -- FPL, FSL MODELS
E90FPLE EN 1999	GEARCASE -- FPL, FSL MODELS
E90FPLS IF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E90FPLS NF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL

E90FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPL, MODELS
E90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
E90FPLSTB	GEARCASE - FPL, FSL MODELS
E90FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E90FSLECS 1998	GEARCASE -- FSL, FTL MODELS
E90FSLSTB	GEARCASE - FPL, FSL MODELS
E90FSLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FSL
E90FTLECS 1998	GEARCASE -- FSL, FTL MODELS
E90FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
E90GLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90GNLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90HGLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HGLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFA	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFB	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFF	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFH	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFI	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFK	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90HSLAFL	07-1_GEARCASE, (0.50 Ratio) S2-Type
E90JLEIE 1991	GEARCASE
E90JLEND 1992	GEARCASE

E90JLEOR 1995	GEARCASE
E90JLERC 1994	GEARCASE
E90JLETS 1993	GEARCASE
E90MLCDC 1986	GEARCASE
E90MLCIH 1981	GEARCASE
E90MLCIM 1981	GEARCASE
E90MLCNB 1982	GEARCASE
E90MLCOS 1985	GEARCASE
E90MLCRD 1984	GEARCASE
E90MLCTE 1983	GEARCASE
E90MLCUR 1987	GEARCASE
E90MLEOR 1995	GEARCASE
E90MLERC 1994	GEARCASE
E90SLABA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
E90SLEDR 1996	GEARCASE - 20 IN. MODELS
E90SLEOC 1995	GEARCASE - 20 IN. MODELS
E90SLEUA 1997	GEARCASE - 20 IN. MODELS
E90SLEUC 1997	GEARCASE - 20 IN. MODELS
E90SNLABA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLABB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFA	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFB	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFC	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFD	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFF	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90SNLAFG	07-1_GEARCASE, (0.42 Ratio) S2-Type
E90TLCCA 1988	GEARCASE
E90TLCDC 1986	GEARCASE
E90TLCEM 1989	GEARCASE
E90TLCIH 1981	GEARCASE

E90TLCIM 1981	GEARCASE
E90TLCNB 1982	GEARCASE
E90TLCOS 1985	GEARCASE
E90TLCRD 1984	GEARCASE
E90TLCTE 1983	GEARCASE
E90TLCUR 1987	GEARCASE
E90TLEDA 1996	GEARCASE
E90TLEIE 1991	GEARCASE
E90TLEND 1992	GEARCASE
E90TLEOR 1995	GEARCASE
E90TLERC 1994	GEARCASE
E90TLESB 1990	GEARCASE
E90TLETS 1993	GEARCASE
E90TSLECM 1998	GEARCASE
E90TSLEUA 1997	GEARCASE
E90TXARC 1994	GEARCASE
E90TXATS 1993	GEARCASE
E90TXCDC 1986	GEARCASE
E90TXCIH 1981	GEARCASE
E90TXCIM 1981	GEARCASE
E90TXCNB 1982	GEARCASE
E90TXCOS 1985	GEARCASE
E90TXCRD 1984	GEARCASE
E90TXCTE 1983	GEARCASE
E90WDELIIA	GEARCASE, S-Type
E90WDELIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELINM	GEARCASE, S-Type
E90WDELINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELISF	GEARCASE - PL, SL MODELS
E90WDELISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELISR	GEARCASE - PL, SL MODELS
E90WDELISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELSCS	GEARCASE - PL, SL MODELS
E90WDELSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
E90WDELSEC	GEARCASE - PL, SL MODELS

E90WDELSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type S
HE115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
HE115SLEDR 1996	GEARCASE - 20 IN. MODELS
HE115SLEUA 1997	GEARCASE - 20 IN. MODELS
HE115SLEUC 1997	GEARCASE - 20 IN. MODELS
HE115TXADA 1996	GEARCASE
HE130CXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HE130CXAUUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HE130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HE130TXAUUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HE45RCLEDS 1996	GEARCASE
HE45RCLEUC 1997	GEARCASE
HE55RSLC 1997	GEARCASE
HE55RSLW 1996	GEARCASE
HE55WMLM 1996	GEARCASE
HE55WMLZ 1997	GEARCASE
HE70TXEDA 1996	GEARCASE
HE70TXEUM 1997	GEARCASE
HE88MSLEDC 1996	GEARCASE
HE90MLEDA 1996	GEARCASE
HE90TXADA 1996	GEARCASE
HJ115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
HJ115SLEDR 1996	GEARCASE - 20 IN. MODELS
HJ115SLEUA 1997	GEARCASE - 20 IN. MODELS
HJ115SLEUC 1997	GEARCASE - 20 IN. MODELS
HJ115TXADA 1996	GEARCASE
HJ130CXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HJ130CXAUUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HJ130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
HJ130TXAUUM 1997	GEARCASE - 130CX COUNTER-ROTATION
HJ45RCLEDS 1996	GEARCASE
HJ45RCLEUC 1997	GEARCASE
HJ55RSLC 1997	GEARCASE
HJ55RSLW 1996	GEARCASE
HJ55WMLM 1996	GEARCASE

HJ55WMLZ 1997	GEARCASE
HJ70TXEDA 1996	GEARCASE
HJ70TXEUM 1997	GEARCASE
HJ88MSLEDC 1996	GEARCASE
HJ90MLEDA 1996	GEARCASE
HJ90TXADA 1996	GEARCASE
J100MLCSC 1980	GEARCASE
J100STLCCA 1988	GEARCASE
J100STLCEM 1989	GEARCASE
J100STLEIE 1991	GEARCASE
J100STLEND 1992	GEARCASE
J100STLERC 1994	GEARCASE
J100STLESB 1990	GEARCASE
J100STLETS 1993	GEARCASE
J100TRLCSC 1980	GEARCASE
J100TRXCSC 1980	GEARCASE
J100WQLECS 1998	GEARCASE -- 100WQL MODELS
J100WQXECS 1998	GEARCASE -- 100WQL MODELS
J110MLCCA 1988	GEARCASE
J110MLCDC 1986	GEARCASE
J110MLCEM 1989	GEARCASE
J110MLCUR 1987	GEARCASE
J110TLAEM 1989	GEARCASE
J110TLCCA 1988	GEARCASE
J110TLCDC 1986	GEARCASE
J110TLCDF 1986	GEARCASE
J110TLCEM 1989	GEARCASE
J110TLCUR 1987	GEARCASE
J110TXCCA 1988	GEARCASE
J110TXCEM 1989	GEARCASE
J110TXCUR 1987	GEARCASE
J112TSLEDR 1996	GEARCASE
J112TSLEOC 1995	GEARCASE
J112TSLERS 1994	GEARCASE
J112TSXEDR 1996	GEARCASE

J112TSXEOC 1995	GEARCASE
J112TSXERS 1994	GEARCASE
J115ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115ELEDR 1996	GEARCASE - 20 IN. MODELS
J115ELEOC 1995	GEARCASE - 20 IN. MODELS
J115ELEUA 1997	GEARCASE - 20 IN. MODELS
J115ELEUC 1997	GEARCASE - 20 IN. MODELS
J115FSLECS 1998	GEARCASE -- FSL, FTL MODELS
J115FSXECS 1998	GEARCASE -- FSL, FTL MODELS
J115FTLECS 1998	GEARCASE -- FSL, FTL MODELS
J115GLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115GLEDR 1996	GEARCASE - 20 IN. MODELS
J115GLEOC 1995	GEARCASE - 20 IN. MODELS
J115GLEUA 1997	GEARCASE - 20 IN. MODELS
J115GLEUC 1997	GEARCASE - 20 IN. MODELS
J115GLSDE	GEARCASE - PL, GL MODELS
J115GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J115GLSOB	GEARCASE - PL, GL MODELS
J115GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115GLSRC	GEARCASE - PL, GL MODELS
J115GLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115GLSTA	GEARCASE - PL, GL MODELS
J115GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J115JKLEOC 1995	GEARCASE
J115JKLERS 1994	GEARCASE
J115JLEDA 1996	GEARCASE
J115JLEIE 1991	GEARCASE
J115JLEND 1992	GEARCASE
J115JLEOR 1995	GEARCASE
J115JLERC 1994	GEARCASE
J115JLETS 1993	GEARCASE
J115JPLEEC 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115JTLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS

J115MLCIH 1981	GEARCASE
J115MLCIM 1981	GEARCASE
J115MLCNB 1982	GEARCASE
J115MLCOS 1985	GEARCASE
J115MLCRD 1984	GEARCASE
J115MLCSA 1980	GEARCASE
J115MLCTE 1983	GEARCASE
J115MLEIE 1991	GEARCASE
J115MLEND 1992	GEARCASE
J115MLEOR 1995	GEARCASE
J115MLERS 1994	GEARCASE
J115MLESB 1990	GEARCASE
J115MLETS 1993	GEARCASE
J115PLEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115PLSDA	GEARCASE - PL, GL MODELS
J115PLSDA - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J115PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J115PLSOR	GEARCASE - PL, GL MODELS
J115PLSOR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115PLSRC	GEARCASE - PL, GL MODELS
J115PLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115PLSTS	GEARCASE - PL, GL MODELS
J115PLSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J115PXEEM 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115PXS NF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J115PXS NF Carbureted, 25 in. shaft, White, Remote, Elec, TNT, 2002	GEARCASE - PLS, VLS MODELS
J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115PXSTS	GEARCASE - PL, GL MODELS
J115PXSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J115SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115SLEDR 1996	GEARCASE - 20 IN. MODELS

J115SLEOC 1995	GEARCASE - 20 IN. MODELS
J115SLEUA 1997	GEARCASE - 20 IN. MODELS
J115SLEUC 1997	GEARCASE - 20 IN. MODELS
J115SPLEES 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115SXECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J115SXEDR 1996	GEARCASE - 20 IN. MODELS
J115SXEOC 1995	GEARCASE - 20 IN. MODELS
J115SXEUA 1997	GEARCASE - 20 IN. MODELS
J115SXEUC 1997	GEARCASE - 20 IN. MODELS
J115TLAIE 1991	GEARCASE
J115TLAND 1992	GEARCASE
J115TLARC 1994	GEARCASE
J115TLASB 1990	GEARCASE
J115TLATS 1993	GEARCASE
J115TLCIH 1981	GEARCASE
J115TLCIM 1981	GEARCASE
J115TLCNB 1982	GEARCASE
J115TLCOS 1985	GEARCASE
J115TLCRD 1984	GEARCASE
J115TLCSA 1980	GEARCASE
J115TLCTE 1983	GEARCASE
J115TLEDA 1996	GEARCASE
J115TLEIE 1991	GEARCASE
J115TLEND 1992	GEARCASE
J115TLEOR 1995	GEARCASE
J115TLERC 1994	GEARCASE
J115TLESB 1990	GEARCASE
J115TLETS 1993	GEARCASE
J115TSLECM 1998	GEARCASE
J115TSLEUA 1997	GEARCASE
J115TSXECM 1998	GEARCASE
J115TSXEUA 1997	GEARCASE
J115TXADA 1996	GEARCASE
J115TXAOR 1995	GEARCASE

J115TXARS 1994	GEARCASE
J115TXATS 1993	GEARCASE
J115TXCIH 1981	GEARCASE
J115TXCIM 1981	GEARCASE
J115TXCNB 1982	GEARCASE
J115TXCRD 1984	GEARCASE
J115TXCSA 1980	GEARCASE
J115TXCTE 1983	GEARCASE
J115TXEIE 1991	GEARCASE
J115TXEND 1992	GEARCASE
J115TXESB 1990	GEARCASE
J115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J115VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J115VLSSS Elec. Start, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J120TLAEM 1989	GEARCASE - 120TL & TX/140 TL
J120TLAIE 1991	GEARCASE - 120TL & TX/140 TL
J120TLAND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TLARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLARC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLARK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLASB 1990	GEARCASE - 120TL & TX/140 TL
J120TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLATS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLCCA 1988	GEARCASE - 120TL & TX/140 TL
J120TLCDC 1986	GEARCASE
J120TLCEM 1989	GEARCASE - 120TL & TX/140 TL
J120TLCUR 1987	GEARCASE
J120TLEIE 1991	GEARCASE - 120TL & TX/140 TL

J120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TLERC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLERC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLESB 1990	GEARCASE - 120TL & TX/140 TL
J120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXCCA 1988	GEARCASE - 120TL & TX/140 TL
J120TXCDC 1986	GEARCASE
J120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
J120TXCUR 1987	GEARCASE
J120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
J120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J120TXERC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXERC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J120TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXESB 1990	GEARCASE - 120TL & TX/140 TL
J120TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

J120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
J125ESXENR 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J125ESXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J125ESXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J125ESXESS 1990	GEARCASE - ESX MODELS ONLY
J125ESXETA 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J125ESXETA 1993	GEARCASE - 140CX COUNTER ROTATION
J125ESXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J125ESXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J125ESXW 1989	GEARCASE - ESX MODELS ONLY
J130CXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
J130TLEDM 1996	GEARCASE - 130CX COUNTER ROTATION
J130TLEOA 1995	GEARCASE - 130CX COUNTER ROTATION
J130TLEUB 1997	GEARCASE - 130CX COUNTER-ROTATION
J130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
J130TXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
J130TXAUM 1997	GEARCASE - 130CX COUNTER-ROTATION
J140CXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140CXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140CXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXCCS 1988	GEARCASE - 120TL & TX/140 TL
J140CXCEC 1989	GEARCASE - 120TL & TX/140 TL
J140CXEIA 1991	GEARCASE - 120TL & TX/140 TL
J140CXENM 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140CXERE 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXERE 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140CXERK 1994	GEARCASE - 140CX COUNTER ROTATION

J140CXESR 1990	GEARCASE - 120TL & TX/140 TL
J140CXETB 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140CXETB 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140CXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140MLCIH 1981	GEARCASE
J140MLCIM 1981	GEARCASE
J140MLCNB 1982	GEARCASE
J140MLCSA 1980	GEARCASE
J140MLCTE 1983	GEARCASE
J140TLAEB 1989	GEARCASE - 120TL & TX/140 TL
J140TLANS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TLARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLARR 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLARR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLASE 1990	GEARCASE - 120TL & TX/140 TL
J140TLATC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLATC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLCCM 1988	GEARCASE - 120TL & TX/140 TL
J140TLCDC 1986	GEARCASE
J140TLCEB 1989	GEARCASE - 120TL & TX/140 TL
J140TLCIH 1981	GEARCASE
J140TLCIM 1981	GEARCASE
J140TLCNB 1982	GEARCASE
J140TLCRD 1984	GEARCASE
J140TLCSA 1980	GEARCASE
J140TLCTE 1983	GEARCASE
J140TLCUA 1987	GEARCASE
J140TLEID 1991	GEARCASE - 120TL & TX/140 TL
J140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL

J140TLERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLERR 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TLERR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLESE 1990	GEARCASE - 120TL & TX/140 TL
J140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXARC 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXARK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXCCM 1988	GEARCASE - 120TL & TX/140 TL
J140TXCDC 1986	GEARCASE
J140TXCEB 1989	GEARCASE - 120TL & TX/140 TL
J140TXCIH 1981	GEARCASE
J140TXCIM 1981	GEARCASE
J140TXCNB 1982	GEARCASE
J140TXCRD 1984	GEARCASE
J140TXCSA 1980	GEARCASE
J140TXCTE 1983	GEARCASE
J140TXCUA 1987	GEARCASE
J140TXEID 1991	GEARCASE - 120TL & TX/140 TL
J140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
J140TXERK 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXERR 1994	GEARCASE - 120TL, 125ESX, & 140TL
J140TXERR 1994	GEARCASE - 140CX COUNTER ROTATION

J140TXESE 1990	GEARCASE - 120TL & TX/140 TL
J140TXETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
J140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J150CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150CXSD E	GEARCASE - CX, MODELS
J150CXSD E - FR	17-1_BOÎTIER D'ENGRENAGES - CX, MODELES
J150CXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002	GEARCASE - CX, MODELS
J150CXSOB	GEARCASE - CX, MODELS
J150CXSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150CXSRM	GEARCASE - CX, MODELS
J150CXSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150CXSTA	GEARCASE - CX, MODELS
J150CXSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150ELARA 1994	GEARCASE - COUNTER ROTATION
J150ELARV 1994	GEARCASE - COUNTER ROTATION
J150ELATG 1993	GEARCASE - COUNTER ROTATION
J150ELATR 1993	GEARCASE - COUNTER ROTATION
J150ELECD 1998	GEARCASE -- COUNTER-ROTATION
J150ELEDB 1996	GEARCASE - COUNTER-ROTATION
J150ELEOM 1995	GEARCASE - COUNTER ROTATION
J150ELERA 1994	GEARCASE - COUNTER ROTATION
J150ELERV 1994	GEARCASE - COUNTER ROTATION
J150ELETG 1993	GEARCASE - COUNTER ROTATION
J150ELETR 1993	GEARCASE - COUNTER ROTATION
J150ELEUC 1997	GEARCASE - COUNTER-ROTATION
J150ELEUE 1997	GEARCASE - COUNTER-ROTATION
J150EXARC 1994	GEARCASE - COUNTER ROTATION
J150EXARV 1994	GEARCASE - COUNTER ROTATION
J150EXATG 1993	GEARCASE - COUNTER ROTATION
J150EXATS 1993	GEARCASE - COUNTER ROTATION

J150EXECD 1998	GEARCASE -- COUNTER-ROTATION
J150EXEDB 1996	GEARCASE - COUNTER-ROTATION
J150EXEOM 1995	GEARCASE - COUNTER ROTATION
J150EXERA 1994	GEARCASE - COUNTER ROTATION
J150EXERV 1994	GEARCASE - COUNTER ROTATION
J150EXETG 1993	GEARCASE - COUNTER ROTATION
J150EXETR 1993	GEARCASE - COUNTER ROTATION
J150XEUC 1997	GEARCASE - COUNTER-ROTATION
J150XEUE 1997	GEARCASE - COUNTER-ROTATION
J150FCXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FSLECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FSXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150GLECD 1998	GEARCASE -- COUNTER-ROTATION
J150GLEDB 1996	GEARCASE - COUNTER-ROTATION
J150GLEOM 1995	GEARCASE - COUNTER ROTATION
J150GLERA 1994	GEARCASE - COUNTER ROTATION
J150GLERV 1994	GEARCASE - COUNTER ROTATION
J150GLETG 1993	GEARCASE - COUNTER ROTATION
J150GLETR 1993	GEARCASE - COUNTER ROTATION
J150GLEUC 1997	GEARCASE - COUNTER-ROTATION
J150GLEUE 1997	GEARCASE - COUNTER-ROTATION
J150GLSTA	GEARCASE - CX, MODELS
J150GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150ICXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150ILECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150ILEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150IXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150JLECD 1998	GEARCASE -- COUNTER-ROTATION
J150JLEDB 1996	GEARCASE - COUNTER-ROTATION
J150JLEOM 1995	GEARCASE - COUNTER ROTATION
J150JLERA 1994	GEARCASE - COUNTER ROTATION
J150JLERV 1994	GEARCASE - COUNTER ROTATION
J150JLETG 1993	GEARCASE - COUNTER ROTATION
J150JLETR 1993	GEARCASE - COUNTER ROTATION
J150JLEUC 1997	GEARCASE - COUNTER-ROTATION

J150JLEUE 1997	GEARCASE - COUNTER-ROTATION
J150JPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150NXARC 1994	GEARCASE - COUNTER ROTATION
J150NXARV 1994	GEARCASE - COUNTER ROTATION
J150NXATG 1993	GEARCASE - COUNTER ROTATION
J150NXATS 1993	GEARCASE - COUNTER ROTATION
J150NXECD 1998	GEARCASE -- COUNTER-ROTATION
J150NXEDB 1996	GEARCASE - COUNTER-ROTATION
J150NXEOM 1995	GEARCASE - COUNTER ROTATION
J150NXERA 1994	GEARCASE - COUNTER ROTATION
J150NXERV 1994	GEARCASE - COUNTER ROTATION
J150NXETG 1993	GEARCASE - COUNTER ROTATION
J150NXETR 1993	GEARCASE - COUNTER ROTATION
J150NXEUC 1997	GEARCASE - COUNTER-ROTATION
J150XEUE 1997	GEARCASE - COUNTER-ROTATION
J150PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150PLEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150PLSNF Carbureted, 20 in. shaft, Smoke 2002	GEARCASE - CX, MODELS
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150PLSTM	GEARCASE - CX, MODELS
J150PLSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150PXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150PXSUF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150PXSUF Carbureted, 25 in. shaft, White 2002	GEARCASE - CX, MODELS
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150PXSTM	GEARCASE - CX, MODELS
J150PXSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150SLECD 1998	GEARCASE -- COUNTER-ROTATION
J150SLEDB 1996	GEARCASE - COUNTER-ROTATION

J150SLEOM 1995	GEARCASE - COUNTER ROTATION
J150SLEUC 1997	GEARCASE - COUNTER-ROTATION
J150SLEUE 1997	GEARCASE - COUNTER-ROTATION
J150SPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150VLSNF Carbureted, 20 in. shaft, White 2002	GEARCASE - CX, MODELS
J150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175CXSD E	GEARCASE - CX, MODELS
J175CXSD E - FR	17-1_BOÎTIER D'ENGRENAGES - CX, MODELES
J175CXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002	GEARCASE - CX, MODELS
J175CXSOB	GEARCASE - CX, MODELS
J175CXSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175CXSRM	GEARCASE - CX, MODELS
J175CXSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175CXSTA	GEARCASE - CX, MODELS
J175CXSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175EXARC 1994	GEARCASE - COUNTER ROTATION
J175EXARV 1994	GEARCASE - COUNTER ROTATION
J175EXATG 1993	GEARCASE - COUNTER ROTATION
J175EXATS 1993	GEARCASE - COUNTER ROTATION
J175EXECD 1998	GEARCASE -- COUNTER-ROTATION
J175EXEDB 1996	GEARCASE - COUNTER-ROTATION
J175EXEOM 1995	GEARCASE - COUNTER ROTATION

J175EXERA 1994	GEARCASE - COUNTER ROTATION
J175EXERV 1994	GEARCASE - COUNTER ROTATION
J175EXETG 1993	GEARCASE - COUNTER ROTATION
J175EXETR 1993	GEARCASE - COUNTER ROTATION
J175XEUC 1997	GEARCASE - COUNTER-ROTATION
J175XEUE 1997	GEARCASE - COUNTER-ROTATION
J175FCXECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FSLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FSXECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FTLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175GLECD 1998	GEARCASE -- COUNTER-ROTATION
J175GLEDB 1996	GEARCASE - COUNTER-ROTATION
J175GLEOM 1995	GEARCASE - COUNTER ROTATION
J175GLERA 1994	GEARCASE - COUNTER ROTATION
J175GLETG 1993	GEARCASE - COUNTER ROTATION
J175GLETR 1993	GEARCASE - COUNTER ROTATION
J175GLEUC 1997	GEARCASE - COUNTER-ROTATION
J175GLEUE 1997	GEARCASE - COUNTER-ROTATION
J175GLSTA	GEARCASE - CX, MODELS
J175GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175NXARC 1994	GEARCASE - COUNTER ROTATION
J175NXARV 1994	GEARCASE - COUNTER ROTATION
J175NXATG 1993	GEARCASE - COUNTER ROTATION
J175NXATS 1993	GEARCASE - COUNTER ROTATION
J175NXECD 1998	GEARCASE -- COUNTER-ROTATION
J175NXEDB 1996	GEARCASE - COUNTER-ROTATION
J175NXEOM 1995	GEARCASE - COUNTER ROTATION
J175NXERA 1994	GEARCASE - COUNTER ROTATION
J175NXERV 1994	GEARCASE - COUNTER ROTATION
J175NXETG 1993	GEARCASE - COUNTER ROTATION
J175NXETR 1993	GEARCASE - COUNTER ROTATION
J175NXEUC 1997	GEARCASE - COUNTER-ROTATION
J175NXEUE 1997	GEARCASE - COUNTER-ROTATION
J175PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS

J175PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175PLSNF Carbureted, 20 in. shaft, Smoke 2002	GEARCASE - CX, MODELS
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175PLSTM	GEARCASE - CX, MODELS
J175PLSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175PXS NF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175PXS NF Carbureted, 25 in. shaft, White 2002	GEARCASE - CX, MODELS
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175PXSTM	GEARCASE - CX, MODELS
J175PXSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175SLECD 1998	GEARCASE -- COUNTER-ROTATION
J175SLEDB 1996	GEARCASE - COUNTER-ROTATION
J175SLEOM 1995	GEARCASE - COUNTER ROTATION
J175SLERA 1994	GEARCASE - COUNTER ROTATION
J175SLEUC 1997	GEARCASE - COUNTER-ROTATION
J175SLEUE 1997	GEARCASE - COUNTER-ROTATION
J175SPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175VLSNF Carbureted, 20 in. shaft, White 2002	GEARCASE - CX, MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J185ESERK 1994	GEARCASE - COUNTER ROTATION
J185ESXETA 1993	GEARCASE - COUNTER ROTATION
J185ESXETF 1993	GEARCASE - COUNTER ROTATION
J200CXARC 1994	GEARCASE - COUNTER ROTATION
J200CXARK 1994	GEARCASE - COUNTER ROTATION
J200CXATF 1993	GEARCASE - COUNTER ROTATION

J200CXATS 1993	GEARCASE - COUNTER ROTATION
J200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200CXEDR 1996	GEARCASE - COUNTER-ROTATION
J200CXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200CXEOC 1995	GEARCASE - COUNTER ROTATION
J200CXERK 1994	GEARCASE - COUNTER ROTATION
J200CXERS 1994	GEARCASE - COUNTER ROTATION
J200CXETD 1993	GEARCASE - COUNTER ROTATION
J200CXETF 1993	GEARCASE - COUNTER ROTATION
J200CXEUA 1997	GEARCASE - COUNTER-ROTATION
J200XSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200CZARK 1994	GEARCASE - COUNTER ROTATION
J200CZATF 1993	GEARCASE - COUNTER ROTATION
J200CZATS 1993	GEARCASE - COUNTER ROTATION
J200CZEOC 1995	GEARCASE - COUNTER ROTATION
J200CZERK 1994	GEARCASE - COUNTER ROTATION
J200CZERS 1994	GEARCASE - COUNTER ROTATION
J200CZETD 1993	GEARCASE - COUNTER ROTATION
J200CZETF 1993	GEARCASE - COUNTER ROTATION
J200PLEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200STLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200STLEDM 1996	GEARCASE - COUNTER-ROTATION
J200STLEOA 1995	GEARCASE - COUNTER ROTATION
J200STLERK 1994	GEARCASE - COUNTER ROTATION
J200STLERR 1994	GEARCASE - COUNTER ROTATION
J200STLETC 1993	GEARCASE - COUNTER ROTATION
J200STLETF 1993	GEARCASE - COUNTER ROTATION

J200STLEUB 1997	GEARCASE - COUNTER-ROTATION
J200TLECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200TXARC 1994	GEARCASE - COUNTER ROTATION
J200TXARK 1994	GEARCASE - COUNTER ROTATION
J200TXATF 1993	GEARCASE - COUNTER ROTATION
J200TXATS 1993	GEARCASE - COUNTER ROTATION
J200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200TXEDR 1996	GEARCASE - COUNTER-ROTATION
J200TXEOC 1995	GEARCASE - COUNTER ROTATION
J200TXERK 1994	GEARCASE - COUNTER ROTATION
J200TXERS 1994	GEARCASE - COUNTER ROTATION
J200TXETD 1993	GEARCASE - COUNTER ROTATION
J200XETF 1993	GEARCASE - COUNTER ROTATION
J200XEUA 1997	GEARCASE - COUNTER-ROTATION
J200TZARK 1994	GEARCASE - COUNTER ROTATION
J200TZATF 1993	GEARCASE - COUNTER ROTATION
J200TZATS 1993	GEARCASE - COUNTER ROTATION
J200TZEOC 1995	GEARCASE - COUNTER ROTATION
J200TZERK 1994	GEARCASE - COUNTER ROTATION
J200TZERS 1994	GEARCASE - COUNTER ROTATION
J200TZETD 1993	GEARCASE - COUNTER ROTATION
J200TZETF 1993	GEARCASE - COUNTER ROTATION
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225CXARC 1994	GEARCASE - COUNTER ROTATION
J225CXARK 1994	GEARCASE - COUNTER ROTATION
J225CXATF 1993	GEARCASE - COUNTER ROTATION
J225CXATS 1993	GEARCASE - COUNTER ROTATION
J225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225CXEDE 1996	GEARCASE - COUNTER-ROTATION

J225CXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225CXEOB 1995	GEARCASE - COUNTER ROTATION
J225CXERK 1994	GEARCASE - COUNTER ROTATION
J225CXERM 1994	GEARCASE - COUNTER ROTATION
J225CXETA 1993	GEARCASE - COUNTER ROTATION
J225CXETF 1993	GEARCASE - COUNTER ROTATION
J225CXEUD 1997	GEARCASE - COUNTER-ROTATION
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225CZARK 1994	GEARCASE - COUNTER ROTATION
J225CZATF 1993	GEARCASE - COUNTER ROTATION
J225CZATS 1993	GEARCASE - COUNTER ROTATION
J225CZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225CZEDE 1996	GEARCASE - COUNTER-ROTATION
J225CZEOB 1995	GEARCASE - COUNTER ROTATION
J225CZERK 1994	GEARCASE - COUNTER ROTATION
J225CZERM 1994	GEARCASE - COUNTER ROTATION
J225CZETA 1993	GEARCASE - COUNTER ROTATION
J225CZETF 1993	GEARCASE - COUNTER ROTATION
J225CZEUD 1997	GEARCASE - COUNTER-ROTATION
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225HPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225HPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PLEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PLERK 1994	GEARCASE - COUNTER ROTATION
J225PLERM 1994	GEARCASE - COUNTER ROTATION
J225PLETA 1993	GEARCASE - COUNTER ROTATION
J225PLETF 1993	GEARCASE - COUNTER ROTATION
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS

J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PXARC 1994	GEARCASE - COUNTER ROTATION
J225PXARK 1994	GEARCASE - COUNTER ROTATION
J225PXATF 1993	GEARCASE - COUNTER ROTATION
J225PXATS 1993	GEARCASE - COUNTER ROTATION
J225PXEDE 1996	GEARCASE - COUNTER-ROTATION
J225PXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PXEEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PXEOB 1995	GEARCASE - COUNTER ROTATION
J225PXERK 1994	GEARCASE - COUNTER ROTATION
J225PXERM 1994	GEARCASE - COUNTER ROTATION
J225PXETA 1993	GEARCASE - COUNTER ROTATION
J225PXETF 1993	GEARCASE - COUNTER ROTATION
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PZARK 1994	GEARCASE - COUNTER ROTATION
J225PZATF 1993	GEARCASE - COUNTER ROTATION
J225PZATS 1993	GEARCASE - COUNTER ROTATION
J225PZEOB 1995	GEARCASE - COUNTER ROTATION
J225PZERK 1994	GEARCASE - COUNTER ROTATION
J225PZERM 1994	GEARCASE - COUNTER ROTATION
J225PZETA 1993	GEARCASE - COUNTER ROTATION
J225PZETF 1993	GEARCASE - COUNTER ROTATION
J225STLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225STLEDE 1996	GEARCASE - COUNTER-ROTATION
J225STLEOB 1995	GEARCASE - COUNTER ROTATION
J225STLERC 1994	GEARCASE - COUNTER ROTATION
J225STLERK 1994	GEARCASE - COUNTER ROTATION
J225STLETF 1993	GEARCASE - COUNTER ROTATION
J225STLEUD 1997	GEARCASE - COUNTER-ROTATION
J225STLERK 1994	GEARCASE - COUNTER ROTATION
J225STLERM 1994	GEARCASE - COUNTER ROTATION
J225STLETA 1993	GEARCASE - COUNTER ROTATION
J225STLETF 1993	GEARCASE - COUNTER ROTATION
J225TXARC 1994	GEARCASE - COUNTER ROTATION
J225TXARK 1994	GEARCASE - COUNTER ROTATION

J225TXATF 1993	GEARCASE - COUNTER ROTATION
J225TXATS 1993	GEARCASE - COUNTER ROTATION
J225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225TXEDE 1996	GEARCASE - COUNTER-ROTATION
J225TXEOB 1995	GEARCASE - COUNTER ROTATION
J225TXERK 1994	GEARCASE - COUNTER ROTATION
J225TXERM 1994	GEARCASE - COUNTER ROTATION
J225TXETA 1993	GEARCASE - COUNTER ROTATION
J225TXETF 1993	GEARCASE - COUNTER ROTATION
J225TXEUD 1997	GEARCASE - COUNTER-ROTATION
J225TZARK 1994	GEARCASE - COUNTER ROTATION
J225TZATF 1993	GEARCASE - COUNTER ROTATION
J225TZATS 1993	GEARCASE - COUNTER ROTATION
J225TZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225TZEDE 1996	GEARCASE - COUNTER-ROTATION
J225TZEOb 1995	GEARCASE - COUNTER ROTATION
J225TZERK 1994	GEARCASE - COUNTER ROTATION
J225TZERM 1994	GEARCASE - COUNTER ROTATION
J225TZETA 1993	GEARCASE - COUNTER ROTATION
J225TZETF 1993	GEARCASE - COUNTER ROTATION
J225TZEUD 1997	GEARCASE - COUNTER-ROTATION
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250CXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250CZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250CZEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CZEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS

J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250PXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250PXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250PZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250PZEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PZEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J40AELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ARLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ATLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40ELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40JPLEEC 1999	GEARCASE
J40JPLSIA jet drive,elec start, TNT, 20 in shaft 2001	GEARCASE
J40JPLSSR Jet Drive, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J40JVLSIA jet drive,elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J40RCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40RLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40TTLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J40WREES 1999	GEARCASE

J40WRLEES 1999	GEARCASE
J40WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J40WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J40WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40WRYEES 1999	GEARCASE
J40WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J40WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J45RCCDS 1986	GEARCASE
J45RCCUC 1987	GEARCASE
J45RCE 1989	GEARCASE
J45RCEIA 1991	GEARCASE
J45RCENM 1992	GEARCASE
J45RCEOD 1995	GEARCASE
J45RCERE 1994	GEARCASE
J45RCESR 1990	GEARCASE
J45RCETB 1993	GEARCASE
J45RCLCDS 1986	GEARCASE
J45RCLCUC 1987	GEARCASE
J45RCLE 1989	GEARCASE
J45RCLEDS 1996	GEARCASE
J45RCLEIA 1991	GEARCASE
J45RCLENM 1992	GEARCASE
J45RCLEOD 1995	GEARCASE
J45RCLERE 1994	GEARCASE
J45RCLESR 1990	GEARCASE
J45RCLETB 1993	GEARCASE
J45RCLEUC 1997	GEARCASE
J45WMLE 1989	GEARCASE
J45WMLEIA 1991	GEARCASE
J45WMLENM 1992	GEARCASE
J45WMLESR 1990	GEARCASE
J50BECCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50BELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY

J50DTLECA 1998	GEARCASE
J50DTLEDC 1996	GEARCASE
J50DTLEOS 1995	GEARCASE
J50DTLEUR 1997	GEARCASE
J50ELED 1996	GEARCASE
J50ELEOS 1995	GEARCASE
J50ELEUR 1997	GEARCASE
J50TELCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50TLCCS 1988	GEARCASE - 40AR, 40AE, 40AT MODELS ONLY
J50TTLECA 1998	GEARCASE
J50TTLEDC 1996	GEARCASE
J50TTLEOS 1995	GEARCASE
J50TTLEUR 1997	GEARCASE
J55APRL	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRL - FR	27-6_BOÎTIER D'ENGRENAGES & BOÎTIER DE ROTOR - Modèles APRL
J55APRLSOM	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSOM - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRA	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRA - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55APRLSRG	GEARCASE & ROTOR HOUSING (APRL MODEL)
J55APRLSRG - FR	27-6_BOÎTIER D'ENGRENAGES ET BOÎTIER DE ROTOR - Modèles APRL
J55MLSOR	GEARCASE (ML MODEL)
J55MLSOR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MLSRC	GEARCASE (ML MODEL)
J55MLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MLSRG	GEARCASE (ML MODEL)
J55MLSRG - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55MRL	GEARCASE (ML MODEL)
J55MRL - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML
J55RSLC 1997	GEARCASE
J55RSLG 1995	GEARCASE
J55RSLN 1983	GEARCASE
J55RSLN-2 1983	GEARCASE

J55RSLW 1996	GEARCASE
J55RSN 1983	GEARCASE
J55RSN-2 1983	GEARCASE
J55RSYN 1983	GEARCASE
J55RSYN-2 1983	GEARCASE
J55RWLCDC 1986	GEARCASE
J55RWLCOS 1985	GEARCASE
J55RWLCRD 1984	GEARCASE
J55RWLCUC 1987	GEARCASE
J55RWLE 1989	GEARCASE
J55RWLEIA 1991	GEARCASE
J55RWLENM 1992	GEARCASE
J55RWLERE 1994	GEARCASE
J55RWLESR 1990	GEARCASE
J55RWLETB 1993	GEARCASE
J55WREES 1999	GEARCASE
J55WRLEES 1999	GEARCASE
J55WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE
J55WRLSOE	GEARCASE
J55WRLSOE - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSRB	GEARCASE
J55WRLSRB - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSRG	GEARCASE
J55WRLSRG - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRLSSC Commercial, Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J55WRLSTM	GEARCASE
J55WRLSTM - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRSIR commercial, rope start, 15 in shaft 2001	GEARCASE
J55WRSSC Commercial, Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J55WRYEES 1999	GEARCASE
J55WRYSIR commercial, rope start, 25 in shaft 2001	GEARCASE
J55WRYSOB	GEARCASE
J55WRYSOB - FR	27-1_BOÎTIER D'ENGRENAGES
J55WRYSRM	GEARCASE
J55WRYSRM - FR	27-1_BOÎTIER D'ENGRENAGES

J55WRYSSC Commercial, Rope Start, Tiller, 22.5 IN. shaft 2000	GEARCASE
J60ELCCR 1988	GEARCASE
J60ELCDS 1986	GEARCASE - 20" MODELS
J60ELCEA 1989	GEARCASE
J60ELCUC 1987	GEARCASE - 20" MODELS
J60ELEDR 1996	GEARCASE
J60ELEIB 1991	GEARCASE
J60ELENE 1992	GEARCASE
J60ELEOC 1995	GEARCASE
J60ELERS 1994	GEARCASE
J60ELERV 1994	GEARCASE
J60ELES M 1990	GEARCASE
J60ELETD 1993	GEARCASE
J60ELEUA 1997	GEARCASE
J60PLEEB 1999	GEARCASE
J60PLSID elec start, TNT, 20 in shaft 2001	GEARCASE
J60PLSSE Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J60TLCCR 1988	GEARCASE
J60TLCDS 1986	GEARCASE - 20" MODELS
J60TLCEA 1989	GEARCASE
J60TLCUC 1987	GEARCASE - 20" MODELS
J60TLECM 1998	GEARCASE
J60TLEDR 1996	GEARCASE
J60TLEIB 1991	GEARCASE
J60TLENE 1992	GEARCASE
J60TLEOC 1995	GEARCASE
J60TLERS 1994	GEARCASE
J60TLERV 1994	GEARCASE
J60TLES M 1990	GEARCASE
J60TLETD 1993	GEARCASE
J60TLEUA 1997	GEARCASE
J60TTLCCR 1988	GEARCASE
J60TTLCEA 1989	GEARCASE
J60TTLECM 1998	GEARCASE

J60TTLEDR 1996	GEARCASE
J60TTLEIB 1991	GEARCASE
J60TTLENE 1992	GEARCASE
J60TTLEOC 1995	GEARCASE
J60TTLERS 1994	GEARCASE
J60TTLERV 1994	GEARCASE
J60TTLESM 1990	GEARCASE
J60TTLETD 1993	GEARCASE
J60TTLEUA 1997	GEARCASE
J60VLSID elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J65RSLC 1995	GEARCASE
J65RSLM 1996	GEARCASE
J65RSLZ2 1997	GEARCASE
J65RWLCDR 1986	GEARCASE
J65RWLCOC 1985	GEARCASE
J65RWLCRS 1984	GEARCASE
J65TELCDR 1986	GEARCASE
J65TELCOC 1985	GEARCASE
J65TELCRS 1984	GEARCASE
J65WELEES 1999	GEARCASE
J65WELSIR Commercial, elec start, 20 in shaft 2001	GEARCASE
J65WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
J65WMLCDR 1986	GEARCASE
J65WMLCOC 1985	GEARCASE
J65WMLCUA 1987	GEARCASE
J65WMLEIB 1991	GEARCASE
J65WMLENE 1992	GEARCASE
J65WMLEOC 1995	GEARCASE
J65WMLERS 1994	GEARCASE
J65WMLESM 1990	GEARCASE
J65WMLETD 1993	GEARCASE
J65WMLZ 1989	GEARCASE
J65WRLEEO 1999	GEARCASE
J65WRLEES 1999	GEARCASE
J65WRLSIR commercial, rope start, 20 in shaft 2001	GEARCASE

J65WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
J65WRYEEO 1999	GEARCASE
J65WRYEES 1999	GEARCASE
J65WRYSIR commercial, rope start, 22.5 in shaft 2001	GEARCASE
J65WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
J65WTLCOC 1985	GEARCASE
J65WTLCRS 1984	GEARCASE
J70ELCCA 1988	GEARCASE
J70ELCDC 1986	GEARCASE
J70ELCEM 1989	GEARCASE
J70ELCIH 1981	GEARCASE - 20" TRANSOM
J70ELCIM 1981	GEARCASE - 20" TRANSOM
J70ELCNB 1982	GEARCASE - 20" TRANSOM
J70ELCOS 1985	GEARCASE - 20" MODELS
J70ELCRD 1984	GEARCASE - 20" MODELS
J70ELCSA 1980	GEARCASE-20"TRANSOM
J70ELCTE 1983	GEARCASE - 20" TRANSOM
J70ELCUR 1987	GEARCASE
J70ELEIE 1991	GEARCASE
J70ELEND 1992	GEARCASE
J70ELEOR 1995	GEARCASE
J70ELERC 1994	GEARCASE
J70ELERV 1994	GEARCASE
J70ELESB 1990	GEARCASE
J70ELETS 1993	GEARCASE
J70JLEOS 1995	GEARCASE
J70PLEEE 1999	GEARCASE
J70PLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
J70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J70TLCCA 1988	GEARCASE
J70TLCDC 1986	GEARCASE
J70TLCEM 1989	GEARCASE
J70TLCIM 1981	GEARCASE - 20" TRANSOM
J70TLCNB 1982	GEARCASE - 20" TRANSOM
J70TLCOS 1985	GEARCASE - 20" MODELS

J70TLCRD 1984	GEARCASE - 20" MODELS
J70TLCTE 1983	GEARCASE - 20" TRANSOM
J70TLCUR 1987	GEARCASE
J70TLECB 1998	GEARCASE
J70TLEDA 1996	GEARCASE
J70TLEIE 1991	GEARCASE
J70TLEND 1992	GEARCASE
J70TLEOR 1995	GEARCASE
J70TLERC 1994	GEARCASE
J70TLERV 1994	GEARCASE
J70TLESB 1990	GEARCASE
J70TLETS 1993	GEARCASE
J70TLEUM 1997	GEARCASE
J70TTLEIE 1991	GEARCASE
J70TTLEND 1992	GEARCASE
J70TTLEOR 1995	GEARCASE
J70TTLERC 1994	GEARCASE
J70TTLERV 1994	GEARCASE
J70TTLETS 1993	GEARCASE
J70VLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
J75ECDC 1986	GEARCASE - 20" MODELS
J75ECNB 1982	GEARCASE - 20" TRANSOM
J75ECOS 1985	GEARCASE - 20" MODELS
J75ECDRD 1984	GEARCASE - 20" MODELS
J75ECTE 1983	GEARCASE - 20" TRANSOM
J75ECUR 1987	GEARCASE - 20" MODELS
J75ELCNB 1982	GEARCASE - 20" TRANSOM
J75ELCRD 1984	GEARCASE - 20" MODELS
J75ELCTE 1983	GEARCASE - 20" TRANSOM
J75ERCIH 1981	GEARCASE - 20" TRANSOM
J75ERCIM 1981	GEARCASE - 20" TRANSOM
J75ERCSA 1980	GEARCASE-20"TRANSOM
J75ERLCIH 1981	GEARCASE - 20" TRANSOM
J75ERLCIM 1981	GEARCASE - 20" TRANSOM
J75ERLCSA 1980	GEARCASE-20"TRANSOM

J75TELCIM 1981	GEARCASE - 20" TRANSOM
J75TLCNB 1982	GEARCASE - 20" TRANSOM
J75TLCRD 1984	GEARCASE - 20" MODELS
J75TLCTE 1983	GEARCASE - 20" TRANSOM
J75TRLCIH 1981	GEARCASE - 20" TRANSOM
J75TRLCSA 1980	GEARCASE-20"TRANSOM
J85MLCSA 1980	GEARCASE
J85TLCSA 1980	GEARCASE
J85TTLEIE 1991	GEARCASE
J85TTLEND 1992	GEARCASE
J85TTLEOR 1995	GEARCASE
J85TTLERC 1994	GEARCASE
J85TTLETS 1993	GEARCASE
J85TXCSA 1980	GEARCASE
J88MSLCCC 1988	GEARCASE
J88MSLCER 1989	GEARCASE
J88MSLCUS 1987	GEARCASE
J88MSLEDC 1996	GEARCASE
J88MSLEIM 1991	GEARCASE
J88MSLENB 1992	GEARCASE
J88MSLEOS 1995	GEARCASE
J88MSLERD 1994	GEARCASE
J88MSLESA 1990	GEARCASE
J88MSLETE 1993	GEARCASE
J88TSLEDR 1996	GEARCASE
J88TSLEOC 1995	GEARCASE
J88TSLERS 1994	GEARCASE
J90ELECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J90ELEDR 1996	GEARCASE - 20 IN. MODELS
J90ELEOC 1995	GEARCASE - 20 IN. MODELS
J90ELEUA 1997	GEARCASE - 20 IN. MODELS
J90ELEUC 1997	GEARCASE - 20 IN. MODELS
J90EXEOC 1995	GEARCASE - 20 IN. MODELS
J90FSLECS 1998	GEARCASE -- FSL, FTL MODELS
J90FTLECS 1998	GEARCASE -- FSL, FTL MODELS

J90GLSDE	GEARCASE - PL, GL MODELS
J90GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J90GLSOB	GEARCASE - PL, GL MODELS
J90GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90GLSRM	GEARCASE - PL, GL MODELS
J90GLSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90GLSTA	GEARCASE - PL, GL MODELS
J90GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J90JLEIE 1991	GEARCASE
J90JLEND 1992	GEARCASE
J90JLEOR 1995	GEARCASE
J90JLERC 1994	GEARCASE
J90JLETS 1993	GEARCASE
J90MLCDC 1986	GEARCASE
J90MLCIH 1981	GEARCASE
J90MLCIM 1981	GEARCASE
J90MLCNB 1982	GEARCASE
J90MLCOS 1985	GEARCASE
J90MLCRD 1984	GEARCASE
J90MLCTE 1983	GEARCASE
J90MLCUR 1987	GEARCASE
J90MLEOR 1995	GEARCASE
J90MLERC 1994	GEARCASE
J90PLEEB 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J90PLSDM	GEARCASE - PL, GL MODELS
J90PLSDM - FR	17-1_BOÎTIER D'ENGRENAGES - PL, GL MODELES
J90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
J90PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J90PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J90PLSOA	GEARCASE - PL, GL MODELS
J90PLSOA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90PLSRR	GEARCASE - PL, GL MODELS
J90PLSRR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS

J90PLSTC	GEARCASE - PL, GL MODELS
J90PLSTC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et GL
J90SLECM 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
J90SLEDR 1996	GEARCASE - 20 IN. MODELS
J90SLEOC 1995	GEARCASE - 20 IN. MODELS
J90SLEUA 1997	GEARCASE - 20 IN. MODELS
J90SLEUC 1997	GEARCASE - 20 IN. MODELS
J90SPLEES 1999	GEARCASE -- 90 & 115 PL AND 90 & 115 SPL MODELS
J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
J90TLAEM 1989	GEARCASE
J90TLAIE 1991	GEARCASE
J90TLAND 1992	GEARCASE
J90TLARC 1994	GEARCASE
J90TLASB 1990	GEARCASE
J90TLATS 1993	GEARCASE
J90TLCCA 1988	GEARCASE
J90TLCDC 1986	GEARCASE
J90TLCEM 1989	GEARCASE
J90TLCIH 1981	GEARCASE
J90TLCIM 1981	GEARCASE
J90TLCNB 1982	GEARCASE
J90TLCOS 1985	GEARCASE
J90TLCRD 1984	GEARCASE
J90TLCTE 1983	GEARCASE
J90TLCUR 1987	GEARCASE
J90TLEDA 1996	GEARCASE
J90TLEIE 1991	GEARCASE
J90TLEND 1992	GEARCASE
J90TLEOR 1995	GEARCASE
J90TLERC 1994	GEARCASE
J90TLESB 1990	GEARCASE
J90TLETS 1993	GEARCASE
J90TSLECM 1998	GEARCASE
J90TSLEUA 1997	GEARCASE
J90TXARC 1994	GEARCASE

J90TXATS 1993	GEARCASE
J90TXCDC 1986	GEARCASE
J90TXCIH 1981	GEARCASE
J90TXCIM 1981	GEARCASE
J90TXCNB 1982	GEARCASE
J90TXCOS 1985	GEARCASE
J90TXCRD 1984	GEARCASE
J90TXCTE 1983	GEARCASE
J90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
J90VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PLS et VLS
J90VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002	GEARCASE - PLS, VLS MODELS
J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
L115GLECA 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
L115GLEDC 1996	GEARCASE - 20 IN. MODELS
L115GLEOS 1995	GEARCASE - 20 IN. MODELS
L115GLEUC 1997	GEARCASE - 20 IN. MODELS
L115GLEUR 1997	GEARCASE - 20 IN. MODELS
L150GLECA 1998	GEARCASE -- COUNTER-ROTATION
L150GLEDC 1996	GEARCASE - COUNTER-ROTATION
L150GLEOS 1995	GEARCASE - COUNTER ROTATION
L150GLEUC 1997	GEARCASE - COUNTER-ROTATION
L150GLEUR 1997	GEARCASE - COUNTER-ROTATION
L90GLECS 1998	GEARCASE -- 90 & 115 EL, GL, SL MODELS
LE200SLEDR 1996	GEARCASE - COUNTER-ROTATION
LE200SLEOC 1995	GEARCASE - COUNTER ROTATION
LJ200SLEDR 1996	GEARCASE - COUNTER-ROTATION
LJ200SLEOC 1995	GEARCASE - COUNTER ROTATION
M55RWLR 1988	GEARCASE
N65WMLM 1988	GEARCASE
R45RCLR 1988	GEARCASE
R45RCR 1988	GEARCASE
R55RWLR 1988	GEARCASE
RE115FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE115FLSSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS

RE115FLSSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE115FSSSH FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FSSSR FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE115FXSSH FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE115FXSSR FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS

RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - Counter Rotation
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
RE225FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
RE225FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - Counter Rotation
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - Counter Rotation
RE75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPL - FSL - FL - FVL - FSS MODELS
RE90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RE90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPL, FSL, FL, FS MODELS
RJ115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS

RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175CX SIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225CX SIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS

RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ70PLSIS elec start, TNT, 20 in shaft 2001	GEARCASE
RJ70PLSSD Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
RJ90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 PL - VL MODELS
RJ90VLSSS Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PL, SPL, AND VL MODELS
S45RCLR 1988	GEARCASE
S45RCR 1988	GEARCASE
SE100WMPLM 1996	GEARCASE
SE100WMPLZ 1997	GEARCASE
SE100WTPLM 1996	GEARCASE
SE100WTPLZ 1997	GEARCASE
SE225GLECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225NXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225NZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225QXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225QZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE40RPB 1997	GEARCASE
SE40RPH 1996	GEARCASE
SE40RPLB 1997	GEARCASE
SE40RPLH 1996	GEARCASE
SE40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE40RPYB 1997	GEARCASE
SE40RPYH 1996	GEARCASE
SE40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SE40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY

SE45RSLB 1997	GEARCASE
SE45RSLH 1996	GEARCASE
SE55RSC 1997	GEARCASE
SE55RSLC 1997	GEARCASE
SE55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSLW 1996	GEARCASE
SE55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSW 1996	GEARCASE
SE55RSYC 1997	GEARCASE
SE55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SE55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SE55RSYW 1996	GEARCASE
SE65RSLD 1998	GEARCASE
SE65RSLM 1996	GEARCASE
SE65RSLZ2 1997	GEARCASE
SE65RSYD 1998	GEARCASE
SE65RSYM 1996	GEARCASE
SE65RSYZ2 1997	GEARCASE
SE65WMLD 1998	GEARCASE
SE65WMLM 1996	GEARCASE
SE65WMLZ2 1997	GEARCASE
SE65WMYD 1998	GEARCASE
SE65WMYM 1996	GEARCASE
SE65WMYZ2 1997	GEARCASE
SJ100WMPLM 1996	GEARCASE
SJ100WMPLZ 1997	GEARCASE
SJ100WTPLM 1996	GEARCASE
SJ100WTPLZ 1997	GEARCASE
SJ115ELED 1996	GEARCASE - 20 IN. MODELS
SJ130CXADA 1996	GEARCASE - 130CX COUNTER ROTATION
SJ130TLED 1996	GEARCASE - 130CX COUNTER ROTATION
SJ130TXADA 1996	GEARCASE - 130CX COUNTER ROTATION
SJ150ELED 1996	GEARCASE - COUNTER-ROTATION

SJ200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200CXEUA 1997	GEARCASE - COUNTER-ROTATION
SJ200SLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200SLEDM 1996	GEARCASE - COUNTER-ROTATION
SJ200SLEUB 1997	GEARCASE - COUNTER-ROTATION
SJ200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200TXEUA 1997	GEARCASE - COUNTER-ROTATION
SJ225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225CXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225CXEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225GLECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225NXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225NZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225PXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225QXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225QZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225SLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225SLEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225SLEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225TXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225TXEUD 1997	GEARCASE - COUNTER-ROTATION
SJ40RPB 1997	GEARCASE
SJ40RPH 1996	GEARCASE
SJ40RPLB 1997	GEARCASE
SJ40RPLH 1996	GEARCASE
SJ40RPLT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPLT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ40RPYB 1997	GEARCASE
SJ40RPYH 1996	GEARCASE
SJ40RPYT2 1998	GEARCASE -- T & M MODELS ONLY
SJ40RPYT2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ45RSLB 1997	GEARCASE

SJ45RSLH 1996	GEARCASE
SJ55RSC 1997	GEARCASE
SJ55RSLC 1997	GEARCASE
SJ55RSLM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSLM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSLW 1996	GEARCASE
SJ55RSM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSW 1996	GEARCASE
SJ55RSYC 1997	GEARCASE
SJ55RSYM2 1998	GEARCASE -- T & M MODELS ONLY
SJ55RSYM2 1998	GEARCASE -- T2 & M2 MODELS ONLY
SJ55RSYW 1996	GEARCASE
SJ60TLEDR 1996	GEARCASE
SJ65RSLD 1998	GEARCASE
SJ65RSLM 1996	GEARCASE
SJ65RSLZ2 1997	GEARCASE
SJ65RSYD 1998	GEARCASE
SJ65RSYM 1996	GEARCASE
SJ65RSYZ2 1997	GEARCASE
SJ65WMLD 1998	GEARCASE
SJ65WMLM 1996	GEARCASE
SJ65WMLZ2 1997	GEARCASE
SJ65WMYD 1998	GEARCASE
SJ65WMYM 1996	GEARCASE
SJ65WMYZ2 1997	GEARCASE
SJ70LEDA 1996	GEARCASE
SJ90ELEDR 1996	GEARCASE - 20 IN. MODELS
T65WMLM 1988	GEARCASE
TE110TLCEM 1989	GEARCASE
TE110TLESF 1989	GEARCASE
TE110TXCEM 1989	GEARCASE
TE115TLEIE 1991	GEARCASE
TE115TLEND 1992	GEARCASE
TE115TLESB 1990	GEARCASE

TE115TLETS 1993	GEARCASE
TE120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
TE150GLETG 1993	GEARCASE - COUNTER ROTATION
TE150GLETR 1993	GEARCASE - COUNTER ROTATION
TE60TLCEA 1989	GEARCASE
TE60TLEIB 1991	GEARCASE
TE60TLENE 1992	GEARCASE
TE60TLESF 1989	GEARCASE
TE60TLESF 1990	GEARCASE
TE60TLESM 1990	GEARCASE
TE60TLETD 1993	GEARCASE
TE70TLCEM 1989	GEARCASE
TE70TLESB 1990	GEARCASE
TE70TLESF 1989	GEARCASE
TE70TLESF 1990	GEARCASE
TE90TLCEM 1989	GEARCASE
TE90TLEIE 1991	GEARCASE
TE90TLEND 1992	GEARCASE
TE90TLESB 1990	GEARCASE
TE90TLESF 1989	GEARCASE
TE90TLESF 1990	GEARCASE
TE90TLETS 1993	GEARCASE
TJ110TLCEM 1989	GEARCASE
TJ110TXCEM 1989	GEARCASE
TJ115TLEIE 1991	GEARCASE
TJ115TLEND 1992	GEARCASE
TJ115TLESB 1990	GEARCASE
TJ115TLETS 1993	GEARCASE
TJ120TXCEM 1989	GEARCASE - 120TL & TX/140 TL
TJ150GLETG 1993	GEARCASE - COUNTER ROTATION
TJ150GLETR 1993	GEARCASE - COUNTER ROTATION
TJ60TLCEA 1989	GEARCASE
TJ60TLEIB 1991	GEARCASE
TJ60TLENE 1992	GEARCASE
TJ60TLESF 1989	GEARCASE

TJ60TLESF 1990	GEARCASE
TJ60TLESM 1990	GEARCASE
TJ60TLETD 1993	GEARCASE
TJ70TLCEM 1989	GEARCASE
TJ70TLESB 1990	GEARCASE
TJ70TLESF 1989	GEARCASE
TJ70TLESF 1990	GEARCASE
TJ90TLCEM 1989	GEARCASE
TJ90TLEIE 1991	GEARCASE
TJ90TLEND 1992	GEARCASE
TJ90TLESB 1990	GEARCASE
TJ90TLETS 1993	GEARCASE
V115SHLETS 1993	GEARCASE
V115SLEIE 1991	GEARCASE
V115SLEND 1992	GEARCASE
V115SLETS 1993	GEARCASE
V150SLETG 1993	GEARCASE - COUNTER ROTATION
V150SLETS 1993	GEARCASE - COUNTER ROTATION
V90SLEIE 1991	GEARCASE
V90SLEND 1992	GEARCASE
V90SLETE 1993	GEARCASE
VE100SLEIE 1991	GEARCASE
VE100SLEND 1992	GEARCASE
VE100SLESB 1990	GEARCASE
VE100SLETS 1993	GEARCASE
VE115TLEIE 1991	GEARCASE
VE115TLESB 1990	GEARCASE
VE115TLETS 1993	GEARCASE
VE115TXEIE 1991	GEARCASE
VE115TXESB 1990	GEARCASE
VE120TLEIE 1991	GEARCASE - 120TL & TX/140 TL
VE120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE120TLESB 1990	GEARCASE - 120TL & TX/140 TL
VE120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY

VE120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
VE120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE120TXESB 1990	GEARCASE - 120TL & TX/140 TL
VE120TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TXETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TLEID 1991	GEARCASE - 120TL & TX/140 TL
VE140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE140TLESE 1990	GEARCASE - 120TL & TX/140 TL
VE140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TXEID 1991	GEARCASE - 120TL & TX/140 TL
VE140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VE140TXESE 1990	GEARCASE - 120TL & TX/140 TL
VE140TXETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TXETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VE140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE150ELETG 1993	GEARCASE - COUNTER ROTATION
VE150ELETR 1993	GEARCASE - COUNTER ROTATION
VE150EXETG 1993	GEARCASE - COUNTER ROTATION
VE150EXETR 1993	GEARCASE - COUNTER ROTATION
VE150GLETG 1993	GEARCASE - COUNTER ROTATION
VE150GLETR 1993	GEARCASE - COUNTER ROTATION
VE150HLEOS 1995	GEARCASE - COUNTER ROTATION
VE175EXETG 1993	GEARCASE - COUNTER ROTATION

VE175EXETR 1993	GEARCASE - COUNTER ROTATION
VE175GLETG 1993	GEARCASE - COUNTER ROTATION
VE175GLETR 1993	GEARCASE - COUNTER ROTATION
VE200SLETC 1993	GEARCASE - COUNTER ROTATION
VE200SLETF 1993	GEARCASE - COUNTER ROTATION
VE200TXETD 1993	GEARCASE - COUNTER ROTATION
VE200TXETF 1993	GEARCASE - COUNTER ROTATION
VE200TZETD 1993	GEARCASE - COUNTER ROTATION
VE200TZETF 1993	GEARCASE - COUNTER ROTATION
VE225PLETA 1993	GEARCASE - COUNTER ROTATION
VE225PLETF 1993	GEARCASE - COUNTER ROTATION
VE225PXETA 1993	GEARCASE - COUNTER ROTATION
VE225PXETF 1993	GEARCASE - COUNTER ROTATION
VE225PZETA 1993	GEARCASE - COUNTER ROTATION
VE225PZETF 1993	GEARCASE - COUNTER ROTATION
VE225STLETF 1993	GEARCASE - COUNTER ROTATION
VE225TLETA 1993	GEARCASE - COUNTER ROTATION
VE225TLETF 1993	GEARCASE - COUNTER ROTATION
VE225TXETA 1993	GEARCASE - COUNTER ROTATION
VE225TXETF 1993	GEARCASE - COUNTER ROTATION
VE225TZETA 1993	GEARCASE - COUNTER ROTATION
VE225TZETF 1993	GEARCASE - COUNTER ROTATION
VE60ELEIB 1991	GEARCASE
VE60ELENE 1992	GEARCASE
VE60ELESM 1990	GEARCASE
VE60ELETD 1993	GEARCASE
VE60TLEIB 1991	GEARCASE
VE60TLENE 1992	GEARCASE
VE60TLESM 1990	GEARCASE
VE70ELEIE 1991	GEARCASE
VE70ELEND 1992	GEARCASE
VE70ELESB 1990	GEARCASE
VE70ELETS 1993	GEARCASE
VE70TLEIE 1991	GEARCASE
VE70TLEND 1992	GEARCASE

VE70TLESB 1990	GEARCASE
VE70TLETS 1993	GEARCASE
VE88MSLCCC 1988	GEARCASE
VE88MSLCER 1989	GEARCASE
VE88MSLESA 1990	GEARCASE
VE90MLEIE 1991	GEARCASE
VE90MLEND 1992	GEARCASE
VE90MLESB 1990	GEARCASE
VE90MLETS 1993	GEARCASE
VE90TLEIE 1991	GEARCASE
VE90TLEND 1992	GEARCASE
VE90TLESB 1990	GEARCASE
VE90TLETS 1993	GEARCASE
VJ100SLEIE 1991	GEARCASE
VJ100SLEND 1992	GEARCASE
VJ100SLESB 1990	GEARCASE
VJ100SLETS 1993	GEARCASE
VJ115TLAIE 1991	GEARCASE
VJ115TLAND 1992	GEARCASE
VJ115TLASB 1990	GEARCASE
VJ115TLATS 1993	GEARCASE
VJ115TLEIE 1991	GEARCASE
VJ115TLESB 1990	GEARCASE
VJ115TLETS 1993	GEARCASE
VJ115TXEIE 1991	GEARCASE
VJ115TXESB 1990	GEARCASE
VJ120TLAIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TLAND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TLASB 1990	GEARCASE - 120TL & TX/140 TL
VJ120TLATF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLATS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLATS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLEIE 1991	GEARCASE - 120TL & TX/140 TL

VJ120TLEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TLESB 1990	GEARCASE - 120TL & TX/140 TL
VJ120TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TXEIE 1991	GEARCASE - 120TL & TX/140 TL
VJ120TXEND 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ120TXESB 1990	GEARCASE - 120TL & TX/140 TL
VJ120XETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120XETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120XETS 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ120XETS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TLAID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TLANS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TLASE 1990	GEARCASE - 120TL & TX/140 TL
VJ140TLEID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TLENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TLESE 1990	GEARCASE - 120TL & TX/140 TL
VJ140TLETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TLETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TXEID 1991	GEARCASE - 120TL & TX/140 TL
VJ140TXENS 1992	GEARCASE - 120TL & TX/125ESX/140 TL
VJ140TXESE 1990	GEARCASE - 120TL & TX/140 TL
VJ140XETC 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ140XETC 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140XETF 1993	GEARCASE - 120TL & 140TL 120TX & 125ESX "S" SUFFIX ONLY
VJ140XETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ150ELATG 1993	GEARCASE - COUNTER ROTATION

VJ150ELATR 1993	GEARCASE - COUNTER ROTATION
VJ150ELETG 1993	GEARCASE - COUNTER ROTATION
VJ150ELETR 1993	GEARCASE - COUNTER ROTATION
VJ150EXETG 1993	GEARCASE - COUNTER ROTATION
VJ150EXETR 1993	GEARCASE - COUNTER ROTATION
VJ150GLETG 1993	GEARCASE - COUNTER ROTATION
VJ150GLETR 1993	GEARCASE - COUNTER ROTATION
VJ150HLEOS 1995	GEARCASE - COUNTER ROTATION
VJ175EXETG 1993	GEARCASE - COUNTER ROTATION
VJ175EXETR 1993	GEARCASE - COUNTER ROTATION
VJ175GLETG 1993	GEARCASE - COUNTER ROTATION
VJ175GLETR 1993	GEARCASE - COUNTER ROTATION
VJ200SLETC 1993	GEARCASE - COUNTER ROTATION
VJ200SLETF 1993	GEARCASE - COUNTER ROTATION
VJ200TXETD 1993	GEARCASE - COUNTER ROTATION
VJ200TXETF 1993	GEARCASE - COUNTER ROTATION
VJ200TZETD 1993	GEARCASE - COUNTER ROTATION
VJ200TZETF 1993	GEARCASE - COUNTER ROTATION
VJ225PLETA 1993	GEARCASE - COUNTER ROTATION
VJ225PLETF 1993	GEARCASE - COUNTER ROTATION
VJ225PXETA 1993	GEARCASE - COUNTER ROTATION
VJ225PXETF 1993	GEARCASE - COUNTER ROTATION
VJ225PZETA 1993	GEARCASE - COUNTER ROTATION
VJ225PZETF 1993	GEARCASE - COUNTER ROTATION
VJ225STLETF 1993	GEARCASE - COUNTER ROTATION
VJ225TLETA 1993	GEARCASE - COUNTER ROTATION
VJ225TLETF 1993	GEARCASE - COUNTER ROTATION
VJ225TXETA 1993	GEARCASE - COUNTER ROTATION
VJ225TXETF 1993	GEARCASE - COUNTER ROTATION
VJ225TZETA 1993	GEARCASE - COUNTER ROTATION
VJ225TZETF 1993	GEARCASE - COUNTER ROTATION
VJ60ELEIB 1991	GEARCASE
VJ60ELENE 1992	GEARCASE
VJ60ELES 1990	GEARCASE
VJ60ELETD 1993	GEARCASE

VJ60TLEIB 1991	GEARCASE
VJ60TLENE 1992	GEARCASE
VJ60TLESM 1990	GEARCASE
VJ70ELEIE 1991	GEARCASE
VJ70ELEND 1992	GEARCASE
VJ70ELESB 1990	GEARCASE
VJ70ELETS 1993	GEARCASE
VJ70TLEIE 1991	GEARCASE
VJ70TLEND 1992	GEARCASE
VJ70TLESB 1990	GEARCASE
VJ70TLETS 1993	GEARCASE
VJ88MSLCCC 1988	GEARCASE
VJ88MSLCER 1989	GEARCASE
VJ88MSLESA 1990	GEARCASE
VJ90MLEIE 1991	GEARCASE
VJ90MLEND 1992	GEARCASE
VJ90MLESB 1990	GEARCASE
VJ90MLETS 1993	GEARCASE
VJ90TLAIE 1991	GEARCASE
VJ90TLAND 1992	GEARCASE
VJ90TLASB 1990	GEARCASE
VJ90TLATS 1993	GEARCASE
VJ90TLEIE 1991	GEARCASE
VJ90TLEND 1992	GEARCASE
VJ90TLESB 1990	GEARCASE
VJ90TLETS 1993	GEARCASE
XE112TSLEDR 1996	GEARCASE
XE112TSLEOC 1995	GEARCASE
XE112TSLERS 1994	GEARCASE
XE112TSXEDR 1996	GEARCASE
XE112TSXEOC 1995	GEARCASE
XE112TSXERS 1994	GEARCASE
XE115HLECM 1998	GEARCASE
XE115HLEUA 1997	GEARCASE
XE115HXECM 1998	GEARCASE

XE115HXEUA 1997	GEARCASE
XE88TSLEDR 1996	GEARCASE
XE88TSLEOC 1995	GEARCASE
XE88TSLERS 1994	GEARCASE
XE90TSLECM 1998	GEARCASE
XE90TSLEUA 1997	GEARCASE
XJ112TSLEDR 1996	GEARCASE
XJ112TSLEOC 1995	GEARCASE
XJ112TSLERS 1994	GEARCASE
XJ112TSXEDR 1996	GEARCASE
XJ112TSXEOC 1995	GEARCASE
XJ112TSXERS 1994	GEARCASE
XJ115HLECM 1998	GEARCASE
XJ115HLEUA 1997	GEARCASE
XJ115HXECM 1998	GEARCASE
XJ115HXEUA 1997	GEARCASE
XJ88TSLEDR 1996	GEARCASE
XJ88TSLEOC 1995	GEARCASE
XJ88TSLERS 1994	GEARCASE
XJ90TSLECM 1998	GEARCASE
XJ90TSLEUA 1997	GEARCASE