

Where Used: Part Number 0386764

Model Name	Diagram
50542B 1975	GEARCASE
50543B 1975	GEARCASE
50572B 1975	GEARCASE
50573B 1975	GEARCASE
50902C 1979	GEARCASE, ELECTRIC START
50903C 1979	GEARCASE, ELECTRIC START
50ES75B 1975	GEARCASE
50ESL75B 1975	GEARCASE
50R79C 1979	GEARCASE, ELECTRIC START
50RL79C 1979	GEARCASE, ELECTRIC START
55642E 1976	GEARCASE
55643E 1976	GEARCASE
55672E 1976	GEARCASE
55673E 1976	GEARCASE
55772D 1977	GEARCASE
55773D 1977	GEARCASE
55874S 1978	GEARCASE
55875S 1978	GEARCASE
55974C 1979	GEARCASE, ELECTRIC START
55975C 1979	GEARCASE, ELECTRIC START
55E76E 1976	GEARCASE
55E77D 1977	GEARCASE
55E78S 1978	GEARCASE
55E79C 1979	GEARCASE, ELECTRIC START
55EL76E 1976	GEARCASE
55EL77D 1977	GEARCASE
55EL78S 1978	GEARCASE
55EL79C 1979	GEARCASE, ELECTRIC START
70773S 1977	GEARCASE-15" TRANSOM
70873C 1978	GEARCASE-15" TRANSOM
70973R 1979	GEARCASE-15" TRANSOM
70EL77S 1977	GEARCASE-15"TRANSOM
70EL78C 1978	GEARCASE-15 INCH TRANSOM

70EL79R 1979	GEARCASE-15"TRANSOM
75542B 1975	GEARCASE - 15" TRANSOM
75543B 1975	GEARCASE - 15" TRANSOM
75642D 1976	GEARCASE-15" TRANSOM
75643D 1976	GEARCASE-15" TRANSOM
75742S 1977	GEARCASE-15" TRANSOM
75743S 1977	GEARCASE-15" TRANSOM
75842C 1978	GEARCASE-15" TRANSOM
75843C 1978	GEARCASE-15" TRANSOM
75942R 1979	GEARCASE-15" TRANSOM
75943R 1979	GEARCASE-15" TRANSOM
75ELR76D 1976	GEARCASE-15" TRANSCOM
75ELR77S 1977	GEARCASE-15"TRANSOM
75ELR78C 1978	GEARCASE-15 INCH TRANSOM
75ELR79R 1979	GEARCASE-15"TRANSOM
75ER76D 1976	GEARCASE-15" TRANSCOM
75ER77S 1977	GEARCASE-15"TRANSOM
75ER78C 1978	GEARCASE-15 INCH TRANSOM
75ER79R 1979	GEARCASE-15"TRANSOM
75ESLR75B 1975	GEARCASE-15"TRANSOM
75ESR75B 1975	GEARCASE-15"TRANSOM
BE40EECR 1998	GEARCASE
BE40EEDS 1996	GEARCASE
BE40EEUC 1997	GEARCASE
BE40ELECR 1998	GEARCASE
BE40ELEDs 1996	GEARCASE
BE40ELEUC 1997	GEARCASE
BE40TLECR 1998	GEARCASE
BE40TLEDs 1996	GEARCASE
BE40TLEUC 1997	GEARCASE
BE50BEEDs 1996	GEARCASE
BE50BELEDs 1996	GEARCASE
BE50ESECC 1998	GEARCASE
BE50RLECR 1998	GEARCASE
BE50RLEUC 1997	GEARCASE

BE50TLECR 1998	GEARCASE
BE50TLEDS 1996	GEARCASE
BE50TLEUC 1997	GEARCASE
BE50TSLECC 1998	GEARCASE
BE50TSLEUS 1997	GEARCASE
BJ40EECR 1998	GEARCASE
BJ40EEDS 1996	GEARCASE
BJ40EEEA 1999	GEARCASE
BJ40EEUC 1997	GEARCASE
BJ40ELECR 1998	GEARCASE
BJ40ELEDS 1996	GEARCASE
BJ40ELEEA 1999	GEARCASE
BJ40ELEUC 1997	GEARCASE
BJ40ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ40ELSSM Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ40ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ40ESSM Elec. Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40PLEEA 1999	GEARCASE
BJ40PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ40PLSSM Elec. Start, TNT, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ40TLECR 1998	GEARCASE
BJ40TLEDS 1996	GEARCASE
BJ40TLEUC 1997	GEARCASE
BJ50BEEDS 1996	GEARCASE
BJ50BELEDS 1996	GEARCASE
BJ50EEER 1999	GEARCASE
BJ50ELEER 1999	GEARCASE
BJ50ELSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50ELSSA Elec. Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50ESECC 1998	GEARCASE
BJ50ESIF elec start, 15 in shaft, n/a usa 2001	GEARCASE
BJ50ESSA Elec Start, 15 IN. shaft, N/A USA 2000	GEARCASE
BJ50PLEEA 1999	GEARCASE
BJ50PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft, N/A USA 2000	GEARCASE

BJ50RLECR 1998	GEARCASE
BJ50RLEEA 1999	GEARCASE
BJ50RLEUC 1997	GEARCASE
BJ50RLSIF elec start, 20 in shaft, n/a usa 2001	GEARCASE
BJ50RLSSM Rope Start, 20 IN. shaft, N/A USA 2000	GEARCASE
BJ50TLECR 1998	GEARCASE
BJ50TLEDS 1996	GEARCASE
BJ50TLEUC 1997	GEARCASE
BJ50TSLECC 1998	GEARCASE
BJ50TSLEUS 1997	GEARCASE
E35AELCDE 1986	GEARCASE
E35AELCUD 1987	GEARCASE
E35ARLCDE 1986	GEARCASE
E35ARLCUD 1987	GEARCASE
E40AELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ARLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ATLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ECDE 1986	GEARCASE
E40ECEC 1989	GEARCASE
E40ECOB 1985	GEARCASE
E40ECRM 1984	GEARCASE
E40ECUD 1987	GEARCASE
E40EEIA 1991	GEARCASE
E40EENJ 1992	GEARCASE
E40EENM 1992	GEARCASE
E40EEOD 1995	GEARCASE
E40EERE 1994	GEARCASE
E40EESR 1990	GEARCASE
E40EETB 1993	GEARCASE
E40ELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40ELCDE 1986	GEARCASE
E40ELCEC 1989	GEARCASE
E40ELCOB 1985	GEARCASE
E40ELCRM 1984	GEARCASE

E40ELCUD 1987	GEARCASE
E40ELECR 1998	GEARCASE
E40ELED S 1996	GEARCASE
E40ELEIA 1991	GEARCASE
E40ELENJ 1992	GEARCASE
E40ELENM 1992	GEARCASE
E40ELEOD 1995	GEARCASE
E40ELERE 1994	GEARCASE
E40ELESR 1990	GEARCASE
E40ELETB 1993	GEARCASE
E40ELEUC 1997	GEARCASE
E40RCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40RCDE 1986	GEARCASE
E40RCEC 1989	GEARCASE
E40RCOB 1985	GEARCASE
E40RCRM 1984	GEARCASE
E40RCUD 1987	GEARCASE
E40RECR 1998	GEARCASE
E40REDS 1996	GEARCASE
E40REIA 1991	GEARCASE
E40RENM 1992	GEARCASE
E40REOD 1995	GEARCASE
E40RERE 1994	GEARCASE
E40RESR 1990	GEARCASE
E40RET B 1993	GEARCASE
E40REUC 1997	GEARCASE
E40RLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40RLCDE 1986	GEARCASE
E40RLCEC 1989	GEARCASE
E40RLCOB 1985	GEARCASE
E40RLCRM 1984	GEARCASE
E40RLCUD 1987	GEARCASE
E40RLECR 1998	GEARCASE
E40RLED S 1996	GEARCASE
E40RLEIA 1991	GEARCASE

E40RLENM 1992	GEARCASE
E40RLEOD 1995	GEARCASE
E40RLERE 1994	GEARCASE
E40RLESR 1990	GEARCASE
E40RLETB 1993	GEARCASE
E40RLEUC 1997	GEARCASE
E40TECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TECDE 1986	GEARCASE
E40TECEC 1989	GEARCASE
E40TECOB 1985	GEARCASE
E40TECRM 1984	GEARCASE
E40TECUD 1987	GEARCASE
E40TEECR 1998	GEARCASE
E40TEEDS 1996	GEARCASE
E40TEEIA 1991	GEARCASE
E40TEENJ 1992	GEARCASE
E40TEENM 1992	GEARCASE
E40TEEOD 1995	GEARCASE
E40TEERE 1994	GEARCASE
E40TEESR 1990	GEARCASE
E40TEETB 1993	GEARCASE
E40TEEUC 1997	GEARCASE
E40TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TELCDE 1986	GEARCASE
E40TELCEC 1989	GEARCASE
E40TELCOB 1985	GEARCASE
E40TELCRM 1984	GEARCASE
E40TELECR 1998	GEARCASE
E40TELEDS 1996	GEARCASE
E40TELEIA 1991	GEARCASE
E40TELENJ 1992	GEARCASE
E40TELENM 1992	GEARCASE
E40TELEOD 1995	GEARCASE
E40TELERE 1994	GEARCASE
E40TELESR 1990	GEARCASE

E40TELETB 1993	GEARCASE
E40TELEUC 1997	GEARCASE
E40TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TLCDE 1986	GEARCASE
E40TLCEC 1989	GEARCASE
E40TLCUD 1987	GEARCASE
E40TLECR 1998	GEARCASE
E40TLEDS 1996	GEARCASE
E40TLEIA 1991	GEARCASE
E40TLENJ 1992	GEARCASE
E40TLENM 1992	GEARCASE
E40TLEOD 1995	GEARCASE
E40TLERE 1994	GEARCASE
E40TLESR 1990	GEARCASE
E40TLETB 1993	GEARCASE
E40TLETF 1993	GEARCASE
E40TEUC 1997	GEARCASE
E40TTLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E40TTLCEC 1989	GEARCASE
E40TTLECR 1998	GEARCASE
E40TTLEDS 1996	GEARCASE
E40TTLEIA 1991	GEARCASE
E40TTLENM 1992	GEARCASE
E40TTLEOD 1995	GEARCASE
E40TTLERE 1994	GEARCASE
E40TTLESR 1990	GEARCASE
E40TTLETB 1993	GEARCASE
E40TTLETF 1993	GEARCASE
E40TTLEUC 1997	GEARCASE
E48ESLCCC 1988	GEARCASE
E48ESLCER 1989	GEARCASE (CONTINUED)
E48ESLCUS 1987	GEARCASE
E48ESLEDC 1996	GEARCASE
E48ESLEIM 1991	GEARCASE
E48ESLENB 1992	GEARCASE

E48ESLEOS 1995	GEARCASE
E48ESLERD 1994	GEARCASE
E48ESLESA 1990	GEARCASE
E48ESLETE 1993	GEARCASE
E50BECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50BECDE 1986	GEARCASE
E50BECEC 1989	GEARCASE
E50BECIC 1981	GEARCASE, ELECTRIC START
E50BECNR 1982	GEARCASE
E50BECOB 1985	GEARCASE
E50BECRM 1984	GEARCASE
E50BECTA 1983	GEARCASE
E50BECUD 1987	GEARCASE
E50BEEIA 1991	GEARCASE
E50BEENJ 1992	GEARCASE
E50BEENM 1992	GEARCASE
E50BEEOD 1995	GEARCASE
E50BEERE 1994	GEARCASE
E50BEESR 1990	GEARCASE
E50BEETB 1993	GEARCASE
E50BELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50BELCDE 1986	GEARCASE
E50BELCEC 1989	GEARCASE
E50BELCIC 1981	GEARCASE, ELECTRIC START
E50BELCNR 1982	GEARCASE
E50BELCOB 1985	GEARCASE
E50BELCRM 1984	GEARCASE
E50BELCTA 1983	GEARCASE
E50BELCUD 1987	GEARCASE
E50BELEIA 1991	GEARCASE
E50BELENJ 1992	GEARCASE
E50BELENM 1992	GEARCASE
E50BELEOD 1995	GEARCASE
E50BELERE 1994	GEARCASE
E50BELESR 1990	GEARCASE



E50BELETB 1993	GEARCASE
E50ECSR 1980	GEARCASE
E50ELCSR 1980	GEARCASE
E50ESLECC 1998	GEARCASE
E50ESLEUR 1997	GEARCASE
E50JEDS 1996	GEARCASE
E50JEIA 1991	GEARCASE
E50JENJ 1992	GEARCASE
E50JENM 1992	GEARCASE
E50JEOD 1995	GEARCASE
E50JERE 1994	GEARCASE
E50JETB 1993	GEARCASE
E50JEUC 1997	GEARCASE
E50RNLIA 1990	GEARCASE
E50RNLIB 1992	GEARCASE
E50TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50TELCDE 1986	GEARCASE
E50TELCEC 1989	GEARCASE
E50TELCOB 1985	GEARCASE
E50TELCRM 1984	GEARCASE
E50TELCCTA 1983	GEARCASE
E50TELCUD 1987	GEARCASE
E50TELEIA 1991	GEARCASE
E50TELENM 1992	GEARCASE
E50TELEOD 1995	GEARCASE
E50TELERE 1994	GEARCASE
E50TELESR 1990	GEARCASE
E50TELETB 1993	GEARCASE
E50TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
E50TLCDE 1986	GEARCASE
E50TLCEC 1989	GEARCASE
E50TLCOB 1985	GEARCASE
E50TLCRM 1984	GEARCASE
E50TLCUD 1987	GEARCASE
E50TLECR 1998	GEARCASE

E50TLEDS 1996	GEARCASE
E50TLEIA 1991	GEARCASE
E50TLENJ 1992	GEARCASE
E50TLENM 1992	GEARCASE
E50TLEOD 1995	GEARCASE
E50TLERE 1994	GEARCASE
E50TLESR 1990	GEARCASE
E50TLETB 1993	GEARCASE
E50TLETF 1993	GEARCASE
E50TLEUC 1997	GEARCASE
E50TSLECC 1998	GEARCASE
E50TSLEUS 1997	GEARCASE
E55RCIM 1981	GEARCASE, ELECTRIC START
E55RLCSA 1980	GEARCASE, ELECTRIC START
E55TLCIM 1981	GEARCASE, ELECTRIC START
E60ECIA 1981	GEARCASE, ELECTRIC START
E60ECIH 1981	GEARCASE, ELECTRIC START
E60ECNM 1982	GEARCASE
E60ECSR 1980	GEARCASE, ELECTRIC START
E60ECTB 1983	GEARCASE
E60ELCDS 1986	GEARCASE - 15" TRANSOM
E60ELCIA 1981	GEARCASE, ELECTRIC START
E60ELCIH 1981	GEARCASE, ELECTRIC START
E60ELCNM 1982	GEARCASE
E60ELCOD 1985	GEARCASE
E60ELCRE 1984	GEARCASE
E60ELCSR 1980	GEARCASE, ELECTRIC START
E60ELCTB 1983	GEARCASE
E60ELCUC 1987	GEARCASE - 15" TRANSOM
E60TLCDS 1986	GEARCASE - 15" TRANSOM
E60TLCIA 1981	GEARCASE, ELECTRIC START
E60TLCIH 1981	GEARCASE, ELECTRIC START
E60TLCNM 1982	GEARCASE
E60TLCOD 1985	GEARCASE
E60TLCRE 1984	GEARCASE

E60TLCTB 1983	GEARCASE
E60TLCUC 1987	GEARCASE - 15" TRANSOM
E70ELCIH 1981	GEARCASE-15" TRANSOM
E70ELCIM 1981	GEARCASE-15" TRANSOM
E70ELCNB 1982	GEARCASE - 15" TRANSOM
E70ELCOS 1985	GEARCASE - 15" TRANSOM
E70ELCRD 1984	GEARCASE - 15" TRANSOM
E70ELCSA 1980	GEARCASE-15" TRANSOM
E70ELCTE 1983	GEARCASE-15" TRANSOM
E70TLCIM 1981	GEARCASE-15" TRANSOM
E70TLCNB 1982	GEARCASE - 15" TRANSOM
E70TLCOS 1985	GEARCASE - 15" TRANSOM
E70TLCRD 1984	GEARCASE - 15" TRANSOM
E70TLCTE 1983	GEARCASE-15" TRANSOM
E75ECCA 1988	GEARCASE
E75ECDC 1986	GEARCASE - 15" TRANSOM
E75ECOS 1985	GEARCASE - 15" TRANSOM
E75ECDR 1984	GEARCASE - 15" TRANSOM
E75ECUR 1987	GEARCASE - 15" TRANSOM
E75ELCRD 1984	GEARCASE - 15" TRANSOM
E75ERCIH 1981	GEARCASE-15" TRANSOM
E75ERCIM 1981	GEARCASE-15" TRANSOM
E75ERCNB 1982	GEARCASE - 15" TRANSOM
E75ERCSA 1980	GEARCASE-15" TRANSOM
E75ERCTE 1983	GEARCASE-15" TRANSOM
E75ERLCIH 1981	GEARCASE-15" TRANSOM
E75ERLCIM 1981	GEARCASE-15" TRANSOM
E75ERLCNB 1982	GEARCASE - 15" TRANSOM
E75ERLCSA 1980	GEARCASE-15" TRANSOM
E75ERLCTE 1983	GEARCASE-15" TRANSOM
E75TLCRD 1984	GEARCASE - 15" TRANSOM
E75TRLCIH 1981	GEARCASE-15" TRANSOM
E75TRLCIM 1981	GEARCASE-15" TRANSOM
E75TRLCNB 1982	GEARCASE - 15" TRANSOM
E75TRLCSA 1980	GEARCASE-15" TRANSOM

E75TRLCTE 1983	GEARCASE-15" TRANSOM
HE40REDS 1996	GEARCASE
HE40REUC 1997	GEARCASE
HE40RLEDS 1996	GEARCASE
HE40RLEUC 1997	GEARCASE
HJ40REDS 1996	GEARCASE
HJ40REUC 1997	GEARCASE
HJ40RLEDS 1996	GEARCASE
HJ40RLEUC 1997	GEARCASE
J35AELCDE 1986	GEARCASE
J35AELCUD 1987	GEARCASE
J35ARLCDE 1986	GEARCASE
J35ARLCUD 1987	GEARCASE
J40AELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ARLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ATLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ECDE 1986	GEARCASE
J40ECEC 1989	GEARCASE
J40ECOB 1985	GEARCASE
J40ECRM 1984	GEARCASE
J40ECUD 1987	GEARCASE
J40EEIA 1991	GEARCASE
J40EENJ 1992	GEARCASE
J40EENM 1992	GEARCASE
J40EEOD 1995	GEARCASE
J40EERE 1994	GEARCASE
J40EESR 1990	GEARCASE
J40EETB 1993	GEARCASE
J40ELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40ELCDE 1986	GEARCASE
J40ELCEC 1989	GEARCASE
J40ELCOB 1985	GEARCASE
J40ELCRM 1984	GEARCASE
J40ELCUD 1987	GEARCASE

J40ELECTR 1998	GEARCASE
J40ELED 1996	GEARCASE
J40ELEIA 1991	GEARCASE
J40ELENJ 1992	GEARCASE
J40ELENM 1992	GEARCASE
J40ELEOD 1995	GEARCASE
J40ELERE 1994	GEARCASE
J40ELESR 1990	GEARCASE
J40ELETB 1993	GEARCASE
J40ELEUC 1997	GEARCASE
J40PLEEA 1999	GEARCASE
J40PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J40PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J40PLSOC	GEARCASE
J40PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSRS	GEARCASE
J40PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40PLSSM Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J40PLSTD	GEARCASE
J40PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40RCDE 1986	GEARCASE
J40RCEC 1989	GEARCASE
J40RCOB 1985	GEARCASE
J40RCRM 1984	GEARCASE
J40RCUD 1987	GEARCASE
J40RECR 1998	GEARCASE
J40REDS 1996	GEARCASE
J40REEA 1999	GEARCASE
J40REIA 1991	GEARCASE
J40RENM 1992	GEARCASE
J40REOD 1995	GEARCASE
J40RERE 1994	GEARCASE
J40RESR 1990	GEARCASE

J40RETB 1993	GEARCASE
J40REUC 1997	GEARCASE
J40RLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40RLCDE 1986	GEARCASE
J40RLCEC 1989	GEARCASE
J40RLCOB 1985	GEARCASE
J40RLCRM 1984	GEARCASE
J40RLCUD 1987	GEARCASE
J40RLECR 1998	GEARCASE
J40RLEDS 1996	GEARCASE
J40RLEEA 1999	GEARCASE
J40RLEIA 1991	GEARCASE
J40RLENM 1992	GEARCASE
J40RLEOD 1995	GEARCASE
J40RLERE 1994	GEARCASE
J40RLESR 1990	GEARCASE
J40RLETB 1993	GEARCASE
J40RLEUC 1997	GEARCASE
J40RLSIF rope start, 20 in shaft 2001	GEARCASE
J40RLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSNF 20 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RLSOC	GEARCASE
J40RLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSRS	GEARCASE
J40RLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J40RLSSM Rope Start, Tiller, 20 IN. shaft 2000	GEARCASE
J40RLSTD	GEARCASE
J40RLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSIF rope start, 15 in shaft 2001	GEARCASE
J40RSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSNF 15 in. shaft, White, Tiller, Rope, Touch Trim 2002	GEARCASE
J40RSOC	GEARCASE
J40RSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J40RSRS	GEARCASE
J40RSRS - FR	27-1_BOÎTIER D'ENGRENAGES

J40RSSM Rope Start, Tiller, 15 IN. shaft 2000	GEARCASE
J40RSTD	GEARCASE
J40RSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J40TECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TECDE 1986	GEARCASE
J40TECEC 1989	GEARCASE
J40TECOB 1985	GEARCASE
J40TECRM 1984	GEARCASE
J40TECUD 1987	GEARCASE
J40TEECR 1998	GEARCASE
J40TEEDS 1996	GEARCASE
J40TEEIA 1991	GEARCASE
J40TEENJ 1992	GEARCASE
J40TEENM 1992	GEARCASE
J40TEEOD 1995	GEARCASE
J40TEERE 1994	GEARCASE
J40TEESR 1990	GEARCASE
J40TEETB 1993	GEARCASE
J40TEEUC 1997	GEARCASE
J40TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TELCDE 1986	GEARCASE
J40TELCEC 1989	GEARCASE
J40TELCOB 1985	GEARCASE
J40TELCRM 1984	GEARCASE
J40TELECR 1998	GEARCASE
J40TELEDS 1996	GEARCASE
J40TELEIA 1991	GEARCASE
J40TELENJ 1992	GEARCASE
J40TELENM 1992	GEARCASE
J40TELEOD 1995	GEARCASE
J40TELERE 1994	GEARCASE
J40TELESR 1990	GEARCASE
J40TELETB 1993	GEARCASE
J40TELEUC 1997	GEARCASE
J40TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT

J40TLCDE 1986	GEARCASE
J40TLCEC 1989	GEARCASE
J40TLCUD 1987	GEARCASE
J40TLECR 1998	GEARCASE
J40TLEDS 1996	GEARCASE
J40TLEIA 1991	GEARCASE
J40TLENJ 1992	GEARCASE
J40TLENM 1992	GEARCASE
J40TLEOD 1995	GEARCASE
J40TLERE 1994	GEARCASE
J40TLESR 1990	GEARCASE
J40TLETB 1993	GEARCASE
J40TLETF 1993	GEARCASE
J40TLEUC 1997	GEARCASE
J40TPLEEA 1999	GEARCASE
J40TPLSIF elec start, tiller, TNT, 20 in shaft 2001	GEARCASE
J40TPLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J40TTLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J40TTLCEC 1989	GEARCASE
J40TTLECR 1998	GEARCASE
J40TTLEDS 1996	GEARCASE
J40TTLEIA 1991	GEARCASE
J40TTLENM 1992	GEARCASE
J40TTLEOD 1995	GEARCASE
J40TTLERE 1994	GEARCASE
J40TTLESR 1990	GEARCASE
J40TTLETB 1993	GEARCASE
J40TTLETF 1993	GEARCASE
J40TTLEUC 1997	GEARCASE
J48ESLCCC 1988	GEARCASE
J48ESLCER 1989	GEARCASE (CONTINUED)
J48ESLCUS 1987	GEARCASE
J48ESLEDC 1996	GEARCASE
J48ESLEIM 1991	GEARCASE
J48ESLENB 1992	GEARCASE



J48ESLEOS 1995	GEARCASE
J48ESLERD 1994	GEARCASE
J48ESLESA 1990	GEARCASE
J48ESLETE 1993	GEARCASE
J50BECCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50BECDE 1986	GEARCASE
J50BECEC 1989	GEARCASE
J50BECIC 1981	GEARCASE, ELECTRIC START
J50BECNR 1982	GEARCASE
J50BECOB 1985	GEARCASE
J50BECRM 1984	GEARCASE
J50BECTA 1983	GEARCASE
J50BECUD 1987	GEARCASE
J50BEEIA 1991	GEARCASE
J50BEENJ 1992	GEARCASE
J50BEENM 1992	GEARCASE
J50BEEOD 1995	GEARCASE
J50BEERE 1994	GEARCASE
J50BEESR 1990	GEARCASE
J50BEETB 1993	GEARCASE
J50BELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50BELCDE 1986	GEARCASE
J50BELCEC 1989	GEARCASE
J50BELCIC 1981	GEARCASE, ELECTRIC START
J50BELCNR 1982	GEARCASE
J50BELCOB 1985	GEARCASE
J50BELCRM 1984	GEARCASE
J50BELCTA 1983	GEARCASE
J50BELCUD 1987	GEARCASE
J50BELEIA 1991	GEARCASE
J50BELENJ 1992	GEARCASE
J50BELENM 1992	GEARCASE
J50BELEOD 1995	GEARCASE
J50BELERE 1994	GEARCASE
J50BELESR 1990	GEARCASE

J50BELETB 1993	GEARCASE
J50ECSR 1980	GEARCASE
J50ELCSR 1980	GEARCASE
J50ELEER 1999	GEARCASE
J50ELSIF elec start, 20 in shaft 2001	GEARCASE
J50ELSSA Elec. Start, Tiller, 15 IN. shaft 2000	GEARCASE
J50ESLECC 1998	GEARCASE
J50ESLEUR 1997	GEARCASE
J50JEDS 1996	GEARCASE
J50JEIA 1991	GEARCASE
J50JENJ 1992	GEARCASE
J50JENM 1992	GEARCASE
J50JEOD 1995	GEARCASE
J50JERE 1994	GEARCASE
J50JETB 1993	GEARCASE
J50JEUC 1997	GEARCASE
J50PLEEA 1999	GEARCASE
J50PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J50PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSNF Oil Injection, 20 in., White, Remote, Elec, TNT, 2002	GEARCASE
J50PLSOC	GEARCASE
J50PLSOC - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSRS	GEARCASE
J50PLSRS - FR	27-1_BOÎTIER D'ENGRENAGES
J50PLSSM Elec. Start, TNT, Tiller, 20 IN. shaft 2000	GEARCASE
J50PLSTD	GEARCASE
J50PLSTD - FR	27-1_BOÎTIER D'ENGRENAGES
J50TELCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50TELCDE 1986	GEARCASE
J50TELCEC 1989	GEARCASE
J50TELCOB 1985	GEARCASE
J50TELCRM 1984	GEARCASE
J50TELCCTA 1983	GEARCASE
J50TELCUD 1987	GEARCASE
J50TELEIA 1991	GEARCASE

J50TELENM 1992	GEARCASE
J50TELEOD 1995	GEARCASE
J50TELERE 1994	GEARCASE
J50TELESR 1990	GEARCASE
J50TELETB 1993	GEARCASE
J50TLCCS 1988	GEARCASE-ALL MODELS EXCEPT 40AR, 40AE, 40AT
J50TLCDE 1986	GEARCASE
J50TLCEC 1989	GEARCASE
J50TLCOB 1985	GEARCASE
J50TLCRM 1984	GEARCASE
J50TLCUD 1987	GEARCASE
J50TLECR 1998	GEARCASE
J50TLEDS 1996	GEARCASE
J50TLEIA 1991	GEARCASE
J50TLENJ 1992	GEARCASE
J50TLENM 1992	GEARCASE
J50TELEOD 1995	GEARCASE
J50TLERE 1994	GEARCASE
J50TLESR 1990	GEARCASE
J50TLETB 1993	GEARCASE
J50TLETF 1993	GEARCASE
J50TLEUC 1997	GEARCASE
J50TSLECC 1998	GEARCASE
J50TSLEUS 1997	GEARCASE
J55RCIM 1981	GEARCASE, ELECTRIC START
J55RLCIM 1981	GEARCASE, ELECTRIC START
J55RLCSA 1980	GEARCASE,ELECTRIC START
J60ECIA 1981	GEARCASE, ELECTRIC START
J60ECIH 1981	GEARCASE, ELECTRIC START
J60ECNM 1982	GEARCASE
J60ECSR 1980	GEARCASE,ELECTRIC START
J60ECTB 1983	GEARCASE
J60ELCDS 1986	GEARCASE - 15" TRANSOM
J60ELCIA 1981	GEARCASE, ELECTRIC START
J60ELCIH 1981	GEARCASE, ELECTRIC START

J60ELCNM 1982	GEARCASE
J60ELCOD 1985	GEARCASE
J60ELCRE 1984	GEARCASE
J60ELCSR 1980	GEARCASE,ELECTRIC START
J60ELCTB 1983	GEARCASE
J60ELCUC 1987	GEARCASE - 15" TRANSOM
J60TLCDS 1986	GEARCASE - 15" TRANSOM
J60TLCIA 1981	GEARCASE, ELECTRIC START
J60TLCIH 1981	GEARCASE, ELECTRIC START
J60TLCNM 1982	GEARCASE
J60TLCOD 1985	GEARCASE
J60TLCRE 1984	GEARCASE
J60TLCTB 1983	GEARCASE
J60TLCUC 1987	GEARCASE - 15" TRANSOM
J70ELCIH 1981	GEARCASE-15" TRANSOM
J70ELCIM 1981	GEARCASE-15" TRANSOM
J70ELCNB 1982	GEARCASE - 15" TRANSOM
J70ELCOS 1985	GEARCASE - 15" TRANSOM
J70ELCRD 1984	GEARCASE - 15" TRANSOM
J70ELCSA 1980	GEARCASE-15" TRANSOM
J70ELCTE 1983	GEARCASE-15" TRANSOM
J70TLCIM 1981	GEARCASE-15" TRANSOM
J70TLCNB 1982	GEARCASE - 15" TRANSOM
J70TLCOS 1985	GEARCASE - 15" TRANSOM
J70TLCRD 1984	GEARCASE - 15" TRANSOM
J70TLCTE 1983	GEARCASE-15" TRANSOM
J75ECCA 1988	GEARCASE
J75ECDC 1986	GEARCASE - 15" TRANSOM
J75ECNB 1982	GEARCASE - 15" TRANSOM
J75ECOS 1985	GEARCASE - 15" TRANSOM
J75ECDR 1984	GEARCASE - 15" TRANSOM
J75ECTE 1983	GEARCASE-15" TRANSOM
J75ECUR 1987	GEARCASE - 15" TRANSOM
J75ELCNB 1982	GEARCASE - 15" TRANSOM
J75ELCRD 1984	GEARCASE - 15" TRANSOM

J75ELCTE 1983	GEARCASE-15" TRANSOM
J75ERCIH 1981	GEARCASE-15" TRANSOM
J75ERCIM 1981	GEARCASE-15" TRANSOM
J75ERCSA 1980	GEARCASE-15" TRANSOM
J75ERLCIH 1981	GEARCASE-15" TRANSOM
J75ERLCIM 1981	GEARCASE-15" TRANSOM
J75ERLCSA 1980	GEARCASE-15" TRANSOM
J75TELCIM 1981	GEARCASE-15" TRANSOM
J75TLCNB 1982	GEARCASE - 15" TRANSOM
J75TLCRD 1984	GEARCASE - 15" TRANSOM
J75TLCTE 1983	GEARCASE-15" TRANSOM
J75TRLCIH 1981	GEARCASE-15" TRANSOM
J75TRLCSA 1980	GEARCASE-15" TRANSOM
RJ50ELSIF elec start, TNT, 20 in shaft 2001	GEARCASE
SE40RSLD 1997	GEARCASE
SE40RSLR 1998	GEARCASE
SE40RSLZ 1996	GEARCASE
SE50TLEDS 1996	GEARCASE
SJ40EEDS 1996	GEARCASE
SJ40REDS 1996	GEARCASE
SJ40RLEDS 1996	GEARCASE
SJ40RSLD 1997	GEARCASE
SJ40RSLR 1998	GEARCASE
SJ40RSLZ 1996	GEARCASE
TE40ELCEC 1989	GEARCASE
TE40ELEIA 1991	GEARCASE
TE40ELENJ 1992	GEARCASE
TE40ELENM 1992	GEARCASE
TE40ELESR 1990	GEARCASE
TE40ELETB 1993	GEARCASE
TE40TELESF 1990	GEARCASE
TE40TELESR 1990	GEARCASE
TE48ESLETE 1993	GEARCASE
TE50TLCEC 1989	GEARCASE
TE50TLESF 1989	GEARCASE

TE50TLESF 1990	GEARCASE
TE50TLESR 1990	GEARCASE
TJ40ELCEC 1989	GEARCASE
TJ40ELEIA 1991	GEARCASE
TJ40ELENJ 1992	GEARCASE
TJ40ELENM 1992	GEARCASE
TJ40ELESF 1990	GEARCASE
TJ40ELESR 1990	GEARCASE
TJ40ELETB 1993	GEARCASE
TJ40TELESF 1990	GEARCASE
TJ40TELESR 1990	GEARCASE
TJ48ESLETE 1993	GEARCASE
TJ50TLCEC 1989	GEARCASE
TJ50TLESF 1989	GEARCASE
TJ50TLESF 1990	GEARCASE
TJ50TLESR 1990	GEARCASE
VE40EEIA 1991	GEARCASE
VE40EENJ 1992	GEARCASE
VE40EENM 1992	GEARCASE
VE40EESR 1990	GEARCASE
VE40EETB 1993	GEARCASE
VE40ELEIA 1991	GEARCASE
VE40ELENJ 1992	GEARCASE
VE40ELENM 1992	GEARCASE
VE40ELESR 1990	GEARCASE
VE40ELETB 1993	GEARCASE
VE40TELEIA 1991	GEARCASE
VE40TELENJ 1992	GEARCASE
VE40TELENM 1992	GEARCASE
VE40TELESR 1990	GEARCASE
VE40TELETB 1993	GEARCASE
VE40TLEIA 1991	GEARCASE
VE40TLENJ 1992	GEARCASE
VE40TLENM 1992	GEARCASE
VE40TLESR 1990	GEARCASE

VE40TLETB 1993	GEARCASE
VE40TLETF 1993	GEARCASE
VE48ESLCCC 1988	GEARCASE
VE48ESLCER 1989	GEARCASE (CONTINUED)
VE48ESLENB 1992	GEARCASE
VE48ESLESA 1990	GEARCASE
VE48ESLETE 1993	GEARCASE
VE50BEEIA 1991	GEARCASE
VE50BEENJ 1992	GEARCASE
VE50BEENM 1992	GEARCASE
VE50BEESR 1990	GEARCASE
VE50BEETB 1993	GEARCASE
VE50BELEIA 1991	GEARCASE
VE50BELENJ 1992	GEARCASE
VE50BELENM 1992	GEARCASE
VE50BELESR 1990	GEARCASE
VE50BELETB 1993	GEARCASE
VE50TELENM 1992	GEARCASE
VE50TLEIA 1991	GEARCASE
VE50TLENJ 1992	GEARCASE
VE50TLENM 1992	GEARCASE
VE50TLESR 1990	GEARCASE
VE50TLETB 1993	GEARCASE
VE50TLETF 1993	GEARCASE
VJ40EEIA 1991	GEARCASE
VJ40EENJ 1992	GEARCASE
VJ40EENM 1992	GEARCASE
VJ40EESR 1990	GEARCASE
VJ40EETB 1993	GEARCASE
VJ40ELEIA 1991	GEARCASE
VJ40ELENJ 1992	GEARCASE
VJ40ELENM 1992	GEARCASE
VJ40ELESR 1990	GEARCASE
VJ40ELETB 1993	GEARCASE
VJ40TELEIA 1991	GEARCASE

VJ40TELENJ 1992	GEARCASE
VJ40TELENM 1992	GEARCASE
VJ40TELESR 1990	GEARCASE
VJ40TELETB 1993	GEARCASE
VJ40TLEIA 1991	GEARCASE
VJ40TLENJ 1992	GEARCASE
VJ40TLENM 1992	GEARCASE
VJ40TLESR 1990	GEARCASE
VJ40TLETB 1993	GEARCASE
VJ40TLETF 1993	GEARCASE
VJ48ESLCCC 1988	GEARCASE
VJ48ESLCER 1989	GEARCASE (CONTINUED)
VJ48ESLENB 1992	GEARCASE
VJ48ESLESA 1990	GEARCASE
VJ48ESLETE 1993	GEARCASE
VJ50BEEIA 1991	GEARCASE
VJ50BEENJ 1992	GEARCASE
VJ50BEENM 1992	GEARCASE
VJ50BEESR 1990	GEARCASE
VJ50BEETB 1993	GEARCASE
VJ50BELEIA 1991	GEARCASE
VJ50BELENJ 1992	GEARCASE
VJ50BELENM 1992	GEARCASE
VJ50BELESR 1990	GEARCASE
VJ50BELETB 1993	GEARCASE
VJ50TELENM 1992	GEARCASE
VJ50TLEIA 1991	GEARCASE
VJ50TLENJ 1992	GEARCASE
VJ50TLENM 1992	GEARCASE
VJ50TLESR 1990	GEARCASE
VJ50TLETB 1993	GEARCASE
VJ50TLETF 1993	GEARCASE
X50ESLECC 1998	GEARCASE