

Where Used: Part Number 0388685

Model Name	Diagram
6704M 1977	FUEL PUMP
6705M 1977	FUEL PUMP
6804B 1978	FUEL PUMP
6805B 1978	FUEL PUMP
6904E 1979	FUEL PUMP
6905E 1979	FUEL PUMP
6R77M 1977	FUEL PUMP
6R78B 1978	FUEL PUMP
6R79E 1979	FUEL PUMP
6RL77M 1977	FUEL PUMP
6RL78B 1978	FUEL PUMP
6RL79E 1979	FUEL PUMP
E5RCIC 1981	FUEL PUMP
E5RCSS 1980	FUEL PUMP
E5RHCIC 1981	FUEL PUMP
E5RHCNR 1982	FUEL PUMP
E5RHCSS 1980	FUEL PUMP
E5RHCTA 1983	FUEL PUMP
E5RHLCIC 1981	FUEL PUMP
E5RHLCNR 1982	FUEL PUMP
E5RHLCSS 1980	FUEL PUMP
E5RHLCTA 1983	FUEL PUMP
E5RLCIC 1981	FUEL PUMP
E5RLCSS 1980	FUEL PUMP
E8RCIC 1981	FUEL PUMP
E8RCNR 1982	FUEL PUMP
E8RCSS 1980	FUEL PUMP
E8RCTA 1983	FUEL PUMP
E8RLCIC 1981	FUEL PUMP
E8RLCNR 1982	FUEL PUMP
E8RLCSS 1980	FUEL PUMP
E8RLCTA 1983	FUEL PUMP
E8SRLCNR 1982	FUEL PUMP

E8SRLCTA 1983	FUEL PUMP
J5RCIC 1981	FUEL PUMP
J5RCSS 1980	FUEL PUMP
J5RHCIC 1981	FUEL PUMP
J5RHCNR 1982	FUEL PUMP
J5RHCSS 1980	FUEL PUMP
J5RHCTA 1983	FUEL PUMP
J5RHLCIC 1981	FUEL PUMP
J5RHLCNR 1982	FUEL PUMP
J5RHLCSS 1980	FUEL PUMP
J5RHLCTA 1983	FUEL PUMP
J5RLCIC 1981	FUEL PUMP
J5RLCSS 1980	FUEL PUMP
J8RCIC 1981	FUEL PUMP
J8RCNR 1982	FUEL PUMP
J8RCSS 1980	FUEL PUMP
J8RCTA 1983	FUEL PUMP
J8RLCIC 1981	FUEL PUMP
J8RLCNR 1982	FUEL PUMP
J8RLCSS 1980	FUEL PUMP
J8RLCTA 1983	FUEL PUMP
J8SRLCNR 1982	FUEL PUMP
J8SRLCTA 1983	FUEL PUMP