

Where Used: Part Number 0389042

Model Name	Diagram
150840S 1978	GEARCASE
150849S 1978	GEARCASE
150940C 1979	GEARCASE
150949C 1979	GEARCASE
150SHLERC 1994	GEARCASE - COUNTER ROTATION
150SHLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
150SHLERC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
150SLERC 1994	GEARCASE - COUNTER ROTATION
150SLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
150SLERC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
150TL78S 1978	GEARCASE
150TL79C 1979	GEARCASE
150TXL78S 1978	GEARCASE
150TXL79C 1979	GEARCASE
170SPMCCIF 1981	LOWER GEARCASE GROUP
170SPMCCIS 1981	LOWER GEARCASE GROUP
170SPMRCIF 1981	LOWER GEARCASE GROUP
170SPMRCIS 1981	LOWER GEARCASE GROUP
170STMCCIF 1981	LOWER GEARCASE GROUP
170STMCCIS 1981	LOWER GEARCASE GROUP
170STMRCIF 1981	LOWER GEARCASE GROUP
170STMRCIS 1981	LOWER GEARCASE GROUP
175840C 1978	GEARCASE
175840S 1978	GEARCASE
175940R 1979	GEARCASE
175949R 1979	GEARCASE
175TL78C 1978	GEARCASE
175TL79R 1979	GEARCASE
175TX78C 1978	GEARCASE
175TXL79R 1979	GEARCASE
200490A 1979	GEARCASE
200840R 1978	GEARCASE

200849R 1978	GEARCASE
200940A 1979	GEARCASE
200949A 1979	GEARCASE
200FTHRCIF 1981	LOWER GEARCASE GROUP
200FTHRCIS 1981	LOWER GEARCASE GROUP
200SPHRCIF 1981	LOWER GEARCASE GROUP
200SPHRCIS 1981	LOWER GEARCASE GROUP
200STHRCIF 1981	LOWER GEARCASE GROUP
200STHRCIS 1981	LOWER GEARCASE GROUP
200TL78R 1978	GEARCASE
200TL79A 1979	GEARCASE
200TX78R 1978	GEARCASE
200TXL79A 1979	GEARCASE
230FTHRCIF 1981	LOWER GEARCASE GROUP
230FTHRCIS 1981	LOWER GEARCASE GROUP
230SPHRCIF 1981	LOWER GEARCASE GROUP
230SPHRCIS 1981	LOWER GEARCASE GROUP
230STHRCIF 1981	LOWER GEARCASE GROUP
230STHRCIS 1981	LOWER GEARCASE GROUP
235840R 1978	GEARCASE
235849R 1978	GEARCASE
235940A 1979	GEARCASE
235949A 1979	GEARCASE
235TL70A 1979	GEARCASE
235TL78R 1978	GEARCASE
235TX78R 1978	GEARCASE
235TXL79A 1979	GEARCASE
260FTHRCIF 1981	LOWER GEARCASE GROUP
260FTHRCIS 1981	LOWER GEARCASE GROUP
260SPHRCIF 1981	LOWER GEARCASE GROUP
260SPHRCIS 1981	LOWER GEARCASE GROUP
260STHRCIF 1981	LOWER GEARCASE GROUP
260STHRCIS 1981	LOWER GEARCASE GROUP
262AMLMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
262AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION

262APRMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
262APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302AMRPWC 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302APRPWC 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRPWR 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302BMRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BMRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302BMRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
302BPRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BPRPWR 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302BPRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302BPRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302CMLPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMLPWR 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302CMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMLPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302CMRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRPWR 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302CMRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CMRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302CMRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
302CPRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRPWR 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRPWR 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
302CPRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
302CPRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION

302CPRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
350AMLMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
350AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
350APRMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
350APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
382FTMRCOM 1985	LOWER GEARCASE GROUP
382FTMRCRA 1984	LOWER GEARCASE GROUP
382FTMRCRJ 1984	LOWER GEARCASE GROUP
382FTMRCTR 1983	LOWER GEARCASE GROUP
382SPMCCNC 1982	LOWER GEARCASE GROUP
382SPMCCTR 1983	LOWER GEARCASE GROUP
382SPMRCNC 1982	LOWER GEARCASE GROUP
382SPMRCOM 1985	LOWER GEARCASE GROUP
382SPMRCRA 1984	LOWER GEARCASE GROUP
382SPMRCRJ 1984	LOWER GEARCASE GROUP
382SPMRCTR 1983	LOWER GEARCASE GROUP
382STMCCNC 1982	LOWER GEARCASE GROUP
382STMCCTR 1983	LOWER GEARCASE GROUP
382STMRCNC 1982	LOWER GEARCASE GROUP
382STMRCOM 1985	LOWER GEARCASE GROUP
382STMRCTR 1983	LOWER GEARCASE GROUP
384FTMRCOM 1985	LOWER GEARCASE GROUP
384FTMRCRA 1984	LOWER GEARCASE GROUP
384FTMRCRJ 1984	LOWER GEARCASE GROUP
384FTMRCTR 1983	LOWER GEARCASE GROUP
384SPMCCNC 1982	LOWER GEARCASE GROUP
384SPMCCTR 1983	LOWER GEARCASE GROUP
384SPMRCNC 1982	LOWER GEARCASE GROUP
384SPMRCOM 1985	LOWER GEARCASE GROUP
384SPMRCRA 1984	LOWER GEARCASE GROUP
384SPMRCRJ 1984	LOWER GEARCASE GROUP
384SPMRCTR 1983	LOWER GEARCASE GROUP
384STMCCNC 1982	LOWER GEARCASE GROUP
384STMCCTR 1983	LOWER GEARCASE GROUP
384STMRCNC 1982	LOWER GEARCASE GROUP

384STMRCOM 1985	LOWER GEARCASE GROUP
384STMRCRA 1984	LOWER GEARCASE GROUP
384STMRCRJ 1984	LOWER GEARCASE GROUP
384STMRCTR 1983	LOWER GEARCASE GROUP
384STNRCNC 1982	LOWER GEARCASE GROUP
432AMARY 1987	LOWER GEARCASE
432AMFTC 1987	LOWER GEARCASE
432AMKWB 1986	LOWER GEARCASE
432AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432AMLGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432AMLMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
432AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432AMLPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432AMWXS 1986	LOWER GEARCASE
432APARY 1987	LOWER GEARCASE
432APFTC 1987	LOWER GEARCASE
432APKWB 1986	LOWER GEARCASE
432APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APLAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APLJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APLJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APLRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
432APLRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
432APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRGDE 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRGDE 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION

432APRJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
432APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
432APRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
432APRRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
432APRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
432APSRC 1987	LOWER GEARCASE
432APSRV 1987	LOWER GEARCASE
432APWXS 1986	LOWER GEARCASE
432FTMRCOM 1985	LOWER GEARCASE GROUP
432SPMRCOM 1985	LOWER GEARCASE GROUP
432STMRCOM 1985	LOWER GEARCASE GROUP
434AMARY 1987	LOWER GEARCASE
434AMFTC 1987	LOWER GEARCASE
434AMKWB 1986	LOWER GEARCASE
434AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434AMLGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434AMLPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434AMWXS 1986	LOWER GEARCASE
434APARY 1987	LOWER GEARCASE
434APFTC 1987	LOWER GEARCASE
434APKWB 1986	LOWER GEARCASE
434APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APLAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APLJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APLJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APLRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
434APLRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
434APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION

434APRGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APRJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
434APRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
434APRRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
434APRRGD 1991	LOWER GEARCASE-STANDARD (R.H.) ROTATION
434APSRC 1987	LOWER GEARCASE
434APSRV 1987	LOWER GEARCASE
434APWXS 1986	LOWER GEARCASE
434FTMRCOM 1985	LOWER GEARCASE GROUP
434SPMRCOM 1985	LOWER GEARCASE GROUP
434STMRCOM 1985	LOWER GEARCASE GROUP
502AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502AMLGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502AMLMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
502AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502AMLPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APLAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APLAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APLAMK 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APLRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
502APLRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRAMK 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION

502APRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APRMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
502APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502APRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502APRRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
502APRRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502BPRAMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRAMK 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502BPRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502BPRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502BPRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
502BPRRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
502FTHRCOK 1985	LOWER GEARCASE GROUP
502FTHRCOM 1985	LOWER GEARCASE GROUP
502FTHRCRA 1984	LOWER GEARCASE GROUP
502FTHRCTR 1983	LOWER GEARCASE GROUP
502SPHCCNC 1982	LOWER GEARCASE GROUP
502SPHCCNG 1982	LOWER GEARCASE GROUP
502SPHCCTR 1983	LOWER GEARCASE GROUP
502SPHRCNC 1982	LOWER GEARCASE GROUP
502SPHRCNG 1982	LOWER GEARCASE GROUP
502SPHRCOK 1985	LOWER GEARCASE GROUP
502SPHRCOM 1985	LOWER GEARCASE GROUP
502SPHRCRA 1984	LOWER GEARCASE GROUP
502SPHRCTR 1983	LOWER GEARCASE GROUP
502SPMCCNC 1982	LOWER GEARCASE GROUP
502SPMCCNG 1982	LOWER GEARCASE GROUP
502SPMCCTR 1983	LOWER GEARCASE GROUP
502SPMRCNC 1982	LOWER GEARCASE GROUP

502SPMRCNG 1982	LOWER GEARCASE GROUP
502SPMRCTR 1983	LOWER GEARCASE GROUP
502SPNCCNC 1982	LOWER GEARCASE GROUP
502SPNRCNC 1982	LOWER GEARCASE GROUP
502SPNRCNG 1982	LOWER GEARCASE GROUP
502STHCCNC 1982	LOWER GEARCASE GROUP
502STHCCNG 1982	LOWER GEARCASE GROUP
502STHCCTR 1983	LOWER GEARCASE GROUP
502STHRCNC 1982	LOWER GEARCASE GROUP
502STHRCNG 1982	LOWER GEARCASE GROUP
502STHRCOK 1985	LOWER GEARCASE GROUP
502STHRCOM 1985	LOWER GEARCASE GROUP
502STHRCRA 1984	LOWER GEARCASE GROUP
502STHRCTR 1983	LOWER GEARCASE GROUP
502STMCCNC 1982	LOWER GEARCASE GROUP
502STMCCNG 1982	LOWER GEARCASE GROUP
502STMCCR 1983	LOWER GEARCASE GROUP
502STMRCNC 1982	LOWER GEARCASE GROUP
502STMRCNG 1982	LOWER GEARCASE GROUP
502STMRCTR 1983	LOWER GEARCASE GROUP
504AMARY 1987	LOWER GEARCASE
504AMFTC 1987	LOWER GEARCASE
504AMKWB 1986	LOWER GEARCASE
504AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
504AMLGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
504AMWXS 1986	LOWER GEARCASE
504APARY 1987	LOWER GEARCASE
504APFTC 1987	LOWER GEARCASE
504APKWB 1986	LOWER GEARCASE
504APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
504APRGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
504APWXS 1986	LOWER GEARCASE
504FTHRCOK 1985	LOWER GEARCASE GROUP
504FTHRCOM 1985	LOWER GEARCASE GROUP
504FTHRCRA 1984	LOWER GEARCASE GROUP

504FTHRCTR 1983	LOWER GEARCASE GROUP
504SPHCNC 1982	LOWER GEARCASE GROUP
504SPHCNG 1982	LOWER GEARCASE GROUP
504SPHCCTR 1983	LOWER GEARCASE GROUP
504SPHCNC 1982	LOWER GEARCASE GROUP
504SPHCNG 1982	LOWER GEARCASE GROUP
504SPHCOK 1985	LOWER GEARCASE GROUP
504SPHRCOM 1985	LOWER GEARCASE GROUP
504SPHCRA 1984	LOWER GEARCASE GROUP
504SPHRCTR 1983	LOWER GEARCASE GROUP
504SPMCCNC 1982	LOWER GEARCASE GROUP
504SPMCCNG 1982	LOWER GEARCASE GROUP
504SPMCCTR 1983	LOWER GEARCASE GROUP
504SPMRCNC 1982	LOWER GEARCASE GROUP
504SPMRCNG 1982	LOWER GEARCASE GROUP
504SPMRCTR 1983	LOWER GEARCASE GROUP
504STHCCNC 1982	LOWER GEARCASE GROUP
504STHCCNG 1982	LOWER GEARCASE GROUP
504STHCCTR 1983	LOWER GEARCASE GROUP
504STHCNC 1982	LOWER GEARCASE GROUP
504STHCNG 1982	LOWER GEARCASE GROUP
504STHCOK 1985	LOWER GEARCASE GROUP
504STHRCOM 1985	LOWER GEARCASE GROUP
504STHCRA 1984	LOWER GEARCASE GROUP
504STHRCTR 1983	LOWER GEARCASE GROUP
504STMCCNG 1982	LOWER GEARCASE GROUP
504STMCCR 1983	LOWER GEARCASE GROUP
504STMRCNC 1982	LOWER GEARCASE GROUP
504STMRCNG 1982	LOWER GEARCASE GROUP
504STMRCTR 1983	LOWER GEARCASE GROUP
504STNCCNC 1982	LOWER GEARCASE GROUP
50FAPLJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
50FAPLJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
50FAPLJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
50FAPLJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION

50FAPRJVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
50FAPRJVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
50FAPRJVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
50FAPRJVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574AMFTC 1987	LOWER GEARCASE
574AMKWB 1986	LOWER GEARCASE
574AMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574AMLGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574AMLMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
574AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574AMLPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574AMLPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574AMWXS 1986	LOWER GEARCASE
574APARY 1987	LOWER GEARCASE
574APFTC 1987	LOWER GEARCASE
574APKWB 1986	LOWER GEARCASE
574APLAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APLAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574APLRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
574APLRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRAMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRAMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574APRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574APRMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
574APRMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRPWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APRPWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574APRRGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
574APRRGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574APSRC 1987	LOWER GEARCASE
574APWXS 1986	LOWER GEARCASE
574BMLGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION
574BMLGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574BPRGDP 1988	LOWER GEARCASE - STANDARD (R.H.) ROTATION

574BPRGDP 1988	LOWER GEARCASE - COUNTER (L.H.) ROTATION
574FTHRCOK 1985	LOWER GEARCASE GROUP
574FTHRCOM 1985	LOWER GEARCASE GROUP
574FTHRCRA 1984	LOWER GEARCASE GROUP
574SPHCCNC 1982	LOWER GEARCASE GROUP
574SPHCCNG 1982	LOWER GEARCASE GROUP
574SPHCCTR 1983	LOWER GEARCASE GROUP
574SPHRCNC 1982	LOWER GEARCASE GROUP
574SPHRCNG 1982	LOWER GEARCASE GROUP
574SPHRCOK 1985	LOWER GEARCASE GROUP
574SPHRCOM 1985	LOWER GEARCASE GROUP
574SPHRCRA 1984	LOWER GEARCASE GROUP
574SPHRCTR 1983	LOWER GEARCASE GROUP
574SPMCCNC 1982	LOWER GEARCASE GROUP
574SPMCCNG 1982	LOWER GEARCASE GROUP
574SPMCCTR 1983	LOWER GEARCASE GROUP
574SPMRCNC 1982	LOWER GEARCASE GROUP
574SPMRCNG 1982	LOWER GEARCASE GROUP
574SPMRCTR 1983	LOWER GEARCASE GROUP
574STHCCNC 1982	LOWER GEARCASE GROUP
574STHCCNG 1982	LOWER GEARCASE GROUP
574STHCCTR 1983	LOWER GEARCASE GROUP
574STHRCNC 1982	LOWER GEARCASE GROUP
574STHRCNG 1982	LOWER GEARCASE GROUP
574STHRCOK 1985	LOWER GEARCASE GROUP
574STHRCOM 1985	LOWER GEARCASE GROUP
574STHRCRA 1984	LOWER GEARCASE GROUP
574STHRCTR 1983	LOWER GEARCASE GROUP
574STMCCNC 1982	LOWER GEARCASE GROUP
574STMCCNG 1982	LOWER GEARCASE GROUP
574STMCCR 1983	LOWER GEARCASE GROUP
574STMRCMC 1982	LOWER GEARCASE GROUP
574STMRCMG 1982	LOWER GEARCASE GROUP
574STMRCNC 1982	LOWER GEARCASE GROUP
574STMRCNG 1982	LOWER GEARCASE GROUP

574STMRCTR 1983	LOWER GEARCASE GROUP
584AMLMED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
584AMLMED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584AML PWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584AML PWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APL AMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APL AMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APL AMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APL AMK 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APL JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APL JVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APL RGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
584APL RGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR AMH 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR AMH 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APR AMK 1992	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR AMK 1992	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APR JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR JVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APR MED 1989	LOWER GEARCASE-COUNTER (L.H.) ROTATION
584APR MED 1989	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR PWS 1990	LOWER GEARCASE - STANDARD (R.H.) ROTATION
584APR PWS 1990	LOWER GEARCASE - COUNTER (L.H.) ROTATION
584APR RGD 1991	LOWER GEARCASE-COUNTER (L.H.) ROTATION
584APR RGD 1991	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPL JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPL JVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
58FAPL JVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPL JVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
58FAPR JVB 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPR JVB 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
58FAPR JVN 1993	LOWER GEARCASE - STANDARD (R.H.) ROTATION
58FAPR JVN 1993	LOWER GEARCASE - COUNTER (L.H.) ROTATION
990250D 1978	LOWER GEARCASE GROUP
990250H 1978	LOWER GEARCASE GROUP

990250J 1978	LOWER GEARCASE GROUP
990250N 1978	LOWER GEARCASE GROUP
990250P 1978	LOWER GEARCASE GROUP
990250U 1978	LOWER GEARCASE GROUP
990251D 1978	LOWER GEARCASE GROUP
990251H 1978	LOWER GEARCASE GROUP
990251J 1978	LOWER GEARCASE GROUP
990251N 1978	LOWER GEARCASE GROUP
990251S 1979	LOWER GEARCASE GROUP
990251U 1978	LOWER GEARCASE GROUP
990252C 1980	LOWER GEARCASE GROUP
990252D 1978	LOWER GEARCASE GROUP
990252H 1978	LOWER GEARCASE GROUP
990252J 1978	LOWER GEARCASE GROUP
990252K 1980	LOWER GEARCASE GROUP
990252S 1979	LOWER GEARCASE GROUP
990252S1 1979	LOWER GEARCASE GROUP
990253C 1980	LOWER GEARCASE GROUP
990253D 1978	LOWER GEARCASE GROUP
990253H 1978	LOWER GEARCASE GROUP
990253J 1978	LOWER GEARCASE GROUP
990253K 1980	LOWER GEARCASE GROUP
990253S 1979	LOWER GEARCASE GROUP
990253S1 1979	LOWER GEARCASE GROUP
990254C 1980	LOWER GEARCASE GROUP
990254D 1978	LOWER GEARCASE GROUP
990254H 1978	LOWER GEARCASE GROUP
990254J 1978	LOWER GEARCASE GROUP
990254K 1980	LOWER GEARCASE GROUP
990254S 1979	LOWER GEARCASE GROUP
990254S1 1979	LOWER GEARCASE GROUP
990254V 1979	LOWER GEARCASE GROUP
990255C 1980	LOWER GEARCASE GROUP
990255D 1978	LOWER GEARCASE GROUP
990255H 1978	LOWER GEARCASE GROUP

990255J 1978	LOWER GEARCASE GROUP
990255K 1980	LOWER GEARCASE GROUP
990255S 1979	LOWER GEARCASE GROUP
990255S1 1979	LOWER GEARCASE GROUP
990255V 1979	LOWER GEARCASE GROUP
990256C 1980	LOWER GEARCASE GROUP
990256K 1980	LOWER GEARCASE GROUP
990256S 1979	LOWER GEARCASE GROUP
990256S1 1979	LOWER GEARCASE GROUP
990257C 1980	LOWER GEARCASE GROUP
990257K 1980	LOWER GEARCASE GROUP
990257S 1979	LOWER GEARCASE GROUP
990257S1 1979	LOWER GEARCASE GROUP
990260C 1980	LOWER GEARCASE GROUP
990260K 1980	LOWER GEARCASE GROUP
990260S 1979	LOWER GEARCASE GROUP
990260S1 1979	LOWER GEARCASE GROUP
990260U 1980	LOWER GEARCASE GROUP
990261C 1980	LOWER GEARCASE GROUP
990261K 1980	LOWER GEARCASE GROUP
990261S 1979	LOWER GEARCASE GROUP
990261S1 1979	LOWER GEARCASE GROUP
990261U 1980	LOWER GEARCASE GROUP
990262C 1980	LOWER GEARCASE GROUP
990262K 1980	LOWER GEARCASE GROUP
990262S 1979	LOWER GEARCASE GROUP
990262S1 1979	LOWER GEARCASE GROUP
990262U 1980	LOWER GEARCASE GROUP
990266C 1980	LOWER GEARCASE GROUP
990266K 1980	LOWER GEARCASE GROUP
990266S 1979	LOWER GEARCASE GROUP
990266S1 1979	LOWER GEARCASE GROUP
990267C 1980	LOWER GEARCASE GROUP
990267K 1980	LOWER GEARCASE GROUP
990267S 1979	LOWER GEARCASE GROUP

A250ZCAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A250ZCAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A250ZCAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A250ZCAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A250ZCAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A250ZCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
A300XCUAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300XCUAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300XCUAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300XCUAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300XCUAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300XCUAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300XCUAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300XCUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
A300XUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
A300ZCUAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300ZCUAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300ZCUAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300ZCUAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300ZCUAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300ZCUAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
A300ZCUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
A300ZUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
BE115LEDR 1996	GEARCASE - 25 IN. MODELS
BE115LEUA 1997	GEARCASE - 25 IN. MODELS
BE115LEUC 1997	GEARCASE - 25 IN. MODELS
BE115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE115GLEDR 1996	GEARCASE - 25 IN. MODELS
BE115GLEUA 1997	GEARCASE - 25 IN. MODELS
BE115GLEUC 1997	GEARCASE - 25 IN. MODELS
BE115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE115SXEDR 1996	GEARCASE - 25 IN. MODELS
BE115SXEUA 1997	GEARCASE - 25 IN. MODELS
BE115SXEUC 1997	GEARCASE - 25 IN. MODELS

BE130TLECE 1998	GEARCASE
BE130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
BE130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
BE150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150ELECD 1998	GEARCASE -- COUNTER-ROTATION
BE150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150ELEDB 1996	GEARCASE - COUNTER-ROTATION
BE150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUC 1997	GEARCASE - COUNTER-ROTATION
BE150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150ELEUE 1997	GEARCASE - COUNTER-ROTATION
BE150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150EXECD 1998	GEARCASE -- COUNTER-ROTATION
BE150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150EXEDB 1996	GEARCASE - COUNTER-ROTATION
BE150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150EXEUC 1997	GEARCASE - COUNTER-ROTATION
BE150EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150EXEUE 1997	GEARCASE - COUNTER-ROTATION
BE150EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150GLECD 1998	GEARCASE -- COUNTER-ROTATION
BE150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150GLEDB 1996	GEARCASE - COUNTER-ROTATION
BE150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS

BE150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUC 1997	GEARCASE - COUNTER-ROTATION
BE150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150GLEUE 1997	GEARCASE - COUNTER-ROTATION
BE150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE150NXECD 1998	GEARCASE -- COUNTER-ROTATION
BE150NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE150NXEDB 1996	GEARCASE - COUNTER-ROTATION
BE150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUC 1997	GEARCASE - COUNTER-ROTATION
BE150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE150NXEUE 1997	GEARCASE - COUNTER-ROTATION
BE150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175EXECD 1998	GEARCASE -- COUNTER-ROTATION
BE175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE175EXEDB 1996	GEARCASE - COUNTER-ROTATION
BE175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175EXEUC 1997	GEARCASE - COUNTER-ROTATION
BE175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175EXEUE 1997	GEARCASE - COUNTER-ROTATION
BE175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS

BE175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175GLECD 1998	GEARCASE -- COUNTER-ROTATION
BE175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE175GLEDB 1996	GEARCASE - COUNTER-ROTATION
BE175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUC 1997	GEARCASE - COUNTER-ROTATION
BE175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175GLEUE 1997	GEARCASE - COUNTER-ROTATION
BE175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BE175NXECD 1998	GEARCASE -- COUNTER-ROTATION
BE175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BE175NXEDB 1996	GEARCASE - COUNTER-ROTATION
BE175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BE175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUC 1997	GEARCASE - COUNTER-ROTATION
BE175NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BE175NXEUE 1997	GEARCASE - COUNTER-ROTATION
BE175NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BE200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE200CXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE200CXEDR 1996	GEARCASE - COUNTER-ROTATION
BE200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200CXEUA 1997	GEARCASE - COUNTER-ROTATION
BE200CXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

BE200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE200TXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE200TXEDR 1996	GEARCASE - COUNTER-ROTATION
BE200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE200TXEUA 1997	GEARCASE - COUNTER-ROTATION
BE200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE225CXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE225CXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225CXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225CXEUD 1997	GEARCASE - COUNTER-ROTATION
BE225CXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225PXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225SLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225SLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
BE225SLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE225SLEDE 1996	GEARCASE - COUNTER-ROTATION
BE225SLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225SLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225SLEUD 1997	GEARCASE - COUNTER-ROTATION
BE225SLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225SLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
BE225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS

BE225TXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
BE225TXEDE 1996	GEARCASE - COUNTER-ROTATION
BE225TXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE225TXEUD 1997	GEARCASE - COUNTER-ROTATION
BE225TXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BE225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BE90ELEDR 1996	GEARCASE - 25 IN. MODELS
BE90ELEUA 1997	GEARCASE - 25 IN. MODELS
BE90ELEUC 1997	GEARCASE - 25 IN. MODELS
BE90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE90SLEDR 1996	GEARCASE - 25 IN. MODELS
BE90SLEUA 1997	GEARCASE - 25 IN. MODELS
BE90SLEUC 1997	GEARCASE - 25 IN. MODELS
BE90SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BE90SXEUA 1997	GEARCASE - 25 IN. MODELS
BE90SXEUC 1997	GEARCASE - 25 IN. MODELS
BJ115ELEDR 1996	GEARCASE - 25 IN. MODELS
BJ115ELEUA 1997	GEARCASE - 25 IN. MODELS
BJ115ELEUC 1997	GEARCASE - 25 IN. MODELS
BJ115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ115GLEDR 1996	GEARCASE - 25 IN. MODELS
BJ115GLEUA 1997	GEARCASE - 25 IN. MODELS
BJ115GLEUC 1997	GEARCASE - 25 IN. MODELS
BJ115PLEEM 1999	GEARCASE -- 90 & 115 PX MODELS
BJ115PLSIE elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ115PXEEM 1999	GEARCASE -- 90 & 115 PX MODELS
BJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ115SXEDR 1996	GEARCASE - 25 IN. MODELS
BJ115SXEUA 1997	GEARCASE - 25 IN. MODELS
BJ115SXEUC 1997	GEARCASE - 25 IN. MODELS
BJ115VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS

BJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ130PLEED 1999	GEARCASE
BJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
BJ130PXED 1999	GEARCASE
BJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
BJ130TLECE 1998	GEARCASE
BJ130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
BJ130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
BJ135PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE
BJ135VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE
BJ150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150ELECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150ELEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150ELEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150EXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150EXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150EXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

BJ150EXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150GLECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150GLEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150GLEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ150NXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ150NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ150NXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ150NXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175EXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ175EXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"

BJ175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175EXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175EXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175GLECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ175GLEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175GLEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
BJ175NXECD 1998	GEARCASE -- COUNTER-ROTATION
BJ175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
BJ175NXEDB 1996	GEARCASE - COUNTER-ROTATION
BJ175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUC 1997	GEARCASE - COUNTER-ROTATION
BJ175NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
BJ175NXEUE 1997	GEARCASE - COUNTER-ROTATION
BJ175NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
BJ175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS

BJ175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
BJ175PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
BJ175PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
BJ175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
BJ175PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ175PXSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
BJ175VXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
BJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
BJ200CXEDR 1996	GEARCASE - COUNTER-ROTATION
BJ200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
BJ200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BJ200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200CXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200CXSSS Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS

BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200CXSSSE Elec. Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PLEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200PLSSC Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200PXSSC Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200TXEDR 1996	GEARCASE - COUNTER-ROTATION
BJ200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

BJ200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200VCSIF elec start, TNT, 25 in , wht, cntr rotate, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200VSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200VSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200VSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200VSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ200VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225CXEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225CXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225CXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS

BJ225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PLEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225PLSIF elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225PLSSR Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
BJ225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
BJ225PXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225PXSSR Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS

BJ225VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225VCSSE Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
BJ225VXSIF elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
BJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
BJ90ELEDR 1996	GEARCASE - 25 IN. MODELS
BJ90ELEUA 1997	GEARCASE - 25 IN. MODELS
BJ90ELEUC 1997	GEARCASE - 25 IN. MODELS
BJ90PLEEB 1999	GEARCASE -- 90 & 115 PX MODELS
BJ90PLSID elec start, TNT, 20 in shaft, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ90PXEEB 1999	GEARCASE -- 90 & 115 PX MODELS
BJ90PXSSS Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
BJ90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ90SLEDR 1996	GEARCASE - 25 IN. MODELS
BJ90SLEUA 1997	GEARCASE - 25 IN. MODELS
BJ90SLEUC 1997	GEARCASE - 25 IN. MODELS
BJ90SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
BJ90SXEUUA 1997	GEARCASE - 25 IN. MODELS
BJ90SXEUUC 1997	GEARCASE - 25 IN. MODELS
BJ90VLSIC elec start, TNT, 20 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS

BJ90VXSIC elec start, TNT, 25 in shaft, wht, n/a usa 2001	GEARCASE - 90 - 115 VX MODELS
BJ90VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
C150ALCAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C150ALCABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150ALHABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150AXCAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C150AXCAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C150AXCABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C150AXHAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150AXHAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150AXHABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FLHAAA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FLHAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FLHAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FLHAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FLHAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FLHAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FLHABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FXHAAA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FXHAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FXHAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FXHAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FXHAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FXHAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150FXHABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150PLAAA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150PLAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150PLAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150PLAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150PLAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150PLAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C150PLABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)

C175PXCAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175PXCAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175PXCAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175XCAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175XCAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175XCAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175XCAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175XCAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C175XCABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200AXAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200AXAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200AXABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200AXCAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200AXCAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200AXCABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200CXAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200CXAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200FLAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FLAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FLAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FLAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FLAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FLABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FXAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FXAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FXAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FXAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200FXAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)

C200FXABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PLAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PLAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PLAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PLAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PLABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PXAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PXAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PXA AE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PXA AF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PXABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200PXCAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200PXCAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200PXCAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200PXCAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200PXCABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200XCAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200XCAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200XCAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200XCAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200XCABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type - Counter Rotation (Ratio: 12:26, 0.46, 2.16:1)
C200XOAAB - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200XOAAC - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200XOAAD - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200XOAAE - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200XOAAF - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
C200XOABA - (G2 66 degree V6, 2.7 L)	07-1_GEARCASE, SLX-Type (Ratio: 12:26, 0.46, 2.16:1)
D100WTLM 1988	GEARCASE
D100WTXM 1988	GEARCASE
DE150PXAAA	07-1_GEARCASE, M2-Type
DE150PXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2

DE150PXAAB	07-1_GEARCASE, M2-Type
DE150PXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE150PXAAC	07-1_GEARCASE, M2-Type
DE150PXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE150PXABA	07-1_GEARCASE, M2-Type
DE150PXABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE150PXABB	07-1_GEARCASE, M2-Type
DE150PXABF	07-1_GEARCASE, M2-Type
DE150PXABG	07-1_GEARCASE, M2-Type
DE150PXABH	07-1_GEARCASE, M2-Type
DE150PXINS	GEARCASE, M2-Type
DE150PXINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200HXAAA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXAAA - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200HXAAAB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXAAAB - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200HXAAAC - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXAAAC - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200HXAAD - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXAAD - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200HXABA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXABA - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200HXABB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE200HXINS - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
DE200HXINS - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200PXAAB - (60 degree V6)	07-1_GEARCASE, M2-Type
DE200PXAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200PXAAB - (60 degree V6)	07-1_GEARCASE, M2-Type
DE200PXAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200PXAAC - (60 degree V6)	07-1_GEARCASE, M2-Type
DE200PXAAC - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200PXABA	07-1_GEARCASE, M2-Type

DE200PXABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE200PXABB	07-1_GEARCASE, M2-Type
DE200PXABF	07-1_GEARCASE, M2-Type
DE200PXABG	07-1_GEARCASE, M2-Type
DE200PXABH	07-1_GEARCASE, M2-Type
DE200PXINS - (60 degree V6)	GEARCASE, M2-Type
DE200PXINS - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE225PXAAA	07-1_GEARCASE, M2-Type
DE225PXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE225PXAAAB	07-1_GEARCASE, M2-Type
DE225PXAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE225PXAAAC	07-1_GEARCASE, M2-Type
DE225PXAAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE225PXAAAD	07-1_GEARCASE, M2-Type
DE225PXAAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE225PXABA	07-1_GEARCASE, M2-Type
DE225PXABB	07-1_GEARCASE, M2-Type
DE225PXABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE225PXABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE225PXABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE225PXINS	GEARCASE, M2-Type
DE225PXINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXAAA - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PXAAA - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXAAAB - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PXAAAB - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXAAAC - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PXAAAC - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXAAAD - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PXAAAD - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXABA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PXABB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PXABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PXABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PXABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type

DE250PXIIC - (90 degree 6, 3.3 L)	GEARCASE, M2-Type
DE250PXIIC - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXINR - (90 degree V6, 3.3L)	GEARCASE, M2-Type
DE250PXINR - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXISF	GEARCASE
DE250PXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PXISS	GEARCASE
DE250PXISS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZAAA - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PZAAA - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZAAB - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PZAAB - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZAAC - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PZAAC - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZAAD - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
DE250PZAAD - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZABA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PZABB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PZABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PZABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PZABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
DE250PZIIC - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZIIC - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
DE250PZINR - (90 degree V6, 3.3L)	GEARCASE, M2-Type
DE250PZINR - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZISF	GEARCASE
DE250PZISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE250PZISS	GEARCASE
DE250PZISS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXAAA	07-1_GEARCASE, M2-Type
DE300PXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXAAB	07-1_GEARCASE, M2-Type
DE300PXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXAAC	07-1_GEARCASE, M2-Type
DE300PXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2

DE300PXAAD	07-1_GEARCASE, M2-Type
DE300PXAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXABA	07-1_GEARCASE, M2-Type
DE300PXABB	07-1_GEARCASE, M2-Type
DE300PXABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
DE300PXABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
DE300PXABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
DE300PXIIC	GEARCASE, M2-Type
DE300PXIIC - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXINR	GEARCASE, M2-Type
DE300PXINR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXISF	GEARCASE
DE300PXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXISG	GEARCASE
DE300PXISG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PXISS	GEARCASE
DE300PXISS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZAAA	07-1_GEARCASE, M2-Type
DE300PZAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZAAB	07-1_GEARCASE, M2-Type
DE300PZAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZAAC	07-1_GEARCASE, M2-Type
DE300PZAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZAAD	07-1_GEARCASE, M2-Type
DE300PZAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZABA	07-1_GEARCASE, M2-Type
DE300PZABB	07-1_GEARCASE, M2-Type
DE300PZABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
DE300PZABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
DE300PZABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
DE300PZIIC	GEARCASE, M2-Type
DE300PZIIC - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZINR	GEARCASE, M2-Type
DE300PZINR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZISF	GEARCASE

DE300PZISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZISG	GEARCASE
DE300PZISG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
DE300PZISS	GEARCASE
DE300PZISS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E100WMLCDR 1986	GEARCASE
E100WMLCOC 1985	GEARCASE
E100WMLCRS 1984	GEARCASE
E100WPLEEC 1999	GEARCASE
E100WPLSIF commercial, elec start, 20 in shaft 2001	GEARCASE
E100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
E100WPXECC 1999	GEARCASE
E100WPXSIF commercial, elec start, 25 in shaft 2001	GEARCASE
E100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
E100WQLECS 1998	GEARCASE -- 100WQX MODELS
E100WQXECS 1998	GEARCASE -- 100WQX MODELS
E100WTLCDR 1986	GEARCASE
E100WTLCOC 1985	GEARCASE
E100WTLCRS 1984	GEARCASE
E100WTLCUA 1987	GEARCASE
E100WTLEDR 1996	GEARCASE
E100WTLEIB 1991	GEARCASE
E100WTLENE 1992	GEARCASE
E100WTLEOC 1995	GEARCASE
E100WTLERS 1994	GEARCASE
E100WTLESM 1990	GEARCASE EARLY PRODUCTION
E100WTLESM 1990	GEARCASE LATE PRODUCTION
E100WTLETD 1993	GEARCASE
E100WTLEUA 1997	GEARCASE
E100WTLZ 1989	GEARCASE
E100WTXCDR 1986	GEARCASE
E100WTXCUA 1987	GEARCASE
E100WTXEDR 1996	GEARCASE
E100WTXEIB 1991	GEARCASE

E100WTXENE 1992	GEARCASE
E100WTXEOC 1995	GEARCASE
E100WTXERS 1994	GEARCASE
E100WTXESM 1990	GEARCASE EARLY PRODUCTION
E100WTXESM 1990	GEARCASE LATE PRODUCTION
E100WTXETD 1993	GEARCASE
E100WTXEUA 1997	GEARCASE
E100WTXZ 1989	GEARCASE
E105WELEEN 1999	GEARCASE
E105WELEES 1999	GEARCASE
E105WELSIF commercial, elec start, 20 in shaft 2001	GEARCASE
E105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
E105WPLEES 1999	GEARCASE
E105WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
E105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
E105WPXEES 1999	GEARCASE
E105WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
E105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
E105WRLEES 1999	GEARCASE
E105WRLSIF commercial, rope start, 20 in shaft 2001	GEARCASE
E105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
E105WRYEES 1999	GEARCASE
E105WRYISIF commercial, rope start, 22.5 in shaft 2001	GEARCASE
E105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
E115DBXAAA	07-1_GEARCASE, O-Type
E115DBXAAB	07-1_GEARCASE, O-Type
E115DBXABA	07-1_GEARCASE, O-Type
E115DBXAFA	07-1_GEARCASE, O-Type
E115DBXAFB	07-1_GEARCASE, O-Type
E115DBXIIB	GEARCASE, O-Type
E115DBXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXINE	GEARCASE, O-Type
E115DBXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E115DBXISF	GEARCASE
E115DBXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXISM	GEARCASE
E115DBXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSCR	GEARCASE
E115DBXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSEF	GEARCASE
E115DBXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DBXSUC	GEARCASE
E115DBXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DCXAAA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAAB	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXABA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFA	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFB	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFF	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFG	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFH	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFI	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXAFL	07-1_GEARCASE, O-Type, Counter Rotation
E115DCXIIA	GEARCASE, O-Type, Counter Rotation
E115DCXIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXINM	GEARCASE, O-Type, Counter Rotation
E115DCXINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXISF	GEARCASE
E115DCXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXISR	GEARCASE
E115DCXISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXSCS	GEARCASE
E115DCXSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DCXSEF	GEARCASE
E115DCXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E115DGXAFB	07-1_GEARCASE, O-Type
E115DGXAFF	07-1_GEARCASE, O-Type

E115DGXAFG	07-1_GEARCASE, O-Type
E115DGXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAIFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DGXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DHXAAA	07-1_GEARCASE, O-Type
E115DHXAAB	07-1_GEARCASE, O-Type
E115DHXABA	07-1_GEARCASE, O-Type
E115DHXAFA	07-1_GEARCASE, O-Type
E115DHXAFB	07-1_GEARCASE, O-Type
E115DHXAFF	07-1_GEARCASE, O-Type
E115DHXIIR	GEARCASE, O-Type
E115DHXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXINA	GEARCASE, O-Type
E115DHXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXISC	GEARCASE
E115DHXISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXISF	GEARCASE
E115DHXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DHXSES	GEARCASE
E115DHXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXAAA	07-1_GEARCASE, O-Type
E115DPXAAB	07-1_GEARCASE, O-Type
E115DPXABA	07-1_GEARCASE, O-Type
E115DPXAFA	07-1_GEARCASE, O-Type
E115DPXAFB	07-1_GEARCASE, O-Type
E115DPXAFF	07-1_GEARCASE, O-Type
E115DPXAFG	07-1_GEARCASE, O-Type
E115DPXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAIFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E115DPXIIB	GEARCASE, O-Type
E115DPXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXINE	GEARCASE, O-Type

E115DPXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXISF	GEARCASE
E115DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXISM	GEARCASE
E115DPXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSCR	GEARCASE
E115DPXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSEF	GEARCASE
E115DPXSEF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115DPXSUC	GEARCASE
E115DPXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E115ELECTM 1998	GEARCASE -- 90 & 115 SX MODELS
E115ELEDR 1996	GEARCASE - 25 IN. MODELS
E115ELEOC 1995	GEARCASE - 25 IN. MODELS
E115ELEUA 1997	GEARCASE - 25 IN. MODELS
E115ELEUC 1997	GEARCASE - 25 IN. MODELS
E115FPLEEC 1999	GEARCASE -- FPX MODELS
E115FPLEEN 1999	GEARCASE -- FPX MODELS
E115FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E115FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E115FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPX MODELS
E115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E115FPLSTB	GEARCASE - FPX MODELS
E115FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E115FPXEEC 1999	GEARCASE -- FPX MODELS
E115FPXEEN 1999	GEARCASE -- FPX MODELS
E115FPXSDS	GEARCASE - PX MODELS
E115FPXSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E115FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E115FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E115FPXSNF Ficht Fuel Injection, 25 in., White, Remote, Elec, TNT 2002	GEARCASE - FPX MODELS
E115FPXSOD	GEARCASE - FPX MODELS
E115FPXSOD - FR	07-1_BOÎTIER D'ENGRENAGES - FPX MODELES

E115FPXSRE	GEARCASE - FPX MODELS
E115FPXSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E115FPXSSH FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FPXSSR FFI, Elec Start, TNT, 25 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FPXSTB	GEARCASE - FPX MODELS
E115FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E115FSLECS 1998	GEARCASE -- FSX MODELS
E115FSLEEC 1999	GEARCASE -- FPX MODELS
E115FSLEEN 1999	GEARCASE -- FPX MODELS
E115FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E115FSLSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FSLSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
E115FSLSTB	GEARCASE - FPX MODELS
E115FSLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E115FSXECS 1998	GEARCASE -- FSX MODELS
E115FTLECS 1998	GEARCASE -- FSX MODELS
E115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115GLEDR 1996	GEARCASE - 25 IN. MODELS
E115GLEOC 1995	GEARCASE - 25 IN. MODELS
E115GLEUA 1997	GEARCASE - 25 IN. MODELS
E115GLEUC 1997	GEARCASE - 25 IN. MODELS
E115GNLAFB	07-1_GEARCASE, O-Type
E115GNLAFF	07-1_GEARCASE, O-Type
E115GNLAFG	07-1_GEARCASE, O-Type
E115GNLAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E115GNLAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E115GNLAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115JTLECS 1998	GEARCASE -- 90 & 115 SX MODELS
E115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115SLEDR 1996	GEARCASE - 25 IN. MODELS
E115SLEOC 1995	GEARCASE - 25 IN. MODELS
E115SLEUA 1997	GEARCASE - 25 IN. MODELS
E115SLEUC 1997	GEARCASE - 25 IN. MODELS
E115SNLAFA	07-1_GEARCASE, O-Type
E115SNLAFB	07-1_GEARCASE, O-Type

E115SNLAFF	07-1_GEARCASE, O-Type
E115SNLAFG	07-1_GEARCASE, O-Type
E115SNLAFH	07-1_GEARCASE, O-Type
E115SNLAFI	07-1_GEARCASE, O-Type
E115SNLAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
E115SXEDR 1996	GEARCASE - 25 IN. MODELS
E115SXEOC 1995	GEARCASE - 25 IN. MODELS
E115SXEU A 1997	GEARCASE - 25 IN. MODELS
E115SXEU C 1997	GEARCASE - 25 IN. MODELS
E120TLCCA 1988	GEARCASE - 140TX STANDARD ROTATION
E120TLCCA 1988	GEARCASE - 140CX COUNTER ROTATION
E120TLCEM 1989	GEARCASE - 140TX STANDARD ROTATION
E120TLCEM 1989	GEARCASE - 140CX COUNTER ROTATION
E120TLCOS 1985	GEARCASE
E120TLEIE 1991	GEARCASE - 140TX STANDARD ROTATION
E120TLEIE 1991	GEARCASE - 140CX COUNTER ROTATION
E120TLEND 1992	GEARCASE - 140TX STANDARD ROTATION
E120TLEND 1992	GEARCASE - 140CX COUNTER ROTATION
E120TLERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TLERC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
E120TLESB 1990	GEARCASE - 140CX COUNTER ROTATION
E120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX

E120TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXCCA 1988	GEARCASE - 140TX STANDARD ROTATION
E120TXCCA 1988	GEARCASE - 140CX COUNTER ROTATION
E120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
E120TXCEM 1989	GEARCASE - 140CX COUNTER ROTATION
E120XCCOS 1985	GEARCASE
E120TXEIE 1991	GEARCASE - 140TX STANDARD ROTATION
E120TXEIE 1991	GEARCASE - 140CX COUNTER ROTATION
E120TXEND 1992	GEARCASE - 140TX STANDARD ROTATION
E120TXEND 1992	GEARCASE - 140CX COUNTER ROTATION
E120TXERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXERC 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E120TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E120TXESB 1990	GEARCASE - 140TX STANDARD ROTATION
E120TXESB 1990	GEARCASE - 140CX COUNTER ROTATION
E120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
E120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125ESXENR 1992	GEARCASE - 140TX STANDARD ROTATION
E125ESXENR 1992	GEARCASE - 140CX COUNTER ROTATION
E125ESXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E125ESXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E125ESXETA 1993	GEARCASE - 140CX COUNTER ROTATION
E125ESXETA 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125ESXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E125ESXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E125WTPLE 1995	GEARCASE
E130CXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
E130CXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130DCXAAA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAAB	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXABA	07-1_GEARCASE, O-Type, Counter Rotation

E130DCXAFA	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFB	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFF	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFH	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFI	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFK	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXAFL	07-1_GEARCASE, O-Type, Counter Rotation
E130DCXIIR	GEARCASE, O-Type, Counter Rotation
E130DCXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXINA	GEARCASE, O-Type, Counter Rotation
E130DCXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXISC	GEARCASE
E130DCXISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXISF	GEARCASE
E130DCXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DCXSES	GEARCASE
E130DCXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O, contre-rotation
E130DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXAAA	07-1_GEARCASE, O-Type
E130DPXAAB	07-1_GEARCASE, O-Type
E130DPXABA	07-1_GEARCASE, O-Type
E130DPXAFA	07-1_GEARCASE, O-Type
E130DPXAFB	07-1_GEARCASE, O-Type
E130DPXAFF	07-1_GEARCASE, O-Type
E130DPXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E130DPXIIR	GEARCASE, O-Type
E130DPXIIR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXINA	GEARCASE, O-Type
E130DPXINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130DPXISC	GEARCASE
E130DPXISF	GEARCASE
E130DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E130DPXSES	GEARCASE
E130DPXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E130TLECE 1998	GEARCASE
E130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TLEOA 1995	GEARCASE - 130CX COUNTER ROTATION
E130TLEOA 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXACB 1998	GEARCASE
E130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
E130TXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
E130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
E135DHLAAB	07-1_GEARCASE, L2-Type
E135DHLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135DHLABA	07-1_GEARCASE, L2-Type
E135DHLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135DHLABB	07-1_GEARCASE, L2-Type
E135DHXAAC	07-1_GEARCASE, M2-Type
E135DHXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E135DHXABA	07-1_GEARCASE, M2-Type
E135DHXABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E135DHXABB	07-1_GEARCASE, M2-Type
E135DHXABF	07-1_GEARCASE, M2-Type
E135DHXABG	07-1_GEARCASE, M2-Type
E135DHXABH	07-1_GEARCASE, M2-Type
E135DHXABJ	07-1_GEARCASE, M2-Type
E135FCXSDE	GEARCASE - CX, MODELS
E135FCXSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E135FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FPL - FPX MODELS

E135FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX, MODELS
E135FCXSOB	GEARCASE - CX MODELS
E135FCXSOB - FR	07-1_BOÎTIER D'ENGRENAGES - CX MODELES
E135FCXSRM	GEARCASE - CX MODELS
E135FCXSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FCXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FCXSTA	GEARCASE - FCX, MODELS
E135FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E135FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FPLSDE	GEARCASE - PL - SL MODELS
E135FPLSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E135FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002	GEARCASE - FPL - FPX MODELS
E135FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX, MODELS
E135FPLSOB	GEARCASE - PL - SL MODELS
E135FPLSOB - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E135FPLSRM	GEARCASE - PL - SL MODELS
E135FPLSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FPLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FPLSTA	GEARCASE - FCX, MODELS
E135FPLSTA	GEARCASE - FPL - FSL - FPX MODELS
E135FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E135FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation

E135FPLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E135FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E135FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FPXSDE	GEARCASE - PX MODELS
E135FPXSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E135FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E135FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002	GEARCASE - FPL - FPX MODELS
E135FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002	GEARCASE - FCX, MODELS
E135FPXSOB	GEARCASE - PX MODELS
E135FPXSOB - FR	07-1_BOÎTIER D'ENGRENAGES - PX MODELES
E135FPXSRM	GEARCASE - PX MODELS
E135FPXSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E135FPXSTA	GEARCASE - FCX, MODELS
E135FPXSTA	GEARCASE - FPL - FSL - FPX MODELS
E135FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E135FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FSLSDE	GEARCASE - PL - SL MODELS
E135FSLSDE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSLSOB	GEARCASE - PL - SL MODELS
E135FSLSOB - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E135FSLSRM	GEARCASE - PL - SL MODELS
E135FSLSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSLSSS FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSLSTA	GEARCASE - FCX, MODELS
E135FSLSTA	GEARCASE - FPL - FSL - FPX MODELS
E135FSLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX

E135FSLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E135FSLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E135FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E135FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E135FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E135FSXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E135HGLABB	07-1_GEARCASE, L2-Type
E135HGLABF	07-1_GEARCASE, L2-Type
E135HGLABG	07-1_GEARCASE, L2-Type
E135HGLABH	07-1_GEARCASE, L2-Type
E135HGLABJ	07-1_GEARCASE, L2-Type
E135HGXABB	07-1_GEARCASE, M2-Type
E135HGXABF	07-1_GEARCASE, M2-Type
E135HGXABG	07-1_GEARCASE, M2-Type
E135HGXABH	07-1_GEARCASE, M2-Type
E135HGXABJ	07-1_GEARCASE, M2-Type
E135HSLAAB	07-1_GEARCASE, L2-Type
E135HSLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135HSLABA	07-1_GEARCASE, L2-Type
E135HSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E135HSLABB	07-1_GEARCASE, L2-Type
E135HSLABF	07-1_GEARCASE, L2-Type
E135HSLABG	07-1_GEARCASE, L2-Type
E135HSLABH	07-1_GEARCASE, L2-Type
E135HSLABJ	07-1_GEARCASE, L2-Type
E140CXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXARK 1994	GEARCASE - 140CX COUNTER ROTATION

E140CXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXCCS 1988	GEARCASE - 140TX STANDARD ROTATION
E140CXCCS 1988	GEARCASE - 140CX COUNTER ROTATION
E140CXCEC 1989	GEARCASE - 140TX STANDARD ROTATION
E140CXCEC 1989	GEARCASE - 140CX COUNTER ROTATION
E140CXEIA 1991	GEARCASE - 140TX STANDARD ROTATION
E140CXEIA 1991	GEARCASE - 140CX COUNTER ROTATION
E140CXENM 1992	GEARCASE - 140TX STANDARD ROTATION
E140CXENM 1992	GEARCASE - 140CX COUNTER ROTATION
E140CXERE 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXERE 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140CXERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140CXESR 1990	GEARCASE - 140TX STANDARD ROTATION
E140CXESR 1990	GEARCASE - 140CX COUNTER ROTATION
E140CXETB 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXETB 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140CXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140CXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLATC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLATC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLCCM 1988	GEARCASE - 140TX STANDARD ROTATION
E140TLCCM 1988	GEARCASE - 140CX COUNTER ROTATION
E140TLCEB 1989	GEARCASE - 140TX STANDARD ROTATION
E140TLCEB 1989	GEARCASE - 140CX COUNTER ROTATION
E140TLCOS 1985	GEARCASE
E140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
E140TLEID 1991	GEARCASE - 140CX COUNTER ROTATION
E140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
E140TLENS 1992	GEARCASE - 140CX COUNTER ROTATION

E140TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TLERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TLERR 1994	GEARCASE - 140CX COUNTER ROTATION
E140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
E140TLESE 1990	GEARCASE - 140CX COUNTER ROTATION
E140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
E140TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E140TXCCM 1988	GEARCASE - 140TX STANDARD ROTATION
E140TXCCM 1988	GEARCASE - 140CX COUNTER ROTATION
E140TXCEB 1989	GEARCASE - 140TX STANDARD ROTATION
E140TXCEB 1989	GEARCASE - 140CX COUNTER ROTATION
E140XCOS 1985	GEARCASE
E140XEID 1991	GEARCASE - 140TX STANDARD ROTATION
E140XEID 1991	GEARCASE - 140CX COUNTER ROTATION
E140XENS 1992	GEARCASE - 140TX STANDARD ROTATION
E140XENS 1992	GEARCASE - 140CX COUNTER ROTATION
E140XERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140XERK 1994	GEARCASE - 140CX COUNTER ROTATION
E140XERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
E140XERR 1994	GEARCASE - 140CX COUNTER ROTATION
E140XESE 1990	GEARCASE - 140TX STANDARD ROTATION
E140XESE 1990	GEARCASE - 140CX COUNTER ROTATION
E140XETC 1993	GEARCASE - 140CX COUNTER ROTATION
E140XETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX

E140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
E140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
E150ANCRS 1984	GEARCASE
E150CXCCA 1988	GEARCASE - COUNTER ROTATION
E150CXCCA 1988	GEARCASE - STANDARD ROTATION
E150CXCEM 1989	GEARCASE - COUNTER ROTATION
E150CXCEM 1989	GEARCASE - STANDARD ROTATION
E150CXEIE 1991	GEARCASE - COUNTER ROTATION
E150CXEIE 1991	GEARCASE - STANDARD ROTATION
E150CXESB 1990	GEARCASE - COUNTER ROTATION
E150CXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E150CXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E150DBXAAA	07-1_GEARCASE, M2-Type
E150DBXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXAAB	07-1_GEARCASE, M2-Type
E150DBXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXAAC	07-1_GEARCASE, M2-Type
E150DBXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXABA	07-1_GEARCASE, M2-Type
E150DBXABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXABB	07-1_GEARCASE, M2-Type
E150DBXIIB	GEARCASE, M2-Type
E150DBXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXINE	GEARCASE, M2-Type
E150DBXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXISF	GEARCASE
E150DBXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXISM	GEARCASE
E150DBXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXSCF	GEARCASE
E150DBXSCR	GEARCASE
E150DBXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E150DBXSEA	GEARCASE
E150DBXSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DBXSUF	GEARCASE

E150DBXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E150DCXSCR	GEARCASE
E150DCXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E150DCXSUC	GEARCASE
E150DCXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E150DCXSUF	GEARCASE
E150DCXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E150DGLABB	07-1_GEARCASE, O-Type
E150DGLABF	07-1_GEARCASE, O-Type
E150DGLABG	07-1_GEARCASE, O-Type
E150DGLABH	07-1_GEARCASE, O-Type
E150DGLABJ	07-1_GEARCASE, O-Type
E150DGXABB	07-1_GEARCASE, M2-Type
E150DGXABF	07-1_GEARCASE, M2-Type
E150DGXABG	07-1_GEARCASE, M2-Type
E150DGXABH	07-1_GEARCASE, M2-Type
E150DGXABJ	07-1_GEARCASE, M2-Type
E150DHLAAA	07-1_GEARCASE, L2-Type
E150DHLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLAAB	07-1_GEARCASE, L2-Type
E150DHLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLABA	07-1_GEARCASE, L2-Type
E150DHLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLABB	07-1_GEARCASE, L2-Type
E150DHLIIB	GEARCASE, L2-Type
E150DHLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLINE	GEARCASE, L2-Type
E150DHLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLISF	GEARCASE
E150DHLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLISM	GEARCASE
E150DHLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLSCF	GEARCASE
E150DHLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLSCR	GEARCASE - HL MODEL

E150DHLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150DHLSEA	GEARCASE
E150DHLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150DHLSUC	GEARCASE - HL MODEL
E150DHLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150DHLSUF	GEARCASE - HL MODEL
E150DHLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150DPLAAA	07-1_GEARCASE, O-Type
E150DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLAAB	07-1_GEARCASE, O-Type
E150DPLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLABA	07-1_GEARCASE, O-Type
E150DPLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLABB	07-1_GEARCASE, O-Type
E150DPLIIB	GEARCASE, O-Type
E150DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLINE	GEARCASE, O-Type
E150DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLISF	GEARCASE - PL, SL MODELS
E150DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLISM	GEARCASE - PL, SL MODELS
E150DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSCR	GEARCASE - PL, SL MODELS
E150DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSEA	GEARCASE - PL, SL MODELS
E150DPLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSUC	GEARCASE - PL, SL MODELS
E150DPLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPLSUF	GEARCASE - PL, SL MODELS
E150DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DPXAAA	07-1_GEARCASE, M2-Type
E150DPXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXAAB	07-1_GEARCASE, M2-Type
E150DPXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXAAC	07-1_GEARCASE, M2-Type

E150DPXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXABA	07-1_GEARCASE, M2-Type
E150DPXABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXABB	07-1_GEARCASE, M2-Type
E150DPXABF	07-1_GEARCASE, M2-Type
E150DPXABG	07-1_GEARCASE, M2-Type
E150DPXABH	07-1_GEARCASE, M2-Type
E150DPXABJ	07-1_GEARCASE, M2-Type
E150DPXIIB	GEARCASE, M2-Type
E150DPXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXINE	GEARCASE, M2-Type
E150DPXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXISF	GEARCASE
E150DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXISM	GEARCASE
E150DPXSCF	GEARCASE
E150DPXSCR	GEARCASE
E150DPXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E150DPXSEA	GEARCASE
E150DPXSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150DPXSUC	GEARCASE
E150DPXSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E150DPXSUF	GEARCASE
E150DPXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E150DSLAAA	07-1_GEARCASE, O-Type
E150DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLAAAB	07-1_GEARCASE, O-Type
E150DSLAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLABA	07-1_GEARCASE, O-Type
E150DSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLABB	07-1_GEARCASE, O-Type
E150DSLABF	07-1_GEARCASE, O-Type
E150DSLABG	07-1_GEARCASE, O-Type
E150DSLABH	07-1_GEARCASE, O-Type
E150DSLABJ	07-1_GEARCASE, O-Type

E150DSLIIIB	GEARCASE, O-Type
E150DSLIIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLIIIB	GEARCASE, O-Type
E150DSLIIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLISF	GEARCASE - PL, SL MODELS
E150DSLISM	GEARCASE - PL, SL MODELS
E150DSLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLISCR	GEARCASE - PL, SL MODELS
E150DSLISCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DSLSEA	GEARCASE - PL, SL MODELS
E150DSLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DLSUC	GEARCASE - PL, SL MODELS
E150DLSUC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150DLSUF	GEARCASE - PL, SL MODELS
E150DLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150ELECD 1998	GEARCASE -- COUNTER-ROTATION
E150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150ELEDB 1996	GEARCASE - COUNTER-ROTATION
E150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEIS 1991	GEARCASE - COUNTER ROTATION
E150ELEIS 1991	GEARCASE - STANDARD ROTATION
E150ELENC 1992	GEARCASE - COUNTER ROTATION
E150ELENC 1992	GEARCASE - STANDARD ROTATION
E150ELEOM 1995	GEARCASE - COUNTER ROTATION
E150ELEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150ELERA 1994	GEARCASE - COUNTER ROTATION
E150ELERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150ELERV 1994	GEARCASE - COUNTER ROTATION
E150ELERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

E150ELETG 1993	GEARCASE - COUNTER ROTATION
E150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150ELETR 1993	GEARCASE - COUNTER ROTATION
E150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEUC 1997	GEARCASE - COUNTER-ROTATION
E150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150ELEUE 1997	GEARCASE - COUNTER-ROTATION
E150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150EXARC 1994	GEARCASE - COUNTER ROTATION
E150EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXARV 1994	GEARCASE - COUNTER ROTATION
E150EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXATG 1993	GEARCASE - COUNTER ROTATION
E150EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXATS 1993	GEARCASE - COUNTER ROTATION
E150EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150EXECD 1998	GEARCASE -- COUNTER-ROTATION
E150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150EXEDB 1996	GEARCASE - COUNTER-ROTATION
E150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEIS 1991	GEARCASE - COUNTER ROTATION
E150EXEIS 1991	GEARCASE - STANDARD ROTATION
E150EXENC 1992	GEARCASE - COUNTER ROTATION

E150EXENC 1992	GEARCASE - STANDARD ROTATION
E150EXEOM 1995	GEARCASE - COUNTER ROTATION
E150EXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150EXERA 1994	GEARCASE - COUNTER ROTATION
E150EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXERV 1994	GEARCASE - COUNTER ROTATION
E150EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150EXETG 1993	GEARCASE - COUNTER ROTATION
E150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXETR 1993	GEARCASE - COUNTER ROTATION
E150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEUC 1997	GEARCASE - COUNTER-ROTATION
E150EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150EXEUE 1997	GEARCASE - COUNTER-ROTATION
E150EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150FCXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150FCXEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FCXEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS

E150FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FCXSDR	GEARCASE - CX, MODELS
E150FCXSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E150FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FPL - FPX MODELS
E150FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX, MODELS
E150FCXSOC	GEARCASE - CX MODELS
E150FCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES - CX MODELES
E150FCXSRS	GEARCASE - CX MODELS
E150FCXSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E150FCXSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FCXSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FCXSTD	GEARCASE - FCX, MODELS
E150FCXSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FCXSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E150FCXSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FHLSDR	GEARCASE - FHL MODEL
E150FHLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E150FHLSOC	GEARCASE - FHL MODEL
E150FHLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - FHL MODELES
E150FHLSRS	GEARCASE - FHL MODEL
E150FHLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL

E150FPLEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPLEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPLEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPLSDR	GEARCASE - PL - SL MODELS
E150FPLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E150FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002	GEARCASE - FPL - FPX MODELS
E150FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX, MODELS
E150FPLSOC	GEARCASE - PL - SL MODELS
E150FPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E150FPLSRS	GEARCASE - PL - SL MODELS
E150FPLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPLSTD	GEARCASE - FCX, MODELS
E150FPLSTD	GEARCASE - FPL - FSL - FPX MODELS
E150FPLSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPLSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E150FPLSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FPLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E150FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E150FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FPXEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS

E150FPXEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FPXSDR	GEARCASE - PX MODELS
E150FPXSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E150FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002	GEARCASE - FPL - FPX MODELS
E150FPXSNF Ficht Fuel Injection, 25 in. shaft, White 2002	GEARCASE - FCX, MODELS
E150FPXSOC	GEARCASE - PX MODELS
E150FPXSOC - FR	07-1_BOÎTIER D'ENGRENAGES - PX MODELES
E150FPXSRS	GEARCASE - PX MODELS
E150FPXSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FPXSMM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FPXSTD	GEARCASE - FCX, MODELS
E150FPXSTD	GEARCASE - FPL - FSL - FPX MODELS
E150FPXSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FPXSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL

E150FPXSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FSLECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150FSLEEA 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FSLEEA 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FSLEEA 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E150FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E150FSLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSLSDR	GEARCASE - PL - SL MODELS
E150FSLSDR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSOC	GEARCASE - PL - SL MODELS
E150FSLSOC - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E150FSLSRS	GEARCASE - PL - SL MODELS
E150FSLSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E150FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E150FSLSTD	GEARCASE - FCX, MODELS
E150FSLSTD	GEARCASE - FPL - FSL - FPX MODELS
E150FSLSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E150FSLSTD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E150FSLSTD - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FSLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E150FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX

E150FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E150FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E150FSXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150GLECD 1998	GEARCASE -- COUNTER-ROTATION
E150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150GLEDB 1996	GEARCASE - COUNTER-ROTATION
E150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEIS 1991	GEARCASE - COUNTER ROTATION
E150GLEIS 1991	GEARCASE - STANDARD ROTATION
E150GLENC 1992	GEARCASE - COUNTER ROTATION
E150GLENC 1992	GEARCASE - STANDARD ROTATION
E150GLEOM 1995	GEARCASE - COUNTER ROTATION
E150GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150GLERA 1994	GEARCASE - COUNTER ROTATION
E150GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150GLERV 1994	GEARCASE - COUNTER ROTATION
E150GLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150GLETG 1993	GEARCASE - COUNTER ROTATION
E150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150GLETR 1993	GEARCASE - COUNTER ROTATION
E150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEUC 1997	GEARCASE - COUNTER-ROTATION
E150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS

E150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150GLEUE 1997	GEARCASE - COUNTER-ROTATION
E150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150GNLABB	07-1_GEARCASE, O-Type
E150GNLABF	07-1_GEARCASE, O-Type
E150GNLABG	07-1_GEARCASE, O-Type
E150GNLABH	07-1_GEARCASE, O-Type
E150GNLABJ	07-1_GEARCASE, O-Type
E150HGLABA	07-1_GEARCASE, L2-Type
E150HGLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HGLABB	07-1_GEARCASE, L2-Type
E150HGLABF	07-1_GEARCASE, L2-Type
E150HGLABG	07-1_GEARCASE, L2-Type
E150HGLABH	07-1_GEARCASE, L2-Type
E150HGLABJ	07-1_GEARCASE, L2-Type
E150HGLSES	GEARCASE
E150HGLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HGXABA	07-1_GEARCASE, M2-Type
E150HGXABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150HGXABB	07-1_GEARCASE, M2-Type
E150HGXABF	07-1_GEARCASE, M2-Type
E150HGXABG	07-1_GEARCASE, M2-Type
E150HGXABH	07-1_GEARCASE, M2-Type
E150HGXABJ	07-1_GEARCASE, M2-Type
E150HGXSES	GEARCASE
E150HGXSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E150HSLAAA	07-1_GEARCASE, L2-Type
E150HSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLAAB	07-1_GEARCASE, L2-Type
E150HSLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLABA	07-1_GEARCASE, L2-Type
E150HSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLABB	07-1_GEARCASE, L2-Type
E150HSLABF	07-1_GEARCASE, L2-Type

E150HSLABG	07-1_GEARCASE, L2-Type
E150HSLABH	07-1_GEARCASE, L2-Type
E150HSLABJ	07-1_GEARCASE, L2-Type
E150HSLIIA	GEARCASE, L2-Type
E150HSLIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLINM	GEARCASE, L2-Type
E150HSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLISF	GEARCASE
E150HSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLISR	GEARCASE
E150HSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLSCF	GEARCASE
E150HSLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150HSLSCS	GEARCASE - HL MODEL
E150HSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E150HSLSEC	GEARCASE
E150HSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E150ICXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150ILECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E150ILECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E150ILECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E150ILEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150IXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150JLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150JLECD 1998	GEARCASE -- COUNTER-ROTATION
E150JLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150JLEDB 1996	GEARCASE - COUNTER-ROTATION
E150JLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS

E150JLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEIE 1991	GEARCASE - COUNTER ROTATION
E150JLEIE 1991	GEARCASE - STANDARD ROTATION
E150JLENC 1992	GEARCASE - COUNTER ROTATION
E150JLENC 1992	GEARCASE - STANDARD ROTATION
E150JLEOM 1995	GEARCASE - COUNTER ROTATION
E150JLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150JLERA 1994	GEARCASE - COUNTER ROTATION
E150JLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150JLERV 1994	GEARCASE - COUNTER ROTATION
E150JLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150JLETG 1993	GEARCASE - COUNTER ROTATION
E150JLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150JLETR 1993	GEARCASE - COUNTER ROTATION
E150JLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150JLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150JLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEUC 1997	GEARCASE - COUNTER-ROTATION
E150JLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150JLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150JLEUE 1997	GEARCASE - COUNTER-ROTATION
E150JLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150NXARC 1994	GEARCASE - COUNTER ROTATION
E150NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXARV 1994	GEARCASE - COUNTER ROTATION
E150NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

E150NXATG 1993	GEARCASE - COUNTER ROTATION
E150NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXATS 1993	GEARCASE - COUNTER ROTATION
E150NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150NXECD 1998	GEARCASE -- COUNTER-ROTATION
E150NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150NXEDB 1996	GEARCASE - COUNTER-ROTATION
E150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEIS 1991	GEARCASE - COUNTER ROTATION
E150NXEIS 1991	GEARCASE - STANDARD ROTATION
E150NXENC 1992	GEARCASE - COUNTER ROTATION
E150NXENC 1992	GEARCASE - STANDARD ROTATION
E150NXEOM 1995	GEARCASE - COUNTER ROTATION
E150NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150NXERA 1994	GEARCASE - COUNTER ROTATION
E150NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXERV 1994	GEARCASE - COUNTER ROTATION
E150NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E150NXETG 1993	GEARCASE - COUNTER ROTATION
E150NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXETR 1993	GEARCASE - COUNTER ROTATION
E150NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

E150NXEUC 1997	GEARCASE - COUNTER-ROTATION
E150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150NXEUE 1997	GEARCASE - COUNTER-ROTATION
E150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150PLEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
E150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
E150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
E150SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E150SLECD 1998	GEARCASE -- COUNTER-ROTATION
E150SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E150SLEDB 1996	GEARCASE - COUNTER-ROTATION
E150SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E150SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEOM 1995	GEARCASE - COUNTER ROTATION
E150SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E150SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E150SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEUC 1997	GEARCASE - COUNTER-ROTATION
E150SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E150SLEUE 1997	GEARCASE - COUNTER-ROTATION
E150SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E150SNLABA	07-1_GEARCASE, O-Type
E150SNLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E150SNLABB	07-1_GEARCASE, O-Type
E150SNLABF	07-1_GEARCASE, O-Type
E150SNLABG	07-1_GEARCASE, O-Type
E150SNLABH	07-1_GEARCASE, O-Type
E150SNLABJ	07-1_GEARCASE, O-Type
E150STLCCA 1988	GEARCASE
E150STLCDC 1986	GEARCASE
E150STLCEM 1989	GEARCASE

E150STLCOH 1985	GEARCASE
E150STLCOS 1985	GEARCASE
E150STLCRD 1984	GEARCASE
E150STLCTE 1983	GEARCASE
E150STLCUR 1987	GEARCASE
E150STLEIE 1991	GEARCASE
E150STLESB 1990	GEARCASE EARLY PRODUCTION
E150STLESB 1990	GEARCASE LATE PRODUCTION
E150TLCCA 1988	GEARCASE - COUNTER ROTATION
E150TLCCA 1988	GEARCASE - STANDARD ROTATION
E150TLCDC 1986	GEARCASE
E150TLCEM 1989	GEARCASE - COUNTER ROTATION
E150TLCEM 1989	GEARCASE - STANDARD ROTATION
E150TLCOS 1985	GEARCASE
E150TLCRD 1984	GEARCASE
E150TLCUR 1987	GEARCASE
E150TLEIE 1991	GEARCASE - COUNTER ROTATION
E150TLEIE 1991	GEARCASE - STANDARD ROTATION
E150TLESB 1990	GEARCASE - COUNTER ROTATION
E150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E150TRLCIA 1981	GEARCASE
E150TRLCIH 1981	GEARCASE
E150TRLCNM 1982	GEARCASE
E150TRLCSF 1980	GEARCASE
E150TRLCSR 1980	GEARCASE
E150TRLCTB 1983	GEARCASE
E150TRLCTE 1983	GEARCASE
E150TRXCIA 1981	GEARCASE
E150TRXCIH 1981	GEARCASE
E150TRXCNM 1982	GEARCASE
E150TRXCSF 1980	GEARCASE
E150TRXCSR 1980	GEARCASE
E150TRXCTB 1983	GEARCASE
E150TRXCTE 1983	GEARCASE

E150TXCCA 1988	GEARCASE - COUNTER ROTATION
E150TXCCA 1988	GEARCASE - STANDARD ROTATION
E150TXCDC 1986	GEARCASE
E150TXCEM 1989	GEARCASE - COUNTER ROTATION
E150TXCEM 1989	GEARCASE - STANDARD ROTATION
E150TXCOS 1985	GEARCASE
E150TXCRD 1984	GEARCASE
E150TXCUR 1987	GEARCASE
E150TXEIE 1991	GEARCASE - COUNTER ROTATION
E150TXEIE 1991	GEARCASE - STANDARD ROTATION
E150TXESB 1990	GEARCASE - COUNTER ROTATION
E150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
E150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
E150WTLEOR 1995	GEARCASE
E150WTLERC 1994	GEARCASE
E150WTLERV 1994	GEARCASE
E150WTLETG 1993	GEARCASE - 20" MODELS
E150WTLETG 1993	GEARCASE - 25" MODELS
E150WTLETS 1993	GEARCASE - 20" MODELS
E150WTLETS 1993	GEARCASE - 25" MODELS
E150WTXEOR 1995	GEARCASE
E150WTXERC 1994	GEARCASE
E150WTXERV 1994	GEARCASE
E150WTXETG 1993	GEARCASE - 20" MODELS
E150WTXETG 1993	GEARCASE - 25" MODELS
E150WTXETS 1993	GEARCASE - 20" MODELS
E150WTXETS 1993	GEARCASE - 25" MODELS
E155WTLEIB 1991	GEARCASE
E155WTLENE 1992	GEARCASE
E155WTXEIB 1991	GEARCASE
E155WTXENE 1992	GEARCASE
E175DCXSCR	GEARCASE

E175DCXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E175DCXSUF	GEARCASE
E175DCXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E175DGLABB	07-1_GEARCASE, O-Type
E175DGLABF	07-1_GEARCASE, O-Type
E175DGLABG	07-1_GEARCASE, O-Type
E175DGLABH	07-1_GEARCASE, O-Type
E175DGXABB	07-1_GEARCASE, M2-Type
E175DGXABF	07-1_GEARCASE, M2-Type
E175DGXABG	07-1_GEARCASE, M2-Type
E175DGXABH	07-1_GEARCASE, M2-Type
E175DMXAAA	07-1_GEARCASE, M2-Type
E175DMXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DMXAAB	07-1_GEARCASE, M2-Type
E175DMXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DMXAAC	07-1_GEARCASE, M2-Type
E175DMXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DMXSUF	GEARCASE
E175DPLAAA	07-1_GEARCASE, O-Type
E175DPLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLAAB	07-1_GEARCASE, O-Type
E175DPLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLABA	07-1_GEARCASE, O-Type
E175DPLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLABB	07-1_GEARCASE, O-Type
E175DPLIIB	GEARCASE, O-Type
E175DPLIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLINE	GEARCASE, O-Type
E175DPLINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLISF	GEARCASE - PL, SL MODELS
E175DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLISM	GEARCASE - PL, SL MODELS
E175DPLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSCR	GEARCASE - PL, SL MODELS
E175DPLSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E175DPLSEA	GEARCASE - PL, SL MODELS
E175DPLSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPLSUF	GEARCASE - PL, SL MODELS
E175DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DPXAAA	07-1_GEARCASE, M2-Type
E175DPXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXAAB	07-1_GEARCASE, M2-Type
E175DPXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXAAC	07-1_GEARCASE, M2-Type
E175DPXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXABA	07-1_GEARCASE, M2-Type
E175DPXABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXABB	07-1_GEARCASE, M2-Type
E175DPXABF	07-1_GEARCASE, M2-Type
E175DPXABG	07-1_GEARCASE, M2-Type
E175DPXABH	07-1_GEARCASE, M2-Type
E175DPXABJ	07-1_GEARCASE, M2-Type
E175DPXIIB	GEARCASE, M2-Type
E175DPXIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXINE	GEARCASE, M2-Type
E175DPXINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXISF	GEARCASE
E175DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXISM	GEARCASE
E175DPXISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXSCF	GEARCASE
E175DPXSCR	GEARCASE
E175DPXSCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E175DPXSEA	GEARCASE
E175DPXSEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E175DPXSUF	GEARCASE
E175DPXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E175DSLAAA	07-1_GEARCASE, O-Type
E175DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLAAAB	07-1_GEARCASE, O-Type

E175DSLAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLABA	07-1_GEARCASE, O-Type
E175DSLABA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLABB	07-1_GEARCASE, O-Type
E175DSLABF	07-1_GEARCASE, O-Type
E175DSLABG	07-1_GEARCASE, O-Type
E175DSLABH	07-1_GEARCASE, O-Type
E175DSLABJ	07-1_GEARCASE, O-Type
E175DSLIIIB	GEARCASE, O-Type
E175DSLIIIB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLIIINE	GEARCASE, O-Type
E175DSLIIINE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLISF	GEARCASE - PL, SL MODELS
E175DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLISM	GEARCASE - PL, SL MODELS
E175DSLISM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLISCR	GEARCASE - PL, SL MODELS
E175DSLISCR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DSLISEA	GEARCASE - PL, SL MODELS
E175DSLISEA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175DLSLSUF	GEARCASE - PL, SL MODELS
E175DLSLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E175EXARC 1994	GEARCASE - COUNTER ROTATION
E175EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXARV 1994	GEARCASE - COUNTER ROTATION
E175EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXATG 1993	GEARCASE - COUNTER ROTATION
E175EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXATS 1993	GEARCASE - COUNTER ROTATION
E175EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

E175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175EXECD 1998	GEARCASE -- COUNTER-ROTATION
E175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175EXEDB 1996	GEARCASE - COUNTER-ROTATION
E175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEIS 1991	GEARCASE - COUNTER ROTATION
E175EXEIS 1991	GEARCASE - STANDARD ROTATION
E175EXENC 1992	GEARCASE - COUNTER ROTATION
E175EXENC 1992	GEARCASE - STANDARD ROTATION
E175EXEOM 1995	GEARCASE - COUNTER ROTATION
E175EXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175EXERA 1994	GEARCASE - COUNTER ROTATION
E175EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXERV 1994	GEARCASE - COUNTER ROTATION
E175EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175EXETG 1993	GEARCASE - COUNTER ROTATION
E175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXETR 1993	GEARCASE - COUNTER ROTATION
E175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEUC 1997	GEARCASE - COUNTER-ROTATION
E175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175EXEUE 1997	GEARCASE - COUNTER-ROTATION
E175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175FCX ECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS

E175FCXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FCXECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175FCXECC 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FCXECC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXECC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FCXSDS	GEARCASE - CX, MODELS
E175FCXSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E175FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FPL - FPX MODELS
E175FCXSNF Ficht Fuel Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX, MODELS
E175FCXSOD	GEARCASE - CX MODELS
E175FCXSOD - FR	07-1_BOÎTIER D'ENGRENAGES - CX MODELES
E175FCXSRE	GEARCASE - CX MODELS
E175FCXSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles CX
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FCXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS

E175FCXSTB	GEARCASE - FCX, MODELS
E175FCXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FCXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E175FCXSTB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FPLEEC 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPLEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPLEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPLSDS	GEARCASE - PL - SL MODELS
E175FPLSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E175FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue, 2002	GEARCASE - FPL - FPX MODELS
E175FPLSNF Ficht Fuel Injection, 20 in. shaft, Blue, 2002	GEARCASE - FCX, MODELS
E175FPLSOD	GEARCASE - PL - SL MODELS
E175FPLSOD - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E175FPLSRE	GEARCASE - PL - SL MODELS
E175FPLSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPLSTB	GEARCASE - FCX, MODELS
E175FPLSTB	GEARCASE - FPL - FSL - FPX MODELS
E175FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E175FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation

E175FPLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E175FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E175FPLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FPXEEC 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPXEEC 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEC 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FPXSDS	GEARCASE - PX MODELS
E175FPXSDS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL et FPX
E175FPXSNF Ficht Fuel Injection, 25 in. shaft, White, 2002	GEARCASE - FPL - FPX MODELS
E175FPXSNF Ficht Fuel Injection, 25 in. shaft, White, 2002	GEARCASE - FCX, MODELS
E175FPXSOD	GEARCASE - PX MODELS
E175FPXSOD - FR	07-1_BOÎTIER D'ENGRENAGES - PX MODELES
E175FPXSRE	GEARCASE - PX MODELS
E175FPXSRE - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FPXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS

E175FPXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FPXSTB	GEARCASE - FCX, MODELS
E175FPXSTB	GEARCASE - FPL - FSL - FPX MODELS
E175FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E175FPXSTB - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FSLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FSLEEO 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FSLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL MODELS
E175FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FSL, FPX MODELS
E175FSLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSLSD	GEARCASE - PL - SL MODELS
E175FSLSD - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL, SL
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSOE	GEARCASE - PL - SL MODELS
E175FSLSOE - FR	07-1_BOÎTIER D'ENGRENAGES - PL - SL MODELES
E175FSLSRB	GEARCASE - PL - SL MODELS
E175FSLSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
E175FSLSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
E175FSLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
E175FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX

E175FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E175FSLSTF - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FSLSTM	GEARCASE - FCX, MODELS
E175FSLSTM	GEARCASE - FPL - FSL - FPX MODELS
E175FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX
E175FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FSL
E175FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES, de type F, standard rotation
E175FSXECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175FTLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
E175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
E175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
E175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175GLECD 1998	GEARCASE -- COUNTER-ROTATION
E175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175GLEDB 1996	GEARCASE - COUNTER-ROTATION
E175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEIS 1991	GEARCASE - COUNTER ROTATION
E175GLEIS 1991	GEARCASE - STANDARD ROTATION
E175GLENC 1992	GEARCASE - COUNTER ROTATION
E175GLENC 1992	GEARCASE - STANDARD ROTATION
E175GLEOM 1995	GEARCASE - COUNTER ROTATION
E175GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175GLERA 1994	GEARCASE - COUNTER ROTATION
E175GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175GLETG 1993	GEARCASE - COUNTER ROTATION
E175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175GLETR 1993	GEARCASE - COUNTER ROTATION
E175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEUC 1997	GEARCASE - COUNTER-ROTATION
E175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175GLEUE 1997	GEARCASE - COUNTER-ROTATION
E175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175MFXSOS	GEARCASE - MFX MODELS
E175MFXSOS - FR	07-1_BOÎTIER D'ENGRENAGES - MFX MODELES
E175NXARC 1994	GEARCASE - COUNTER ROTATION
E175NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXARV 1994	GEARCASE - COUNTER ROTATION
E175NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXATG 1993	GEARCASE - COUNTER ROTATION
E175NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXATS 1993	GEARCASE - COUNTER ROTATION
E175NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175NXECD 1998	GEARCASE -- COUNTER-ROTATION
E175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175NXEDB 1996	GEARCASE - COUNTER-ROTATION
E175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175NXENC 1992	GEARCASE - COUNTER ROTATION
E175NXENC 1992	GEARCASE - STANDARD ROTATION
E175NXEOM 1995	GEARCASE - COUNTER ROTATION
E175NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS

E175NXERA 1994	GEARCASE - COUNTER ROTATION
E175NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXERV 1994	GEARCASE - COUNTER ROTATION
E175NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175NXETG 1993	GEARCASE - COUNTER ROTATION
E175NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175NXETR 1993	GEARCASE - COUNTER ROTATION
E175NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
E175XEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175XEUC 1997	GEARCASE - COUNTER-ROTATION
E175XEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175XEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175XEUE 1997	GEARCASE - COUNTER-ROTATION
E175XEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
E175SLECD 1998	GEARCASE -- COUNTER-ROTATION
E175SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
E175SLEDB 1996	GEARCASE - COUNTER-ROTATION
E175SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
E175SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEOM 1995	GEARCASE - COUNTER ROTATION
E175SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
E175SLERA 1994	GEARCASE - COUNTER ROTATION
E175SLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E175SLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
E175SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"

E175SLEUC 1997	GEARCASE - COUNTER-ROTATION
E175SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
E175SLEUE 1997	GEARCASE - COUNTER-ROTATION
E175SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
E175STLCCM 1988	GEARCASE - COUNTER ROTATION
E175STLCCM 1988	GEARCASE - STANDARD ROTATION
E175STLCEB 1989	GEARCASE - COUNTER ROTATION
E175STLCEB 1989	GEARCASE - STANDARD ROTATION
E175STLEID 1991	GEARCASE - COUNTER ROTATION
E175STLEID 1991	GEARCASE - STANDARD ROTATION
E175STLESE 1990	GEARCASE - COUNTER ROTATION
E175STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E175STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E175TLCCM 1988	GEARCASE - COUNTER ROTATION
E175TLCCM 1988	GEARCASE - STANDARD ROTATION
E175TLCDR 1986	GEARCASE
E175TLCOC 1985	GEARCASE
E175TLCUA 1987	GEARCASE
E175TRLCIM 1981	GEARCASE
E175TRLCNB 1982	GEARCASE
E175TRLCSA 1980	GEARCASE
E175TRLCSF 1980	GEARCASE
E175TRLCTD 1983	GEARCASE
E175TRLCTE 1983	GEARCASE
E175TRXCIH 1981	GEARCASE
E175TRXCIM 1981	GEARCASE
E175TRXCNB 1982	GEARCASE
E175TRXCSA 1980	GEARCASE
E175TRXCSF 1980	GEARCASE
E175TRXCTD 1983	GEARCASE
E175TRXCTE 1983	GEARCASE
E175TXCCM 1988	GEARCASE - COUNTER ROTATION
E175TXCCM 1988	GEARCASE - STANDARD ROTATION

E175TXCDR 1986	GEARCASE
E175TXCEB 1989	GEARCASE - COUNTER ROTATION
E175TXCEB 1989	GEARCASE - STANDARD ROTATION
E175TXCOC 1985	GEARCASE
E175TXCUA 1987	GEARCASE
E175TXEID 1991	GEARCASE - COUNTER ROTATION
E175TXEID 1991	GEARCASE - STANDARD ROTATION
E175TXESE 1990	GEARCASE - COUNTER ROTATION
E175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E185ESERK 1994	GEARCASE - COUNTER ROTATION
E185ESERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E185ESERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXENR 1992	GEARCASE - COUNTER ROTATION
E185ESXENR 1992	GEARCASE - STANDARD ROTATION
E185ESXESS 1990	GEARCASE - COUNTER ROTATION
E185ESXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E185ESXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E185ESXETA 1993	GEARCASE - COUNTER ROTATION
E185ESXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E185ESXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXETF 1993	GEARCASE - COUNTER ROTATION
E185ESXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E185ESXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E185ESXW 1989	GEARCASE - COUNTER ROTATION
E185ESXW 1989	GEARCASE - STANDARD ROTATION
E185TLCOC 1985	GEARCASE
E185TLCRS 1984	GEARCASE
E185TXCOC 1985	GEARCASE
E185TXCRS 1984	GEARCASE
E200AXCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E200AXHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E200CXARC 1994	GEARCASE - COUNTER ROTATION
E200CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E200CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXARK 1994	GEARCASE - COUNTER ROTATION
E200CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXATF 1993	GEARCASE - COUNTER ROTATION
E200CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXATS 1993	GEARCASE - COUNTER ROTATION
E200CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXCCR 1988	GEARCASE - COUNTER ROTATION
E200CXCCR 1988	GEARCASE - STANDARD ROTATION
E200CXCEA 1989	GEARCASE - COUNTER ROTATION
E200CXCEA 1989	GEARCASE - STANDARD ROTATION
E200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200CXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E200CXEDR 1996	GEARCASE - COUNTER-ROTATION
E200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXEIB 1991	GEARCASE - COUNTER ROTATION
E200CXEIB 1991	GEARCASE - STANDARD ROTATION
E200CXENE 1992	GEARCASE - COUNTER ROTATION
E200CXENE 1992	GEARCASE - STANDARD ROTATION
E200CXEOC 1995	GEARCASE - COUNTER ROTATION
E200CXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXERK 1994	GEARCASE - COUNTER ROTATION
E200CXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXERS 1994	GEARCASE - COUNTER ROTATION
E200CXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXESM 1990	GEARCASE - COUNTER ROTATION

E200CXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E200CXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E200CXETD 1993	GEARCASE - COUNTER ROTATION
E200CXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXETF 1993	GEARCASE - COUNTER ROTATION
E200CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CXEUA 1997	GEARCASE - COUNTER-ROTATION
E200CXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZARK 1994	GEARCASE - COUNTER ROTATION
E200CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZATF 1993	GEARCASE - COUNTER ROTATION
E200CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZATS 1993	GEARCASE - COUNTER ROTATION
E200CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZEOC 1995	GEARCASE - COUNTER ROTATION
E200CZEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZERK 1994	GEARCASE - COUNTER ROTATION
E200CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZERS 1994	GEARCASE - COUNTER ROTATION
E200CZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZETD 1993	GEARCASE - COUNTER ROTATION
E200CZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200CZETF 1993	GEARCASE - COUNTER ROTATION
E200CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E200DCXSCA	GEARCASE
E200DCXSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200DCXSOC	GEARCASE CX, CZ MODELS
E200DCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E200DCXSUF	GEARCASE
E200DCXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200DCXSUR	GEARCASE
E200DCXSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200DGLABB	07-1_GEARCASE, O-Type
E200DGLABF	07-1_GEARCASE, O-Type
E200DGLABG	07-1_GEARCASE, O-Type
E200DGLABH	07-1_GEARCASE, M2-Type
E200DGXABB	07-1_GEARCASE, M2-Type
E200DGXABF	07-1_GEARCASE, M2-Type
E200DGXABG	07-1_GEARCASE, M2-Type
E200DGXABH	07-1_GEARCASE, M2-Type
E200DHAAAA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200DHAAAA - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHAAAB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200DHAAAB - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHAAAC - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200DHAAAC - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHAAAD - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200DHAAAD - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHAAAB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200DHAAAB - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHAAAB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200DHAAID - (90 degree V6 3,3 L)	GEARCASE, L2-Type
E200DHAAID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHAAINF - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
E200DHAAINF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHAAINS - (90 degree V6, 3.3 L)	GEARCASE, L2-Type
E200DHAAINS - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHAAISE - (90 degree V6 3,3 L)	GEARCASE
E200DHAAISE - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2

E200DHLISF - (90 degree V6 3,3 L)	GEARCASE
E200DHLISF - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSCF - (90 degree V6 3,3 L)	GEARCASE
E200DHLSCF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHLSCG - (90 degree V6 3,3 L)	GEARCASE
E200DHLSCG - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSCH - (90 degree V6 3,3 L)	GEARCASE
E200DHLSCH - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSCM - (90 degree V6 3,3 L)	GEARCASE
E200DHLSCM - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHLSDF - (90 degree V6 3,3 L)	GEARCASE
E200DHLSDF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHLSEB - (90 degree V6 3,3 L)	GEARCASE
E200DHLSEB - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200DHLSOC - (90 degree V6 3,3 L)	GEARCASE - HL, HX MODELS (L Type)
E200DHLSOC - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHL SOG - (90 degree V6 3,3 L)	GEARCASE HL, HX. MODELS (XP Type)
E200DHL SOG - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHL SUA - (90 degree V6, 3,3 L)	GEARCASE
E200DHL SUA - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHL SUG - (90 degree V6 3,3 L)	GEARCASE
E200DHL SUG - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200DHXAAA - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type
E200DHXAAA - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXAAB - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type
E200DHXAAB - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXAAC - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type
E200DHXAAC - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXAAD - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type
E200DHXAAD - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXABA - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type
E200DHXABA - (90 degree V6, 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXABB - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type
E200DHXABF - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type
E200DHXABG - (90 degree V6, 3,3 L)	07-1_GEARCASE, M2-Type

E200DHXABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200DHXIIB - (90 degree V6 3,3 L)	GEARCASE, M2-Type
E200DHXIIB - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXINE - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
E200DHXINE - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXISF - (90 degree V6 3,3 L)	GEARCASE
E200DHXISF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXISM - (90 degree V6 3,3 L)	GEARCASE
E200DHXISM - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXSCF - (90 degree V6 3,3 L)	GEARCASE
E200DHXSCF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200DHXSCG - (90 degree V6 3,3 L)	GEARCASE
E200DHXSCH - (90 degree V6 3,3 L)	GEARCASE
E200DHXSCR - (90 degree V6 3,3 L)	GEARCASE
E200DHXSCR - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200DHXSDS - (90 degree V6 3,3 L)	GEARCASE
E200DHXSDS - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200DHXSEA - (90 degree V6 3,3 L)	GEARCASE
E200DHXSEA - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DHXSUC - (90 degree V6 3,3 L)	GEARCASE
E200DHXSUC - (90 degree V6 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200DPLAAA - (60 degree V6)	07-1_GEARCASE, O-Type
E200DPLAAA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLAAB - (60 degree V6)	07-1_GEARCASE, O-Type
E200DPLAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLABA	07-1_GEARCASE, O-Type
E200DPLABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLABB	07-1_GEARCASE, O-Type
E200DPLIIE - (60 degree V6)	GEARCASE, O-Type
E200DPLIIE - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLIND - (60 degree V6)	GEARCASE, O-Type
E200DPLIND - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLISB	GEARCASE - PL, SL MODELS
E200DPLISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLISF	GEARCASE - PL, SL MODELS

E200DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSCA	GEARCASE - PL, SL MODELS
E200DPLSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSEM	GEARCASE - PL, SL MODELS
E200DPLSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E200DPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E200DPLSUF	GEARCASE - PL, SL MODELS
E200DPLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPLSUR	GEARCASE - PL, SL MODELS
E200DPLSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DPXAAA - (60 degree V6)	07-1_GEARCASE, M2-Type
E200DPXAAA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXAAB - (60 degree V6)	07-1_GEARCASE, M2-Type
E200DPXAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXAAC - (60 degree V6)	07-1_GEARCASE, M2-Type
E200DPXAAC - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXABA	07-1_GEARCASE, M2-Type
E200DPXABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXABB	07-1_GEARCASE, M2-Type
E200DPXABF	07-1_GEARCASE, M2-Type
E200DPXABG	07-1_GEARCASE, M2-Type
E200DPXABH	07-1_GEARCASE, M2-Type
E200DPXABJ	07-1_GEARCASE, M2-Type
E200DPXIIE - (60 degree V6)	GEARCASE, M2-Type
E200DPXIIE - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXIND - (60 degree V6)	GEARCASE, M2-Type
E200DPXIND - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXISB	GEARCASE
E200DPXISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXISF	GEARCASE
E200DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXSCA	GEARCASE
E200DPXSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200DPXSCF	GEARCASE

E200DPXSEM	GEARCASE
E200DPXSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200DPXSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E200DPXSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E200DPXSUF	GEARCASE
E200DPXSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200DPXSUR	GEARCASE
E200DPXSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200DSLAAA - (60 degree V6)	07-1_GEARCASE, O-Type
E200DSLAAA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLAAAB - (60 degree V6)	07-1_GEARCASE, O-Type
E200DSLAAAB - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLABA	07-1_GEARCASE, O-Type
E200DSLABA - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLABB	07-1_GEARCASE, O-Type
E200DSLABF	07-1_GEARCASE, O-Type
E200DSLABG	07-1_GEARCASE, O-Type
E200DSLABH	07-1_GEARCASE, M2-Type
E200DSLABJ	07-1_GEARCASE, O-Type
E200DSLIIIE - (60 degree V6)	GEARCASE, O-Type
E200DSLIIIE - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLIND - (60 degree V6)	GEARCASE, O-Type
E200DSLIND - (60 degree V6) - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLISB	GEARCASE - PL, SL MODELS
E200DSLISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLISF	GEARCASE - PL, SL MODELS
E200DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLSCA	GEARCASE - PL, SL MODELS
E200DSLSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DSLSEM	GEARCASE - PL, SL MODELS
E200DSLSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200DLSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E200DLSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E200DLSUF	GEARCASE - PL, SL MODELS
E200DLSUF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O

E200DSLUR	GEARCASE - PL, SL MODELS
E200DSLUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E200FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FCXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E200FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E200FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E200FCXSOE	GEARCASE - FCX & FCZ MODELS
E200FCXSOE - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E200FCXSRB	GEARCASE - FCX & FCZ MODELS
E200FCXSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E200FCXSTM	GEARCASE - FCX & FCZ MODELS
E200FCXSTM	GEARCASE - FHL MODEL
E200FCXSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E200FHLSOR	GEARCASE - FHL, FHX MODELS

E200FHLSOR - FR	07-1_BOÎTIER D'ENGRENAGES - FHL, FHX MODELES
E200FHLSRC	GEARCASE - FHL, FHX MODELS
E200FHLSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX
E200FHLSTS	GEARCASE - FCX & FCZ MODELS
E200FHLSTS	GEARCASE - FHL MODEL
E200FHLSTS	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FHLSTS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FHLSTS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FHLSTS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E200FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
E200FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FHL MODEL
E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FPL - FPX - FPZ MODELS
E200FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX & FCZ MODELS
E200FPLSOE	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FPLSOE - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E200FPLSRB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FPLSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E200FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPLSTM	GEARCASE - FCX & FCZ MODELS
E200FPLSTM	GEARCASE - FHL MODEL

E200FPLSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E200FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FPXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
E200FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E200FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FHL MODEL
E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FPL - FPX - FPZ MODELS
E200FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E200FPXSOE	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FPXSOE - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E200FPXSRB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FPXSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E200FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FPXSTM	GEARCASE - FCX & FCZ MODELS
E200FPXSTM	GEARCASE - FHL MODEL
E200FPXSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL

E200FSLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FSLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FSLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E200FSLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E200FSLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E200FSLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - Counter Rotation
E200FSLSOE	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FSLSOE - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E200FSLSRB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FSLSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E200FSLSSC FFI, Elec Start, TNT, 20 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FSLSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E200FSLSTM	GEARCASE - FCX & FCZ MODELS
E200FSLSTM	GEARCASE - FHL MODEL
E200FSLSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E200FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E200FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E200FSLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E200HCXSCF - (90 degree V6 3,3 L)	GEARCASE
E200HCXSCF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200HCXSCR - (90 degree V6 3,3 L)	GEARCASE
E200HCXSCR - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200HCXSDS - (90 degree V6 3,3 L)	GEARCASE
E200HCXSDS - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200HCXSUC - (90 degree V6 3,3 L)	GEARCASE
E200HCXSUC - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E200HGLABA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HGLABB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HGLABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type

E200HGLABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HGLABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLAAA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLAAA - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HSLAAB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLAAB - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HSLAAC - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLAAC - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HSLAAD - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLAAD - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HSLABA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLABA - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HSLABB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E200HSLIIB - (90 degree V6 3,3 L)	GEARCASE, L2-Type
E200HSLIIB - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HSLINE - (90 degree V6, 3.3 L)	GEARCASE, L2-Type
E200HSLINE - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLINF - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
E200HSLINF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLISF - (90 degree V6 3,3 L)	GEARCASE
E200HSLISF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLISM - (90 degree V6 3,3 L)	GEARCASE
E200HSLISM - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HSLSCF - (90 degree V6 3,3 L)	GEARCASE
E200HSLSCF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200HSLSCG - (90 degree V6 3,3 L)	GEARCASE
E200HSLSCG - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HLSLCH - (90 degree V6 3,3 L)	GEARCASE
E200HLSLCH - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HLSLSCR - (90 degree V6 3,3 L)	GEARCASE
E200HLSLSCR - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200HLSLSDS - (90 degree V6 3,3 L)	GEARCASE

E200HSLSDS - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200HSLSEA - (90 degree V6 3,3 L)	GEARCASE
E200HSLSEA - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E200HLSUC - (90 degree V6 3,3 L)	GEARCASE
E200HLSUC - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E200HVLIIA - (90 degree V6 3,3 L)	GEARCASE, M2-Type
E200HVLIIA - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HVLINM - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
E200HVLINM - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HVLISF - (90 degree V6 3,3 L)	GEARCASE
E200HVLISF - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HVLISR - (90 degree V6 3,3 L)	GEARCASE
E200HVLISR - (90 degree V6, 3.3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200HVLSCF - (90 degree V6 3,3 L)	GEARCASE
E200HVLSCF - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200HVLSCG - (90 degree V6 3,3 L)	GEARCASE
E200HVLSCG - (90 degree V6 3,3 L) - FR	GEARCASE
E200HVLSCS - (90 degree V6 3,3 L)	GEARCASE
E200HVLSCS - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E200HVLSEC - (90 degree V6 3,3 L)	GEARCASE
E200HVLSEC - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E200LHABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E200LHOABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHOAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHOAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHOAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHOAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type

E200LHOAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHOAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200LHOAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E200STLCCM 1988	GEARCASE - COUNTER ROTATION
E200STLCCM 1988	GEARCASE - STANDARD ROTATION
E200STLCDR 1986	GEARCASE
E200STLCEB 1989	GEARCASE - COUNTER ROTATION
E200STLCEB 1989	GEARCASE - STANDARD ROTATION
E200STLCUA 1987	GEARCASE
E200STLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200STLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200STLECE 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E200STLEDM 1996	GEARCASE - COUNTER-ROTATION
E200STLEDM 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLEID 1991	GEARCASE - COUNTER ROTATION
E200STLEID 1991	GEARCASE - STANDARD ROTATION
E200STLENS 1992	GEARCASE - COUNTER ROTATION
E200STLENS 1992	GEARCASE - STANDARD ROTATION
E200STLEOA 1995	GEARCASE - COUNTER ROTATION
E200STLEOA 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLEOA 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLERK 1994	GEARCASE - COUNTER ROTATION
E200STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLERR 1994	GEARCASE - COUNTER ROTATION
E200STLERR 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLERR 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200STLESE 1990	GEARCASE - COUNTER ROTATION
E200STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E200STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E200STLETC 1993	GEARCASE - COUNTER ROTATION
E200STLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200STLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E200TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXCCR 1988	GEARCASE - COUNTER ROTATION
E200TXCCR 1988	GEARCASE - STANDARD ROTATION
E200TXCDS 1986	GEARCASE
E200TXCEA 1989	GEARCASE - COUNTER ROTATION
E200TXCEA 1989	GEARCASE - STANDARD ROTATION
E200TXCUC 1987	GEARCASE
E200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E200TXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E200TXEDR 1996	GEARCASE - COUNTER-ROTATION
E200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXEIB 1991	GEARCASE - COUNTER ROTATION
E200TXEIB 1991	GEARCASE - STANDARD ROTATION
E200TXENE 1992	GEARCASE - COUNTER ROTATION
E200TXENE 1992	GEARCASE - STANDARD ROTATION
E200TXEOC 1995	GEARCASE - COUNTER ROTATION
E200TXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXERK 1994	GEARCASE - COUNTER ROTATION
E200TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXERS 1994	GEARCASE - COUNTER ROTATION
E200TXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXESM 1990	GEARCASE - COUNTER ROTATION
E200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E200TXETD 1993	GEARCASE - COUNTER ROTATION
E200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXETF 1993	GEARCASE - COUNTER ROTATION
E200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TXEUA 1997	GEARCASE - COUNTER-ROTATION
E200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZARK 1994	GEARCASE - COUNTER ROTATION
E200TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZATF 1993	GEARCASE - COUNTER ROTATION
E200TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZATS 1993	GEARCASE - COUNTER ROTATION
E200TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZE0C 1995	GEARCASE - COUNTER ROTATION
E200TZE0C 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZE0C 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZERK 1994	GEARCASE - COUNTER ROTATION
E200TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZERS 1994	GEARCASE - COUNTER ROTATION
E200TZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZETD 1993	GEARCASE - COUNTER ROTATION
E200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200TZETF 1993	GEARCASE - COUNTER ROTATION
E200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E200WPXEEN 1999	GEARCASE
E200WPXEES 1999	GEARCASE
E200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
E200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	GEARCASE
E200XHABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200XHAFa - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type

E200XHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200XHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200XHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200XHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200XHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200XHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E200XHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E200XHCABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E200XHCAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E200XHCAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E200XHCAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E200XHCAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E200XHCAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E200XHCAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E200XHCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E225CLCUB 1987	GEARCASE
E225CXARC 1994	GEARCASE - COUNTER ROTATION
E225CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXARK 1994	GEARCASE - COUNTER ROTATION
E225CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXATF 1993	GEARCASE - COUNTER ROTATION
E225CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXATS 1993	GEARCASE - COUNTER ROTATION
E225CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225XCCE 1988	GEARCASE - COUNTER ROTATION
E225XCCE 1988	GEARCASE - STANDARD ROTATION
E225XCED 1989	GEARCASE - COUNTER ROTATION
E225XCED 1989	GEARCASE - STANDARD ROTATION
E225XCUB 1987	GEARCASE
E225XECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

E225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225CXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225CXEDE 1996	GEARCASE - COUNTER-ROTATION
E225CXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXEIC 1991	GEARCASE - COUNTER ROTATION
E225CXEIC 1991	GEARCASE - STANDARD ROTATION
E225CXENR 1992	GEARCASE - COUNTER ROTATION
E225CXENR 1992	GEARCASE - STANDARD ROTATION
E225CXEOB 1995	GEARCASE - COUNTER ROTATION
E225CXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXERK 1994	GEARCASE - COUNTER ROTATION
E225CXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXERM 1994	GEARCASE - COUNTER ROTATION
E225CXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXESS 1990	GEARCASE - COUNTER ROTATION
E225CXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225CXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225CXETA 1993	GEARCASE - COUNTER ROTATION
E225CXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXETF 1993	GEARCASE - COUNTER ROTATION
E225CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CXEUD 1997	GEARCASE - COUNTER-ROTATION
E225CXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZARK 1994	GEARCASE - COUNTER ROTATION
E225CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZATF 1993	GEARCASE - COUNTER ROTATION
E225CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E225CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZATS 1993	GEARCASE - COUNTER ROTATION
E225CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225CZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225CZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225CZEDE 1996	GEARCASE - COUNTER-ROTATION
E225CZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZEOB 1995	GEARCASE - COUNTER ROTATION
E225CZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZERK 1994	GEARCASE - COUNTER ROTATION
E225CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZERM 1994	GEARCASE - COUNTER ROTATION
E225CZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZETA 1993	GEARCASE - COUNTER ROTATION
E225CZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZETF 1993	GEARCASE - COUNTER ROTATION
E225CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225CZEUD 1997	GEARCASE - COUNTER-ROTATION
E225CZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225CZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225DCXSCF	GEARCASE
E225DCXSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCXSCM	GEARCASE
E225DCXSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCXSDR	GEARCASE
E225DCXSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation

E225DCXSOC	GEARCASE CX, CZ MODELS
E225DCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E225DCXSUA	GEARCASE
E225DCXSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSCF	GEARCASE
E225DCZSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSCM	GEARCASE
E225DCZSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSDR	GEARCASE
E225DCZSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSOC	GEARCASE CX, CZ MODELS
E225DCZSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E225DCZSUA	GEARCASE
E225DCZSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DCZSUG	GEARCASE
E225DCZSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E225DHLAAA	07-1_GEARCASE, M2-Type
E225DHLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHLAAB	07-1_GEARCASE, M2-Type
E225DHLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHLAAC	07-1_GEARCASE, M2-Type
E225DHLAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHLAAD	07-1_GEARCASE, M2-Type
E225DHLAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHLABA	07-1_GEARCASE, M2-Type
E225DHLABB	07-1_GEARCASE, M2-Type
E225DHLIID	GEARCASE, M2-Type
E225DHLIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHLINS	GEARCASE, M2-Type
E225DHLINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHLISE	GEARCASE
E225DHLISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLISF	GEARCASE
E225DHLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSCF	GEARCASE

E225DHLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSCG	GEARCASE
E225DHLSCG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSCH	GEARCASE
E225DHLSCH - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSCM	GEARCASE
E225DHLSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSDF	GEARCASE
E225DHLSDF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSEB	GEARCASE
E225DHLSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHLSOC	GEARCASE - HL, HX MODELS (L Type)
E225DHLSOC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSOF	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E225DHLSOF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSOG	GEARCASE HL, HX. MODELS (XP Type)
E225DHLSOG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSUA	GEARCASE
E225DHLSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHLSUG	GEARCASE
E225DHLSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXAAA	07-1_GEARCASE, M2-Type
E225DHXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHXAAB	07-1_GEARCASE, M2-Type
E225DHXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHXAAC	07-1_GEARCASE, M2-Type
E225DHXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHXAAD	07-1_GEARCASE, M2-Type
E225DHXAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHXABA	07-1_GEARCASE, M2-Type
E225DHXABB	07-1_GEARCASE, M2-Type
E225DHXIIE	GEARCASE, M2-Type
E225DHXIIE - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DHXIND	GEARCASE, M2-Type
E225DHXIND - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2

E225DHXISB	GEARCASE
E225DHXISB - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXISF	GEARCASE
E225DHXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXSCA	GEARCASE
E225DHXSCA - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSCF	GEARCASE
E225DHXSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSCG	GEARCASE
E225DHXSCG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXSCH	GEARCASE
E225DHXSCH - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXSDF	GEARCASE
E225DHXSDF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSEM	GEARCASE
E225DHXSEM - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225DHXSOC	GEARCASE - HL, HX MODELS (L Type)
E225DHXSOC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXSOG	GEARCASE HL, HX. MODELS (XP Type)
E225DHXSOG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L
E225DHXUG	GEARCASE
E225DHXUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DHXSUR	GEARCASE
E225DHXSUR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPLIID	GEARCASE, M2-Type
E225DPLIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPLINS	GEARCASE, M2-Type
E225DPLINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPLISE	GEARCASE
E225DPLISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPLISF	GEARCASE
E225DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPLSCF	GEARCASE
E225DPLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPLSCG	GEARCASE

E225DPLSCH	GEARCASE
E225DPLSCM	GEARCASE
E225DPLSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPLSDR	GEARCASE
E225DPLSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPLSEB	GEARCASE
E225DPLSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPLSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E225DPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E225DPLSUA	GEARCASE
E225DPLSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPLSUG	GEARCASE
E225DPLSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPXAAA	07-1_GEARCASE, M2-Type
E225DPXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXAAB	07-1_GEARCASE, M2-Type
E225DPXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXAAC	07-1_GEARCASE, M2-Type
E225DPXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXAAD	07-1_GEARCASE, M2-Type
E225DPXAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXABA	07-1_GEARCASE, M2-Type
E225DPXABB	07-1_GEARCASE, M2-Type
E225DPXABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225DPXABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225DPXABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225DPXIID	GEARCASE, M2-Type
E225DPXIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXINS	GEARCASE, M2-Type
E225DPXINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXISE	GEARCASE
E225DPXISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXISF	GEARCASE
E225DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXSCF	GEARCASE

E225DPXSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPXSCG	GEARCASE
E225DPXSCH	GEARCASE
E225DPXSCM	GEARCASE
E225DPXSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPXSDR	GEARCASE
E225DPXSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPXSEB	GEARCASE
E225DPXSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPXSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E225DPXSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E225DPXSUA	GEARCASE
E225DPXSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPXSUG	GEARCASE
E225DPXSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPZIID	GEARCASE, M2-Type
E225DPZIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPZINS	GEARCASE, M2-Type
E225DPZINS - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPZISE	GEARCASE
E225DPZISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPZISF	GEARCASE
E225DPZISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPZSCF	GEARCASE
E225DPZSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPZSCG	GEARCASE
E225DPZSCH	GEARCASE
E225DPZSCM	GEARCASE
E225DPZSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPZSDR	GEARCASE
E225DPZSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225DPZSEB	GEARCASE
E225DPZSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225DPZSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E225DPZSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)

E225DPZSUA	GEARCASE
E225DPZSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E225FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FPL - FPX - FPZ MODELS
E225FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E225FCXSOE	GEARCASE - FCX & FCZ MODELS
E225FCXSOE - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E225FCXSRB	GEARCASE - FCX & FCZ MODELS
E225FCXSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCXSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCXSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCXSTM	GEARCASE - FCX & FCZ MODELS
E225FCXSTM	GEARCASE - FHL MODEL
E225FCXSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ

E225FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FCXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E225FCZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FCZEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FCZEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E225FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FPL - FPX - FPZ MODELS
E225FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E225FCZSOE	GEARCASE - FCX & FCZ MODELS
E225FCZSOE - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E225FCZSRB	GEARCASE - FCX & FCZ MODELS
E225FCZSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FCZSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCZSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E225FCZSTM	GEARCASE - FCX & FCZ MODELS
E225FCZSTM	GEARCASE - FHL MODEL
E225FCZSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FCZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ

E225FCZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FCZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E225FGLSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FGLSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FHLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
E225FHLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FHLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FHLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002	GEARCASE - FHL MODEL
E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002	GEARCASE - FPL - FPX - FPZ MODELS
E225FHLSNF Ficht RAM Injection, H.O., 20 in. shaft, Blue 2002	GEARCASE - FCX & FCZ MODELS
E225FHLSOB	GEARCASE - FHL, FHX MODELS
E225FHLSOB - FR	07-1_BOÎTIER D'ENGRENAGES - FHL, FHX MODELES
E225FHLSRM	GEARCASE - FHL, FHX MODELS
E225FHLSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX
E225FHLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FHLSTA	GEARCASE - FCX & FCZ MODELS
E225FHLSTA	GEARCASE - FHL MODEL
E225FHLSTA	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FHLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FHLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FHLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E225FHXSOC	GEARCASE - FHL, FHX MODELS
E225FHXSOC - FR	07-1_BOÎTIER D'ENGRENAGES - FHL, FHX MODELES
E225FHXSRS	GEARCASE - FHL, FHX MODELS
E225FHXSRS - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL et FHX
E225FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPLEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS

E225FPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPLEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPLEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPLEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPLSIF FFI	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FHL MODEL
E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FPL - FPX - FPZ MODELS
E225FPLSNF Ficht RAM Injection, 20 in. shaft, Blue 2002	GEARCASE - FCX & FCZ MODELS
E225FPLSOE	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPLSOE - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E225FPLSRB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPLSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E225FPLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPLSTM	GEARCASE - FCX & FCZ MODELS
E225FPLSTM	GEARCASE - FHL MODEL
E225FPLSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPLSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E225FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPXEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPXEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPXEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPXEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS

E225FPXEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FPXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - Counter Rotation
E225FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FHL MODEL
E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FPL - FPX - FPZ MODELS
E225FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E225FPXSOE	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPXSOE - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E225FPXSRB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPXSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E225FPXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPXSTM	GEARCASE - FCX & FCZ MODELS
E225FPXSTM	GEARCASE - FHL MODEL
E225FPXSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPXSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E225FPZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPZEEN 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEEN 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPZEEO 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEEO 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS
E225FPZEES 1999	GEARCASE -- STANDARD ROTATION -- FPL, FSL MODELS
E225FPZEES 1999	GEARCASE -- STANDARD ROTATION -- FPX, FPZ MODELS
E225FPZEES 1999	GEARCASE -- COUNTER-ROTATION -- FCX, FCZ MODELS

E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E225FPZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - Counter Rotation
E225FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E225FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FHL MODEL
E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FPL - FPX - FPZ MODELS
E225FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E225FPZSOE	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPZSOE - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E225FPZSRB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPZSRB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E225FPZSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E225FPZSTM	GEARCASE - FCX & FCZ MODELS
E225FPZSTM	GEARCASE - FHL MODEL
E225FPZSTM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E225FPZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E225FPZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E225FPZSTM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E225HGLABA	07-1_GEARCASE, M2-Type
E225HGLABB	07-1_GEARCASE, M2-Type
E225HGLABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HGLABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HGLABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HGXABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HGXABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HGXABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HSLAAA	07-1_GEARCASE, M2-Type
E225HSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2

E225HSLAAB	07-1_GEARCASE, M2-Type
E225HSLAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225HSLAAC	07-1_GEARCASE, M2-Type
E225HSLAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225HSLAAD	07-1_GEARCASE, M2-Type
E225HSLAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225HSLABA	07-1_GEARCASE, M2-Type
E225HSLABB	07-1_GEARCASE, M2-Type
E225HSLABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HSLABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HSLABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E225HSLIIA	GEARCASE, M2-Type
E225HSLIIA - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225HSLINM	GEARCASE, M2-Type
E225HSLINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E225HSLISF	GEARCASE
E225HSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLISR	GEARCASE
E225HSLISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSCF	GEARCASE
E225HSLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E225HSLSCG	GEARCASE
E225HSLSCG - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSCH	GEARCASE
E225HSLSCH - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSCS	GEARCASE
E225HSLSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225HSLSEC	GEARCASE
E225HSLSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E225LHABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type

E225LHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E225LHOABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHOAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHOAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHOAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHOAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHOAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHOAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225LHOAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E225PLCCE 1988	GEARCASE - COUNTER ROTATION
E225PLCCE 1988	GEARCASE - STANDARD ROTATION
E225PLCED 1989	GEARCASE - COUNTER ROTATION
E225PLCED 1989	GEARCASE - STANDARD ROTATION
E225PLCUB 1987	GEARCASE
E225PLEIC 1991	GEARCASE - COUNTER ROTATION
E225PLEIC 1991	GEARCASE - STANDARD ROTATION
E225PLENR 1992	GEARCASE - COUNTER ROTATION
E225PLENR 1992	GEARCASE - STANDARD ROTATION
E225PLERK 1994	GEARCASE - COUNTER ROTATION
E225PLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLERM 1994	GEARCASE - COUNTER ROTATION
E225PLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLESS 1990	GEARCASE - COUNTER ROTATION
E225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225PLETA 1993	GEARCASE - COUNTER ROTATION
E225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PLETF 1993	GEARCASE - COUNTER ROTATION
E225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225PTLCDA 1986	GEARCASE
E225PTXCDA 1986	GEARCASE
E225PXARC 1994	GEARCASE - COUNTER ROTATION
E225PXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXARK 1994	GEARCASE - COUNTER ROTATION
E225PXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXATF 1993	GEARCASE - COUNTER ROTATION
E225PXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXATS 1993	GEARCASE - COUNTER ROTATION
E225PXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXCCE 1988	GEARCASE - COUNTER ROTATION
E225PXCCE 1988	GEARCASE - STANDARD ROTATION
E225PXCED 1989	GEARCASE - COUNTER ROTATION
E225PXCED 1989	GEARCASE - STANDARD ROTATION
E225PXCUB 1987	GEARCASE
E225PXEDE 1996	GEARCASE - COUNTER-ROTATION
E225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXEIC 1991	GEARCASE - COUNTER ROTATION
E225PXEIC 1991	GEARCASE - STANDARD ROTATION
E225PXENR 1992	GEARCASE - COUNTER ROTATION
E225PXENR 1992	GEARCASE - STANDARD ROTATION
E225PXEOB 1995	GEARCASE - COUNTER ROTATION
E225PXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXERK 1994	GEARCASE - COUNTER ROTATION
E225PXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXERM 1994	GEARCASE - COUNTER ROTATION
E225PXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225PXESS 1990	GEARCASE - COUNTER ROTATION
E225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225PXETA 1993	GEARCASE - COUNTER ROTATION
E225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PXETF 1993	GEARCASE - COUNTER ROTATION
E225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZARK 1994	GEARCASE - COUNTER ROTATION
E225PZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZATF 1993	GEARCASE - COUNTER ROTATION
E225PZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZATS 1993	GEARCASE - COUNTER ROTATION
E225PZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZEOB 1995	GEARCASE - COUNTER ROTATION
E225PZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZERK 1994	GEARCASE - COUNTER ROTATION
E225PZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZERM 1994	GEARCASE - COUNTER ROTATION
E225PZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZETA 1993	GEARCASE - COUNTER ROTATION
E225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225PZETF 1993	GEARCASE - COUNTER ROTATION
E225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

E225STLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225STLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225STLEDE 1996	GEARCASE - COUNTER-ROTATION
E225STLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLEOB 1995	GEARCASE - COUNTER ROTATION
E225STLEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLERC 1994	GEARCASE - COUNTER ROTATION
E225STLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLERC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLERK 1994	GEARCASE - COUNTER ROTATION
E225STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLETF 1993	GEARCASE - COUNTER ROTATION
E225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225STLEUD 1997	GEARCASE - COUNTER-ROTATION
E225STLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225STLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLCCE 1988	GEARCASE - COUNTER ROTATION
E225TLCCE 1988	GEARCASE - STANDARD ROTATION
E225TLCDA 1986	GEARCASE
E225TLCED 1989	GEARCASE - COUNTER ROTATION
E225TLCED 1989	GEARCASE - STANDARD ROTATION
E225TLCUB 1987	GEARCASE
E225TLEIC 1991	GEARCASE - COUNTER ROTATION
E225TLEIC 1991	GEARCASE - STANDARD ROTATION
E225TLENR 1992	GEARCASE - COUNTER ROTATION
E225TLENR 1992	GEARCASE - STANDARD ROTATION
E225TLERK 1994	GEARCASE - COUNTER ROTATION
E225TLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLERM 1994	GEARCASE - COUNTER ROTATION
E225TLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

E225TLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLESS 1990	GEARCASE - COUNTER ROTATION
E225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225TLETA 1993	GEARCASE - COUNTER ROTATION
E225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TLETF 1993	GEARCASE - COUNTER ROTATION
E225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXARC 1994	GEARCASE - COUNTER ROTATION
E225TXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXARK 1994	GEARCASE - COUNTER ROTATION
E225TXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXATF 1993	GEARCASE - COUNTER ROTATION
E225TXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXATS 1993	GEARCASE - COUNTER ROTATION
E225TXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225XCCE 1988	GEARCASE - COUNTER ROTATION
E225XCCE 1988	GEARCASE - STANDARD ROTATION
E225XCDA 1986	GEARCASE
E225XCED 1989	GEARCASE - COUNTER ROTATION
E225XCED 1989	GEARCASE - STANDARD ROTATION
E225XCUB 1987	GEARCASE
E225XECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E225XECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225XECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225XEDE 1996	GEARCASE - COUNTER-ROTATION
E225XEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225XEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

E225TXEIC 1991	GEARCASE - COUNTER ROTATION
E225TXEIC 1991	GEARCASE - STANDARD ROTATION
E225TXENR 1992	GEARCASE - COUNTER ROTATION
E225TXENR 1992	GEARCASE - STANDARD ROTATION
E225TXEOB 1995	GEARCASE - COUNTER ROTATION
E225TXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXERK 1994	GEARCASE - COUNTER ROTATION
E225TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXERM 1994	GEARCASE - COUNTER ROTATION
E225TXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXESS 1990	GEARCASE - COUNTER ROTATION
E225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
E225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
E225TXETA 1993	GEARCASE - COUNTER ROTATION
E225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXETF 1993	GEARCASE - COUNTER ROTATION
E225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TXEUD 1997	GEARCASE - COUNTER-ROTATION
E225TXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZARK 1994	GEARCASE - COUNTER ROTATION
E225TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZATF 1993	GEARCASE - COUNTER ROTATION
E225TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZATS 1993	GEARCASE - COUNTER ROTATION
E225TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

E225TZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E225TZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E225TZEDE 1996	GEARCASE - COUNTER-ROTATION
E225TZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZEOb 1995	GEARCASE - COUNTER ROTATION
E225TZEOb 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZEOb 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZERK 1994	GEARCASE - COUNTER ROTATION
E225TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZERM 1994	GEARCASE - COUNTER ROTATION
E225TZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZETA 1993	GEARCASE - COUNTER ROTATION
E225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZETF 1993	GEARCASE - COUNTER ROTATION
E225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225TZEUD 1997	GEARCASE - COUNTER-ROTATION
E225TZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
E225TZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
E225XABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E225XCABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation

E225XCAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E225XCHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E225XCHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E225XHABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E225XHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E235STLCOR 1985	GEARCASE
E235STLCRC 1984	GEARCASE
E235STLCTS 1983	GEARCASE
E235TLCOR 1985	GEARCASE
E235TLCRC 1984	GEARCASE
E235TRLCIB 1981	GEARCASE
E235TRLCIH 1981	GEARCASE
E235TRLCNE 1982	GEARCASE
E235TRLCSM 1980	GEARCASE
E235TRLCTD 1983	GEARCASE
E235TRLCTS 1983	GEARCASE
E235TRXCIB 1981	GEARCASE
E235TRXCIH 1981	GEARCASE
E235TRXCNE 1982	GEARCASE

E235TRXCMSM 1980	GEARCASE
E235TRXCTD 1983	GEARCASE
E235TRXCTS 1983	GEARCASE
E235TXCOR 1985	GEARCASE
E235TXCRC 1984	GEARCASE
E250ALCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E250ALHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250AXCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E250AXHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250AZAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250AZCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E250CXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250CXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250CXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E250CZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250CZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250CZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E250DCXSCF	GEARCASE
E250DCXSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCXSCM	GEARCASE
E250DCXSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCXSDR	GEARCASE
E250DCXSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCXSOC	GEARCASE CX, CZ MODELS
E250DCXSOC - FR	07-1_BOÎTIER D'ENGRENAGES CX, CZ MODELES
E250DCXSUA	GEARCASE
E250DCXSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCXSUG	GEARCASE
E250DCXSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCZSCF	GEARCASE
E250DCZSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation
E250DCZSCM	GEARCASE
E250DCZSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M, contre rotation

E250DHXAAC - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DHXAAD - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250DHXAAD - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DHXABA - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250DHXABB - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250DHXIIA - (90 degree V6 3,4 L)	GEARCASE, M2-Type
E250DHXIIA - (90 degree V6, 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DHXINM - (90 degree V6, 3,4 L)	GEARCASE, M2-Type
E250DHXINM - (90 degree V6, 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DHXISF - (90 degree V6 3,4 L)	GEARCASE
E250DHXISF - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXISG - (90 degree V6 3,4 L)	GEARCASE
E250DHXISG - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXISR - (90 degree V6 3,4 L)	GEARCASE
E250DHXISR - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXSCS - (90 degree V6 3,4 L)	GEARCASE
E250DHXSCS - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DHXSEC - (90 degree V6 3,4 L)	GEARCASE
E250DHXSEC - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250DPLIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPLIID - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
E250DPLINS - (90 degree V6, 3.3L)	GEARCASE, M2-Type
E250DPLINS - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPLISE	GEARCASE
E250DPLISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPLISF	GEARCASE
E250DPLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPLSCF	GEARCASE
E250DPLSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPLSCG	GEARCASE
E250DPLSCH	GEARCASE
E250DPLSCM	GEARCASE
E250DPLSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPLSDR	GEARCASE
E250DPLSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M

E250DPLSEB	GEARCASE
E250DPLSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPLSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E250DPLSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E250DPLSUA	GEARCASE
E250DPLSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPXAAA - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPXAAA - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXAAB - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPXAAB - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXAAC - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPXAAC - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXAAD - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPXAAD - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXABA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPXABB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPXABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPXABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPXABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPXIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXIID - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
E250DPXINS - (90 degree V6, 3.3L)	GEARCASE, M2-Type
E250DPXINS - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXISE	GEARCASE
E250DPXISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXISF	GEARCASE
E250DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXSCF	GEARCASE
E250DPXSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPXSCG	GEARCASE
E250DPXSCH	GEARCASE
E250DPXSCM	GEARCASE
E250DPXSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPXSDR	GEARCASE
E250DPXSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M

E250DPXSEB	GEARCASE
E250DPXSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPXSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E250DPXSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E250DPXSUA	GEARCASE
E250DPXSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPXSUG	GEARCASE
E250DPXSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPZAAA - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPZAAA - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZAAB - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPZAAB - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZAAC - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPZAAC - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZAAD - (90 degree V6, 3.3L)	07-1_GEARCASE, M2-Type
E250DPZAAD - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZABA - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPZABB - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPZABF - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPZABG - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPZABH - (90 degree V6, 3.3 L)	07-1_GEARCASE, M2-Type
E250DPZIID - (90 degree V6 3,3 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZIID - (90 degree V6, 3.3 L)	GEARCASE, M2-Type
E250DPZINS - (90 degree V6, 3.3L)	GEARCASE, M2-Type
E250DPZINS - (90 degree V6, 3.3L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZISE	GEARCASE
E250DPZISE - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZISF	GEARCASE
E250DPZISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZSCF	GEARCASE
E250DPZSCF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPZSCG	GEARCASE
E250DPZSCH	GEARCASE
E250DPZSCM	GEARCASE
E250DPZSCM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M

E250DPZSDR	GEARCASE
E250DPZSDR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPZSEB	GEARCASE
E250DPZSEB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250DPZSOC	GEARCASE PL, SL,PX,PZ MODELS (M Type)
E250DPZSOC - FR	07-1_BOÎTIER D'ENGRENAGES PL, SL,PX,PZ MODELES (M Type)
E250DPZSUA	GEARCASE
E250DPZSUA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250DPZSUG	GEARCASE
E250DPZSUG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FCXSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E250FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FCXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FPL - FPX - FPZ MODELS
E250FCXSNF Ficht RAM Injection, 25 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E250FCXSOB	GEARCASE - FCX & FCZ MODELS
E250FCXSOB - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E250FCXSRM	GEARCASE - FCX & FCZ MODELS
E250FCXSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCXSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E250FCXSTA	GEARCASE - FCX & FCZ MODELS
E250FCXSTA	GEARCASE - FHL MODEL
E250FCXSTA	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FCXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL

E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FCZSIF FFI, elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
E250FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FCZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FHL MODEL
E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FPL - FPX - FPZ MODELS
E250FCZSNF Ficht RAM Injection, 30 in., White, Counter Rotation 2002	GEARCASE - FCX & FCZ MODELS
E250FCZSOB	GEARCASE - FCX & FCZ MODELS
E250FCZSOB - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E250FCZSRM	GEARCASE - FCX & FCZ MODELS
E250FCZSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FCZSSS FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
E250FCZSTA	GEARCASE - FCX & FCZ MODELS
E250FCZSTA	GEARCASE - FHL MODEL
E250FCZSTA	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FCZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FCZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FCZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E250FGLSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FPLSOM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPLSOM - FR	07-1_BOÎTIER D'ENGRENAGES- FCX & FCZ MODELES
E250FPLSRA	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPLSRA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E250FPLSSS FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FPLSTR	GEARCASE - FCX & FCZ MODELS
E250FPLSTR	GEARCASE - FHL MODEL
E250FPLSTR	GEARCASE - FPL - FSL - FPX - FPZ MODELS

E250FPLSTR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FPLSTR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPLSTR - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FPXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
E250FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPXSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E250FPXSNF Ficht RAM Injection, 25 in. shaft, White 2002	GEARCASE - FPL - FPX - FPZ MODELS
E250FPXSOB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPXSOB - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E250FPXSRM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPXSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E250FPXSSS FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPXSTA	GEARCASE - FCX & FCZ MODELS
E250FPXSTA	GEARCASE - FHL MODEL
E250FPXSTA	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPXSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
E250FPZSIF FFI, elec start, TNT, 30 in shaft 2001	GEARCASE - Counter Rotation
E250FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX et FCZ
E250FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPZSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX et FPZ
E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FHL MODEL
E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FPL - FPX - FPZ MODELS

E250FPZSNF Ficht RAM Injection, 30 in. shaft, White 2002	GEARCASE - FCX & FCZ MODELS
E250FPZSOB	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPZSOB - FR	07-1_BOÎTIER D'ENGRENAGES - FPL - FSL - FPX - FPZ MODELES
E250FPZSRM	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPZSRM - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ et FSL
E250FPZSSS FFI, Elec Start, TNT, 30 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
E250FPZSTA	GEARCASE - FCX & FCZ MODELS
E250FPZSTA	GEARCASE - FHL MODEL
E250FPZSTA	GEARCASE - FPL - FSL - FPX - FPZ MODELS
E250FPZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FCX, FCZ
E250FPZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FHL
E250FPZSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPL, FPX, FPZ , FSL
E250HGLAAB - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLAAB - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HGLAAC - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLAAC - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HGLAAD - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLAAD - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HGLABA - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLABB - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGLSES - (90 degree V6 3,4 L)	GEARCASE
E250HGLSES - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HGXAAB - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGXAAB - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HGXAAC - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGXAAC - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HGXAAD - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGXAAD - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HGXABA - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGXABB - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGXABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type

E250HGXABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGXABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HGXSSES - (90 degree V6 3,4 L)	GEARCASE
E250HGXSSES - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HSLAAA - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLAAA - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HSLAAB - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLAAB - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HSLAAC - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLAAC - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HSLAAD - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLAAD - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HSLABA - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLABB - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E250HSLIIR - (90 degree V6 3,4 L)	GEARCASE, M2-Type
E250HSLIIR - (90 degree V6, 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HSLINA - (90 degree V6, 3.4 L)	GEARCASE, M2-Type
E250HSLINA - (90 degree V6, 3.4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E250HSLISC - (90 degree V6 3,4 L)	GEARCASE
E250HSLISC - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HSLISF - (90 degree V6 3,4 L)	GEARCASE
E250HSLISF - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HSLISG - (90 degree V6 3,4 L)	GEARCASE
E250HSLISG - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250HLSSES - (90 degree V6 3,4 L)	GEARCASE
E250HLSSES - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type L2
E250LHABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHAFa - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type

E250LHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250LHOABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250LHOAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250PXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250PXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250PXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E250PZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
E250PZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
E250PZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
E250XABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250XCABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation

E250XCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E250XCHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250XCHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E250XHABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XHAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XHAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XHAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XHAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XHAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XHAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250XHAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250ZABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250ZAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250ZAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250ZAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250ZAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250ZAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250ZAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E250ZAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E250ZCABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250ZCAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250ZCAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250ZCAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250ZCAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250ZCAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250ZCAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E250ZCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E300AXCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)

E300AXUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E300AZCAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E300AZUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E300DGXABA	07-1_GEARCASE, M2-Type
E300DGXABB	07-1_GEARCASE, M2-Type
E300DGXABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DGXABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DGXABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DPXAAA	07-1_GEARCASE, M2-Type
E300DPXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXAAB	07-1_GEARCASE, M2-Type
E300DPXAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXAAC	07-1_GEARCASE, M2-Type
E300DPXAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXAAD	07-1_GEARCASE, M2-Type
E300DPXAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXABA	07-1_GEARCASE, M2-Type
E300DPXABB	07-1_GEARCASE, M2-Type
E300DPXABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DPXABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DPXABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DPXIIA	GEARCASE, M2-Type
E300DPXIIA - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXINM	GEARCASE, M2-Type
E300DPXINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXISF	GEARCASE
E300DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXISG	GEARCASE
E300DPXISG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXISR	GEARCASE
E300DPXISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPXSCS	GEARCASE
E300DPXSEC	GEARCASE
E300DPXSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2

E300DPZAAA	07-1_GEARCASE, M2-Type
E300DPZAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZAAB	07-1_GEARCASE, M2-Type
E300DPZAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZAAC	07-1_GEARCASE, M2-Type
E300DPZAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZAAD	07-1_GEARCASE, M2-Type
E300DPZAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZABA	07-1_GEARCASE, M2-Type
E300DPZABB	07-1_GEARCASE, M2-Type
E300DPZABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DPZABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DPZABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DPZIIA	GEARCASE, M2-Type
E300DPZIIA - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZINM	GEARCASE, M2-Type
E300DPZINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZISF	GEARCASE
E300DPZISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZISG	GEARCASE
E300DPZISG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZISR	GEARCASE
E300DPZISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DPZSCS	GEARCASE
E300DPZSEC	GEARCASE
E300DPZSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLAAA	07-1_GEARCASE, M2-Type
E300DSLAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLAAAB	07-1_GEARCASE, M2-Type
E300DSLAAAB - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLAAAC	07-1_GEARCASE, M2-Type
E300DSLAAAC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLAAAD	07-1_GEARCASE, M2-Type
E300DSLAAAD - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLABA	07-1_GEARCASE, M2-Type

E300DSLABB	07-1_GEARCASE, M2-Type
E300DSLABF - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DSLABG - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DSLABH - (90 degree V6, 3.4 L)	07-1_GEARCASE, M2-Type
E300DSLIIR	GEARCASE, M2-Type
E300DSLIIR - (90 degree V6 3,4 L) - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLINA	GEARCASE, M2-Type
E300DSLINA - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLISC	GEARCASE
E300DSLISC - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLISF	GEARCASE
E300DSLISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLISG	GEARCASE
E300DSLISG - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300DSLSES	GEARCASE
E300DSLSES - FR	07-1_BOÎTIER D'ENGRENAGES, de type M2
E300LUABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300LUAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300LUAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300LUAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300LUAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300LUAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300LUAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300LUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E300XCUABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300XCUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E300XUABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type

E300XUAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300XUAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300XUAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300XUAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300XUAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300XUAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300XUAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300XUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E300ZCUABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation
E300ZCUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
E300ZUABA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAFA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAGA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAGB - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAGC - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAGD - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAGE - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAGF - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type
E300ZUAGG - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
E60HGXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E60HGXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type
E75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E75FPLSNF - FR	07-1_BÔÎTIER D'ENGRENAGES - Modèles FPX
E75FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPX MODELS
E75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS

E75FPLSTA	GEARCASE - FPX MODELS
E75FPLSTA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E75FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E90DGXAFA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DGXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DMXSES	GEARCASE - DMX
E90DPXAAA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAAA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXABA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXABB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFA	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFB	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFC	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFD	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFF	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXAFG	07-1_GEARCASE, (0.44 Ratio) O-Type
E90DPXIIS	GEARCASE, O-Type
E90DPXIIS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXINC	GEARCASE, O-Type
E90DPXINC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXISD	GEARCASE - PX MODELS
E90DPXISD - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXISF	GEARCASE - PX MODELS
E90DPXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSCB	GEARCASE - PX MODELS
E90DPXSCB - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSDA	GEARCASE - PX MODELS
E90DPXSDA - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E90DPXSEE	GEARCASE - PX MODELS
E90DPXSEE - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90DPXSOR	GEARCASE PX , W MODELS

E90DPXSOR - FR	07-1_BOÎTIER D'ENGRENAGES PX , W MODELES
E90DPXSRC	GEARCASE PX MODELS
E90DPXSRC - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles PX
E90DPXSUM	GEARCASE - PX MODELS
E90DPXSUM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
E90ELEDR 1996	GEARCASE - 25 IN. MODELS
E90ELEOC 1995	GEARCASE - 25 IN. MODELS
E90ELEUA 1997	GEARCASE - 25 IN. MODELS
E90ELEUC 1997	GEARCASE - 25 IN. MODELS
E90EXEOC 1995	GEARCASE - 25 IN. MODELS
E90FPLEEC 1999	GEARCASE -- FPX MODELS
E90FPLEEN 1999	GEARCASE -- FPX MODELS
E90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
E90FPLSNF - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E90FPLSNF Ficht Fuel Injection, 20 in., Blue, Remote, Elec, TNT 2002	GEARCASE - FPX MODELS
E90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
E90FPLSTB	GEARCASE - FPX MODELS
E90FPLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E90FSLECS 1998	GEARCASE -- FSX MODELS
E90FSLSTB	GEARCASE - FPX MODELS
E90FSLSTB - FR	07-1_BOÎTIER D'ENGRENAGES - Modèles FPX
E90FTLECS 1998	GEARCASE -- FSX MODELS
E90FVLSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
E90HGXAFB	07-1_GEARCASE, O-Type
E90HGXAFF	07-1_GEARCASE, O-Type
E90HGXAFFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HGXAFFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFA	07-1_GEARCASE, O-Type
E90HSXAFFB	07-1_GEARCASE, O-Type
E90HSXAFFI	07-1_GEARCASE, O-Type

E90HSXAFH	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFI	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFK	07-1_GEARCASE, (0.44 Ratio) O-Type
E90HSXAFL	07-1_GEARCASE, (0.44 Ratio) O-Type
E90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
E90SLEDR 1996	GEARCASE - 25 IN. MODELS
E90SLEOC 1995	GEARCASE - 25 IN. MODELS
E90SLEUA 1997	GEARCASE - 25 IN. MODELS
E90SLEUC 1997	GEARCASE - 25 IN. MODELS
E90WDEXIIA	GEARCASE, O-Type
E90WDEXIIA - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXINM	GEARCASE, O-Type
E90WDEXINM - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXISF	GEARCASE - PX MODELS
E90WDEXISF - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXISR	GEARCASE - PX MODELS
E90WDEXISR - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXSCS	GEARCASE - PX MODELS
E90WDEXSCS - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDEXSEC	GEARCASE - PX MODELS
E90WDEXSEC - FR	07-1_BOÎTIER D'ENGRENAGES, de type O
E90WDPLSOS	GEARCASE PX , W MODELS
E90WDPLSOS - FR	07-1_BOÎTIER D'ENGRENAGES PX , W MODELES
H200AXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H200AXCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H200AXHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200HAXAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200HIXAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200HLAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200HLOAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200HXAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200HXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H200IXAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200IXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)

H200IXCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H200LHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200LHOAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200XHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H200XHCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H225HLAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H225HXAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H225HXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H225LHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H225LHOAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H225XAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H225XAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H225XCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H225XCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H225XCHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H225XHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250ALCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250AXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250AXCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250AXHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250AZAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250AZAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250AZCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250AZCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250HALAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250HAXAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250HLAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250HLOAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250HXAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250HXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)

H250IXAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250IXAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250IXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250IXCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250IZAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250IZAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250IZCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250IZCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250LHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250LHOAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250XAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250XAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250XCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250XCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250XCHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250XHAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250ZAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250ZAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H250ZCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H250ZCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300AXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300AXCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300AXUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300AXUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300AZCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300AZCAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300AZUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300AZUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300IXCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)

H300IXCUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300IXUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300IXUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300IZCAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300IZCUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300IZUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300IZUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300LUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300LUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300XCUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300XCUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300XCUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300XUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300XUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300ZCUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300ZCUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300ZCUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type, Counter Rotation (Ratio 13:24, 0.542, 1.85:1)
H300ZUAGH - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
H300ZUAHA - (G2 74 degree V6, 3.4 L)	07-1_GEARCASE, SLX-Type (Ratio 13:24 - 0.542 - 1.85:1)
HE115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
HE115SLEDR 1996	GEARCASE - 25 IN. MODELS
HE115SLEUA 1997	GEARCASE - 25 IN. MODELS
HE115SLEUC 1997	GEARCASE - 25 IN. MODELS
HE130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130CXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130TXACB 1998	GEARCASE
HE130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HE130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
HJ115SLEDR 1996	GEARCASE - 25 IN. MODELS
HJ115SLEUA 1997	GEARCASE - 25 IN. MODELS
HJ115SLEUC 1997	GEARCASE - 25 IN. MODELS

HJ130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130CXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130TXACB 1998	GEARCASE
HJ130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
HJ130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J100WMLCDR 1986	GEARCASE
J100WMLCOC 1985	GEARCASE
J100WMLCRS 1984	GEARCASE
J100WPLEEC 1999	GEARCASE
J100WPLSIF commercial, elec start, 20 in shaft 2001	GEARCASE
J100WPLSSR Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J100WPXEEC 1999	GEARCASE
J100WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J100WPXSSR Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J100WQLECS 1998	GEARCASE -- 100WQX MODELS
J100WQXECS 1998	GEARCASE -- 100WQX MODELS
J100WTLCDR 1986	GEARCASE
J100WTLCOG 1985	GEARCASE
J100WTLCRS 1984	GEARCASE
J100WTLCUA 1987	GEARCASE
J100WTLEDR 1996	GEARCASE
J100WTLEIB 1991	GEARCASE
J100WTLENE 1992	GEARCASE
J100WTLEOC 1995	GEARCASE
J100WTLEERS 1994	GEARCASE
J100WTLESM 1990	GEARCASE EARLY PRODUCTION
J100WTLESM 1990	GEARCASE LATE PRODUCTION
J100WTLETD 1993	GEARCASE
J100WTLEUA 1997	GEARCASE
J100WTLZ 1989	GEARCASE
J100WTXCDR 1986	GEARCASE
J100WTXCUA 1987	GEARCASE
J100WTXEDR 1996	GEARCASE
J100WTXEIB 1991	GEARCASE

J100WTXENE 1992	GEARCASE
J100WTXEOC 1995	GEARCASE
J100WTXERS 1994	GEARCASE
J100WTXESM 1990	GEARCASE EARLY PRODUCTION
J100WTXESM 1990	GEARCASE LATE PRODUCTION
J100WTXETD 1993	GEARCASE
J100WTXEUA 1997	GEARCASE
J100WTXZ 1989	GEARCASE
J105WELEEN 1999	GEARCASE
J105WELEES 1999	GEARCASE
J105WELSIF commercial, elec start, 20 in shaft 2001	GEARCASE
J105WELSSC Commercial, Elec. Start, 20 IN. shaft 2000	GEARCASE
J105WPLEEN 1999	GEARCASE
J105WPLEES 1999	GEARCASE
J105WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
J105WPLSSC Commercial, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J105WPLSTM	GEARCASE - PX - WPL MODELS
J105WPLSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J105WPXEEN 1999	GEARCASE
J105WPXEES 1999	GEARCASE
J105WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J105WPXSSC Commercial, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J105WRLEES 1999	GEARCASE
J105WRLSIF commercial, rope start, 20 in shaft 2001	GEARCASE
J105WRLSSC Commercial, Rope Start, 20 IN. shaft 2000	GEARCASE
J105WRYEES 1999	GEARCASE
J105WRYSIF commercial, rope start, 22.5 in shaft 2001	GEARCASE
J105WRYSSC Commercial, Rope Start, 22.5 IN. shaft 2000	GEARCASE
J115ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115ELEDR 1996	GEARCASE - 25 IN. MODELS
J115ELEOC 1995	GEARCASE - 25 IN. MODELS
J115ELEUA 1997	GEARCASE - 25 IN. MODELS
J115ELEUC 1997	GEARCASE - 25 IN. MODELS

J115FSLECS 1998	GEARCASE -- FSX MODELS
J115FSXECS 1998	GEARCASE -- FSX MODELS
J115FTLECS 1998	GEARCASE -- FSX MODELS
J115GLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115GLEDR 1996	GEARCASE - 25 IN. MODELS
J115GLEOC 1995	GEARCASE - 25 IN. MODELS
J115GLEUA 1997	GEARCASE - 25 IN. MODELS
J115GLEUC 1997	GEARCASE - 25 IN. MODELS
J115GLSTA	GEARCASE - PX - WPL MODELS
J115GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J115JPLEEC 1999	GEARCASE -- 90 & 115 PX MODELS
J115JPLSIA jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J115JPLSSR Jet Drive, Elec. Start,TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115JTLECS 1998	GEARCASE -- 90 & 115 SX MODELS
J115PLEEM 1999	GEARCASE -- 90 & 115 PX MODELS
J115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J115PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PXS
J115PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002	GEARCASE - PXS MODELS
J115PLSSB Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115PLSTS	GEARCASE - PX - WPL MODELS
J115PLSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J115PXEEM 1999	GEARCASE -- 90 & 115 PX MODELS
J115PXSDA	GEARCASE - PX MODELS
J115PXSDA - FR	17-1_BOÎTIER D'ENGRENAGES - PX MODELES
J115PXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PXS
J115PXSNF Carbureted, 25 in. shaft, White, Remote, Elec, TNT, 2002	GEARCASE - PXS MODELS
J115PXSOR	GEARCASE - PX - WPL MODELS
J115PXSOR - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J115PXSRM	GEARCASE - PX - WPL MODELS
J115PXSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J115PXSSB Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115PXSTS	GEARCASE - PX - WPL MODELS
J115PXSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J115SLECM 1998	GEARCASE -- 90 & 115 SX MODELS

J115SLEDR 1996	GEARCASE - 25 IN. MODELS
J115SLEOC 1995	GEARCASE - 25 IN. MODELS
J115SLEUA 1997	GEARCASE - 25 IN. MODELS
J115SLEUC 1997	GEARCASE - 25 IN. MODELS
J115SPLEES 1999	GEARCASE -- 90 & 115 PX MODELS
J115SPLSSC Elec. Start, TNT, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115SXECM 1998	GEARCASE -- 90 & 115 SX MODELS
J115SXEDR 1996	GEARCASE - 25 IN. MODELS
J115SXEOC 1995	GEARCASE - 25 IN. MODELS
J115SXEUA 1997	GEARCASE - 25 IN. MODELS
J115SXEUC 1997	GEARCASE - 25 IN. MODELS
J115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J115VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PXS
J115VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002	GEARCASE - PXS MODELS
J115VLSSS Elec. Start, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J115WPLSOC	GEARCASE - PX - WPL MODELS
J115WPLSOC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J115WPLSRS	GEARCASE - PX - WPL MODELS
J115WPLSRS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J120TLAEM 1989	GEARCASE - 140TX STANDARD ROTATION
J120TLAEM 1989	GEARCASE - 140CX COUNTER ROTATION
J120TLAIE 1991	GEARCASE - 140TX STANDARD ROTATION
J120TLAIE 1991	GEARCASE - 140CX COUNTER ROTATION
J120TLAND 1992	GEARCASE - 140TX STANDARD ROTATION
J120TLAND 1992	GEARCASE - 140CX COUNTER ROTATION
J120TLARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLARC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLARK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLASB 1990	GEARCASE - 140TX STANDARD ROTATION
J120TLASB 1990	GEARCASE - 140CX COUNTER ROTATION
J120TLATF 1993	GEARCASE - 140CX COUNTER ROTATION

J120LATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120LATS 1993	GEARCASE - 140CX COUNTER ROTATION
J120LATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLCCA 1988	GEARCASE - 140TX STANDARD ROTATION
J120TLCCA 1988	GEARCASE - 140CX COUNTER ROTATION
J120TLCEM 1989	GEARCASE - 140TX STANDARD ROTATION
J120TLCEM 1989	GEARCASE - 140CX COUNTER ROTATION
J120TLCOS 1985	GEARCASE
J120TLEIE 1991	GEARCASE - 140TX STANDARD ROTATION
J120TLEIE 1991	GEARCASE - 140CX COUNTER ROTATION
J120TLEND 1992	GEARCASE - 140TX STANDARD ROTATION
J120TLEND 1992	GEARCASE - 140CX COUNTER ROTATION
J120TLERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLERC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
J120TLESB 1990	GEARCASE - 140CX COUNTER ROTATION
J120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXCCA 1988	GEARCASE - 140TX STANDARD ROTATION
J120TXCCA 1988	GEARCASE - 140CX COUNTER ROTATION
J120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
J120TXCEM 1989	GEARCASE - 140CX COUNTER ROTATION
J120XCCOS 1985	GEARCASE

J120TXEIE 1991	GEARCASE - 140TX STANDARD ROTATION
J120TXEIE 1991	GEARCASE - 140CX COUNTER ROTATION
J120TXEND 1992	GEARCASE - 140TX STANDARD ROTATION
J120TXEND 1992	GEARCASE - 140CX COUNTER ROTATION
J120TXERC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXERC 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J120TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J120TXESB 1990	GEARCASE - 140TX STANDARD ROTATION
J120TXESB 1990	GEARCASE - 140CX COUNTER ROTATION
J120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
J120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125ESXENR 1992	GEARCASE - 140TX STANDARD ROTATION
J125ESXENR 1992	GEARCASE - 140CX COUNTER ROTATION
J125ESXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J125ESXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J125ESXETA 1993	GEARCASE - 140CX COUNTER ROTATION
J125ESXETA 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125ESXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J125ESXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J125WTPLE 1995	GEARCASE
J130CXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
J130CXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130PLEED 1999	GEARCASE
J130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
J130PXEEED 1999	GEARCASE
J130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
J130TLECE 1998	GEARCASE
J130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TLEOA 1995	GEARCASE - 130CX COUNTER ROTATION
J130TLEOA 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TLEUB 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXACB 1998	GEARCASE

J130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXAOR 1995	GEARCASE - 130CX COUNTER ROTATION
J130TXAOR 1995	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130TXAUM 1997	GEARCASE - 130TL & 130TX STANDARD ROTATION
J130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE
J135PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
J135VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE
J135VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE
J140CXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXCCS 1988	GEARCASE - 140TX STANDARD ROTATION
J140CXCCS 1988	GEARCASE - 140CX COUNTER ROTATION
J140CXCEC 1989	GEARCASE - 140TX STANDARD ROTATION
J140CXCEC 1989	GEARCASE - 140CX COUNTER ROTATION
J140CXEIA 1991	GEARCASE - 140TX STANDARD ROTATION
J140CXEIA 1991	GEARCASE - 140CX COUNTER ROTATION
J140CXENM 1992	GEARCASE - 140TX STANDARD ROTATION
J140CXENM 1992	GEARCASE - 140CX COUNTER ROTATION
J140CXERE 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXERE 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140CXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140CXESR 1990	GEARCASE - 140TX STANDARD ROTATION
J140CXESR 1990	GEARCASE - 140CX COUNTER ROTATION
J140CXETB 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXETB 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140CXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140CXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLAEB 1989	GEARCASE - 140TX STANDARD ROTATION

J140TLAEB 1989	GEARCASE - 140CX COUNTER ROTATION
J140TLANS 1992	GEARCASE - 140TX STANDARD ROTATION
J140TLANS 1992	GEARCASE - 140CX COUNTER ROTATION
J140TLARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLARR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLARR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLASE 1990	GEARCASE - 140TX STANDARD ROTATION
J140TLASE 1990	GEARCASE - 140CX COUNTER ROTATION
J140TLATC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLATC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLCCM 1988	GEARCASE - 140TX STANDARD ROTATION
J140TLCCM 1988	GEARCASE - 140CX COUNTER ROTATION
J140TLCEB 1989	GEARCASE - 140TX STANDARD ROTATION
J140TLCEB 1989	GEARCASE - 140CX COUNTER ROTATION
J140TLCOS 1985	GEARCASE
J140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
J140TLEID 1991	GEARCASE - 140CX COUNTER ROTATION
J140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
J140TLENS 1992	GEARCASE - 140CX COUNTER ROTATION
J140TLERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TLERR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
J140TLESE 1990	GEARCASE - 140CX COUNTER ROTATION
J140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXARC 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXARC 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXARK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION

J140TXARK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXATF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXATS 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXCCM 1988	GEARCASE - 140TX STANDARD ROTATION
J140TXCCM 1988	GEARCASE - 140CX COUNTER ROTATION
J140TXCEB 1989	GEARCASE - 140TX STANDARD ROTATION
J140TXCEB 1989	GEARCASE - 140CX COUNTER ROTATION
J140TXCOS 1985	GEARCASE
J140TXEID 1991	GEARCASE - 140TX STANDARD ROTATION
J140TXEID 1991	GEARCASE - 140CX COUNTER ROTATION
J140TXENS 1992	GEARCASE - 140TX STANDARD ROTATION
J140TXENS 1992	GEARCASE - 140CX COUNTER ROTATION
J140TXERK 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXERK 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXERR 1994	GEARCASE - 120TX & 140TX STANDARD ROTATION
J140TXERR 1994	GEARCASE - 140CX COUNTER ROTATION
J140TXESE 1990	GEARCASE - 140TX STANDARD ROTATION
J140TXESE 1990	GEARCASE - 140CX COUNTER ROTATION
J140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
J140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
J150CXCCA 1988	GEARCASE - COUNTER ROTATION
J150CXCCA 1988	GEARCASE - STANDARD ROTATION
J150CXCEM 1989	GEARCASE - COUNTER ROTATION
J150CXCEM 1989	GEARCASE - STANDARD ROTATION
J150CXEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150CXEIE 1991	GEARCASE - COUNTER ROTATION
J150CXEIE 1991	GEARCASE - STANDARD ROTATION
J150CXESB 1990	GEARCASE - COUNTER ROTATION

J150CXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J150CXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150CXSD E	GEARCASE - CX, MODELS
J150CXSD E - FR	17-1_BOÎTIER D'ENGRENAGES - CX, MODELES
J150CXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150CXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J150CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002	GEARCASE - PL - VL - PX MODELS
J150CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002	GEARCASE - CX, MODELS
J150CXSOB	GEARCASE - CX, MODELS
J150CXSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150CXSRM	GEARCASE - CX, MODELS
J150CXSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150CXSTA	GEARCASE - CX, MODELS
J150CXSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150ELAIS 1991	GEARCASE - COUNTER ROTATION
J150ELAIS 1991	GEARCASE - STANDARD ROTATION
J150ELANC 1992	GEARCASE - COUNTER ROTATION
J150ELANC 1992	GEARCASE - STANDARD ROTATION
J150ELARA 1994	GEARCASE - COUNTER ROTATION
J150ELARA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELARA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELARV 1994	GEARCASE - COUNTER ROTATION
J150ELARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELATG 1993	GEARCASE - COUNTER ROTATION
J150ELATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELATR 1993	GEARCASE - COUNTER ROTATION
J150ELATR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

J150ELATR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150ELECD 1998	GEARCASE -- COUNTER-ROTATION
J150ELECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150ELEDB 1996	GEARCASE - COUNTER-ROTATION
J150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEIS 1991	GEARCASE - COUNTER ROTATION
J150ELEIS 1991	GEARCASE - STANDARD ROTATION
J150ELENC 1992	GEARCASE - COUNTER ROTATION
J150ELENC 1992	GEARCASE - STANDARD ROTATION
J150ELEOM 1995	GEARCASE - COUNTER ROTATION
J150ELEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150ELERA 1994	GEARCASE - COUNTER ROTATION
J150ELERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELERV 1994	GEARCASE - COUNTER ROTATION
J150ELERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150ELETG 1993	GEARCASE - COUNTER ROTATION
J150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELETR 1993	GEARCASE - COUNTER ROTATION
J150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150ELEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEUC 1997	GEARCASE - COUNTER-ROTATION
J150ELEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150ELEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150ELEUE 1997	GEARCASE - COUNTER-ROTATION
J150ELEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS

J150EXARC 1994	GEARCASE - COUNTER ROTATION
J150EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXARV 1994	GEARCASE - COUNTER ROTATION
J150EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXATG 1993	GEARCASE - COUNTER ROTATION
J150EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXATS 1993	GEARCASE - COUNTER ROTATION
J150EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150EXECD 1998	GEARCASE -- COUNTER-ROTATION
J150EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150EXEDB 1996	GEARCASE - COUNTER-ROTATION
J150EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEIS 1991	GEARCASE - COUNTER ROTATION
J150EXEIS 1991	GEARCASE - STANDARD ROTATION
J150EXENC 1992	GEARCASE - COUNTER ROTATION
J150EXENC 1992	GEARCASE - STANDARD ROTATION
J150EXEOM 1995	GEARCASE - COUNTER ROTATION
J150EXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150EXERA 1994	GEARCASE - COUNTER ROTATION
J150EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXERV 1994	GEARCASE - COUNTER ROTATION
J150EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150EXETG 1993	GEARCASE - COUNTER ROTATION

J150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXETR 1993	GEARCASE - COUNTER ROTATION
J150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEUC 1997	GEARCASE - COUNTER-ROTATION
J150EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150EXEUE 1997	GEARCASE - COUNTER-ROTATION
J150EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150FCXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FCXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J150FSLECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FSLECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J150FSXECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150FSXECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J150GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150GLECD 1998	GEARCASE -- COUNTER-ROTATION
J150GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150GLEDB 1996	GEARCASE - COUNTER-ROTATION
J150GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEIS 1991	GEARCASE - COUNTER ROTATION
J150GLEIS 1991	GEARCASE - STANDARD ROTATION
J150GLENC 1992	GEARCASE - COUNTER ROTATION
J150GLENC 1992	GEARCASE - STANDARD ROTATION
J150GLEOM 1995	GEARCASE - COUNTER ROTATION
J150GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS

J150GLERA 1994	GEARCASE - COUNTER ROTATION
J150GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150GLERV 1994	GEARCASE - COUNTER ROTATION
J150GLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150GLETG 1993	GEARCASE - COUNTER ROTATION
J150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150GLETR 1993	GEARCASE - COUNTER ROTATION
J150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEUC 1997	GEARCASE - COUNTER-ROTATION
J150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150GLEUE 1997	GEARCASE - COUNTER-ROTATION
J150GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150GLSDE	GEARCASE - PL - GL MODELS
J150GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J150GLSOB	GEARCASE - PL - SL MODELS
J150GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J150GLSRM	GEARCASE - PL - GL MODELS
J150GLSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J150GLSTA	GEARCASE - CX, MODELS
J150GLSTA	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J150GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J150GLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J150GLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard
J150GTLCUR 1987	GEARCASE
J150ICXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS

J150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150ICXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150ILECR 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J150ILECR 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J150ILECR 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J150ILEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150ILEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150IXEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150IXEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150JLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150JLECD 1998	GEARCASE -- COUNTER-ROTATION
J150JLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150JLEDB 1996	GEARCASE - COUNTER-ROTATION
J150JLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150JLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEIE 1991	GEARCASE - COUNTER ROTATION
J150JLEIE 1991	GEARCASE - STANDARD ROTATION
J150JLENC 1992	GEARCASE - COUNTER ROTATION
J150JLENC 1992	GEARCASE - STANDARD ROTATION
J150JLEOM 1995	GEARCASE - COUNTER ROTATION
J150JLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150JLERA 1994	GEARCASE - COUNTER ROTATION
J150JLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150JLERV 1994	GEARCASE - COUNTER ROTATION
J150JLERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150JLETG 1993	GEARCASE - COUNTER ROTATION
J150JLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

J150JLETR 1993	GEARCASE - COUNTER ROTATION
J150JLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150JLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150JLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEUC 1997	GEARCASE - COUNTER-ROTATION
J150JLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150JLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150JLEUE 1997	GEARCASE - COUNTER-ROTATION
J150JLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150JPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150JPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150JPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150JPLSIF jet drive, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150JPLSSC Jet Drive, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150MLSOR	GEARCASE - ML - MX - PX MODELS
J150MLSRC	GEARCASE - ML - MX - PX MODELS
J150MLSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX
J150MLSTS	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J150MLSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J150MXSOR	GEARCASE - ML - MX - PX MODELS
J150MXSRC	GEARCASE - ML - MX - PX MODELS
J150MXSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150MXSSD Military, Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150MXSTS	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix

J150MXSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J150NXARC 1994	GEARCASE - COUNTER ROTATION
J150NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXARV 1994	GEARCASE - COUNTER ROTATION
J150NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXATG 1993	GEARCASE - COUNTER ROTATION
J150NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXATS 1993	GEARCASE - COUNTER ROTATION
J150NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150NXECD 1998	GEARCASE -- COUNTER-ROTATION
J150NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150NXEDB 1996	GEARCASE - COUNTER-ROTATION
J150NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEIS 1991	GEARCASE - COUNTER ROTATION
J150NXEIS 1991	GEARCASE - STANDARD ROTATION
J150NXENC 1992	GEARCASE - COUNTER ROTATION
J150NXENC 1992	GEARCASE - STANDARD ROTATION
J150NXEOM 1995	GEARCASE - COUNTER ROTATION
J150NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150NXERA 1994	GEARCASE - COUNTER ROTATION
J150NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J150NXERV 1994	GEARCASE - COUNTER ROTATION
J150NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS

J150NXETG 1993	GEARCASE - COUNTER ROTATION
J150NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXETR 1993	GEARCASE - COUNTER ROTATION
J150NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J150NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEUC 1997	GEARCASE - COUNTER-ROTATION
J150NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150NXEUE 1997	GEARCASE - COUNTER-ROTATION
J150NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150PLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150PLEUC 1997	GEARCASE -- COUNTER-ROTATION -- ICX MODELS
J150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- IL MODELS
J150PLEUC 1997	GEARCASE -- STANDARD ROTATION -- PL & IX MODELS
J150PLSDD	GEARCASE - PL - GL MODELS
J150PLSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J150PLSNF Carbureted, 20 in. shaft, Smoke 2002	GEARCASE - PL - VL - PX MODELS
J150PLSNF Carbureted, 20 in. shaft, Smoke 2002	GEARCASE - CX, MODELS
J150PLSOE	GEARCASE - PL - SL MODELS
J150PLSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J150PLSRB	GEARCASE - PL - GL MODELS
J150PLSRB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150PLSSC Military, Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS

J150PLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J150PLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard
J150PLSTM	GEARCASE - CX, MODELS
J150PLSTM	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J150PLSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150PLSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J150PXEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150PXEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150PXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150PXSDD	GEARCASE - PX MODELS
J150PXSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PX MODELS
J150PXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150PXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J150PXSNF Carbureted, 25 in. shaft, White 2002	GEARCASE - PL - VL - PX MODELS
J150PXSNF Carbureted, 25 in. shaft, White 2002	GEARCASE - CX, MODELS
J150PXSOE	GEARCASE - PX MODELS
J150PXSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX
J150PXSRB	GEARCASE - ML - MX - PX MODELS
J150PXSRB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150PXSTM	GEARCASE - CX, MODELS
J150PXSTM	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J150PXSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150PXSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J150SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J150SLECD 1998	GEARCASE -- COUNTER-ROTATION
J150SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J150SLEDB 1996	GEARCASE - COUNTER-ROTATION
J150SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J150SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"

J150SLEOM 1995	GEARCASE - COUNTER ROTATION
J150SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J150SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J150SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150SLEUC 1997	GEARCASE - COUNTER-ROTATION
J150SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J150SLEUE 1997	GEARCASE - COUNTER-ROTATION
J150SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J150SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J150SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J150SPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150STLACA 1988	GEARCASE
J150STLCCA 1988	GEARCASE
J150STLCDC 1986	GEARCASE
J150STLCEM 1989	GEARCASE
J150STLCOH 1985	GEARCASE
J150STLCOS 1985	GEARCASE
J150STLCRD 1984	GEARCASE
J150STLCTE 1983	GEARCASE
J150STLCUR 1987	GEARCASE
J150STLEIE 1991	GEARCASE
J150STLESB 1990	GEARCASE EARLY PRODUCTION
J150STLESB 1990	GEARCASE LATE PRODUCTION
J150TLAEM 1989	GEARCASE - COUNTER ROTATION
J150TLAEM 1989	GEARCASE - STANDARD ROTATION
J150TLAIE 1991	GEARCASE - COUNTER ROTATION
J150TLAIE 1991	GEARCASE - STANDARD ROTATION
J150TLASB 1990	GEARCASE - COUNTER ROTATION
J150TLASB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION

J150TLASB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150TLCCA 1988	GEARCASE - COUNTER ROTATION
J150TLCCA 1988	GEARCASE - STANDARD ROTATION
J150TLCDC 1986	GEARCASE
J150TLCEM 1989	GEARCASE - COUNTER ROTATION
J150TLCEM 1989	GEARCASE - STANDARD ROTATION
J150TLCIA 1981	GEARCASE
J150TLCIH 1981	GEARCASE
J150TLCNM 1982	GEARCASE
J150TLCOS 1985	GEARCASE
J150TLCRD 1984	GEARCASE
J150TLCSF 1980	GEARCASE
J150TLCSR 1980	GEARCASE
J150TLCTB 1983	GEARCASE
J150TLCTE 1983	GEARCASE
J150TLCUR 1987	GEARCASE
J150TLEIE 1991	GEARCASE - COUNTER ROTATION
J150TLEIE 1991	GEARCASE - STANDARD ROTATION
J150TLESB 1990	GEARCASE - COUNTER ROTATION
J150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150TXCCA 1988	GEARCASE - COUNTER ROTATION
J150TXCCA 1988	GEARCASE - STANDARD ROTATION
J150TXCDC 1986	GEARCASE
J150TXCEM 1989	GEARCASE - COUNTER ROTATION
J150TXCEM 1989	GEARCASE - STANDARD ROTATION
J150TXCIA 1981	GEARCASE
J150TXCIH 1981	GEARCASE
J150TXCNM 1982	GEARCASE
J150TXCOS 1985	GEARCASE
J150TXCRD 1984	GEARCASE
J150TXCSF 1980	GEARCASE
J150TXCSR 1980	GEARCASE
J150TXCTB 1983	GEARCASE
J150TXCTE 1983	GEARCASE

J150TXCUR 1987	GEARCASE
J150TXEIE 1991	GEARCASE - COUNTER ROTATION
J150TXEIE 1991	GEARCASE - STANDARD ROTATION
J150TXESB 1990	GEARCASE - COUNTER ROTATION
J150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J150VCSSES Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150VCSSES Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VCSSES Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J150VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J150VLSNF Carbureted, 20 in. shaft, White 2002	GEARCASE - PL - VL - PX MODELS
J150VLSNF Carbureted, 20 in. shaft, White 2002	GEARCASE - CX, MODELS
J150VLSSES Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150VLSSES Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VLSSES Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J150VXSSSES Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J150VXSSSES Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J150VXSSSES Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J150WPLEES 1999	GEARCASE

J150WPLSIF commercial, elec start, TNT, 20 in shaft 2001	GEARCASE
J150WPLSSC Commercial, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE
J150WTLEOR 1995	GEARCASE
J150WTLERC 1994	GEARCASE
J150WTLERV 1994	GEARCASE
J150WTLETG 1993	GEARCASE - 20" MODELS
J150WTLETG 1993	GEARCASE - 25" MODELS
J150WTLETS 1993	GEARCASE - 20" MODELS
J150WTLETS 1993	GEARCASE - 25" MODELS
J150WTXEOR 1995	GEARCASE
J150WTXERC 1994	GEARCASE
J150WTXERV 1994	GEARCASE
J150WTXETG 1993	GEARCASE - 20" MODELS
J150WTXETG 1993	GEARCASE - 25" MODELS
J150WTXETS 1993	GEARCASE - 20" MODELS
J150WTXETS 1993	GEARCASE - 25" MODELS
J155WTLEIB 1991	GEARCASE
J155WTLENE 1992	GEARCASE
J155WTXEIB 1991	GEARCASE
J155WTXENE 1992	GEARCASE
J175CXEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175CXSD	GEARCASE - CX, MODELS
J175CXSD - FR	17-1_BOÎTIER D'ENGRENAGES - CX, MODELES
J175CXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175CXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J175CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002	GEARCASE - PL - VL - PX MODELS
J175CXSNF Carbureted, 25 in. shaft, White, Counter Rotation 2002	GEARCASE - CX, MODELS
J175CXSOB	GEARCASE - CX, MODELS
J175CXSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175CXSRM	GEARCASE - CX, MODELS
J175CXSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX

J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175CXSTA	GEARCASE - CX, MODELS
J175CXSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175EXARC 1994	GEARCASE - COUNTER ROTATION
J175EXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXARV 1994	GEARCASE - COUNTER ROTATION
J175EXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXATG 1993	GEARCASE - COUNTER ROTATION
J175EXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXATS 1993	GEARCASE - COUNTER ROTATION
J175EXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175EXECD 1998	GEARCASE -- COUNTER-ROTATION
J175EXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175EXEDB 1996	GEARCASE - COUNTER-ROTATION
J175EXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J175EXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEIS 1991	GEARCASE - COUNTER ROTATION
J175EXEIS 1991	GEARCASE - STANDARD ROTATION
J175EXENC 1992	GEARCASE - COUNTER ROTATION
J175EXENC 1992	GEARCASE - STANDARD ROTATION
J175EXEOM 1995	GEARCASE - COUNTER ROTATION
J175EXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175EXERA 1994	GEARCASE - COUNTER ROTATION
J175EXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

J175EXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXERV 1994	GEARCASE - COUNTER ROTATION
J175EXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175EXETG 1993	GEARCASE - COUNTER ROTATION
J175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXETR 1993	GEARCASE - COUNTER ROTATION
J175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175EXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEUC 1997	GEARCASE - COUNTER-ROTATION
J175EXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175EXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175EXEUE 1997	GEARCASE - COUNTER-ROTATION
J175EXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175FCX ECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FCX ECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FCX ECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175FSLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FSLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175FSXECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FSXECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175FTLECS 1998	GEARCASE -- COUNTER-ROTATION -- FCX MODELS
J175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- FSL & FSX MODELS
J175FTLECS 1998	GEARCASE -- STANDARD ROTATION -- IL & FTL MODELS
J175GLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175GLECD 1998	GEARCASE -- COUNTER-ROTATION
J175GLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175GLEDB 1996	GEARCASE - COUNTER-ROTATION
J175GLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS

J175GLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEIS 1991	GEARCASE - COUNTER ROTATION
J175GLEIS 1991	GEARCASE - STANDARD ROTATION
J175GLENC 1992	GEARCASE - COUNTER ROTATION
J175GLENC 1992	GEARCASE - STANDARD ROTATION
J175GLEOM 1995	GEARCASE - COUNTER ROTATION
J175GLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175GLERA 1994	GEARCASE - COUNTER ROTATION
J175GLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175GLETG 1993	GEARCASE - COUNTER ROTATION
J175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175GLETR 1993	GEARCASE - COUNTER ROTATION
J175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEUC 1997	GEARCASE - COUNTER-ROTATION
J175GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175GLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175GLEUE 1997	GEARCASE - COUNTER-ROTATION
J175GLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175GLSDE	GEARCASE - PL - GL MODELS
J175GLSDE - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J175GLSOB	GEARCASE - PL - SL MODELS
J175GLSOB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J175GLSRM	GEARCASE - PL - GL MODELS
J175GLSRM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J175GLSTA	GEARCASE - CX, MODELS
J175GLSTA	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J175GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"

J175GLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J175GLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard
J175MXSOR	GEARCASE - ML - MX - PX MODELS
J175MXSRC	GEARCASE - ML - MX - PX MODELS
J175MXSRC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX
J175MXSTS	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J175MXSTS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J175NXARC 1994	GEARCASE - COUNTER ROTATION
J175NXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXARC 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXARV 1994	GEARCASE - COUNTER ROTATION
J175NXARV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXARV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXATG 1993	GEARCASE - COUNTER ROTATION
J175NXATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXATS 1993	GEARCASE - COUNTER ROTATION
J175NXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXATS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175NXECD 1998	GEARCASE -- COUNTER-ROTATION
J175NXECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175NXEDB 1996	GEARCASE - COUNTER-ROTATION
J175NXEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J175NXEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175NXENC 1992	GEARCASE - COUNTER ROTATION
J175NXENC 1992	GEARCASE - STANDARD ROTATION
J175NXEOM 1995	GEARCASE - COUNTER ROTATION
J175NXEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175NXERA 1994	GEARCASE - COUNTER ROTATION
J175NXERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

J175NXERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXERV 1994	GEARCASE - COUNTER ROTATION
J175NXERV 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXERV 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175NXETG 1993	GEARCASE - COUNTER ROTATION
J175NXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXETR 1993	GEARCASE - COUNTER ROTATION
J175NXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175NXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
J175NXEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175NXEUC 1997	GEARCASE - COUNTER-ROTATION
J175NXEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175NXEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175NXEUE 1997	GEARCASE - COUNTER-ROTATION
J175NXEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175PLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175PLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175PLSDD	GEARCASE - PL - GL MODELS
J175PLSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PL - GL MODELES
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J175PLSNF Carbureted, 20 in. shaft, Smoke 2002	GEARCASE - PL - VL - PX MODELS
J175PLSNF Carbureted, 20 in. shaft, Smoke 2002	GEARCASE - CX, MODELS
J175PLSOE	GEARCASE - PL - SL MODELS
J175PLSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL et SL
J175PLSRB	GEARCASE - PL - GL MODELS
J175PLSRB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles GL et PL
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS

J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175PLSTF	GEARCASE - STANDARD ROTATION - "F" Suffix Models
J175PLSTF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles suffixe "F" rotation standard
J175PLSTM	GEARCASE - CX, MODELS
J175PLSTM	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J175PLSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175PLSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175PXSDD	GEARCASE - PX MODELS
J175PXSDD - FR	17-1_BOÎTIER D'ENGRENAGES - PX MODELS
J175PXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175PXSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J175PXSNF Carbureted, 25 in. shaft, White 2002	GEARCASE - PL - VL - PX MODELS
J175PXSNF Carbureted, 25 in. shaft, White 2002	GEARCASE - CX, MODELS
J175PXSOE	GEARCASE - PX MODELS
J175PXSOE - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX
J175PXSRB	GEARCASE - ML - MX - PX MODELS
J175PXSRB - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles ML, MX et PX
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175PXSSC Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175PXSTM	GEARCASE - CX, MODELS
J175PXSTM	GEARCASE - PL - GL - ML - PX - MX MODELS \ With "M", "A", "S" Suffix
J175PXSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175PXSTM - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, GL, ML, PX, MX avec suffixe "M", "A" ou "S"
J175SLECD 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
J175SLECD 1998	GEARCASE -- COUNTER-ROTATION
J175SLECD 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
J175SLEDB 1996	GEARCASE - COUNTER-ROTATION

J175SLEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
J175SLEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEOM 1995	GEARCASE - COUNTER ROTATION
J175SLEOM 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175SLEOM 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
J175SLERA 1994	GEARCASE - COUNTER ROTATION
J175SLERA 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J175SLERA 1994	GEARCASE - STANDARD ROT.- 20"(150&175SL ONLY) ALL 25" MODELS
J175SLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEUC 1997	GEARCASE - COUNTER-ROTATION
J175SLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175SLEUE 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
J175SLEUE 1997	GEARCASE - COUNTER-ROTATION
J175SLEUE 1997	GEARCASE - STANDARD ROTATION - GL MODELS
J175SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL MODELS
J175SPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX AND 150 & 175 SPL MODELS
J175SPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175SPLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175STLACM 1988	GEARCASE - COUNTER ROTATION
J175STLACM 1988	GEARCASE - STANDARD ROTATION
J175STLCCM 1988	GEARCASE - COUNTER ROTATION
J175STLCCM 1988	GEARCASE - STANDARD ROTATION
J175STLCEB 1989	GEARCASE - COUNTER ROTATION
J175STLCEB 1989	GEARCASE - STANDARD ROTATION
J175STLEID 1991	GEARCASE - COUNTER ROTATION
J175STLEID 1991	GEARCASE - STANDARD ROTATION
J175STLESE 1990	GEARCASE - COUNTER ROTATION
J175STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J175STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J175TLCCM 1988	GEARCASE - COUNTER ROTATION
J175TLCCM 1988	GEARCASE - STANDARD ROTATION

J175TLCDR 1986	GEARCASE
J175TLCIH 1981	GEARCASE
J175TLCIM 1981	GEARCASE
J175TLCNB 1982	GEARCASE
J175TLCOC 1985	GEARCASE
J175TLCSA 1980	GEARCASE
J175TLCSF 1980	GEARCASE
J175TLCTD 1983	GEARCASE
J175TLCTE 1983	GEARCASE
J175TLCUA 1987	GEARCASE
J175TXCCM 1988	GEARCASE - COUNTER ROTATION
J175TXCCM 1988	GEARCASE - STANDARD ROTATION
J175TXCDR 1986	GEARCASE
J175TXCEB 1989	GEARCASE - COUNTER ROTATION
J175TXCEB 1989	GEARCASE - STANDARD ROTATION
J175TXCIH 1981	GEARCASE
J175TXCIM 1981	GEARCASE
J175TXCNB 1982	GEARCASE
J175TXCOC 1985	GEARCASE
J175TXCSA 1980	GEARCASE
J175TXCSF 1980	GEARCASE
J175TXCTD 1983	GEARCASE
J175TXCTE 1983	GEARCASE
J175TXCUA 1987	GEARCASE
J175TXEID 1991	GEARCASE - COUNTER ROTATION
J175TXEID 1991	GEARCASE - STANDARD ROTATION
J175TXESE 1990	GEARCASE - COUNTER ROTATION
J175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS

J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles CX
J175VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PL, PX et VL
J175VLSNF Carbureted, 20 in. shaft, White 2002	GEARCASE - PL - VL - PX MODELS
J175VLSNF Carbureted, 20 in. shaft, White 2002	GEARCASE - CX, MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VLSSS Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
J175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
J175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
J185ESERK 1994	GEARCASE - COUNTER ROTATION
J185ESERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J185ESERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXENR 1992	GEARCASE - COUNTER ROTATION
J185ESXENR 1992	GEARCASE - STANDARD ROTATION
J185ESXESS 1990	GEARCASE - COUNTER ROTATION
J185ESXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J185ESXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J185ESXETA 1993	GEARCASE - COUNTER ROTATION
J185ESXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J185ESXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXETF 1993	GEARCASE - COUNTER ROTATION
J185ESXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J185ESXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J185ESXW 1989	GEARCASE - COUNTER ROTATION
J185ESXW 1989	GEARCASE - STANDARD ROTATION

J185TLCOC 1985	GEARCASE
J185TLCRS 1984	GEARCASE
J185TXCOC 1985	GEARCASE
J185TXCR 1984	GEARCASE
J200CXARC 1994	GEARCASE - COUNTER ROTATION
J200CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXARK 1994	GEARCASE - COUNTER ROTATION
J200CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXATF 1993	GEARCASE - COUNTER ROTATION
J200CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXATS 1993	GEARCASE - COUNTER ROTATION
J200CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXCCR 1988	GEARCASE - COUNTER ROTATION
J200CXCCR 1988	GEARCASE - STANDARD ROTATION
J200CXCEA 1989	GEARCASE - COUNTER ROTATION
J200CXCEA 1989	GEARCASE - STANDARD ROTATION
J200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200CXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J200CXEDR 1996	GEARCASE - COUNTER-ROTATION
J200CXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200CXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200CXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200CXEIB 1991	GEARCASE - COUNTER ROTATION
J200CXEIB 1991	GEARCASE - STANDARD ROTATION

J200CXENE 1992	GEARCASE - COUNTER ROTATION
J200CXENE 1992	GEARCASE - STANDARD ROTATION
J200CXEOC 1995	GEARCASE - COUNTER ROTATION
J200CXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXERK 1994	GEARCASE - COUNTER ROTATION
J200CXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXERS 1994	GEARCASE - COUNTER ROTATION
J200CXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXESM 1990	GEARCASE - COUNTER ROTATION
J200CXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J200CXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J200CXETD 1993	GEARCASE - COUNTER ROTATION
J200CXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXETF 1993	GEARCASE - COUNTER ROTATION
J200CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXEUA 1997	GEARCASE - COUNTER-ROTATION
J200CXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CXSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200CXSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200CXSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200CXSE Elec. Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200CZARK 1994	GEARCASE - COUNTER ROTATION
J200CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZATF 1993	GEARCASE - COUNTER ROTATION
J200CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200CZATS 1993	GEARCASE - COUNTER ROTATION
J200CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZEOC 1995	GEARCASE - COUNTER ROTATION
J200CZEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZERK 1994	GEARCASE - COUNTER ROTATION
J200CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZERS 1994	GEARCASE - COUNTER ROTATION
J200CZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZETD 1993	GEARCASE - COUNTER ROTATION
J200CZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200CZETF 1993	GEARCASE - COUNTER ROTATION
J200CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PLEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PLEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS

J200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J200PXEEB 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J200PXEEB 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200STLACM 1988	GEARCASE - COUNTER ROTATION
J200STLACM 1988	GEARCASE - STANDARD ROTATION
J200STLCCM 1988	GEARCASE - COUNTER ROTATION
J200STLCCM 1988	GEARCASE - STANDARD ROTATION
J200STLCDR 1986	GEARCASE
J200STLCEB 1989	GEARCASE - COUNTER ROTATION
J200STLCEB 1989	GEARCASE - STANDARD ROTATION
J200STLCUA 1987	GEARCASE
J200STLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200STLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200STLECE 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J200STLEDM 1996	GEARCASE - COUNTER-ROTATION
J200STLEDM 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLEID 1991	GEARCASE - COUNTER ROTATION
J200STLEID 1991	GEARCASE - STANDARD ROTATION
J200STLENS 1992	GEARCASE - COUNTER ROTATION
J200STLENS 1992	GEARCASE - STANDARD ROTATION
J200STLEOA 1995	GEARCASE - COUNTER ROTATION
J200STLEOA 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLEOA 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLERK 1994	GEARCASE - COUNTER ROTATION
J200STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLERR 1994	GEARCASE - COUNTER ROTATION
J200STLERR 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

J200STLERR 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLESE 1990	GEARCASE - COUNTER ROTATION
J200STLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J200STLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J200STLETC 1993	GEARCASE - COUNTER ROTATION
J200STLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLETF 1993	GEARCASE - COUNTER ROTATION
J200STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200STLEUB 1997	GEARCASE - COUNTER-ROTATION
J200STLEUB 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200STLEUB 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TLCIH 1981	GEARCASE
J200TLCNE 1982	GEARCASE
J200TLCSF 1980	GEARCASE
J200TLCSM 1980	GEARCASE
J200TLCTD 1983	GEARCASE
J200TLCTS 1983	GEARCASE
J200TLECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200TLECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200TLECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J200TXARC 1994	GEARCASE - COUNTER ROTATION
J200TXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXARK 1994	GEARCASE - COUNTER ROTATION
J200TXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXATF 1993	GEARCASE - COUNTER ROTATION
J200TXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXATS 1993	GEARCASE - COUNTER ROTATION
J200TXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J200TXCCR 1988	GEARCASE - COUNTER ROTATION
J200TXCCR 1988	GEARCASE - STANDARD ROTATION
J200TXCDS 1986	GEARCASE
J200TXCEA 1989	GEARCASE - COUNTER ROTATION
J200TXCEA 1989	GEARCASE - STANDARD ROTATION
J200TXCIB 1981	GEARCASE
J200TXCIH 1981	GEARCASE
J200TXCNE 1982	GEARCASE
J200TXCSF 1980	GEARCASE
J200TXCSM 1980	GEARCASE
J200TXCTD 1983	GEARCASE
J200TXCTS 1983	GEARCASE
J200TXCUC 1987	GEARCASE
J200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J200TXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J200TXEDR 1996	GEARCASE - COUNTER-ROTATION
J200TXEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXEIB 1991	GEARCASE - COUNTER ROTATION
J200TXEIB 1991	GEARCASE - STANDARD ROTATION
J200TXENE 1992	GEARCASE - COUNTER ROTATION
J200TXENE 1992	GEARCASE - STANDARD ROTATION
J200TXEOC 1995	GEARCASE - COUNTER ROTATION
J200TXEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXERK 1994	GEARCASE - COUNTER ROTATION
J200TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXERS 1994	GEARCASE - COUNTER ROTATION
J200TXERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXESM 1990	GEARCASE - COUNTER ROTATION
J200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION

J200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J200TXETD 1993	GEARCASE - COUNTER ROTATION
J200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXETF 1993	GEARCASE - COUNTER ROTATION
J200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TXEUA 1997	GEARCASE - COUNTER-ROTATION
J200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZARK 1994	GEARCASE - COUNTER ROTATION
J200TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZATF 1993	GEARCASE - COUNTER ROTATION
J200TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZATS 1993	GEARCASE - COUNTER ROTATION
J200TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZE0C 1995	GEARCASE - COUNTER ROTATION
J200TZE0C 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZE0C 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZERK 1994	GEARCASE - COUNTER ROTATION
J200TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZERS 1994	GEARCASE - COUNTER ROTATION
J200TZERS 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZERS 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZETD 1993	GEARCASE - COUNTER ROTATION
J200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200TZETF 1993	GEARCASE - COUNTER ROTATION
J200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS

J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J200WPXEEN 1999	GEARCASE
J200WPXEES 1999	GEARCASE
J200WPXSIF commercial, elec start, TNT, 25 in shaft 2001	GEARCASE
J200WPXSSC Commercial, Elec Start, TNT, 25 IN shaft 2000	GEARCASE
J225CLCUB 1987	GEARCASE
J225CXARC 1994	GEARCASE - COUNTER ROTATION
J225CXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXARK 1994	GEARCASE - COUNTER ROTATION
J225CXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225CXATF 1993	GEARCASE - COUNTER ROTATION
J225CXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXATS 1993	GEARCASE - COUNTER ROTATION
J225CXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XCCE 1988	GEARCASE - COUNTER ROTATION
J225XCCE 1988	GEARCASE - STANDARD ROTATION
J225XCED 1989	GEARCASE - COUNTER ROTATION
J225XCED 1989	GEARCASE - STANDARD ROTATION
J225XCUB 1987	GEARCASE
J225XECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225XECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225XECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225XEDE 1996	GEARCASE - COUNTER-ROTATION
J225XEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225XEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XEED 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225XEED 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225XEED 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225XEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225XEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225XEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225XEIC 1991	GEARCASE - COUNTER ROTATION
J225XEIC 1991	GEARCASE - STANDARD ROTATION
J225XENR 1992	GEARCASE - COUNTER ROTATION
J225XENR 1992	GEARCASE - STANDARD ROTATION
J225XEEOB 1995	GEARCASE - COUNTER ROTATION
J225XEEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225XEEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XERK 1994	GEARCASE - COUNTER ROTATION
J225XERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225XERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XERM 1994	GEARCASE - COUNTER ROTATION

J225CXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXESS 1990	GEARCASE - COUNTER ROTATION
J225CXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225CXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225CXETA 1993	GEARCASE - COUNTER ROTATION
J225CXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXETF 1993	GEARCASE - COUNTER ROTATION
J225CXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXEUD 1997	GEARCASE - COUNTER-ROTATION
J225CXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225CXSSR Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225CZARK 1994	GEARCASE - COUNTER ROTATION
J225CZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZATF 1993	GEARCASE - COUNTER ROTATION
J225CZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZATS 1993	GEARCASE - COUNTER ROTATION
J225CZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225CZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225CZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225CZEDE 1996	GEARCASE - COUNTER-ROTATION
J225CZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225CZEOB 1995	GEARCASE - COUNTER ROTATION
J225CZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZERK 1994	GEARCASE - COUNTER ROTATION
J225CZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZERM 1994	GEARCASE - COUNTER ROTATION
J225CZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZETA 1993	GEARCASE - COUNTER ROTATION
J225CZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZETF 1993	GEARCASE - COUNTER ROTATION
J225CZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225CZEUD 1997	GEARCASE - COUNTER-ROTATION
J225CZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225CZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225HGLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225HGLSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225HPLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225HPLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225HPLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225HPLEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225HPLEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225HPLEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS

J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225HPLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225HPLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PLAED 1989	GEARCASE - COUNTER ROTATION
J225PLAED 1989	GEARCASE - STANDARD ROTATION
J225PLASS 1990	GEARCASE - COUNTER ROTATION
J225PLASS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225PLASS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225PLCCE 1988	GEARCASE - COUNTER ROTATION
J225PLCCE 1988	GEARCASE - STANDARD ROTATION
J225PLCED 1989	GEARCASE - COUNTER ROTATION
J225PLCED 1989	GEARCASE - STANDARD ROTATION
J225PLCUB 1987	GEARCASE
J225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PLEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PLEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PLEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PLEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PLEIC 1991	GEARCASE - COUNTER ROTATION
J225PLEIC 1991	GEARCASE - STANDARD ROTATION
J225PLENR 1992	GEARCASE - COUNTER ROTATION
J225PLENR 1992	GEARCASE - STANDARD ROTATION
J225PLERK 1994	GEARCASE - COUNTER ROTATION
J225PLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLERM 1994	GEARCASE - COUNTER ROTATION
J225PLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLESS 1990	GEARCASE - COUNTER ROTATION

J225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225PLETA 1993	GEARCASE - COUNTER ROTATION
J225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLETF 1993	GEARCASE - COUNTER ROTATION
J225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PTLCDA 1986	GEARCASE
J225PTXCDA 1986	GEARCASE
J225PXARC 1994	GEARCASE - COUNTER ROTATION
J225PXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXARK 1994	GEARCASE - COUNTER ROTATION
J225PXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXATF 1993	GEARCASE - COUNTER ROTATION
J225PXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXATS 1993	GEARCASE - COUNTER ROTATION
J225PXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXCCE 1988	GEARCASE - COUNTER ROTATION
J225PXCCE 1988	GEARCASE - STANDARD ROTATION
J225PXCED 1989	GEARCASE - COUNTER ROTATION
J225PXCED 1989	GEARCASE - STANDARD ROTATION

J225PXCUB 1987	GEARCASE
J225PXEDE 1996	GEARCASE - COUNTER-ROTATION
J225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PXEEC 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PXEEC 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J225PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J225PXEEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J225PXEIC 1991	GEARCASE - COUNTER ROTATION
J225PXEIC 1991	GEARCASE - STANDARD ROTATION
J225PXENR 1992	GEARCASE - COUNTER ROTATION
J225PXENR 1992	GEARCASE - STANDARD ROTATION
J225PXEOB 1995	GEARCASE - COUNTER ROTATION
J225PXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXERK 1994	GEARCASE - COUNTER ROTATION
J225PXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXERM 1994	GEARCASE - COUNTER ROTATION
J225PXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXESS 1990	GEARCASE - COUNTER ROTATION
J225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225PXETA 1993	GEARCASE - COUNTER ROTATION
J225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXETF 1993	GEARCASE - COUNTER ROTATION
J225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS

J225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225PZARK 1994	GEARCASE - COUNTER ROTATION
J225PZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZATF 1993	GEARCASE - COUNTER ROTATION
J225PZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZATS 1993	GEARCASE - COUNTER ROTATION
J225PZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZEOB 1995	GEARCASE - COUNTER ROTATION
J225PZEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZERK 1994	GEARCASE - COUNTER ROTATION
J225PZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZERM 1994	GEARCASE - COUNTER ROTATION
J225PZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZETA 1993	GEARCASE - COUNTER ROTATION
J225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225PZETF 1993	GEARCASE - COUNTER ROTATION
J225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225STLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225STLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225STLEDE 1996	GEARCASE - COUNTER-ROTATION
J225STLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLEOB 1995	GEARCASE - COUNTER ROTATION
J225STLEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS

J225STLERC 1994	GEARCASE - COUNTER ROTATION
J225STLERC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLERC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLERK 1994	GEARCASE - COUNTER ROTATION
J225STLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLETF 1993	GEARCASE - COUNTER ROTATION
J225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225STLEUD 1997	GEARCASE - COUNTER-ROTATION
J225STLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225STLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLAED 1989	GEARCASE - COUNTER ROTATION
J225TLAED 1989	GEARCASE - STANDARD ROTATION
J225TLASS 1990	GEARCASE - COUNTER ROTATION
J225TLASS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225TLASS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225TLCCE 1988	GEARCASE - COUNTER ROTATION
J225TLCCE 1988	GEARCASE - STANDARD ROTATION
J225TLCDA 1986	GEARCASE
J225TLCED 1989	GEARCASE - COUNTER ROTATION
J225TLCED 1989	GEARCASE - STANDARD ROTATION
J225TLCUB 1987	GEARCASE
J225TLEIC 1991	GEARCASE - COUNTER ROTATION
J225TLEIC 1991	GEARCASE - STANDARD ROTATION
J225TLENR 1992	GEARCASE - COUNTER ROTATION
J225TLENR 1992	GEARCASE - STANDARD ROTATION
J225TLERK 1994	GEARCASE - COUNTER ROTATION
J225TLERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TLERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLERM 1994	GEARCASE - COUNTER ROTATION
J225TLERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TLERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLESS 1990	GEARCASE - COUNTER ROTATION
J225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION

J225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225TLETA 1993	GEARCASE - COUNTER ROTATION
J225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TLETF 1993	GEARCASE - COUNTER ROTATION
J225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXARC 1994	GEARCASE - COUNTER ROTATION
J225TXARC 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXARC 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXARK 1994	GEARCASE - COUNTER ROTATION
J225TXARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXATF 1993	GEARCASE - COUNTER ROTATION
J225TXATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXATS 1993	GEARCASE - COUNTER ROTATION
J225TXATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXCCE 1988	GEARCASE - COUNTER ROTATION
J225TXCCE 1988	GEARCASE - STANDARD ROTATION
J225TXCDA 1986	GEARCASE
J225TXCED 1989	GEARCASE - COUNTER ROTATION
J225TXCED 1989	GEARCASE - STANDARD ROTATION
J225XCUB 1987	GEARCASE
J225XECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225XECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225XECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J225XEDE 1996	GEARCASE - COUNTER-ROTATION
J225XEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225XEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225XEIC 1991	GEARCASE - COUNTER ROTATION
J225XEIC 1991	GEARCASE - STANDARD ROTATION
J225XENR 1992	GEARCASE - COUNTER ROTATION

J225TXENR 1992	GEARCASE - STANDARD ROTATION
J225TXEOB 1995	GEARCASE - COUNTER ROTATION
J225TXEOB 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXEOB 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXERK 1994	GEARCASE - COUNTER ROTATION
J225TXERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXERM 1994	GEARCASE - COUNTER ROTATION
J225TXERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXESS 1990	GEARCASE - COUNTER ROTATION
J225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
J225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
J225TXETA 1993	GEARCASE - COUNTER ROTATION
J225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXETF 1993	GEARCASE - COUNTER ROTATION
J225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TXEUD 1997	GEARCASE - COUNTER-ROTATION
J225TXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZARK 1994	GEARCASE - COUNTER ROTATION
J225TZARK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZARK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZATF 1993	GEARCASE - COUNTER ROTATION
J225TZATF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZATF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZATS 1993	GEARCASE - COUNTER ROTATION
J225TZATS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZATS 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225ZECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J225ZECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J225ZECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS

J225TZEDE 1996	GEARCASE - COUNTER-ROTATION
J225TZEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZE0B 1995	GEARCASE - COUNTER ROTATION
J225TZE0B 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZE0B 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZERK 1994	GEARCASE - COUNTER ROTATION
J225TZERK 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZERK 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZERM 1994	GEARCASE - COUNTER ROTATION
J225TZERM 1994	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZERM 1994	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZETA 1993	GEARCASE - COUNTER ROTATION
J225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZETF 1993	GEARCASE - COUNTER ROTATION
J225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225TZEUD 1997	GEARCASE - COUNTER-ROTATION
J225TZEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
J225TZEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VCXSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS

J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J235STLCOR 1985	GEARCASE
J235STLCRC 1984	GEARCASE
J235STLCTS 1983	GEARCASE
J235TLCIB 1981	GEARCASE
J235TLCIH 1981	GEARCASE
J235TLCNE 1982	GEARCASE
J235TLCOR 1985	GEARCASE
J235TLCRC 1984	GEARCASE
J235TLCSM 1980	GEARCASE
J235TLCTD 1983	GEARCASE
J235TLCTS 1983	GEARCASE
J235TXCIB 1981	GEARCASE
J235TXCIH 1981	GEARCASE
J235TXCNE 1982	GEARCASE
J235TXCOR 1985	GEARCASE
J235TXCRC 1984	GEARCASE
J235TXCSM 1980	GEARCASE
J235TXCTD 1983	GEARCASE
J235TXCTS 1983	GEARCASE
J250CXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250CXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250CXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CXEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS

J250CXEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CXEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CXEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CXEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250CZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250CZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250CZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250CZEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CZEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CZEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CZEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250CZEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250CZEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250CZSSC Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250PXECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250PXECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250PXECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PXEEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PXEEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PXEEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PXEEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS

J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250PZECD 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
J250PZECD 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
J250PZECD 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
J250PZEEN 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PZEEN 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PZEEN 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PZEES 1999	GEARCASE -- STANDARD ROTATION -- PL, HPL MODELS
J250PZEES 1999	GEARCASE -- STANDARD ROTATION -- PX, PZ MODELS
J250PZEES 1999	GEARCASE -- COUNTER-ROTATION -- CX, CZ MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250PZSSC Elec. Start, TNT, 30 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VCXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VCZSIF elec start, TNT, 30 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VCZSSS Elec. Start, TNT, 30 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS

J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
J250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
J250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
J90ELECM 1998	GEARCASE -- 90 & 115 SX MODELS
J90ELEDR 1996	GEARCASE - 25 IN. MODELS
J90ELEOC 1995	GEARCASE - 25 IN. MODELS
J90ELEUA 1997	GEARCASE - 25 IN. MODELS
J90ELEUC 1997	GEARCASE - 25 IN. MODELS
J90EXEOC 1995	GEARCASE - 25 IN. MODELS
J90FSLECS 1998	GEARCASE -- FSX MODELS
J90FTLECS 1998	GEARCASE -- FSX MODELS
J90GLSTA	GEARCASE - PX - WPL MODELS
J90GLSTA - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J90PLEEB 1999	GEARCASE -- 90 & 115 PX MODELS
J90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
J90PLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PXS
J90PLSNF Carbureted, 20 in. shaft, Smoke, Remote, Elec, TNT 2002	GEARCASE - PXS MODELS
J90PLSSE Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J90PLSTC	GEARCASE - PX - WPL MODELS
J90PLSTC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J90PXSDR	GEARCASE - PX MODELS

J90PXSDR - FR	17-1_BOÎTIER D'ENGRENAGES - PX MODELES
J90PXSOC	GEARCASE - PX - WPL MODELS
J90PXSOC - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J90PXSRS	GEARCASE - PX - WPL MODELS
J90PXSRS - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PX et WPL
J90SLECM 1998	GEARCASE -- 90 & 115 SX MODELS
J90SLEDR 1996	GEARCASE - 25 IN. MODELS
J90SLEOC 1995	GEARCASE - 25 IN. MODELS
J90SLEUA 1997	GEARCASE - 25 IN. MODELS
J90SLEUC 1997	GEARCASE - 25 IN. MODELS
J90SPLEES 1999	GEARCASE -- 90 & 115 PX MODELS
J90SPLSSC Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
J90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
J90VLSNF - FR	27-1_BOÎTIER D'ENGRENAGES - Modèles PXS
J90VLSNF Carbureted, 20 in. shaft, White, Remote, Elec, TNT 2002	GEARCASE - PXS MODELS
J90VLSSE Elec. Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - 90 AND 115 PX, VX MODELS
L115GLECA 1998	GEARCASE -- 90 & 115 SX MODELS
L115GLEDC 1996	GEARCASE - 25 IN. MODELS
L115GLEOS 1995	GEARCASE - 25 IN. MODELS
L115GLEUC 1997	GEARCASE - 25 IN. MODELS
L115GLEUR 1997	GEARCASE - 25 IN. MODELS
L150GLECA 1998	GEARCASE-STD ROTATION-20" 150SL, EL, 175SL & ALL 25" MODELS
L150GLECA 1998	GEARCASE -- COUNTER-ROTATION
L150GLECA 1998	GEARCASE -- STANDARD ROTATION -- GL MODELS
L150GLEDC 1996	GEARCASE - COUNTER-ROTATION
L150GLEDC 1996	GEARCASE - STANDARD ROTATION - GL MODELS
L150GLEDC 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEOS 1995	GEARCASE - COUNTER ROTATION
L150GLEOS 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
L150GLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
L150GLEUC 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEUC 1997	GEARCASE - COUNTER-ROTATION
L150GLEUC 1997	GEARCASE - STANDARD ROTATION - GL MODELS

L150GLEUR 1997	GEARCASE-STANDARD ROTATION - 20" 150SL, EL, 175SL & ALL 25"
L150GLEUR 1997	GEARCASE - COUNTER-ROTATION
L150GLEUR 1997	GEARCASE - STANDARD ROTATION - GL MODELS
L90GLECS 1998	GEARCASE -- 90 & 115 SX MODELS
LE200SLEDR 1996	GEARCASE - COUNTER-ROTATION
LE200SLEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LE200SLEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LE200SLEOC 1995	GEARCASE - COUNTER ROTATION
LE200SLEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LE200SLEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LJ200SLEDR 1996	GEARCASE - COUNTER-ROTATION
LJ200SLEDR 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LJ200SLEDR 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
LJ200SLEOC 1995	GEARCASE - COUNTER ROTATION
LJ200SLEOC 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
LJ200SLEOC 1995	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
MISCELLANEOUS 1980	COUNTER ROTATION GEARCASE V-6 MODELS
MISCELLANEOUS 1981	COUNTER ROTATION GEARCASE V-6 MODELS
MISCELLANEOUS 1982	COUNTER ROTATION GEARCASE V-6 MODELS
MISCELLANEOUS 1983	COUNTER ROTATION GEARCASE V-6 MODELS
RE115FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE115FLSSSH FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FLSSSR FFI, Elec Start, TNT, 20 IN.shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
RE115FSSSH FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FSSSR FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - FPX, FX MODELS
RE115FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - FPX - FX MODELS
RE115FXSSH FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE115FXSSR FFI, Elec Start, TNT, 25 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS

RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FCSSS FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FLSSS FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE135FXSSS FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSSM FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS

RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSM FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FSSV FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSSM FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE150FXSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS

RE175FCSSR FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FCSSV FFI, Elec Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FLSSV FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FSSC FFI, Elec Start, TNT, 20 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FPL - FL MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSSR FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FPL, FL MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - FSL, FS, FPX, FX MODELS
RE175FXSSV FFI, Elec Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - FCX, FC MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS

RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
RE200FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FSSH FFI, Elec Start, TNT, 20 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FSSIF FFI, elec start, TNT, 20 in shaft, wht 2001	GEARCASE - Counter Rotation
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE200FXSIF FFI, elec start, TNT, 25 in shaft 2001	GEARCASE - Counter Rotation
RE200FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE200FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FCSIF FFI, elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - Counter Rotation
RE225FCSSC FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation

RE225FCSSH FFI, Elec Start, TNT, 25 IN shaft, wht, cntr rotate 2000	GEARCASE - Counter Rotation
RE225FGSSC FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FGSSH FFI, Elec Start, TNT, 20 IN shaft, hs gc 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FHSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - Counter Rotation
RE225FHSSS FFI, Elec Start, TNT, 20 IN shaft, hs gc, HO 2000	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FLSSC FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FLSSH FFI, Elec Start, TNT, 20 IN shaft 2000	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FXSIF FFI, elec start, TNT, 25 in shaft, wht 2001	GEARCASE - Counter Rotation
RE225FXSSC FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FXSSH FFI, Elec Start, TNT, 25 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FL - FPL - FSL - FS MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - FH - FHL MODELS
RE225FZSIF FFI, elec start, TNT, 30 in shaft, wht 2001	GEARCASE - Counter Rotation
RE225FZSSH FFI, Elec Start, TNT, 30 IN shaft, wht 2000	GEARCASE - STANDARD ROTATION - FX - FPX - FZ - FPZ MODELS
RE75FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE75FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE90FPLSIF FFI, elec start, TNT, 20 in shaft 2001	GEARCASE - FPX - FX MODELS
RE90FPLSSH FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RE90FPLSSR FFI, Elec Start, TNT, 20 IN. shaft 2000	GEARCASE - FPX, FX MODELS
RJ115PLSIE elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
RJ115PLSSB Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS

RJ115PXSSB Elec. Start, TNT, 25 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ115VLSSB Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ115VXSIC elec start, TNT, 25 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ115VXSSS Elec. Start, TNT, 25 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ130PLSSS Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE
RJ130PXSSS Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE
RJ130VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE
RJ135PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE
RJ135VXSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150CXSSC Elec. Start, TNT, 25 IN. shaft, cntr. Rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VCSIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VCSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS

RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VLSIF elec start, TNT, 20 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VLSSS Elec. Start, TNT, 20 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ150VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ150VXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175CXsIF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS
RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL, VX MODELS
RJ175VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VC - VCX MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, VL, VX & SPL MODELS
RJ175VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, VC, VCX MODELS

RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ200PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200PLSSC Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200PXSSC Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ200VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ200VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225CXSF elec start, TNT, 25 in shaft, wht, cntr rotate 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225CXSSS Elec Start, TNT, 25 IN. shaft, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS

RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225HGSSC Elec. Start, TNT, 20 IN. shaft, H.O., HS GC 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225HLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225HLSSC Elec. Start, TNT, 20 IN. shaft, H.O. 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225PLSIF elec start, TNT, 20 in shaft 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225PLSSR Elec. Start, TNT, 20 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225PXSSR Elec. Start, TNT, 25 IN. shaft 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ225VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ225VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS

RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250CXSSS Elec. Start, TNT, 25 IN. shaft, wht, cntr rotate 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ250VXSIF elec start, TNT, 25 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250VXSSS Elec. Start, TNT, 25 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VL - HGL MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - PL - HPL - HL MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - STANDARD ROTATION - VX - VZ MODELS
RJ250VZSSIF elec start, TNT, 30 in shaft, wht 2001	GEARCASE - COUNTER ROTATION - CX - VCX - VC - VCZ MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - HG, HGL MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PL, HPL MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - STANDARD ROTATION - PX, PZ MODELS
RJ250VZSSS Elec. Start, TNT, 30 IN. shaft, wht 2000	GEARCASE - COUNTER ROTATION - CX, CZ MODELS
RJ90PLSID elec start, TNT, 20 in shaft 2001	GEARCASE - 90 - 115 VX MODELS
RJ90PLSSE Elec. Start, TNT, 20 IN. shaft, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
RJ90VLSIC elec start, TNT, 20 in shaft, wht 2001	GEARCASE - 90 - 115 VX MODELS
RJ90VLSSE Elec. Start, 20 IN. shaft, wht, N/A USA 2000	GEARCASE - 90 AND 115 PX, VX MODELS
SE105RWLH 1998	GEARCASE
SE105RWLP 1997	GEARCASE
SE105RWYH 1998	GEARCASE
SE105RWYP 1997	GEARCASE
SE105WELV 1998	GEARCASE
SE105WEXV 1998	GEARCASE
SE105WRPLV 1998	GEARCASE
SE105WRPXV 1998	GEARCASE
SE125RWYJ 1997	GEARCASE
SE125RWYN 1998	GEARCASE

SE125RWYV 1996	GEARCASE
SE125WTPLJ 1997	GEARCASE
SE125WTPLN 1998	GEARCASE
SE125WTPLV 1996	GEARCASE
SE125WTPXJ 1997	GEARCASE
SE125WTPXN 1998	GEARCASE
SE125WTPXV 1996	GEARCASE
SE150WTPLB 1996	GEARCASE
SE150WTPLT 1997	GEARCASE
SE150WTPLT4 1997	GEARCASE
SE150WTPLY 1998	GEARCASE
SE150WTPXB 1996	GEARCASE
SE150WTPXT 1997	GEARCASE
SE150WTPXT4 1997	GEARCASE
SE150WTPXY 1998	GEARCASE
SE200WTPLA 1996	GEARCASE
SE200WTPLG 1998	GEARCASE
SE200WTPLS 1997	GEARCASE
SE200WTPXA 1996	GEARCASE
SE200WTPXG 1998	GEARCASE
SE200WTPXS 1997	GEARCASE
SE225GLECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225GLECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225GLECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SE225NXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225NXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225NXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SE225NZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225NZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225NZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SE225QXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225QXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225QXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS

SE225QZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SE225QZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SE225QZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ105RWLH 1998	GEARCASE
SJ105RWLP 1997	GEARCASE
SJ105RWYH 1998	GEARCASE
SJ105RWYP 1997	GEARCASE
SJ105WELV 1998	GEARCASE
SJ105WEXV 1998	GEARCASE
SJ105WRPLV 1998	GEARCASE
SJ105WRPXV 1998	GEARCASE
SJ115ELEDR 1996	GEARCASE - 25 IN. MODELS
SJ125RWYJ 1997	GEARCASE
SJ125RWYN 1998	GEARCASE
SJ125RWYV 1996	GEARCASE
SJ125WTPLJ 1997	GEARCASE
SJ125WTPLN 1998	GEARCASE
SJ125WTPLV 1996	GEARCASE
SJ125WTPXJ 1997	GEARCASE
SJ125WTPXN 1998	GEARCASE
SJ125WTPXV 1996	GEARCASE
SJ130CXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ130TLEDM 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ130TXADA 1996	GEARCASE - 130TL & 130TX STANDARD ROTATION
SJ150ELEDB 1996	GEARCASE - COUNTER-ROTATION
SJ150ELEDB 1996	GEARCASE - STANDARD ROTATION - GL MODELS
SJ150ELEDB 1996	GEARCASE - STD. ROTATION - 20" 150SL, EL, 175SL & ALL 25"
SJ150WTPLB 1996	GEARCASE
SJ150WTPLT 1997	GEARCASE
SJ150WTPLT4 1997	GEARCASE
SJ150WTPLY 1998	GEARCASE
SJ150WTPXB 1996	GEARCASE
SJ150WTPXT 1997	GEARCASE
SJ150WTPXT4 1997	GEARCASE

SJ150WTPXY 1998	GEARCASE
SJ200CXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200CXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200CXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ200CXEUA 1997	GEARCASE - COUNTER-ROTATION
SJ200CXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200CXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200SLECE 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200SLECE 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200SLECE 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ200SLEDM 1996	GEARCASE - COUNTER-ROTATION
SJ200SLEDM 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200SLEDM 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200SLEUB 1997	GEARCASE - COUNTER-ROTATION
SJ200SLEUB 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200SLEUB 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200TXECM 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ200TXECM 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ200TXECM 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ200TXEUA 1997	GEARCASE - COUNTER-ROTATION
SJ200TXEUA 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ200TXEUA 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ200WTPLA 1996	GEARCASE
SJ200WTPLG 1998	GEARCASE
SJ200WTPLS 1997	GEARCASE
SJ200WTPXA 1996	GEARCASE
SJ200WTPXG 1998	GEARCASE
SJ200WTPXS 1997	GEARCASE
SJ225CXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225CXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225CXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225CXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225CXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

SJ225CXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225CXEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225CXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225CXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225GLECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225GLECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225GLECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225NXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225NXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225NXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225NZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225NZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225NZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225PXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225PXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225PXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225QXECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225QXECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225QXECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225QZECC 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225QZECC 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225QZECC 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225SLECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS
SJ225SLECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225SLECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225SLEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225SLEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225SLEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225SLEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225SLEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225SLEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225TXECS 1998	GEARCASE - STANDARD ROTATION - PX, PZ, TL, TX, TZ, QX MODELS

SJ225TXECS 1998	GEARCASE -- COUNTER-ROTATION -- CX, CZ, NX MODELS
SJ225TXECS 1998	GEARCASE -- STANDARD ROTATION -- GL, SL, & STL MODELS
SJ225TXEDE 1996	GEARCASE - COUNTER-ROTATION
SJ225TXEDE 1996	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225TXEDE 1996	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ225TXEUD 1997	GEARCASE - COUNTER-ROTATION
SJ225TXEUD 1997	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
SJ225TXEUD 1997	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
SJ90ELEDR 1996	GEARCASE - 25 IN. MODELS
TE120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
TE120TXCEM 1989	GEARCASE - 140CX COUNTER ROTATION
TE150GLEIS 1991	GEARCASE - COUNTER ROTATION
TE150GLEIS 1991	GEARCASE - STANDARD ROTATION
TE150GLENC 1992	GEARCASE - COUNTER ROTATION
TE150GLENC 1992	GEARCASE - STANDARD ROTATION
TE150GLETG 1993	GEARCASE - COUNTER ROTATION
TE150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TE150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TE150GLETR 1993	GEARCASE - COUNTER ROTATION
TE150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TE150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TE150SLCEM 1989	GEARCASE
TE150SLEIE 1991	GEARCASE
TE150SLESB 1990	GEARCASE EARLY PRODUCTION
TE150SLESB 1990	GEARCASE LATE PRODUCTION
TE150TXCEM 1989	GEARCASE - COUNTER ROTATION
TE150TXCEM 1989	GEARCASE - STANDARD ROTATION
TE200TXCEA 1989	GEARCASE - COUNTER ROTATION
TE200TXCEA 1989	GEARCASE - STANDARD ROTATION
TJ120TXCEM 1989	GEARCASE - 140TX STANDARD ROTATION
TJ120TXCEM 1989	GEARCASE - 140CX COUNTER ROTATION
TJ150GLEIS 1991	GEARCASE - COUNTER ROTATION
TJ150GLEIS 1991	GEARCASE - STANDARD ROTATION
TJ150GLENC 1992	GEARCASE - COUNTER ROTATION
TJ150GLENC 1992	GEARCASE - STANDARD ROTATION

TJ150GLETG 1993	GEARCASE - COUNTER ROTATION
TJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TJ150GLETR 1993	GEARCASE - COUNTER ROTATION
TJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
TJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
TJ150SLCEM 1989	GEARCASE
TJ150SLEIE 1991	GEARCASE
TJ150SLESB 1990	GEARCASE EARLY PRODUCTION
TJ150SLESB 1990	GEARCASE LATE PRODUCTION
TJ150TXCEM 1989	GEARCASE - COUNTER ROTATION
TJ150TXCEM 1989	GEARCASE - STANDARD ROTATION
TJ200TXCEA 1989	GEARCASE - COUNTER ROTATION
TJ200TXCEA 1989	GEARCASE - STANDARD ROTATION
V150SLETG 1993	GEARCASE - COUNTER ROTATION
V150SLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
V150SLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
V150SLETS 1993	GEARCASE - COUNTER ROTATION
V150SLETS 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
V150SLETS 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE120LEIE 1991	GEARCASE - 140TX STANDARD ROTATION
VE120LEIE 1991	GEARCASE - 140CX COUNTER ROTATION
VE120TLEND 1992	GEARCASE - 140TX STANDARD ROTATION
VE120TLEND 1992	GEARCASE - 140CX COUNTER ROTATION
VE120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
VE120TLESB 1990	GEARCASE - 140CX COUNTER ROTATION
VE120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TXEIE 1991	GEARCASE - 140TX STANDARD ROTATION
VE120TXEIE 1991	GEARCASE - 140CX COUNTER ROTATION
VE120TXEND 1992	GEARCASE - 140TX STANDARD ROTATION
VE120TXEND 1992	GEARCASE - 140CX COUNTER ROTATION
VE120TXESB 1990	GEARCASE - 140TX STANDARD ROTATION

VE120TXESB 1990	GEARCASE - 140CX COUNTER ROTATION
VE120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
VE120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
VE140TLEID 1991	GEARCASE - 140CX COUNTER ROTATION
VE140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
VE140TLENS 1992	GEARCASE - 140CX COUNTER ROTATION
VE140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
VE140TLESE 1990	GEARCASE - 140CX COUNTER ROTATION
VE140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TXEID 1991	GEARCASE - 140TX STANDARD ROTATION
VE140TXEID 1991	GEARCASE - 140CX COUNTER ROTATION
VE140TXENS 1992	GEARCASE - 140TX STANDARD ROTATION
VE140TXENS 1992	GEARCASE - 140CX COUNTER ROTATION
VE140TXESE 1990	GEARCASE - 140TX STANDARD ROTATION
VE140TXESE 1990	GEARCASE - 140CX COUNTER ROTATION
VE140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VE140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VE150ELEIS 1991	GEARCASE - COUNTER ROTATION
VE150ELEIS 1991	GEARCASE - STANDARD ROTATION
VE150ELENC 1992	GEARCASE - COUNTER ROTATION
VE150ELENC 1992	GEARCASE - STANDARD ROTATION
VE150ELETG 1993	GEARCASE - COUNTER ROTATION
VE150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150ELETR 1993	GEARCASE - COUNTER ROTATION
VE150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

VE150EXEIS 1991	GEARCASE - COUNTER ROTATION
VE150EXEIS 1991	GEARCASE - STANDARD ROTATION
VE150EXENC 1992	GEARCASE - COUNTER ROTATION
VE150EXENC 1992	GEARCASE - STANDARD ROTATION
VE150EXETG 1993	GEARCASE - COUNTER ROTATION
VE150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150EXETR 1993	GEARCASE - COUNTER ROTATION
VE150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150GLEIS 1991	GEARCASE - COUNTER ROTATION
VE150GLEIS 1991	GEARCASE - STANDARD ROTATION
VE150GLETG 1993	GEARCASE - COUNTER ROTATION
VE150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150GLETR 1993	GEARCASE - COUNTER ROTATION
VE150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE150HLEOS 1995	GEARCASE - COUNTER ROTATION
VE150HLEOS 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE150HLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
VE150SLEIE 1991	GEARCASE
VE150SLESB 1990	GEARCASE EARLY PRODUCTION
VE150SLESB 1990	GEARCASE LATE PRODUCTION
VE150TLEIE 1991	GEARCASE - COUNTER ROTATION
VE150TLEIE 1991	GEARCASE - STANDARD ROTATION
VE150TLESB 1990	GEARCASE - COUNTER ROTATION
VE150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE150TXEIE 1991	GEARCASE - COUNTER ROTATION
VE150TXEIE 1991	GEARCASE - STANDARD ROTATION
VE150TXESB 1990	GEARCASE - COUNTER ROTATION
VE150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION

VE175EXEIS 1991	GEARCASE - COUNTER ROTATION
VE175EXEIS 1991	GEARCASE - STANDARD ROTATION
VE175EXENC 1992	GEARCASE - COUNTER ROTATION
VE175EXENC 1992	GEARCASE - STANDARD ROTATION
VE175EXETG 1993	GEARCASE - COUNTER ROTATION
VE175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175EXETR 1993	GEARCASE - COUNTER ROTATION
VE175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175GLEIS 1991	GEARCASE - COUNTER ROTATION
VE175GLEIS 1991	GEARCASE - STANDARD ROTATION
VE175GLENC 1992	GEARCASE - COUNTER ROTATION
VE175GLENC 1992	GEARCASE - STANDARD ROTATION
VE175GLETG 1993	GEARCASE - COUNTER ROTATION
VE175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175GLETR 1993	GEARCASE - COUNTER ROTATION
VE175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VE175SLEID 1991	GEARCASE - COUNTER ROTATION
VE175SLEID 1991	GEARCASE - STANDARD ROTATION
VE175SLESE 1990	GEARCASE - COUNTER ROTATION
VE175SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE175SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE175TXEID 1991	GEARCASE - COUNTER ROTATION
VE175TXEID 1991	GEARCASE - STANDARD ROTATION
VE175TXESE 1990	GEARCASE - COUNTER ROTATION
VE175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE200SLEID 1991	GEARCASE - COUNTER ROTATION
VE200SLEID 1991	GEARCASE - STANDARD ROTATION
VE200SLENS 1992	GEARCASE - COUNTER ROTATION
VE200SLENS 1992	GEARCASE - STANDARD ROTATION
VE200SLESE 1990	GEARCASE - COUNTER ROTATION

VE200SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE200SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE200SLETC 1993	GEARCASE - COUNTER ROTATION
VE200SLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200SLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200SLETF 1993	GEARCASE - COUNTER ROTATION
VE200SLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200SLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TXEIB 1991	GEARCASE - COUNTER ROTATION
VE200TXEIB 1991	GEARCASE - STANDARD ROTATION
VE200TXENE 1992	GEARCASE - COUNTER ROTATION
VE200TXENE 1992	GEARCASE - STANDARD ROTATION
VE200TXESM 1990	GEARCASE - COUNTER ROTATION
VE200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE200TXETD 1993	GEARCASE - COUNTER ROTATION
VE200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TXETF 1993	GEARCASE - COUNTER ROTATION
VE200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TZETD 1993	GEARCASE - COUNTER ROTATION
VE200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE200TZETF 1993	GEARCASE - COUNTER ROTATION
VE200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PLEIC 1991	GEARCASE - COUNTER ROTATION
VE225PLEIC 1991	GEARCASE - STANDARD ROTATION
VE225PLENR 1992	GEARCASE - COUNTER ROTATION
VE225PLENR 1992	GEARCASE - STANDARD ROTATION
VE225PLESS 1990	GEARCASE - COUNTER ROTATION
VE225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225PLETA 1993	GEARCASE - COUNTER ROTATION

VE225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PLETF 1993	GEARCASE - COUNTER ROTATION
VE225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PXEIC 1991	GEARCASE - COUNTER ROTATION
VE225PXEIC 1991	GEARCASE - STANDARD ROTATION
VE225PXENR 1992	GEARCASE - COUNTER ROTATION
VE225PXENR 1992	GEARCASE - STANDARD ROTATION
VE225PXESS 1990	GEARCASE - COUNTER ROTATION
VE225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225PXETA 1993	GEARCASE - COUNTER ROTATION
VE225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PXETF 1993	GEARCASE - COUNTER ROTATION
VE225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PZETA 1993	GEARCASE - COUNTER ROTATION
VE225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225PZETF 1993	GEARCASE - COUNTER ROTATION
VE225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225STLETF 1993	GEARCASE - COUNTER ROTATION
VE225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TLEIC 1991	GEARCASE - COUNTER ROTATION
VE225TLEIC 1991	GEARCASE - STANDARD ROTATION
VE225TLENR 1992	GEARCASE - COUNTER ROTATION
VE225TLENR 1992	GEARCASE - STANDARD ROTATION
VE225TLESS 1990	GEARCASE - COUNTER ROTATION
VE225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225TLETA 1993	GEARCASE - COUNTER ROTATION

VE225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TLETF 1993	GEARCASE - COUNTER ROTATION
VE225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TXEIC 1991	GEARCASE - COUNTER ROTATION
VE225TXEIC 1991	GEARCASE - STANDARD ROTATION
VE225TXENR 1992	GEARCASE - COUNTER ROTATION
VE225TXENR 1992	GEARCASE - STANDARD ROTATION
VE225TXESS 1990	GEARCASE - COUNTER ROTATION
VE225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VE225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VE225TXETA 1993	GEARCASE - COUNTER ROTATION
VE225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TXETF 1993	GEARCASE - COUNTER ROTATION
VE225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TZETA 1993	GEARCASE - COUNTER ROTATION
VE225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VE225TZETF 1993	GEARCASE - COUNTER ROTATION
VE225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VE225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ120TLAIE 1991	GEARCASE - 140TX STANDARD ROTATION
VJ120TLAIE 1991	GEARCASE - 140CX COUNTER ROTATION
VJ120TLAND 1992	GEARCASE - 140TX STANDARD ROTATION
VJ120TLAND 1992	GEARCASE - 140CX COUNTER ROTATION
VJ120TLASB 1990	GEARCASE - 140TX STANDARD ROTATION
VJ120TLASB 1990	GEARCASE - 140CX COUNTER ROTATION
VJ120TLATF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLATF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLATS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLATS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLEIE 1991	GEARCASE - 140TX STANDARD ROTATION

VJ120TLEIE 1991	GEARCASE - 140CX COUNTER ROTATION
VJ120TLEND 1992	GEARCASE - 140TX STANDARD ROTATION
VJ120TLEND 1992	GEARCASE - 140CX COUNTER ROTATION
VJ120TLESB 1990	GEARCASE - 140TX STANDARD ROTATION
VJ120TLESB 1990	GEARCASE - 140CX COUNTER ROTATION
VJ120TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TLETS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TLETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TXEIE 1991	GEARCASE - 140TX STANDARD ROTATION
VJ120TXEIE 1991	GEARCASE - 140CX COUNTER ROTATION
VJ120TXEND 1992	GEARCASE - 140TX STANDARD ROTATION
VJ120TXEND 1992	GEARCASE - 140CX COUNTER ROTATION
VJ120TXESB 1990	GEARCASE - 140TX STANDARD ROTATION
VJ120TXESB 1990	GEARCASE - 140CX COUNTER ROTATION
VJ120TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ120TXETS 1993	GEARCASE - 140CX COUNTER ROTATION
VJ120TXETS 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TLAID 1991	GEARCASE - 140TX STANDARD ROTATION
VJ140TLAID 1991	GEARCASE - 140CX COUNTER ROTATION
VJ140TLANS 1992	GEARCASE - 140TX STANDARD ROTATION
VJ140TLANS 1992	GEARCASE - 140CX COUNTER ROTATION
VJ140TLASE 1990	GEARCASE - 140TX STANDARD ROTATION
VJ140TLASE 1990	GEARCASE - 140CX COUNTER ROTATION
VJ140TLEID 1991	GEARCASE - 140TX STANDARD ROTATION
VJ140TLEID 1991	GEARCASE - 140CX COUNTER ROTATION
VJ140TLENS 1992	GEARCASE - 140TX STANDARD ROTATION
VJ140TLENS 1992	GEARCASE - 140CX COUNTER ROTATION
VJ140TLESE 1990	GEARCASE - 140TX STANDARD ROTATION
VJ140TLESE 1990	GEARCASE - 140CX COUNTER ROTATION
VJ140TLETC 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TLETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TLETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TLETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX

VJ140TXEID 1991	GEARCASE - 140TX STANDARD ROTATION
VJ140TXEID 1991	GEARCASE - 140CX COUNTER ROTATION
VJ140TXENS 1992	GEARCASE - 140TX STANDARD ROTATION
VJ140TXENS 1992	GEARCASE - 140CX COUNTER ROTATION
VJ140TXESE 1990	GEARCASE - 140TX STANDARD ROTATION
VJ140TXESE 1990	GEARCASE - 140CX COUNTER ROTATION
VJ140TXETC 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TXETC 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ140TXETF 1993	GEARCASE - 140CX COUNTER ROTATION
VJ140TXETF 1993	GEARCASE - 140TX STD ROTATION 120TX & 125ESX "F" SUFFIX
VJ150ELANC 1992	GEARCASE - COUNTER ROTATION
VJ150ELANC 1992	GEARCASE - STANDARD ROTATION
VJ150ELATG 1993	GEARCASE - COUNTER ROTATION
VJ150ELATG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELATG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELATR 1993	GEARCASE - COUNTER ROTATION
VJ150ELATR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELATR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELEIS 1991	GEARCASE - COUNTER ROTATION
VJ150ELEIS 1991	GEARCASE - STANDARD ROTATION
VJ150ELENC 1992	GEARCASE - COUNTER ROTATION
VJ150ELENC 1992	GEARCASE - STANDARD ROTATION
VJ150ELETG 1993	GEARCASE - COUNTER ROTATION
VJ150ELETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150ELETR 1993	GEARCASE - COUNTER ROTATION
VJ150ELETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150ELETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150EXEIS 1991	GEARCASE - COUNTER ROTATION
VJ150EXEIS 1991	GEARCASE - STANDARD ROTATION
VJ150EXENC 1992	GEARCASE - COUNTER ROTATION
VJ150EXENC 1992	GEARCASE - STANDARD ROTATION
VJ150EXETG 1993	GEARCASE - COUNTER ROTATION
VJ150EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

VJ150EXETR 1993	GEARCASE - COUNTER ROTATION
VJ150EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150GLEIS 1991	GEARCASE - COUNTER ROTATION
VJ150GLEIS 1991	GEARCASE - STANDARD ROTATION
VJ150GLETG 1993	GEARCASE - COUNTER ROTATION
VJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150GLETR 1993	GEARCASE - COUNTER ROTATION
VJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ150HLEOS 1995	GEARCASE - COUNTER ROTATION
VJ150HLEOS 1995	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ150HLEOS 1995	GEARCASE - STANDARD ROTATION-20" 150SL,175SL -ALL 25" MODELS
VJ150SLEIE 1991	GEARCASE
VJ150SLESB 1990	GEARCASE EARLY PRODUCTION
VJ150SLESB 1990	GEARCASE LATE PRODUCTION
VJ150TLEIE 1991	GEARCASE - COUNTER ROTATION
VJ150TLEIE 1991	GEARCASE - STANDARD ROTATION
VJ150TLESB 1990	GEARCASE - COUNTER ROTATION
VJ150TLESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ150TLESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ150TXEIE 1991	GEARCASE - COUNTER ROTATION
VJ150TXEIE 1991	GEARCASE - STANDARD ROTATION
VJ150TXESB 1990	GEARCASE - COUNTER ROTATION
VJ150TXESB 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ150TXESB 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ175EXEIS 1991	GEARCASE - COUNTER ROTATION
VJ175EXEIS 1991	GEARCASE - STANDARD ROTATION
VJ175EXENC 1992	GEARCASE - COUNTER ROTATION
VJ175EXENC 1992	GEARCASE - STANDARD ROTATION
VJ175EXETG 1993	GEARCASE - COUNTER ROTATION
VJ175EXETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175EXETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS

VJ175EXETR 1993	GEARCASE - COUNTER ROTATION
VJ175EXETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175EXETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175GLEIS 1991	GEARCASE - COUNTER ROTATION
VJ175GLEIS 1991	GEARCASE - STANDARD ROTATION
VJ175GLENC 1992	GEARCASE - COUNTER ROTATION
VJ175GLENC 1992	GEARCASE - STANDARD ROTATION
VJ175GLETG 1993	GEARCASE - COUNTER ROTATION
VJ175GLETG 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175GLETG 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175GLETR 1993	GEARCASE - COUNTER ROTATION
VJ175GLETR 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ175GLETR 1993	GEARCASE - STANDARD ROTATION - 25" MODELS
VJ175SLEID 1991	GEARCASE - COUNTER ROTATION
VJ175SLEID 1991	GEARCASE - STANDARD ROTATION
VJ175SLESE 1990	GEARCASE - COUNTER ROTATION
VJ175SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ175SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ175TXEID 1991	GEARCASE - COUNTER ROTATION
VJ175TXEID 1991	GEARCASE - STANDARD ROTATION
VJ175TXESE 1990	GEARCASE - COUNTER ROTATION
VJ175TXESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ175TXESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ200SLEID 1991	GEARCASE - COUNTER ROTATION
VJ200SLEID 1991	GEARCASE - STANDARD ROTATION
VJ200SLENS 1992	GEARCASE - COUNTER ROTATION
VJ200SLENS 1992	GEARCASE - STANDARD ROTATION
VJ200SLESE 1990	GEARCASE - COUNTER ROTATION
VJ200SLESE 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ200SLESE 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ200SLETC 1993	GEARCASE - COUNTER ROTATION
VJ200SLETC 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200SLETC 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200SLETF 1993	GEARCASE - COUNTER ROTATION
VJ200SLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

VJ200SLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TXEIB 1991	GEARCASE - COUNTER ROTATION
VJ200TXEIB 1991	GEARCASE - STANDARD ROTATION
VJ200TXENE 1992	GEARCASE - COUNTER ROTATION
VJ200TXENE 1992	GEARCASE - STANDARD ROTATION
VJ200TXESM 1990	GEARCASE - COUNTER ROTATION
VJ200TXESM 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ200TXESM 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ200TXETD 1993	GEARCASE - COUNTER ROTATION
VJ200TXETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TXETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TXETF 1993	GEARCASE - COUNTER ROTATION
VJ200TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TZETD 1993	GEARCASE - COUNTER ROTATION
VJ200TZETD 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TZETD 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ200TZETF 1993	GEARCASE - COUNTER ROTATION
VJ200TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ200TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PLEIC 1991	GEARCASE - COUNTER ROTATION
VJ225PLEIC 1991	GEARCASE - STANDARD ROTATION
VJ225PLENR 1992	GEARCASE - COUNTER ROTATION
VJ225PLENR 1992	GEARCASE - STANDARD ROTATION
VJ225PLESS 1990	GEARCASE - COUNTER ROTATION
VJ225PLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225PLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225PLETA 1993	GEARCASE - COUNTER ROTATION
VJ225PLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PLETF 1993	GEARCASE - COUNTER ROTATION
VJ225PLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PXEIC 1991	GEARCASE - COUNTER ROTATION
VJ225PXEIC 1991	GEARCASE - STANDARD ROTATION

VJ225PXENR 1992	GEARCASE - COUNTER ROTATION
VJ225PXENR 1992	GEARCASE - STANDARD ROTATION
VJ225PXESS 1990	GEARCASE - COUNTER ROTATION
VJ225PXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225PXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225PXETA 1993	GEARCASE - COUNTER ROTATION
VJ225PXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PXETF 1993	GEARCASE - COUNTER ROTATION
VJ225PXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PZETA 1993	GEARCASE - COUNTER ROTATION
VJ225PZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225PZETF 1993	GEARCASE - COUNTER ROTATION
VJ225PZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225PZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225STLETF 1993	GEARCASE - COUNTER ROTATION
VJ225STLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225STLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TLASS 1990	GEARCASE - COUNTER ROTATION
VJ225TLASS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225TLASS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225TLEIC 1991	GEARCASE - COUNTER ROTATION
VJ225TLEIC 1991	GEARCASE - STANDARD ROTATION
VJ225TLENR 1992	GEARCASE - COUNTER ROTATION
VJ225TLENR 1992	GEARCASE - STANDARD ROTATION
VJ225TLESS 1990	GEARCASE - COUNTER ROTATION
VJ225TLESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225TLESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225TLETA 1993	GEARCASE - COUNTER ROTATION
VJ225TLETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TLETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TLETF 1993	GEARCASE - COUNTER ROTATION
VJ225TLETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS

VJ225TLETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TXEIC 1991	GEARCASE - COUNTER ROTATION
VJ225TXEIC 1991	GEARCASE - STANDARD ROTATION
VJ225TXENR 1992	GEARCASE - COUNTER ROTATION
VJ225TXENR 1992	GEARCASE - STANDARD ROTATION
VJ225TXESS 1990	GEARCASE - COUNTER ROTATION
VJ225TXESS 1990	GEARCASE - STANDARD ROTATION EARLY PRODUCTION
VJ225TXESS 1990	GEARCASE - STANDARD ROTATION LATE PRODUCTION
VJ225TXETA 1993	GEARCASE - COUNTER ROTATION
VJ225TXETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TXETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TXETF 1993	GEARCASE - COUNTER ROTATION
VJ225TXETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TXETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TZETA 1993	GEARCASE - COUNTER ROTATION
VJ225TZETA 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TZETA 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
VJ225TZETF 1993	GEARCASE - COUNTER ROTATION
VJ225TZETF 1993	GEARCASE - STANDARD ROTATION - 20 IN. MODELS
VJ225TZETF 1993	GEARCASE - STANDARD ROTATION - 25 IN. & 30 IN. MODELS
W100WTLM 1988	GEARCASE
W100WTXM 1988	GEARCASE