

Where Used: Part Number 0389720

Model Name	Diagram
10924B 1979	EXHAUST HOUSING
10925B 1979	EXHAUST HOUSING
10935B 1979	EXHAUST HOUSING
10955B 1979	EXHAUST HOUSING
10EL79B 1979	EXHAUST HOUSING
10R79B 1979	EXHAUST HOUSING
10RL79B 1979	EXHAUST HOUSING
10SEL79B 1979	EXHAUST HOUSING
15904E 1979	EXHAUST HOUSING
15905E 1979	EXHAUST HOUSING
15954E 1979	EXHAUST HOUSING
15955E 1979	EXHAUST HOUSING
15E79E 1979	EXHAUST HOUSING
15EL79E 1979	EXHAUST HOUSING
15R79E 1979	EXHAUST HOUSING
15RL79E 1979	EXHAUST HOUSING
E10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10ECSE 1980	EXHAUST HOUSING
E10ELCID 1981	EXHAUST HOUSING
E10ELCNS 1982	EXHAUST HOUSING
E10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10ELCRA 1984	MIDSECTION (10SEL ONLY)
E10ELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10ELCSE 1980	EXHAUST HOUSING
E10ELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10ELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RCID 1981	EXHAUST HOUSING
E10RCNS 1982	EXHAUST HOUSING
E10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RCRA 1984	MIDSECTION (10SEL ONLY)
E10RCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10RCSE 1980	EXHAUST HOUSING
E10RCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS

E10RCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10RLCID 1981	EXHAUST HOUSING
E10RLCNS 1982	EXHAUST HOUSING
E10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10RLCRA 1984	MIDSECTION (10SEL ONLY)
E10RLCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10RLCSE 1980	EXHAUST HOUSING
E10RLCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10RLCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E10SELCID 1981	EXHAUST HOUSING
E10SELCNS 1982	EXHAUST HOUSING
E10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
E10SELCRA 1984	MIDSECTION (10SEL ONLY)
E10SELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E10SELCSE 1980	EXHAUST HOUSING
E10SELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E10SELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15ECIS 1981	EXHAUST HOUSING
E15ECNC 1982	EXHAUST HOUSING
E15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15ECRM 1984	MIDSECTION (10SEL ONLY)
E15ECRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15ECSD 1980	EXHAUST HOUSING
E15ECTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15ECTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15ELCRM 1984	MIDSECTION (10SEL ONLY)
E15ELCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15ELCSD 1980	EXHAUST HOUSING
E15ELCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15ELCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RCIS 1981	EXHAUST HOUSING
E15RCNC 1982	EXHAUST HOUSING

E15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RCRM 1984	MIDSECTION (10SEL ONLY)
E15RCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15RCSD 1980	EXHAUST HOUSING
E15RCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RLCIS 1981	EXHAUST HOUSING
E15RLCNC 1982	EXHAUST HOUSING
E15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
E15RLCRM 1984	MIDSECTION (10SEL ONLY)
E15RLCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
E15RLCSD 1980	EXHAUST HOUSING
E15RLCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RLCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
E15RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
E15RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10ECOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10ECSE 1980	EXHAUST HOUSING
J10ELCID 1981	EXHAUST HOUSING
J10ELCNS 1982	EXHAUST HOUSING
J10ELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10ELCRA 1984	MIDSECTION (10SEL ONLY)
J10ELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10ELCSE 1980	EXHAUST HOUSING
J10ELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10ELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RCID 1981	EXHAUST HOUSING
J10RCNS 1982	EXHAUST HOUSING
J10RCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RCRA 1984	MIDSECTION (10SEL ONLY)
J10RCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10RCSE 1980	EXHAUST HOUSING
J10RCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS

J10RCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RLCID 1981	EXHAUST HOUSING
J10RLCNS 1982	EXHAUST HOUSING
J10RLCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10RLCRA 1984	MIDSECTION (10SEL ONLY)
J10RLCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10RLCSE 1980	EXHAUST HOUSING
J10RLCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RLCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J10SELCID 1981	EXHAUST HOUSING
J10SELCNS 1982	EXHAUST HOUSING
J10SELCOM 1985	STEERING HANDLE & THROTTLE CONTROL
J10SELCRA 1984	MIDSECTION (10SEL ONLY)
J10SELCRA 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J10SELCSE 1980	EXHAUST HOUSING
J10SELCTC 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J10SELCTC 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15ECIS 1981	EXHAUST HOUSING
J15ECNC 1982	EXHAUST HOUSING
J15ECOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15ECRM 1984	MIDSECTION (10SEL ONLY)
J15ECRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15ECSD 1980	EXHAUST HOUSING
J15ECTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15ECTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15ELCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15ELCRM 1984	MIDSECTION (10SEL ONLY)
J15ELCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15ELCSD 1980	EXHAUST HOUSING
J15ELCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15ELCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS

J15RCIS 1981	EXHAUST HOUSING
J15RCNC 1982	EXHAUST HOUSING
J15RCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RCRM 1984	MIDSECTION (10SEL ONLY)
J15RCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15RCSD 1980	EXHAUST HOUSING
J15RCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RLCIS 1981	EXHAUST HOUSING
J15RLCNC 1982	EXHAUST HOUSING
J15RLCOB 1985	STEERING HANDLE & THROTTLE CONTROL
J15RLCRM 1984	MIDSECTION (10SEL ONLY)
J15RLCRM 1984	MIDSECTION (ALL MODELS EXCEPT SEL)
J15RLCSD 1980	EXHAUST HOUSING
J15RLCTA 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RLCTA 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS
J15RLCTR 1983	EXHAUST HOUSING 9.9 "R" MODELS,15 ELECT START & "A" MODELS
J15RLCTR 1983	EXHAUST HOUSING-9.9"C" MODELS,15 ROPE "R" MODELS